

Device support list: UniMax(ChipMax2)

Manufacturer	Device	Package	Pin	Adapter	Manufacturer	Device	Package	Pin	Adapter
ALLIANCE	AS29F040	DIP	32	Not use adapter	ALLIANCE	AS29LV800B	SOP	44	PA44SO44D
ALLIANCE	AS29LV800B	TSOP	48	PA48TS48D	ALLIANCE	AS29LV800T	TSOP	48	PA48TS48D
ALLIANCE	AS29LV800T	SOP	44	PA44SO44D	ALTERA	EP330	DIP	20	Not use adapter
ALTERA	EP900	DIP	40	Not use adapter	ALTERA	EP900I	DIP	40	Not use adapter
ALTERA	EP910	DIP	40	Not use adapter	ALTERA	EP910I	DIP	40	Not use adapter
ALTERA	EPM3032A	PLCC	44	PA44-48U	ALTERA	EPM3032A	TQFP	44	PA44QF44D
ALTERA	EPM3064A	PLCC	44	PA44-48U	ALTERA	EPM3064A	TQFP	100	PA100TQ48D
ALTERA	EPM3064A	TQFP	44	PA44QF44D	ALTERA	EPM3128A	TQFP	100	PA100TQ48D
ALTERA	EPM7032	PLCC	44	PA44-48U	ALTERA	EPM7032AE as 7032	PLCC	44	PA44-48U
ALTERA	EPM7032AE as 7032S	PLCC	44	PA44-48U	ALTERA	EPM7032V	PLCC	44	PA44-48U
ALTERA	EPM7064	PLCC	68	PA7064/96-68LC	ALTERA	EPM7064	PLCC	84	PA84-40A
ALTERA	EPM7064	PLCC	68	PA68-40A	ALTERA	EPM7064	PLCC	44	PA44-40F
ALTERA	EPM7064	PLCC	44	PA44-48U	ALTERA	EPM7064	PLCC	84	PA7064/96-84LC
ALTERA	EPM7064AE	PLCC	44	PA44-48U	ALTERA	EPM7064AE	TQFP	44	PA44QF44D
ALTERA	EPM7064AE as 7064	PLCC	44	PA44-48U	ALTERA	EPM7064AE as 7064	TQFP	44	PA44QF44D
ALTERA	EPM7064AE as 7064S	PLCC	44	PA44-48U	ALTERA	EPM7064AE as 7064S	TQFP	44	PA44QF44D
ALTERA	EPM7096	PLCC	84	PA84-40B	ALTERA	EPM7096	PLCC	68	PA68-40B
ALTERA	EPM7096	PLCC	84	PA7064/96-84LC	ALTERA	EPM7096	PLCC	68	PA7064/96-68LC
AMD	8751H	DIP	40	Not use adapter	AMD	8753H	DIP	40	Not use adapter
AMD	87C51	DIP	40	Not use adapter	AMD	87C521	DIP	40	Not use adapter
AMD	87C521T2	DIP	40	Not use adapter	AMD	87C541	DIP	40	Not use adapter
AMD	Am27128	DIP	28	Not use adapter	AMD	Am27128	PLCC	32	PA32-28
AMD	Am27128A	DIP	28	Not use adapter	AMD	Am27128A	PLCC	32	PA32-28
AMD	Am2716	DIP	24	Not use adapter	AMD	Am2716B	DIP	24	Not use adapter
AMD	Am27256	DIP	28	Not use adapter	AMD	Am27256	PLCC	32	PA32-28
AMD	Am2732	DIP	24	Not use adapter	AMD	Am2732A	DIP	24	Not use adapter
AMD	Am2732B	DIP	24	Not use adapter	AMD	Am27512	DIP	28	Not use adapter
AMD	Am2764	DIP	28	Not use adapter	AMD	Am2764	PLCC	32	PA32-28
AMD	Am2764A	DIP	28	Not use adapter	AMD	Am2764A	PLCC	32	PA32-28
AMD	Am27C010	DIP	32	Not use adapter	AMD	Am27C020	DIP	32	Not use adapter
AMD	Am27C040	DIP	32	Not use adapter	AMD	Am27C1024	DIP	40	Not use adapter
AMD	Am27C1024	PLCC	44	PA44-48U	AMD	Am27C128	DIP	28	Not use adapter
AMD	Am27C128	PLCC	32	PA32-28	AMD	Am27C2048	PLCC	44	PA44-48U
AMD	Am27C2048	DIP	40	Not use adapter	AMD	Am27C256	DIP	28	Not use adapter
AMD	Am27C256	PLCC	32	PA32-28	AMD	Am27C4096	PLCC	44	PA44-48U
AMD	Am27C4096	DIP	40	Not use adapter	AMD	Am27C512	DIP	28	Not use adapter
AMD	Am27C64	DIP	28	Not use adapter	AMD	Am27C64	PLCC	32	PA32-28
AMD	Am27C800	PLCC	44	PA44-48U	AMD	Am27C800	DIP	42	Not use adapter
AMD	Am27H010	DIP	32	Not use adapter	AMD	Am27H256	DIP	28	Not use adapter
AMD	Am27H256	PLCC	32	PA32-28	AMD	Am27HB010	DIP	32	Not use adapter
AMD	Am27LV010B	DIP	32	Not use adapter	AMD	Am2817A	DIP	28	Not use adapter
AMD	Am2864A	DIP	28	Not use adapter	AMD	Am2864AE	DIP	28	Not use adapter
AMD	Am2864B	DIP	28	Not use adapter	AMD	Am2864BE	DIP	28	Not use adapter
AMD	Am28F010	DIP	32	Not use adapter	AMD	Am28F010	PLCC	32	PA32PL32D
AMD	Am28F020	DIP	32	Not use adapter	AMD	Am28F020	PLCC	32	PA32PL32D
AMD	Am28F256	DIP	32	Not use adapter	AMD	Am28F256	PLCC	32	PA32PL32D
AMD	Am28F512	DIP	32	Not use adapter	AMD	Am28F512	PLCC	32	PA32PL32D
AMD	Am29BL802CB	SSOP	56	PA56SS48DA	AMD	Am29DL162CB	TSOP	48	PA48TS48D
AMD	Am29DL162CT	TSOP	48	PA48TS48D	AMD	Am29DL162DB	BGA	48	HA48BGA48DAO
AMD	Am29DL162DT	BGA	48	HA48BGA48DAO	AMD	Am29DL163CB	TSOP	48	PA48TS48D
AMD	Am29DL163CT	TSOP	48	PA48TS48D	AMD	Am29DL164DB	TSOP	48	PA48TS48D
AMD	Am29DL164DT	TSOP	48	PA48TS48D	AMD	Am29DL316CB	TSOP	40	PA40TS40D
AMD	Am29DL316CT	TSOP	40	PA40TS40D	AMD	Am29DL322CB	TSOP	48	PA48TS48D
AMD	Am29DL322CT	TSOP	48	PA48TS48D	AMD	Am29DL322DB	TSOP	48	PA48TS48D
AMD	Am29DL322DT	TSOP	48	PA48TS48D	AMD	Am29DL323CB	TSOP	48	PA48TS48D
AMD	Am29DL323CT	TSOP	48	PA48TS48D	AMD	Am29DL323DB	TSOP	48	PA48TS48D
AMD	Am29DL323DT	TSOP	48	PA48TS48D	AMD	Am29DL323GB	TSOP	48	PA48TS48D
AMD	Am29DL323GT	TSOP	48	PA48TS48D	AMD	Am29DL324DB	TSOP	48	PA48TS48D
AMD	Am29DL324DT	TSOP	48	PA48TS48D	AMD	Am29DL400BB	SOP	44	PA44SO44D
AMD	Am29DL400BB	TSOP	48	PA48TS48D	AMD	Am29DL400BT	TSOP	48	PA48TS48D
AMD	Am29DL400BT	SOP	44	PA44SO44D	AMD	Am29DL640D	TSOP	48	PA48TS48D
AMD	Am29DL640G	TSOP	48	PA48TS48D	AMD	Am29DL800BB	SOP	44	PA44SO44D
AMD	Am29DL800BB	TSOP	48	PA48TS48D	AMD	Am29DL800BT	SOP	44	PA44SO44D
AMD	Am29DL800BT	TSOP	48	PA48TS48D	AMD	Am29F002B	PLCC	32	PA32PL32D
AMD	Am29F002B	DIP	32	Not use adapter	AMD	Am29F002B	TSOP	32	PA32TS14/PA32TS32D-14
AMD	Am29F002BB	PLCC	32	PA32PL32D	AMD	Am29F002BB	DIP	32	Not use adapter
AMD	Am29F002BB	TSOP	32	PA32TS14/PA32TS32D-14	AMD	Am29F002BT	PLCC	32	PA32PL32D
AMD	Am29F002BT	DIP	32	Not use adapter	AMD	Am29F002BT	TSOP	32	PA32TS14/PA32TS32D-14
AMD	Am29F002NB	PLCC	32	PA32PL32D	AMD	Am29F002NB	DIP	32	Not use adapter
AMD	Am29F002NB	TSOP	32	PA32TS14/PA32TS32D-14	AMD	Am29F002NBB	DIP	32	Not use adapter
AMD	Am29F002NBB	PLCC	32	PA32PL32D	AMD	Am29F002NBB	TSOP	32	PA32TS14/PA32TS32D-14
AMD	Am29F002NBT	PLCC	32	PA32PL32D	AMD	Am29F002NBT	DIP	32	Not use adapter

AMD	Am29F002NBT	TSOP	32	PA32TS14/PA32TS32D-14	AMD	Am29F002NT	PLCC	32	PA32PL32D
AMD	Am29F002NT	DIP	32	Not use adapter	AMD	Am29F002NT	TSOP	32	PA32TS14/PA32TS32D-14
AMD	Am29F002T	DIP	32	Not use adapter	AMD	Am29F002T	PLCC	32	PA32PL32D
AMD	Am29F002T	TSOP	32	PA32TS14/PA32TS32D-14	AMD	Am29F004BB	DIP	32	Not use adapter
AMD	Am29F004BB	PLCC	32	PA32PL32D	AMD	Am29F004BB	TSOP	32	PA32TS14/PA32TS32D-14
AMD	Am29F004BT	DIP	32	Not use adapter	AMD	Am29F004BT	PLCC	32	PA32PL32D
AMD	Am29F004BT	TSOP	32	PA32TS14/PA32TS32D-14	AMD	Am29F010	DIP	32	Not use adapter
AMD	Am29F010	PLCC	32	PA32PL32D	AMD	Am29F010	TSOP	32	PA32TS14/PA32TS32D-14
AMD	Am29F010A	DIP	32	Not use adapter	AMD	Am29F010A	PLCC	32	PA32PL32D
AMD	Am29F010A	TSOP	32	PA32TS14/PA32TS32D-14	AMD	Am29F010B	DIP	32	Not use adapter
AMD	Am29F010B	PLCC	32	PA32PL32D	AMD	Am29F010B	TSOP	32	PA32TS14/PA32TS32D-14
AMD	Am29F016	TSOP	48	PA48TS48D	AMD	Am29F016B	SOP	44	PA44SO44D
AMD	Am29F016B	TSOP	48	PA48TS48D	AMD	Am29F016B	TSOP	40	PA40TS40D
AMD	Am29F017B	TSOP	48	PA48TS48D	AMD	Am29F017B	TSOP	40	PA40TS40D
AMD	Am29F017D	TSOP	48	PA48TS48D	AMD	Am29F017D	TSOP	40	PA40TS40D
AMD	Am29F032B	SOP	44	PA44SO44D	AMD	Am29F032B	TSOP	40	PA40TS40D
AMD	Am29F032B	DIP	40	R.F.53432101	AMD	Am29F040B	PLCC	32	PA32PL32D
AMD	Am29F040B	DIP	32	Not use adapter	AMD	Am29F040B	TSOP	32	PA32TS14/PA32TS32D-14
AMD	Am29F080	SOP	44	PA44SO44D	AMD	Am29F080	TSOP	40	PA40TS40D
AMD	Am29F080B	SOP	44	PA44SO44D	AMD	Am29F080B	TSOP	40	PA40TS40D
AMD	Am29F100B	TSOP	48	PA48TS48D	AMD	Am29F100B	SOP	44	PA44SO44D
AMD	Am29F100T	TSOP	48	PA48TS48D	AMD	Am29F100T	SOP	44	PA44SO44D
AMD	Am29F160DB	TSOP	48	PA48TS48D	AMD	Am29F160DT	TSOP	48	PA48TS48D
AMD	Am29F200AB	SOP	44	PA44SO44D	AMD	Am29F200AB	TSOP	48	PA48TS48D
AMD	Am29F200AT	SOP	44	PA44SO44D	AMD	Am29F200AT	TSOP	48	PA48TS48D
AMD	Am29F200B	TSOP	48	PA48TS48D	AMD	Am29F200B	SOP	44	PA44SO44D
AMD	Am29F200BB	TSOP	48	PA48TS48D	AMD	Am29F200BB	SOP	44	PA44SO44D
AMD	Am29F200BT	TSOP	48	PA48TS48D	AMD	Am29F200BT	SOP	44	PA44SO44D
AMD	Am29F200T	SOP	44	PA44SO44D	AMD	Am29F200T	TSOP	48	PA48TS48D
AMD	Am29F400AB	TSOP	48	PA48TS48D	AMD	Am29F400AB	SOP	44	PA44SO44D
AMD	Am29F400AT	TSOP	48	PA48TS48D	AMD	Am29F400AT	SOP	44	PA44SO44D
AMD	Am29F400B	SOP	44	PA44SO44D	AMD	Am29F400B	TSOP	48	PA48TS48D
AMD	Am29F400BB	TSOP	48	PA48TS48D	AMD	Am29F400BB	SOP	44	PA44SO44D
AMD	Am29F400BT	TSOP	48	PA48TS48D	AMD	Am29F400BT	SOP	44	PA44SO44D
AMD	Am29F400T	SOP	44	PA44SO44D	AMD	Am29F400T	TSOP	48	PA48TS48D
AMD	Am29F800AB	TSOP	48	PA48TS48D	AMD	Am29F800AB	SOP	44	PA44SO44D
AMD	Am29F800AT	SOP	44	PA44SO44D	AMD	Am29F800AT	TSOP	48	PA48TS48D
AMD	Am29F800B	TSOP	48	PA48TS48D	AMD	Am29F800B	SOP	44	PA44SO44D
AMD	Am29F800BB	TSOP	48	PA48TS48D	AMD	Am29F800BB	SOP	44	PA44SO44D
AMD	Am29F800BT	SOP	44	PA44SO44D	AMD	Am29F800BT	TSOP	48	PA48TS48D
AMD	Am29F800T	TSOP	48	PA48TS48D	AMD	Am29F800T	SOP	44	PA44SO44D
AMD	Am29LV001BB	DIP	32	Not use adapter	AMD	Am29LV001BT	DIP	32	Not use adapter
AMD	Am29LV002B	TSOP	40	PA40TS40D	AMD	Am29LV002T	TSOP	40	PA40TS40D
AMD	Am29LV004B	TSOP	40	PA40TS40D	AMD	Am29LV004T	TSOP	40	PA40TS40D
AMD	Am29LV008B	TSOP	40	PA40TS40D	AMD	Am29LV008BB	TSOP	40	PA40TS40D
AMD	Am29LV008BT	TSOP	40	PA40TS40D	AMD	Am29LV008T	TSOP	40	PA40TS40D
AMD	Am29LV010B	DIP	32	Not use adapter	AMD	Am29LV017B	TSOP	40	PA40TS40D
AMD	Am29LV017D	TSOP	40	PA40TS40D	AMD	Am29LV033C	TSOP	40	PA40TS40D
AMD	Am29LV040B	DIP	32	Not use adapter	AMD	Am29LV065D	TSOP	48	PA40TS40D
AMD	Am29LV081	TSOP	40	PA40TS40D	AMD	Am29LV081B	TSOP	40	PA40TS40D
AMD	Am29LV116BB	TSOP	40	PA40TS40D	AMD	Am29LV116BT	TSOP	40	PA40TS40D
AMD	Am29LV116DB	TSOP	40	PA40TS40D	AMD	Am29LV116DT	TSOP	40	PA40TS40D
AMD	Am29LV128MH	TSOP	56	PA56TS48DB	AMD	Am29LV128ML	TSOP	56	PA56TS48DB
AMD	Am29LV160BB	SOP	44	PA44SO44D	AMD	Am29LV160BB	TSOP	48	PA48TS48D
AMD	Am29LV160BT	SOP	44	PA44SO44D	AMD	Am29LV160BT	TSOP	48	PA48TS48D
AMD	Am29LV160DB	SOP	44	PA44SO44D	AMD	Am29LV160DB	TSOP	48	PA48TS48D
AMD	Am29LV160DT	SOP	44	PA44SO44D	AMD	Am29LV160DT	TSOP	48	PA48TS48D
AMD	Am29LV200B	SOP	44	PA44SO44D	AMD	Am29LV200B	TSOP	48	PA48TS48D
AMD	Am29LV200BB	TSOP	48	PA48TS48D	AMD	Am29LV200BB	SOP	44	PA44SO44D
AMD	Am29LV200BT	SOP	44	PA44SO44D	AMD	Am29LV200BT	TSOP	48	PA48TS48D
AMD	Am29LV200T	TSOP	48	PA48TS48D	AMD	Am29LV200T	SOP	44	PA44SO44D
AMD	Am29LV256MH	TSOP	56	PA56TS48DC	AMD	Am29LV256ML	TSOP	56	PA56TS48DC
AMD	Am29LV320DB	TSOP	48	PA48TS48D	AMD	Am29LV320DT	TSOP	48	PA48TS48D
AMD	Am29LV320MB	TSOP	48	PA48TS48D1	AMD	Am29LV320MT	TSOP	48	PA48TS48D1
AMD	Am29LV400B	TSOP	48	PA48TS48D	AMD	Am29LV400B	SOP	44	PA44SO44D
AMD	Am29LV400BB	SOP	44	PA44SO44D	AMD	Am29LV400BB	TSOP	48	PA48TS48D
AMD	Am29LV400BB	BGA	48	PA48BG48DW	AMD	Am29LV400BT	TSOP	48	PA48TS48D
AMD	Am29LV400BT	SOP	44	PA44SO44D	AMD	Am29LV400BT	BGA	48	PA48BG48DW
AMD	Am29LV400T	SOP	44	PA44SO44D	AMD	Am29LV400T	TSOP	48	PA48TS48D
AMD	Am29LV640MB	TSOP	48	PA48TS48D	AMD	Am29LV640MT	TSOP	48	PA48TS48D
AMD	Am29LV641DH	TSOP	48	PA48TS48D	AMD	Am29LV641DL	TSOP	48	PA48TS48D
AMD	Am29LV641MH	TSOP	48	PA48TS48D	AMD	Am29LV641ML	TSOP	48	PA48TS48D
AMD	Am29LV800B	TSOP	48	PA48TS48D	AMD	Am29LV800B	SOP	44	PA44SO44D
AMD	Am29LV800BB	SOP	44	PA44SO44D	AMD	Am29LV800BB	TSOP	48	PA48TS48D

AMD	Am29LV800BB	BGA	48	HA48BG48DAP	AMD	Am29LV800BT	SOP	44	PA44SO44D
AMD	Am29LV800BT	TSOP	48	PA48TS48D	AMD	Am29LV800DB	BGA	48	HA48BG48DAP
AMD	Am29LV800DB	SOP	44	PA44SO44D	AMD	Am29LV800DT	TSOP	48	PA48TS48D
AMD	Am29LV800DB	BGA	48	HA48BG48DAP	AMD	Am29LV800DT	TSOP	48	PA48TS48D
AMD	Am29LV800DT	SOP	44	PA44SO44D	AMD	Am29LV800T	BGA	48	HA48BG48DAP
AMD	Am29LV800T	SOP	44	PA44SO44D	AMD	Am29LV800T	TSOP	48	PA48TS48D
AMD	Am29PL160CB	TSOP	48	PA48TS48D	AMD	Am29PL160CB	SOP	44	PA44SO44D
AMD	Am29PL160CT	TSOP	48	PA48TS48D	AMD	Am29PL160CT	SOP	44	PA44SO44D
AMD	Am29SL160BB	TSOP	48	PA48TS48D	AMD	Am29SL160BT	TSOP	48	PA48TS48D
AMD	Am29SL160CB	TSOP	48	PA48TS48D	AMD	Am29SL160CT	TSOP	48	PA48TS48D
AMD	Am29SL800CB	TSOP	48	PA48TS48D	AMD	Am29SL800CT	TSOP	48	PA48TS48D
AMD	Am29SL800DB	TSOP	48	PA48TS48D	AMD	Am29SL800DT	TSOP	48	PA48TS48D
AMD	Am42DL640AG	BGA	73	PA73BGA48DC-YO-8X11.6	AMD	Am45DL6408G	BGA	73	PA73BGA48DC-YO-8X11.6
AMD	Am49DL640BG	BGA	73	PA73BGA48DC-YO-8X11.6	AMD	Am50DL128BG	BGA	73	PA73BGA48DC-YO-8X11.6
AMD	Am50DL128CG	BGA	88	PA88BG48DB-WO-11.6X8	AMD	Am50DL128CH	BGA	88	PA88BG48DB-WO-11.6X8
AMD	Am50DL9608BG	BGA	73	PA73BGA48DC-YO-8X11.6	AMD	Am50PDL193BH	BGA	73	PA73BG48DG
AMD	Am50PDL193CH	BGA	73	PA73BG48DG	AMD	AmPAL20L10-20	DIP	24	Not use adapter
AMD	AmPAL20L10-20	PLCC	28	PA28-24-2P6	AMD	AmPAL20L10A	DIP	24	Not use adapter
AMD	AmPAL20L10A	PLCC	28	PA28-24-2P6	AMD	AmPAL20L10B	DIP	24	Not use adapter
AMD	AmPAL20L10B	PLCC	28	PA28-24-2P6	AMD	PAL20L8-10/2	DIP	24	Not use adapter
AMD	PAL20L8-10/2	PLCC	28	PA28-24-2P6	AMD	PAL20L8-5	DIP	24	Not use adapter
AMD	PAL20L8-5	PLCC	28	PA28-24-2P6	AMD	PAL20L8-7	DIP	24	Not use adapter
AMD	PAL20L8-7	PLCC	28	PA28-24-2P6	AMD	PAL20R4-10/2	DIP	24	Not use adapter
AMD	PAL20R4-10/2	PLCC	28	PA28-24-2P6	AMD	PAL20R4-5	DIP	24	Not use adapter
AMD	PAL20R4-5	PLCC	28	PA28-24-2P6	AMD	PAL20R4-7	DIP	24	Not use adapter
AMD	PAL20R4-7	PLCC	28	PA28-24-2P6	AMD	PAL20R6-10/2	DIP	24	Not use adapter
AMD	PAL20R6-10/2	PLCC	28	PA28-24-2P6	AMD	PAL20R6-5	DIP	24	Not use adapter
AMD	PAL20R6-5	PLCC	28	PA28-24-2P6	AMD	PAL20R6-7	DIP	24	Not use adapter
AMD	PAL20R6-7	PLCC	28	PA28-24-2P6	AMD	PAL20R8-10/2	DIP	24	Not use adapter
AMD	PAL20R8-10/2	PLCC	28	PA28-24-2P6	AMD	PAL20R8-5	DIP	24	Not use adapter
AMD	PAL20R8-5	PLCC	28	PA28-24-2P6	AMD	PAL20R8-7	DIP	24	Not use adapter
AMD	PAL20R8-7	PLCC	28	PA28-24-2P6	AMD	PALCE16V8H	DIP	20	Not use adapter
AMD	PALCE16V8H	PLCC	20	PA20LC20D	AMD	PALCE16V8H	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 10H8	DIP	20	Not use adapter	AMD	PALCE16V8H as 10H8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 10H8	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 10L8	DIP	20	Not use adapter
AMD	PALCE16V8H as 10L8	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 10L8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 10P8	DIP	20	Not use adapter	AMD	PALCE16V8H as 10P8	PLCC	20	PA20LC20D
AMD	PALCE16V8H as 10P8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8H as 12H6	DIP	20	Not use adapter
AMD	PALCE16V8H as 12H6	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8H as 12H6	PLCC	20	PA20LC20D
AMD	PALCE16V8H as 12L6	DIP	20	Not use adapter	AMD	PALCE16V8H as 12L6	PLCC	20	PA20LC20D
AMD	PALCE16V8H as 12L6	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8H as 12P6	DIP	20	Not use adapter
AMD	PALCE16V8H as 12P6	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 12P6	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 14H4	DIP	20	Not use adapter	AMD	PALCE16V8H as 14H4	PLCC	20	PA20LC20D
AMD	PALCE16V8H as 14H4	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8H as 14L4	DIP	20	Not use adapter
AMD	PALCE16V8H as 14L4	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8H as 14L4	PLCC	20	PA20LC20D
AMD	PALCE16V8H as 14P4	DIP	20	Not use adapter	AMD	PALCE16V8H as 14P4	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 14P4	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16H2	DIP	20	Not use adapter
AMD	PALCE16V8H as 16H2	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16H2	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16H8	DIP	20	Not use adapter	AMD	PALCE16V8H as 16H8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16H8	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16L2	DIP	20	Not use adapter
AMD	PALCE16V8H as 16L2	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16L2	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16L8	DIP	20	Not use adapter	AMD	PALCE16V8H as 16L8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16L8	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16P2	DIP	20	Not use adapter
AMD	PALCE16V8H as 16P2	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16P2	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16P8	DIP	20	Not use adapter	AMD	PALCE16V8H as 16P8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16P8	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16R4	DIP	20	Not use adapter
AMD	PALCE16V8H as 16R4	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8H as 16R4	PLCC	20	PA20LC20D
AMD	PALCE16V8H as 16R6	DIP	20	Not use adapter	AMD	PALCE16V8H as 16R6	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16R6	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16R8	DIP	20	Not use adapter
AMD	PALCE16V8H as 16R8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8H as 16R8	PLCC	20	PA20LC20D
AMD	PALCE16V8H as 16RP4	DIP	20	Not use adapter	AMD	PALCE16V8H as 16RP4	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16RP4	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16RP6	DIP	20	Not use adapter
AMD	PALCE16V8H as 16RP6	PLCC	20	PA20LC20D	AMD	PALCE16V8H as 16RP6	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16RP8	DIP	20	Not use adapter	AMD	PALCE16V8H as 16RP8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8H as 16RP8	PLCC	20	PA20LC20D	AMD	PALCE16V8Q	DIP	20	Not use adapter
AMD	PALCE16V8Q	PLCC	20	PA20LC20D	AMD	PALCE16V8Q	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8Q as 10H8	DIP	20	Not use adapter	AMD	PALCE16V8Q as 10H8	PLCC	20	PA20LC20D
AMD	PALCE16V8Q as 10H8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8Q as 10L8	DIP	20	Not use adapter
AMD	PALCE16V8Q as 10L8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8Q as 10L8	PLCC	20	PA20LC20D
AMD	PALCE16V8Q as 10P8	DIP	20	Not use adapter	AMD	PALCE16V8Q as 10P8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALCE16V8Q as 10P8	PLCC	20	PA20LC20D	AMD	PALCE16V8Q as 12H6	DIP	20	Not use adapter
AMD	PALCE16V8Q as 12H6	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8Q as 12H6	PLCC	20	PA20LC20D
AMD	PALCE16V8Q as 12L6	DIP	20	Not use adapter	AMD	PALCE16V8Q as 12L6	PLCC	20	PA20LC20D
AMD	PALCE16V8Q as 12L6	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALCE16V8Q as 12P6	DIP	20	Not use adapter

AMD	PALLV16V8 as 16P8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8 as 16P8	PLCC	20	PA20LC20D
AMD	PALLV16V8 as 16R4	DIP	20	Not use adapter	AMD	PALLV16V8 as 16R4	PLCC	20	PA20LC20D
AMD	PALLV16V8 as 16R4	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8 as 16R6	DIP	20	Not use adapter
AMD	PALLV16V8 as 16R6	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8 as 16R6	PLCC	20	PA20LC20D
AMD	PALLV16V8 as 16R8	DIP	20	Not use adapter	AMD	PALLV16V8 as 16R8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8 as 16R8	PLCC	20	PA20LC20D	AMD	PALLV16V8 as 16RP4	DIP	20	Not use adapter
AMD	PALLV16V8 as 16RP4	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8 as 16RP4	PLCC	20	PA20LC20D
AMD	PALLV16V8 as 16RP6	DIP	20	Not use adapter	AMD	PALLV16V8 as 16RP6	PLCC	20	PA20LC20D
AMD	PALLV16V8 as 16RP6	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8 as 16RP8	DIP	20	Not use adapter
AMD	PALLV16V8 as 16RP8	PLCC	20	PA20LC20D	AMD	PALLV16V8 as 16RP8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z	DIP	20	Not use adapter	AMD	PALLV16V8Z	PLCC	20	PA20LC20D
AMD	PALLV16V8Z	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 10H8	DIP	20	Not use adapter
AMD	PALLV16V8Z as 10H8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 10H8	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 10L8	DIP	20	Not use adapter	AMD	PALLV16V8Z as 10L8	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 10L8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 10P8	DIP	20	Not use adapter
AMD	PALLV16V8Z as 10P8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 10P8	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 12H6	DIP	20	Not use adapter	AMD	PALLV16V8Z as 12H6	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 12H6	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 12L6	DIP	20	Not use adapter
AMD	PALLV16V8Z as 12L6	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 12L6	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 12P6	DIP	20	Not use adapter	AMD	PALLV16V8Z as 12P6	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 12P6	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 14H4	DIP	20	Not use adapter
AMD	PALLV16V8Z as 14H4	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 14H4	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 14L4	DIP	20	Not use adapter	AMD	PALLV16V8Z as 14L4	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 14L4	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 14P4	DIP	20	Not use adapter
AMD	PALLV16V8Z as 14P4	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 14P4	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 16H2	DIP	20	Not use adapter	AMD	PALLV16V8Z as 16H2	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 16H2	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 16H8	DIP	20	Not use adapter
AMD	PALLV16V8Z as 16H8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 16H8	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 16L2	DIP	20	Not use adapter	AMD	PALLV16V8Z as 16L2	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 16L2	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 16L8	DIP	20	Not use adapter
AMD	PALLV16V8Z as 16L8	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 16L8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 16P2	DIP	20	Not use adapter	AMD	PALLV16V8Z as 16P2	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 16P2	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 16P8	DIP	20	Not use adapter
AMD	PALLV16V8Z as 16P8	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 16P8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 16R4	DIP	20	Not use adapter	AMD	PALLV16V8Z as 16R4	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 16R4	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 16R6	DIP	20	Not use adapter
AMD	PALLV16V8Z as 16R6	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 16R6	PLCC	20	PA20LC20D
AMD	PALLV16V8Z as 16R8	DIP	20	Not use adapter	AMD	PALLV16V8Z as 16R8	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 16R8	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 16RP4	DIP	20	Not use adapter
AMD	PALLV16V8Z as 16RP4	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 16RP4	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 16RP6	DIP	20	Not use adapter	AMD	PALLV16V8Z as 16RP6	SOIC	20	PA20SO2006-200/PA20SO20D
AMD	PALLV16V8Z as 16RP6	PLCC	20	PA20LC20D	AMD	PALLV16V8Z as 16RP8	DIP	20	Not use adapter
AMD	PALLV16V8Z as 16RP8	SOIC	20	PA20SO2006-200/PA20SO20D	AMD	PALLV16V8Z as 16RP8	PLCC	20	PA20LC20D
AMD	PALLV22V10	DIP	24	Not use adapter	AMD	PALLV22V10	PLCC	28	PA28PL28D
AMD	PALLV22V10Z	DIP	24	Not use adapter	AMD	PALLV22V10Z	PLCC	28	PA28PL28D
AMI	PEEL18CV8	DIP	20	Not use adapter	AMI	PEEL18CV8	TSSOP	20	PA20SS-P54
AMI	PEEL18CV8	PLCC	20	PA20LC20D	AMI	PEEL18CV8	SOIC	20	PA28SO1-08-06
AMI	PEEL22CV10	DIP	24	Not use adapter	AMI	PEEL22CV10	SOIC	24	PA28SO28D-EO-300
AMI	PEEL22CV10	PLCC	28	PA28PL28D	AMI	PEEL22CV10A	DIP	24	Not use adapter
AMI	PEEL22CV10A	TSSOP	24	PA24TSS24D(M)	AMI	PEEL22CV10A	SOIC	24	PA28SO28D-EO-300
AMI	PEEL22CV10A	PLCC	28	PA28PL28D	AMI	PEEL22CV10A+	DIP	24	Not use adapter
AMI	PEEL22CV10A+	SOIC	24	PA28SO28D-EO-300	AMI	PEEL22CV10A+	TSSOP	24	PA24TSS24D(M)
AMI	PEEL22CV10A+	PLCC	28	PA28PL28D	AMI	PEEL22CV10A++	DIP	24	Not use adapter
AMI	PEEL22CV10A++	PLCC	28	PA28PL28D	AMI	PEEL22CV10A++	SOIC	24	PA28SO28D-EO-300
AMI	PEEL22CV10A++	TSSOP	24	PA24TSS24D(M)	AMI	PEEL22CV10AZ+	DIP	24	Not use adapter
AMI	PEEL22CV10AZ+	SOIC	24	PA28SO28D-EO-300	AMI	PEEL22CV10AZ+	PLCC	28	PA28PL28D
AMI	PEEL22CV10AZ+	TSSOP	24	PA24TSS24D(M)	AMI	PEEL22CV10Z	DIP	24	Not use adapter
AMI	PEEL22CV10Z	PLCC	28	PA28PL28D	AMI	PEEL22CV10Z	SOIC	24	PA28SO28D-EO-300
AMIC	A27020	DIP	32	Not use adapter	AMIC	A27020L	PLCC	32	PA32PL32D
AMIC	A276308A	DIP	28	Not use adapter	AMIC	A276308AL	PLCC	32	PA32-28
AMIC	A290011T	DIP	32	Not use adapter	AMIC	A290011U	DIP	32	Not use adapter
AMIC	A29001T	DIP	32	Not use adapter	AMIC	A29001U	DIP	32	Not use adapter
AMIC	A290021T	DIP	32	Not use adapter	AMIC	A290021U	DIP	32	Not use adapter
AMIC	A29002T	DIP	32	Not use adapter	AMIC	A29002U	DIP	32	Not use adapter
AMIC	A29010	DIP	32	Not use adapter	AMIC	A29010L	PLCC	32	PA32PL32D
AMIC	A29010V	TSOP	32	PA32TS20/PA32TS32D-20	AMIC	A29040	DIP	32	Not use adapter
AMIC	A29040A	DIP	32	Not use adapter	AMIC	A29040AL	PLCC	32	PA32PL32D
AMIC	A29040AV	TSOP	32	PA32TS20/PA32TS32D-20	AMIC	A29040B	DIP	32	Not use adapter
AMIC	A29040BL	PLCC	32	PA32PL32D	AMIC	A29040BV	TSOP	32	PA32TS20/PA32TS32D-20
AMIC	A29040L	PLCC	32	PA32PL32D	AMIC	A29040V	TSOP	32	PA32TS20/PA32TS32D-20
AMIC	A29400T	TSOP	48	PA48TS48D	AMIC	A29400U	TSOP	48	PA48TS48D
AMIC	A29512	DIP	32	Not use adapter	AMIC	A29512L	PLCC	32	PA32PL32D
AMIC	A29512V	TSOP	32	PA32TS20/PA32TS32D-20	AMIC	A29800TM	SOP	44	PA44SO44D
AMIC	A29800TV	TSOP	48	PA48TS48D	AMIC	A29800UM	SOP	44	PA44SO44D

AMIC	A29800UV	TSOP	48	PA48TS48D	AMIC	A29DL162TV	TSOP	48	PA48TS48D1
AMIC	A29DL162UV	TSOP	48	PA48TS48D1	AMIC	A29DL163TV	TSOP	48	PA48TS48D1
AMIC	A29DL163UV	TSOP	48	PA48TS48D1	AMIC	A29DL164TV	TSOP	48	PA48TS48D1
AMIC	A29DL164UV	TSOP	48	PA48TS48D1	AMIC	A29DL320FTV	TSOP	48	PA48TS48D
AMIC	A29DL320FUV	TSOP	48	PA48TS48D	AMIC	A29DL324TV	TSOP	48	PA48TS48D
AMIC	A29DL324UV	TSOP	48	PA48TS48D	AMIC	A29L004TL	PLCC	32	PA32PL32D
AMIC	A29L004TV	TSOP	32	PA32TS20/PA32TS32D-20	AMIC	A29L004TW	TSOP	40	PA40TS40D
AMIC	A29L004TX	TSOP	32	PA32TS14/PA32TS32D-14	AMIC	A29L004UL	PLCC	32	PA32PL32D
AMIC	A29L004UV	TSOP	32	PA32TS20/PA32TS32D-20	AMIC	A29L004UW	TSOP	40	PA40TS40D
AMIC	A29L004UX	TSOP	32	PA32TS14/PA32TS32D-14	AMIC	A29L008TV	TSOP	40	PA40TS40D
AMIC	A29L008UV	TSOP	40	PA40TS40D	AMIC	A29L040L	PLCC	32	PA32PL32D
AMIC	A29L040V	TSOP	32	PA32TS20/PA32TS32D-20	AMIC	A29L040X	TSOP	32	PA32TS14/PA32TS32D-14
AMIC	A29L160ATM	SOP	44	PA44SO44D	AMIC	A29L160ATV	TSOP	48	PA48TS48D1
AMIC	A29L160AUM	SOP	44	PA44SO44D	AMIC	A29L160AUV	TSOP	48	PA48TS48D1
AMIC	A29L160FTV	TSOP	48	PA48TS48D	AMIC	A29L160FUV	TSOP	48	PA48TS48D
AMIC	A29L160HTM	SOP	44	PA44SO44D	AMIC	A29L160HTV	TSOP	48	PA48TS48D
AMIC	A29L160HUM	SOP	44	PA44SO44D	AMIC	A29L160HUV	TSOP	48	PA48TS48D
AMIC	A29L160TM	SOP	44	PA44SO44D	AMIC	A29L160TV	TSOP	48	PA48TS48D
AMIC	A29L160UM	SOP	44	PA44SO44D	AMIC	A29L160UV	TSOP	48	PA48TS48D
AMIC	A29L400ATM	SOP	44	PA44SO44D	AMIC	A29L400ATV	TSOP	48	PA48TS48D
AMIC	A29L400AUM	SOP	44	PA44SO44D	AMIC	A29L400AUV	TSOP	48	PA48TS48D
AMIC	A29L400TM	SOP	44	PA44SO44D	AMIC	A29L400TV	TSOP	48	PA48TS48D
AMIC	A29L400UM	SOP	44	PA44SO44D	AMIC	A29L400UV	TSOP	48	PA48TS48D
AMIC	A29L800ATM	SOP	44	PA44SO44D	AMIC	A29L800ATV	TSOP	48	PA48TS48D
AMIC	A29L800AUM	SOP	44	PA44SO44D	AMIC	A29L800AUV	TSOP	48	PA48TS48D
AMIC	A29L800HTM	SOP	44	PA44SO44D	AMIC	A29L800HTV	TSOP	48	PA48TS48D
AMIC	A29L800HUM	SOP	44	PA44SO44D	AMIC	A29L800HUV	TSOP	48	PA48TS48D
AMIC	A29L800MV	TSOP	48	PA48TS48D	AMIC	A29L800TM	SOP	44	PA44SO44D
AMIC	A29L800TV	TSOP	48	PA48TS48D	AMIC	A29L800UM	SOP	44	PA44SO44D
AMIC	A49LF004MTL	PLCC	32	PA32PL32D	AMIC	A49LF004TL	PLCC	32	PA32PL32D
AMIC	A49LF040TL	PLCC	32	PA32PL32D	AMIC	A50FW040MTL	PLCC	32	PA32PL32D
AMIC	A50FW040TL	PLCC	32	PA32PL32D	AMIC	A50LPW040TL	PLCC	32	PA32PL32D
ANACHIP	PEEL16CV8	DIP	20	Not use adapter	ANACHIP	PEEL16CV8	PLCC	20	PA20LC20D
ANACHIP	PEEL16CV8	TSSOP	20	PA20SS-P54	ANACHIP	PEEL16CV8	SOIC	20	PA28SO1-08-06
ANACHIP	PEEL18CV8	DIP	20	Not use adapter	ANACHIP	PEEL18CV8	SOIC	20	PA28SO1-08-06
ANACHIP	PEEL18CV8	TSSOP	20	PA20SS-P54	ANACHIP	PEEL18CV8	PLCC	20	PA20LC20D
ANACHIP	PEEL18CV8Z	DIP	20	Not use adapter	ANACHIP	PEEL18CV8Z	SOIC	20	PA28SO1-08-06
ANACHIP	PEEL18CV8Z	TSSOP	20	PA20SS-P54	ANACHIP	PEEL18CV8Z	PLCC	20	PA20LC20D
ANACHIP	PEEL18LV8Z	DIP	20	Not use adapter	ANACHIP	PEEL18LV8Z	TSSOP	20	PA20SS-P54
ANACHIP	PEEL18LV8Z	SOIC	20	PA28SO1-08-06	ANACHIP	PEEL18LV8Z	PLCC	20	PA20LC20D
ANACHIP	PEEL22CV10	DIP	24	Not use adapter	ANACHIP	PEEL22CV10	PLCC	28	PA28PL28D
ANACHIP	PEEL22CV10	SOIC	24	PA28SO28D-EO-300	ANACHIP	PEEL22CV10	TSSOP	24	PA24TSS24D(M)
ANACHIP	PEEL22CV10A	DIP	24	Not use adapter	ANACHIP	PEEL22CV10A	TSSOP	24	PA24TSS24D(M)
ANACHIP	PEEL22CV10A	PLCC	28	PA28PL28D	ANACHIP	PEEL22CV10A	SOIC	24	PA28SO28D-EO-300
ANACHIP	PEEL22CV10A+	DIP	24	Not use adapter	ANACHIP	PEEL22CV10A+	PLCC	28	PA28PL28D
ANACHIP	PEEL22CV10A+	SOIC	24	PA28SO28D-EO-300	ANACHIP	PEEL22CV10A+	TSSOP	24	PA24TSS24D(M)
ANACHIP	PEEL22CV10A++	DIP	24	Not use adapter	ANACHIP	PEEL22CV10A++	PLCC	28	PA28PL28D
ANACHIP	PEEL22CV10A++	TSSOP	24	PA24TSS24D(M)	ANACHIP	PEEL22CV10A++	SOIC	24	PA28SO28D-EO-300
ANACHIP	PEEL22CV10AZ	DIP	24	Not use adapter	ANACHIP	PEEL22CV10AZ	TSSOP	24	PA24TSS24D(M)
ANACHIP	PEEL22CV10AZ	SOIC	24	PA28SO28D-EO-300	ANACHIP	PEEL22CV10AZ	PLCC	28	PA28PL28D
ANACHIP	PEEL22CV10AZ+	DIP	24	Not use adapter	ANACHIP	PEEL22CV10AZ+	SOIC	24	PA28SO28D-EO-300
ANACHIP	PEEL22CV10AZ+	PLCC	28	PA28PL28D	ANACHIP	PEEL22CV10AZ+	TSSOP	24	PA24TSS24D(M)
ANACHIP	PEEL22CV10AZ++	DIP	24	Not use adapter	ANACHIP	PEEL22CV10AZ++	SOIC	24	PA28SO28D-EO-300
ANACHIP	PEEL22CV10AZ++	PLCC	28	PA28PL28D	ANACHIP	PEEL22CV10AZ++	TSSOP	24	PA24TSS24D(M)
ANACHIP	PEEL22CV10Z	DIP	24	Not use adapter	ANACHIP	PEEL22CV10Z	PLCC	28	PA28PL28D
ANACHIP	PEEL22CV10Z	SOIC	24	PA28SO28D-EO-300	ANACHIP	PEEL22CV10Z	TSSOP	24	PA24TSS24D(M)
ASAHI	AK93C10AF	SOIC	8	PA8SO1-05-6	ASAHI	AK93C85AM	SSOP	8	PA8TSS-OT
ASAHI	AK93C95AF	SOIC	8	PA8SO1-05-6	ATMEL	AT17C002	PLCC	20	PA20LC20D
ATMEL	AT17C002	PLCC	44	PA44-48U	ATMEL	AT17C002	QFP	44	PA44QF44D
ATMEL	AT17C002A	PLCC	20	PA20LC20D	ATMEL	AT17C002A	PLCC	44	PA44-48U
ATMEL	AT17C002A	QFP	44	PA44QF44D	ATMEL	AT17C010	DIP	8	Not use adapter
ATMEL	AT17C010	PLCC	20	PA20LC20D	ATMEL	AT17C010A	PLCC	20	PA20LC20D
ATMEL	AT17C020	PLCC	20	PA20LC20D	ATMEL	AT17C020A	PLCC	20	PA20LC20D
ATMEL	AT17C040	PLCC	44	PA44-48U	ATMEL	AT17C040	QFP	44	PA44QF44D
ATMEL	AT17C040A	PLCC	44	PA44-48U	ATMEL	AT17C040A	QFP	44	PA44QF44D
ATMEL	AT17C128	DIP	8	Not use adapter	ATMEL	AT17C128	PLCC	20	PA20LC20D
ATMEL	AT17C128A	PLCC	20	PA20LC20D	ATMEL	AT17C256	PLCC	20	PA20LC20D
ATMEL	AT17C256	DIP	8	Not use adapter	ATMEL	AT17C256A	PLCC	20	PA20LC20D
ATMEL	AT17C512	DIP	8	Not use adapter	ATMEL	AT17C512	PLCC	20	PA20LC20D
ATMEL	AT17C512A	PLCC	20	PA20LC20D	ATMEL	AT17C65	DIP	8	Not use adapter
ATMEL	AT17C65	PLCC	20	PA20LC20D	ATMEL	AT17C65	SOIC	20	PA28SO1-08-06
ATMEL	AT17C65A	PLCC	20	PA20LC20D	ATMEL	AT17LV002	PLCC	44	PA44-48U
ATMEL	AT17LV002	SOIC	20	PA28SO1-08-06	ATMEL	AT17LV002	PLCC	20	PA20LC20D
ATMEL	AT17LV002	QFP	44	PA44QF44D	ATMEL	AT17LV002A	PLCC	44	PA44-48U

ATMEL	AT17LV002A	QFP	44	PA44QF44D	ATMEL	AT17LV002A	PLCC	20	PA20LC20D
ATMEL	AT17LV010	DIP	8	Not use adapter	ATMEL	AT17LV010	SOIC	20	PA28SO1-08-06
ATMEL	AT17LV010	PLCC	20	PA20LC20D	ATMEL	AT17LV010A	DIP	8	Not use adapter
ATMEL	AT17LV010A	PLCC	20	PA20LC20D	ATMEL	AT17LV020	PLCC	20	PA20LC20D
ATMEL	AT17LV020A	PLCC	20	PA20LC20D	ATMEL	AT17LV040	PLCC	44	PA44-48U
ATMEL	AT17LV040	QFP	44	PA44QF44D	ATMEL	AT17LV040A	PLCC	44	PA44-48U
ATMEL	AT17LV040A	QFP	44	PA44QF44D	ATMEL	AT17LV128	DIP	8	Not use adapter
ATMEL	AT17LV128	PLCC	20	PA20LC20D	ATMEL	AT17LV128	SOIC	20	PA28SO1-08-06
ATMEL	AT17LV128A	PLCC	20	PA20LC20D	ATMEL	AT17LV256	DIP	8	Not use adapter
ATMEL	AT17LV256	PLCC	20	PA20LC20D	ATMEL	AT17LV256	SOIC	20	PA28SO1-08-06
ATMEL	AT17LV256A	PLCC	20	PA20LC20D	ATMEL	AT17LV512	DIP	8	Not use adapter
ATMEL	AT17LV512	PLCC	20	PA20LC20D	ATMEL	AT17LV512	SOIC	20	PA28SO1-08-06
ATMEL	AT17LV512A	PLCC	20	PA20LC20D	ATMEL	AT17LV65	DIP	8	Not use adapter
ATMEL	AT17LV65	PLCC	20	PA20LC20D	ATMEL	AT17LV65	SOIC	20	PA28SO1-08-06
ATMEL	AT17LV65A	PLCC	20	PA20LC20D	ATMEL	AT17N002	LAP	8	PA8LAP8D
ATMEL	AT17N002	SOIC	20	PA28SO1-08-06	ATMEL	AT17N002	QFP	44	PA44QF44D
ATMEL	AT17N010	DIP	8	Not use adapter	ATMEL	AT17N010	LAP	8	PA8LAP8D
ATMEL	AT17N010	SOIC	20	PA28SO1-08-06	ATMEL	AT17N040	QFP	44	PA44QF44D
ATMEL	AT17N256	DIP	8	Not use adapter	ATMEL	AT17N256	SOIC	20	PA28SO1-08-06
ATMEL	AT17N256	SOIC	8	PA16SO16D	ATMEL	AT17N512	DIP	8	Not use adapter
ATMEL	AT17N512	SOIC	20	PA28SO1-08-06	ATMEL	AT17N512	LAP	8	PA8LAP8D
ATMEL	AT22LV10	DIP	24	Not use adapter	ATMEL	AT22LV10	PLCC	28	PA28-24-2P6
ATMEL	AT22LV10	SOIC	24	PA28SO28D-08	ATMEL	AT22LV10L	DIP	24	Not use adapter
ATMEL	AT22LV10L	PLCC	28	PA28-24-2P6	ATMEL	AT22LV10L	SOIC	24	PA28SO28D-08
ATMEL	AT22V10	DIP	24	Not use adapter	ATMEL	AT22V10	PLCC	28	PA28-24-2P6
ATMEL	AT22V10	SOIC	24	PA28SO28D-08	ATMEL	AT22V10B	DIP	24	Not use adapter
ATMEL	AT22V10B	PLCC	28	PA28-24-2P6	ATMEL	AT22V10B	SOIC	24	PA28SO28D-08
ATMEL	AT22V10BL	DIP	24	Not use adapter	ATMEL	AT22V10BL	SOIC	24	PA28SO28D-08
ATMEL	AT22V10BL	PLCC	28	PA28-24-2P6	ATMEL	AT22V10L	DIP	24	Not use adapter
ATMEL	AT22V10L	SOIC	24	PA28SO28D-08	ATMEL	AT22V10L	PLCC	28	PA28-24-2P6
ATMEL	AT24C01	DIP	8	Not use adapter	ATMEL	AT24C01A	DIP	8	Not use adapter
ATMEL	AT24C02	DIP	8	Not use adapter	ATMEL	AT24C02A	DIP	8	Not use adapter
ATMEL	AT24C04	DIP	8	Not use adapter	ATMEL	AT24C04A	DIP	8	Not use adapter
ATMEL	AT24C08	DIP	8	Not use adapter	ATMEL	AT24C08A	DIP	8	Not use adapter
ATMEL	AT24C1024	DIP	8	Not use adapter	ATMEL	AT24C1024	LAP	8	PA8MAP8
ATMEL	AT24C1024	SOIC	8	PA8SO8D	ATMEL	AT24C128	DIP	8	Not use adapter
ATMEL	AT24C128	TSSOP	8	PA24TSS24D(M)	ATMEL	AT24C16	DIP	8	Not use adapter
ATMEL	AT24C164	DIP	8	Not use adapter	ATMEL	AT24C16A	DIP	8	Not use adapter
ATMEL	AT24C256	DIP	8	Not use adapter	ATMEL	AT24C256	TSSOP	8	PA24TSS24D(M)
ATMEL	AT24C256N	SOIC	8	PA8SO8D	ATMEL	AT24C32	DIP	8	Not use adapter
ATMEL	AT24C512	DIP	8	Not use adapter	ATMEL	AT24C512	TSSOP	8	PA24TSS24D(M)
ATMEL	AT24C64	DIP	8	Not use adapter	ATMEL	AT24C64A	SOIC	8	PA8SO8D
ATMEL	AT24CS128	DIP	8	Not use adapter	ATMEL	AT24CS256	DIP	8	Not use adapter
ATMEL	AT25010	DIP	8	Not use adapter	ATMEL	AT25010	SOIC	8	PA8SO8D
ATMEL	AT25010A	DIP	8	Not use adapter	ATMEL	AT25010A	TSSOP	8	PA24TSS24D(M)
ATMEL	AT25010A	MAP	8	PA8MAP8	ATMEL	AT25010A	SOIC	8	PA8SO8D
ATMEL	AT25020	DIP	8	Not use adapter	ATMEL	AT25020	SOIC	8	PA8SO8D
ATMEL	AT25020A	DIP	8	Not use adapter	ATMEL	AT25020A	MAP	8	PA8MAP8
ATMEL	AT25020A	SOIC	8	PA8SO8D	ATMEL	AT25020A	TSSOP	8	PA24TSS24D(M)
ATMEL	AT25040	DIP	8	Not use adapter	ATMEL	AT25040	SOIC	8	PA8SO8D
ATMEL	AT25040A	DIP	8	Not use adapter	ATMEL	AT25040A	MAP	8	PA8MAP8
ATMEL	AT25040A	TSSOP	8	PA24TSS24D(M)	ATMEL	AT25040A	SOIC	8	PA8SO8D
ATMEL	AT25080	DIP	8	Not use adapter	ATMEL	AT25080	SOIC	8	PA8SO8D
ATMEL	AT25080A	DIP	8	Not use adapter	ATMEL	AT25080A	SOIC	8	PA8SO8D
ATMEL	AT25080A	MAP	8	PA8MAP8	ATMEL	AT25080A	TSSOP	8	PA24TSS24D(M)
ATMEL	AT25128	DIP	8	Not use adapter	ATMEL	AT25128	SOIC	8	PA8SO8D
ATMEL	AT25128A	DIP	8	Not use adapter	ATMEL	AT25128A	SOIC	8	PA8SO8D
ATMEL	AT25128A	TSSOP	8	PA24TSS24D(M)	ATMEL	AT25128A	MAP	8	PA8MAP8
ATMEL	AT25160	DIP	8	Not use adapter	ATMEL	AT25160	SOIC	8	PA8SO8D
ATMEL	AT25160A	DIP	8	Not use adapter	ATMEL	AT25160A	MAP	8	PA8MAP8
ATMEL	AT25160A	TSSOP	8	PA24TSS24D(M)	ATMEL	AT25160A	SOIC	8	PA8SO8D
ATMEL	AT25256	DIP	8	Not use adapter	ATMEL	AT25256	SOIC	8	PA8SO8D
ATMEL	AT25256A	DIP	8	Not use adapter	ATMEL	AT25256A	SOIC	8	PA8SO8D
ATMEL	AT25256A	TSSOP	8	PA24TSS24D(M)	ATMEL	AT25256A	MAP	8	PA8MAP8
ATMEL	AT25320	DIP	8	Not use adapter	ATMEL	AT25320	SOIC	8	PA8SO8D
ATMEL	AT25320A	DIP	8	Not use adapter	ATMEL	AT25320A	SOIC	8	PA8SO8D
ATMEL	AT25320A	MAP	8	PA8MAP8	ATMEL	AT25320A	TSSOP	8	PA24TSS24D(M)
ATMEL	AT25640	DIP	8	Not use adapter	ATMEL	AT25640	SOIC	8	PA8SO8D
ATMEL	AT25640A	DIP	8	Not use adapter	ATMEL	AT25640A	SOIC	8	PA8SO8D
ATMEL	AT25640A	TSSOP	8	PA24TSS24D(M)	ATMEL	AT25640A	MAP	8	PA8MAP8
ATMEL	AT25F1024	SOIC	8	PA16SO16D	ATMEL	AT25F2048	SOIC	8	PA16SO16D
ATMEL	AT25F4096	SOIC	8	PA16SO16D	ATMEL	AT25HP256	DIP	8	Not use adapter
ATMEL	AT25HP512	DIP	8	Not use adapter	ATMEL	AT27BV010	DIP	32	Not use adapter
ATMEL	AT27BV020	DIP	32	Not use adapter	ATMEL	AT27BV040	DIP	32	Not use adapter

ATMEL	AT27BV1024	PLCC	44	PA44-48U	ATMEL	AT27BV1024	DIP	40	Not use adapter
ATMEL	AT27BV256	DIP	28	Not use adapter	ATMEL	AT27BV256	PLCC	32	PA32-28
ATMEL	AT27BV256	TSOP	28	PA28TSOP3	ATMEL	AT27BV256	SOIC	28	PA28SO28D-08
ATMEL	AT27BV4096	PLCC	44	PA44-48U	ATMEL	AT27BV4096	DIP	40	Not use adapter
ATMEL	AT27BV512	DIP	28	Not use adapter	ATMEL	AT27C010	DIP	32	Not use adapter
ATMEL	AT27C010L	DIP	32	Not use adapter	ATMEL	AT27C020	DIP	32	Not use adapter
ATMEL	AT27C020	PLCC	32	PA32PL32D	ATMEL	AT27C040	DIP	32	Not use adapter
ATMEL	AT27C080	DIP	32	Not use adapter	ATMEL	AT27C1024	PLCC	44	PA44-48U
ATMEL	AT27C1024	DIP	40	Not use adapter	ATMEL	AT27C1024L	PLCC	44	PA44-48U
ATMEL	AT27C1024L	DIP	40	Not use adapter	ATMEL	AT27C128	DIP	28	Not use adapter
ATMEL	AT27C128	PLCC	32	PA32-28	ATMEL	AT27C2048	DIP	40	Not use adapter
ATMEL	AT27C2048	PLCC	44	PA44-48U	ATMEL	AT27C256	DIP	28	Not use adapter
ATMEL	AT27C256	PLCC	32	PA32-28	ATMEL	AT27C256R	DIP	28	Not use adapter
ATMEL	AT27C256R	SOIC	28	PA28SO28D-08	ATMEL	AT27C256R	PLCC	32	PA32-28
ATMEL	AT27C256R	TSOP	28	PA28TSOP3	ATMEL	AT27C256R	PLCC	32	PA32-28
ATMEL	AT27C400	DIP	40	Not use adapter	ATMEL	AT27C4096	PLCC	44	PA44-48U
ATMEL	AT27C4096	DIP	40	Not use adapter	ATMEL	AT27C512	DIP	28	Not use adapter
ATMEL	AT27C512R	DIP	28	Not use adapter	ATMEL	AT27C516	PLCC	44	PA44-48U
ATMEL	AT27C516	DIP	40	Not use adapter	ATMEL	AT27C64	DIP	28	Not use adapter
ATMEL	AT27C64	PLCC	32	PA32-28	ATMEL	AT27C800	PLCC	44	PA44-48U
ATMEL	AT27C800	DIP	42	Not use adapter	ATMEL	AT27HC1024	PLCC	44	PA44-48U
ATMEL	AT27HC1024	DIP	40	Not use adapter	ATMEL	AT27HC256	DIP	28	Not use adapter
ATMEL	AT27HC256	PLCC	32	PA32-28	ATMEL	AT27HC256R	DIP	28	Not use adapter
ATMEL	AT27HC256R	PLCC	32	PA32-28	ATMEL	AT27HC64	DIP	28	Not use adapter
ATMEL	AT27HC64	PLCC	32	PA32-28	ATMEL	AT27HC64L	DIP	28	Not use adapter
ATMEL	AT27HC64L	PLCC	32	PA32-28	ATMEL	AT27LV010	DIP	32	Not use adapter
ATMEL	AT27LV010A	DIP	32	Not use adapter	ATMEL	AT27LV010AL	DIP	32	Not use adapter
ATMEL	AT27LV020	DIP	32	Not use adapter	ATMEL	AT27LV020A	DIP	32	Not use adapter
ATMEL	AT27LV040	DIP	32	Not use adapter	ATMEL	AT27LV040A	DIP	32	Not use adapter
ATMEL	AT27LV080	DIP	32	Not use adapter	ATMEL	AT27LV1024	PLCC	44	PA44-48U
ATMEL	AT27LV1024	DIP	40	Not use adapter	ATMEL	AT27LV256A	DIP	28	Not use adapter
ATMEL	AT27LV256A/R	TSOP	28	PA28TSOP3	ATMEL	AT27LV256A/R	SOIC	28	PA28SO28D-08
ATMEL	AT27LV256A/R	PLCC	32	PA32-28	ATMEL	AT27LV256R	DIP	28	Not use adapter
ATMEL	AT27LV4096	PLCC	44	PA44-48U	ATMEL	AT27LV4096	DIP	40	Not use adapter
ATMEL	AT27LV512A	DIP	28	Not use adapter	ATMEL	AT27LV512R	DIP	28	Not use adapter
ATMEL	AT27RW1024	PLCC	44	PA44-48U	ATMEL	AT28BV16	DIP	24	Not use adapter
ATMEL	AT28BV256	DIP	28	Not use adapter	ATMEL	AT28BV64	DIP	28	Not use adapter
ATMEL	AT28C010	DIP	32	Not use adapter	ATMEL	AT28C040	DIP	32	Not use adapter
ATMEL	AT28C1024	PLCC	44	PA44-48U	ATMEL	AT28C1024	DIP	40	Not use adapter
ATMEL	AT28C16	DIP	24	Not use adapter	ATMEL	AT28C17	DIP	28	Not use adapter
ATMEL	AT28C256	DIP	28	Not use adapter	ATMEL	AT28C64	DIP	28	Not use adapter
ATMEL	AT28HC16	DIP	24	Not use adapter	ATMEL	AT28HC16L	DIP	24	Not use adapter
ATMEL	AT28HC256	DIP	28	Not use adapter	ATMEL	AT28HC64	DIP	28	Not use adapter
ATMEL	AT28HC64B	DIP	28	Not use adapter	ATMEL	AT28LV010	PLCC	32	PA32PL32D
ATMEL	AT28LV010	DIP	32	Not use adapter	ATMEL	AT28LV010	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT28LV256	DIP	28	Not use adapter	ATMEL	AT28LV64	DIP	28	Not use adapter
ATMEL	AT28LV64B	DIP	28	Not use adapter	ATMEL	AT28MC010	DIP	32	Not use adapter
ATMEL	AT28MC040	DIP	32	Not use adapter	ATMEL	AT28PC64	DIP	28	Not use adapter
ATMEL	AT28PC64E	DIP	28	Not use adapter	ATMEL	AT29BV010A	DIP	32	Not use adapter
ATMEL	AT29BV020	DIP	32	Not use adapter	ATMEL	AT29BV1024	DIP	40	Not use adapter
ATMEL	AT29BV1024	PLCC	44	PA44-48U	ATMEL	AT29BV256	DIP	28	Not use adapter
ATMEL	AT29C010	DIP	32	Not use adapter	ATMEL	AT29C010A	PLCC	32	PA32PL32D
ATMEL	AT29C010A	DIP	32	Not use adapter	ATMEL	AT29C020	DIP	32	Not use adapter
ATMEL	AT29C020	PLCC	32	PA32PL32D	ATMEL	AT29C040	DIP	32	Not use adapter
ATMEL	AT29C040A	DIP	32	Not use adapter	ATMEL	AT29C1024	PLCC	44	PA44-48U
ATMEL	AT29C1024	TSOP	48	PA48TS48D	ATMEL	AT29C1024	DIP	40	Not use adapter
ATMEL	AT29C256	DIP	28	Not use adapter	ATMEL	AT29C257	DIP	32	Not use adapter
ATMEL	AT29C512	DIP	32	Not use adapter	ATMEL	AT29LV010	DIP	32	Not use adapter
ATMEL	AT29LV010A	DIP	32	Not use adapter	ATMEL	AT29LV020	DIP	32	Not use adapter
ATMEL	AT29LV040A	DIP	32	Not use adapter	ATMEL	AT29LV1024	DIP	40	Not use adapter
ATMEL	AT29LV1024	TSOP	48	PA48TS48D	ATMEL	AT29LV1024	PLCC	44	PA44-48U
ATMEL	AT29LV256	DIP	28	Not use adapter	ATMEL	AT29LV512	DIP	32	Not use adapter
ATMEL	AT32C16	DIP	40	Not use adapter	ATMEL	AT34C02	DIP	8	Not use adapter
ATMEL	AT45D011	PLCC	32	PA32PL32D	ATMEL	AT45D011	SOP	8	PA8SO1-2006-3
ATMEL	AT45D021	PLCC	32	PA32PL32D	ATMEL	AT45D021	SOP	28	PA28SO1-15B-3
ATMEL	AT45D021	TSOP	28	PA28TSOP3	ATMEL	AT45D041	PLCC	32	PA32PL32D
ATMEL	AT45D041	SOP	28	PA28SO1-15B-3	ATMEL	AT45D041	TSOP	28	PA28TSOP3
ATMEL	AT45D081	TSOP	32	PA48TS48D	ATMEL	AT45D081	SOP	28	PA28SO1-15B-3
ATMEL	AT45D161	PLCC	32	PA32PL32D	ATMEL	AT45D161	SOP	28	PA28SO1-15B-3
ATMEL	AT45D161	TSOP	28	PA28TSOP3	ATMEL	AT45DB011	PLCC	32	PA32PL32D
ATMEL	AT45DB011	SOP	8	PA8SO1-2006-3	ATMEL	AT45DB011B	PLCC	32	PA32PL32D
ATMEL	AT45DB011B	TSOP	14	PA24TSS24D(M)	ATMEL	AT45DB011B	SOP	8	PA8SO1-2006-3
ATMEL	AT45DB021	PLCC	32	PA32PL32D	ATMEL	AT45DB021	SOP	28	PA28SO1-15B-3
ATMEL	AT45DB021	TSOP	28	PA28TSOP3	ATMEL	AT45DB021B	TSOP	28	PA28TSOP3

ATMEL	AT45DB021B	SOP	28	PA28SO1-15B-3	ATMEL	AT45DB041	PLCC	32	PA32PL32D
ATMEL	AT45DB041	SOP	28	PA28SO1-15B-3	ATMEL	AT45DB041	TSOP	28	PA28TSOP3
ATMEL	AT45DB041B	CASON	8	PA8SON20D	ATMEL	AT45DB041B	TSOP	28	PA28TSOP3
ATMEL	AT45DB041B	SOP	8	PA8SO1-2006-3	ATMEL	AT45DB041B	SOP	28	PA28SO1-15B-3
ATMEL	AT45DB081	TSOP	32	PA48TS48D	ATMEL	AT45DB081	SOP	28	PA28SO1-15B-3
ATMEL	AT45DB081B	CASON	8	PA8SON20D	ATMEL	AT45DB081B	TSOP	32	PA48TS48D
ATMEL	AT45DB081B	TSOP	28	PA28TSOP3	ATMEL	AT45DB161	PLCC	32	PA32PL32D
ATMEL	AT45DB161	SOP	28	PA28SO1-15B-3	ATMEL	AT45DB161	TSOP	28	PA28TSOP3
ATMEL	AT45DB161B	CASON	8	PA8SON20D	ATMEL	AT45DB161B	SOP	28	PA28SO1-15B-3
ATMEL	AT45DB161B	TSOP	28	PA28TSOP3	ATMEL	AT45DB321	TSOP	32	PA48TS48D
ATMEL	AT45DB321	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT45DB321	SOP	28	PA28SO1-15B-3
ATMEL	AT45DB321B	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT45DB642	TSOP	40	PA40TS40D
ATMEL	AT45DCB002	SOP	28	PAAT02-04A	ATMEL	AT45DCB004	SOP	28	PAAT02-04A
ATMEL	AT45DCB008	SOP	28	PAAT02-04A	ATMEL	AT49BV001	DIP	32	Not use adapter
ATMEL	AT49BV001A	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49BV001A	PLCC	32	PA32PL32D
ATMEL	AT49BV001A	TSOP	32	PA32ST32D	ATMEL	AT49BV001AN	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49BV001ANT	PLCC	32	PA32PL32D	ATMEL	AT49BV001ANT	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49BV001AT	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49BV001AT	PLCC	32	PA32PL32D
ATMEL	AT49BV001AT	SSOP	32	PA32ST32D	ATMEL	AT49BV001N	DIP	32	Not use adapter
ATMEL	AT49BV001NT	DIP	32	Not use adapter	ATMEL	AT49BV001T	DIP	32	Not use adapter
ATMEL	AT49BV002	DIP	32	Not use adapter	ATMEL	AT49BV002A	DIP	32	Not use adapter
ATMEL	AT49BV002A	PLCC	32	PA32PL32D	ATMEL	AT49BV002A	SSOP	32	PA32ST32D
ATMEL	AT49BV002AN	DIP	32	Not use adapter	ATMEL	AT49BV002AN	PLCC	32	PA32PL32D
ATMEL	AT49BV002AN	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49BV002AN	SSOP	32	PA32ST32D
ATMEL	AT49BV002ANT	DIP	32	Not use adapter	ATMEL	AT49BV002ANT	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49BV002ANT	SSOP	32	PA32ST32D	ATMEL	AT49BV002AT	PLCC	32	PA32PL32D
ATMEL	AT49BV002AT	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49BV002AT	DIP	32	Not use adapter
ATMEL	AT49BV002AT	SSOP	32	PA32ST32D	ATMEL	AT49BV002N	DIP	32	Not use adapter
ATMEL	AT49BV002NT	DIP	32	Not use adapter	ATMEL	AT49BV002T	DIP	32	Not use adapter
ATMEL	AT49BV008A	TSOP	40	PA40TS40D	ATMEL	AT49BV008AT	TSOP	40	PA40TS40D
ATMEL	AT49BV010	DIP	32	Not use adapter	ATMEL	AT49BV020	DIP	32	Not use adapter
ATMEL	AT49BV040	DIP	32	Not use adapter	ATMEL	AT49BV040A	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49BV040A	PLCC	32	PA32PL32D	ATMEL	AT49BV040A	SSOP	32	PA32ST32D
ATMEL	AT49BV040T	DIP	32	Not use adapter	ATMEL	AT49BV080	SOP	44	PA44SO44D
ATMEL	AT49BV080	TSOP	40	PA40TS40D	ATMEL	AT49BV080T	SOP	44	PA44SO44D
ATMEL	AT49BV080T	TSOP	40	PA40TS40D	ATMEL	AT49BV160	TSOP	48	PA48TS48D
ATMEL	AT49BV1604	TSOP	48	PA48TS48D	ATMEL	AT49BV1604A	TSOP	48	PA48TS48D
ATMEL	AT49BV1604AT	TSOP	48	PA48TS48D	ATMEL	AT49BV1604T	TSOP	48	PA48TS48D
ATMEL	AT49BV160C	TSOP	48	PA48TS48D	ATMEL	AT49BV160CT	TSOP	48	PA48TS48D
ATMEL	AT49BV160T	TSOP	48	PA48TS48D	ATMEL	AT49BV161	TSOP	48	PA48TS48D
ATMEL	AT49BV1614	TSOP	48	PA48TS48D	ATMEL	AT49BV1614A	TSOP	48	PA48TS48D
ATMEL	AT49BV1614AT	TSOP	48	PA48TS48D	ATMEL	AT49BV1614T	TSOP	48	PA48TS48D
ATMEL	AT49BV1618	TSOP	48	PA48TS48D	ATMEL	AT49BV1618T	TSOP	48	PA48TS48D
ATMEL	AT49BV161T	TSOP	48	PA48TS48D	ATMEL	AT49BV162A	TSOP	48	PA48TS48D
ATMEL	AT49BV162AT	TSOP	48	PA48TS48D	ATMEL	AT49BV163A	TSOP	48	PA48TS48D
ATMEL	AT49BV2048	TSOP	48	PA48TS48D	ATMEL	AT49BV2048	SOP	44	PA44SO44D
ATMEL	AT49BV2048A	SOP	44	PA44SO44D	ATMEL	AT49BV2048A	TSOP	48	PA48TS48D
ATMEL	AT49BV320	TSOP	48	PA48TS48D	ATMEL	AT49BV320A	TSOP	48	PA48TS48D
ATMEL	AT49BV320AT	TSOP	48	PA48TS48D	ATMEL	AT49BV320C	TSOP	48	PA48TS48D
ATMEL	AT49BV320CT	TSOP	48	PA48TS48D	ATMEL	AT49BV320T	TSOP	48	PA48TS48D
ATMEL	AT49BV321	TSOP	48	PA48TS48D	ATMEL	AT49BV321T	TSOP	48	PA48TS48D
ATMEL	AT49BV322A	TSOP	48	PA48TS48D	ATMEL	AT49BV322A	BGA	48	HA48BG48DAR
ATMEL	AT49BV322AT	TSOP	48	PA48TS48D	ATMEL	AT49BV322AT	BGA	48	HA48BG48DAR
ATMEL	AT49BV4096	SOP	44	PA44SO44D	ATMEL	AT49BV4096	TSOP	48	PA48TS48D
ATMEL	AT49BV4096A	TSOP	48	PA48TS48D	ATMEL	AT49BV4096A	SOP	44	PA44SO44D
ATMEL	AT49BV4096AT	SOP	44	PA44SO44D	ATMEL	AT49BV4096AT	TSOP	48	PA48TS48D
ATMEL	AT49BV512	DIP	32	Not use adapter	ATMEL	AT49BV6416	TSOP	48	PA48TS48D
ATMEL	AT49BV6416T	TSOP	48	PA48TS48D	ATMEL	AT49BV8004	TSOP	48	PA48TS48D
ATMEL	AT49BV8004T	TSOP	48	PA48TS48D	ATMEL	AT49BV8011	TSOP	48	PA48TS48D
ATMEL	AT49BV8011T	TSOP	48	PA48TS48D	ATMEL	AT49BV802A	TSOP	48	PA48TS48D
ATMEL	AT49BV802AT	TSOP	48	PA48TS48D	ATMEL	AT49BV8192	TSOP	48	PA48TS48D
ATMEL	AT49BV8192	SOP	44	PA44SO44D	ATMEL	AT49BV8192A	TSOP	48	PA48TS48D
ATMEL	AT49BV8192AT	TSOP	48	PA48TS48D	ATMEL	AT49BV8192T	TSOP	48	PA48TS48D
ATMEL	AT49F001	DIP	32	Not use adapter	ATMEL	AT49F001	PLCC	32	PA32PL32D
ATMEL	AT49F001	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F001A	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F001A	PLCC	32	PA32PL32D	ATMEL	AT49F001A	SSOP	32	PA32ST32D
ATMEL	AT49F001AN	PLCC	32	PA32PL32D	ATMEL	AT49F001AN	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F001AN	SSOP	32	PA32ST32D	ATMEL	AT49F001ANT	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F001ANT	PLCC	32	PA32PL32D	ATMEL	AT49F001ANT	SSOP	32	PA32ST32D
ATMEL	AT49F001AT	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F001AT	PLCC	32	PA32PL32D
ATMEL	AT49F001AT	SSOP	32	PA32ST32D	ATMEL	AT49F001N	PLCC	32	PA32PL32D
ATMEL	AT49F001N	DIP	32	Not use adapter	ATMEL	AT49F001N	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F001NT	DIP	32	Not use adapter	ATMEL	AT49F001NT	PLCC	32	PA32PL32D
ATMEL	AT49F001NT	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F001T	TSOP	32	PA32TS20/PA32TS32D-20

ATMEL	AT49F001T	DIP	32	Not use adapter	ATMEL	AT49F001T	PLCC	32	PA32PL32D
ATMEL	AT49F002	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F002	PLCC	32	PA32PL32D
ATMEL	AT49F002	DIP	32	Not use adapter	ATMEL	AT49F002A	PLCC	32	PA32PL32D
ATMEL	AT49F002A	DIP	32	Not use adapter	ATMEL	AT49F002A	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F002A	SSOP	32	PA32ST32D	ATMEL	AT49F002AN	PLCC	32	PA32PL32D
ATMEL	AT49F002AN	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F002AN	DIP	32	Not use adapter
ATMEL	AT49F002AN	SSOP	32	PA32ST32D	ATMEL	AT49F002ANT	DIP	32	Not use adapter
ATMEL	AT49F002ANT	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F002ANT	PLCC	32	PA32PL32D
ATMEL	AT49F002ANT	SSOP	32	PA32ST32D	ATMEL	AT49F002AT	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F002AT	DIP	32	Not use adapter	ATMEL	AT49F002AT	SSOP	32	PA32ST32D
ATMEL	AT49F002N	PLCC	32	PA32PL32D	ATMEL	AT49F002N	DIP	32	Not use adapter
ATMEL	AT49F002N	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F002NT	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F002NT	PLCC	32	PA32PL32D	ATMEL	AT49F002NT	DIP	32	Not use adapter
ATMEL	AT49F002T	DIP	32	Not use adapter	ATMEL	AT49F002T	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F002T	PLCC	32	PA32PL32D	ATMEL	AT49F010	PLCC	32	PA32PL32D
ATMEL	AT49F010	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F010	DIP	32	Not use adapter
ATMEL	AT49F020	PLCC	32	PA32PL32D	ATMEL	AT49F020	DIP	32	Not use adapter
ATMEL	AT49F020	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F040	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F040	DIP	32	Not use adapter	ATMEL	AT49F040	PLCC	32	PA32PL32D
ATMEL	AT49F040A	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F040A	PLCC	32	PA32PL32D
ATMEL	AT49F040A	DIP	32	Not use adapter	ATMEL	AT49F040T	PLCC	32	PA32PL32D
ATMEL	AT49F040T	TSOP	32	PA32TS20/PA32TS32D-20	ATMEL	AT49F040T	DIP	32	Not use adapter
ATMEL	AT49F080	TSOP	40	PA40TS40D	ATMEL	AT49F080T	TSOP	40	PA40TS40D
ATMEL	AT49F1024	TSOP	40	PA40TS14-OT	ATMEL	AT49F1025	SOP	40	PA44SO44D
ATMEL	AT49F1025	PLCC	44	PA44-48U	ATMEL	AT49F1604	TSOP	48	PA48TS48D
ATMEL	AT49F1604T	TSOP	48	PA48TS48D	ATMEL	AT49F1614	TSOP	48	PA48TS48D
ATMEL	AT49F1614T	TSOP	48	PA48TS48D	ATMEL	AT49F1618	TSOP	48	PA48TS48D
ATMEL	AT49F1618T	TSOP	48	PA48TS48D	ATMEL	AT49F2048	SOP	44	PA44SO44D
ATMEL	AT49F2048	TSOP	48	PA48TS48D	ATMEL	AT49F4096	TSOP	48	PA48TS48D
ATMEL	AT49F4096	SOP	44	PA44SO44D	ATMEL	AT49F4096A	SOP	44	PA44SO44D
ATMEL	AT49F4096A	TSOP	48	PA48TS48D	ATMEL	AT49F4096AT	TSOP	48	PA48TS48D
ATMEL	AT49F4096AT	SOP	44	PA44SO44D	ATMEL	AT49F512	TSOP	32	PA32TS20/PA32TS32D-20
ATMEL	AT49F512	PLCC	32	PA32PL32D	ATMEL	AT49F512	DIP	32	Not use adapter
ATMEL	AT49F8004	TSOP	48	PA48TS48D	ATMEL	AT49F8004T	TSOP	48	PA48TS48D
ATMEL	AT49F8011	TSOP	48	PA48TS48D	ATMEL	AT49F8011T	TSOP	48	PA48TS48D
ATMEL	AT49F8192	TSOP	48	PA48TS48D	ATMEL	AT49F8192	SOP	44	PA44SO44D
ATMEL	AT49F8192A	SOP	44	PA44SO44D	ATMEL	AT49F8192A	TSOP	48	PA48TS48D
ATMEL	AT49F8192AT	SOP	44	PA44SO44D	ATMEL	AT49F8192AT	TSOP	48	PA48TS48D
ATMEL	AT49F8192T	SOP	44	PA44SO44D	ATMEL	AT49F8192T	TSOP	48	PA48TS48D
ATMEL	AT49LH002-xxJC	PLCC	32	PA32PL32D	ATMEL	AT49LH002-xxTC	TSOP	40	PA40TS40D
ATMEL	AT49LH004-xxJC	PLCC	32	PA32PL32D	ATMEL	AT49LH004-xxTC	TSOP	40	PA40TS40D
ATMEL	AT49LL040	PLCC	32	PA32PL32D	ATMEL	AT49LV001	DIP	32	Not use adapter
ATMEL	AT49LV001N	DIP	32	Not use adapter	ATMEL	AT49LV001NT	DIP	32	Not use adapter
ATMEL	AT49LV001T	DIP	32	Not use adapter	ATMEL	AT49LV002	DIP	32	Not use adapter
ATMEL	AT49LV002N	DIP	32	Not use adapter	ATMEL	AT49LV002NT	DIP	32	Not use adapter
ATMEL	AT49LV002T	DIP	32	Not use adapter	ATMEL	AT49LV010	DIP	32	Not use adapter
ATMEL	AT49LV020	DIP	32	Not use adapter	ATMEL	AT49LV040	DIP	32	Not use adapter
ATMEL	AT49LV040T	DIP	32	Not use adapter	ATMEL	AT49LV080	SOP	44	PA44SO44D
ATMEL	AT49LV080	TSOP	40	PA40TS40D	ATMEL	AT49LV080T	SOP	44	PA44SO44D
ATMEL	AT49LV080T	TSOP	40	PA40TS40D	ATMEL	AT49LV1025	PLCC	44	PA44-48U
ATMEL	AT49LV1614	TSOP	48	PA48TS48D	ATMEL	AT49LV1614A	TSOP	48	PA48TS48D
ATMEL	AT49LV1614AT	TSOP	48	PA48TS48D	ATMEL	AT49LV1614T	TSOP	48	PA48TS48D
ATMEL	AT49LV2048	SOP	44	PA44SO44D	ATMEL	AT49LV2048	TSOP	48	PA48TS48D
ATMEL	AT49LV4096A	TSOP	48	PA48TS48D	ATMEL	AT49LV4096A	SOP	44	PA44SO44D
ATMEL	AT49LV8192A	TSOP	48	PA48TS48D	ATMEL	AT49LW040	PLCC	32	PA32PL32D
ATMEL	AT49LW040	TSOP	40	PA40TS40D	ATMEL	AT49LW080	PLCC	32	PA32PL32D
ATMEL	AT49LW080	TSOP	40	PA40TS40D	ATMEL	AT49SV322A	TSOP	48	HA48TS48DJ
ATMEL	AT49SV322AT	TSOP	48	HA48TS48DJ	ATMEL	AT49SV802A	TSOP	48	HA48TS48DJ
ATMEL	AT49SV802A	BGA	48	HA48BG48DAY	ATMEL	AT49SV802AT	BGA	48	HA48BG48DAY
ATMEL	AT49SV802AT	TSOP	48	HA48TS48DJ	ATMEL	AT59C11	DIP	8	Not use adapter
ATMEL	AT59C13	DIP	8	Not use adapter	ATMEL	AT59C22	DIP	8	Not use adapter
ATMEL	AT87F51	PLCC	44	PA44-48U	ATMEL	AT87F51	DIP	40	Not use adapter
ATMEL	AT87F51RC	PLCC	44	PA44-48U	ATMEL	AT87F51RC	DIP	40	Not use adapter
ATMEL	AT87F52	PLCC	44	PA44-48U	ATMEL	AT87F52	DIP	40	Not use adapter
ATMEL	AT87F55	DIP	40	Not use adapter	ATMEL	AT87F55	PLCC	44	PA44-48U
ATMEL	AT87F55WD	DIP	40	Not use adapter	ATMEL	AT87F55WD	PLCC	44	PA44-48U
ATMEL	AT89C1051	DIP	20	Not use adapter	ATMEL	AT89C1051	SOP	20	PA28SO28D-08
ATMEL	AT89C1051U	DIP	20	Not use adapter	ATMEL	AT89C1051U	SOP	20	PA28SO28D-08
ATMEL	AT89C2051	DIP	20	Not use adapter	ATMEL	AT89C2051	SOP	20	PA28SO28D-08
ATMEL	AT89C2051X2	DIP	20	Not use adapter	ATMEL	AT89C2051X2	SOP	20	PA28SO28D-08
ATMEL	AT89C4051	DIP	20	Not use adapter	ATMEL	AT89C4051	SOP	20	PA28SO28D-08
ATMEL	AT89C51	DIP	40	Not use adapter	ATMEL	AT89C51	PLCC	44	PA44-48U
ATMEL	AT89C51CC03	PLCC	44	PA44-48U	ATMEL	AT89C51ED2	DIP	40	Not use adapter
ATMEL	AT89C51ED2	PLCC	44	PA44-48U	ATMEL	AT89C51ED2	QFP	44	PA44QF44D

ATMEL	AT89C51ED2	VQFP	64	PA64VQ40D	ATMEL	AT89C51ED2	PLCC	68	PA68PL40DG
ATMEL	AT89C51ID2	PLCC	44	PA44-48U	ATMEL	AT89C51ID2	QFP	44	PA44QF44D
ATMEL	AT89C51ID2	VQFP	64	PA64VQ40D	ATMEL	AT89C51ID2	PLCC	68	PA68PL40DG
ATMEL	AT89C51IRD2	DIP	40	Not use adapter	ATMEL	AT89C51RC	DIP	40	Not use adapter
ATMEL	AT89C51RC	PLCC	44	PA44-48U	ATMEL	AT89C51RC2-xL_3V	DIP	40	Not use adapter
ATMEL	AT89C51RC2-xL_3V	PLCC	44	PA44-48U	ATMEL	AT89C51RC2-xL_3V	QFP	44	PA44QF44D
ATMEL	AT89C51RC2-xM_5V	DIP	40	Not use adapter	ATMEL	AT89C51RC2-xM_5V	PLCC	44	PA44-48U
ATMEL	AT89C51RC2-xM_5V	QFP	44	PA44QF44D	ATMEL	AT89C51RD2	PLCC	44	PA44-48U
ATMEL	AT89C51RD2	VQFP	64	PA64VQ40D	ATMEL	AT89C51RD2	PLCC	68	PA68PL40DG
ATMEL	AT89C51RD2	QFP	44	PA44QF44D	ATMEL	AT89C52	PLCC	44	PA44-48U
ATMEL	AT89C52	DIP	40	Not use adapter	ATMEL	AT89C55	PLCC	44	PA44-48U
ATMEL	AT89C55	DIP	40	Not use adapter	ATMEL	AT89C55WD	DIP	40	Not use adapter
ATMEL	AT89C55WD	PLCC	44	PA44-48U	ATMEL	AT89LP2052	DIP	20	Not use adapter
ATMEL	AT89LP2052	TSSOP	20	PA24TSS24D(M)	ATMEL	AT89LP2052	SOP	20	PA28SO28D-08
ATMEL	AT89LP4052	DIP	20	Not use adapter	ATMEL	AT89LP4052	TSSOP	20	PA24TSS24D(M)
ATMEL	AT89LP4052	SOP	20	PA28SO28D-08	ATMEL	AT89LS1	TQFP	44	PA44VQ44D
ATMEL	AT89LS52	PLCC	44	PA44-48U	ATMEL	AT89LS52	DIP	40	Not use adapter
ATMEL	AT89LS8252	PLCC	44	PA44-48U	ATMEL	AT89LS8252	DIP	40	Not use adapter
ATMEL	AT89LV51	DIP	40	Not use adapter	ATMEL	AT89LV51	PLCC	44	PA44-48U
ATMEL	AT89LV52	PLCC	44	PA44-48U	ATMEL	AT89LV52	DIP	40	Not use adapter
ATMEL	AT89S2051	DIP	20	Not use adapter	ATMEL	AT89S2051	SOP	20	PA28SO28D-08
ATMEL	AT89S2051	TSSOP	20	PA24TSS24D(M)	ATMEL	AT89S4051	DIP	20	Not use adapter
ATMEL	AT89S4051	TSSOP	20	PA24TSS24D(M)	ATMEL	AT89S4051	SOP	20	PA28SO28D-08
ATMEL	AT89S51	DIP	40	Not use adapter	ATMEL	AT89S51	PLCC	44	PA44-48U
ATMEL	AT89S52	DIP	40	Not use adapter	ATMEL	AT89S52	PLCC	44	PA44-48U
ATMEL	AT89S53	PLCC	44	PA44-48U	ATMEL	AT89S53	DIP	40	Not use adapter
ATMEL	AT89S8252	DIP	40	Not use adapter	ATMEL	AT89S8252	PLCC	44	PA44-48U
ATMEL	AT89S8253	DIP	40	Not use adapter	ATMEL	AT89S8253	PLCC	44	PA44-48U
ATMEL	AT89S8253	QFP	44	PA44QF44D	ATMEL	AT90LS2323	DIP	8	Not use adapter
ATMEL	AT90LS2333	DIP	28	Not use adapter	ATMEL	AT90LS2343	DIP	8	Not use adapter
ATMEL	AT90LS4433	DIP	28	Not use adapter	ATMEL	AT90LS4434	PLCC	44	PA44-48U
ATMEL	AT90LS4434	DIP	40	Not use adapter	ATMEL	AT90LS8535	PLCC	44	PA44-48U
ATMEL	AT90LS8535	DIP	40	Not use adapter	ATMEL	AT90S1200	DIP	20	Not use adapter
ATMEL	AT90S1200	SOIC	20	PA28SO28D-EO-300	ATMEL	AT90S1200	SSOP	20	PA28SS28D
ATMEL	AT90S1200A	DIP	20	Not use adapter	ATMEL	AT90S1200A	SOIC	20	PA28SO28D-EO-300
ATMEL	AT90S1200A	SSOP	20	PA28SS28D	ATMEL	AT90S2313	DIP	20	Not use adapter
ATMEL	AT90S2323	DIP	8	Not use adapter	ATMEL	AT90S2333	DIP	28	Not use adapter
ATMEL	AT90S2343	DIP	8	Not use adapter	ATMEL	AT90S4414	DIP	40	Not use adapter
ATMEL	AT90S4414	PLCC	44	PA44-48U	ATMEL	AT90S4433	DIP	28	Not use adapter
ATMEL	AT90S4434	PLCC	44	PA44-48U	ATMEL	AT90S4434	DIP	40	Not use adapter
ATMEL	AT90S8515	DIP	40	Not use adapter	ATMEL	AT90S8515	PLCC	44	PA44-48U
ATMEL	AT90S8535	PLCC	44	PA44-48U	ATMEL	AT90S8535	DIP	40	Not use adapter
ATMEL	AT93C46	TSSOP	8	PA8TSS-OT	ATMEL	AT93C46	DIP	8	Not use adapter
ATMEL	AT93C46	SOIC	8	PA8SO8D	ATMEL	AT93C46A	DIP	8	Not use adapter
ATMEL	AT93C46A	TSSOP	8	PA8TSS-OT	ATMEL	AT93C46A	SOIC	8	PA8SO8D
ATMEL	AT93C46R	SOIC	8	PA8SO8D-EO-150	ATMEL	AT93C56	DIP	8	Not use adapter
ATMEL	AT93C56	TSSOP	8	PA8TSS-OT	ATMEL	AT93C56	SOIC	8	PA8SO8D
ATMEL	AT93C56A	DIP	8	Not use adapter	ATMEL	AT93C56A	TSSOP	8	PA8TSS-OT
ATMEL	AT93C56A	SOIC	8	PA8SO8D	ATMEL	AT93C56R	SOIC	8	PA8SO8D-EO-150
ATMEL	AT93C57	DIP	8	Not use adapter	ATMEL	AT93C57	SOIC	8	PA8SO8D
ATMEL	AT93C66	DIP	8	Not use adapter	ATMEL	AT93C66	TSSOP	8	PA8TSS-OT
ATMEL	AT93C66	SOIC	8	PA8SO8D	ATMEL	AT93C66A	DIP	8	Not use adapter
ATMEL	AT93C66A	TSSOP	8	PA8TSS-OT	ATMEL	AT93C66A	SOIC	8	PA8SO8D
ATMEL	AT93C66R	SOIC	8	PA8SO8D-EO-150	ATMEL	AT93C86	TSSOP	8	PA8TSS-OT
ATMEL	AT93C86	DIP	8	Not use adapter	ATMEL	AT93C86	SOIC	8	PA8SO8D
ATMEL	AT93C86A	DIP	8	Not use adapter	ATMEL	AT93C86A	TSSOP	8	PA8TSS-OT
ATMEL	AT93C86A	SOIC	8	PA8SO8D	ATMEL	ATF1500	PLCC	44	PA44-48U
ATMEL	ATF1500	QFP	44	PA44QF44D	ATMEL	ATF1500A	PLCC	44	PA44-48U
ATMEL	ATF1500A	QFP	44	PA44QF44D	ATMEL	ATF1500ABV	PLCC	44	PA44-48U
ATMEL	ATF1500ABV	QFP	44	PA44QF44D	ATMEL	ATF1500AL	PLCC	44	PA44-48U
ATMEL	ATF1500AL	QFP	44	PA44QF44D	ATMEL	ATF1502AS	PLCC	44	PA44-48U
ATMEL	ATF1502AS	QFP	44	PA44QF44D	ATMEL	ATF1502ASL	PLCC	44	PA44-48U
ATMEL	ATF1502ASL	QFP	44	PA44QF44D	ATMEL	ATF1502ASV	PLCC	44	PA44-48U
ATMEL	ATF1502ASV	QFP	44	PA44QF44D	ATMEL	ATF1504AS	PLCC	44	PA44-48U
ATMEL	ATF1504AS	PLCC	84	PA150X-84LC	ATMEL	ATF1504AS	PLCC	68	PA150X-68LC
ATMEL	ATF1504ASV	PLCC	44	PA44-48U	ATMEL	ATF1504ASV	PLCC	84	PA150X-84LC
ATMEL	ATF1504ASV	PLCC	68	PA150X-68LC	ATMEL	ATF1508AS	PLCC	84	PA150X-84LC
ATMEL	ATF1508AS	TQFP	100	PA100TQ48D	ATMEL	ATF1508ASV	PLCC	84	PA150X-84LC
ATMEL	ATF16LV8C	DIP	20	Not use adapter	ATMEL	ATF16LV8C	PLCC	20	PA20LC20D
ATMEL	ATF16LV8C	SOIC	20	PA20SO2006-200/PA20SO20D	ATMEL	ATF16LV8C	TSSOP	20	PA20SS-P54
ATMEL	ATF16LV8C as 10H8	DIP	20	Not use adapter	ATMEL	ATF16LV8C as 10H8	PLCC	20	PA20LC20D
ATMEL	ATF16LV8C as 10H8	TSSOP	20	PA20SS-P54	ATMEL	ATF16LV8C as 10H8	SOIC	20	PA20SO2006-200/PA20SO20D
ATMEL	ATF16LV8C as 10L8	DIP	20	Not use adapter	ATMEL	ATF16LV8C as 10L8	PLCC	20	PA20LC20D
ATMEL	ATF16LV8C as 10L8	TSSOP	20	PA20SS-P54	ATMEL	ATF16LV8C as 10L8	SOIC	20	PA20SO2006-200/PA20SO20D

ATMEL	ATF2500CQL	PLCC	44	PA44-48U	ATMEL	ATF2500CQL	DIP	40	Not use adapter
ATMEL	ATF2500CQL	TQFP	44	PA44QF44D	ATMEL	ATF2500CQL(V2500B)	DIP	40	Not use adapter
ATMEL	ATF2500CQL(V2500B)	PLCC	44	PA44-48U	ATMEL	ATF2500CQL(V2500B)	TQFP	44	PA44QF44D
ATMEL	ATF750C	DIP	24	Not use adapter	ATMEL	ATF750C	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750C	SOIC	24	PA28SO28D-08	ATMEL	ATF750C	PLCC	28	PA28PL28D
ATMEL	ATF750C(V750)	DIP	24	Not use adapter	ATMEL	ATF750C(V750)	SOIC	24	PA28SO28D-08
ATMEL	ATF750C(V750)	PLCC	28	PA28PL28D	ATMEL	ATF750C(V750)	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750C(V750B)	DIP	24	Not use adapter	ATMEL	ATF750C(V750B)	SOIC	24	PA28SO28D-08
ATMEL	ATF750C(V750B)	TSSOP	24	PA24TSS24D(M)	ATMEL	ATF750C(V750B)	PLCC	28	PA28PL28D
ATMEL	ATF750CEXT	DIP	24	Not use adapter	ATMEL	ATF750CEXT	SOIC	24	PA28SO28D-08
ATMEL	ATF750CEXT	PLCC	28	PA28PL28D	ATMEL	ATF750CEXT	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750CL	DIP	24	Not use adapter	ATMEL	ATF750CL	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750CL	PLCC	28	PA28PL28D	ATMEL	ATF750CL	SOIC	24	PA28SO28D-08
ATMEL	ATF750CL(V750)	DIP	24	Not use adapter	ATMEL	ATF750CL(V750)	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750CL(V750)	PLCC	28	PA28PL28D	ATMEL	ATF750CL(V750)	SOIC	24	PA28SO28D-08
ATMEL	ATF750CL(V750B)	DIP	24	Not use adapter	ATMEL	ATF750CL(V750B)	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750CL(V750B)	SOIC	24	PA28SO28D-08	ATMEL	ATF750CL(V750B)	PLCC	28	PA28PL28D
ATMEL	ATF750LVC	DIP	24	Not use adapter	ATMEL	ATF750LVC	PLCC	28	PA28PL28D
ATMEL	ATF750LVC	SOIC	24	PA28SO28D-08	ATMEL	ATF750LVC	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750LVC(V750)	DIP	24	Not use adapter	ATMEL	ATF750LVC(V750)	SOIC	24	PA28SO28D-08
ATMEL	ATF750LVC(V750)	PLCC	28	PA28PL28D	ATMEL	ATF750LVC(V750)	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750LVC(V750B)	DIP	24	Not use adapter	ATMEL	ATF750LVC(V750B)	PLCC	28	PA28PL28D
ATMEL	ATF750LVC(V750B)	SOIC	24	PA28SO28D-08	ATMEL	ATF750LVC(V750B)	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750LVCEXT	DIP	24	Not use adapter	ATMEL	ATF750LVCEXT	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750LVCEXT	PLCC	28	PA28PL28D	ATMEL	ATF750LVCEXT	SOIC	24	PA28SO28D-08
ATMEL	ATF750LVCL	DIP	24	Not use adapter	ATMEL	ATF750LVCL	TSSOP	24	PA24TSS24D(M)
ATMEL	ATF750LVCL	PLCC	28	PA28PL28D	ATMEL	ATF750LVCL	SOIC	24	PA28SO28D-08
ATMEL	ATF750LVCL(V750)	DIP	24	Not use adapter	ATMEL	ATF750LVCL(V750)	PLCC	28	PA28PL28D
ATMEL	ATF750LVCL(V750)	TSSOP	24	PA24TSS24D(M)	ATMEL	ATF750LVCL(V750)	SOIC	24	PA28SO28D-08
ATMEL	ATF750LVCL(V750B)	DIP	24	Not use adapter	ATMEL	ATF750LVCL(V750B)	SOIC	24	PA28SO28D-08
ATMEL	ATF750LVCL(V750B)	PLCC	28	PA28PL28D	ATMEL	ATF750LVCL(V750B)	TSSOP	24	PA24TSS24D(M)
ATMEL	ATMEGA128	TQFP	64	PA64QF48DD	ATMEL	ATMEGA16	DIP	40	Not use adapter
ATMEL	ATMEGA16	QFP	44	PA44QF44D	ATMEL	ATMEGA161	PLCC	44	PA44-48U
ATMEL	ATMEGA161	DIP	40	Not use adapter	ATMEL	ATMEGA161	QFP	44	PA44QF44D
ATMEL	ATMEGA161L	PLCC	44	PA44-48U	ATMEL	ATMEGA161L	DIP	40	Not use adapter
ATMEL	ATMEGA161L	QFP	44	PA44QF44D	ATMEL	ATMEGA163	DIP	40	Not use adapter
ATMEL	ATMEGA163	QFP	44	PA44QF44D	ATMEL	ATMEGA163L	DIP	40	Not use adapter
ATMEL	ATMEGA163L	QFP	44	PA44QF44D	ATMEL	ATMEGA168	DIP	28	Not use adapter
ATMEL	ATMEGA168	MLF	32	AS-32-28-01ML-6	ATMEL	ATMEGA168V	DIP	28	Not use adapter
ATMEL	ATMEGA168V	MLF	32	AS-32-28-01ML-6	ATMEL	ATMEGA16L	DIP	40	Not use adapter
ATMEL	ATMEGA16L	QFP	44	PA44QF44D	ATMEL	ATMEGA32	DIP	40	Not use adapter
ATMEL	ATMEGA32	QFP	44	PA44QF44D	ATMEL	ATMEGA32L	DIP	40	Not use adapter
ATMEL	ATMEGA32L	QFP	44	PA44QF44D	ATMEL	ATMEGA48	DIP	28	Not use adapter
ATMEL	ATMEGA48	MLF	32	AS-32-28-01ML-6	ATMEL	ATMEGA48V	DIP	28	Not use adapter
ATMEL	ATMEGA48V	MLF	32	AS-32-28-01ML-6	ATMEL	ATMEGA8	DIP	28	Not use adapter
ATMEL	ATMEGA8	TQFP	32	PA32TQ32DA	ATMEL	ATMEGA8	MLF	32	AS-32-28-01ML-6
ATMEL	ATMEGA8515	PLCC	44	PA44-48U	ATMEL	ATMEGA8515	DIP	40	Not use adapter
ATMEL	ATMEGA8515	QFP	44	PA44QF44D	ATMEL	ATMEGA8515L	DIP	40	Not use adapter
ATMEL	ATMEGA8515L	PLCC	44	PA44-48U	ATMEL	ATMEGA8515L	QFP	44	PA44QF44D
ATMEL	ATMEGA8535	PLCC	44	PA44-48U	ATMEL	ATMEGA8535	DIP	40	Not use adapter
ATMEL	ATMEGA8535	QFP	44	PA44QF44D	ATMEL	ATMEGA8535L	PLCC	44	PA44-48U
ATMEL	ATMEGA8535L	DIP	40	Not use adapter	ATMEL	ATMEGA8535L	QFP	44	PA44QF44D
ATMEL	ATMEGA88	DIP	28	Not use adapter	ATMEL	ATMEGA88	MLF	32	AS-32-28-01ML-6
ATMEL	ATMEGA88V	DIP	28	Not use adapter	ATMEL	ATMEGA88V	MLF	32	AS-32-28-01ML-6
ATMEL	ATMEGA8L	DIP	28	Not use adapter	ATMEL	ATMEGA8L	MLF	32	AS-32-28-01ML-6
ATMEL	ATTINY13	DIP	8	Not use adapter	ATMEL	ATTINY13V	DIP	8	Not use adapter
ATMEL	ATTINY2313	DIP	20	Not use adapter	ATMEL	ATTINY2313	SOIC	20	PA28SO28D-08
ATMEL	ATTINY26	DIP	20	Not use adapter	ATMEL	ATTINY26	MLF	32	AS-32-28-01ML-6
ATMEL	ATTINY26	SOIC	20	PA28SO28D-08	ATMEL	ATTINY26L	DIP	20	Not use adapter
ATMEL	ATTINY26L	SOIC	20	PA28SO28D-08	ATMEL	ATTINY26L	MLF	32	AS-32-28-01ML-6
ATMEL	ATTINY28L	DIP	28	Not use adapter	ATMEL	ATTINY28L	QFP	32	PA32TQ32D-YC
ATMEL	ATTINY28V	DIP	28	Not use adapter	ATMEL	ATTINY28V	QFP	32	PA32TQ32D-YC
ATMEL(TEMIC)	T89C51AC2	PLCC	44	PA44-48U	ATMEL(TEMIC)	T89C51CC01	PLCC	44	PA44-48U
ATMEL(TEMIC)	T89C51CC01	TQFP	44	PA44VQ44D	ATMEL(TEMIC)	T89C51IB2-xL_3V	PLCC	44	PA44-48U
ATMEL(TEMIC)	T89C51IB2-xM_5V	PLCC	44	PA44-48U	ATMEL(TEMIC)	T89C51IC2-xL_3V	PLCC	44	PA44-48U
ATMEL(TEMIC)	T89C51IC2-xM_5V	PLCC	44	PA44-48U	ATMEL(TEMIC)	T89C51RB2-xL_3V	PLCC	44	PA44-48U
ATMEL(TEMIC)	T89C51RB2-xL_3V	DIP	40	Not use adapter	ATMEL(TEMIC)	T89C51RB2-xM_5V	PLCC	44	PA44-48U
ATMEL(TEMIC)	T89C51RB2-xM_5V	DIP	40	Not use adapter	ATMEL(TEMIC)	T89C51RC2-xL_3V	PLCC	44	PA44-48U
ATMEL(TEMIC)	T89C51RC2-xL_3V	DIP	40	Not use adapter	ATMEL(TEMIC)	T89C51RC2-xM_5V	PLCC	44	PA44-48U
ATMEL(TEMIC)	T89C51RC2-xM_5V	DIP	40	Not use adapter	ATMEL(TEMIC)	T89C51RD2-xL_3V	DIP	40	Not use adapter
ATMEL(TEMIC)	T89C51RD2-xL_3V	PLCC	44	PA44-48U	ATMEL(TEMIC)	T89C51RD2-xM_5V	PLCC	44	PA44-48U
ATMEL(TEMIC)	T89C51RD2-xM_5V	DIP	40	Not use adapter	ATMEL(TEMIC)	TS87C51U2	DIP	40	Not use adapter
ATMEL(TEMIC)	TS87C51U2	PLCC	44	PA44-48U	ATMEL(TEMIC)	TSC71RBX2	DIP	40	Not use adapter
ATMEL(TEMIC)	TSC71RBX2	PLCC	44	PA44-48U	ATMEL(TEMIC)	TSC71RCX2	PLCC	44	PA44-48U

ATMEL(TEMIC)	TSC71RCX2	DIP	40	Not use adapter	ATMEL(TEMIC)	TSC71RDX2	DIP	40	Not use adapter
ATMEL(TEMIC)	TSC71RDX2	PLCC	44	PA44-48U	ATMEL(TEMIC)	TSC87251G1A	DIP	40	Not use adapter
ATMEL(TEMIC)	TSC87251G1A	PLCC	44	PA44-48U	ATMEL(TEMIC)	TSC87251G1D	PLCC	44	PA44-48U
ATMEL(TEMIC)	TSC87251G1D	DIP	40	Not use adapter	ATMEL(TEMIC)	TSC87251G2D	PLCC	44	PA44-48U
ATMEL(TEMIC)	TSC87251G2D	DIP	40	Not use adapter	ATMEL(TEMIC)	TSC87C51	PLCC	44	PA44-48U
ATMEL(TEMIC)	TSC87C51	DIP	40	Not use adapter	ATMEL(TEMIC)	TSC87C51RB2	DIP	40	Not use adapter
ATMEL(TEMIC)	TSC87C51RB2	PLCC	44	PA44-48U	ATMEL(TEMIC)	TSC87C51RC2	DIP	40	Not use adapter
ATMEL(TEMIC)	TSC87C51RC2	PLCC	44	PA44-48U	ATMEL(TEMIC)	TSC87C51RD2	PLCC	44	PA44-48U
ATMEL(TEMIC)	TSC87C51RD2	DIP	40	Not use adapter	ATMEL(TEMIC)	TSC87C52	DIP	40	Not use adapter
ATMEL(TEMIC)	TSC87C52	PLCC	44	PA44-48U	ATMEL(TEMIC)	TSC87C52X2	DIP	40	Not use adapter
ATMEL(TEMIC)	TSC87C52X2	PLCC	44	PA44-48U	ATMEL(TEMIC)	TSC87C54	PLCC	44	PA44-48U
ATMEL(TEMIC)	TSC87C54	DIP	40	Not use adapter	ATMEL(TEMIC)	TSC87C58	DIP	40	Not use adapter
ATMEL(TEMIC)	TSC87C58	PLCC	44	PA44-48U	BENCHMARQ	BQ4011	DIP	28	Not use adapter
BENCHMARQ	BQ4013	DIP	32	Not use adapter	BENCHMARQ	BQ4013Y	DIP	32	Not use adapter
BRIGHT	BM29F040	DIP	32	Not use adapter	BRIGHT	BM29F400B	TSOP	48	PA48TS48D
BRIGHT	BM29F400B	SOP	44	PA44SO44D	BRIGHT	BM29F400T	SOP	44	PA44SO44D
BRIGHT	BM29F400T	TSOP	48	PA48TS48D	CATALYST	CAT24C02	DIP	8	Not use adapter
CATALYST	CAT24C04	DIP	8	Not use adapter	CATALYST	CAT24C08	DIP	8	Not use adapter
CATALYST	CAT24C16	DIP	8	Not use adapter	CATALYST	CAT24FC32A	DIP	8	Not use adapter
CATALYST	CAT24WC01	DIP	8	Not use adapter	CATALYST	CAT24WC02	DIP	8	Not use adapter
CATALYST	CAT24WC04	DIP	8	Not use adapter	CATALYST	CAT24WC08	DIP	8	Not use adapter
CATALYST	CAT24WC128	DIP	8	Not use adapter	CATALYST	CAT24WC16	DIP	8	Not use adapter
CATALYST	CAT24WC32	DIP	8	Not use adapter	CATALYST	CAT24WC64	DIP	8	Not use adapter
CATALYST	CAT25C02	DIP	8	Not use adapter	CATALYST	CAT25C04	DIP	8	Not use adapter
CATALYST	CAT25C08	DIP	8	Not use adapter	CATALYST	CAT25C128	DIP	8	Not use adapter
CATALYST	CAT25C16	DIP	8	Not use adapter	CATALYST	CAT25C256	DIP	8	Not use adapter
CATALYST	CAT25C32	DIP	8	Not use adapter	CATALYST	CAT25C32S	DIP	8	Not use adapter
CATALYST	CAT25C64	DIP	8	Not use adapter	CATALYST	CAT27010	DIP	32	Not use adapter
CATALYST	CAT27128A	DIP	28	Not use adapter	CATALYST	CAT27128A	PLCC	32	PA32-28
CATALYST	CAT27256	DIP	28	Not use adapter	CATALYST	CAT27512	DIP	28	Not use adapter
CATALYST	CAT2764A	DIP	28	Not use adapter	CATALYST	CAT27C210	DIP	40	Not use adapter
CATALYST	CAT27C210	PLCC	44	PA44-48U	CATALYST	CAT27HC256	DIP	28	Not use adapter
CATALYST	CAT27HC256	PLCC	32	PA32-28	CATALYST	CAT27HC256L	DIP	28	Not use adapter
CATALYST	CAT27HC256L	PLCC	32	PA32-28	CATALYST	CAT28C16A	DIP	24	Not use adapter
CATALYST	CAT28C17A	DIP	28	Not use adapter	CATALYST	CAT28C256	DIP	28	Not use adapter
CATALYST	CAT28C512	DIP	32	Not use adapter	CATALYST	CAT28C512	TSOP	32	PA32TS20/PA32TS32D-20
CATALYST	CAT28C512	PLCC	32	PA32PL32D	CATALYST	CAT28C513	PLCC	32	PA32PL32D
CATALYST	CAT28C64A	DIP	28	Not use adapter	CATALYST	CAT28C64B	DIP	28	Not use adapter
CATALYST	CAT28C65A	DIP	28	Not use adapter	CATALYST	CAT28C65BJ	SOIC	28	PA28SO28D-08
CATALYST	CAT28F010	DIP	32	Not use adapter	CATALYST	CAT28F010	PLCC	32	PA32PL32D
CATALYST	CAT28F020	PLCC	32	PA32PL32D	CATALYST	CAT28F020	DIP	32	Not use adapter
CATALYST	CAT33C101	DIP	8	Not use adapter	CATALYST	CAT33C104	DIP	8	Not use adapter
CATALYST	CAT33C116	DIP	8	Not use adapter	CATALYST	CAT33C116I	DIP	8	Not use adapter
CATALYST	CAT33C204	DIP	8	Not use adapter	CATALYST	CAT35C102	DIP	8	Not use adapter
CATALYST	CAT35C104	DIP	8	Not use adapter	CATALYST	CAT35C116	DIP	8	Not use adapter
CATALYST	CAT35C116I	DIP	8	Not use adapter	CATALYST	CAT35C202	DIP	8	Not use adapter
CATALYST	CAT35C204	DIP	8	Not use adapter	CATALYST	CAT59C11	DIP	8	Not use adapter
CATALYST	CAT93C46	DIP	8	Not use adapter	CATALYST	CAT93C46	TSSOP	8	PA8TSS-OT
CATALYST	CAT93C46	SOIC	8	PA8SO8D	CATALYST	CAT93C46A	DIP	8	Not use adapter
CATALYST	CAT93C46A	SOIC	8	PA8SO8D	CATALYST	CAT93C46A-J	SOIC	8	PA8SO8D-EO-150
CATALYST	CAT93C46-J	SOIC	8	PA8SO8D-EO-150	CATALYST	CAT93C56	DIP	8	Not use adapter
CATALYST	CAT93C56	TSSOP	8	PA8TSS-OT	CATALYST	CAT93C56	SOIC	8	PA8SO8D
CATALYST	CAT93C56-J	SOIC	8	PA8SO8D-EO-150	CATALYST	CAT93C57	DIP	8	Not use adapter
CATALYST	CAT93C57	TSSOP	8	PA8TSS-OT	CATALYST	CAT93C57	SOIC	8	PA8SO8D
CATALYST	CAT93C57-J	SOIC	8	PA8SO8D-EO-150	CATALYST	CAT93C66	DIP	8	Not use adapter
CATALYST	CAT93C66	TSSOP	8	PA8TSS-OT	CATALYST	CAT93C66	SOIC	8	PA8SO8D
CATALYST	CAT93C66A	TSSOP	8	PA8TSS-OT	CATALYST	CAT93C66A	DIP	8	Not use adapter
CATALYST	CAT93C66A	SOIC	8	PA8SO8D	CATALYST	CAT93C66A-J	SOIC	8	PA8SO8D-EO-150
CATALYST	CAT93C66-J	SOIC	8	PA8SO8D-EO-150	CATALYST	CAT93C86	DIP	8	Not use adapter
CATALYST	CAT93C86	TSSOP	8	PA8TSS-OT	CATALYST	CAT93C86	SOIC	8	PA8SO8D
CATALYST	CAT93C86A	TSSOP	8	PA8TSS-OT	CATALYST	CAT93C86A	DIP	8	Not use adapter
CATALYST	CAT93C86A	SOIC	8	PA8SO8D	CATALYST	CAT93C86A-J	SOIC	8	PA8SO8D-EO-150
CATALYST	CAT93C86-J	SOIC	8	PA8SO8D-EO-150	CYPRESS	CY27C010	DIP	32	Not use adapter
CYPRESS	CY27C020	DIP	32	Not use adapter	CYPRESS	CY27C040	DIP	32	Not use adapter
CYPRESS	CY27C256	DIP	28	Not use adapter	CYPRESS	CY27C256	PLCC	32	PA32-28
CYPRESS	CY27C256	TSOP	28	PA28TSOP3	CYPRESS	CY27C256A	DIP	28	Not use adapter
CYPRESS	CY27C256A	PLCC	32	PA32-28	CYPRESS	CY27C256A	TSOP	28	PA28TSOP3
CYPRESS	CY27C512	DIP	28	Not use adapter	CYPRESS	CY27H256	DIP	28	Not use adapter
CYPRESS	CY27H256	PLCC	32	PA32-28	CYPRESS	CY7C225	DIP	24	Not use adapter
CYPRESS	CY7C225	PLCC	28	PA28PL28D	CYPRESS	CY7C225A	DIP	24	Not use adapter
CYPRESS	CY7C225A	PLCC	28	PA28PL28D	CYPRESS	CY7C235	DIP	24	Not use adapter
CYPRESS	CY7C235	PLCC	28	PA28PL28D	CYPRESS	CY7C235A	DIP	24	Not use adapter
CYPRESS	CY7C235A	PLCC	28	PA28PL28D	CYPRESS	CY7C245	DIP	24	Not use adapter
CYPRESS	CY7C245	PLCC	28	PA28PL28D	CYPRESS	CY7C245A	DIP	24	Not use adapter

CYPRESS	CY7C245A	PLCC	28	PA28PL28D	CYPRESS	CY7C251	DIP	28	Not use adapter
CYPRESS	CY7C254	DIP	28	Not use adapter	CYPRESS	CY7C261	DIP	24	Not use adapter
CYPRESS	CY7C261	PLCC	28	PA28PL28D	CYPRESS	CY7C263	DIP	24	Not use adapter
CYPRESS	CY7C263	PLCC	28	PA28PL28D	CYPRESS	CY7C264	DIP	24	Not use adapter
CYPRESS	CY7C264	PLCC	28	PA28PL28D	CYPRESS	CY7C265	DIP	28	Not use adapter
CYPRESS	CY7C265	PLCC	28	PA28PL28D	CYPRESS	CY7C266	DIP	28	Not use adapter
CYPRESS	CY7C266	PLCC	32	PA32PL32D	CYPRESS	CY7C268	DIP	32	Not use adapter
CYPRESS	CY7C269	DIP	28	Not use adapter	CYPRESS	CY7C270	PLCC	44	PA44-48U
CYPRESS	CY7C271	PLCC	32	PA32PL32D	CYPRESS	CY7C271	DIP	28	Not use adapter
CYPRESS	CY7C271A	DIP	28	Not use adapter	CYPRESS	CY7C271A	PLCC	32	PA32PL32D
CYPRESS	CY7C274	PLCC	32	PA32PL32D	CYPRESS	CY7C274	DIP	28	Not use adapter
CYPRESS	CY7C274A	PLCC	32	PA32PL32D	CYPRESS	CY7C274A	DIP	28	Not use adapter
CYPRESS	CY7C276	PLCC	44	PA44-48U	CYPRESS	CY7C277	DIP	28	Not use adapter
CYPRESS	CY7C279	DIP	28	Not use adapter	CYPRESS	CY7C281	DIP	24	Not use adapter
CYPRESS	CY7C281	PLCC	28	PA28PL28D	CYPRESS	CY7C281A	DIP	24	Not use adapter
CYPRESS	CY7C281A	PLCC	28	PA28PL28D	CYPRESS	CY7C282	DIP	24	Not use adapter
CYPRESS	CY7C282	PLCC	28	PA28PL28D	CYPRESS	CY7C282A	DIP	24	Not use adapter
CYPRESS	CY7C282A	PLCC	28	PA28PL28D	CYPRESS	CY7C285	DIP	28	Not use adapter
CYPRESS	CY7C286	DIP	28	Not use adapter	CYPRESS	CY7C287	DIP	28	Not use adapter
CYPRESS	CY7C289	DIP	32	Not use adapter	CYPRESS	CY7C291	DIP	24	Not use adapter
CYPRESS	CY7C291	PLCC	28	PA28PL28D	CYPRESS	CY7C291A	DIP	24	Not use adapter
CYPRESS	CY7C291A	PLCC	28	PA28PL28D	CYPRESS	CY7C292	DIP	24	Not use adapter
CYPRESS	CY7C292	PLCC	28	PA28PL28D	CYPRESS	CY7C292A	DIP	24	Not use adapter
CYPRESS	CY7C292A	PLCC	28	PA28PL28D	CYPRESS	CY7C293A	DIP	24	Not use adapter
CYPRESS	CY7C293A	PLCC	28	PA28PL28D	DALLAS	DS1220AB	DIP	24	Not use adapter
DALLAS	DS1220AD	DIP	24	Not use adapter	DALLAS	DS1220Y	DIP	24	Not use adapter
DALLAS	DS1225AB	DIP	28	Not use adapter	DALLAS	DS1225AD	DIP	28	Not use adapter
DALLAS	DS1225Y	DIP	28	Not use adapter	DALLAS	DS1230AB	DIP	28	Not use adapter
DALLAS	DS1230Y	DIP	28	Not use adapter	DALLAS	DS1235YW	DIP	28	Not use adapter
DALLAS	DS1243Y	DIP	28	Not use adapter	DALLAS	DS1244Y	DIP	28	Not use adapter
DALLAS	DS1245AB	DIP	32	Not use adapter	DALLAS	DS1245Y	DIP	32	Not use adapter
DALLAS	DS1248Y	DIP	32	Not use adapter	DALLAS	DS12887	DIP	24	Not use adapter
DALLAS	DS12C887	DIP	24	Not use adapter	DALLAS	DS1624	DIP	8	Not use adapter
DALLAS	DS1624S	SOIC	8	PA20SO2006-200/PA20SO20D	DALLAS	DS1642	DIP	24	Not use adapter
DALLAS	DS87C520	PLCC	44	PA44-48U	DALLAS	DS87C520	DIP	40	Not use adapter
DALLAS	DS87C530	PLCC	52	PA530-52	DALLAS	DS89C420	PLCC	44	PA44-48U
DALLAS	DS89C420	DIP	40	Not use adapter	DALLAS	DS89C420 REV B4	DIP	40	Not use adapter
DALLAS	DS89C420 REV B4	PLCC	44	PA44-48U	DALLAS	DS89C420 REV B4	TQFP	44	PA44QF44D
DALLAS	DS89C430	PLCC	44	PA44-48U	DALLAS	DS89C430	DIP	40	Not use adapter
DALLAS	DS89C430	TQFP	44	PA44QF44D	DALLAS	DS89C440	PLCC	44	PA44-48U
DALLAS	DS89C440	DIP	40	Not use adapter	DALLAS	DS89C440	TQFP	44	PA44QF44D
DALLAS	DS89C450	PLCC	44	PA44-48U	DALLAS	DS89C450	DIP	40	Not use adapter
DALLAS	DS89C450	TQFP	44	PA44QF44D	DENSE	DPV27C101	DIP	32	Not use adapter
DENSE	DPV27C256	DIP	28	Not use adapter	DENSE	DPV27C512	DIP	28	Not use adapter
EON	EN27C010	DIP	32	Not use adapter	EON	EN27C020	DIP	32	Not use adapter
EON	EN27C512	DIP	28	Not use adapter	EON	EN27C512	PLCC	32	PA32-28
EON	EN27C512	PLCC	32	PA32-28	EON	EN27C512	PLCC	32	PA32-28
EON	EN27C512	PLCC	32	PA32-28	EON	EN27C512	PLCC	32	PA32-28
EON	EN27C512	PLCC	32	PA32-28	EON	EN27C512	PLCC	32	PA32-28
EON	EN27C512	PLCC	32	PA32-28	EON	EN27LV010	DIP	32	Not use adapter
EON	EN27LV010B	DIP	32	Not use adapter	EON	EN27LV020	DIP	32	Not use adapter
EON	EN27LV020B	DIP	32	Not use adapter	EON	EN27LV512	DIP	28	Not use adapter
EON	EN27LV512	PLCC	32	PA32-28	EON	EN27LV512	PLCC	32	PA32-28
EON	EN27LV512	PLCC	32	PA32-28	EON	EN27LV512	PLCC	32	PA32-28
EON	EN27LV512	PLCC	32	PA32-28	EON	EN27LV512	PLCC	32	PA32-28
EON	EN27LV512	PLCC	32	PA32-28	EON	EN27LV512	PLCC	32	PA32-28
EON	EN27LV512B	DIP	28	Not use adapter	EON	EN27LV512B	PLCC	32	PA32-28
EON	EN27LV512B	PLCC	32	PA32-28	EON	EN27LV512B	PLCC	32	PA32-28
EON	EN27LV512B	PLCC	32	PA32-28	EON	EN27LV512B	PLCC	32	PA32-28
EON	EN27LV512B	PLCC	32	PA32-28	EON	EN27LV512B	PLCC	32	PA32-28
EON	EN27LV512B	PLCC	32	PA32-28	EON	EN29F002ANT	PLCC	32	PA32PL32D
EON	EN29F002B	DIP	32	Not use adapter	EON	EN29F002NB	DIP	32	Not use adapter
EON	EN29F002NT	DIP	32	Not use adapter	EON	EN29F002T	DIP	32	Not use adapter
EON	EN29F010	PLCC	32	PA32PL32D	EON	EN29F010	TSOP	32	PA32TS20/PA32TS32D-20
EON	EN29F040	DIP	32	Not use adapter	EON	EN29F040A	PLCC	32	PA32PL32D
EON	EN29F512	PLCC	32	PA32PL32D	EON	EN29F512	TSOP	32	PA32TS20/PA32TS32D-20
EON	EN29LV010	PLCC	32	PA32PL32D	EON	EN29LV010	TSOP	32	PA32TS20/PA32TS32D-20
EON	EN29LV040	PLCC	32	PA32PL32D	EON	EN29LV040	sTSOP	32	PA32ST32D
EON	EN29LV040A	PLCC	32	PA32PL32D	EON	EN29LV040A	sTSOP	32	PA32ST32D
EON	EN29LV160AB	TSOP	48	PA48TS48D1	EON	EN29LV160AT	TSOP	48	PA48TS48D1
EON	EN29LV320B	TSOP	48	PA48TS48D1	EON	EN29LV320T	TSOP	48	PA48TS48D1
EON	EN29LV400B	TSOP	48	PA48TS48D	EON	EN29LV400T	TSOP	48	PA48TS48D
EON	EN29LV512	PLCC	32	PA32PL32D	EON	EN29LV512	TSOP	32	PA32TS20/PA32TS32D-20
EON	EN29LV641H	TSOP	48	PA48TS48D	EON	EN29LV641L	TSOP	48	PA48TS48D

EON	EN29LV800AB	TSOP	48	PA48TS48D	EON	EN29LV800AT	TSOP	48	PA48TS48D
EON	EN29LV800BB	TSOP	48	PA48TS48D1	EON	EN29LV800BT	TSOP	48	PA48TS48D1
EXCELSEMI	ES29LV160DB	TSOP	48	PA48TS48D1	EXCELSEMI	ES29LV160DT	TSOP	48	PA48TS48D1
EXCELSEMI	ES29LV160EB	TSOP	48	PA48TS48D1	EXCELSEMI	ES29LV160ET	TSOP	48	PA48TS48D1
EXCELSEMI	ES29LV320DB	TSOP	48	PA48TS48D1	EXCELSEMI	ES29LV320DT	TSOP	48	PA48TS48D1
EXCELSEMI	ES29LV400EB	BGA	48	HA48BG48DBC	EXCELSEMI	ES29LV400EB	TSOP	48	PA48TS48D1
EXCELSEMI	ES29LV400ET	BGA	48	HA48BG48DBC	EXCELSEMI	ES29LV400ET	TSOP	48	PA48TS48D1
EXCELSEMI	ES29LV800DB	TSOP	48	PA48TS48D1	EXCELSEMI	ES29LV800DT	TSOP	48	PA48TS48D1
EXCELSEMI	ES29LV800EB	BGA	48	HA48BG48DBC	EXCELSEMI	ES29LV800EB	TSOP	48	PA48TS48D1
EXCELSEMI	ES29LV800ET	TSOP	48	PA48TS48D1	EXCELSEMI	ES29LV800ET	BGA	48	HA48BG48DBC
EXEL	XL93C06	DIP	8	Not use adapter	EXEL	XL93C06	SOIC	8	PA8SO8D
EXEL	XL93C46	DIP	8	Not use adapter	EXEL	XL93C46	SOIC	8	PA8SO8D
EXEL	XL93C46A	DIP	8	Not use adapter	EXEL	XL93C46A	SOIC	8	PA8SO8D
EXEL	XL93C56	DIP	8	Not use adapter	EXEL	XL93C56	SOIC	8	PA8SO8D
EXEL	XL93C56A	DIP	8	Not use adapter	EXEL	XL93C56A	SOIC	8	PA8SO8D
EXEL	XL93C66	DIP	8	Not use adapter	EXEL	XL93C66	SOIC	8	PA8SO8D
EXEL	XL93C66A	DIP	8	Not use adapter	EXEL	XL93C66A	SOIC	8	PA8SO8D
EXEL	XL93CS46	DIP	8	Not use adapter	EXEL	XL93LC46	DIP	8	Not use adapter
EXEL	XL93LC46	SOIC	8	PA8SO8D	EXEL	XL93LC56	DIP	8	Not use adapter
EXEL	XL93LC56	SOIC	8	PA8SO8D	EXEL	XL93LC66	DIP	8	Not use adapter
EXEL	XL93LC66	SOIC	8	PA8SO8D	EXEL	XL93LL46	DIP	8	Not use adapter
EXEL	XL93LL56	DIP	8	Not use adapter	EXEL	XL93LL66	DIP	8	Not use adapter
EXEL	XLE93C46	DIP	8	Not use adapter	EXEL	XLE93C56	DIP	8	Not use adapter
EXEL	XLE93C66	DIP	8	Not use adapter	EXEL	XLE93CS46	DIP	8	Not use adapter
EXEL	XLS2804A	DIP	24	Not use adapter	EXEL	XLS2816A	DIP	24	Not use adapter
EXEL	XLS2817A	DIP	28	Not use adapter	EXEL	XLS2864A	DIP	28	Not use adapter
EXEL	XLS2865A	DIP	28	Not use adapter	EXEL	XLS93C46	DIP	8	Not use adapter
EXEL	XLS93C46	SOIC	8	PA8SO8D	EXEL	XLS93C56	DIP	8	Not use adapter
EXEL	XLS93C56	SOIC	8	PA8SO8D	EXEL	XLS93C66	DIP	8	Not use adapter
EXEL	XLS93C66	SOIC	8	PA8SO8D	EXEL	XLS93CS46	DIP	8	Not use adapter
EXEL	XLS93LC46	DIP	8	Not use adapter	EXEL	XLS93LC56	DIP	8	Not use adapter
EXEL	XLS93LC66	DIP	8	Not use adapter	FAIRCHILD	F2732	DIP	24	Not use adapter
FAIRCHILD	FM27C040Q	DIP	32	Not use adapter	FAIRCHILD	FM27C256	DIP	28	Not use adapter
FAIRCHILD	FM27C256	PLCC	32	PA32-28	FAIRCHILD	NM27C128	DIP	28	Not use adapter
FAIRCHILD	NM27C128	PLCC	32	PA32-28	FAIRCHILD	NM27C256	DIP	28	Not use adapter
FAIRCHILD	NM27C256	PLCC	32	PA32-28	FAIRCHILD	NM27C256B	DIP	28	Not use adapter
FAIRCHILD	NM27C256B	PLCC	32	PA32-28	FAIRCHILD	NM27LC256	DIP	28	Not use adapter
FAIRCHILD	NM27LC256	PLCC	32	PA32-28	FAIRCHILD	NM93C06	TSSOP	8	PA8TSS-OT
FAIRCHILD	NM93C06	DIP	8	Not use adapter	FAIRCHILD	NM93C06	SOIC	8	PA8SO8D
FAIRCHILD	NM93C46	TSSOP	8	PA8TSS-OT	FAIRCHILD	NM93C46	DIP	8	Not use adapter
FAIRCHILD	NM93C46	SOIC	8	PA8SO8D	FAIRCHILD	NM93C56	TSSOP	8	PA8TSS-OT
FAIRCHILD	NM93C56	DIP	8	Not use adapter	FAIRCHILD	NM93C56	SOIC	8	PA8SO8D
FAIRCHILD	NM93C66	DIP	8	Not use adapter	FAIRCHILD	NM93C66	TSSOP	8	PA8TSS-OT
FAIRCHILD	NM93C66	SOIC	8	PA8SO8D	FAIRCHILD	NM93C86	DIP	8	Not use adapter
FAIRCHILD	NM93C86	TSSOP	8	PA8TSS-OT	FAIRCHILD	NM93C86	SOIC	8	PA8SO8D
FAIRCHILD	NM93CS06	DIP	8	Not use adapter	FAIRCHILD	NM93CS06	TSSOP	8	PA8TSS-OT
FAIRCHILD	NM93CS06	SOIC	8	PA8SO8D	FAIRCHILD	NM93CS46	DIP	8	Not use adapter
FAIRCHILD	NM93CS46	TSSOP	8	PA8TSS-OT	FAIRCHILD	NM93CS46	SOIC	8	PA8SO8D
FAIRCHILD	NM93CS56	TSSOP	8	PA8TSS-OT	FAIRCHILD	NM93CS56	DIP	8	Not use adapter
FAIRCHILD	NM93CS56	SOIC	8	PA8SO8D	FAIRCHILD	NM93CS66	TSSOP	8	PA8TSS-OT
FAIRCHILD	NM93CS66	DIP	8	Not use adapter	FAIRCHILD	NM93CS66	SOIC	8	PA8SO8D
FAIRCHILD	NMC27C64	DIP	28	Not use adapter	FAIRCHILD	NMC27LC64	DIP	28	Not use adapter
FUJITSU	MB84VD23280FA	BGA	65	PA65BGA48DA	FUJITSU	MB84VD23381FJ	BGA	65	PA65BGA48DA
FUJITSU	MB84VD23381HJ	BGA	56	PA56BG48DG	FUJITSU	MB84VF5F5F4J2	BGA	107	PA107BG48DA
FUJITSU	MB84VF5F5F5J2	BGA	107	PA107BG48DA	FUJITSU	MBL8742H	DIP	40	Not use adapter
FUJITSU	MBM27128	DIP	28	Not use adapter	FUJITSU	MBM27128	PLCC	32	PA32-28
FUJITSU	MBM2716	DIP	24	Not use adapter	FUJITSU	MBM2716H	DIP	24	Not use adapter
FUJITSU	MBM27256	DIP	28	Not use adapter	FUJITSU	MBM27256	PLCC	32	PA32-28
FUJITSU	MBM2732	DIP	24	Not use adapter	FUJITSU	MBM2732A	DIP	24	Not use adapter
FUJITSU	MBM2764	DIP	28	Not use adapter	FUJITSU	MBM27C1000	DIP	32	Not use adapter
FUJITSU	MBM27C1001	DIP	32	Not use adapter	FUJITSU	MBM27C1001A	DIP	32	Not use adapter
FUJITSU	MBM27C1024	PLCC	44	PA44-48U	FUJITSU	MBM27C1024	DIP	40	Not use adapter
FUJITSU	MBM27C128	DIP	28	Not use adapter	FUJITSU	MBM27C128P	DIP	28	Not use adapter
FUJITSU	MBM27C128P	PLCC	32	PA32-28	FUJITSU	MBM27C2048	PLCC	44	PA44-48U
FUJITSU	MBM27C2048	DIP	40	Not use adapter	FUJITSU	MBM27C256	DIP	28	Not use adapter
FUJITSU	MBM27C256	PLCC	32	PA32-28	FUJITSU	MBM27C256A	DIP	28	Not use adapter
FUJITSU	MBM27C256A	PLCC	32	PA32-28	FUJITSU	MBM27C256A-##-W	DIP	28	Not use adapter
FUJITSU	MBM27C256AP	DIP	28	Not use adapter	FUJITSU	MBM27C256AP	SOIC	28	PA28SO28D-08
FUJITSU	MBM27C256AP	PLCC	32	PA32-28	FUJITSU	MBM27C256H	DIP	28	Not use adapter
FUJITSU	MBM27C256H	PLCC	32	PA32-28	FUJITSU	MBM27C4001	DIP	32	Not use adapter
FUJITSU	MBM27C4096	PLCC	44	PA44-48U	FUJITSU	MBM27C4096	DIP	40	Not use adapter
FUJITSU	MBM27C512	DIP	28	Not use adapter	FUJITSU	MBM27C512P	DIP	28	Not use adapter
FUJITSU	MBM27C64	DIP	28	Not use adapter	FUJITSU	MBM28C256	DIP	28	Not use adapter
FUJITSU	MBM28C64	DIP	28	Not use adapter	FUJITSU	MBM28C65	DIP	28	Not use adapter

FUJITSU	MBM28F010	PLCC	32	PA32PL32D	FUJITSU	MBM28F010	DIP	32	Not use adapter
FUJITSU	MBM29DL161BD	BGA	48	PA48BG48DAH	FUJITSU	MBM29DL161TD	BGA	48	PA48BG48DAH
FUJITSU	MBM29DL162CB	TSOP	48	PA48TS48D	FUJITSU	MBM29DL162CT	TSOP	48	PA48TS48D
FUJITSU	MBM29DL163CB	TSOP	48	PA48TS48D	FUJITSU	MBM29DL163CT	TSOP	48	PA48TS48D
FUJITSU	MBM29DL316CB	TSOP	40	PA40TS40D	FUJITSU	MBM29DL316CT	TSOP	40	PA40TS40D
FUJITSU	MBM29DL322CB	TSOP	48	PA48TS48D	FUJITSU	MBM29DL322CT	TSOP	48	PA48TS48D
FUJITSU	MBM29DL323CB	TSOP	48	PA48TS48D	FUJITSU	MBM29DL323CT	TSOP	48	PA48TS48D
FUJITSU	MBM29DL32BF	TSOP	48	PA48TS48D	FUJITSU	MBM29DL32TF	TSOP	48	PA48TS48D
FUJITSU	MBM29DL400BB	TSOP	48	PA48TS48D	FUJITSU	MBM29DL400BB	SOP	44	PA44SO44D
FUJITSU	MBM29DL400BT	TSOP	48	PA48TS48D	FUJITSU	MBM29DL400BT	SOP	44	PA44SO44D
FUJITSU	MBM29DL800BB	TSOP	48	PA48TS48D	FUJITSU	MBM29DL800BB	SOP	44	PA44SO44D
FUJITSU	MBM29DL800BT	SOP	44	PA44SO44D	FUJITSU	MBM29DL800BT	TSOP	48	PA48TS48D
FUJITSU	MBM29F002B	DIP	32	Not use adapter	FUJITSU	MBM29F002T	DIP	32	Not use adapter
FUJITSU	MBM29F016	TSOP	48	PA48TS48D	FUJITSU	MBM29F040B	DIP	32	Not use adapter
FUJITSU	MBM29F040C	DIP	32	Not use adapter	FUJITSU	MBM29F080	SOP	44	PA44SO44D
FUJITSU	MBM29F080	TSOP	40	PA40TS40D	FUJITSU	MBM29F160BE	TSOP	48	PA48TS48D
FUJITSU	MBM29F160TE	TSOP	48	PA48TS48D	FUJITSU	MBM29F200BB	TSOP	48	PA48TS48D
FUJITSU	MBM29F200BB	SOP	44	PA44SO44D	FUJITSU	MBM29F200BC	TSOP	48	PA48TS48D
FUJITSU	MBM29F200BT	SOP	44	PA44SO44D	FUJITSU	MBM29F200BT	TSOP	48	PA48TS48D
FUJITSU	MBM29F200TC	TSOP	48	PA48TS48D	FUJITSU	MBM29F400BB	SOP	44	PA44SO44D
FUJITSU	MBM29F400BB	TSOP	48	PA48TS48D	FUJITSU	MBM29F400BT	SOP	44	PA44SO44D
FUJITSU	MBM29F400BT	TSOP	48	PA48TS48D	FUJITSU	MBM29F800B	TSOP	48	PA48TS48D
FUJITSU	MBM29F800BA	SOP	44	PA44SO44D	FUJITSU	MBM29F800BA	TSOP	48	PA48TS48D
FUJITSU	MBM29F800T	TSOP	48	PA48TS48D	FUJITSU	MBM29F800TA	SOP	44	PA44SO44D
FUJITSU	MBM29F800TA	TSOP	48	PA48TS48D	FUJITSU	MBM29LV002B	TSOP	40	PA40TS40D
FUJITSU	MBM29LV002T	TSOP	40	PA40TS40D	FUJITSU	MBM29LV004B	TSOP	40	PA40TS40D
FUJITSU	MBM29LV004T	TSOP	40	PA40TS40D	FUJITSU	MBM29LV008B	TSOP	40	PA40TS40D
FUJITSU	MBM29LV008BB	TSOP	40	PA40TS40D	FUJITSU	MBM29LV008BT	TSOP	40	PA40TS40D
FUJITSU	MBM29LV008T	TSOP	40	PA40TS40D	FUJITSU	MBM29LV160B	TSOP	48	PA48TS48D
FUJITSU	MBM29LV160BB	TSOP	48	PA48TS48D	FUJITSU	MBM29LV160BB	SOP	44	PA44SO44D
FUJITSU	MBM29LV160BE	TSOP	48	PA48TS48D	FUJITSU	MBM29LV160BE	BGA	48	PA48BG48DAG
FUJITSU	MBM29LV160BT	TSOP	48	PA48TS48D	FUJITSU	MBM29LV160BT	SOP	44	PA44SO44D
FUJITSU	MBM29LV160DB	TSOP	48	PA48TS48D	FUJITSU	MBM29LV160DB	SOP	44	PA44SO44D
FUJITSU	MBM29LV160DT	SOP	44	PA44SO44D	FUJITSU	MBM29LV160DT	TSOP	48	PA48TS48D
FUJITSU	MBM29LV160T	TSOP	48	PA48TS48D	FUJITSU	MBM29LV160TE	TSOP	48	PA48TS48D
FUJITSU	MBM29LV160TE	BGA	48	PA48BG48DAG	FUJITSU	MBM29LV200BB	SOP	44	PA44SO44D
FUJITSU	MBM29LV200BB	TSOP	48	PA48TS48D	FUJITSU	MBM29LV200BT	SOP	44	PA44SO44D
FUJITSU	MBM29LV200BT	TSOP	48	PA48TS48D	FUJITSU	MBM29LV320BE	TSOP	48	PA48TS48D
FUJITSU	MBM29LV320TE	TSOP	48	PA48TS48D	FUJITSU	MBM29LV400BB	SOP	44	PA44SO44D
FUJITSU	MBM29LV400BB	TSOP	48	PA48TS48D	FUJITSU	MBM29LV400BC	TSOP	48	PA48TS48D
FUJITSU	MBM29LV400BT	TSOP	48	PA48TS48D	FUJITSU	MBM29LV400BT	SOP	44	PA44SO44D
FUJITSU	MBM29LV400TC	TSOP	48	PA48TS48D	FUJITSU	MBM29LV650UE	TSOP	48	PA48TS48D
FUJITSU	MBM29LV651UE	TSOP	48	PA48TS48D	FUJITSU	MBM29LV800BA	TSOP	48	PA48TS48D
FUJITSU	MBM29LV800BA	SOP	44	PA44SO44D	FUJITSU	MBM29LV800BB	SOP	44	PA44SO44D
FUJITSU	MBM29LV800BB	TSOP	48	PA48TS48D	FUJITSU	MBM29LV800BE	TSOP	48	PA48TS48D
FUJITSU	MBM29LV800BT	SOP	44	PA44SO44D	FUJITSU	MBM29LV800BT	TSOP	48	PA48TS48D
FUJITSU	MBM29LV800TA	TSOP	48	PA48TS48D	FUJITSU	MBM29LV800TA	SOP	44	PA44SO44D
FUJITSU	MBM29LV800TE	TSOP	48	PA48TS48D	FUJITSU	MBM29PL160CB	TSOP	48	PA48TS48D
FUJITSU	MBM29PL160CB	SOP	44	PA44SO44D	FUJITSU	MBM29PL160CT	SOP	44	PA44SO44D
FUJITSU	MBM29PL160CT	TSOP	48	PA48TS48D	FUJITSU	MBM29SL160CB	TSOP	48	PA48TS48D
FUJITSU	MBM29SL160CT	TSOP	48	PA48TS48D	FUJITSU	MBM29SL800CB	TSOP	48	PA48TS48D
FUJITSU	MBM29SL800CT	TSOP	48	PA48TS48D	GENCORE	GC87C520A0	PLCC	44	PA44-48U
GENCORE	GC87C520A0	DIP	40	Not use adapter	GENCORE	GC87C520A0	VQFP	44	PA44VQ44D
GENERAL	27256	DIP	28	Not use adapter	GENERAL	27C128	DIP	28	Not use adapter
GENERAL	27C128	PLCC	32	PA32-28	GENERAL	27C256	DIP	28	Not use adapter
GENERAL	27C256	PLCC	32	PA32-28	GENERAL	27C512	DIP	28	Not use adapter
GENERAL	27C64	DIP	28	Not use adapter	GENERAL	27HC64	DIP	28	Not use adapter
GENERAL	27HC64L	PLCC	32	PA32-28	GENERAL	28C04	DIP	24	Not use adapter
GENERAL	28C04F	DIP	24	Not use adapter	GENERAL	28C16	DIP	24	Not use adapter
GENERAL	28C17	DIP	28	Not use adapter	GENERAL	28C17F	DIP	28	Not use adapter
GENERAL	28C64	DIP	28	Not use adapter	GENERAL	28C64A	DIP	28	Not use adapter
GENERAL	28C64AX	DIP	28	Not use adapter	GENERIC	27128	DIP	28	Not use adapter
GENERIC	27128A	DIP	28	Not use adapter	GENERIC	2716	DIP	24	Not use adapter
GENERIC	27256	DIP	28	Not use adapter	GENERIC	2732	DIP	24	Not use adapter
GENERIC	2732A	DIP	24	Not use adapter	GENERIC	2732B	DIP	24	Not use adapter
GENERIC	27512	DIP	28	Not use adapter	GENERIC	2764	DIP	28	Not use adapter
GENERIC	2764A	DIP	28	Not use adapter	GENERIC	27C128	DIP	28	Not use adapter
GENERIC	27C128	DIP	28	Not use adapter	GENERIC	27C16	DIP	24	Not use adapter
GENERIC	27C256	DIP	28	Not use adapter	GENERIC	27C32	DIP	24	Not use adapter
GENERIC	27C512	DIP	28	Not use adapter	GENERIC	27C64	DIP	28	Not use adapter
GENERIC	27C64	DIP	28	Not use adapter	GOULD	PEEL153	DIP	20	Not use adapter
GOULD	PEEL173	DIP	24	Not use adapter	GOULD	PEEL18CV8	DIP	20	Not use adapter
GOULD	PEEL18CV8	TSSOP	20	PA20SS-P54	GOULD	PEEL18CV8	SOIC	20	PA28SO1-08-06
GOULD	PEEL18CV8	PLCC	20	PA20LC20D	GOULD	PEEL20CG10	DIP	24	Not use adapter

GOULD	PEEL22CV10	DIP	24	Not use adapter	GOULD	PEEL22CV10	PLCC	28	PA28PL28D
GOULD	PEEL22CV10	SOIC	24	PA28SO28D-EO-300	GOULD	PEEL22CV10	TSSOP	24	PA24TSS24D(M)
GOULD	PEEL22CV10A	DIP	24	Not use adapter	GOULD	PEEL22CV10A	TSSOP	24	PA24TSS24D(M)
GOULD	PEEL22CV10A	SOIC	24	PA28SO28D-EO-300	GOULD	PEEL22CV10A	PLCC	28	PA28PL28D
GOULD	PEEL22CV10A+	DIP	24	Not use adapter	GOULD	PEEL22CV10A+	PLCC	28	PA28PL28D
GOULD	PEEL22CV10A+	TSSOP	24	PA24TSS24D(M)	GOULD	PEEL22CV10A+	SOIC	24	PA28SO28D-EO-300
GOULD	PEEL22CV10A++	DIP	24	Not use adapter	GOULD	PEEL22CV10A++	TSSOP	24	PA24TSS24D(M)
GOULD	PEEL22CV10A++	SOIC	24	PA28SO28D-EO-300	GOULD	PEEL22CV10A++	PLCC	28	PA28PL28D
GOULD	PEEL22CV10AZ+	DIP	24	Not use adapter	GOULD	PEEL22CV10AZ+	SOIC	24	PA28SO28D-EO-300
GOULD	PEEL22CV10AZ+	PLCC	28	PA28PL28D	GOULD	PEEL22CV10AZ+	TSSOP	24	PA24TSS24D(M)
GOULD	PEEL22CV10AZ++	DIP	24	Not use adapter	GOULD	PEEL22CV10AZ++	SOIC	24	PA28SO28D-EO-300
GOULD	PEEL22CV10AZ++	PLCC	28	PA28PL28D	GOULD	PEEL22CV10AZ++	TSSOP	24	PA24TSS24D(M)
GOULD	PEEL22CV10Z	DIP	24	Not use adapter	GOULD	PEEL22CV10Z	SOIC	24	PA28SO28D-EO-300
GOULD	PEEL22CV10Z	PLCC	28	PA28PL28D	GOULD	PEEL22CV10Z	TSSOP	24	PA24TSS24D(M)
GOULD	PEEL253	DIP	20	Not use adapter	GOULD	PEEL273	DIP	24	Not use adapter
GREENWICH	GR12882	DIP	32	Not use adapter	GREENWICH	GR128823	DIP	32	Not use adapter
GREENWICH	GR27128	DIP	28	Not use adapter	GREENWICH	GR27256	DIP	28	Not use adapter
GREENWICH	GR27512	DIP	28	Not use adapter	GREENWICH	GR2764	DIP	28	Not use adapter
GREENWICH	GR281	DIP	24	Not use adapter	GREENWICH	GR3281	DIP	28	Not use adapter
GREENWICH	GR881	DIP	28	Not use adapter	HITACHI	H8/532	PLCC	84	PA84PL40DD
HITACHI	H8/534	PLCC	84	PA84PL40DD	HITACHI	H8/536	PLCC	84	PA84PL40DD
HITACHI	HN27128A	DIP	28	Not use adapter	HITACHI	HN27128AG	DIP	28	Not use adapter
HITACHI	HN27128AP	DIP	28	Not use adapter	HITACHI	HN27256	DIP	28	Not use adapter
HITACHI	HN27256G	DIP	28	Not use adapter	HITACHI	HN27256P	DIP	28	Not use adapter
HITACHI	HN27512	DIP	28	Not use adapter	HITACHI	HN27512G	DIP	28	Not use adapter
HITACHI	HN27512P	DIP	28	Not use adapter	HITACHI	HN2764	DIP	28	Not use adapter
HITACHI	HN2764AG	DIP	28	Not use adapter	HITACHI	HN27C101AG	DIP	32	Not use adapter
HITACHI	HN27C101AP	DIP	32	Not use adapter	HITACHI	HN27C101G	DIP	32	Not use adapter
HITACHI	HN27C101P	DIP	32	Not use adapter	HITACHI	HN27C1024HG	DIP	40	Not use adapter
HITACHI	HN27C1024HG	PLCC	44	PA44-48U	HITACHI	HN27C256	DIP	28	Not use adapter
HITACHI	HN27C256A	SOIC	28	PA28SO28D-08	HITACHI	HN27C256A	PLCC	32	PA32-28
HITACHI	HN27C256AG	DIP	28	Not use adapter	HITACHI	HN27C256G	DIP	28	Not use adapter
HITACHI	HN27C256H	PLCC	32	PA32-28	HITACHI	HN27C256H	SOIC	28	PA28SO28D-08
HITACHI	HN27C256HG	DIP	28	Not use adapter	HITACHI	HN27C301G	DIP	32	Not use adapter
HITACHI	HN27C301P	DIP	32	Not use adapter	HITACHI	HN27C4001G	DIP	32	Not use adapter
HITACHI	HN27C4096AHCC	PLCC	44	PA44-48U	HITACHI	HN27C4096AHG	DIP	40	Not use adapter
HITACHI	HN27C4096G	PLCC	44	PA44-48U	HITACHI	HN27C4096G	DIP	40	Not use adapter
HITACHI	HN27C4096HCC	PLCC	44	PA44-48U	HITACHI	HN27C4096HG	DIP	40	Not use adapter
HITACHI	HN27C512AG	DIP	28	Not use adapter	HITACHI	HN27C64	DIP	28	Not use adapter
HITACHI	HN27C64G	DIP	28	Not use adapter	HITACHI	HN28F101	DIP	32	Not use adapter
HITACHI	HN462716	DIP	24	Not use adapter	HITACHI	HN462716G	DIP	24	Not use adapter
HITACHI	HN462732	DIP	24	Not use adapter	HITACHI	HN462732G	DIP	24	Not use adapter
HITACHI	HN48016P	DIP	24	Not use adapter	HITACHI	HN4827128G	DIP	28	Not use adapter
HITACHI	HN4827128P	DIP	28	Not use adapter	HITACHI	HN482732A	DIP	24	Not use adapter
HITACHI	HN482732AG	DIP	24	Not use adapter	HITACHI	HN482764G	DIP	28	Not use adapter
HITACHI	HN482764P	DIP	28	Not use adapter	HITACHI	HN58C1001	DIP	32	Not use adapter
HITACHI	HN58C256P(Page)	DIP	28	Not use adapter	HITACHI	HN58C256P(Single)	DIP	28	Not use adapter
HITACHI	HN58C65P	DIP	28	Not use adapter	HOLTEK	HT27C010	DIP	32	Not use adapter
HOLTEK	HT27C010	PLCC	32	PA32PL32D	HOLTEK	HT27C010	SOP	32	PA32PS-32D-450
HOLTEK	HT27C040	DIP	32	Not use adapter	HOLTEK	HT27C040	PLCC	32	PA32PL32D
HOLTEK	HT27C040	SOP	32	PA32PS-32D-450	HOLTEK	HT27C512	DIP	28	Not use adapter
HOLTEK	HT27C512	PLCC	32	PA32-28	HOLTEK	HT27LC020	DIP	32	Not use adapter
HOLTEK	HT93C46	DIP	8	Not use adapter	HOLTEK	HT93C46	SOIC	8	PA8SO8D
HOLTEK	HT93C56	DIP	8	Not use adapter	HOLTEK	HT93C56	SOIC	8	PA8SO8D
HOLTEK	HT93C66	DIP	8	Not use adapter	HOLTEK	HT93C66	SOIC	8	PA8SO8D
HOLTEK	HT93LC46	TSSOP	8	PA8TSS-OT	HOLTEK	HT93LC46	DIP	8	Not use adapter
HOLTEK	HT93LC46	SOIC	8	PA8SO8D	HOLTEK	HT93LC56	DIP	8	Not use adapter
HOLTEK	HT93LC56	SOIC	8	PA8SO8D	HOLTEK	HT93LC66	DIP	8	Not use adapter
HOLTEK	HT93LC66	TSSOP	8	PA8TSS-OT	HOLTEK	HT93LC66	SOIC	8	PA8SO8D
HOLTEK	HT93LC86	DIP	8	Not use adapter	HOLTEK	HT93LC86	TSSOP	8	PA8TSS-OT
HOLTEK	HT93LC86	SOIC	8	PA8SO8D	HYNIX(HYUNDAI)	GMS77C1000	DIP	18	Not use adapter
HYNIX(HYUNDAI)	GMS77C1001	DIP	18	Not use adapter	HYNIX(HYUNDAI)	GMS87C1102	DIP	16	Not use adapter
HYNIX(HYUNDAI)	GMS87C1202	DIP	20	Not use adapter	HYNIX(HYUNDAI)	GMS97C51	DIP	40	Not use adapter
HYNIX(HYUNDAI)	GMS97C51	PLCC	44	PA44-48U	HYNIX(HYUNDAI)	GMS97C52	DIP	40	Not use adapter
HYNIX(HYUNDAI)	GMS97C52	PLCC	44	PA44-48U	HYNIX(HYUNDAI)	GMS97C54	DIP	40	Not use adapter
HYNIX(HYUNDAI)	GMS97C54	PLCC	44	PA44-48U	HYNIX(HYUNDAI)	GMS97C54	QFP	44	PA44QF44D
HYNIX(HYUNDAI)	GMS97C56	PLCC	44	PA44-48U	HYNIX(HYUNDAI)	GMS97C56	DIP	40	Not use adapter
HYNIX(HYUNDAI)	GMS97C58	DIP	40	Not use adapter	HYNIX(HYUNDAI)	GMS97C58	PLCC	44	PA44-48U
HYNIX(HYUNDAI)	GMS97L51	DIP	40	Not use adapter	HYNIX(HYUNDAI)	GMS97L51	PLCC	44	PA44-48U
HYNIX(HYUNDAI)	GMS97L52	DIP	40	Not use adapter	HYNIX(HYUNDAI)	GMS97L52	PLCC	44	PA44-48U
HYNIX(HYUNDAI)	HMS77C2000	DIP	8	Not use adapter	HYNIX(HYUNDAI)	HMS77C2001	DIP	8	Not use adapter
HYNIX(HYUNDAI)	HMS99C51S	DIP	40	Not use adapter	HYNIX(HYUNDAI)	HMS99C52S	DIP	40	Not use adapter
HYNIX(HYUNDAI)	HMS99C54S	DIP	40	Not use adapter	HYNIX(HYUNDAI)	HMS99C56S	DIP	40	Not use adapter
HYNIX(HYUNDAI)	HMS99C58S	DIP	40	Not use adapter	HYNIX(HYUNDAI)	HY2764	DIP	28	Not use adapter

HYNIX(HYUNDAI)	HY27C64A	DIP	28	Not use adapter	HYNIX(HYUNDAI)	HY29DL162BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29DL162TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY29DL163BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29DL163TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY29DS162BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29DS162TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY29DS163BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29DS163TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY29F002CT	PLCC	32	PA32PL32D
HYNIX(HYUNDAI)	HY29F002TT	TSOP	32	PA32TS20/PA32TS32D-20	HYNIX(HYUNDAI)	HY29F040	DIP	32	Not use adapter
HYNIX(HYUNDAI)	HY29F040A	DIP	32	Not use adapter	HYNIX(HYUNDAI)	HY29F080T	SOP	44	PA44SO44D
HYNIX(HYUNDAI)	HY29F080T	TSOP	40	PA40TS40D	HYNIX(HYUNDAI)	HY29F400BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29F400TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY29F800BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29F800TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY29LV160BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29LV160TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY29LV320BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29LV320TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY29LV400BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29LV400BT	SOP	44	PA44SO44D	HYNIX(HYUNDAI)	HY29LV400TT	SOP	44	PA44SO44D
HYNIX(HYUNDAI)	HY29LV400TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY29LV800BT	TSOP	48	PA48TS48D
HYNIX(HYUNDAI)	HY29LV800BT	SOP	44	PA44SO44D	HYNIX(HYUNDAI)	HY29LV800TT	SOP	44	PA44SO44D
HYNIX(HYUNDAI)	HY29LV800TT	TSOP	48	PA48TS48D	HYNIX(HYUNDAI)	HY91U3204AD	BGA	72	PA72BGA48D-B11
HYNIX(HYUNDAI)	HY91U3208AD	BGA	72	PA72BGA48D-B11	HYNIX(HYUNDAI)	HY93C46	DIP	8	Not use adapter
HYNIX(HYUNDAI)	HY96U1604M	BGA	69	PA69BGA48DH	HYNIX(HYUNDAI)	PEEL18CV8	DIP	20	Not use adapter
HYNIX(HYUNDAI)	PEEL18CV8	TSSOP	20	PA20SS-P54	HYNIX(HYUNDAI)	PEEL18CV8	SOIC	20	PA28SO1-08-06
HYNIX(HYUNDAI)	PEEL18CV8	PLCC	20	PA20LC20D	ICT	27CX010	DIP	32	Not use adapter
ICT	93C46	DIP	8	Not use adapter	ICT	93C46A	DIP	8	Not use adapter
ICT	93C56A	DIP	8	Not use adapter	ICT	93C66A	DIP	8	Not use adapter
ICT	93CX46	DIP	8	Not use adapter	ICT	93CX56	DIP	8	Not use adapter
ICT	93CX66	DIP	8	Not use adapter	ICT	PA7024J	PLCC	28	PA28PL28D
ICT	PA7024P	DIP	24	Not use adapter	ICT	PA7128P	DIP	28	Not use adapter
ICT	PA7140J	PLCC	44	PA44-48U	ICT	PA7140P	DIP	40	Not use adapter
ICT	PA7536J	PLCC	28	PA28PL28D	ICT	PA7536P	DIP	28	Not use adapter
ICT	PA7536S	SOIC	28	PA28SO28D-08	ICT	PA7536T	TSSOP	28	PA28TSOP3
ICT	PA7540J	PLCC	28	PA28PL28D	ICT	PA7540P	DIP	24	Not use adapter
ICT	PA7572J	PLCC	44	PA44-48U	ICT	PA7572P	DIP	40	Not use adapter
ICT	PA7572Q	TQFP	44	PA44QF44D	ICT	PEEL153	DIP	20	Not use adapter
ICT	PEEL16CV8	DIP	20	Not use adapter	ICT	PEEL16CV8	TSSOP	20	PA20SS-P54
ICT	PEEL16CV8	SOIC	20	PA28SO1-08-06	ICT	PEEL16CV8	PLCC	20	PA20LC20D
ICT	PEEL173	DIP	24	Not use adapter	ICT	PEEL18CV8	DIP	20	Not use adapter
ICT	PEEL18CV8	TSSOP	20	PA20SS-P54	ICT	PEEL18CV8	PLCC	20	PA20LC20D
ICT	PEEL18CV8	SOIC	20	PA28SO1-08-06	ICT	PEEL18CV8Z	DIP	20	Not use adapter
ICT	PEEL18CV8Z	SOIC	20	PA28SO1-08-06	ICT	PEEL18CV8Z	TSSOP	20	PA20SS-P54
ICT	PEEL18CV8Z	PLCC	20	PA20LC20D	ICT	PEEL18LV8Z	DIP	20	Not use adapter
ICT	PEEL18LV8Z	SOIC	20	PA28SO1-08-06	ICT	PEEL18LV8Z	PLCC	20	PA20LC20D
ICT	PEEL18LV8Z	TSSOP	20	PA20SS-P54	ICT	PEEL20CG10	DIP	24	Not use adapter
ICT	PEEL20CG10A	DIP	24	Not use adapter	ICT	PEEL22CV10	DIP	24	Not use adapter
ICT	PEEL22CV10	TSSOP	24	PA24TSS24D(M)	ICT	PEEL22CV10	SOIC	24	PA28SO28D-EO-300
ICT	PEEL22CV10	PLCC	28	PA28PL28D	ICT	PEEL22CV10A	DIP	24	Not use adapter
ICT	PEEL22CV10A	PLCC	28	PA28PL28D	ICT	PEEL22CV10A	SOIC	24	PA28SO28D-EO-300
ICT	PEEL22CV10A	TSSOP	24	PA24TSS24D(M)	ICT	PEEL22CV10A+	DIP	24	Not use adapter
ICT	PEEL22CV10A+	PLCC	28	PA28PL28D	ICT	PEEL22CV10A+	SOIC	24	PA28SO28D-EO-300
ICT	PEEL22CV10A+	TSSOP	24	PA24TSS24D(M)	ICT	PEEL22CV10A++	DIP	24	Not use adapter
ICT	PEEL22CV10A++	PLCC	28	PA28PL28D	ICT	PEEL22CV10A++	TSSOP	24	PA24TSS24D(M)
ICT	PEEL22CV10A++	SOIC	24	PA28SO28D-EO-300	ICT	PEEL22CV10AZ	DIP	24	Not use adapter
ICT	PEEL22CV10AZ	SOIC	24	PA28SO28D-EO-300	ICT	PEEL22CV10AZ	TSSOP	24	PA24TSS24D(M)
ICT	PEEL22CV10AZ	PLCC	28	PA28PL28D	ICT	PEEL22CV10AZ+	DIP	24	Not use adapter
ICT	PEEL22CV10AZ+	TSSOP	24	PA24TSS24D(M)	ICT	PEEL22CV10AZ+	SOIC	24	PA28SO28D-EO-300
ICT	PEEL22CV10AZ+	PLCC	28	PA28PL28D	ICT	PEEL22CV10AZ++	DIP	24	Not use adapter
ICT	PEEL22CV10AZ++	PLCC	28	PA28PL28D	ICT	PEEL22CV10AZ++	SOIC	24	PA28SO28D-EO-300
ICT	PEEL22CV10AZ++	TSSOP	24	PA24TSS24D(M)	ICT	PEEL22CV10Z	DIP	24	Not use adapter
ICT	PEEL22CV10Z	PLCC	28	PA28PL28D	ICT	PEEL22CV10Z	TSSOP	24	PA24TSS24D(M)
ICT	PEEL22CV10Z	SOIC	24	PA28SO28D-EO-300	ICT	PEEL253	DIP	20	Not use adapter
ICT	PEEL273	DIP	24	Not use adapter	IMT	IM29F001T	DIP	32	Not use adapter
IMT	IM29F002T	DIP	32	Not use adapter	IMT	IM29F004B	DIP	32	Not use adapter
IMT	IM29F004B	PLCC	32	PA32PL32D	IMT	IM29F004T	DIP	32	Not use adapter
IMT	IM29F004T	PLCC	32	PA32PL32D	INTEL	27010	DIP	32	Not use adapter
INTEL	27128	DIP	28	Not use adapter	INTEL	27128A	DIP	28	Not use adapter
INTEL	27128B	DIP	28	Not use adapter	INTEL	2716	DIP	24	Not use adapter
INTEL	27210	PLCC	44	PA44-48U	INTEL	27210	DIP	40	Not use adapter
INTEL	27256	DIP	28	Not use adapter	INTEL	2732	DIP	24	Not use adapter
INTEL	2732A	DIP	24	Not use adapter	INTEL	27512	DIP	28	Not use adapter
INTEL	27512J	DIP	28	Not use adapter	INTEL	2764	DIP	28	Not use adapter
INTEL	2764A	DIP	28	Not use adapter	INTEL	27C010	DIP	32	Not use adapter
INTEL	27C010A	DIP	32	Not use adapter	INTEL	27C020	DIP	32	Not use adapter
INTEL	27C040	DIP	32	Not use adapter	INTEL	27C100	DIP	32	Not use adapter
INTEL	27C128	DIP	28	Not use adapter	INTEL	27C128	PLCC	32	PA32-28
INTEL	27C210	DIP	40	Not use adapter	INTEL	27C210	PLCC	44	PA44-48U
INTEL	27C220	DIP	40	Not use adapter	INTEL	27C220	PLCC	44	PA44-48U
INTEL	27C240	DIP	40	Not use adapter	INTEL	27C240	PLCC	44	PA44-48U

INTEL	27C256	DIP	28	Not use adapter	INTEL	27C256	PLCC	32	PA32-28
INTEL	27C400	DIP	40	Not use adapter	INTEL	27C512	DIP	28	Not use adapter
INTEL	27C64	DIP	28	Not use adapter	INTEL	27C64	PLCC	32	PA32-28
INTEL	2816A	DIP	24	Not use adapter	INTEL	2817A	DIP	28	Not use adapter
INTEL	2864	DIP	28	Not use adapter	INTEL	2864A	DIP	28	Not use adapter
INTEL	28F256-###P1C2	DIP	32	Not use adapter	INTEL	28F256-###P2C2	DIP	32	Not use adapter
INTEL	28F256A	DIP	32	Not use adapter	INTEL	28F512	DIP	32	Not use adapter
INTEL	5C090	DIP	40	Not use adapter	INTEL	8741A	DIP	40	Not use adapter
INTEL	8741AH	DIP	40	Not use adapter	INTEL	8742	DIP	40	Not use adapter
INTEL	8742AH	DIP	40	Not use adapter	INTEL	8748	DIP	40	Not use adapter
INTEL	8748H	DIP	40	Not use adapter	INTEL	8749H	DIP	40	Not use adapter
INTEL	8751BH	DIP	40	Not use adapter	INTEL	8751H(10ms)	DIP	40	Not use adapter
INTEL	8751H(50ms)	DIP	40	Not use adapter	INTEL	8752BH	DIP	40	Not use adapter
INTEL	8755A	DIP	40	Not use adapter	INTEL	87C196CA	PLCC	68	PA68-40E
INTEL	87C196JQ	PLCC	52	PA52-40C	INTEL	87C196JR	PLCC	52	PA52-40C
INTEL	87C196JT	PLCC	52	PA52-40C	INTEL	87C196JV	PLCC	52	PA52-40C
INTEL	87C196KB	PLCC	68	PA68-40D	INTEL	87C196KC	PLCC	68	PA68-40D
INTEL	87C196KD	PLCC	68	PA68-40D	INTEL	87C196KQ	PLCC	68	PA68-40C
INTEL	87C196KR	PLCC	68	PA68-40C	INTEL	87C196KS	PLCC	68	PA68-40C
INTEL	87C196KT	PLCC	68	PA68-40C	INTEL	87C196MC	PLCC	84	PA84-40C
INTEL	87C196MD	PLCC	84	PA84-40C	INTEL	87C196MH	PLCC	84	PA84-40C
INTEL	87C251SB	DIP	40	Not use adapter	INTEL	87C251SB	PLCC	44	PA44-48U
INTEL	87C42	DIP	40	Not use adapter	INTEL	87C51	PLCC	44	PA44-48U
INTEL	87C51	DIP	40	Not use adapter	INTEL	87C51FA	DIP	40	Not use adapter
INTEL	87C51FA	PLCC	44	PA44-48U	INTEL	87C51FB	PLCC	44	PA44-48U
INTEL	87C51FB	DIP	40	Not use adapter	INTEL	87C51FC	DIP	40	Not use adapter
INTEL	87C51FC	PLCC	44	PA44-48U	INTEL	87C51RA	DIP	40	Not use adapter
INTEL	87C51RA	PLCC	44	PA44-48U	INTEL	87C51RB	DIP	40	Not use adapter
INTEL	87C51RB	PLCC	44	PA44-48U	INTEL	87C51RC	DIP	40	Not use adapter
INTEL	87C51RC	PLCC	44	PA44-48U	INTEL	87C52	PLCC	44	PA44-48U
INTEL	87C52	DIP	40	Not use adapter	INTEL	87C521	PLCC	44	PA44-48U
INTEL	87C521	DIP	40	Not use adapter	INTEL	87C54	DIP	40	Not use adapter
INTEL	87C54	PLCC	44	PA44-48U	INTEL	87C64	DIP	28	Not use adapter
INTEL	87L51FA	PLCC	44	PA44-48U	INTEL	87L51FB	PLCC	44	PA44-48U
INTEL	87L51FC	PLCC	44	PA44-48U	INTEL	AB28F200BRB	SOP	44	PA44SO44D
INTEL	AB28F200BRT	SOP	44	PA44SO44D	INTEL	AB28F400BRB	SOP	44	PA44SO44D
INTEL	AB28F400BRT	SOP	44	PA44SO44D	INTEL	DA28F320J5	SSOP	56	CIC-56SS-48D-B6-TI
INTEL	DA28F640J5	SSOP	56	CIC-56SS-48D-B6-TI	INTEL	DT28F160F3-B	SSOP	56	CIC-56SS-48D-C6-TI
INTEL	DT28F160F3-T	SSOP	56	CIC-56SS-48D-C6-TI	INTEL	DT28F160S3	SSOP	56	CIC-56SS-48D-B6-TI
INTEL	DT28F320S3	SSOP	56	CIC-56SS-48D-B6-TI	INTEL	E28F004B3-B	TSOP	40	PA40TS40D
INTEL	E28F004B3-T	TSOP	40	PA40TS40D	INTEL	E28F008B3-B	TSOP	40	PA40TS40D
INTEL	E28F008B3-T	TSOP	40	PA40TS40D	INTEL	E28F008C3-B	TSOP	40	PA40TS40D
INTEL	E28F008C3-T	TSOP	40	PA40TS40D	INTEL	E28F016B3-B	TSOP	40	PA40TS40D
INTEL	E28F016B3-T	TSOP	40	PA40TS40D	INTEL	E28F016C3-B	TSOP	40	PA40TS40D
INTEL	E28F016C3-T	TSOP	40	PA40TS40D	INTEL	E28F128J3A	TSOP	56	PA56TS48D-B6-YAM
INTEL	E28F128J3C	TSOP	56	PA56TS48D-B6-YAM	INTEL	E28F160B3-B	TSOP	48	PA48TS48D
INTEL	E28F160B3-T	TSOP	48	PA48TS48D	INTEL	E28F160C2-BA	TSOP	48	PA48TS48D
INTEL	E28F160C2-TA	TSOP	48	PA48TS48D	INTEL	E28F160C3-B	TSOP	48	PA48TS48D
INTEL	E28F160C3-T	TSOP	48	PA48TS48D	INTEL	E28F160S3	TSOP	56	PA56TS48D-B6-YAM
INTEL	E28F160S5	TSOP	56	PA56TS48D-B6-YAM	INTEL	E28F320B3-B	TSOP	48	PA48TS48D
INTEL	E28F320B3-T	TSOP	48	PA48TS48D	INTEL	E28F320C3-B	TSOP	48	PA48TS48D
INTEL	E28F320C3-T	TSOP	48	PA48TS48D	INTEL	E28F320J3A	TSOP	56	PA56TS48D-B6-YAM
INTEL	E28F320J5	TSOP	56	PA56TS48D-B6-YAM	INTEL	E28F400B3-B	TSOP	48	PA48TS48D
INTEL	E28F400B3-T	TSOP	48	PA48TS48D	INTEL	E28F400C3-B	TSOP	48	PA48TS48D
INTEL	E28F400C3-T	TSOP	48	PA48TS48D	INTEL	E28F640J3A	TSOP	56	PA56TS48D-B6-YAM
INTEL	E28F640J3C	TSOP	56	PA56TS48D-B6-YAM	INTEL	E28F640J5	TSOP	56	PA56TS48D-B6-YAM
INTEL	E28F800B3-B	TSOP	48	PA48TS48D	INTEL	E28F800B3-T	TSOP	48	PA48TS48D
INTEL	E28F800B5-B	TSOP	48	PA48TS48D	INTEL	E28F800B5-T	TSOP	48	PA48TS48D
INTEL	E28F800C2-BA	TSOP	48	PA48TS48D	INTEL	E28F800C2-TA	TSOP	48	PA48TS48D
INTEL	E28F800C3-B	TSOP	48	PA48TS48D	INTEL	E28F800C3-T	TSOP	48	PA48TS48D
INTEL	E28F800CV-B	TSOP	48	PA48TS48D	INTEL	E28F800CV-T	TSOP	48	PA48TS48D
INTEL	E82802AB	TSOP	40	PA40TS40D	INTEL	E82802AC	TSOP	40	PA40TS40D
INTEL	G28F320J5	BGA	48	CIC-56uBGA-48D-A6-YAM	INTEL	G28F640J5	BGA	48	CIC-56uBGA-48D-A6-YAM
INTEL	GE28F3204W30-B	BGA	56	PA56BGA48D-TO	INTEL	GE28F3204W30-T	BGA	56	PA56BGA48D-TO
INTEL	GE28F3208W30-B	BGA	56	PA56BGA48D-TO	INTEL	GE28F3208W30-T	BGA	56	PA56BGA48D-TO
INTEL	GE28F320W30-B	BGA	56	PA56BGA48D-TO	INTEL	GE28F320W30-T	BGA	56	PA56BGA48D-TO
INTEL	GE28F6408W18-B	BGA	56	PA56BGA48DE	INTEL	GE28F6408W18-T	BGA	56	PA56BGA48DE
INTEL	GE28F6408W30-B	BGA	56	PA56BGA48D-TO	INTEL	GE28F6408W30-T	BGA	56	PA56BGA48D-TO
INTEL	GT28F004B3-B	BGA	48	CIC-48uBGA-40D-B6-TI	INTEL	GT28F004B3-T	BGA	48	CIC-48uBGA-40D-B6-TI
INTEL	GT28F008B3-B	BGA	48	CIC-48uBGA-40D-B6-TI	INTEL	GT28F008B3-T	BGA	48	CIC-48uBGA-40D-B6-TI
INTEL	GT28F008C3-B	BGA	48	CIC-48uBGA-40D-B6-TI	INTEL	GT28F008C3-T	BGA	48	CIC-48uBGA-40D-B6-TI
INTEL	GT28F016B3-B	BGA	48	CIC-48uBGA-40D-B6-TI	INTEL	GT28F016B3-T	BGA	48	CIC-48uBGA-40D-B6-TI
INTEL	GT28F016C3-B	BGA	48	CIC-48uBGA-40D-B6-TI	INTEL	GT28F016C3-T	BGA	48	CIC-48uBGA-40D-B6-TI
INTEL	GT28F160B3-B	BGA	48	CIC-48uBGA-44D-A6-YAM	INTEL	GT28F160B3-T	BGA	48	CIC-48uBGA-44D-A6-YAM

INTEL	GT28F160C2-BA	BGA	48	CIC-48uBGA-44D-A6-YAM	INTEL	GT28F160C2-TA	BGA	48	CIC-48uBGA-44D-A6-YAM
INTEL	GT28F160C3-B	BGA	48	CIC-48uBGA-44D-A6-YAM	INTEL	GT28F160C3-T	BGA	48	CIC-48uBGA-44D-A6-YAM
INTEL	GT28F160F3-B	BGA	56	CIC-56uBGA-48D-B6-TI	INTEL	GT28F160F3-T	BGA	56	CIC-56uBGA-48D-B6-TI
INTEL	GT28F320B3-B	BGA	48	CIC-48uBGA-48D-A6-TI	INTEL	GT28F320B3-T	BGA	48	CIC-48uBGA-48D-A6-TI
INTEL	GT28F320C3-B	BGA	48	CIC-48uBGA-48D-A6-TI	INTEL	GT28F320C3-T	BGA	48	CIC-48uBGA-48D-A6-TI
INTEL	GT28F400B3-B	BGA	48	CIC-48uBGA-44D-A6-YAM	INTEL	GT28F400B3-T	BGA	48	CIC-48uBGA-44D-A6-YAM
INTEL	GT28F400C3-B	BGA	48	CIC-48uBGA-44D-A6-YAM	INTEL	GT28F400C3-T	BGA	48	CIC-48uBGA-44D-A6-YAM
INTEL	GT28F800B3-B	BGA	48	CIC-48uBGA-44D-A6-YAM	INTEL	GT28F800B3-T	BGA	48	CIC-48uBGA-44D-A6-YAM
INTEL	GT28F800C2-BA	BGA	48	CIC-48uBGA-44D-A6-YAM	INTEL	GT28F800C2-TA	BGA	48	CIC-48uBGA-44D-A6-YAM
INTEL	GT28F800C3-B	BGA	48	CIC-48uBGA-44D-A6-YAM	INTEL	GT28F800C3-T	BGA	48	CIC-48uBGA-44D-A6-YAM
INTEL	GT28F800F3-B	BGA	56	CIC-56uBGA-48D-B6-TI	INTEL	GT28F800F3-T	BGA	56	CIC-56uBGA-48D-B6-TI
INTEL	JS28F128J3D	TSOP	56	PA56TS48D-B6-YAM	INTEL	N28F001BX-B	PLCC	32	PA32PL32D
INTEL	N28F001BX-T	PLCC	32	PA32PL32D	INTEL	N28F010	PLCC	32	PA32PL32D
INTEL	N28F020	PLCC	32	PA32PL32D	INTEL	N28802AB	PLCC	32	PA32PL32D
INTEL	N82802AC	PLCC	32	PA32PL32D	INTEL	P27128A	DIP	28	Not use adapter
INTEL	P27128B	DIP	28	Not use adapter	INTEL	P27256	DIP	28	Not use adapter
INTEL	P27512	DIP	28	Not use adapter	INTEL	P2764A	DIP	28	Not use adapter
INTEL	P27C128	DIP	28	Not use adapter	INTEL	P27C256	DIP	28	Not use adapter
INTEL	P27C256	PLCC	32	PA32-28	INTEL	P27C64	DIP	28	Not use adapter
INTEL	P28F001BX-B	DIP	32	Not use adapter	INTEL	P28F001BX-T	DIP	32	Not use adapter
INTEL	P28F010	DIP	32	Not use adapter	INTEL	P28F020	DIP	32	Not use adapter
INTEL	RC28F128J3A	EBGA	64	PA64EBGA48D	INTEL	RC28F128J3C	EBGA	64	PA64EBGA48D
INTEL	RC28F128K3	EBGA	64	PA64BGA48DA	INTEL	RC28F256K3	EBGA	64	PA64BGA48DA
INTEL	RC28F256P30B	EBGA	64	PA64BGA48DI	INTEL	RC28F256P30T	EBGA	64	PA64BGA48DI
INTEL	RC28F320J3A	EBGA	64	PA64EBGA48D	INTEL	RC28F320J3C	EBGA	64	PA64EBGA48D
INTEL	RC28F640J3A	EBGA	64	PA64EBGA48D	INTEL	RC28F640J3C	EBGA	64	PA64EBGA48D
INTEL	RC28F640K3	EBGA	64	PA64BGA48DA	INTEL	RC28F640P30B	EBGA	64	PA64BGA48DI
INTEL	RC28F640P30T	EBGA	64	PA64BGA48DI	INTEL	RD28F128J3AM	BGA	80	PA80BGA48D-A
INTEL	RD28F1602C3-B	BGA	72	PA72BGA48D-B	INTEL	RD28F1602C3-T	BGA	72	PA72BGA48D-B
INTEL	RD28F1604C3-B	BGA	72	PA72BGA48D-B	INTEL	RD28F1604C3-T	BGA	72	PA72BGA48D-B
INTEL	RD28F192SJ3AM	BGA	80	PA80BGA48D-A	INTEL	RD28F256SJ3AM	BGA	80	PA80BGA48D-A
INTEL	RD28F3202C3-B	BGA	72	PA72BGA48D-B	INTEL	RD28F3202C3-T	BGA	72	PA72BGA48D-B
INTEL	RD28F3204C3-B	BGA	72	PA72BGA48D-B	INTEL	RD28F3204C3-T	BGA	72	PA72BGA48D-B
INTEL	RD28F3208W30-B	BGA	80	PA80BGA48D	INTEL	RD28F3208W30-T	BGA	80	PA80BGA48D
INTEL	RD28F320W30-B	BGA	80	PA80BGA48D	INTEL	RD28F320W30-T	BGA	80	PA80BGA48D
INTEL	RD28F6408W30-B	BGA	80	PA80BGA48D	INTEL	RD28F6408W30-T	BGA	80	PA80BGA48D
INTEL	RD28F640W30-B	BGA	80	PA80BGA48D	INTEL	RD28F640W30-T	BGA	80	PA80BGA48D
INTEL	RD38F1010C0ZBL0	BGA	66	PA66BGA48DB	INTEL	RD38F1010C0ZTL0	BGA	66	PA66BGA48DB
INTEL	RD38F1020C0ZBL0	BGA	66	PA66BGA48DB	INTEL	RD38F1020C0ZTL0	BGA	66	PA66BGA48DB
INTEL	RD38F1030W0ZBQ0	BGA	88	PA88BGA48DA-YO-8X10	INTEL	RD38F2030W0ZBQ1	BGA	88	PA88BGA48DA-YO-8X10
INTEL	RD38F2040W0ZBQ0	BGA	88	PA88BGA48DA-YO-8X10	INTEL	RD38F2230WWZBQ0	BGA	88	PA88BGA48DA-YO-8X10
INTEL	RD38F2240WWZBQ0	BGA	88	PA88BGA48DA-YO-8X10	INTEL	RD38F2240WWZDQ0	BGA	88	PA88BGA48DA-YO-8X10
INTEL	RD38F3040L0ZBQ0	BGA	88	PA88BGA48DA-YO-8X10	INTEL	RD38F3040L0ZTQ0	BGA	88	PA88BGA48DA-YO-8X10
INTEL	RD38F3350LLZDQ0	BGA	88	PA88BGA48DA-YO-8X10	INTEL	RD38F3350WWZDQ1	BGA	88	PA88BGA48DA-YO-8X10
INTEL	TE28F128J3C	TSOP	56	PA56TS48D-B6-YAM	INTEL	TE28F320J3C	TSOP	56	PA56TS48D-B6-YAM
INTEL	TE28F640C3-B	TSOP	48	PA48TS48D	INTEL	TE28F640C3-T	TSOP	48	PA48TS48D
INTEL	TE28F640J3C	TSOP	56	PA56TS48D-B6-YAM	INTEL	TE28F640P30B	TSOP	56	HA56TS48DF
INTEL	TE28F640P30T	TSOP	56	HA56TS48DF	ISSI	IS27C512	DIP	28	Not use adapter
ISSI	IS27HC010	DIP	32	Not use adapter	ISSI	IS27HC256	DIP	28	Not use adapter
ISSI	IS27HC512	DIP	28	Not use adapter	ISSI	IS28F010	DIP	32	Not use adapter
ISSI	IS93C46	DIP	8	Not use adapter	ISSI	IS93C46-3G	SOIC	8	PA8SO8D-EO-150
ISSI	IS93C46-3GR	SOIC	8	PA8SO8D	ISSI	IS93C46-3P	DIP	8	Not use adapter
ISSI	IS93C46A-3G	SOIC	8	PA8SO8D-EO-150	ISSI	IS93C46A-3GR	SOIC	8	PA8SO8D
ISSI	IS93C46A-3P	DIP	8	Not use adapter	ISSI	IS93C56	DIP	8	Not use adapter
ISSI	IS93C56-3G	SOIC	8	PA8SO8D-EO-150	ISSI	IS93C56-3GR	SOIC	8	PA8SO8D
ISSI	IS93C56-3P	DIP	8	Not use adapter	ISSI	IS93C56A-3G	SOIC	8	PA8SO8D-EO-150
ISSI	IS93C56A-3GR	SOIC	8	PA8SO8D	ISSI	IS93C56A-3P	DIP	8	Not use adapter
ISSI	IS93C66	DIP	8	Not use adapter	ISSI	IS93C66-3G	SOIC	8	PA8SO8D-EO-150
ISSI	IS93C66-3GR	SOIC	8	PA8SO8D	ISSI	IS93C66-3P	DIP	8	Not use adapter
ISSI	IS93C66A-3G	SOIC	8	PA8SO8D-EO-150	ISSI	IS93C66A-3GR	SOIC	8	PA8SO8D
ISSI	IS93C66A-3P	DIP	8	Not use adapter	ISSI	IS93C76A-3G	SOIC	8	PA8SO8D-EO-150
ISSI	IS93C76A-3GR	SOIC	8	PA8SO8D	ISSI	IS93C76A-3P	DIP	8	Not use adapter
ISSI	IS93C86A-3G	SOIC	8	PA8SO8D-EO-150	ISSI	IS93C86A-3GR	SOIC	8	PA8SO8D
ISSI	IS93C86A-3P	DIP	8	Not use adapter	LATTICE	GAL16V8	DIP	20	Not use adapter
LATTICE	GAL16V8	SOIC	20	PA20SO2006-200/PA20SO20D	LATTICE	GAL16V8	PLCC	20	PA20LC20D
LATTICE	GAL16V8 as 10H8	DIP	20	Not use adapter	LATTICE	GAL16V8 as 10H8	SOIC	20	PA20SO2006-200/PA20SO20D
LATTICE	GAL16V8 as 10H8	PLCC	20	PA20LC20D	LATTICE	GAL16V8 as 10L8	DIP	20	Not use adapter
LATTICE	GAL16V8 as 10L8	SOIC	20	PA20SO2006-200/PA20SO20D	LATTICE	GAL16V8 as 10L8	PLCC	20	PA20LC20D
LATTICE	GAL16V8 as 10P8	DIP	20	Not use adapter	LATTICE	GAL16V8 as 10P8	PLCC	20	PA20LC20D
LATTICE	GAL16V8 as 10P8	SOIC	20	PA20SO2006-200/PA20SO20D	LATTICE	GAL16V8 as 12H6	DIP	20	Not use adapter
LATTICE	GAL16V8 as 12H6	PLCC	20	PA20LC20D	LATTICE	GAL16V8 as 12H6	SOIC	20	PA20SO2006-200/PA20SO20D
LATTICE	GAL16V8 as 12L6	DIP	20	Not use adapter	LATTICE	GAL16V8 as 12L6	SOIC	20	PA20SO2006-200/PA20SO20D
LATTICE	GAL16V8 as 12L6	PLCC	20	PA20LC20D	LATTICE	GAL16V8 as 12P6	DIP	20	Not use adapter
LATTICE	GAL16V8 as 12P6	PLCC	20	PA20LC20D	LATTICE	GAL16V8 as 12P6	SOIC	20	PA20SO2006-200/PA20SO20D

LATTICE	PALLV22V10Z	PLCC	28	PA28PL28D	LINVEX	LX59CF2010	TSOP	32	PA32TS20/PA32TS32D-20
LINVEX	LX59CF2128	TSOP	32	PA32TS20/PA32TS32D-20	LINVEX	LX59CF4010	TSOP	40	PA40TS40D
LINVEX	LX59CF4128	TSOP	32	PA32TS20/PA32TS32D-20	LINVEX	LX59CF432	TSOP	32	PA32TS20/PA32TS32D-20
MACRONIX	MX23C1000PC	DIP	28	Not use adapter	MACRONIX	MX23C1010MC	SOP	32	PA44SO44D
MACRONIX	MX23C1010PC	DIP	32	Not use adapter	MACRONIX	MX23C1010QC	PLCC	32	PA32PL32D
MACRONIX	MX23C2000MC	SOP	32	PA44SO44D	MACRONIX	MX23C2000PC	DIP	32	Not use adapter
MACRONIX	MX23C2000QC	PLCC	32	PA32PL32D	MACRONIX	MX23C4000MC	SOP	32	PA44SO44D
MACRONIX	MX23C4000PC	DIP	32	Not use adapter	MACRONIX	MX23C4000QC	PLCC	32	PA32PL32D
MACRONIX	MX23C8000MC	SOP	32	PA44SO44D	MACRONIX	MX23C8000PC	DIP	32	Not use adapter
MACRONIX	MX23C8000QC	PLCC	32	PA32PL32D	MACRONIX	MX25L1005MC	SOP	8	PA16SO16D-EO-150
MACRONIX	MX25L1005ZMC	CASON	8	PA8SON8D	MACRONIX	MX25L12805NMC	SOIC	16	PA28SO28D-EO-300
MACRONIX	MX25L1602MC	SOP	28	PA28SO1-06(H)	MACRONIX	MX25L1605AMC	SOP	8	PA16SO16D-EO-150
MACRONIX	MX25L1605AMC	SOIC	16	PA28SO28D-EO-300	MACRONIX	MX25L1605MC	SOP	8	PA16SO16D-EO-150
MACRONIX	MX25L1605MC	SOIC	16	PA28SO28D-EO-300	MACRONIX	MX25L2005MC	SOP	8	PA16SO16D-EO-150
MACRONIX	MX25L2005ZMC	CASON	8	PA8SON8D	MACRONIX	MX25L3202MC	SOP	32	PA32SO32D-1
MACRONIX	MX25L3205MC	SOP	8	PA16SO16D-EO-150	MACRONIX	MX25L3205MC	SOIC	16	PA28SO28D-EO-300
MACRONIX	MX25L4005AMC	SOP	8	PA16SO16D-EO-150	MACRONIX	MX25L4005AZMC	CASON	8	PA8SON8D
MACRONIX	MX25L4005M2C	SOP	8	PA20SO2006-200/PA20SO20D	MACRONIX	MX25L4005MC	SOP	8	PA16SO16D-EO-150
MACRONIX	MX25L4005ZMC	CASON	8	PA8SON8D	MACRONIX	MX25L512MC	SOP	8	PA16SO16D-EO-150
MACRONIX	MX25L512ZMC	CASON	8	PA8SON8D	MACRONIX	MX25L6402AMC	SOP	28	PA28SO1-06(H)
MACRONIX	MX25L6402MC	SOP	32	PA32SO32D-1	MACRONIX	MX25L6405MC	SOIC	16	PA28SO28D-EO-300
MACRONIX	MX25L8005M2C	SOP	8	PA20SO2006-200/PA20SO20D	MACRONIX	MX25L8005MC	SOP	8	PA16SO16D-EO-150
MACRONIX	MX25L8005ZMC	CASON	8	PA8SON8D	MACRONIX	MX25L802MC	SOP	28	PA28SO1-06(H)
MACRONIX	MX26C1000A	DIP	32	Not use adapter	MACRONIX	MX26C1000B	DIP	32	Not use adapter
MACRONIX	MX26C1000B	PLCC	32	PA32PL32D	MACRONIX	MX26C2000B	DIP	32	Not use adapter
MACRONIX	MX26C2000B	PLCC	32	PA32PL32D	MACRONIX	MX26C512A	DIP	28	Not use adapter
MACRONIX	MX26F128J3	EBGA	64	PA64EBGA48D	MACRONIX	MX26F640J3	TSOP	56	PA56TS48D-B6-YAM
MACRONIX	MX26F640J3	EBGA	64	PA64EBGA48D	MACRONIX	MX26L3220	TSOP	48	PA48TS48D
MACRONIX	MX26L6419	TSOP	48	PA48TS48D	MACRONIX	MX26L6420	TSOP	48	PA48TS48D
MACRONIX	MX26LV004BQC	PLCC	32	PA32PL32D	MACRONIX	MX26LV004BTC	TSOP	40	PA40TS40D
MACRONIX	MX26LV004TQC	PLCC	32	PA32PL32D	MACRONIX	MX26LV004TTC	TSOP	40	PA40TS40D
MACRONIX	MX26LV008BTC	TSOP	40	PA40TS40D	MACRONIX	MX26LV008TTC	TSOP	40	PA40TS40D
MACRONIX	MX26LV128J3	TSOP	56	PA56TS48D-B6-YAM	MACRONIX	MX26LV160ABTC	TSOP	48	PA48TS48D1
MACRONIX	MX26LV160ATTC	TSOP	48	PA48TS48D1	MACRONIX	MX26LV160BTC	TSOP	48	PA48TS48D1
MACRONIX	MX26LV160TTC	TSOP	48	PA48TS48D1	MACRONIX	MX26LV400BTC	TSOP	48	PA48TS48D1
MACRONIX	MX26LV400TTC	TSOP	48	PA48TS48D1	MACRONIX	MX26LV800BTC	TSOP	48	PA48TS48D1
MACRONIX	MX26LV800TTC	TSOP	48	PA48TS48D1	MACRONIX	MX27C1000	DIP	32	Not use adapter
MACRONIX	MX27C1001	DIP	32	Not use adapter	MACRONIX	MX27C1024	PLCC	44	PA44-48U
MACRONIX	MX27C1024	DIP	40	Not use adapter	MACRONIX	MX27C1100	DIP	40	Not use adapter
MACRONIX	MX27C2000	DIP	32	Not use adapter	MACRONIX	MX27C2000A	DIP	32	Not use adapter
MACRONIX	MX27C2048	PLCC	44	PA44-48U	MACRONIX	MX27C2048	DIP	40	Not use adapter
MACRONIX	MX27C2100	DIP	40	Not use adapter	MACRONIX	MX27C256	DIP	28	Not use adapter
MACRONIX	MX27C4000	DIP	32	Not use adapter	MACRONIX	MX27C4000A	DIP	32	Not use adapter
MACRONIX	MX27C4096	PLCC	44	PA44-48U	MACRONIX	MX27C4096	DIP	40	Not use adapter
MACRONIX	MX27C4100	DIP	40	Not use adapter	MACRONIX	MX27C4111	DIP	40	Not use adapter
MACRONIX	MX27C512	DIP	28	Not use adapter	MACRONIX	MX27C512	PLCC	32	PA32-28
MACRONIX	MX27C512	PLCC	32	PA32-28	MACRONIX	MX27C512	PLCC	32	PA32-28
MACRONIX	MX27C512	PLCC	32	PA32-28	MACRONIX	MX27C512	PLCC	32	PA32-28
MACRONIX	MX27C512	PLCC	32	PA32-28	MACRONIX	MX27C512	PLCC	32	PA32-28
MACRONIX	MX27C512	PLCC	32	PA32-28	MACRONIX	MX27C516	PLCC	44	PA44-48U
MACRONIX	MX27C64	DIP	28	Not use adapter	MACRONIX	MX27C8000	DIP	32	Not use adapter
MACRONIX	MX27C8100	DIP	42	Not use adapter	MACRONIX	MX27C8111	DIP	42	Not use adapter
MACRONIX	MX27L1000	DIP	32	Not use adapter	MACRONIX	MX27L2000	DIP	32	Not use adapter
MACRONIX	MX27L256	DIP	28	Not use adapter	MACRONIX	MX27L4000	DIP	32	Not use adapter
MACRONIX	MX27L512	DIP	28	Not use adapter	MACRONIX	MX28F1000	DIP	32	Not use adapter
MACRONIX	MX28F1000	PLCC	32	PA32PL32D	MACRONIX	MX28F160C3BTC	TSOP	48	PA48TS48D
MACRONIX	MX28F160C3TTC	TSOP	48	PA48TS48D	MACRONIX	MX28F2000	PLCC	32	PA32PL32D
MACRONIX	MX28F2000	DIP	32	Not use adapter	MACRONIX	MX29F001B	DIP	32	Not use adapter
MACRONIX	MX29F001T	DIP	32	Not use adapter	MACRONIX	MX29F002B	DIP	32	Not use adapter
MACRONIX	MX29F002NB	DIP	32	Not use adapter	MACRONIX	MX29F002NT	DIP	32	Not use adapter
MACRONIX	MX29F002T	DIP	32	Not use adapter	MACRONIX	MX29F004B	DIP	32	Not use adapter
MACRONIX	MX29F004T	DIP	32	Not use adapter	MACRONIX	MX29F016	TSOP	40	PA40TS40D
MACRONIX	MX29F040CPC	DIP	32	Not use adapter	MACRONIX	MX29F040CQC	PLCC	32	PA32PL32D
MACRONIX	MX29F040CTC	TSOP	32	PA32TS20/PA32TS32D-20	MACRONIX	MX29F040PC	DIP	32	Not use adapter
MACRONIX	MX29F040QC	PLCC	32	PA32PL32D	MACRONIX	MX29F040TC	TSOP	32	PA32TS20/PA32TS32D-20
MACRONIX	MX29F200B	TSOP	48	PA48TS48D	MACRONIX	MX29F200B	SOP	44	PA44SO44D
MACRONIX	MX29F200CBMI	SOP	44	PA44SO44D	MACRONIX	MX29F200CBTI	TSOP	48	PA48TS48D
MACRONIX	MX29F200CTMI	SOP	44	PA44SO44D	MACRONIX	MX29F200CTTI	TSOP	48	PA48TS48D
MACRONIX	MX29F200T	SOP	44	PA44SO44D	MACRONIX	MX29F200T	TSOP	48	PA48TS48D
MACRONIX	MX29F400BMC	SOP	44	PA44SO44D	MACRONIX	MX29F400BTC	TSOP	48	PA48TS48D
MACRONIX	MX29F400CBMC	SOP	44	PA44SO44D	MACRONIX	MX29F400CBTC	TSOP	48	PA48TS48D
MACRONIX	MX29F400CTMC	SOP	44	PA44SO44D	MACRONIX	MX29F400CTTC	TSOP	48	PA48TS48D
MACRONIX	MX29F400TMC	SOP	44	PA44SO44D	MACRONIX	MX29F400TTC	TSOP	48	PA48TS48D
MACRONIX	MX29F800B	TSOP	48	PA48TS48D	MACRONIX	MX29F800B	SOP	44	PA44SO44D

MACRONIX	MX29LV800BTXBC	BGA	48	PA48BG48DW	MACRONIX	MX29LV800BTXEC	BGA	48	PA48BG48DW
MACRONIX	MX29LV800BXBC	BGA	48	PA48BG48DW	MACRONIX	MX29LV800BXEC	BGA	48	PA48BG48DW
MACRONIX	MX29LV800CBMC	SOP	44	PA44SO44D1	MACRONIX	MX29LV800CBTC	TSOP	48	PA48TS48D1
MACRONIX	MX29LV800CBXBC	BGA	48	PA48BG48DW	MACRONIX	MX29LV800CBXEC	BGA	48	PA48BG48DW
MACRONIX	MX29LV800CTMC	SOP	44	PA44SO44D1	MACRONIX	MX29LV800CTTC	TSOP	48	PA48TS48D1
MACRONIX	MX29LV800CTXBC	BGA	48	PA48BG48DW	MACRONIX	MX29LV800CTXEC	BGA	48	PA48BG48DW
MACRONIX	MX29LV800TMC	SOP	44	PA44SO44D1	MACRONIX	MX29LV800TTC	TSOP	48	PA48TS48D1
MACRONIX	MX29LV800TXBC	BGA	48	PA48BG48DW	MACRONIX	MX29LV800TXEC	BGA	48	PA48BG48DW
MICROCHIP	24AA00	DIP	8	Not use adapter	MICROCHIP	24AA01	DIP	8	Not use adapter
MICROCHIP	24AA02	DIP	8	Not use adapter	MICROCHIP	24AA04	DIP	8	Not use adapter
MICROCHIP	24AA08	DIP	8	Not use adapter	MICROCHIP	24AA128	DIP	8	Not use adapter
MICROCHIP	24AA16	DIP	8	Not use adapter	MICROCHIP	24AA164	DIP	8	Not use adapter
MICROCHIP	24AA64	DIP	8	Not use adapter	MICROCHIP	24AA65	DIP	8	Not use adapter
MICROCHIP	24C00	DIP	8	Not use adapter	MICROCHIP	24C01A	DIP	8	Not use adapter
MICROCHIP	24C02A	DIP	8	Not use adapter	MICROCHIP	24C04A	DIP	8	Not use adapter
MICROCHIP	24C32	DIP	8	Not use adapter	MICROCHIP	24C65	DIP	8	Not use adapter
MICROCHIP	24FC128	DIP	8	Not use adapter	MICROCHIP	24LC00	DIP	8	Not use adapter
MICROCHIP	24LC01B	DIP	8	Not use adapter	MICROCHIP	24LC02B	DIP	8	Not use adapter
MICROCHIP	24LC04B	DIP	8	Not use adapter	MICROCHIP	24LC08B	DIP	8	Not use adapter
MICROCHIP	24LC128	DIP	8	Not use adapter	MICROCHIP	24LC164	DIP	8	Not use adapter
MICROCHIP	24LC16B	DIP	8	Not use adapter	MICROCHIP	24LC21	DIP	8	Not use adapter
MICROCHIP	24LC256	DIP	8	Not use adapter	MICROCHIP	24LC32	DIP	8	Not use adapter
MICROCHIP	24LC32A	DIP	8	Not use adapter	MICROCHIP	24LC64	DIP	8	Not use adapter
MICROCHIP	24LC64	SOIC	8	PA8SO8D	MICROCHIP	24LC65	DIP	8	Not use adapter
MICROCHIP	25AA040	DIP	8	Not use adapter	MICROCHIP	25AA080	DIP	8	Not use adapter
MICROCHIP	25AA080	MSOP	8	PA8MSOP8D	MICROCHIP	25AA160	DIP	8	Not use adapter
MICROCHIP	25AA640	DIP	8	Not use adapter	MICROCHIP	25C040	DIP	8	Not use adapter
MICROCHIP	25C080	DIP	8	Not use adapter	MICROCHIP	25C080	MSOP	8	PA8MSOP8D
MICROCHIP	25C160	DIP	8	Not use adapter	MICROCHIP	25C320	DIP	8	Not use adapter
MICROCHIP	25C640	DIP	8	Not use adapter	MICROCHIP	25LC040	DIP	8	Not use adapter
MICROCHIP	25LC080	DIP	8	Not use adapter	MICROCHIP	25LC080	MSOP	8	PA8MSOP8D
MICROCHIP	25LC160	DIP	8	Not use adapter	MICROCHIP	25LC320	DIP	8	Not use adapter
MICROCHIP	25LC640	DIP	8	Not use adapter	MICROCHIP	27256	DIP	28	Not use adapter
MICROCHIP	27C128	DIP	28	Not use adapter	MICROCHIP	27C128	SOIC	28	PA28SO28D-08
MICROCHIP	27C128	PLCC	32	PA32-28	MICROCHIP	27C256	DIP	28	Not use adapter
MICROCHIP	27C512	DIP	28	Not use adapter	MICROCHIP	27C64	DIP	28	Not use adapter
MICROCHIP	27C64	PLCC	32	PA32-28	MICROCHIP	27C64	SOIC	28	PA28SO28D-08
MICROCHIP	27HC128	DIP	28	Not use adapter	MICROCHIP	27HC128	SOIC	28	PA28SO28D-08
MICROCHIP	27HC128	PLCC	32	PA32-28	MICROCHIP	27HC256	DIP	28	Not use adapter
MICROCHIP	27HC256L	DIP	28	Not use adapter	MICROCHIP	27HC64	DIP	28	Not use adapter
MICROCHIP	27HC64	PLCC	32	PA32-28	MICROCHIP	27HC64	SOIC	28	PA28SO28D-08
MICROCHIP	27HC64L	DIP	28	Not use adapter	MICROCHIP	27LV64	DIP	28	Not use adapter
MICROCHIP	27LV64	SOIC	28	PA28SO28D-08	MICROCHIP	27LV64	PLCC	32	PA32-28
MICROCHIP	28C04	DIP	24	Not use adapter	MICROCHIP	28C04A	DIP	24	Not use adapter
MICROCHIP	28C04AF	DIP	24	Not use adapter	MICROCHIP	28C04F	DIP	24	Not use adapter
MICROCHIP	28C16	DIP	24	Not use adapter	MICROCHIP	28C16A	DIP	24	Not use adapter
MICROCHIP	28C16AF	DIP	24	Not use adapter	MICROCHIP	28C16F	DIP	24	Not use adapter
MICROCHIP	28C17	DIP	28	Not use adapter	MICROCHIP	28C17A	DIP	28	Not use adapter
MICROCHIP	28C17AF	DIP	28	Not use adapter	MICROCHIP	28C17F	DIP	28	Not use adapter
MICROCHIP	28C64	DIP	28	Not use adapter	MICROCHIP	28C64A	DIP	28	Not use adapter
MICROCHIP	28C64AF	DIP	28	Not use adapter	MICROCHIP	28C64AX	DIP	28	Not use adapter
MICROCHIP	85C72	DIP	8	Not use adapter	MICROCHIP	85C72	SOP	8	PA8SO1-2006-6
MICROCHIP	85C82	DIP	8	Not use adapter	MICROCHIP	85C82	SOP	8	PA8SO1-2006-6
MICROCHIP	85C92	DIP	8	Not use adapter	MICROCHIP	85C92	SOP	8	PA8SO1-2006-6
MICROCHIP	93AA46	DIP	8	Not use adapter	MICROCHIP	93AA46	SOIC	8	PA8SO8D
MICROCHIP	93AA46A	TSSOP	8	PA8TSS-OT	MICROCHIP	93AA46A	DIP	8	Not use adapter
MICROCHIP	93AA46A	SOIC	8	PA8SO8D	MICROCHIP	93AA46AX	SOIC	8	PA8SO8D-EO-150
MICROCHIP	93AA46B	TSSOP	8	PA8TSS-OT	MICROCHIP	93AA46B	DIP	8	Not use adapter
MICROCHIP	93AA46B	SOIC	8	PA8SO8D	MICROCHIP	93AA46BX	SOIC	8	PA8SO8D-EO-150
MICROCHIP	93AA46C	TSSOP	8	PA8TSS-OT	MICROCHIP	93AA46C	DIP	8	Not use adapter
MICROCHIP	93AA46C	SOIC	8	PA8SO8D	MICROCHIP	93AA46CX	SOIC	8	PA8SO8D-EO-150
MICROCHIP	93AA46X	SOIC	8	PA8SO8D-EO-150	MICROCHIP	93AA56	DIP	8	Not use adapter
MICROCHIP	93AA56	SOIC	8	PA8SO8D	MICROCHIP	93AA56A	DIP	8	Not use adapter
MICROCHIP	93AA56A	TSSOP	8	PA8TSS-OT	MICROCHIP	93AA56A	SOIC	8	PA8SO8D
MICROCHIP	93AA56AX	SOIC	8	PA8SO8D-EO-150	MICROCHIP	93AA56B	TSSOP	8	PA8TSS-OT
MICROCHIP	93AA56B	DIP	8	Not use adapter	MICROCHIP	93AA56B	SOIC	8	PA8SO8D
MICROCHIP	93AA56BX	SOIC	8	PA8SO8D-EO-150	MICROCHIP	93AA56C	TSSOP	8	PA8TSS-OT
MICROCHIP	93AA56C	DIP	8	Not use adapter	MICROCHIP	93AA56C	SOIC	8	PA8SO8D
MICROCHIP	93AA56CX	SOIC	8	PA8SO8D-EO-150	MICROCHIP	93AA56X	SOIC	8	PA8SO8D-EO-150
MICROCHIP	93AA66	DIP	8	Not use adapter	MICROCHIP	93AA66	SOIC	8	PA8SO8D
MICROCHIP	93AA66A	TSSOP	8	PA8TSS-OT	MICROCHIP	93AA66A	DIP	8	Not use adapter
MICROCHIP	93AA66A	SOIC	8	PA8SO8D	MICROCHIP	93AA66AX	SOIC	8	PA8SO8D-EO-150
MICROCHIP	93AA66B	DIP	8	Not use adapter	MICROCHIP	93AA66B	TSSOP	8	PA8TSS-OT
MICROCHIP	93AA66B	SOIC	8	PA8SO8D	MICROCHIP	93AA66BX	SOIC	8	PA8SO8D-EO-150

MICROCHIP	93LC86C	TSSOP	8	PA8TSS-OT	MICROCHIP	93LC86C	DIP	8	Not use adapter
MICROCHIP	93LC86C	SOIC	8	PA8SO8D	MICROCHIP	93LC86X	SOIC	8	PA8SO8D-EO-150
MICROCHIP	93LCS56	DIP	8	Not use adapter	MICROCHIP	93LCS56	SOIC	8	PA8SO8D
MICROCHIP	93LCS66	DIP	8	Not use adapter	MICROCHIP	93LCS66	SOIC	8	PA8SO8D
MICROCHIP	HCS200	DIP	8	Not use adapter	MICROCHIP	HCS200	SOIC	8	PA8SO8D
MICROCHIP	HCS201	DIP	8	Not use adapter	MICROCHIP	HCS201	SOIC	8	PA8SO8D
MICROCHIP	HCS300	DIP	8	Not use adapter	MICROCHIP	HCS300	SOIC	8	PA8SO8D
MICROCHIP	HCS301	DIP	8	Not use adapter	MICROCHIP	HCS301	SOIC	8	PA8SO8D
MICROCHIP	HCS320	DIP	8	Not use adapter	MICROCHIP	HCS320	SOIC	8	PA8SO8D
MICROCHIP	HCS360	DIP	8	Not use adapter	MICROCHIP	HCS360	SOIC	8	PA8SO8D
MICROCHIP	HCS361	DIP	8	Not use adapter	MICROCHIP	HCS361	SOIC	8	PA8SO8D
MICROCHIP	HCS362	TSSOP	8	PA8TSS-OT	MICROCHIP	HCS362	DIP	8	Not use adapter
MICROCHIP	HCS362	SOIC	8	PA8SO8D	MICROCHIP	HCS410	DIP	8	Not use adapter
MICROCHIP	HCS410	TSSOP	8	PA8TSS-OT	MICROCHIP	HCS410	SOIC	8	PA8SO8D
MICROCHIP	HCS412	DIP	8	Not use adapter	MICROCHIP	HCS412	SOIC	8	PA8SO8D
MICROCHIP	PIC10F200	DIP	8	Not use adapter	MICROCHIP	PIC10F202	DIP	8	Not use adapter
MICROCHIP	PIC10F204	DIP	8	Not use adapter	MICROCHIP	PIC10F208	DIP	8	Not use adapter
MICROCHIP	PIC12C508	DIP	8	Not use adapter	MICROCHIP	PIC12C508A	DIP	8	Not use adapter
MICROCHIP	PIC12C509	DIP	8	Not use adapter	MICROCHIP	PIC12C509A	DIP	8	Not use adapter
MICROCHIP	PIC12C509AF	DIP	20	Not use adapter	MICROCHIP	PIC12C509AG	DIP	18	Not use adapter
MICROCHIP	PIC12C671	DIP	8	Not use adapter	MICROCHIP	PIC12C672	DIP	8	Not use adapter
MICROCHIP	PIC12CE508	DIP	8	Not use adapter	MICROCHIP	PIC12CE508A	DIP	8	Not use adapter
MICROCHIP	PIC12CE509	DIP	8	Not use adapter	MICROCHIP	PIC12CE509A	DIP	8	Not use adapter
MICROCHIP	PIC12CE518	DIP	8	Not use adapter	MICROCHIP	PIC12CE519	DIP	8	Not use adapter
MICROCHIP	PIC12F508	DIP	8	Not use adapter	MICROCHIP	PIC12F508	SOIC	8	PA8SO1-05-6
MICROCHIP	PIC12F509	DIP	8	Not use adapter	MICROCHIP	PIC12F509	SOIC	8	PA8SO1-05-6
MICROCHIP	PIC12F629	DIP	8	Not use adapter	MICROCHIP	PIC12F635	DIP	8	Not use adapter
MICROCHIP	PIC12F635	SOIC	8	PA8SO1-05-6	MICROCHIP	PIC12F675	DIP	8	Not use adapter
MICROCHIP	PIC12F683	DIP	8	Not use adapter	MICROCHIP	PIC12F683	SOIC	8	PA8SO1-05-6
MICROCHIP	PIC16C505	DIP	14	Not use adapter	MICROCHIP	PIC16C52	DIP	18	Not use adapter
MICROCHIP	PIC16C52(OTP)	DIP	18	Not use adapter	MICROCHIP	PIC16C54	DIP	18	Not use adapter
MICROCHIP	PIC16C54(OTP)	DIP	18	Not use adapter	MICROCHIP	PIC16C54A	DIP	18	Not use adapter
MICROCHIP	PIC16C54B	DIP	18	Not use adapter	MICROCHIP	PIC16C54C	DIP	18	Not use adapter
MICROCHIP	PIC16C55	DIP	28	Not use adapter	MICROCHIP	PIC16C55(OTP)	DIP	28	Not use adapter
MICROCHIP	PIC16C554	DIP	18	Not use adapter	MICROCHIP	PIC16C556	DIP	18	Not use adapter
MICROCHIP	PIC16C558	DIP	18	Not use adapter	MICROCHIP	PIC16C55A	DIP	28	Not use adapter
MICROCHIP	PIC16C56	DIP	18	Not use adapter	MICROCHIP	PIC16C56(OTP)	DIP	18	Not use adapter
MICROCHIP	PIC16C56A	DIP	18	Not use adapter	MICROCHIP	PIC16C57	DIP	28	Not use adapter
MICROCHIP	PIC16C57(OTP)	DIP	28	Not use adapter	MICROCHIP	PIC16C57C	DIP	28	Not use adapter
MICROCHIP	PIC16C58A	DIP	18	Not use adapter	MICROCHIP	PIC16C58B	DIP	18	Not use adapter
MICROCHIP	PIC16C61	DIP	18	Not use adapter	MICROCHIP	PIC16C62	DIP	28	Not use adapter
MICROCHIP	PIC16C620	DIP	18	Not use adapter	MICROCHIP	PIC16C620A	DIP	18	Not use adapter
MICROCHIP	PIC16C621	DIP	18	Not use adapter	MICROCHIP	PIC16C621A	DIP	18	Not use adapter
MICROCHIP	PIC16C622	DIP	18	Not use adapter	MICROCHIP	PIC16C622A	DIP	18	Not use adapter
MICROCHIP	PIC16C62A	DIP	28	Not use adapter	MICROCHIP	PIC16C62B	DIP	28	Not use adapter
MICROCHIP	PIC16C63	DIP	28	Not use adapter	MICROCHIP	PIC16C63A	DIP	28	Not use adapter
MICROCHIP	PIC16C64	PLCC	44	PA44-48U	MICROCHIP	PIC16C64	DIP	40	Not use adapter
MICROCHIP	PIC16C641	DIP	28	Not use adapter	MICROCHIP	PIC16C642	DIP	28	Not use adapter
MICROCHIP	PIC16C64A	DIP	40	Not use adapter	MICROCHIP	PIC16C64A	PLCC	44	PA44-48U
MICROCHIP	PIC16C65	PLCC	44	PA44-48U	MICROCHIP	PIC16C65	DIP	40	Not use adapter
MICROCHIP	PIC16C65A	PLCC	44	PA44-48U	MICROCHIP	PIC16C65A	DIP	40	Not use adapter
MICROCHIP	PIC16C65B	PLCC	44	PA44-48U	MICROCHIP	PIC16C65B	DIP	40	Not use adapter
MICROCHIP	PIC16C66	DIP	28	Not use adapter	MICROCHIP	PIC16C661	DIP	40	Not use adapter
MICROCHIP	PIC16C662	DIP	40	Not use adapter	MICROCHIP	PIC16C67	DIP	40	Not use adapter
MICROCHIP	PIC16C67	PLCC	44	PA44-48U	MICROCHIP	PIC16C71	DIP	18	Not use adapter
MICROCHIP	PIC16C710	DIP	18	Not use adapter	MICROCHIP	PIC16C711	DIP	18	Not use adapter
MICROCHIP	PIC16C712	DIP	18	Not use adapter	MICROCHIP	PIC16C715	DIP	18	Not use adapter
MICROCHIP	PIC16C716	DIP	18	Not use adapter	MICROCHIP	PIC16C717	DIP	18	Not use adapter
MICROCHIP	PIC16C72	DIP	28	Not use adapter	MICROCHIP	PIC16C72A	DIP	28	Not use adapter
MICROCHIP	PIC16C73	DIP	28	Not use adapter	MICROCHIP	PIC16C73A	DIP	28	Not use adapter
MICROCHIP	PIC16C73B	DIP	28	Not use adapter	MICROCHIP	PIC16C73B	SOIC	28	PA28SO28D-08
MICROCHIP	PIC16C74	PLCC	44	PA44-48U	MICROCHIP	PIC16C74	DIP	40	Not use adapter
MICROCHIP	PIC16C745	DIP	28	Not use adapter	MICROCHIP	PIC16C74A	PLCC	44	PA44-48U
MICROCHIP	PIC16C74A	DIP	40	Not use adapter	MICROCHIP	PIC16C74B	PLCC	44	PA44-48U
MICROCHIP	PIC16C74B	DIP	40	Not use adapter	MICROCHIP	PIC16C76	DIP	28	Not use adapter
MICROCHIP	PIC16C765	DIP	40	Not use adapter	MICROCHIP	PIC16C77	DIP	40	Not use adapter
MICROCHIP	PIC16C770	DIP	20	Not use adapter	MICROCHIP	PIC16C771	DIP	20	Not use adapter
MICROCHIP	PIC16C773	DIP	28	Not use adapter	MICROCHIP	PIC16C774	PLCC	44	PA44-48U
MICROCHIP	PIC16C774	DIP	40	Not use adapter	MICROCHIP	PIC16C781	DIP	20	Not use adapter
MICROCHIP	PIC16C782	DIP	20	Not use adapter	MICROCHIP	PIC16C84	DIP	18	Not use adapter
MICROCHIP	PIC16C923	PLCC	68	PA756-68Z	MICROCHIP	PIC16C924	PLCC	68	PA756-68Z
MICROCHIP	PIC16CE623	DIP	18	Not use adapter	MICROCHIP	PIC16CE624	DIP	18	Not use adapter
MICROCHIP	PIC16CE625	DIP	18	Not use adapter	MICROCHIP	PIC16CR54A	DIP	18	Not use adapter
MICROCHIP	PIC16CR54B	DIP	18	Not use adapter	MICROCHIP	PIC16CR54C	DIP	18	Not use adapter

MICROCHIP	PIC16CR56A	DIP	18	Not use adapter	MICROCHIP	PIC16CR57B	DIP	28	Not use adapter
MICROCHIP	PIC16CR57C	DIP	28	Not use adapter	MICROCHIP	PIC16CR58A	DIP	18	Not use adapter
MICROCHIP	PIC16CR58B	DIP	18	Not use adapter	MICROCHIP	PIC16CR83	DIP	18	Not use adapter
MICROCHIP	PIC16CR84	DIP	18	Not use adapter	MICROCHIP	PIC16F505	DIP	14	Not use adapter
MICROCHIP	PIC16F505	SOIC	14	PA16SO16D	MICROCHIP	PIC16F505	TSSOP	14	PA24TSS24D(M)
MICROCHIP	PIC16F54	DIP	18	Not use adapter	MICROCHIP	PIC16F54	SOIC	18	PA18SO1-08H-6D
MICROCHIP	PIC16F54	SSOP	20	PA20SS-P54	MICROCHIP	PIC16F57	DIP	28	Not use adapter
MICROCHIP	PIC16F57	SSOP	28	PA28TSSOP3	MICROCHIP	PIC16F57	SOIC	28	PA28SO1-15B-3
MICROCHIP	PIC16F627	DIP	18	Not use adapter	MICROCHIP	PIC16F627A	DIP	18	Not use adapter
MICROCHIP	PIC16F627A	SSOP	20	PA20SS-P54	MICROCHIP	PIC16F627A	SOIC	18	PA18SO1-08H-6D
MICROCHIP	PIC16F628	DIP	18	Not use adapter	MICROCHIP	PIC16F628A	DIP	18	Not use adapter
MICROCHIP	PIC16F628A	SOIC	18	PA18SO1-08H-6D	MICROCHIP	PIC16F628A	SSOP	20	PA20SS-P54
MICROCHIP	PIC16F630	DIP	14	Not use adapter	MICROCHIP	PIC16F636	DIP	14	Not use adapter
MICROCHIP	PIC16F636	TSSOP	14	PA24TSS24D(M)	MICROCHIP	PIC16F636	SOIC	14	PA16SO16D
MICROCHIP	PIC16F648A	DIP	18	Not use adapter	MICROCHIP	PIC16F648A	SSOP	20	PA20SS-P54
MICROCHIP	PIC16F648A	SOIC	18	PA18SO1-08H-6D	MICROCHIP	PIC16F676	DIP	14	Not use adapter
MICROCHIP	PIC16F676	SOIC	14	PA16SO16D	MICROCHIP	PIC16F684	DIP	14	Not use adapter
MICROCHIP	PIC16F684	TSSOP	14	PA24TSS24D(M)	MICROCHIP	PIC16F684	SOIC	14	PA16SO16D
MICROCHIP	PIC16F688	DIP	14	Not use adapter	MICROCHIP	PIC16F688	SOIC	14	PA16SO16D
MICROCHIP	PIC16F688	TSSOP	14	PA24TSS24D(M)	MICROCHIP	PIC16F716	DIP	18	Not use adapter
MICROCHIP	PIC16F716	SSOP	20	PA20SS-P54	MICROCHIP	PIC16F716	SOIC	18	PA18SO1-08H-6D
MICROCHIP	PIC16F72	DIP	28	Not use adapter	MICROCHIP	PIC16F73	DIP	28	Not use adapter
MICROCHIP	PIC16F737	DIP	28	Not use adapter	MICROCHIP	PIC16F737	SOIC	28	PA28SO28D-08
MICROCHIP	PIC16F74	PLCC	44	PA44-48U	MICROCHIP	PIC16F74	DIP	40	Not use adapter
MICROCHIP	PIC16F74	QFP	44	PA44QF44D	MICROCHIP	PIC16F76	DIP	28	Not use adapter
MICROCHIP	PIC16F767	DIP	28	Not use adapter	MICROCHIP	PIC16F767	SOIC	28	PA28SO28D-08
MICROCHIP	PIC16F77	PLCC	44	PA44-48U	MICROCHIP	PIC16F77	DIP	40	Not use adapter
MICROCHIP	PIC16F77	QFP	44	PA44QF44D	MICROCHIP	PIC16F818	DIP	18	Not use adapter
MICROCHIP	PIC16F818	SSOP	20	PA20SS-P54	MICROCHIP	PIC16F818	SOIC	18	PA18SO1-08H-6D
MICROCHIP	PIC16F819	DIP	18	Not use adapter	MICROCHIP	PIC16F819	SOIC	18	PA18SO1-08H-6D
MICROCHIP	PIC16F819	SSOP	20	PA20SS-P54	MICROCHIP	PIC16F83	DIP	18	Not use adapter
MICROCHIP	PIC16F84	DIP	18	Not use adapter	MICROCHIP	PIC16F84A	DIP	18	Not use adapter
MICROCHIP	PIC16F87	DIP	18	Not use adapter	MICROCHIP	PIC16F87	SSOP	20	PA20SS-P54
MICROCHIP	PIC16F87	SOIC	18	PA18SO1-08H-6D	MICROCHIP	PIC16F870	DIP	28	Not use adapter
MICROCHIP	PIC16F871	DIP	40	Not use adapter	MICROCHIP	PIC16F871	QFP	44	PA44QF44D
MICROCHIP	PIC16F872	DIP	28	Not use adapter	MICROCHIP	PIC16F873	DIP	28	Not use adapter
MICROCHIP	PIC16F873A	DIP	28	Not use adapter	MICROCHIP	PIC16F874	PLCC	44	PA44-48U
MICROCHIP	PIC16F874	DIP	40	Not use adapter	MICROCHIP	PIC16F874	QFP	44	PA44QF44D
MICROCHIP	PIC16F874A	DIP	40	Not use adapter	MICROCHIP	PIC16F874A	PLCC	44	PA44-48U
MICROCHIP	PIC16F874A	QFP	44	PA44QF44D	MICROCHIP	PIC16F876	DIP	28	Not use adapter
MICROCHIP	PIC16F876A	DIP	28	Not use adapter	MICROCHIP	PIC16F877	PLCC	44	PA44-48U
MICROCHIP	PIC16F877	DIP	40	Not use adapter	MICROCHIP	PIC16F877	QFP	44	PA44QF44D
MICROCHIP	PIC16F877A	PLCC	44	PA44-48U	MICROCHIP	PIC16F877A	DIP	40	Not use adapter
MICROCHIP	PIC16F877A	QFP	44	PA44QF44D	MICROCHIP	PIC16F88	DIP	18	Not use adapter
MICROCHIP	PIC16F88	SOIC	18	PA18SO1-08H-6D	MICROCHIP	PIC16F88	SSOP	20	PA20SS-P54
MICROCHIP	PIC16HV540	DIP	18	Not use adapter	MICROCHIP	PIC16LC73A	DIP	28	Not use adapter
MICROCHIP	PIC16LC73B	DIP	28	Not use adapter	MICROCHIP	PIC16LC74A	PLCC	44	PA44-48U
MICROCHIP	PIC16LC74A	DIP	40	Not use adapter	MICROCHIP	PIC16LC74B	DIP	40	Not use adapter
MICROCHIP	PIC16LC74B	PLCC	44	PA44-48U	MICROCHIP	PIC16LC77	DIP	40	Not use adapter
MICROCHIP	PIC16LF72	DIP	28	Not use adapter	MICROCHIP	PIC16LF873A	DIP	28	Not use adapter
MICROCHIP	PIC16LF876A	DIP	28	Not use adapter	MICROCHIP	PIC17C42	PLCC	44	PA44-48U
MICROCHIP	PIC17C42	DIP	40	Not use adapter	MICROCHIP	PIC17C42A	DIP	40	Not use adapter
MICROCHIP	PIC17C42A	PLCC	44	PA44-48U	MICROCHIP	PIC17C43	PLCC	44	PA44-48U
MICROCHIP	PIC17C43	DIP	40	Not use adapter	MICROCHIP	PIC17C44	DIP	40	Not use adapter
MICROCHIP	PIC17C44	PLCC	44	PA44-48U	MICROCHIP	PIC17C752	PLCC	68	PA756-68Z
MICROCHIP	PIC17C756	SDIP	64	PA923-SD	MICROCHIP	PIC17C756	PLCC	68	PA756-68Z
MICROCHIP	PIC17C756A	PLCC	68	PA756-68Z	MICROCHIP	PIC17C756A	SDIP	64	PA923-SD
MICROCHIP	PIC17LC44	DIP	40	Not use adapter	MICROCHIP	PIC17LC44	PLCC	44	PA44-48U
MICROCHIP	PIC18C242	DIP	28	Not use adapter	MICROCHIP	PIC18C252	DIP	28	Not use adapter
MICROCHIP	PIC18C442	PLCC	44	Not use adapter	MICROCHIP	PIC18C442	DIP	40	Not use adapter
MICROCHIP	PIC18C452	DIP	40	Not use adapter	MICROCHIP	PIC18C452	PLCC	44	Not use adapter
MICROCHIP	PIC18C658	TQFP	64	PA64TQ40D	MICROCHIP	PIC18F1220	DIP	18	Not use adapter
MICROCHIP	PIC18F1220	SSOP	20	PA20SS-P54	MICROCHIP	PIC18F1220	SOIC	18	PA28SO28D-08
MICROCHIP	PIC18F1320	DIP	18	Not use adapter	MICROCHIP	PIC18F1320	SOIC	18	PA28SO28D-08
MICROCHIP	PIC18F1320	SSOP	20	PA20SS-P54	MICROCHIP	PIC18F2220	DIP	28	Not use adapter
MICROCHIP	PIC18F2220	SOIC	28	PA28SO28D-08	MICROCHIP	PIC18F2221	DIP	28	Not use adapter
MICROCHIP	PIC18F2221	QFN	28	PA28QFN28D	MICROCHIP	PIC18F2221	SOIC	28	PA28SO28D-08
MICROCHIP	PIC18F2320	DIP	28	Not use adapter	MICROCHIP	PIC18F2320	SOIC	28	PA28SO28D-08
MICROCHIP	PIC18F2321	DIP	28	Not use adapter	MICROCHIP	PIC18F2321	QFN	28	PA28QFN28D
MICROCHIP	PIC18F2321	SOIC	28	PA28SO28D-08	MICROCHIP	PIC18F2410	DIP	28	Not use adapter
MICROCHIP	PIC18F2410	QFN	28	PA28QFN28D	MICROCHIP	PIC18F2410	SOIC	28	PA28SO28D-08
MICROCHIP	PIC18F242	DIP	28	Not use adapter	MICROCHIP	PIC18F2420	DIP	28	Not use adapter
MICROCHIP	PIC18F2420	QFN	28	PA28QFN28D	MICROCHIP	PIC18F2420	SOIC	28	PA28SO28D-08
MICROCHIP	PIC18F2455	DIP	28	Not use adapter	MICROCHIP	PIC18F2455	SOIC	28	PA28SO28D-08

MICROCHIP	PIC18LF2680	SOIC	28	PA28SO28D-08	MICROCHIP	PIC18LF4221	QFN	44	PA44QFN44D
MICROCHIP	PIC18LF4221	DIP	40	Not use adapter	MICROCHIP	PIC18LF4221	QFP	44	PA44QF44D
MICROCHIP	PIC18LF4321	DIP	40	Not use adapter	MICROCHIP	PIC18LF4321	QFN	44	PA44QFN44D
MICROCHIP	PIC18LF4321	QFP	44	PA44QF44D	MICROCHIP	PIC18LF4410	DIP	40	Not use adapter
MICROCHIP	PIC18LF4410	QFN	44	PA44QFN44D	MICROCHIP	PIC18LF4410	QFP	44	PA44QF44D
MICROCHIP	PIC18LF4420	DIP	40	Not use adapter	MICROCHIP	PIC18LF4420	QFN	44	PA44QFN44D
MICROCHIP	PIC18LF4420	QFP	44	PA44QF44D	MICROCHIP	PIC18LF4455	DIP	40	Not use adapter
MICROCHIP	PIC18LF4455	QFN	44	PA44QFN44D	MICROCHIP	PIC18LF4455	QFP	44	PA44QF44D
MICROCHIP	PIC18LF4480	QFN	44	PA44QFN44D	MICROCHIP	PIC18LF4480	DIP	40	Not use adapter
MICROCHIP	PIC18LF4480	QFP	44	PA44QF44D	MICROCHIP	PIC18LF4510	QFN	44	PA44QFN44D
MICROCHIP	PIC18LF4510	DIP	40	Not use adapter	MICROCHIP	PIC18LF4510	QFP	44	PA44QF44D
MICROCHIP	PIC18LF4515	DIP	40	Not use adapter	MICROCHIP	PIC18LF4515	QFN	44	PA44QFN44D
MICROCHIP	PIC18LF4515	QFP	44	PA44QF44D	MICROCHIP	PIC18LF4520	QFN	44	PA44QFN44D
MICROCHIP	PIC18LF4520	DIP	40	Not use adapter	MICROCHIP	PIC18LF4520	QFP	44	PA44QF44D
MICROCHIP	PIC18LF4525	QFN	44	PA44QFN44D	MICROCHIP	PIC18LF4525	DIP	40	Not use adapter
MICROCHIP	PIC18LF4525	QFP	44	PA44QF44D	MICROCHIP	PIC18LF4550	QFN	44	PA44QFN44D
MICROCHIP	PIC18LF4550	DIP	40	Not use adapter	MICROCHIP	PIC18LF4550	QFP	44	PA44QF44D
MICROCHIP	PIC18LF4580	QFN	44	PA44QFN44D	MICROCHIP	PIC18LF4580	DIP	40	Not use adapter
MICROCHIP	PIC18LF4580	QFP	44	PA44QF44D	MICROCHIP	PIC18LF4585	QFN	44	PA44QFN44D
MICROCHIP	PIC18LF4585	DIP	40	Not use adapter	MICROCHIP	PIC18LF4585	QFP	44	PA44QF44D
MICROCHIP	PIC18LF4610	QFN	44	PA44QFN44D	MICROCHIP	PIC18LF4610	DIP	40	Not use adapter
MICROCHIP	PIC18LF4610	QFP	44	PA44QF44D	MICROCHIP	PIC18LF4620	DIP	40	Not use adapter
MICROCHIP	PIC18LF4620	QFN	44	PA44QFN44D	MICROCHIP	PIC18LF4620	QFP	44	PA44QF44D
MICROCHIP	PIC18LF4680	DIP	40	Not use adapter	MICROCHIP	PIC18LF4680	QFN	44	PA44QFN44D
MICROCHIP	PIC18LF4680	QFP	44	PA44QF44D	MICROCHIP	PIC18LF6520	TQFP	64	PA64TQ40D
MICROCHIP	PIC18LF6522	TQFP	64	PA64TQ40D	MICROCHIP	PIC18LF6527	TQFP	64	PA64TQ40D
MICROCHIP	PIC18LF6620	TQFP	64	PA64TQ40D	MICROCHIP	PIC18LF6627	TQFP	64	PA64TQ40D
MICROCHIP	PIC18LF6720	TQFP	64	PA64TQ40D	MICROCHIP	PIC18LF6722	TQFP	64	PA64TQ40D
MICROCHIP	PIC18LF8520	TQFP	80	PA80TQ40D	MICROCHIP	PIC18LF8527	TQFP	80	PA80TQ40D
MICROCHIP	PIC18LF8620	TQFP	80	PA80TQ40D	MICROCHIP	PIC18LF8622	TQFP	80	PA80TQ40D
MICROCHIP	PIC18LF8627	TQFP	80	PA80TQ40D	MICROCHIP	PIC18LF8720	TQFP	80	PA80TQ40D
MICROCHIP	PIC18LF8722	TQFP	80	PA80TQ40D	MICRON	MT28C128532W30D-TB	BGA	88	PA88BGA48DA-YO-8X10
MICRON	MT28C128564W30D-TB	BGA	88	PA88BGA48DA-YO-8X10	MICRON	MT28C64432W30A-T	BGA	88	PA88BGA48DA-YO-8X10
MICRON	MT28F128J3	TSOP	56	PA56TS48D-B6-YAM	MICRON	MT28F320J3	TSOP	56	PA56TS48D-B6-YAM
MICRON	MT28F640J3	TSOP	56	PA56TS48D-B6-YAM	MICRON	MT28F800B3-B	TSOP	48	PA48TS48D
MICRON	MT28F800B3-T	TSOP	48	PA48TS48D	MITSUBISHI	M37531E4	DIP	32	PCA7435SP
MITSUBISHI	M37531E8	DIP	32	PCA7435SP	MITSUBISHI	M5L27128K	DIP	28	Not use adapter
MITSUBISHI	M5L27256K	DIP	28	Not use adapter	MITSUBISHI	M5L2732	DIP	24	Not use adapter
MITSUBISHI	M5L27512K	DIP	28	Not use adapter	MITSUBISHI	M5L2764K	DIP	28	Not use adapter
MITSUBISHI	M5M27128P	DIP	28	Not use adapter	MITSUBISHI	M5M27256P	DIP	28	Not use adapter
MITSUBISHI	M5M27512P	DIP	28	Not use adapter	MITSUBISHI	M5M2764P	DIP	28	Not use adapter
MITSUBISHI	M5M27C100K	DIP	32	Not use adapter	MITSUBISHI	M5M27C100P	DIP	32	Not use adapter
MITSUBISHI	M5M27C101K	DIP	32	Not use adapter	MITSUBISHI	M5M27C101P	DIP	32	Not use adapter
MITSUBISHI	M5M27C102K	DIP	40	Not use adapter	MITSUBISHI	M5M27C102P	DIP	40	Not use adapter
MITSUBISHI	M5M27C128K	DIP	28	Not use adapter	MITSUBISHI	M5M27C201K	DIP	32	Not use adapter
MITSUBISHI	M5M27C202K	PLCC	44	PA44-48U	MITSUBISHI	M5M27C202K	DIP	40	Not use adapter
MITSUBISHI	M5M27C256AK	DIP	28	Not use adapter	MITSUBISHI	M5M27C256K	DIP	28	Not use adapter
MITSUBISHI	M5M27C256P	DIP	28	Not use adapter	MITSUBISHI	M5M27C401K	DIP	32	Not use adapter
MITSUBISHI	M5M27C402K	DIP	40	Not use adapter	MITSUBISHI	M5M27C512AK	DIP	28	Not use adapter
MITSUBISHI	M5M27C512AP	DIP	28	Not use adapter	MITSUBISHI	M5M28C64AP	DIP	28	Not use adapter
MITSUBISHI	M5M28C64P	DIP	28	Not use adapter	MOSEL	V29C51001B	DIP	32	Not use adapter
MOSEL	V29C51001T	DIP	32	Not use adapter	MOSEL	V29C51002B	DIP	32	Not use adapter
MOSEL	V29C51002T	DIP	32	Not use adapter	MOSTEK	ET2716	DIP	24	Not use adapter
MOSTEK	ETC2716	DIP	24	Not use adapter	MOSTEK	ETC2732	DIP	24	Not use adapter
MOSTEK	MK2716	DIP	24	Not use adapter	MOSTEK	MK2764	DIP	28	Not use adapter
MOTOROLA	MC68HC11A1FN	PLCC	52	PA52-48A	MOTOROLA	MC68HC11A1P	DIP	48	Not use adapter
MOTOROLA	MC68HC11A8FN	PLCC	52	PA52-48A	MOTOROLA	MC68HC11A8P	DIP	48	Not use adapter
MOTOROLA	MC68HC11E1FN	PLCC	52	PA52-48A	MOTOROLA	MC68HC11E20FN	PLCC	52	PA52-48A
MOTOROLA	MC68HC11E9CFN2	PLCC	52	PA52-48A	MOTOROLA	MC68HC11E9CFN3	PLCC	52	PA52-48A
MOTOROLA	MC68HC11E9CFU2	QFP	64	PA64TQ40D-HCx11E	MOTOROLA	MC68HC11E9CFU3	QFP	64	PA64TQ40D-HCx11E
MOTOROLA	MC68HC11E9CMU2	QFP	64	PA64TQ40D-HCx11E	MOTOROLA	MC68HC11E9CVU2	QFP	64	PA64TQ40D-HCx11E
MOTOROLA	MC68HC11E9MFN2	PLCC	52	PA52-48A	MOTOROLA	MC68HC11E9VFN2	PLCC	52	PA52-48A
MOTOROLA	MC68HC11F1FN	PLCC	68	PA84-48C	MOTOROLA	MC68HC11K4CFN	PLCC	84	PA84-48C
MOTOROLA	MC68HC11K4CFN2	PLCC	84	PA84-48C	MOTOROLA	MC68HC11K4CFN3	PLCC	84	PA84-48C
MOTOROLA	MC68HC11K4CFN4	PLCC	84	PA84-48C	MOTOROLA	MC68HC11K4MFN2	PLCC	84	PA84-48C
MOTOROLA	MC68HC11K4MFN3	PLCC	84	PA84-48C	MOTOROLA	MC68HC11K4MFN4	PLCC	84	PA84-48C
MOTOROLA	MC68HC11K4VFN2	PLCC	84	PA84-48C	MOTOROLA	MC68HC11K4VFN3	PLCC	84	PA84-48C
MOTOROLA	MC68HC11K4VFN4	PLCC	84	PA84-48C	MOTOROLA	MC68HC11L6FN	PLCC	68	PA68-48D
MOTOROLA	MC68HC11P2FN	PLCC	84	PA84-48D	MOTOROLA	MC68HC705B16CFN	PLCC	52	ET-524801P600-YAM
MOTOROLA	MC68HC705C4AFN	PLCC	44	PA44-48U	MOTOROLA	MC68HC705C4AP	DIP	40	Not use adapter
MOTOROLA	MC68HC705C8AFB	QFP	44	PA44QF44D	MOTOROLA	MC68HC705C8AFN	PLCC	44	PA44-48U
MOTOROLA	MC68HC705C8AP	DIP	40	Not use adapter	MOTOROLA	MC68HC705C8FN	PLCC	44	PA44-48U
MOTOROLA	MC68HC705C8P	DIP	40	Not use adapter	MOTOROLA	MC68HC705C9AFB	QFP	44	PA44QF44D
MOTOROLA	MC68HC705C9AFN	PLCC	44	PA44-48U	MOTOROLA	MC68HC705C9AP	DIP	40	Not use adapter

MOTOROLA	MC68HC705C9FN	PLCC	44	PA44-48U	MOTOROLA	MC68HC705C9P	DIP	40	Not use adapter
MOTOROLA	MC68HC705D32AFN	PLCC	44	PA44-48U	MOTOROLA	MC68HC705D32AP	DIP	40	Not use adapter
MOTOROLA	MC68HC705D32FN	PLCC	44	PA44-48U	MOTOROLA	MC68HC705D32P	DIP	40	Not use adapter
MOTOROLA	MC68HC705D9FN	PLCC	44	PA44-48U	MOTOROLA	MC68HC705D9P	DIP	40	Not use adapter
MOTOROLA	MC68HC705J1A	DIP	20	Not use adapter	MOTOROLA	MC68HC705J1A	SOP	20	PA28SO08
MOTOROLA	MC68HC705KJ1	DIP	16	Not use adapter	MOTOROLA	MC68HC705KJ1	SOP	16	PA28SO08
MOTOROLA	MC68HC705P6ACDW	SOIC	28	PA28SO28D-08	MOTOROLA	MC68HC705P6ACP	DIP	28	Not use adapter
MOTOROLA	MC68HC705P6ADW	SOIC	28	PA28SO28D-08	MOTOROLA	MC68HC705P6AP	DIP	28	Not use adapter
MOTOROLA	MC68HC705P6DW	SOIC	28	PA28SO28D-08	MOTOROLA	MC68HC705P6P	DIP	28	Not use adapter
MOTOROLA	MC68HC705P9CDW	SOIC	28	PA28SO28D-08	MOTOROLA	MC68HC705P9CP	DIP	28	Not use adapter
MOTOROLA	MC68HC705P9DW	SOIC	28	PA28SO28D-08	MOTOROLA	MC68HC705P9P	DIP	28	Not use adapter
MOTOROLA	MC68HC711D3CFN	PLCC	44	PA44-48U	MOTOROLA	MC68HC711D3CP	DIP	40	Not use adapter
MOTOROLA	MC68HC711D3FN	PLCC	44	PA44-48U	MOTOROLA	MC68HC711D3FS	PLCC	44	PA44-48U
MOTOROLA	MC68HC711D3P	DIP	40	Not use adapter	MOTOROLA	MC68HC711D3S	DIP	40	Not use adapter
MOTOROLA	MC68HC711E20CFN2	PLCC	52	PA52-48A	MOTOROLA	MC68HC711E20CFN3	PLCC	52	PA52-48A
MOTOROLA	MC68HC711E20FN3	PLCC	52	PA52-48A	MOTOROLA	MC68HC711E20MFN2	PLCC	52	PA52-48A
MOTOROLA	MC68HC711E20VFN2	PLCC	52	PA52-48A	MOTOROLA	MC68HC711E9CFN2	PLCC	52	PA52-48A
MOTOROLA	MC68HC711E9CFN3	PLCC	52	PA52-48A	MOTOROLA	MC68HC711E9CFU2	QFP	64	PA64TQ40D-HCx11E
MOTOROLA	MC68HC711E9CFU3	QFP	64	PA64TQ40D-HCx11E	MOTOROLA	MC68HC711E9CMU2	QFP	64	PA64TQ40D-HCx11E
MOTOROLA	MC68HC711E9CVU2	QFP	64	PA64TQ40D-HCx11E	MOTOROLA	MC68HC711E9MFN2	PLCC	52	PA52-48A
MOTOROLA	MC68HC711E9VFN2	PLCC	52	PA52-48A	MOTOROLA	MC68HC711K4CFN	PLCC	84	PA84-48C
MOTOROLA	MC68HC711K4CFN2	PLCC	84	PA84-48C	MOTOROLA	MC68HC711K4CFN3	PLCC	84	PA84-48C
MOTOROLA	MC68HC711K4CFN4	PLCC	84	PA84-48C	MOTOROLA	MC68HC711K4MFN2	PLCC	84	PA84-48C
MOTOROLA	MC68HC711K4MFN3	PLCC	84	PA84-48C	MOTOROLA	MC68HC711K4MFN4	PLCC	84	PA84-48C
MOTOROLA	MC68HC711K4VFN2	PLCC	84	PA84-48C	MOTOROLA	MC68HC711K4VFN3	PLCC	84	PA84-48C
MOTOROLA	MC68HC711K4VFN4	PLCC	84	PA84-48C	MOTOROLA	MC68HC711KS2VFN	PLCC	68	PA68-48H
MOTOROLA	MC68HC711L6FN	PLCC	68	PA68-48D	MOTOROLA	MC68HC711P2FN	PLCC	84	PA84-48D
MOTOROLA	MC68HC811E2FN	PLCC	52	PA52-48A	MOTOROLA	MC68HC811E2P	DIP	48	Not use adapter
MOTOROLA	MC68HC908GP32CB	SDIP	42	PA-MACH4	MOTOROLA	MC68HC908GP32CFB	TQFP	44	PA44QF44D
MOTOROLA	MC68HC908GP32CP	DIP	40	Not use adapter	MOTOROLA	MC68HC908GP32MB	SDIP	42	PA-MACH4
MOTOROLA	MC68HC908GP32MFB	TQFP	44	PA44QF44D	MOTOROLA	MC68HC908GP32MP	DIP	40	Not use adapter
MOTOROLA	MC68HC908GP32VB	SDIP	42	PA-MACH4	MOTOROLA	MC68HC908GP32VFB	TQFP	44	PA44QF44D
MOTOROLA	MC68HC908GP32VP	DIP	40	Not use adapter	MOTOROLA	MC68HC908GT16CB	SDIP	42	PA-MACH4
MOTOROLA	MC68HC908GT16CFB	TQFP	44	PA44QF44D	MOTOROLA	MC68HC908GT8CB	SDIP	42	PA-MACH4
MOTOROLA	MC68HC908GT8CFB	TQFP	44	PA44QF44D	MOTOROLA	MC68HC908JK1CDW	SOP	20	PA28SO28D-08
MOTOROLA	MC68HC908JK1CP	DIP	20	Not use adapter	MOTOROLA	MC68HC908JK1MDW	SOP	20	PA28SO28D-08
MOTOROLA	MC68HC908JK1MP	DIP	20	Not use adapter	MOTOROLA	MC68HC908JK3CDW	SOP	20	PA28SO28D-08
MOTOROLA	MC68HC908JK3CP	DIP	20	Not use adapter	MOTOROLA	MC68HC908JK3MDW	SOP	20	PA28SO28D-08
MOTOROLA	MC68HC908JK3MP	DIP	20	Not use adapter	MOTOROLA	MC68HC908JL3CDW	SOP	28	PA28SO28D-08
MOTOROLA	MC68HC908JL3CP	DIP	28	Not use adapter	MOTOROLA	MC68HC908JL3MDW	SOP	28	PA28SO28D-08
MOTOROLA	MC68HC908JL3MP	DIP	28	Not use adapter	MOTOROLA	MC68HC908QT1CDW	SOIC	8	PA16SO16D
MOTOROLA	MC68HC908QT1CFQ	DFN	8	PA8SON8D	MOTOROLA	MC68HC908QT1CP	DIP	8	Not use adapter
MOTOROLA	MC68HC908QT2CDW	SOIC	8	PA16SO16D	MOTOROLA	MC68HC908QT2CFQ	DFN	8	PA8SON8D
MOTOROLA	MC68HC908QT2CP	DIP	8	Not use adapter	MOTOROLA	MC68HC908QT4CDW	SOIC	8	PA16SO16D
MOTOROLA	MC68HC908QT4CFQ	DFN	8	PA8SON8D	MOTOROLA	MC68HC908QT4CP	DIP	8	Not use adapter
MOTOROLA	MC68HC908QY1CDT	TSSOP	16	PA24TSS24D(M)	MOTOROLA	MC68HC908QY1CDW	SOIC	16	PA28SO28D-08
MOTOROLA	MC68HC908QY1CP	DIP	16	Not use adapter	MOTOROLA	MC68HC908QY2CDT	TSSOP	16	PA24TSS24D(M)
MOTOROLA	MC68HC908QY2CDW	SOIC	16	PA28SO28D-08	MOTOROLA	MC68HC908QY2CP	DIP	16	Not use adapter
MOTOROLA	MC68HC908QY4CDT	TSSOP	16	PA24TSS24D(M)	MOTOROLA	MC68HC908QY4CDW	SOIC	16	PA28SO28D-08
MOTOROLA	MC68HC908QY4CP	DIP	16	Not use adapter	MOTOROLA	MC68S711E9CFN2	PLCC	52	PA52-48A
MOTOROLA	MC9S08GT16CFB	TQFP	44	PA44QF44D	MOTOROLA	MC9S08GT32CFB	TQFP	44	PA44QF44D
MOTOROLA	MCM2716	DIP	24	Not use adapter	NATIONAL	GAL16V8	DIP	20	Not use adapter
NATIONAL	GAL16V8	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 10H8	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 10H8	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 10L8	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 10L8	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 10P8	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 10P8	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 12H6	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 12H6	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 12L6	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 12L6	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 12P6	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 12P6	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 14H4	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 14H4	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 14L4	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 14L4	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 14P4	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 14P4	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16H2	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16H2	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16H8	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16H8	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16L2	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16L2	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16L8	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16L8	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16P2	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16P2	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16P8	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16P8	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16R4	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16R4	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16R6	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16R6	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16R8	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16R8	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16RP4	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16RP4	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16RP6	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16RP6	PLCC	20	PA20LC20D	NATIONAL	GAL16V8 as 16RP8	DIP	20	Not use adapter
NATIONAL	GAL16V8 as 16RP8	PLCC	20	PA20LC20D	NATIONAL	GAL16V8A	DIP	20	Not use adapter

NATIONAL	NMC2732	DIP	24	Not use adapter	NATIONAL	NMC27C010	DIP	32	Not use adapter
NATIONAL	NMC27C020	DIP	32	Not use adapter	NATIONAL	NMC27C1024	DIP	40	Not use adapter
NATIONAL	NMC27C1024	PLCC	44	PA44-48U	NATIONAL	NMC27C128B	DIP	28	Not use adapter
NATIONAL	NMC27C128BN	DIP	28	Not use adapter	NATIONAL	NMC27C128BQ	DIP	28	Not use adapter
NATIONAL	NMC27C128C	DIP	28	Not use adapter	NATIONAL	NMC27C128CQ	DIP	28	Not use adapter
NATIONAL	NMC27C128Q	DIP	28	Not use adapter	NATIONAL	NMC27C16	DIP	24	Not use adapter
NATIONAL	NMC27C16BQ	DIP	24	Not use adapter	NATIONAL	NMC27C16H	DIP	24	Not use adapter
NATIONAL	NMC27C16HQ	DIP	24	Not use adapter	NATIONAL	NMC27C16Q	DIP	24	Not use adapter
NATIONAL	NMC27C2048	DIP	40	Not use adapter	NATIONAL	NMC27C2048	PLCC	44	PA44-48U
NATIONAL	NMC27C256	DIP	28	Not use adapter	NATIONAL	NMC27C256B	DIP	28	Not use adapter
NATIONAL	NMC27C256BN	DIP	28	Not use adapter	NATIONAL	NMC27C256C	DIP	28	Not use adapter
NATIONAL	NMC27C256Q	DIP	28	Not use adapter	NATIONAL	NMC27C32	DIP	24	Not use adapter
NATIONAL	NMC27C32B	DIP	24	Not use adapter	NATIONAL	NMC27C32E	DIP	24	Not use adapter
NATIONAL	NMC27C32EH	DIP	24	Not use adapter	NATIONAL	NMC27C32H	DIP	24	Not use adapter
NATIONAL	NMC27C32Q	DIP	24	Not use adapter	NATIONAL	NMC27C512	DIP	28	Not use adapter
NATIONAL	NMC27C512A	DIP	28	Not use adapter	NATIONAL	NMC27C512AN	DIP	28	Not use adapter
NATIONAL	NMC27C64	DIP	28	Not use adapter	NATIONAL	NMC27C64B	DIP	28	Not use adapter
NATIONAL	NMC27C64BN	DIP	28	Not use adapter	NATIONAL	NMC27C64N	DIP	28	Not use adapter
NATIONAL	NMC27CP128	DIP	28	Not use adapter	NATIONAL	NMC9306	DIP	8	Not use adapter
NATIONAL	NMC9307	DIP	8	Not use adapter	NATIONAL	NMC9313B	DIP	8	Not use adapter
NATIONAL	NMC9314B	DIP	8	Not use adapter	NATIONAL	NMC9346	DIP	8	Not use adapter
NATIONAL	NMC93C06	DIP	8	Not use adapter	NATIONAL	NMC93C06	TSSOP	8	PA8TSS-OT
NATIONAL	NMC93C06	SOIC	8	PA8SO8D	NATIONAL	NMC93C13	DIP	8	Not use adapter
NATIONAL	NMC93C13	SOIC	8	PA8SO8D	NATIONAL	NMC93C14	DIP	8	Not use adapter
NATIONAL	NMC93C14	SOIC	8	PA8SO8D	NATIONAL	NMC93C46	TSSOP	8	PA8TSS-OT
NATIONAL	NMC93C46	DIP	8	Not use adapter	NATIONAL	NMC93C46	SOIC	8	PA8SO8D
NATIONAL	NMC93C56	TSSOP	8	PA8TSS-OT	NATIONAL	NMC93C56	DIP	8	Not use adapter
NATIONAL	NMC93C56	SOIC	8	PA8SO8D	NATIONAL	NMC93C66	TSSOP	8	PA8TSS-OT
NATIONAL	NMC93C66	DIP	8	Not use adapter	NATIONAL	NMC93C66	SOIC	8	PA8SO8D
NATIONAL	NMC93C86	DIP	8	Not use adapter	NATIONAL	NMC93C86	TSSOP	8	PA8TSS-OT
NATIONAL	NMC93C86	SOIC	8	PA8SO8D	NATIONAL	NMC93CS06	DIP	8	Not use adapter
NATIONAL	NMC93CS06	TSSOP	8	PA8TSS-OT	NATIONAL	NMC93CS06	SOIC	8	PA8SO8D
NATIONAL	NMC93CS46	TSSOP	8	PA8TSS-OT	NATIONAL	NMC93CS46	DIP	8	Not use adapter
NATIONAL	NMC93CS46	SOIC	8	PA8SO8D	NATIONAL	NMC93CS56	TSSOP	8	PA8TSS-OT
NATIONAL	NMC93CS56	DIP	8	Not use adapter	NATIONAL	NMC93CS56	SOIC	8	PA8SO8D
NATIONAL	NMC93CS66	TSSOP	8	PA8TSS-OT	NATIONAL	NMC93CS66	DIP	8	Not use adapter
NATIONAL	NMC93CS66	SOIC	8	PA8SO8D	NEC	8749H	DIP	40	Not use adapter
NEC	uPD27128	DIP	28	Not use adapter	NEC	uPD2716	DIP	24	Not use adapter
NEC	uPD27256	DIP	28	Not use adapter	NEC	uPD2732	DIP	24	Not use adapter
NEC	uPD2732A	DIP	24	Not use adapter	NEC	uPD2764	DIP	28	Not use adapter
NEC	uPD27C1000	DIP	32	Not use adapter	NEC	uPD27C1000A	DIP	32	Not use adapter
NEC	uPD27C1001A	DIP	32	Not use adapter	NEC	uPD27C1001D	DIP	32	Not use adapter
NEC	uPD27C1024	DIP	40	Not use adapter	NEC	uPD27C1024	PLCC	44	PA44-48U
NEC	uPD27C1024A	PLCC	44	PA44-48U	NEC	uPD27C1024A	DIP	40	Not use adapter
NEC	uPD27C2001	DIP	32	Not use adapter	NEC	uPD27C256	DIP	28	Not use adapter
NEC	uPD27C256A	DIP	28	Not use adapter	NEC	uPD27C4001	DIP	32	Not use adapter
NEC	uPD27C4096	PLCC	44	PA44-48U	NEC	uPD27C4096	DIP	40	Not use adapter
NEC	uPD27C512	DIP	28	Not use adapter	NEC	uPD27C64	DIP	28	Not use adapter
NEC	uPD27C8000	DIP	42	Not use adapter	NEC	uPD27C8001	DIP	32	Not use adapter
NEC	uPD28C64	DIP	28	Not use adapter	NEC	uPD28C64C	DIP	28	Not use adapter
NEXFLASH	NX25P10VNI	SOIC	8	PA16SO16D-EO-150	NEXFLASH	NX25P16VFIG	SOIC	16	PA68-40B
NEXFLASH	NX25P16VSI	SOIC	8	PA20SO2006-200/PA20SO20D	NEXFLASH	NX25P20VNI	SOIC	8	PA16SO16D-EO-150
NEXFLASH	NX25P32VFI	SOIC	16	PA68-40B	NEXFLASH	NX25P40VNI	SOIC	8	PA16SO16D-EO-150
NEXFLASH	NX25P80VSI	SOIC	8	PA20SO2006-200/PA20SO20D	NEXFLASH	NX29F010	DIP	32	Not use adapter
NOVATEK	NT68F631L	PLCC	44	HA44PL48DZ4	NOVATEK	NT68F632L	PLCC	44	HA44PL48DZ4
NOVATEK	NT68F63LA	PLCC	44	HA44PL48DZ4	NOVATEK	NT68F63LG	PLCC	44	HA44PL48DZ4
OKI	MR27V1602D	DIP	42	Not use adapter	OKI	MR27V1602D	SOP	44	PA44SO44D
OKI	MR27V1652D	DIP	42	Not use adapter	OKI	MR27V1652D	SOP	44	PA44SO44D
OKI	MR27V3202E	TSOP	44	PA44TS44D	OKI	MR27V3202F	TSOP	48	PA48TS48D
OKI	MR27V402D	DIP	40	Not use adapter	OKI	MR27V402D	TSOP	44	PA44TS44D
OKI	MR27V402E	DIP	40	Not use adapter	OKI	MR27V402E	TSOP	44	PA44TS44D
OKI	MR27V6402G	SOP	44	PA44SO44D	OKI	MR27V6466F	TSOP	86	PA6466R
OKI	MSM271000	DIP	32	Not use adapter	OKI	MSM271000AS	DIP	32	Not use adapter
OKI	MSM271000ZB	DIP	32	Not use adapter	OKI	MSM271024	DIP	40	Not use adapter
OKI	MSM271024	PLCC	44	PA44-48U	OKI	MSM271024AS	PLCC	44	PA44-48U
OKI	MSM271024AS	DIP	40	Not use adapter	OKI	MSM271024ZB	DIP	40	Not use adapter
OKI	MSM271024ZB	PLCC	44	PA44-48U	OKI	MSM27128A	DIP	28	Not use adapter
OKI	MSM27128AS	DIP	28	Not use adapter	OKI	MSM27128AZB-RS	DIP	28	Not use adapter
OKI	MSM2716	DIP	24	Not use adapter	OKI	MSM27256	DIP	28	Not use adapter
OKI	MSM27256AS	DIP	28	Not use adapter	OKI	MSM27256ZB-RS	DIP	28	Not use adapter
OKI	MSM2732	DIP	24	Not use adapter	OKI	MSM2732A	DIP	24	Not use adapter
OKI	MSM27512	DIP	28	Not use adapter	OKI	MSM27512AS	DIP	28	Not use adapter
OKI	MSM27512ZB-RS	DIP	28	Not use adapter	OKI	MSM2764	DIP	28	Not use adapter
OKI	MSM2764A	DIP	28	Not use adapter	OKI	MSM2764AS	DIP	28	Not use adapter

OKI	MSM2764AZB	DIP	28	Not use adapter	OKI	MSM2764RS	DIP	28	Not use adapter
OKI	MSM27C101ZB	DIP	32	Not use adapter	OKI	MSM27C1024	DIP	40	Not use adapter
OKI	MSM27C1024	PLCC	44	PA44-48U	OKI	MSM27C1024AS	PLCC	44	PA44-48U
OKI	MSM27C1024AS	DIP	40	Not use adapter	OKI	MSM27C128AS	DIP	28	Not use adapter
OKI	MSM27C1652CZ	SOP	44	PA44SO44D	OKI	MSM27C1652CZ	DIP	42	Not use adapter
OKI	MSM27C2000	DIP	32	Not use adapter	OKI	MSM27C2048	DIP	40	Not use adapter
OKI	MSM27C2048	PLCC	44	PA44-48U	OKI	MSM27C256	DIP	28	Not use adapter
OKI	MSM27C256H	DIP	28	Not use adapter	OKI	MSM27C256H2B	DIP	28	Not use adapter
OKI	MSM27C256ZB	DIP	28	Not use adapter	OKI	MSM27C3252CZ	SOP	44	PA44SO44D
OKI	MSM27C402ZB	SOP	44	PA44SO44D	OKI	MSM27C452CZ	DIP	40	Not use adapter
OKI	MSM27C64AS	DIP	28	Not use adapter	OKI	MSM2816ARS	DIP	24	Not use adapter
PHILIPS	27C010	DIP	32	Not use adapter	PHILIPS	27C210	PLCC	44	PA44-48U
PHILIPS	27C210	DIP	40	Not use adapter	PHILIPS	27C240	PLCC	44	PA44-48U
PHILIPS	27C240	DIP	40	Not use adapter	PHILIPS	27C256	DIP	28	Not use adapter
PHILIPS	27C512	DIP	28	Not use adapter	PHILIPS	27C64A	DIP	28	Not use adapter
PHILIPS	P85LPC764	PLCC	44	PA44-48U	PHILIPS	P87C51	DIP	40	Not use adapter
PHILIPS	P87C51	PLCC	44	PA44-48U	PHILIPS	P87C51FA	PLCC	44	PA44-48U
PHILIPS	P87C51FA	DIP	40	Not use adapter	PHILIPS	P87C51FB	PLCC	44	PA44-48U
PHILIPS	P87C51FB	DIP	40	Not use adapter	PHILIPS	P87C51FC	PLCC	44	PA44-48U
PHILIPS	P87C51FC	DIP	40	Not use adapter	PHILIPS	P87C51MA2	PLCC	44	PA44-48U
PHILIPS	P87C51MB2	PLCC	44	PA44-48U	PHILIPS	P87C51MC2	PLCC	44	PA44-48U
PHILIPS	P87C51RA+	DIP	40	Not use adapter	PHILIPS	P87C51RA+	PLCC	44	PA44-48U
PHILIPS	P87C51RA2BA	PLCC	44	PA44-48U	PHILIPS	P87C51RA2BBD	QFP	44	PA44QF44D
PHILIPS	P87C51RB+	DIP	40	Not use adapter	PHILIPS	P87C51RB+	PLCC	44	PA44-48U
PHILIPS	P87C51RB2BA	PLCC	44	PA44-48U	PHILIPS	P87C51RB2BBD	QFP	44	PA44QF44D
PHILIPS	P87C51RB2BN	DIP	40	Not use adapter	PHILIPS	P87C51RC+	DIP	40	Not use adapter
PHILIPS	P87C51RC+	PLCC	44	PA44-48U	PHILIPS	P87C51RC2BA	PLCC	44	PA44-48U
PHILIPS	P87C51RC2BBD	QFP	44	PA44QF44D	PHILIPS	P87C51RC2BN	DIP	40	Not use adapter
PHILIPS	P87C51RD+	DIP	40	Not use adapter	PHILIPS	P87C51RD+	PLCC	44	PA44-48U
PHILIPS	P87C51RD2BA	PLCC	44	PA44-48U	PHILIPS	P87C51RD2BBD	QFP	44	PA44QF44D
PHILIPS	P87C51RD2BN	DIP	40	Not use adapter	PHILIPS	P87C51X2	PLCC	44	PA44-48U
PHILIPS	P87C51X2	DIP	40	Not use adapter	PHILIPS	P87C52	PLCC	44	PA44-48U
PHILIPS	P87C52	DIP	40	Not use adapter	PHILIPS	P87C52	QFP	44	PA44QF44D
PHILIPS	P87C52X2	DIP	40	Not use adapter	PHILIPS	P87C52X2	PLCC	44	PA44-48U
PHILIPS	P87C54	PLCC	44	PA44-48U	PHILIPS	P87C54	DIP	40	Not use adapter
PHILIPS	P87C54X2	DIP	40	Not use adapter	PHILIPS	P87C54X2	PLCC	44	PA44-48U
PHILIPS	P87C58	PLCC	44	PA44-48U	PHILIPS	P87C58	DIP	40	Not use adapter
PHILIPS	P87C58X2	DIP	40	Not use adapter	PHILIPS	P87C58X2	PLCC	44	PA44-48U
PHILIPS	P87C591	PLCC	44	PA44-48U	PHILIPS	P87C654X2BBD	QFP	44	PA44QF44D
PHILIPS	P87C654X2FA	PLCC	44	PA44-48U	PHILIPS	P87C660X2BBD	QFP	44	PA44QF44D
PHILIPS	P87C660X2FA	PLCC	44	PA44-48U	PHILIPS	P87C661X2BBD	QFP	44	PA44QF44D
PHILIPS	P87C661X2FA	PLCC	44	PA44-48U	PHILIPS	P87LC52X2BBD	QFP	44	PA44QF44D
PHILIPS	P87LC52X2FA	PLCC	44	PA44-48U	PHILIPS	P87LC54X2BBD	QFP	44	PA44QF44D
PHILIPS	P87LC54X2FA	PLCC	44	PA44-48U	PHILIPS	P87LPC761	DIP	16	Not use adapter
PHILIPS	P87LPC762	DIP	20	Not use adapter	PHILIPS	P87LPC762	DIP	8	Not use adapter
PHILIPS	P87LPC762	DIP	16	Not use adapter	PHILIPS	P87LPC762	SOIC	20	PA28SO28D-08
PHILIPS	P87LPC764	DIP	16	Not use adapter	PHILIPS	P87LPC764	DIP	20	Not use adapter
PHILIPS	P87LPC764	DIP	8	Not use adapter	PHILIPS	P87LPC764	SOIC	20	PA28SO28D-08
PHILIPS	P87LPC767	DIP	20	Not use adapter	PHILIPS	P87LPC767	SOIC	20	PA28SO28D-08
PHILIPS	P87LPC768	DIP	20	Not use adapter	PHILIPS	P87LPC768	SOIC	20	PA28SO28D-08
PHILIPS	P87LPC769	DIP	20	Not use adapter	PHILIPS	P87LPC769	SOIC	20	PA28SO28D-08
PHILIPS	P89C51B	DIP	40	Not use adapter	PHILIPS	P89C51B	PLCC	44	PA44-48U
PHILIPS	P89C51RA+	DIP	40	Not use adapter	PHILIPS	P89C51RA+	PLCC	44	PA44-48U
PHILIPS	P89C51RA2BA	PLCC	44	PA44-48U	PHILIPS	P89C51RA2BB	QFP	44	PA44QF44D
PHILIPS	P89C51RA2BN	DIP	40	Not use adapter	PHILIPS	P89C51RB+	PLCC	44	PA44-48U
PHILIPS	P89C51RB+	DIP	40	Not use adapter	PHILIPS	P89C51RB2BA	PLCC	44	PA44-48U
PHILIPS	P89C51RB2BB	QFP	44	PA44QF44D	PHILIPS	P89C51RB2BN	DIP	40	Not use adapter
PHILIPS	P89C51RB2H	PLCC	44	PA44-48U	PHILIPS	P89C51RB2H	DIP	40	Not use adapter
PHILIPS	P89C51RC+	DIP	40	Not use adapter	PHILIPS	P89C51RC+	PLCC	44	PA44-48U
PHILIPS	P89C51RC2BA	PLCC	44	PA44-48U	PHILIPS	P89C51RC2BB	QFP	44	PA44QF44D
PHILIPS	P89C51RC2BN	DIP	40	Not use adapter	PHILIPS	P89C51RC2FA	PLCC	44	PA44-48U
PHILIPS	P89C51RC2FB	QFP	44	PA44QF44D	PHILIPS	P89C51RC2H	PLCC	44	PA44-48U
PHILIPS	P89C51RC2H	DIP	40	Not use adapter	PHILIPS	P89C51RD+	DIP	40	Not use adapter
PHILIPS	P89C51RD+	PLCC	44	PA44-48U	PHILIPS	P89C51RD2BA	PLCC	44	PA44-48U
PHILIPS	P89C51RD2BB	QFP	44	PA44QF44D	PHILIPS	P89C51RD2BN	DIP	40	Not use adapter
PHILIPS	P89C51RD2FA	PLCC	44	PA44-48U	PHILIPS	P89C51RD2H	DIP	40	Not use adapter
PHILIPS	P89C51RD2H	PLCC	44	PA44-48U	PHILIPS	P89C51U	DIP	40	Not use adapter
PHILIPS	P89C51U	PLCC	44	PA44-48U	PHILIPS	P89C51X2BA	PLCC	44	PA44-48U
PHILIPS	P89C51X2BBD	QFP	44	PA44QF44D	PHILIPS	P89C51X2BN	DIP	40	Not use adapter
PHILIPS	P89C51X2FA	PLCC	44	PA44-48U	PHILIPS	P89C52B	PLCC	44	PA44-48U
PHILIPS	P89C52B	DIP	40	Not use adapter	PHILIPS	P89C52U	DIP	40	Not use adapter
PHILIPS	P89C52U	PLCC	44	PA44-48U	PHILIPS	P89C52X2BA	PLCC	44	PA44-48U
PHILIPS	P89C52X2BBD	QFP	44	PA44QF44D	PHILIPS	P89C52X2BN	DIP	40	Not use adapter
PHILIPS	P89C52X2FA	PLCC	44	PA44-48U	PHILIPS	P89C52X2FBD	QFP	44	PA44QF44D

PHILIPS	P89C52X2FN	DIP	40	Not use adapter	PHILIPS	P89C54B	PLCC	44	PA44-48U
PHILIPS	P89C54B	DIP	40	Not use adapter	PHILIPS	P89C54U	PLCC	44	PA44-48U
PHILIPS	P89C54U	DIP	40	Not use adapter	PHILIPS	P89C54X2BA	PLCC	44	PA44-48U
PHILIPS	P89C54X2BBD	QFP	44	PA44QF44D	PHILIPS	P89C54X2BN	DIP	40	Not use adapter
PHILIPS	P89C54X2FA	PLCC	44	PA44-48U	PHILIPS	P89C58B	PLCC	44	PA44-48U
PHILIPS	P89C58B	DIP	40	Not use adapter	PHILIPS	P89C58U	DIP	40	Not use adapter
PHILIPS	P89C58U	PLCC	44	PA44-48U	PHILIPS	P89C58X2BA	PLCC	44	PA44-48U
PHILIPS	P89C58X2BBD	QFP	44	PA44QF44D	PHILIPS	P89C58X2BN	DIP	40	Not use adapter
PHILIPS	P89C58X2FA	PLCC	44	PA44-48U	PHILIPS	P89C60X2BA	PLCC	44	PA44-48U
PHILIPS	P89C61X2BA	QFP	44	PA44QF44D	PHILIPS	P89C660	PLCC	44	PA44-48U
PHILIPS	P89C660	DIP	40	Not use adapter	PHILIPS	P89C662	DIP	40	Not use adapter
PHILIPS	P89C662	PLCC	44	PA44-48U	PHILIPS	P89C664	DIP	40	Not use adapter
PHILIPS	P89C664	PLCC	44	PA44-48U	PHILIPS	P89C668	DIP	40	Not use adapter
PHILIPS	P89C668	PLCC	44	PA44-48U	PHILIPS	P89LPC901FD(ICP)	SOP	8	PA16SO16D
PHILIPS	P89LPC901FN(ICP)	DIP	8	Not use adapter	PHILIPS	P89LPC902FD(ICP)	SOP	8	PA16SO16D
PHILIPS	P89LPC902FN(ICP)	DIP	8	Not use adapter	PHILIPS	P89LPC903FD(ICP)	DIP	8	Not use adapter
PHILIPS	P89LPC904FD(ICP)	SOP	8	PA16SO16D	PHILIPS	P89LPC904FN(ICP)	DIP	8	Not use adapter
PHILIPS	P89LPC906FD(ICP)	SOP	8	PA16SO16D	PHILIPS	P89LPC907FD(ICP)	SOP	8	PA16SO16D
PHILIPS	P89LPC908FD(ICP)	SOP	8	PA16SO16D	PHILIPS	P89LPC9102FTK(ICP)	CASON	10	PA10SON10D
PHILIPS	P89LPC9103FTK(ICP)	CASON	10	PA10SON10D	PHILIPS	P89LPC9107FDH(ICP)	TSSOP	14	PA28TSS28D
PHILIPS	P89LPC9107FN(ICP)	DIP	14	Not use adapter	PHILIPS	P89LPC912FD(ICP)	TSSOP	14	PA28TSS28D
PHILIPS	P89LPC913FD(ICP)	TSSOP	14	PA28TSS28D	PHILIPS	P89LPC914FD(ICP)	TSSOP	14	PA28TSS28D
PHILIPS	P89LPC915FD(ICP)	TSSOP	14	PA28TSS28D	PHILIPS	P89LPC916FD(ICP)	TSSOP	16	PA28TSS28D
PHILIPS	P89LPC917FD(ICP)	TSSOP	16	PA28TSS28D	PHILIPS	P89LPC920FD	TSSOP	20	PA28TSS28D
PHILIPS	P89LPC920FD(ICP)	TSSOP	20	PA28TSS28D	PHILIPS	P89LPC921FD	TSSOP	20	PA28TSS28D
PHILIPS	P89LPC921FD(ICP)	TSSOP	20	PA28TSS28D	PHILIPS	P89LPC9221FD(ICP)	TSSOP	20	PA28TSS28D
PHILIPS	P89LPC9221FN(ICP)	DIP	20	Not use adapter	PHILIPS	P89LPC922FD	TSSOP	20	PA28TSS28D
PHILIPS	P89LPC922FD(ICP)	TSSOP	20	PA28TSS28D	PHILIPS	P89LPC922FN	DIP	20	Not use adapter
PHILIPS	P89LPC922FN(ICP)	DIP	20	Not use adapter	PHILIPS	P89LPC924FD	TSSOP	20	PA28TSS28D
PHILIPS	P89LPC924FD(ICP)	TSSOP	20	PA28TSS28D	PHILIPS	P89LPC925FD	TSSOP	20	PA28TSS28D
PHILIPS	P89LPC925FD(ICP)	TSSOP	20	PA28TSS28D	PHILIPS	P89LPC930FD	TSSOP	28	PA28TSS28D
PHILIPS	P89LPC930FD(ICP)	TSSOP	28	PA28TSS28D	PHILIPS	P89LPC931FD	TSSOP	28	PA28TSS28D
PHILIPS	P89LPC931FD(ICP)	TSSOP	28	PA28TSS28D	PHILIPS	P89LPC932A1FA	PLCC	28	PA28PL28D
PHILIPS	P89LPC932A1FDH	TSSOP	28	PA28TSS28D	PHILIPS	P89LPC932A1FHN	QFN	28	PA28QFN28D
PHILIPS	P89LPC932BA	PLCC	28	PA28PL28D	PHILIPS	P89LPC932BDB	TSSOP	28	PA28TSS28D
PHILIPS	P89LPC932FDH	TSSOP	28	PA28TSS28D	PHILIPS	P89LPC932FHN	QFN	28	PA28QFN28D
PHILIPS	P89LPC933FDH	TSSOP	28	PA28TSS28D	PHILIPS	P89LPC933FDH(ICP)	TSSOP	28	PA28TSS28D
PHILIPS	P89LPC934FDH	TSSOP	28	PA28TSS28D	PHILIPS	P89LPC934FDH(ICP)	TSSOP	28	PA28TSS28D
PHILIPS	P89LPC935FA	PLCC	28	PA28PL28D	PHILIPS	P89LPC935FA(ICP)	PLCC	28	PA28PL28D
PHILIPS	P89LPC935FDH	TSSOP	28	PA28TSS28D	PHILIPS	P89LPC935FDH(ICP)	TSSOP	28	PA28TSS28D
PHILIPS	P89LPC935FHN	QFN	28	PA28QFN28D	PHILIPS	P89LPC935FHN(ICP)	QFN	28	PA28QFN28D
PHILIPS	P89LPC936FDH	TSSOP	28	PA28TSS28D	PHILIPS	P89LPC936FDH(ICP)	TSSOP	28	PA28TSS28D
PHILIPS	P89LPC938FA	PLCC	28	PA28PL28D	PHILIPS	P89LPC938FA(ICP)	PLCC	28	PA28PL28D
PHILIPS	P89LPC938FDH	TSSOP	28	PA28TSS28D	PHILIPS	P89LPC938FDH(ICP)	TSSOP	28	PA28TSS28D
PHILIPS	P89LPC938FHN	QFN	28	PA28QFN28D	PHILIPS	P89LPC938FHN(ICP)	QFN	28	PA28QFN28D
PHILIPS	P89LV51RB2BA	PLCC	44	PA44-48U	PHILIPS	P89LV51RB2BBC	TQFP	44	PA44QF44D
PHILIPS	P89LV51RC2BN	DIP	40	Not use adapter	PHILIPS	P89LV51RC2FA	PLCC	44	PA44-48U
PHILIPS	P89LV51RC2FBC	TQFP	44	PA44QF44D	PHILIPS	P89LV51RD2BA	PLCC	44	PA44-48U
PHILIPS	P89LV51RD2BBC	TQFP	44	PA44QF44D	PHILIPS	P89LV51RD2BN	DIP	40	Not use adapter
PHILIPS	P89LV51RD2FA	PLCC	44	PA44-48U	PHILIPS	P89V51RB2BA	PLCC	44	PA44-48U
PHILIPS	P89V51RB2BBC	TQFP	44	PA44QF44D	PHILIPS	P89V51RC2BN	DIP	40	Not use adapter
PHILIPS	P89V51RC2FA	PLCC	44	PA44-48U	PHILIPS	P89V51RC2FBC	TQFP	44	PA44QF44D
PHILIPS	P89V51RD2BN	DIP	40	Not use adapter	PHILIPS	P89V51RD2FA	PLCC	44	PA44-48U
PHILIPS	P89V51RD2FBC	TQFP	44	PA44QF44D	PMC	PM25LV010	SOIC	8	PA16SO16D
PMC	PM25LV512	SOIC	8	PA16SO16D	PMC	Pm29F002B	DIP	32	Not use adapter
PMC	Pm29F002T	DIP	32	Not use adapter	PMC	Pm29F004B	DIP	32	Not use adapter
PMC	Pm29F004T	DIP	32	Not use adapter	PMC	Pm29LV002B	DIP	32	Not use adapter
PMC	Pm29LV002T	DIP	32	Not use adapter	PMC	Pm29LV104RB	DIP	32	PA32PL32D
PMC	Pm29LV104RT	DIP	32	PA32PL32D	PMC	Pm39F010-xxJC	PLCC	32	PA32PL32D
PMC	Pm39F020-xxJC	PLCC	32	PA32PL32D	PMC	Pm39F040-xxJC	PLCC	32	PA32PL32D
PMC	Pm39LV010-xxJC	PLCC	32	PA32PL32D	PMC	Pm39LV010-xxVC	sTSOP	32	PA32ST32D
PMC	Pm39LV020-xxJC	PLCC	32	PA32PL32D	PMC	Pm39LV040-xxJC	PLCC	32	PA32PL32D
PMC	Pm39LV512R	DIP	32	PA32PL32D	PMC	Pm39LV512-xxJC	PLCC	32	PA32PL32D
PMC	Pm39LV512-xxVC	sTSOP	32	PA32ST32D	PMC	Pm49FL002T-xxJC	PLCC	32	PA32PL32D
PMC	Pm49FL002T-xxJV	sTSOP	32	PA32TS14/PA32TS32D-14	PMC	Pm49FL004T-xxJC	PLCC	32	PA32PL32D
PMC	Pm49FL004T-xxJV	sTSOP	32	PA32TS14/PA32TS32D-14	PMC	Pm49FL008T-xxJC	PLCC	32	PA32PL32D
PMC	Pm49FL008T-xxJV	sTSOP	32	PA32TS14/PA32TS32D-14	QUICK	27010	DIP	32	Not use adapter
QUICK	27040	DIP	32	Not use adapter	QUICK	27128A	DIP	28	Not use adapter
QUICK	27210	DIP	40	Not use adapter	QUICK	27210	PLCC	44	PA44-48U
QUICK	27256	DIP	28	Not use adapter	QUICK	27512	DIP	28	Not use adapter
QUICK	2764A	DIP	28	Not use adapter	RAMTRON	FM18L08-P	DIP	28	Not use adapter
RAMTRON	FM18L08-PG	DIP	28	Not use adapter	RAMTRON	FM18L08-S	SOIC	28	PA68-40B
RAMTRON	FM18L08-SG	SOIC	28	PA68-40B	RICOH	RD27C256	DIP	28	Not use adapter
RICOH	RD27C64	DIP	28	Not use adapter	ROCKWELL	R2764	DIP	28	Not use adapter

ROCKWELL	R2764C	DIP	28	Not use adapter	ROCKWELL	R2764P	DIP	28	Not use adapter
ROCKWELL	R27C64	DIP	28	Not use adapter	ROCKWELL	R2816	DIP	24	Not use adapter
ROHM	BR24C01A	DIP	8	Not use adapter	ROHM	BR24C02	DIP	8	Not use adapter
ROHM	BR24C04	DIP	8	Not use adapter	ROHM	BR24C08	DIP	8	Not use adapter
ROHM	BR24C16	DIP	8	Not use adapter	ROHM	BR24E16	DIP	8	Not use adapter
ROHM	BR9010	DIP	8	Not use adapter	ROHM	BR9010F	DIP	8	Not use adapter
ROHM	BR9010F	SSOP	8	PA8TSS-OT	ROHM	BR9010F	SOIC	8	PA8SO1-05-6
ROHM	BR9016	DIP	8	Not use adapter	ROHM	BR9016F	SSOP	8	PA8TSS-OT
ROHM	BR9016F	DIP	8	Not use adapter	ROHM	BR9016F	SOIC	8	PA8SO1-05-6
ROHM	BR9020	SSOP	8	PA8TSS-OT	ROHM	BR9020	DIP	8	Not use adapter
ROHM	BR9020	SOIC	8	PA8SO1-05-6	ROHM	BR9020F	DIP	8	Not use adapter
ROHM	BR9020F	SSOP	8	PA8TSS-OT	ROHM	BR9020F	SOIC	8	PA8SO1-05-6
ROHM	BR9040	DIP	8	Not use adapter	ROHM	BR9040F	SSOP	8	PA8TSS-OT
ROHM	BR9040F	DIP	8	Not use adapter	ROHM	BR9040F	SOIC	8	PA8SO1-05-6
ROHM	BR9080	DIP	8	Not use adapter	ROHM	BR9080F	SSOP	8	PA8TSS-OT
ROHM	BR9080F	DIP	8	Not use adapter	ROHM	BR9080F	SOIC	8	PA8SO1-05-6
ROHM	BR93LC46	DIP	8	Not use adapter	ROHM	BR93LC46F	SOIC	8	PA8SO1-05-6
ROHM	BR93LC56	DIP	8	Not use adapter	ROHM	BR93LC56F	SOIC	8	PA8SO1-05-6
ROHM	BR93LC66	DIP	8	Not use adapter	ROHM	BR93LC66F	SOIC	8	PA8SO1-05-6
ROHM	BR93LL46	DIP	8	Not use adapter	ROHM	BR93LL46F	SOIC	8	PA8SO1-05-6
RUSSIAN	573RF2/5	DIP	24	Not use adapter	RUSSIAN	573RF4-21.5	DIP	28	Not use adapter
RUSSIAN	573RF4-23	DIP	28	Not use adapter	RUSSIAN	57RF4-21	DIP	28	Not use adapter
SAMSUNG	K5A3240YBA	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3240YBB	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3240YBM	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3240YTA	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3240YTB	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3240YTM	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3280YBA	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3280YBB	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3280YBC	BGA	69	PA69BGA48DE	SAMSUNG	K5A3280YBM	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3280YTA	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3280YTB	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3280YTC	BGA	69	PA69BGA48DE	SAMSUNG	K5A3280YTM	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3281CBM	BGA	69	PA69BGA48DE	SAMSUNG	K5A3281CTM	BGA	69	PA69BGA48DE
SAMSUNG	K5A3340YBA	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3340YBB	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3340YBM	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3340YTA	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3340YTB	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3340YTM	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3380YBA	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3380YBB	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3380YBM	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3380YTA	BGA	56	PA56BGA48-YO
SAMSUNG	K5A3380YTB	BGA	56	PA56BGA48-YO	SAMSUNG	K5A3380YTM	BGA	56	PA56BGA48-YO
SAMSUNG	K5D3241YBA	BGA	66	PA66BGA48DA-TO-8X11	SAMSUNG	K5D3241YTA	BGA	66	PA66BGA48DA-TO-8X11
SAMSUNG	K5F3264YBM(NOR)	BGA	69	PA69BGA48DB	SAMSUNG	K5F3264YTM(NOR)	BGA	69	PA69BGA48DB
SAMSUNG	K5J6316CBM	BGA	69	PA69BGA48DJ-YO-8X11.6	SAMSUNG	K5J6316CTM	BGA	69	PA69BGA48DJ-YO-8X11.6
SAMSUNG	K8D1616UBA-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D1616UBA-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D1616UBM-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D1616UBM-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D1616UTA-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D1616UTA-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D1616UTM-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D1616UTM-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D1716UBA-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D1716UBA-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D1716UBC-Y	TSOP	48	PA48TS48D	SAMSUNG	K8D1716UTA-T	BGA	48	PA48BGA48DA
SAMSUNG	K8D1716UTA-Y	TSOP	48	PA48TS48D	SAMSUNG	K8D1716UTC-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3216UBA-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3216UBA-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3216UBB-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3216UBB-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3216UBC-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3216UBC-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3216UBM-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3216UBM-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3216UTA-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3216UTA-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3216UTB-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3216UTB-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3216UTC-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3216UTC-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3216UTM-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3216UTM-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3316UBA-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3316UBA-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D3316UBC-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3316UBM-T	BGA	48	PA48BGA48DA
SAMSUNG	K8D3316UBM-Y	TSOP	48	PA48TS48D	SAMSUNG	K8D3316UTA-T	BGA	48	PA48BGA48DA
SAMSUNG	K8D3316UTA-Y	TSOP	48	PA48TS48D	SAMSUNG	K8D3316UTC-T	BGA	48	PA48BGA48DA
SAMSUNG	K8D3316UTM-T	BGA	48	PA48BGA48DA	SAMSUNG	K8D3316UTM-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D6316UBM-T	BGA	48	PA48BGA48DL	SAMSUNG	K8D6316UBM-Y	TSOP	48	PA48TS48D
SAMSUNG	K8D6316UTM-T	BGA	48	PA48BGA48DL	SAMSUNG	K8D6316UTM-Y	TSOP	48	PA48TS48D
SAMSUNG	K9F1208U0A	TSOP	48	PA48TS48D	SAMSUNG	K9F1216U0A	BGA	63	PA63BGA48DD
SAMSUNG	K9F2808U0A	TSOP	48	PA48TS48D	SAMSUNG	K9F2808U0C	TSOP	48	PA48TS48D
SAMSUNG	K9F2808U0M	TSOP	48	PA48TS48D	SAMSUNG	K9F5608U0A	TSOP	48	PA48TS48D
SAMSUNG	K9K1208U0A	TSOP	48	PA48TS48D	SAMSUNG	K9K1216D0C	BGA	63	PA63BGA48DD
SAMSUNG	KAB01D100M	BGA	80	PA80BGA48DB	SAMSUNG	KAB01D100M-A	BGA	80	PA80BGA48DB-A
SAMSUNG	KAC070010M	BGA	69	PA69BGA48DG-YO-8X13	SAMSUNG	KAD070300A	BGA	69	PA69BGA48DJ-YO-8X11.6
SAMSUNG	KAD070300M	BGA	69	PA69BGA48DJ-YO-8X11.6	SAMSUNG	KBB05A300M	BGA	80	PA80BGA48DC
SAMSUNG	KBB05A500M	BGA	80	PA80BGA48DD	SAMSUNG	KBE00F003M	BGA	107	HA107BG48DG
SAMSUNG	KBE00F003M(+Spare)	BGA	107	HA107BG48DG	SAMSUNG	KBE00S003M(+Spare)	BGA	107	HA107BG48DG
SAMSUNG	KBE00S003M(+Spare)	BGA	107	HA107BG48DG	SAMSUNG	KM2816A	DIP	24	Not use adapter
SAMSUNG	KM2816AI	DIP	24	Not use adapter	SAMSUNG	KM2817A	DIP	28	Not use adapter
SAMSUNG	KM2817AI	DIP	28	Not use adapter	SAMSUNG	KM2864A	DIP	28	Not use adapter
SAMSUNG	KM2864AH	DIP	28	Not use adapter	SAMSUNG	KM2865A	DIP	28	Not use adapter

SAMSUNG	KM2865AH	DIP	28	Not use adapter	SAMSUNG	KM28C16	DIP	24	Not use adapter
SAMSUNG	KM28C17	DIP	28	Not use adapter	SAMSUNG	KM28C256	DIP	28	Not use adapter
SAMSUNG	KM28C64A	DIP	28	Not use adapter	SAMSUNG	KM28C65A	DIP	28	Not use adapter
SAMSUNG	KM28U160T-B	TSOP	48	PA48TS48D	SAMSUNG	KM28U160T-T	TSOP	48	PA48TS48D
SAMSUNG	KM28U800T-B	TSOP	48	PA48TS48D	SAMSUNG	KM28U800T-T	TSOP	48	PA48TS48D
SAMSUNG	KM29C010	DIP	32	Not use adapter	SAMSUNG	KM5AU1620-B	BGA	56	PA56FBGA48D
SAMSUNG	KM5AU1620-T	BGA	56	PA56FBGA48D	SAMSUNG	KM5AU1621-B	BGA	56	PA56FBGA48D
SAMSUNG	KM5AU1621-T	BGA	56	PA56FBGA48D	SAMSUNG	KM5MU0820T-B	sTSOP	48	PA48TS48D-A
SAMSUNG	KM5MU0820T-T	sTSOP	48	PA48TS48D-A	SAMSUNG	KM5MU1620T-B	sTSOP	48	PA48TS48D-A
SAMSUNG	KM5MU1620T-T	sTSOP	48	PA48TS48D-A	SAMSUNG	KM93C06	DIP	8	Not use adapter
SAMSUNG	KM93C07	DIP	8	Not use adapter	SAMSUNG	KM93C46	DIP	8	Not use adapter
SAMSUNG	KM93C56	DIP	8	Not use adapter	SAMSUNG	KM93C66	DIP	8	Not use adapter
SAMSUNG	KS24C010	DIP	8	Not use adapter	SAMSUNG	KS24C011	DIP	8	Not use adapter
SAMSUNG	KS24C020	DIP	8	Not use adapter	SAMSUNG	KS24C021	DIP	8	Not use adapter
SAMSUNG	KS24C040	DIP	8	Not use adapter	SAMSUNG	KS24C041	DIP	8	Not use adapter
SAMSUNG	KS24C080	DIP	8	Not use adapter	SAMSUNG	KS24C081	DIP	8	Not use adapter
SAMSUNG	KS24L161	DIP	8	Not use adapter	SAMSUNG	KS24L321	DIP	8	Not use adapter
SAMSUNG	KS24L641	DIP	8	Not use adapter	SEEQ	27128	DIP	28	Not use adapter
SEEQ	27256	DIP	28	Not use adapter	SEEQ	2764	DIP	28	Not use adapter
SEEQ	27C256	DIP	28	Not use adapter	SEEQ	2804A	DIP	24	Not use adapter
SEEQ	2816A	DIP	24	Not use adapter	SEEQ	2816AH	DIP	24	Not use adapter
SEEQ	2817A	DIP	28	Not use adapter	SEEQ	2817AH	DIP	28	Not use adapter
SEEQ	2864	DIP	28	Not use adapter	SEEQ	2864H	DIP	28	Not use adapter
SEEQ	28C010	DIP	32	Not use adapter	SEEQ	28C256	DIP	28	Not use adapter
SEEQ	28C256A	DIP	28	Not use adapter	SEEQ	28C256AH	DIP	28	Not use adapter
SEEQ	28C64	DIP	28	Not use adapter	SEEQ	28C64A	DIP	28	Not use adapter
SEEQ	28C65	DIP	28	Not use adapter	SEEQ	28HC256	DIP	28	Not use adapter
SEEQ	28HC256H	DIP	28	Not use adapter	SEEQ	28HC64	DIP	28	Not use adapter
SEEQ	E28C64	DIP	28	Not use adapter	SEEQ	M28C010	DIP	32	Not use adapter
SEEQ	M28C010A	DIP	32	Not use adapter	SEEQ	M28C64	DIP	28	Not use adapter
SEIKO	S24C01A	DIP	8	Not use adapter	SEIKO	S24C02A	DIP	8	Not use adapter
SEIKO	S24C04A	DIP	8	Not use adapter	SEIKO	S24C08ADPA	DIP	8	Not use adapter
SEIKO	S24C08AFJA	SOP	8	PA16SO16D	SEIKO	S24C16ADPA	DIP	8	Not use adapter
SEIKO	S24C16AFJA	SOP	8	PA16SO16D	SHARP	LH28F160B	BGA	48	CIC-48uBGA-44D-A6-YAM
SHARP	LH28F160BJD-TTL	DIP	42	Not use adapter	SHARP	LH28F160BJE	TSOP	48	PA48TS48D
SHARP	LH28F160BJE-BTL	TSOP	48	PA48TS48D	SHARP	LH28F160BJE-TTL	TSOP	48	PA48TS48D
SHARP	LH28F160S3	SSOP	56	CIC-56SS-48D-B6-TI	SHARP	LH28F160S3	TSOP	56	PA56TS48D-B6-YAM
SHARP	LH28F160S5	SSOP	56	CIC-56SS-48D-B6-TI	SHARP	LH28F320BFHE-PBTL	TSOP	48	PA48TS48D
SHARP	LH28F320BFHE-PTTL	TSOP	48	PA48TS48D	SHARP	LH28F320BFN-PTTL	SOP	44	PA44SO44D
SHARP	LH28F320BJE-PBTL	TSOP	48	PA48TS48D	SHARP	LH28F320BJE-PTTL	TSOP	48	PA48TS48D
SHARP	LH28F400BVE-BL	TSOP	48	PA48TS48D	SHARP	LH28F400BVE-TL	TSOP	48	PA48TS48D
SHARP	LH28F400SUE	TSOP	48	PA48TS48D	SHARP	LH28F640BFN-PTTL	SOP	44	PA44SO44D
SHARP	LH28F800B	BGA	48	CIC-48uBGA-44D-A6-YAM	SHARP	LH28F800BGHE	TSOP	48	PA48TS48D
SHARP	LH28F800BJE	TSOP	48	PA48TS48D	SHARP	LH28F800BVHE	TSOP	48	PA48TS48D
SHARP	LH28F800SGE	TSOP	48	PA48TS48D	SHARP	LH57128	DIP	28	Not use adapter
SHARP	LH57256	DIP	28	Not use adapter	SHARP	LH5764	DIP	28	Not use adapter
SHARP	LHF00L35	PLCC	32	PA32PL32D	SHARP	LHF00L47	TSOP	40	PA40TS40D
SHARP	LRS1311	BGA	72	PA72BGA48D-A	SHARP	LRS1316A	BGA	72	PA72BGA48D-C
SHARP	LRS1325A	BGA	72	PA72BGA48D-A	SHARP	LRS1329	BGA	72	PA72BGA48D-A
SHARP	LRS1331	BGA	72	PA72BGA48D-B	SHARP	LRS1336	BGA	64	PA72BGA48D-A
SHARP	LRS1342	BGA	72	PA72BGA48D-B	SHARP	LRS1350	BGA	72	PA72BGA48D-A
SHARP	LRS1360	BGA	72	PA72BGA48D-B	SHARP	LRS1370	BGA	72	PA72BGA48D-B
SHARP	LRS1381A	BGA	72	PA72BGA48D-B	SHARP	LRS1383	BGA	72	PA72BGA48D-B
SHARP	LRS1386	BGA	72	PA72BGA48D-B	SHARP	LRS1387	BGA	72	PA72BGA48D-B
SHARP	LRS1805A	BGA	72	PA72BGA48D-B	SHARP	LRS1806A	BGA	72	PA72BGA48D-B
SHARP	LRS1850	BGA	72	PA72BGA48D-B	SHARP	LRS1864	BGA	72	PA72BGA48D-BC
SHARP	LRS1876	BGA	72	PA72BGA48D-BC	SIEMENS	C501-1E	DIP	40	Not use adapter
SIEMENS	C501-1E	PLCC	44	PA44-48U	SIGNETICS(PHILIPS)	87C51	DIP	40	Not use adapter
SIGNETICS(PHILIPS)	87C51	PLCC	44	PA44-48U	SIGNETICS(PHILIPS)	87C51FA	PLCC	44	PA44-48U
SIGNETICS(PHILIPS)	87C51FA	DIP	40	Not use adapter	SIGNETICS(PHILIPS)	87C51FB	DIP	40	Not use adapter
SIGNETICS(PHILIPS)	87C51FB	PLCC	44	PA44-48U	SIGNETICS(PHILIPS)	87C51FC	DIP	40	Not use adapter
SIGNETICS(PHILIPS)	87C51FC	PLCC	44	PA44-48U	SIGNETICS(PHILIPS)	87C52	DIP	40	Not use adapter
SIGNETICS(PHILIPS)	87C52	PLCC	44	PA44-48U	SIGNETICS(PHILIPS)	87C524	PLCC	44	PA44-48U
SIGNETICS(PHILIPS)	87C524	DIP	40	Not use adapter	SIGNETICS(PHILIPS)	87C528	PLCC	44	PA44-48U
SIGNETICS(PHILIPS)	87C528	DIP	40	Not use adapter	SIGNETICS(PHILIPS)	87C552	DIP	40	PA552-68
SIGNETICS(PHILIPS)	87C525	DIP	40	Not use adapter	SIGNETICS(PHILIPS)	87C575	PLCC	44	PA44-48U
SIGNETICS(PHILIPS)	87C575	DIP	40	Not use adapter	SIGNETICS(PHILIPS)	87C652	DIP	40	Not use adapter
SIGNETICS(PHILIPS)	87C592	DIP	40	PA592-68	SIGNETICS(PHILIPS)	87C654	PLCC	44	PA44-48U
SIGNETICS(PHILIPS)	87C652	PLCC	44	PA44-48U	SIGNETICS(PHILIPS)	87C749	DIP	28	Not use adapter
SIGNETICS(PHILIPS)	87C654	DIP	40	Not use adapter	SIGNETICS(PHILIPS)	87C750	DIP	24	Not use adapter
SIGNETICS(PHILIPS)	87C749	PLCC	28	PA28PL28D	SIGNETICS(PHILIPS)	87C751	DIP	24	Not use adapter
SIGNETICS(PHILIPS)	87C750	PLCC	28	PA28PL28D	SIGNETICS(PHILIPS)	87C752	DIP	28	Not use adapter
SIGNETICS(PHILIPS)	87C751	PLCC	28	PA28PL28D	SILICON7	SV5C3238UBA	BGA	72	PA72BGA48DD-TO-8X11
SIGNETICS(PHILIPS)	87C752	PLCC	28	PA28PL28D	SILICON7	SV5D2832UDA	BGA	88	PA88BGA48DA-YO-8X10
SILICON7	SV5C3238UTA	BGA	72	PA72BGA48DD-TO-8X11					

SILICON7	SV5D6416UBA	BGA	88	PA88BGA48DA-YO-8X10	SILICON7	SV5D6416UTA	BGA	88	PA88BGA48DA-YO-8X10
SILICONLABS	C8051F320	QFP	32	PA32TQ32D	SMOS	SPM27128	DIP	28	Not use adapter
SMOS	SPM27128C	DIP	28	Not use adapter	SMOS	SPM27C256	DIP	28	Not use adapter
SMOS	SPM27C64	DIP	28	Not use adapter	SMOS	SPM27C64H	DIP	28	Not use adapter
SMOS	SPM2864C	DIP	28	Not use adapter	SPANSION	S25FL004A-M	SOP	8	PA20SO2006-200/PA20SO20D
SPANSION	S25FL004A-N	CASON	8	PA8SON8D	SPANSION	S25FL008A-M	SOP	8	PA20SO2006-200/PA20SO20D
SPANSION	S25FL008A-N	CASON	8	PA8SON8D	SPANSION	S25FL016A-M	SOIC	16	PA28SO28D-EO-300
SPANSION	S25FL016A-M	SOP	8	PA20SO2006-200/PA20SO20D	SPANSION	S25FL016A-N	CASON	8	PA8SON8D
SPANSION	S25FL032A-M	SOIC	16	PA28SO28D-EO-300	SPANSION	S25FL040A-M-B	SOP	8	PA20SO2006-200/PA20SO20D
SPANSION	S25FL040A-M-I	SOP	8	PA20SO2006-200/PA20SO20D	SPANSION	S25FL040A-M-T	SOP	8	PA20SO2006-200/PA20SO20D
SPANSION	S25FL040A-N-B	CASON	8	PA8SON8D	SPANSION	S25FL040A-N-I	CASON	8	PA8SON8D
SPANSION	S25FL040A-N-T	CASON	8	PA8SON8D	SPANSION	S25FL040A-V-B	SOP	8	PA16SO16D-EO-150
SPANSION	S25FL040A-V-I	SOP	8	PA16SO16D-EO-150	SPANSION	S25FL040A-V-T	SOP	8	PA16SO16D-EO-150
SPANSION	S25FL064A-M	SOIC	16	PA28SO28D-EO-300	SPANSION	S29AL002-B-01	BGA	48	PA48BG48DW
SPANSION	S29AL002-B-02	BGA	48	PA48BG48DW	SPANSION	S29AL002-S-01	SOP	44	PA44SO44D
SPANSION	S29AL002-S-02	SOP	44	PA44SO44D	SPANSION	S29AL002-T-01	TSOP	48	PA48TS48D
SPANSION	S29AL002-T-02	TSOP	48	PA48TS48D	SPANSION	S29AL004-B-01	BGA	48	PA48BG48DW
SPANSION	S29AL004-B-02	BGA	48	PA48BG48DW	SPANSION	S29AL004-S-01	SOP	44	PA44SO44D
SPANSION	S29AL004-S-02	SOP	44	PA44SO44D	SPANSION	S29AL004-T-01	TSOP	48	PA48TS48D
SPANSION	S29AL004-T-02	TSOP	48	PA48TS48D	SPANSION	S29AL008-B-01	BGA	48	PA48BG48DW
SPANSION	S29AL008-B-02	BGA	48	PA48BG48DW	SPANSION	S29AL008D-B-01	BGA	48	PA48BG48DW
SPANSION	S29AL008D-B-02	BGA	48	PA48BG48DW	SPANSION	S29AL008D-B-R1	BGA	48	PA48BG48DW
SPANSION	S29AL008D-B-R2	BGA	48	PA48BG48DW	SPANSION	S29AL008D-M-01	SOP	44	PA44SO44D
SPANSION	S29AL008D-M-02	SOP	44	PA44SO44D	SPANSION	S29AL008D-M-R1	SOP	44	PA44SO44D
SPANSION	S29AL008D-M-R2	SOP	44	PA44SO44D	SPANSION	S29AL008D-T-01	TSOP	48	PA48TS48D
SPANSION	S29AL008D-T-02	TSOP	48	PA48TS48D	SPANSION	S29AL008D-T-R1	TSOP	48	PA48TS48D
SPANSION	S29AL008D-T-R2	TSOP	48	PA48TS48D	SPANSION	S29AL008-S-01	SOP	44	PA44SO44D
SPANSION	S29AL008-S-02	SOP	44	PA44SO44D	SPANSION	S29AL008-T-01	TSOP	48	PA48TS48D
SPANSION	S29AL008-T-02	TSOP	48	PA48TS48D	SPANSION	S29AL016DB	TSOP	48	PA48TS48D
SPANSION	S29AL016DT	TSOP	48	PA48TS48D	SPANSION	S29AL016MB	TSOP	48	PA48TS48D
SPANSION	S29AL016M-T-R1	TSOP	48	PA48TS48D	SPANSION	S29AL016M-T-R2	TSOP	48	PA48TS48D
SPANSION	S29AL016-S-01	SOP	44	PA44SO44D	SPANSION	S29AL016-S-02	SOP	44	PA44SO44D
SPANSION	S29AL016-T-01	TSOP	48	PA48TS48D	SPANSION	S29AL016-T-02	TSOP	48	PA48TS48D
SPANSION	S29AL032D-T-03	TSOP	48	PA48TS48D1	SPANSION	S29AL032D-T-04	TSOP	48	PA48TS48D1
SPANSION	S29GL032M-R0	TSOP	40	PA40TS40D	SPANSION	S29GL032M-R3	TSOP	48	PA48TS48D
SPANSION	S29GL032M-R3	BGA	48	PA48BG48DAO1	SPANSION	S29GL032M-R4	BGA	48	PA48BG48DAO1
SPANSION	S29GL032M-R4	TSOP	48	PA48TS48D	SPANSION	S29GL032M-R5	TSOP	48	PA48TS48D
SPANSION	S29GL032M-R5	BGA	48	PA48BG48DAO1	SPANSION	S29GL032M-R6	TSOP	48	PA48TS48D
SPANSION	S29GL032M-R6	BGA	48	PA48BG48DAO1	SPANSION	S29GL064M-R3	TSOP	48	PA48TS48D
SPANSION	S29GL064M-R4	TSOP	48	PA48TS48D	SPANSION	S29GL064M-R6	TSOP	48	PA48TS48D
SPANSION	S29GL064M-R7	TSOP	48	PA48TS48D	SPANSION	S29GL128M-R1	TSOP	56	PA56TS48DB
SPANSION	S29GL128M-R2	TSOP	56	PA56TS48DB	SPANSION	S29GL128N	TSOP	56	PA56TS48DB
SPANSION	S29GL256M-R1	TSOP	56	PA56TS48DC	SPANSION	S29GL256M-R2	TSOP	56	PA56TS48DC
SPANSION	S29GL256N-01	TSOP	56	PA56TS48DC	SPANSION	S29GL256N-R2	TSOP	56	PA56TS48DC
SPANSION	S29GL512N	TSOP	56	PA56TS48DD	SPANSION	S29JL032H-01	TSOP	48	PA48TS48D1
SPANSION	S29JL032H-02	TSOP	48	PA48TS48D1	SPANSION	S29JL032H-21	TSOP	48	PA48TS48D1
SPANSION	S29JL032H-22	TSOP	48	PA48TS48D1	SPANSION	S29JL032H-31	TSOP	48	PA48TS48D1
SPANSION	S29JL032H-32	TSOP	48	PA48TS48D1	SPANSION	S29JL032H-41	TSOP	48	PA48TS48D1
SPANSION	S29JL032H-42	TSOP	48	PA48TS48D1	SPANSION	S29PL032J12	BGA	48	HA48BG48DAS
SPANSION	S71JL064HB0	BGA	73	PA73BGA48DC-YO-8X11.6	SPANSION	S71JL128HB0	BGA	73	PA73BGA48DC-YO-8X11.6
SPANSION	S71PL032JA0	BGA	56	PA44-48U	SPANSION	S71PL064JA0	BGA	56	PA44-48U
SPANSION	S71PL129JA0	BGA	73	PA73BGA48DC-YO-8X11.6	SPANSION	S71PL129JB0	BGA	64	HA64BG48DF
SPANSION	S99PL193JC0	BGA	73	PA73BG48DG	SST	28LF040	DIP	32	Not use adapter
SST	28SF040	DIP	32	Not use adapter	SST	28SF040A	DIP	32	Not use adapter
SST	28VF040	DIP	32	Not use adapter	SST	28VF040A	DIP	32	Not use adapter
SST	65P542R	SOIC	28	PA28SO08	SST	89E516RD	DIP	40	Not use adapter
SST	89E516RD	PLCC	44	PA44-48U	SST	89E516RD	TQFP	44	PA44QF44D
SST	89E516RD2	PLCC	44	PA44-48U	SST	89E516RD2	TQFP	44	PA44QF44D
SST	89E52RD	PLCC	44	PA44-48U	SST	89E52RD	DIP	40	Not use adapter
SST	89E52RD	TQFP	44	PA44QF44D	SST	89E52RD2	PLCC	44	PA44-48U
SST	89E52RD2	TQFP	44	PA44QF44D	SST	89E54RD	DIP	40	Not use adapter
SST	89E54RD	PLCC	44	PA44-48U	SST	89E54RD	TQFP	44	PA44QF44D
SST	89E54RD2	PLCC	44	PA44-48U	SST	89E54RD2	TQFP	44	PA44QF44D
SST	89E54RC	PLCC	44	PA44-48U	SST	89E54RC	DIP	40	Not use adapter
SST	89E564RD	PLCC	44	PA44-48U	SST	89E564RD	DIP	40	Not use adapter
SST	89E58RD	PLCC	44	PA44-48U	SST	89E58RD	DIP	40	Not use adapter
SST	89E58RD	TQFP	44	PA44QF44D	SST	89E58RD2	PLCC	44	PA44-48U
SST	89E58RD2	TQFP	44	PA44QF44D	SST	89V516RD	DIP	40	Not use adapter
SST	89V516RD	PLCC	44	PA44-48U	SST	89V516RD	TQFP	44	PA44QF44D
SST	89V516RD2	PLCC	44	PA44-48U	SST	89V516RD2	TQFP	44	PA44QF44D
SST	89V52RD	PLCC	44	PA44-48U	SST	89V52RD	DIP	40	Not use adapter
SST	89V52RD	QFP	44	PA44QF44D	SST	89V52RD2	PLCC	44	PA44-48U
SST	89V52RD2	TQFP	44	PA44QF44D	SST	89V54RD	PLCC	44	PA44-48U
SST	89V54RD	DIP	40	Not use adapter	SST	89V54RD	TQFP	44	PA44QF44D

SST	89V54RD2	PLCC	44	PA44-48U	SST	89V54RD2	TQFP	44	PA44QF44D
SST	89V554RC	PLCC	44	PA44-48U	SST	89V554RC	DIP	40	Not use adapter
SST	89V564RD	PLCC	44	PA44-48U	SST	89V564RD	DIP	40	Not use adapter
SST	89V58RD	DIP	40	Not use adapter	SST	89V58RD	PLCC	44	PA44-48U
SST	89V58RD	TQFP	44	PA44QF44D	SST	89V58RD2	PLCC	44	PA44-48U
SST	89V58RD2	TQFP	44	PA44QF44D	SST	PH28EE011	DIP	32	Not use adapter
SST	SST25LF020A	SOIC	8	PA16SO16D	SST	SST25LF040A	SOIC	8	PA20SO2006-200/PA20SO20D
SST	SST25LF080A	SOIC	8	PA20SO2006-200/PA20SO20D	SST	SST25VF010	SOIC	8	PA16SO16D
SST	SST25VF016B	WSON	8	PA8SON8D	SST	SST25VF016B	SOIC	8	PA20SO2006-200/PA20SO20D
SST	SST25VF020	SOIC	8	PA16SO16D	SST	SST25VF040	SOIC	8	PA16SO16D
SST	SST25VF040B	WSON	8	PA8SON8D	SST	SST25VF040B	SOIC	8	PA20SO2006-200/PA20SO20D
SST	SST25VF080B	WSON	8	PA8SON8D	SST	SST25VF080B	SOIC	8	PA20SO2006-200/PA20SO20D
SST	SST25VF512	SOIC	8	PA16SO16D	SST	SST27SF010	DIP	32	Not use adapter
SST	SST27SF020	DIP	32	Not use adapter	SST	SST27SF256	DIP	28	Not use adapter
SST	SST27SF512	DIP	28	Not use adapter	SST	SST27SF512	PLCC	32	PA32-28
SST	SST27SF512	PLCC	32	PA32-28	SST	SST27SF512	PLCC	32	PA32-28
SST	SST27SF512	PLCC	32	PA32-28	SST	SST27SF512	PLCC	32	PA32-28
SST	SST27SF512	PLCC	32	PA32-28	SST	SST27SF512	PLCC	32	PA32-28
SST	SST27VF020	DIP	32	Not use adapter	SST	SST27VF010	DIP	32	Not use adapter
SST	SST27VF512	DIP	28	Not use adapter	SST	SST27VF256	DIP	28	Not use adapter
SST	SST29EE010	PLCC	32	PA32PL32D	SST	SST29EE010	DIP	32	Not use adapter
SST	SST29EE010A	PLCC	32	PA32PL32D	SST	SST29EE010A	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29EE010A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29EE020	DIP	32	Not use adapter
SST	SST29EE020	PLCC	32	PA32PL32D	SST	SST29EE020	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29EE020A	DIP	32	Not use adapter	SST	SST29EE020A	PLCC	32	PA32PL32D
SST	SST29EE020A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29EE512	PLCC	32	PA32PL32D
SST	SST29EE512	TSOP	32	PA32TS20/PA32TS32D-20	SST	SST29EE512	DIP	32	Not use adapter
SST	SST29EE512A	DIP	32	Not use adapter	SST	SST29EE512A	PLCC	32	PA32PL32D
SST	SST29EE512A	TSOP	32	PA32TS20/PA32TS32D-20	SST	SST29LE010	PLCC	32	PA32PL32D
SST	SST29LE010	DIP	32	Not use adapter	SST	SST29LE010	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29LE010A	PLCC	32	PA32PL32D	SST	SST29LE010A	DIP	32	Not use adapter
SST	SST29LE010A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29LE020	DIP	32	Not use adapter
SST	SST29LE020	PLCC	32	PA32PL32D	SST	SST29LE020	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29LE020A	DIP	32	Not use adapter	SST	SST29LE020A	PLCC	32	PA32PL32D
SST	SST29LE020A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29LE512	DIP	32	Not use adapter
SST	SST29LE512	PLCC	32	PA32PL32D	SST	SST29LE512	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29LE512A	PLCC	32	PA32PL32D	SST	SST29LE512A	DIP	32	Not use adapter
SST	SST29LE512A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29SF010	DIP	32	Not use adapter
SST	SST29SF010	PLCC	32	PA32PL32D	SST	SST29SF010	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29SF020	PLCC	32	PA32PL32D	SST	SST29SF020	DIP	32	Not use adapter
SST	SST29SF020	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29SF040	DIP	32	Not use adapter
SST	SST29SF040	PLCC	32	PA32PL32D	SST	SST29SF040	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29SF512	PLCC	32	PA32PL32D	SST	SST29SF512	DIP	32	Not use adapter
SST	SST29SF512	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29VE010	DIP	32	Not use adapter
SST	SST29VE010	PLCC	32	PA32PL32D	SST	SST29VE010	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29VE010A	PLCC	32	PA32PL32D	SST	SST29VE010A	DIP	32	Not use adapter
SST	SST29VE010A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29VE020	DIP	32	Not use adapter
SST	SST29VE020	PLCC	32	PA32PL32D	SST	SST29VE020	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29VE020A	DIP	32	Not use adapter	SST	SST29VE020A	PLCC	32	PA32PL32D
SST	SST29VE020A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29VE512	PLCC	32	PA32PL32D
SST	SST29VE512	DIP	32	Not use adapter	SST	SST29VE512	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29VE512A	PLCC	32	PA32PL32D	SST	SST29VE512A	DIP	32	Not use adapter
SST	SST29VE512A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29VF010	DIP	32	Not use adapter
SST	SST29VF010	PLCC	32	PA32PL32D	SST	SST29VF010	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29VF020	DIP	32	Not use adapter	SST	SST29VF020	PLCC	32	PA32PL32D
SST	SST29VF020	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST29VF040	DIP	32	Not use adapter
SST	SST29VF040	PLCC	32	PA32PL32D	SST	SST29VF040	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST29VF512	PLCC	32	PA32PL32D	SST	SST29VF512	DIP	32	Not use adapter
SST	SST29VF512	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST31LF021	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST31LF021	TSOP	40	PA40TS14-OT	SST	SST31LF021E	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST31LF041	TSOP	40	PA40TS14-OT	SST	SST31LF041A	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST32HF1622C	BGA	62	PA62BGA48D	SST	SST32HF1642	BGA	62	PA62BGA48D
SST	SST32HF1642C	BGA	62	PA62BGA48D	SST	SST32HF1682C	BGA	62	PA62BGA48D
SST	SST32HF402	BGA	48	PA68-40A	SST	SST32HF402	BGA	48	PA48BG48DAI
SST	SST32VF201	BGA	48	PA48BGA48-SST	SST	SST34HF1621/Poll.	BGA	56	PA56BGA48D
SST	SST34HF1621/Single	BGA	56	PA56BGA48D	SST	SST34HF1621/Toggle	BGA	56	PA56BGA48D
SST	SST34HF1621A	BGA	62	PA62BGA48D	SST	SST34HF1621A/Poll.	BGA	56	PA56BGA48D
SST	SST34HF1621A/Togg.	BGA	56	PA56BGA48D	SST	SST34HF1621C/Poll.	BGA	56	PA56BGA48D-1
SST	SST34HF1621C/Sing.	BGA	56	PA56BGA48D-1	SST	SST34HF1621C/Togg.	BGA	56	PA56BGA48D-1
SST	SST34HF1621S/Poll.	BGA	56	PA56BGA48D-1	SST	SST34HF1621S/Togg.	BGA	56	PA56BGA48D-1
SST	SST34HF1622	BGA	56	PA56BGA48D	SST	SST34HF1622C	BGA	56	PA56BGA48D
SST	SST34HF1622C	BGA	62	PA62BGA48D	SST	SST34HF1622S	BGA	56	PA56BGA48D
SST	SST34HF1622S	BGA	62	PA62BGA48D	SST	SST34HF1641	BGA	62	PA62BGA48D

SST	SST34HF1641	BGA	56	PA56BGA48D	SST	SST34HF1641A	BGA	62	PA62BGA48D
SST	SST34HF1641A	BGA	56	PA56BGA48D	SST	SST34HF1641C	BGA	62	PA62BGA48D
SST	SST34HF1641C	BGA	56	PA56BGA48D	SST	SST34HF1641D	BGA	62	PA62BGA48D
SST	SST34HF1641D	BGA	56	PA56BGA48D	SST	SST34HF1641S	BGA	56	PA56BGA48D
SST	SST34HF1641S	BGA	62	PA62BGA48D	SST	SST34HF1642	BGA	56	PA56BGA48D
SST	SST34HF1642C	BGA	56	PA56BGA48D1	SST	SST34HF1642C	BGA	62	PA62BGA48D1
SST	SST34HF1642D	BGA	62	PA62BGA48D	SST	SST34HF1642D	BGA	56	PA56BGA48D
SST	SST34HF1642S	BGA	62	PA62BGA48D	SST	SST34HF1642S	BGA	56	PA56BGA48D
SST	SST34HF1681C	BGA	62	PA62BGA48D	SST	SST34HF1681C	BGA	56	PA56BGA48D
SST	SST34HF1681D	BGA	56	PA56BGA48D	SST	SST34HF1681D	BGA	62	PA62BGA48D
SST	SST34HF1682D	BGA	56	PA56BGA48D	SST	SST34HF1682D	BGA	62	PA62BGA48D
SST	SST34HF3223A	BGA	56	PA56BGA48D	SST	SST34HF3243A	BGA	56	PA56BGA48D
SST	SST34HF3244C	BGA	56	PA56BGA48D1	SST	SST34HF3244C	BGA	62	PA62BGA48D1
SST	SST34HF3284	BGA	62	PA62BGA48D1	SST	SST34HF3284	BGA	56	PA56BGA48D1
SST	SST34VF1621	BGA	56	PA56BGA48D	SST	SST34VF1622	BGA	56	PA56BGA48D
SST	SST34VF1641	BGA	56	PA56BGA48D	SST	SST34VF1642	BGA	56	PA56BGA48D
SST	SST36VF1601	TSOP	48	PA48TS48D	SST	SST36VF1601C	TSOP	48	PA48TS48D
SST	SST36VF1602	TSOP	48	PA48TS48D	SST	SST36VF1602C	TSOP	48	PA48TS48D
SST	SST36VF3203	BGA	48	PA48BG48DAI	SST	SST36VF3203	TSOP	48	PA48TS48D1
SST	SST36VF3204	TSOP	48	PA48TS48D1	SST	SST36VF3204	BGA	48	PA48BG48DAI
SST	SST37VF010	PLCC	32	PA32PL32D	SST	SST37VF010	DIP	32	Not use adapter
SST	SST37VF010	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST37VF020	DIP	32	Not use adapter
SST	SST37VF020	PLCC	32	PA32PL32D	SST	SST37VF020	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST37VF040	PLCC	32	PA32PL32D	SST	SST37VF040	DIP	32	Not use adapter
SST	SST37VF040	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST37VF080	TSOP	48	PA48TS48D
SST	SST37VF512	DIP	32	Not use adapter	SST	SST37VF512	PLCC	32	PA32PL32D
SST	SST37VF512	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST39LF010	PLCC	32	PA32PL32D
SST	SST39LF010	DIP	32	Not use adapter	SST	SST39LF010	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39LF020	PLCC	32	PA32PL32D	SST	SST39LF020	DIP	32	Not use adapter
SST	SST39LF020	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST39LF040	DIP	32	Not use adapter
SST	SST39LF040	PLCC	32	PA32PL32D	SST	SST39LF040	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39LF100	TSOP	40	PA40TS14-OT	SST	SST39LF200A	TSOP	48	PA48TS48D1
SST	SST39LF400A	TSOP	48	PA48TS48D1	SST	SST39LF512	DIP	32	Not use adapter
SST	SST39LF512	PLCC	32	PA32PL32D	SST	SST39LF512	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39LF800A	TSOP	48	PA48TS48D1	SST	SST39LF800A	WFBGA	48	PA48WFB48D1
SST	SST39LF800A	BGA	48	PA48BG48DAI	SST	SST39LH010	DIP	32	Not use adapter
SST	SST39LH020	DIP	32	Not use adapter	SST	SST39LH040	DIP	32	Not use adapter
SST	SST39LH512	DIP	32	Not use adapter	SST	SST39SF010	DIP	32	Not use adapter
SST	SST39SF010	PLCC	32	PA32PL32D	SST	SST39SF010	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39SF010A	DIP	32	Not use adapter	SST	SST39SF010A	PLCC	32	PA32PL32D
SST	SST39SF010A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST39SF020	PLCC	32	PA32PL32D
SST	SST39SF020	DIP	32	Not use adapter	SST	SST39SF020	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39SF020A	DIP	32	Not use adapter	SST	SST39SF020A	PLCC	32	PA32PL32D
SST	SST39SF020A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST39SF020P	DIP	32	Not use adapter
SST	SST39SF020P	PLCC	32	PA32PL32D	SST	SST39SF020P	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39SF040	DIP	32	Not use adapter	SST	SST39SF040	PLCC	32	PA32PL32D
SST	SST39SF040	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST39SF040P	DIP	32	Not use adapter
SST	SST39SF040P	PLCC	32	PA32PL32D	SST	SST39SF040P	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39SF512	DIP	32	Not use adapter	SST	SST39SF512	PLCC	32	PA32PL32D
SST	SST39SF512	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST39SF512A	DIP	32	Not use adapter
SST	SST39SF512A	PLCC	32	PA32PL32D	SST	SST39SF512A	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39VF010	PLCC	32	PA32PL32D	SST	SST39VF010	DIP	32	Not use adapter
SST	SST39VF010	BGA	32	PA48WFB32D	SST	SST39VF010	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39VF010	BGA	48	PA48BGAD32N-3O-6X8	SST	SST39VF016Q	TSOP	40	PA40TS40D
SST	SST39VF020	PLCC	32	PA32PL32D	SST	SST39VF020	DIP	32	Not use adapter
SST	SST39VF020	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST39VF020P	PLCC	32	PA32PL32D
SST	SST39VF020P	DIP	32	Not use adapter	SST	SST39VF020P	BGA	48	PA48BGAD32N-3O-6X8
SST	SST39VF020P	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST39VF040	PLCC	32	PA32PL32D
SST	SST39VF040	DIP	32	Not use adapter	SST	SST39VF040	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39VF040P	PLCC	32	PA32PL32D	SST	SST39VF040P	DIP	32	Not use adapter
SST	SST39VF040P	BGA	48	PA48BGAD32N-3O-6X8	SST	SST39VF040P	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39VF080	TSOP	40	PA40TS40D	SST	SST39VF080B	TSOP	48	PA48TS48D
SST	SST39VF080Q	TSOP	40	PA40TS40D	SST	SST39VF088	TSOP	48	PA48TS48D
SST	SST39VF100	TSOP	40	PA40TS14-OT	SST	SST39VF160	TSOP	48	PA48TS48D1
SST	SST39VF160(Single)	TSOP	48	PA48TS48D1	SST	SST39VF1601	TSOP	48	PA48TS48D1
SST	SST39VF1601C	TSOP	48	PA48TS48D1	SST	SST39VF1602	TSOP	48	PA48TS48D1
SST	SST39VF160Q	TSOP	48	PA48TS48D1	SST	SST39VF160Q(Single)	TSOP	48	PA48TS48D1
SST	SST39VF1681	TSOP	48	PA48TS48D1	SST	SST39VF1682	TSOP	48	PA48TS48D1
SST	SST39VF200A	WFBGA	48	PA48WFB48D1	SST	SST39VF200A	BGA	48	PA48BG48DAI
SST	SST39VF200A	TSOP	48	PA48TS48D1	SST	SST39VF320	TSOP	48	PA48TS48D1
SST	SST39VF3201	BGA	48	PA48BG48DAI	SST	SST39VF3201	TSOP	48	PA48TS48D1
SST	SST39VF3202	TSOP	48	PA48TS48D1	SST	SST39VF3202	BGA	48	PA48BG48DAI
SST	SST39VF400	TSOP	48	PA48TS48D1	SST	SST39VF400A	BGA	48	PA48BG48DAI
SST	SST39VF400A	TSOP	48	PA48TS48D1	SST	SST39VF400A	WFBGA	48	PA48WFB48D1

SST	SST39VF400Q	TSOP	48	PA48TS48D1	SST	SST39VF512	DIP	32	Not use adapter
SST	SST39VF512	PLCC	32	PA32PL32D	SST	SST39VF512	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST39VF512	BGA	48	PA48BGAD32N-3O-6X8	SST	SST39VF640	TSOP	48	PA48TS48D1
SST	SST39VF6401	TSOP	48	PA48TS48D1	SST	SST39VF6401B	TSOP	48	PA48TS48D1
SST	SST39VF6402	TSOP	48	PA48TS48D1	SST	SST39VF800	TSOP	48	PA48TS48D1
SST	SST39VF800A	WFBGA	48	PA48WFB48D1	SST	SST39VF800A	BGA	48	PA48BG48DAI
SST	SST39VF800A	TSOP	48	PA48TS48D1	SST	SST39VF800Q	TSOP	48	PA48TS48D1
SST	SST39WF400A	WFBGA	48	PA48WFB48D	SST	SST39WF800A	WFBGA	48	PA48WFB48D1
SST	SST49LF002	PLCC	32	PA32PL32D	SST	SST49LF002	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST49LF002A	PLCC	32	PA32PL32D	SST	SST49LF002A	TSOP	40	PA40TS40D
SST	SST49LF002B	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF002B	PLCC	32	PA32PL32D
SST	SST49LF002B	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF002B	TSOP	40	PA40TS40D
SST	SST49LF003A	PLCC	32	PA32PL32D	SST	SST49LF003A	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST49LF003A	TSOP	40	PA40TS40D	SST	SST49LF003B	PLCC	32	PA32PL32D
SST	SST49LF003B	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF003B	TSOP	40	PA40TS40D
SST	SST49LF004	PLCC	32	PA32PL32D	SST	SST49LF004	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST49LF004A	PLCC	32	PA32PL32D	SST	SST49LF004A	TSOP	40	PA40TS40D
SST	SST49LF004A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF004B	PLCC	32	PA32PL32D
SST	SST49LF004B	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF004B	TSOP	40	PA40TS40D
SST	SST49LF008	PLCC	32	PA32PL32D	SST	SST49LF008	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST49LF008A	PLCC	32	PA32PL32D	SST	SST49LF008A	TSOP	40	PA40TS40D
SST	SST49LF008A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF008B	PLCC	32	PA32PL32D
SST	SST49LF008B	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF008B	TSOP	40	PA40TS40D
SST	SST49LF016C(AAI)	PLCC	32	PA32PL32D	SST	SST49LF016C(AAI)	TSOP	32	PA32TS20/PA32TS32D-20
SST	SST49LF016C(AAI)	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF016C(AAI)	TSOP	40	PA40TS40D
SST	SST49LF016C(LPC)	PLCC	32	PA32PL32D	SST	SST49LF016C(LPC)	TSOP	32	PA32TS20/PA32TS32D-20
SST	SST49LF016C(LPC)	TSOP	40	PA40TS40D	SST	SST49LF016C(LPC)	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST49LF020	PLCC	32	PA32PL32D	SST	SST49LF020	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST49LF020A	PLCC	32	PA32PL32D	SST	SST49LF020A	TSOP	32	PA32TS14/PA32TS32D-14
SST	SST49LF030A	PLCC	32	PA32PL32D	SST	SST49LF040	PLCC	32	PA32PL32D
SST	SST49LF040	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF040A	PLCC	32	PA32PL32D
SST	SST49LF040A	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF040B	PLCC	32	PA32PL32D
SST	SST49LF040B	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF080	PLCC	32	PA32PL32D
SST	SST49LF080	TSOP	32	PA32TS14/PA32TS32D-14	SST	SST49LF080A	PLCC	32	PA32PL32D
SST	SST49LF080A	TSOP	32	PA32TS14/PA32TS32D-14	ST	GAL16V8	DIP	20	Not use adapter
ST	GAL16V8	PLCC	20	PA20LC20D	ST	GAL16V8 as 10H8	DIP	20	Not use adapter
ST	GAL16V8 as 10H8	PLCC	20	PA20LC20D	ST	GAL16V8 as 10L8	DIP	20	Not use adapter
ST	GAL16V8 as 10L8	PLCC	20	PA20LC20D	ST	GAL16V8 as 10P8	DIP	20	Not use adapter
ST	GAL16V8 as 10P8	PLCC	20	PA20LC20D	ST	GAL16V8 as 12H6	DIP	20	Not use adapter
ST	GAL16V8 as 12H6	PLCC	20	PA20LC20D	ST	GAL16V8 as 12L6	DIP	20	Not use adapter
ST	GAL16V8 as 12L6	PLCC	20	PA20LC20D	ST	GAL16V8 as 12P6	DIP	20	Not use adapter
ST	GAL16V8 as 12P6	PLCC	20	PA20LC20D	ST	GAL16V8 as 14H4	DIP	20	Not use adapter
ST	GAL16V8 as 14H4	PLCC	20	PA20LC20D	ST	GAL16V8 as 14L4	DIP	20	Not use adapter
ST	GAL16V8 as 14L4	PLCC	20	PA20LC20D	ST	GAL16V8 as 14P4	DIP	20	Not use adapter
ST	GAL16V8 as 14P4	PLCC	20	PA20LC20D	ST	GAL16V8 as 16H2	DIP	20	Not use adapter
ST	GAL16V8 as 16H2	PLCC	20	PA20LC20D	ST	GAL16V8 as 16H8	DIP	20	Not use adapter
ST	GAL16V8 as 16H8	PLCC	20	PA20LC20D	ST	GAL16V8 as 16L2	DIP	20	Not use adapter
ST	GAL16V8 as 16L2	PLCC	20	PA20LC20D	ST	GAL16V8 as 16L8	DIP	20	Not use adapter
ST	GAL16V8 as 16L8	PLCC	20	PA20LC20D	ST	GAL16V8 as 16P2	DIP	20	Not use adapter
ST	GAL16V8 as 16P2	PLCC	20	PA20LC20D	ST	GAL16V8 as 16P8	DIP	20	Not use adapter
ST	GAL16V8 as 16P8	PLCC	20	PA20LC20D	ST	GAL16V8 as 16R4	DIP	20	Not use adapter
ST	GAL16V8 as 16R4	PLCC	20	PA20LC20D	ST	GAL16V8 as 16R6	DIP	20	Not use adapter
ST	GAL16V8 as 16R6	PLCC	20	PA20LC20D	ST	GAL16V8 as 16R8	DIP	20	Not use adapter
ST	GAL16V8 as 16R8	PLCC	20	PA20LC20D	ST	GAL16V8 as 16RP4	DIP	20	Not use adapter
ST	GAL16V8 as 16RP4	PLCC	20	PA20LC20D	ST	GAL16V8 as 16RP6	DIP	20	Not use adapter
ST	GAL16V8 as 16RP6	PLCC	20	PA20LC20D	ST	GAL16V8 as 16RP8	DIP	20	Not use adapter
ST	GAL16V8 as 16RP8	PLCC	20	PA20LC20D	ST	GAL16V8A	DIP	20	Not use adapter
ST	GAL16V8A	PLCC	20	PA20LC20D	ST	GAL16V8A as 10H8	DIP	20	Not use adapter
ST	GAL16V8A as 10H8	PLCC	20	PA20LC20D	ST	GAL16V8A as 10L8	PLCC	20	PA20LC20D
ST	GAL16V8A as 10L8	DIP	20	Not use adapter	ST	GAL16V8A as 10P8	DIP	20	Not use adapter
ST	GAL16V8A as 10P8	PLCC	20	PA20LC20D	ST	GAL16V8A as 12H6	DIP	20	Not use adapter
ST	GAL16V8A as 12H6	PLCC	20	PA20LC20D	ST	GAL16V8A as 12L6	DIP	20	Not use adapter
ST	GAL16V8A as 12L6	PLCC	20	PA20LC20D	ST	GAL16V8A as 12P6	DIP	20	Not use adapter
ST	GAL16V8A as 12P6	PLCC	20	PA20LC20D	ST	GAL16V8A as 14H4	DIP	20	Not use adapter
ST	GAL16V8A as 14H4	PLCC	20	PA20LC20D	ST	GAL16V8A as 14L4	DIP	20	Not use adapter
ST	GAL16V8A as 14L4	PLCC	20	PA20LC20D	ST	GAL16V8A as 14P4	DIP	20	Not use adapter
ST	GAL16V8A as 14P4	PLCC	20	PA20LC20D	ST	GAL16V8A as 16H2	DIP	20	Not use adapter
ST	GAL16V8A as 16H2	PLCC	20	PA20LC20D	ST	GAL16V8A as 16H8	DIP	20	Not use adapter
ST	GAL16V8A as 16H8	PLCC	20	PA20LC20D	ST	GAL16V8A as 16L2	DIP	20	Not use adapter
ST	GAL16V8A as 16L2	PLCC	20	PA20LC20D	ST	GAL16V8A as 16L8	DIP	20	Not use adapter
ST	GAL16V8A as 16L8	PLCC	20	PA20LC20D	ST	GAL16V8A as 16P2	DIP	20	Not use adapter
ST	GAL16V8A as 16P2	PLCC	20	PA20LC20D	ST	GAL16V8A as 16P8	DIP	20	Not use adapter
ST	GAL16V8A as 16P8	PLCC	20	PA20LC20D	ST	GAL16V8A as 16R4	DIP	20	Not use adapter
ST	GAL16V8A as 16R4	PLCC	20	PA20LC20D	ST	GAL16V8A as 16R6	DIP	20	Not use adapter

ST	GAL16V8A as 16R6	PLCC	20	PA20LC20D	ST	GAL16V8A as 16R8	DIP	20	Not use adapter
ST	GAL16V8A as 16R8	PLCC	20	PA20LC20D	ST	GAL16V8A as 16RP4	DIP	20	Not use adapter
ST	GAL16V8A as 16RP4	PLCC	20	PA20LC20D	ST	GAL16V8A as 16RP6	DIP	20	Not use adapter
ST	GAL16V8A as 16RP6	PLCC	20	PA20LC20D	ST	GAL16V8A as 16RP8	DIP	20	Not use adapter
ST	GAL16V8A as 16RP8	PLCC	20	PA20LC20D	ST	GAL20V8	DIP	24	Not use adapter
ST	GAL20V8	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 14H8	DIP	24	Not use adapter
ST	GAL20V8 as 14H8	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 14L8	DIP	24	Not use adapter
ST	GAL20V8 as 14L8	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 14P8	DIP	24	Not use adapter
ST	GAL20V8 as 14P8	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 16H6	DIP	24	Not use adapter
ST	GAL20V8 as 16H6	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 16L6	DIP	24	Not use adapter
ST	GAL20V8 as 16L6	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 16P6	DIP	24	Not use adapter
ST	GAL20V8 as 16P6	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 18H4	DIP	24	Not use adapter
ST	GAL20V8 as 18H4	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 18L4	DIP	24	Not use adapter
ST	GAL20V8 as 18L4	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 18P4	DIP	24	Not use adapter
ST	GAL20V8 as 18P4	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20H2	DIP	24	Not use adapter
ST	GAL20V8 as 20H2	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20H8	DIP	24	Not use adapter
ST	GAL20V8 as 20H8	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20L2	DIP	24	Not use adapter
ST	GAL20V8 as 20L2	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20L8	DIP	24	Not use adapter
ST	GAL20V8 as 20L8	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20P2	DIP	24	Not use adapter
ST	GAL20V8 as 20P2	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20P8	DIP	24	Not use adapter
ST	GAL20V8 as 20P8	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20R4	DIP	24	Not use adapter
ST	GAL20V8 as 20R4	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20R6	DIP	24	Not use adapter
ST	GAL20V8 as 20R6	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20R8	DIP	24	Not use adapter
ST	GAL20V8 as 20R8	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20RP4	DIP	24	Not use adapter
ST	GAL20V8 as 20RP4	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20RP6	DIP	24	Not use adapter
ST	GAL20V8 as 20RP6	PLCC	28	PA28-24-2P6	ST	GAL20V8 as 20RP8	DIP	24	Not use adapter
ST	GAL20V8 as 20RP8	PLCC	28	PA28-24-2P6	ST	GAL20V8A	DIP	24	Not use adapter
ST	GAL20V8A	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 14H8	DIP	24	Not use adapter
ST	GAL20V8A as 14H8	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 14L8	DIP	24	Not use adapter
ST	GAL20V8A as 14L8	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 14P8	DIP	24	Not use adapter
ST	GAL20V8A as 14P8	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 16H6	DIP	24	Not use adapter
ST	GAL20V8A as 16H6	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 16L6	DIP	24	Not use adapter
ST	GAL20V8A as 16L6	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 16P6	DIP	24	Not use adapter
ST	GAL20V8A as 16P6	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 18H4	DIP	24	Not use adapter
ST	GAL20V8A as 18H4	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 18L4	DIP	24	Not use adapter
ST	GAL20V8A as 18L4	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 18P4	DIP	24	Not use adapter
ST	GAL20V8A as 18P4	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20H2	DIP	24	Not use adapter
ST	GAL20V8A as 20H2	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20H8	DIP	24	Not use adapter
ST	GAL20V8A as 20H8	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20L2	DIP	24	Not use adapter
ST	GAL20V8A as 20L2	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20L8	DIP	24	Not use adapter
ST	GAL20V8A as 20L8	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20P2	DIP	24	Not use adapter
ST	GAL20V8A as 20P2	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20P8	DIP	24	Not use adapter
ST	GAL20V8A as 20P8	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20R4	DIP	24	Not use adapter
ST	GAL20V8A as 20R4	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20R6	DIP	24	Not use adapter
ST	GAL20V8A as 20R6	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20R8	DIP	24	Not use adapter
ST	GAL20V8A as 20R8	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20RP4	DIP	24	Not use adapter
ST	GAL20V8A as 20RP4	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20RP6	DIP	24	Not use adapter
ST	GAL20V8A as 20RP6	PLCC	28	PA28-24-2P6	ST	GAL20V8A as 20RP8	DIP	24	Not use adapter
ST	GAL20V8A as 20RP8	PLCC	28	PA28-24-2P6	ST	M24128	DIP	8	Not use adapter
ST	M24128	SOIC	8	PA16SO16D-EO-150	ST	M24128	TSSOP	8	PA24TSS24D(M)
ST	M24256	DIP	8	Not use adapter	ST	M24256	SOIC	8	PA16SO16D-EO-150
ST	M24C01	DIP	8	Not use adapter	ST	M24C01	SOIC	8	PA16SO16D-EO-150
ST	M24C01	TSSOP	8	PA24TSS24D(M)	ST	M24C02	DIP	8	Not use adapter
ST	M24C02	SOIC	8	PA16SO16D-EO-150	ST	M24C02	TSSOP	8	PA24TSS24D(M)
ST	M24C04	DIP	8	Not use adapter	ST	M24C04	SOIC	8	PA16SO16D-EO-150
ST	M24C04	TSSOP	8	PA24TSS24D(M)	ST	M24C08	DIP	8	Not use adapter
ST	M24C08	TSSOP	8	PA24TSS24D(M)	ST	M24C08	SOIC	8	PA16SO16D-EO-150
ST	M24C16	DIP	8	Not use adapter	ST	M24C16	SOIC	8	PA16SO16D-EO-150
ST	M24C16	TSSOP	8	PA24TSS24D(M)	ST	M24C32	DIP	8	Not use adapter
ST	M24C32	SOIC	8	PA16SO16D-EO-150	ST	M24C32	TSSOP	8	PA24TSS24D(M)
ST	M24C64	DIP	8	Not use adapter	ST	M24C64	SOIC	8	PA16SO16D-EO-150
ST	M24C64	TSSOP	8	PA24TSS24D(M)	ST	M24LC21B	DIP	8	Not use adapter
ST	M24LC21B	TSSOP	8	PA24TSS24D(M)	ST	M24LC21B	SOIC	8	PA16SO16D-EO-150
ST	M25P05VMW	SOIC	8	PA16SO16D-EO-150	ST	M25P10VMW	SOIC	8	PA16SO16D-EO-150
ST	M25P16VMJ	SOIC	16	PA28SO28D-EO-300	ST	M25P20VMW	SOIC	8	PA16SO16D-EO-150
ST	M25P32VME	MLP	8	PA68-40B	ST	M25P32VMF	SOIC	16	PA28SO28D-EO-300
ST	M25P32VMJ	SOIC	16	PA28SO28D-EO-300	ST	M25P32VML	MLP	8	PA68-40B
ST	M25P64VMJ	SOIC	16	PA28SO28D-EO-300	ST	M25P80VMF	SOIC	16	PA28SO28D-EO-300
ST	M25P80VMW	SOIC	8	PA16SO16D-EO-150	ST	M25PE80VMP	MLP	8	PA8SON8D
ST	M25PE80VMW	SOIC	8	PA16SO16D-EO-150	ST	M27128A	DIP	28	Not use adapter
ST	M2716	DIP	24	Not use adapter	ST	M27256	DIP	28	Not use adapter
ST	M2732A	DIP	24	Not use adapter	ST	M27512	DIP	28	Not use adapter
ST	M2764	DIP	28	Not use adapter	ST	M2764A	DIP	28	Not use adapter
ST	M27C1000	DIP	32	Not use adapter	ST	M27C1001	DIP	32	Not use adapter

ST	M27C1024	DIP	40	Not use adapter	ST	M27C1024	PLCC	44	PA44-48U
ST	M27C160	DIP	42	Not use adapter	ST	M27C160	PLCC	44	PA44-48U
ST	M27C2001	DIP	32	Not use adapter	ST	M27C2001	PLCC	32	PA32PL32D
ST	M27C202	DIP	40	Not use adapter	ST	M27C202	PLCC	44	PA44-48U
ST	M27C256B	DIP	28	Not use adapter	ST	M27C320	TSOP	48	PA48TS48D
ST	M27C322	DIP	42	Not use adapter	ST	M27C4001	DIP	32	Not use adapter
ST	M27C4002	DIP	40	Not use adapter	ST	M27C4002	PLCC	44	PA44-48U
ST	M27C405	DIP	32	Not use adapter	ST	M27C512	DIP	28	Not use adapter
ST	M27C512	PLCC	32	PA32-28	ST	M27C512	PLCC	32	PA32-28
ST	M27C512	PLCC	32	PA32-28	ST	M27C512	PLCC	32	PA32-28
ST	M27C512	PLCC	32	PA32-28	ST	M27C512	PLCC	32	PA32-28
ST	M27C64A	DIP	28	Not use adapter	ST	M27C800	PLCC	44	PA44-48U
ST	M27C800	DIP	42	Not use adapter	ST	M27C801	DIP	32	Not use adapter
ST	M27V101	DIP	32	Not use adapter	ST	M27V160	DIP	42	Not use adapter
ST	M27V201	DIP	32	Not use adapter	ST	M27V256	DIP	28	Not use adapter
ST	M27V322	DIP	42	Not use adapter	ST	M27V402	DIP	40	Not use adapter
ST	M27V402	PLCC	44	PA44-48U	ST	M27V800	DIP	42	Not use adapter
ST	M27W101	DIP	32	Not use adapter	ST	M27W102	PLCC	44	PA44-48U
ST	M27W102	DIP	40	Not use adapter	ST	M27W201	DIP	32	Not use adapter
ST	M27W202	PLCC	44	PA44-48U	ST	M27W202	DIP	40	Not use adapter
ST	M27W256B	DIP	28	Not use adapter	ST	M27W322	DIP	42	Not use adapter
ST	M27W401	DIP	32	Not use adapter	ST	M27W402	PLCC	44	PA44-48U
ST	M27W512	DIP	28	Not use adapter	ST	M27W800	PLCC	44	PA44-48U
ST	M27W800	DIP	42	Not use adapter	ST	M27W801	DIP	32	Not use adapter
ST	M28C64	DIP	28	Not use adapter	ST	M28F101	PLCC	32	Not use adapter
ST	M28F101	DIP	32	Not use adapter	ST	M28F201	PLCC	32	Not use adapter
ST	M28F201	DIP	32	Not use adapter	ST	M28F256	DIP	32	Not use adapter
ST	M28F256A	DIP	32	Not use adapter	ST	M28F512	DIP	32	Not use adapter
ST	M28W160B	TSOP	48	PA48TS48D	ST	M28W160BB	TSOP	48	PA48TS48D
ST	M28W160BT	TSOP	48	PA48TS48D	ST	M28W160CB	TSOP	48	PA48TS48D
ST	M28W160CT	TSOP	48	PA48TS48D	ST	M28W160T	TSOP	48	PA48TS48D
ST	M28W320BB	TSOP	48	PA48TS48D	ST	M28W320BT	TSOP	48	PA48TS48D
ST	M28W320CB	TSOP	48	PA48TS48D	ST	M28W320CT	TSOP	48	PA48TS48D
ST	M28W640ECB	TSOP	48	PA48TS48D	ST	M28W640ECT	TSOP	48	PA48TS48D
ST	M28W640FSB-ZA	EBGA	64	PA64EBGA48D	ST	M28W640FST-ZA	EBGA	64	PA64EBGA48D
ST	M28W800CB	TSOP	48	PA48TS48D	ST	M28W800CT	TSOP	48	PA48TS48D
ST	M29DW323DB	TSOP	48	PA48TS48D	ST	M29DW323DT	TSOP	48	PA48TS48D
ST	M29F002BB	DIP	32	Not use adapter	ST	M29F002BNT	DIP	32	Not use adapter
ST	M29F002BT	DIP	32	Not use adapter	ST	M29F010B	DIP	32	Not use adapter
ST	M29F016B	SOP	44	PA44SO44D	ST	M29F016B	TSOP	40	PA40TS40D
ST	M29F016D	SOP	44	PA44SO44D	ST	M29F016D	TSOP	40	PA40TS40D
ST	M29F032D	TSOP	40	PA40TS40D	ST	M29F040	DIP	32	Not use adapter
ST	M29F040B	DIP	32	Not use adapter	ST	M29F040B	PLCC	32	PA32PL32D
ST	M29F080A	TSOP	40	PA40TS40D	ST	M29F160BB	TSOP	48	PA48TS48D
ST	M29F160BT	TSOP	48	PA48TS48D	ST	M29F800AB	SOP	44	PA44SO44D
ST	M29F800AB	TSOP	48	PA48TS48D	ST	M29F800AT	TSOP	48	PA48TS48D
ST	M29F800AT	SOP	44	PA44SO44D	ST	M29F800DB	TSOP	48	PA48TS48D
ST	M29F800DB	SOP	44	PA44SO44D	ST	M29F800DT	SOP	44	PA44SO44D
ST	M29F800DT	TSOP	48	PA48TS48D	ST	M29KW016E	TSOP	48	PA48TS48D1
ST	M29KW032E	TSOP	48	PA48TS48D1	ST	M29KW064E	TSOP	48	PA48TS48D1
ST	M29W004BB	TSOP	40	PA40TS40D	ST	M29W004BT	TSOP	40	PA40TS40D
ST	M29W008AB	TSOP	40	PA40TS40D	ST	M29W008AT	TSOP	40	PA40TS40D
ST	M29W010B	DIP	32	Not use adapter	ST	M29W017D	TSOP	40	PA40TS40D
ST	M29W022BB	PLCC	32	PA32PL32D	ST	M29W022BT	PLCC	32	PA32PL32D
ST	M29W128FH	TSOP	56	PA56TS48DB	ST	M29W128FL	TSOP	56	PA56TS48DB
ST	M29W160DB	TSOP	48	PA48TS48D	ST	M29W160DT	TSOP	48	PA48TS48D
ST	M29W160EB	TSOP	48	PA48TS48D	ST	M29W160ET	TSOP	48	PA48TS48D
ST	M29W200BB	SOP	44	PA44SO44D	ST	M29W200BB	TSOP	48	PA48TS48D
ST	M29W200BT	SOP	44	PA44SO44D	ST	M29W200BT	TSOP	48	PA48TS48D
ST	M29W320DB	TSOP	48	PA48TS48D	ST	M29W320DT	TSOP	48	PA48TS48D
ST	M29W320EB	TSOP	48	PA48TS48D	ST	M29W320ET	TSOP	48	PA48TS48D
ST	M29W400BB	TSOP	48	PA48TS48D	ST	M29W400BT	TSOP	48	PA48TS48D
ST	M29W400DB	TSOP	48	PA48TS48D	ST	M29W400DT	TSOP	48	PA48TS48D
ST	M29W512B	PLCC	32	PA32PL32D	ST	M29W640DB	TSOP	48	PA48TS48D
ST	M29W640DT	TSOP	48	PA48TS48D	ST	M29W641D	TSOP	48	PA48TS48D
ST	M29W800AB	SOP	44	PA44SO44D	ST	M29W800AB	TSOP	48	PA48TS48D
ST	M29W800AT	TSOP	48	PA48TS48D	ST	M29W800AT	SOP	44	PA44SO44D
ST	M29W800DB	TSOP	48	PA48TS48D	ST	M29W800DB	SOP	44	PA44SO44D
ST	M29W800DT	TSOP	48	PA48TS48D	ST	M29W800DT	SOP	44	PA44SO44D
ST	M30LW128D	TSOP	56	PA56TS48D-B6-YAM	ST	M30LW128D	EBGA	64	PA64EBGA48D
ST	M36A0W5030B0	BGA	66	PA66BGA48DB	ST	M36A0W5030T0	BGA	66	PA66BGA48DB
ST	M36WWT6650B0	BGA	88	PA88BGA48DA-YO-8X10	ST	M36WWT6650D0	BGA	88	PA88BGA48DA-YO-8X10
ST	M36WWT6650T0	BGA	88	PA88BGA48DA-YO-8X10	ST	M45PE10VMN	SOP	8	PA16SO16D-EO-150

ST	M45PE10VMP	MLP	8	PA8SON8D	ST	M48T12	DIP	24	Not use adapter
ST	M48T35AV	DIP	28	Not use adapter	ST	M48T35AY	DIP	28	Not use adapter
ST	M48T35V	DIP	28	Not use adapter	ST	M48T35Y	DIP	28	Not use adapter
ST	M48T58	DIP	28	Not use adapter	ST	M48T58Y	DIP	28	Not use adapter
ST	M50FLW080A	TSOP	40	PA40TS40D	ST	M50FLW080B	TSOP	40	PA40TS40D
ST	M50FW016	TSOP	40	PA40TS40D	ST	M50FW020	PLCC	32	PA32PL32D
ST	M50FW040	PLCC	32	PA32PL32D	ST	M50FW040	TSOP	40	PA40TS40D
ST	M50FW080	PLCC	32	PA32PL32D	ST	M50FW080	TSOP	40	PA40TS40D
ST	M50LPW020	PLCC	32	PA32PL32D	ST	M50LPW040	PLCC	32	PA32PL32D
ST	M50LPW040	TSOP	40	PA40TS40D	ST	M50LPW080	PLCC	32	PA32PL32D
ST	M50LPW080	TSOP	40	PA40TS40D	ST	M50LPW116	TSOP	40	PA40TS40D
ST	M58LW032A	TSOP	56	PA56TS48D-B6-YAM	ST	M58LW032C	TSOP	56	PA56TS48D-B6-YAM
ST	M58LW032D	TSOP	56	PA56TS48D-B6-YAM	ST	M58LW064D	TSOP	56	PA56TS48D-B6-YAM
ST	M58LW064D-ZA	EBGA	64	PA64EBGA48D	ST	M72DW54003BB	BGA	73	PA73BGA48DC-YO-8X11.6
ST	M72DW54003TB	BGA	73	PA73BGA48DC-YO-8X11.6	ST	M72DW64000B	BGA	73	PA73BGA48DC-YO-8X11.6
ST	M87C257	DIP	28	Not use adapter	ST	M9306	DIP	8	Not use adapter
ST	M9346	DIP	8	Not use adapter	ST	M93C06	DIP	8	Not use adapter
ST	M93C46	DIP	8	Not use adapter	ST	M93C46-R	DIP	8	Not use adapter
ST	M93C46-W	DIP	8	Not use adapter	ST	M93C56	DIP	8	Not use adapter
ST	M93C66	DIP	8	Not use adapter	ST	M93C76	DIP	8	Not use adapter
ST	M93C86	DIP	8	Not use adapter	ST	M95010/W	DIP	8	Not use adapter
ST	M95010R	DIP	8	Not use adapter	ST	M95020/W	DIP	8	Not use adapter
ST	M95020R	DIP	8	Not use adapter	ST	M95040/W	DIP	8	Not use adapter
ST	M95040R	DIP	8	Not use adapter	ST	M95080/V/W	DIP	8	Not use adapter
ST	M95080/V/W	SOIC	8	PA16SO16D-EO-150	ST	M95080R	DIP	8	Not use adapter
ST	M95128/V/W	DIP	8	Not use adapter	ST	M95128/V/W	SOIC	8	PA16SO16D-EO-150
ST	M95160/V/W	DIP	8	Not use adapter	ST	M95160/V/W	SOIC	8	PA16SO16D-EO-150
ST	M95160R	DIP	8	Not use adapter	ST	M95256/V/W	DIP	8	Not use adapter
ST	M95256/V/W	SOIC	8	PA16SO16D-EO-150	ST	M95320/V/W	DIP	8	Not use adapter
ST	M95320/V/W	SOIC	8	PA16SO16D-EO-150	ST	M95320R	DIP	8	Not use adapter
ST	M95640/V/W	DIP	8	Not use adapter	ST	M95640/V/W	SOIC	8	PA16SO16D-EO-150
ST	M95640R	DIP	8	Not use adapter	ST	MK48T02	DIP	24	Not use adapter
ST	MK48T08	DIP	28	Not use adapter	ST	MK48T12	DIP	24	Not use adapter
ST	MK48T18	DIP	28	Not use adapter	ST	MK48Z02	DIP	24	Not use adapter
ST	MK48Z08	DIP	28	Not use adapter	ST	MK48Z09	DIP	28	Not use adapter
ST	MK48Z12	DIP	24	Not use adapter	ST	MK48Z18	DIP	28	Not use adapter
ST	MK48Z19	DIP	28	Not use adapter	ST	NAND128W3A	TSOP	48	PA48TS48D
ST	NAND256W3A	TSOP	48	PA48TS48D	ST	NAND512W3A	TSOP	48	PA48TS48D
ST	ST24C02	DIP	8	Not use adapter	ST	ST24C02R	DIP	8	Not use adapter
ST	ST24W02	DIP	8	Not use adapter	ST	ST25C02	DIP	8	Not use adapter
ST	ST25W02	DIP	8	Not use adapter	ST	ST27128A	DIP	28	Not use adapter
ST	ST27256	DIP	28	Not use adapter	ST	ST2764A	DIP	28	Not use adapter
ST	ST27C256	DIP	28	Not use adapter	ST	ST72F260G1B	SDIP	32	PA-MACH2
ST	ST72F260G1M	SOIC	28	PA28SO28D-08	ST	ST72F260G2B	SDIP	32	PA-MACH2
ST	ST72F260G2M	SOIC	28	PA28SO28D-08	ST	ST72F262G1B	SDIP	32	PA-MACH2
ST	ST72F262G1M	SOIC	28	PA28SO28D-08	ST	ST72F262G2B	SDIP	32	PA-MACH2
ST	ST72F262G2M	SOIC	28	PA28SO28D-08	ST	ST72F264G1B	SDIP	32	PA-MACH2
ST	ST72F264G1M	SOIC	28	PA28SO28D-08	ST	ST72F264G2B	SDIP	32	PA-MACH2
ST	ST72F264G2M	SOIC	28	PA28SO28D-08	ST	ST93C46A/C/T	DIP	8	Not use adapter
ST	ST93C47C/T	DIP	8	Not use adapter	ST	ST93C56/C	DIP	8	Not use adapter
ST	ST93C57C	DIP	8	Not use adapter	ST	TS27C256	DIP	28	Not use adapter
ST	TS27C64	DIP	28	Not use adapter	ST	TS27C64A	DIP	28	Not use adapter
ST	TS28C16A	DIP	24	Not use adapter	ST	TS28C17A	DIP	28	Not use adapter
ST	TS28C64	DIP	28	Not use adapter	SYNCMOS	F29C51001B	DIP	32	Not use adapter
SYNCMOS	F29C51001T	DIP	32	Not use adapter	SYNCMOS	F29C51002B	DIP	32	Not use adapter
SYNCMOS	F29C51002T	DIP	32	Not use adapter	SYNCMOS	F29C51004B	DIP	32	Not use adapter
SYNCMOS	F29C51004T	DIP	32	Not use adapter	SYNCMOS	SM8951	PLCC	44	PA44-48U
SYNCMOS	SM8951	DIP	40	Not use adapter	SYNCMOS	SM89516	DIP	40	Not use adapter
SYNCMOS	SM89516	PLCC	44	PA44-48U	SYNCMOS	SM89516	QFP	44	PA44QF44D
SYNCMOS	SM8951A	PLCC	44	PA44-48U	SYNCMOS	SM8951A	DIP	40	Not use adapter
SYNCMOS	SM8951A	QFP	44	PA44QF44D	SYNCMOS	SM8952	PLCC	44	PA44-48U
SYNCMOS	SM8952	DIP	40	Not use adapter	SYNCMOS	SM8952A	DIP	40	Not use adapter
SYNCMOS	SM8952A	PLCC	44	PA44-48U	SYNCMOS	SM8952A	QFP	44	PA44QF44D
SYNCMOS	SM8954	DIP	40	Not use adapter	SYNCMOS	SM8954	PLCC	44	PA44-48U
SYNCMOS	SM8958	PLCC	44	PA44-48U	SYNCMOS	SM8958	DIP	40	Not use adapter
SYNERTEK	SY2716	DIP	24	Not use adapter	TELECHIP	TCC763H309-A	BGA	144	PA144BG48D
TELECHIP	TCC764H309-A	BGA	144	PA144BG48D	TELECHIP	TCC766H303-A	BGA	232	PA232BG48D
TELECHIP	TCC767H301-A	BGA	225	PA225BG48D	TEXAS	SMJ2516	DIP	24	Not use adapter
TEXAS	SMJ27C256	DIP	28	Not use adapter	TEXAS	SMJ27C512	DIP	28	Not use adapter
TEXAS	TMS2516JL	DIP	24	Not use adapter	TEXAS	TMS27128	DIP	28	Not use adapter
TEXAS	TMS2732A	DIP	24	Not use adapter	TEXAS	TMS2764	DIP	28	Not use adapter
TEXAS	TMS27C010	DIP	32	Not use adapter	TEXAS	TMS27C010A	DIP	32	Not use adapter
TEXAS	TMS27C020	DIP	32	Not use adapter	TEXAS	TMS27C040	DIP	32	Not use adapter
TEXAS	TMS27C128	DIP	28	Not use adapter	TEXAS	TMS27C210	DIP	40	Not use adapter

TEXAS	TMS27C210	PLCC	44	PA44-48U	TEXAS	TMS27C210A	DIP	40	Not use adapter
TEXAS	TMS27C210A	PLCC	44	PA44-48U	TEXAS	TMS27C240	DIP	40	Not use adapter
TEXAS	TMS27C240	PLCC	44	PA44-48U	TEXAS	TMS27C256	DIP	28	Not use adapter
TEXAS	TMS27C32	DIP	24	Not use adapter	TEXAS	TMS27C512	DIP	28	Not use adapter
TEXAS	TMS27C64	DIP	28	Not use adapter	TEXAS	TMS27P32A	DIP	24	Not use adapter
TEXAS	TMS27P64	DIP	28	Not use adapter	TEXAS	TMS27PC010	DIP	32	Not use adapter
TEXAS	TMS27PC128	DIP	28	Not use adapter	TEXAS	TMS27PC210	PLCC	44	PA44-48U
TEXAS	TMS27PC210	DIP	40	Not use adapter	TEXAS	TMS27PC256	DIP	28	Not use adapter
TEXAS	TMS27PC32	DIP	24	Not use adapter	TEXAS	TMS27PC512	DIP	28	Not use adapter
TEXAS	TMS27PC64	DIP	28	Not use adapter	TEXAS	TMS28C64	DIP	28	Not use adapter
TOSHIBA	TC531000CP	DIP	28	Not use adapter	TOSHIBA	TC531001CF	SOP	32	PA44SO44D
TOSHIBA	TC531001CP	DIP	32	Not use adapter	TOSHIBA	TC541000J	DIP	32	Not use adapter
TOSHIBA	TC541000P	DIP	32	Not use adapter	TOSHIBA	TC541001J	DIP	32	Not use adapter
TOSHIBA	TC541001P	DIP	32	Not use adapter	TOSHIBA	TC54256AF	DIP	28	Not use adapter
TOSHIBA	TC54256AP	DIP	28	Not use adapter	TOSHIBA	TC544000P	DIP	32	Not use adapter
TOSHIBA	TC54512AP	DIP	28	Not use adapter	TOSHIBA	TC54H1024P	DIP	40	Not use adapter
TOSHIBA	TC54H1024P	PLCC	44	PA44-48U	TOSHIBA	TC571000AD	DIP	32	Not use adapter
TOSHIBA	TC571000D	DIP	32	Not use adapter	TOSHIBA	TC571001AD	DIP	32	Not use adapter
TOSHIBA	TC571001D	DIP	32	Not use adapter	TOSHIBA	TC571024D	DIP	40	Not use adapter
TOSHIBA	TC571024D	PLCC	44	PA44-48U	TOSHIBA	TC57256	DIP	28	Not use adapter
TOSHIBA	TC57256AD	DIP	28	Not use adapter	TOSHIBA	TC57256ADI	DIP	28	Not use adapter
TOSHIBA	TC57256D	DIP	28	Not use adapter	TOSHIBA	TC574000D	DIP	32	Not use adapter
TOSHIBA	TC574000DI	DIP	32	Not use adapter	TOSHIBA	TC574096D	DIP	40	Not use adapter
TOSHIBA	TC574096D	PLCC	44	PA44-48U	TOSHIBA	TC574200D	DIP	40	Not use adapter
TOSHIBA	TC57512AD	DIP	28	Not use adapter	TOSHIBA	TC578200D	DIP	42	Not use adapter
TOSHIBA	TC57H1000AD	DIP	32	Not use adapter	TOSHIBA	TC57H1001AD	DIP	32	Not use adapter
TOSHIBA	TC57H1024AD	PLCC	44	PA44-48U	TOSHIBA	TC57H1024AD	DIP	40	Not use adapter
TOSHIBA	TC57H1024D	DIP	40	Not use adapter	TOSHIBA	TC57H1024D	PLCC	44	PA44-48U
TOSHIBA	TC57H1025AD	DIP	40	Not use adapter	TOSHIBA	TC57H1025AD	PLCC	44	PA44-48U
TOSHIBA	TC57H256D	DIP	28	Not use adapter	TOSHIBA	TC58DVG02A1FT00	TSOP	48	PA48TS48D
TOSHIBA	TC58FVB160FT	TSOP	48	PA48TS48D	TOSHIBA	TC58FVB321FT	TSOP	48	PA48TS48D
TOSHIBA	TC58FVB400FT	TSOP	48	PA48TS48D	TOSHIBA	TC58FVB641FT	TSOP	48	PA48TS48D
TOSHIBA	TC58FVB800FT	TSOP	48	PA48TS48D	TOSHIBA	TC58FVM5B2A	TSOP	48	PA48TS48D
TOSHIBA	TC58FVM5B3A	TSOP	48	PA48TS48D	TOSHIBA	TC58FVM5T2A	TSOP	48	PA48TS48D
TOSHIBA	TC58FVM5T3A	TSOP	48	PA48TS48D	TOSHIBA	TC58FVT160FT	TSOP	48	PA48TS48D
TOSHIBA	TC58FVT321FT	TSOP	48	PA48TS48D	TOSHIBA	TC58FVT400FT	TSOP	48	PA48TS48D
TOSHIBA	TC58FVT641FT	TSOP	48	PA48TS48D	TOSHIBA	TC58FT800FT	TSOP	48	PA48TS48D
TOSHIBA	TH50VPF5584ADSB	BGA	73	PA73BGA48DE-TO-7X10	TOSHIBA	TH50VPF5585ADSB	BGA	73	PA73BGA48DE-TO-7X10
TOSHIBA	TH50VPF5682CDSB	BGA	73	PA73BGA48DE-TO-7X10	TOSHIBA	TH50VPF5683CDSB	BGA	73	PA73BGA48DE-TO-7X10
TOSHIBA	TH50VPF6782AASB	BGA	69	PA69BGA48DK-TO-9X12	TOSHIBA	TH50VPF6783AASB	BGA	69	PA69BGA48DK-TO-9X12
TOSHIBA	TH50VPF6784AASB	BGA	69	PA69BGA48DK-TO-9X12	TOSHIBA	TH50VSF2580A	BGA	69	PA69BGA48DF
TOSHIBA	TH50VSF2581A	BGA	69	PA69BGA48DF	TOSHIBA	TH50VSF3680A	BGA	69	PA69BGA48DF
TOSHIBA	TH50VSF3681A	BGA	69	PA69BGA48DF	TOSHIBA	TH50VSF3682A	BGA	69	PA69BGA48DF
TOSHIBA	TH50VSF3683A	BGA	69	PA69BGA48DF	TOSHIBA	TH50VSF4682AASB	BGA	69	PA69BGA48DI
TOSHIBA	TH50VSF4682BCSB	BGA	69	PA69BGA48DI	TOSHIBA	TH50VSF4683AASB	BGA	69	PA69BGA48DI
TOSHIBA	TH50VSF4683BCSB	BGA	69	PA69BGA48DI	TOSHIBA	THPV057022BCBB	BGA	69	PA69BGA48DM
TOSHIBA	THPV057023BCBB	BGA	69	PA69BGA48DM	TOSHIBA	THPV067203BABD	BGA	107	HA107BG48DF
TOSHIBA	THPV068022AABB	BGA	73	PA73BGA48DF	TOSHIBA	THPV068023AABB	BGA	73	PA73BGA48DF
TOSHIBA	THPV357022BCBB	BGA	85	PA85BGA48DA-TO-7X10	TOSHIBA	THPV357023BCBB	BGA	85	PA85BGA48DA-TO-7X10
TOSHIBA	TMM24128A	DIP	28	Not use adapter	TOSHIBA	TMM24256A	DIP	28	Not use adapter
TOSHIBA	TMM24256B	DIP	28	Not use adapter	TOSHIBA	TMM24512	DIP	28	Not use adapter
TOSHIBA	TMM24512A	DIP	28	Not use adapter	TOSHIBA	TMM2464A	DIP	28	Not use adapter
TOSHIBA	TMM27128	DIP	28	Not use adapter	TOSHIBA	TMM27128A	DIP	28	Not use adapter
TOSHIBA	TMM27128AD	DIP	28	Not use adapter	TOSHIBA	TMM27128ADI	DIP	28	Not use adapter
TOSHIBA	TMM27128D	DIP	28	Not use adapter	TOSHIBA	TMM27128DI	DIP	28	Not use adapter
TOSHIBA	TMM27256	DIP	28	Not use adapter	TOSHIBA	TMM27256A	DIP	28	Not use adapter
TOSHIBA	TMM27256AD	DIP	28	Not use adapter	TOSHIBA	TMM27256ADI	DIP	28	Not use adapter
TOSHIBA	TMM27256BD	DIP	28	Not use adapter	TOSHIBA	TMM27256BDI	DIP	28	Not use adapter
TOSHIBA	TMM27256D	DIP	28	Not use adapter	TOSHIBA	TMM27256DI	DIP	28	Not use adapter
TOSHIBA	TMM2732	DIP	24	Not use adapter	TOSHIBA	TMM27512	DIP	28	Not use adapter
TOSHIBA	TMM27512AD	DIP	28	Not use adapter	TOSHIBA	TMM27512ADI	DIP	28	Not use adapter
TOSHIBA	TMM27512D	DIP	28	Not use adapter	TOSHIBA	TMM27512DI	DIP	28	Not use adapter
TOSHIBA	TMM2764	DIP	28	Not use adapter	TOSHIBA	TMM2764A	DIP	28	Not use adapter
TOSHIBA	TMM2764AD	DIP	28	Not use adapter	TOSHIBA	TMM2764ADI	DIP	28	Not use adapter
TOSHIBA	TMM2764D	DIP	28	Not use adapter	TOSHIBA	TMM2764DI	DIP	28	Not use adapter
TOSHIBA	TMP87PH40	DIP	28	Not use adapter	TOSHIBA	TMP87PH46N	DIP	28	Not use adapter
TOSHIBA	TMP87PH808N	DIP	28	Not use adapter	TOSHIBA	TMP88PS49F	DIP	32	Not use adapter
TOSHIBA	TV00670002AABB	BGA	73	PA73BGA48DI	TOSHIBA	TV00678003AABD	BGA	107	HA107BG48DE
TOSHIBA	TV006C002SAABB	BGA	73	PA7064/96-84LC	VANTIS	PALCE16V8H	DIP	20	Not use adapter
VANTIS	PALCE16V8H	SOIC	20	PA20SO2006-200/PA20SO20D	VANTIS	PALCE16V8H	PLCC	20	PA20LC20D
VANTIS	PALCE16V8H as 10H8	DIP	20	Not use adapter	VANTIS	PALCE16V8H as 10H8	SOIC	20	PA20SO2006-200/PA20SO20D
VANTIS	PALCE16V8H as 10H8	PLCC	20	PA20LC20D	VANTIS	PALCE16V8H as 10L8	DIP	20	Not use adapter
VANTIS	PALCE16V8H as 10L8	SOIC	20	PA20SO2006-200/PA20SO20D	VANTIS	PALCE16V8H as 10L8	PLCC	20	PA20LC20D
VANTIS	PALCE16V8H as 10P8	DIP	20	Not use adapter	VANTIS	PALCE16V8H as 10P8	PLCC	20	PA20LC20D

VANTIS	PALCE26V12H/4-10	PLCC	28	PA28PL28D	VANTIS	PALCE29M16H	DIP	24	Not use adapter
VANTIS	PALCE29M16H	PLCC	28	PA28PL28D	VANTIS	PALCE29MA16H	DIP	24	Not use adapter
VANTIS	PALCE29MA16H	PLCC	28	PA28PL28D	VANTIS	PALCE610H	DIP	24	Not use adapter
VANTIS	PALCE610H	PLCC	28	PA28PL28D	VANTIS	PALLV22V10	DIP	24	Not use adapter
VANTIS	PALLV22V10	PLCC	28	PA28PL28D	VANTIS	PALLV22V10Z	DIP	24	Not use adapter
VANTIS	PALLV22V10Z	PLCC	28	PA28PL28D	VLSI	VT27C256	DIP	28	Not use adapter
VLSI	VT27C512	DIP	28	Not use adapter	VLSI	VT27C64	DIP	28	Not use adapter
WAFERSCALE	57C49	DIP	24	Not use adapter	WAFERSCALE	57C49B	DIP	24	Not use adapter
WAFERSCALE	57C49C	DIP	24	Not use adapter	WAFERSCALE	WS27C010L	DIP	32	Not use adapter
WAFERSCALE	WS27C040L	DIP	32	Not use adapter	WAFERSCALE	WS27C128F	DIP	28	Not use adapter
WAFERSCALE	WS27C128F	PLCC	32	PA32-28	WAFERSCALE	WS27C210L	PLCC	44	PA44-48U
WAFERSCALE	WS27C210L	DIP	40	Not use adapter	WAFERSCALE	WS27C256F	DIP	28	Not use adapter
WAFERSCALE	WS27C256L	DIP	28	Not use adapter	WAFERSCALE	WS27C512F	DIP	28	Not use adapter
WAFERSCALE	WS27C512L	DIP	28	Not use adapter	WAFERSCALE	WS27C64F	DIP	28	Not use adapter
WAFERSCALE	WS27C64F	PLCC	32	PA32-28	WAFERSCALE	WS27C64L	DIP	28	Not use adapter
WAFERSCALE	WS27C64L	PLCC	32	PA32-28	WAFERSCALE	WS57C128F	DIP	28	Not use adapter
WAFERSCALE	WS57C256F	DIP	28	Not use adapter	WAFERSCALE	WS57C512F	DIP	28	Not use adapter
WAFERSCALE	WS57C64F	DIP	28	Not use adapter	WHITE	WE128K8	DIP	32	Not use adapter
WHITE	WE256K8	DIP	32	Not use adapter	WHITE	WE512K8	DIP	32	Not use adapter
WINBOND	W19B320AB	TSOP	48	PA48TS48D	WINBOND	W19B320AT	TSOP	48	PA48TS48D
WINBOND	W19L320SBT	TSOP	48	PA48TS48D	WINBOND	W19L320STT	TSOP	48	PA48TS48D
WINBOND	W25P10VSN1	SOIC	8	PA16SO16D-EO-150	WINBOND	W25P10VSNIG	SOIC	8	PA16SO16D-EO-150
WINBOND	W25P16VSSFIG	SOIC	16	PA68-40B	WINBOND	W25P16VSSIG	SOIC	8	PA20SO2006-200/PA20SO20D
WINBOND	W25P20VSN1	SOIC	8	PA16SO16D-EO-150	WINBOND	W25P20VSNIG	SOIC	8	PA16SO16D-EO-150
WINBOND	W25P32VSSFIG	SOIC	16	PA68-40B	WINBOND	W25P40VSN1	SOIC	8	PA16SO16D-EO-150
WINBOND	W25P40VSNIG	SOIC	8	PA16SO16D-EO-150	WINBOND	W25P80VSSIG	SOIC	8	PA20SO2006-200/PA20SO20D
WINBOND	W27C010	DIP	32	Not use adapter	WINBOND	W27C512	DIP	28	Not use adapter
WINBOND	W27C512	PLCC	32	PA32-28	WINBOND	W27E010	DIP	32	Not use adapter
WINBOND	W27E020	DIP	32	Not use adapter	WINBOND	W27E040	DIP	32	Not use adapter
WINBOND	W27E256	DIP	28	Not use adapter	WINBOND	W27E257	DIP	28	Not use adapter
WINBOND	W27E4096	PLCC	44	PA44-48U	WINBOND	W27E4096	DIP	40	Not use adapter
WINBOND	W27E512	DIP	28	Not use adapter	WINBOND	W27F010	DIP	32	Not use adapter
WINBOND	W27F256	DIP	28	Not use adapter	WINBOND	W27F512	DIP	28	Not use adapter
WINBOND	W27L010	DIP	32	Not use adapter	WINBOND	W27L02	DIP	32	Not use adapter
WINBOND	W27L02P	PLCC	32	PA32PL32D	WINBOND	W27L02Q	TSOP	32	PA32TS20/PA32TS32D-20
WINBOND	W29C011	DIP	32	Not use adapter	WINBOND	W29C011	PLCC	32	PA32PL32D
WINBOND	W29C011A	DIP	32	Not use adapter	WINBOND	W29C011A	PLCC	32	PA32PL32D
WINBOND	W29C020	DIP	32	Not use adapter	WINBOND	W29C020P	PLCC	32	PA32PL32D
WINBOND	W29C020T	TSOP	32	PA32TS20/PA32TS32D-20	WINBOND	W29C040	DIP	32	Not use adapter
WINBOND	W29C040P	PLCC	32	PA32PL32D	WINBOND	W29C040T	TSOP	32	PA32TS20/PA32TS32D-20
WINBOND	W29C101	PLCC	44	PA44-48U	WINBOND	W29C101	DIP	40	Not use adapter
WINBOND	W29EE010	DIP	32	Not use adapter	WINBOND	W29EE011	DIP	32	Not use adapter
WINBOND	W29EE021	DIP	32	Not use adapter	WINBOND	W29EE512	DIP	32	Not use adapter
WINBOND	W29EE512	PLCC	32	PA32PL32D	WINBOND	W29F102	PLCC	44	PA44-48U
WINBOND	W39L020P	PLCC	32	PA32PL32D	WINBOND	W39L040P	PLCC	32	PA32PL32D
WINBOND	W39V040FA	PLCC	32	PA32PL32D	WINBOND	W49F002U	DIP	32	Not use adapter
WINBOND	W49F020	DIP	32	Not use adapter	WINBOND	W49F102	TSOP	40	PA40TS14-OT
WINBOND	W49L102	TSOP	40	PA40TS14-OT	WINBOND	W49V002	PLCC	32	PA32PL32D
WINBOND	W49V002	DIP	32	Not use adapter	WINBOND	W77E516	DIP	40	Not use adapter
WINBOND	W77E516F	QFP	44	PA44QF44D	WINBOND	W77E516P	PLCC	44	PA44-48U
WINBOND	W77E532-40	DIP	40	Not use adapter	WINBOND	W77E532A40DL	DIP	40	Not use adapter
WINBOND	W77E532A40FL	QFP	44	PA44QF44D	WINBOND	W77E532A40PL	PLCC	44	PA44-48U
WINBOND	W77E532F-40	QFP	44	PA44QF44D	WINBOND	W77E532P-40	PLCC	44	PA44-48U
WINBOND	W77E58	DIP	40	Not use adapter	WINBOND	W77E58F	QFP	44	PA44QF44D
WINBOND	W77E58P	PLCC	44	PA44-48U	WINBOND	W77LE532-25	DIP	40	Not use adapter
WINBOND	W77LE532A25DL	DIP	40	Not use adapter	WINBOND	W77LE532A25FL	QFP	44	PA44QF44D
WINBOND	W77LE532A25PL	PLCC	44	PA44-48U	WINBOND	W77LE532F-25	QFP	44	PA44QF44D
WINBOND	W77LE532P-25	PLCC	44	PA44-48U	WINBOND	W77LE58	DIP	40	Not use adapter
WINBOND	W77LE58F	QFP	44	PA44QF44D	WINBOND	W77LE58P	PLCC	44	PA44-48U
WINBOND	W78E51	DIP	40	Not use adapter	WINBOND	W78E516	DIP	40	Not use adapter
WINBOND	W78E516B	DIP	40	Not use adapter	WINBOND	W78E516BF	QFP	44	PA44QF44D
WINBOND	W78E516BP	PLCC	44	PA44-48U	WINBOND	W78E516F	QFP	44	PA44QF44D
WINBOND	W78E516P	PLCC	44	PA44-48U	WINBOND	W78E51B	DIP	40	Not use adapter
WINBOND	W78E51BF	QFP	44	PA44QF44D	WINBOND	W78E51BP	PLCC	44	PA44-48U
WINBOND	W78E51C	DIP	40	Not use adapter	WINBOND	W78E51CF	QFP	44	PA44QF44D
WINBOND	W78E51CP	PLCC	44	PA44-48U	WINBOND	W78E51F	QFP	44	PA44QF44D
WINBOND	W78E51P	PLCC	44	PA44-48U	WINBOND	W78E52	DIP	40	Not use adapter
WINBOND	W78E52B	DIP	40	Not use adapter	WINBOND	W78E52BF	QFP	44	PA44QF44D
WINBOND	W78E52BP	PLCC	44	PA44-48U	WINBOND	W78E52C	DIP	40	Not use adapter
WINBOND	W78E52CF	QFP	44	PA44QF44D	WINBOND	W78E52CP	PLCC	44	PA44-48U
WINBOND	W78E52F	QFP	44	PA44QF44D	WINBOND	W78E52P	PLCC	44	PA44-48U
WINBOND	W78E54	DIP	40	Not use adapter	WINBOND	W78E54B	DIP	40	Not use adapter
WINBOND	W78E54BF	QFP	44	PA44QF44D	WINBOND	W78E54BP	PLCC	44	PA44-48U
WINBOND	W78E54C	DIP	40	Not use adapter	WINBOND	W78E54CF	QFP	44	PA44QF44D

WINBOND	W78E54CP	PLCC	44	PA44-48U	WINBOND	W78E54F	QFP	44	PA44QF44D
WINBOND	W78E54P	PLCC	44	PA44-48U	WINBOND	W78E58	DIP	40	Not use adapter
WINBOND	W78E58B	DIP	40	Not use adapter	WINBOND	W78E58BF	QFP	44	PA44QF44D
WINBOND	W78E58BP	PLCC	44	PA44-48U	WINBOND	W78E58F	QFP	44	PA44QF44D
WINBOND	W78E58P	PLCC	44	PA44-48U	WINBOND	W78E62BF	QFP	44	PA44QF44D
WINBOND	W78E62BP	PLCC	44	PA44-48U	WINBOND	W78E65F	QFP	44	PA44QF44D
WINBOND	W78E65P	PLCC	44	PA44-48U	WINBOND	W78ERD2A40DN	DIP	40	Not use adapter
WINBOND	W78ERD2A40FN	QFP	44	PA44QF44D	WINBOND	W78ERD2A40PN	PLCC	44	PA44-48U
WINBOND	W78LE51	DIP	40	Not use adapter	WINBOND	W78LE516	DIP	40	Not use adapter
WINBOND	W78LE516B	DIP	40	Not use adapter	WINBOND	W78LE516BF	QFP	44	PA44QF44D
WINBOND	W78LE516BP	PLCC	44	PA44-48U	WINBOND	W78LE516F	QFP	44	PA44QF44D
WINBOND	W78LE516P	PLCC	44	PA44-48U	WINBOND	W78LE51C	DIP	40	Not use adapter
WINBOND	W78LE51CF	QFP	44	PA44QF44D	WINBOND	W78LE51CP	PLCC	44	PA44-48U
WINBOND	W78LE51F	QFP	44	PA44QF44D	WINBOND	W78LE51P	PLCC	44	PA44-48U
WINBOND	W78LE52	DIP	40	Not use adapter	WINBOND	W78LE52C	DIP	40	Not use adapter
WINBOND	W78LE52CF	QFP	44	PA44QF44D	WINBOND	W78LE52CP	PLCC	44	PA44-48U
WINBOND	W78LE52F	QFP	44	PA44QF44D	WINBOND	W78LE52P	PLCC	44	PA44-48U
WINBOND	W78LE54	DIP	40	Not use adapter	WINBOND	W78LE54C	DIP	40	Not use adapter
WINBOND	W78LE54CF	QFP	44	PA44QF44D	WINBOND	W78LE54CP	PLCC	44	PA44-48U
WINBOND	W78LE54F	QFP	44	PA44QF44D	WINBOND	W78LE54P	PLCC	44	PA44-48U
WINBOND	W78LE58	DIP	40	Not use adapter	WINBOND	W78LE58F	QFP	44	PA44QF44D
WINBOND	W78LE58P	PLCC	44	PA44-48U	WINBOND	W78LE812	DIP	40	Not use adapter
WINBOND	W78LE812F	QFP	44	PA44QF44D	WINBOND	W78LE812P	PLCC	44	PA44-48U
WINBOND	W79E532A40DN	DIP	40	Not use adapter	WINBOND	W79E532A40FN	QFP	44	PA44QF44D
WINBOND	W79E532A40PN	PLCC	44	PA44-48U	WINBOND	W79E632A40DN	DIP	40	Not use adapter
WINBOND	W79E632A40FN	QFP	44	PA44QF44D	WINBOND	W79E632A40PN	PLCC	44	PA44-48U
WINBOND	W79L532A40DN	DIP	40	Not use adapter	WINBOND	W79L532A40FN	QFP	44	PA44QF44D
WINBOND	W79L532A40PN	PLCC	44	PA44-48U	WINBOND	W79L632A40DN	DIP	40	Not use adapter
WINBOND	W79L632A40FN	QFP	44	PA44QF44D	WINBOND	W79L632A40PN	PLCC	44	PA44-48U
XICOR	X2402	DIP	8	Not use adapter	XICOR	X2404	DIP	8	Not use adapter
XICOR	X24164	DIP	8	Not use adapter	XICOR	X24C01	DIP	8	Not use adapter
XICOR	X24C01A	DIP	8	Not use adapter	XICOR	X24C02	DIP	8	Not use adapter
XICOR	X24C04	DIP	8	Not use adapter	XICOR	X24C08	DIP	8	Not use adapter
XICOR	X24C16	DIP	8	Not use adapter	XICOR	X25020	DIP	8	Not use adapter
XICOR	X25021	DIP	8	Not use adapter	XICOR	X25040	DIP	8	Not use adapter
XICOR	X25041	DIP	8	Not use adapter	XICOR	X25057	DIP	8	Not use adapter
XICOR	X25080	DIP	8	Not use adapter	XICOR	X25097	DIP	8	Not use adapter
XICOR	X25128	DIP	8	Not use adapter	XICOR	X25138	DIP	8	Not use adapter
XICOR	X25160	DIP	8	Not use adapter	XICOR	X25170	DIP	8	Not use adapter
XICOR	X25320	DIP	8	Not use adapter	XICOR	X25640	DIP	8	Not use adapter
XICOR	X25642	DIP	8	Not use adapter	XICOR	X25C02	DIP	8	Not use adapter
XICOR	X25F008	DIP	8	Not use adapter	XICOR	X25F016	DIP	8	Not use adapter
XICOR	X25F032	DIP	8	Not use adapter	XICOR	X25F047	DIP	8	Not use adapter
XICOR	X25F064	DIP	8	Not use adapter	XICOR	X25F087	DIP	8	Not use adapter
XICOR	X25F128	DIP	8	Not use adapter	XICOR	X2804A	DIP	24	Not use adapter
XICOR	X2816A	DIP	24	Not use adapter	XICOR	X2816B	DIP	24	Not use adapter
XICOR	X2816C	DIP	24	Not use adapter	XICOR	X28256	DIP	28	Not use adapter
XICOR	X2864A	DIP	28	Not use adapter	XICOR	X2864B	DIP	28	Not use adapter
XICOR	X2864H	DIP	28	Not use adapter	XICOR	X28C010	DIP	32	Not use adapter
XICOR	X28C256	DIP	28	Not use adapter	XICOR	X28C512	DIP	32	Not use adapter
XICOR	X28C513	PLCC	32	PA32PL32D	XICOR	X28C64	DIP	28	Not use adapter
XICOR	X28HC256	DIP	28	Not use adapter	XICOR	X28HC64	DIP	28	Not use adapter
XICOR	X28LC512	DIP	32	Not use adapter	XICOR	X28LC513	PLCC	32	PA32PL32D
XICOR	XM28C010	DIP	32	Not use adapter	XILINX	XC1701	PLCC	44	PA44-48U
XILINX	XC1701	DIP	8	Not use adapter	XILINX	XC1701L	DIP	8	Not use adapter
XILINX	XC1701L	PLCC	44	PA44-48U	XILINX	XC1702L	DIP	8	Not use adapter
XILINX	XC1702L	PLCC	44	PA44-48U	XILINX	XC1704L	DIP	8	Not use adapter
XILINX	XC1704L	PLCC	44	PA44-48U	XILINX	XC17128D	DIP	8	Not use adapter
XILINX	XC17128E	DIP	8	Not use adapter	XILINX	XC17128EL(X)	DIP	8	Not use adapter
XILINX	XC17128L	DIP	8	Not use adapter	XILINX	XC1718D	DIP	8	Not use adapter
XILINX	XC1718L	DIP	8	Not use adapter	XILINX	XC17256D	DIP	8	Not use adapter
XILINX	XC17256E	DIP	8	Not use adapter	XILINX	XC17256EL(X)	DIP	8	Not use adapter
XILINX	XC17256L	DIP	8	Not use adapter	XILINX	XC1736D	DIP	8	Not use adapter
XILINX	XC1736E	DIP	8	Not use adapter	XILINX	XC17512L	DIP	8	Not use adapter
XILINX	XC17512L	PLCC	44	PA44-48U	XILINX	XC17512L	SOIC	20	PA28SO08
XILINX	XC1765D	DIP	8	Not use adapter	XILINX	XC1765E	DIP	8	Not use adapter
XILINX	XC1765EL(X)	DIP	8	Not use adapter	XILINX	XC1765L	DIP	8	Not use adapter
XILINX	XC17S05	DIP	8	Not use adapter	XILINX	XC17S05L	DIP	8	Not use adapter
XILINX	XC17S05XL	DIP	8	Not use adapter	XILINX	XC17S10	DIP	8	Not use adapter
XILINX	XC17S100A	DIP	8	Not use adapter	XILINX	XC17S100A	PLCC	44	PA44-48U
XILINX	XC17S100A	PLCC	20	PA20LC20D	XILINX	XC17S100A	SOIC	20	PA28SO08
XILINX	XC17S100A	QFP	44	PA44QF44D	XILINX	XC17S100L	DIP	8	Not use adapter
XILINX	XC17S100L	SOIC	20	PA28SO08	XILINX	XC17S100XL	DIP	8	Not use adapter
XILINX	XC17S100XL	SOIC	20	PA28SO08	XILINX	XC17S10L	DIP	8	Not use adapter

XILINX	XC17S10XL	DIP	8	Not use adapter	XILINX	XC17S150A	DIP	8	Not use adapter
XILINX	XC17S150A	PLCC	44	PA44-48U	XILINX	XC17S150A	PLCC	20	PA20LC20D
XILINX	XC17S150A	QFP	44	PA44QF44D	XILINX	XC17S150A	SOIC	20	PA28SO08
XILINX	XC17S150L	DIP	8	Not use adapter	XILINX	XC17S150L	SOIC	20	PA28SO08
XILINX	XC17S150XL	DIP	8	Not use adapter	XILINX	XC17S150XL	SOIC	20	PA28SO08
XILINX	XC17S15A	DIP	8	Not use adapter	XILINX	XC17S15A	PLCC	44	PA44-48U
XILINX	XC17S15A	PLCC	20	PA20LC20D	XILINX	XC17S15A	SOIC	20	PA28SO08
XILINX	XC17S15A	QFP	44	PA44QF44D	XILINX	XC17S20	DIP	8	Not use adapter
XILINX	XC17S200A	DIP	8	Not use adapter	XILINX	XC17S200A	PLCC	44	PA44-48U
XILINX	XC17S200A	SOIC	20	PA28SO08	XILINX	XC17S200A	PLCC	20	PA20LC20D
XILINX	XC17S200A	QFP	44	PA44QF44D	XILINX	XC17S20L	DIP	8	Not use adapter
XILINX	XC17S20XL	DIP	8	Not use adapter	XILINX	XC17S30	DIP	8	Not use adapter
XILINX	XC17S30A	PLCC	44	PA44-48U	XILINX	XC17S30A	DIP	8	Not use adapter
XILINX	XC17S30A	QFP	44	PA44QF44D	XILINX	XC17S30A	SOIC	20	PA28SO08
XILINX	XC17S30A	PLCC	20	PA20LC20D	XILINX	XC17S30L	DIP	8	Not use adapter
XILINX	XC17S30XL	DIP	8	Not use adapter	XILINX	XC17S40	DIP	8	Not use adapter
XILINX	XC17S40L	DIP	8	Not use adapter	XILINX	XC17S40XL	DIP	8	Not use adapter
XILINX	XC17S50A	DIP	8	Not use adapter	XILINX	XC17S50A	PLCC	44	PA44-48U
XILINX	XC17S50A	SOIC	20	PA28SO08	XILINX	XC17S50A	PLCC	20	PA20LC20D
XILINX	XC17S50A	QFP	44	PA44QF44D	XILINX	XC17S50L	DIP	8	Not use adapter
XILINX	XC17S50L	SOIC	20	PA28SO08	XILINX	XC17S50XL	DIP	8	Not use adapter
XILINX	XC17S50XL	SOIC	20	PA28SO08	XILINX	XC17V01	DIP	8	Not use adapter
XILINX	XC17V01	PLCC	44	PA44-48U	XILINX	XC17V01	SOIC	20	PA28SO08
XILINX	XC17V01	QFP	44	PA44QF44D	XILINX	XC17V01	PLCC	20	PA20LC20D
XILINX	XC17V02	PLCC	44	PA44-48U	XILINX	XC17V02	DIP	8	Not use adapter
XILINX	XC17V02	QFP	44	PA44QF44D	XILINX	XC17V02	SOIC	20	PA28SO08
XILINX	XC17V02	PLCC	20	PA20LC20D	XILINX	XC17V04	DIP	8	Not use adapter
XILINX	XC17V04	PLCC	44	PA44-48U	XILINX	XC17V04	SOIC	20	PA28SO08
XILINX	XC17V04	PLCC	20	PA20LC20D	XILINX	XC17V04	QFP	44	PA44QF44D
XILINX	XC17V08	PLCC	44	PA44-48U	XILINX	XC17V08	QFP	44	PA44QF44D
XILINX	XC17V16	PLCC	44	PA44-48U	XILINX	XC17V16	QFP	44	PA44QF44D
XILINX	XC18V01PC20	PLCC	20	PA20LC20D	XILINX	XC18V01SO20	SOIC	20	PA68-40B
XILINX	XC18V01VQ44	VQFP	44	PA44QF44D	XILINX	XC18V02PC44	PLCC	44	PA44-48U
XILINX	XC18V02VQ44	VQFP	44	PA44QF44D	XILINX	XC18V04PC44	PLCC	44	PA44-48U
XILINX	XC18V04VQ44	VQFP	44	PA44QF44D	XILINX	XC18V256PC20	PLCC	20	PA20LC20D
XILINX	XC18V256SO20	SOIC	20	PA68-40B	XILINX	XC18V256VQ44	VQFP	44	PA44QF44D
XILINX	XC18V512PC20	PLCC	20	PA20LC20D	XILINX	XC18V512SO20	SOIC	20	PA68-40B
XILINX	XC18V512VQ44	VQFP	44	PA44QF44D	XILINX	XC2C32	VQFP	44	PA44QF44D
XILINX	XC2C32A	VQFP	44	PA44QF44D	XILINX	XC2C64	VQFP	44	PA44QF44D
XILINX	XC2C64A	VQFP	44	PA44QF44D	XILINX	XC95108	PLCC	84	PA84-48B
XILINX	XC9536	PLCC	44	PA44-48U	XILINX	XC9536	VQFP	44	CA44TQ44D-EO
XILINX	XC9536XL	PLCC	44	PA44-48U	XILINX	XC9536XL	VQFP	44	CA44TQ44D-EO
XILINX	XC9572	PLCC	44	PA44-48U	XILINX	XC9572XL	PLCC	44	PA44-48U
XILINX	XCF01SVO20	TSSOP	20	PA24TSS24D(M)	XILINX	XCF01SVOG20	TSSOP	20	PA24TSS24D(M)
XILINX	XCF02SVO20	TSSOP	20	PA24TSS24D(M)	XILINX	XCF02SVOG20	TSSOP	20	PA24TSS24D(M)
XILINX	XCF04SVO20	TSSOP	20	PA24TSS24D(M)	XILINX	XCF04SVOG20	TSSOP	20	PA24TSS24D(M)
XILINX	XCF08PFS48	TFBGA	48	PA44-40-276	XILINX	XCF08PVO48	TSOP	48	PA48TS48D
XILINX	XCF16PFS48	TFBGA	48	PA44-40-276	XILINX	XCF16PVO48	TSOP	48	PA48TS48D
XILINX	XCF32PFS48	TFBGA	48	PA44-40-276	XILINX	XCF32PVO48	TSOP	48	PA48TS48D
ZILOG	Z86E02(1925)	DIP	18	Not use adapter	ZILOG	Z86E0208PSC	DIP	18	Not use adapter
ZILOG	Z86E0208PSC1866	DIP	18	Not use adapter	ZILOG	Z86E0208PSC1903	DIP	18	Not use adapter
ZILOG	Z86E0208SSC	SOIC	18	PA28SO28D-08	ZILOG	Z86E0208SSC1866	SOIC	18	PA28SO28D-08
ZILOG	Z86E0208SSC1903	SOIC	18	PA28SO28D-08	ZILOG	Z86E0308PSC	DIP	18	Not use adapter
ZILOG	Z86E0308SSC	SOIC	18	PA28SO28D-08	ZILOG	Z86E0312PSC	DIP	18	Not use adapter
ZILOG	Z86E0312SSC	SOIC	18	PA28SO28D-08	ZILOG	Z86E04	DIP	18	Not use adapter
ZILOG	Z86E04(1925)	DIP	18	Not use adapter	ZILOG	Z86E0408PEC	DIP	18	Not use adapter
ZILOG	Z86E0408PEC1903	DIP	18	Not use adapter	ZILOG	Z86E0408PSC1866	DIP	18	Not use adapter
ZILOG	Z86E0408PSC1903	DIP	18	Not use adapter	ZILOG	Z86E0408SEC	SOIC	18	PA28SO28D-08
ZILOG	Z86E0408SEC1903	SOIC	18	PA28SO28D-08	ZILOG	Z86E0408SSC1866	SOIC	18	PA28SO28D-08
ZILOG	Z86E0408SSC1903	SOIC	18	PA28SO28D-08	ZILOG	Z86E0412PEC	DIP	18	Not use adapter
ZILOG	Z86E0412PEC1903	DIP	18	Not use adapter	ZILOG	Z86E0412PSC1866	DIP	18	Not use adapter
ZILOG	Z86E0412PSC1903	DIP	18	Not use adapter	ZILOG	Z86E0412SEC	SOIC	18	PA28SO28D-08
ZILOG	Z86E0412SEC1903	SOIC	18	PA28SO28D-08	ZILOG	Z86E0412SSC1866	SOIC	18	PA28SO28D-08
ZILOG	Z86E0412SSC1903	SOIC	18	PA28SO28D-08	ZILOG	Z86E0608PSC	DIP	18	Not use adapter
ZILOG	Z86E0608SSC	SOIC	18	PA28SO28D-08	ZILOG	Z86E0612PSC	DIP	18	Not use adapter
ZILOG	Z86E0612SSC	SOIC	18	PA28SO28D-08	ZILOG	Z86E08	DIP	18	Not use adapter
ZILOG	Z86E08(1925)	DIP	18	Not use adapter	ZILOG	Z86E0808PEC	DIP	18	Not use adapter
ZILOG	Z86E0808PEC1903	DIP	18	Not use adapter	ZILOG	Z86E0808PSC1866	DIP	18	Not use adapter
ZILOG	Z86E0808PSC1903	DIP	18	Not use adapter	ZILOG	Z86E0808SEC	SOIC	18	PA28SO28D-08
ZILOG	Z86E0808SEC1903	SOIC	18	PA28SO28D-08	ZILOG	Z86E0808SSC1866	SOIC	18	PA28SO28D-08
ZILOG	Z86E0808SSC1903	SOIC	18	PA28SO28D-08	ZILOG	Z86E0812PEC	DIP	18	Not use adapter
ZILOG	Z86E0812PEC1903	DIP	18	Not use adapter	ZILOG	Z86E0812PSC1866	DIP	18	Not use adapter
ZILOG	Z86E0812PSC1903	DIP	18	Not use adapter	ZILOG	Z86E0812SEC	SOIC	18	PA28SO28D-08
ZILOG	Z86E0812SEC1903	SOIC	18	PA28SO28D-08	ZILOG	Z86E0812SSC1866	SOIC	18	PA28SO28D-08

ZILOG	Z86E0812SSC1903	SOIC	18	PA28SO28D-08					
-------	-----------------	------	----	--------------	--	--	--	--	--