

DEVICE LIST 9/5/2008

Total Manufacturers 180

Total Devices 33624

ACT (Acer)	ACTRANS	ADVANCE GROUP	ALI
ALL 24 SERIES(ISP)		ALLIANCE	
ALTERA			
AMD	AMI SEMICONDUCTOR		
AMIC			
ANACHIP (AKM)	APLUS FLASH	ARTSCHIP	ASAHI KASEI
ASD	ASI	ASP	
ATC			
ATMEL	ATMEL W&M	ATMEL-CUSTOMER	
AUSTIN			
BELLING-SYSTRON	BENCHMARQ	BMT	
BOSEN			
BRIGHT	CATALYST	CERAMATE	CHINA
CORE			
CHINGIS	CHIPCON	CHIPSWINNER	
CORERIVER			
CWI	CYGNAL	CYPRESS	
DALLAS			
DENSE-PAC	DEUTRON	EFST	
ELECTRONIC ARRAYS		EM	
EMTC			
EON	EPSON	ESMT	
EXCELSEMI			
EXEL	FAIRCHILD	FORCE	
TECHNOLOGIES			
FORWARD	FREESCALE	Fremont Micro	
Devices			

FUJITSU	GENCORE	GENERAL (GI)
GENERIC		
GOAL	GREENWICH	HAIER
HARRIS		
HITACHI	HOLTEK	HONGKONG
HYNIX		
HYNIX-CUSTOMER	HYUNDAI	ICE
ICMIC		
ICSI	ICT	IMT
INTEL		
INTEL-CUSTOMER	INTELSIL	ISSI
ITHINKO		
LATTICE	LG Semicon	LINKSMART
MACRONIX		
MAXIM	MAXWELL	MEGAWIN
MEMOCOM		
MICON	MICROCHIP	MICRON
MICRONAS		
MICRON-CUSTOMER	MITSUBISHI	MOSEL-VITELIC
MOSTEK		
MOTOROLA	MYSON	NEC
NEXFLASH		
NJRC	NOVATEK	NSC
NTE		
NUMONYX	NXP	OKI
PARALLAX		
PFLASH (MSTAR)	PHILIPS	PJ
PMC		
PSS	PTC	QIXIN
Pulse		Quick
RAMTRON	RATO	RAYDIUM
RENESAS		
RICOH	ROCKWELL	ROHM
SAIFUN		
SAMSUNG	SAMSUNG-CUSTOMER	SANYO
SCENIX		
SEQ	SEIKO	SGS-THOMSON
SHARP		

<u>SHARP-CUSTOMER</u>	<u>SIEMENS</u>	<u>SIGNETICS</u>	
<u>Silicon Laboratories</u>		<u>SILICON7</u>	
<u>SIMTEK</u>			
<u>SMOS</u>	<u>SONIX</u>	<u>SONY</u>	
<u>SPACE ELECTRONICS[SEI]</u>		<u>SPANSION</u>	
<u>SPANSION-CUSTOMER</u>		<u>SSSC</u>	
<u>SST</u>			
<u>ST</u>	<u>STC</u>	<u>ST-CUSTOMER</u>	
<u>SUMMIT</u>			
<u>SUNPLUS</u>	<u>SYNCMOS</u>	<u>SYNERTEK</u>	
<u>SYNTEK</u>			
<u>TECHCODE</u>	<u>TEKMOS</u>	<u>TEMIC</u>	
<u>TI</u>			
<u>TMC</u>	<u>TOPRO</u>	<u>TOSHIBA</u>	<u>TOSHIBA-</u>
<u>CUSTOMER</u>			
<u>TURBO IC</u>	<u>UBICOM</u>	<u>UMC</u>	
<u>UTRON</u>			
<u>VANTIS</u>	<u>VERSACHIPS</u>	<u>VLSI</u>	
<u>WELTREND</u>			
<u>WHITE ELECTRONIC DESIGNS</u>		<u>WINBOND</u>	
<u>WSI</u>			
<u>XELTEK</u>	<u>XICOR</u>	<u>XILINX</u>	<u>XILINX-</u>
<u>CUSTOMER</u>			
<u>YMC</u>	<u>YSS</u>	<u>ZHIXIN</u>	
<u>ZILOG</u>			
<u>ZMD</u>			

ACT

E (E) PROM / FRAM / NVRAM

93LC46 (08bit) [(SA602A)]	93LC46 (08bit) @ SOIC8
93LC46 (16bit) [(SA602A)]	93LC46 (16bit) @ SOIC8
93LC56 (08bit)	93LC56 (08bit) @ SOIC8

[(SA602A)]	
93LC56(16bit)	93LC56(16bit)@SOIC8
[(SA602A)]	
93LC66(08bit)	93LC66(08bit)@SOIC8
[(SA602A)]	
93LC66(16bit)	93LC66(16bit)@SOIC8
[(SA602A)]	
93LC86(08bit)	93LC86(08bit)@SOIC8
[(SA602A)]	
93LC86(16bit)	93LC86(16bit)@SOIC8
[(SA602A)]	

ACTRANS

E (E) PROM/FRAM/NVRAM

AC25010@SOIC8 [(SA602A)]	AC25512@SOIC8
[(SA602A)]	
AC25LC010@SOIC8 [(SA602A)]	AC25LC512@SOIC8
[(SA602A)]	
AC39LV010@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV010@PLCC32 [(SA015A1T)]	AC39LV010@VSOP32
[(SA620)]	
AC39LV020@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV020@PLCC32 [(SA015A1T)]	AC39LV020@VSOP32
[(SA620)]	
AC39LV040@PLCC32 [(SA015A1T)]	AC39LV040@VSOP32
[(SA620)]	
AC39LV080@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV080@TSOP40 [(SA409T)]	AC39LV088@TSOP48 [(SA247-B005)]
AC39LV512@PLCC32 [(SA015A1T)]	AC39LV512@VSOP32
[(SA620)]	
AC39VF800@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39VF800@TSOP48 [(SA247-B005)]	

ADVANCE GROUP

E (E) PROM/FRAM/NVRAM

AF24BC01 [(SA602A)]	AF24BC01@SOIC8
AF24BC01@TSOP8 [(SA026)]	
AF24BC02 AF24BC02@SOIC8 [(SA602A)] [(SA026)]	AF24BC02@TSOP8
AF24BC04 [(SA602A)]	AF24BC04@SOIC8
AF24BC04@TSOP8 [(SA026)]	
AF24BC08 AF24BC08@SOIC8 [(SA602A)] [(SA026)]	AF24BC08@TSOP8
AF24BC16 [(SA602A)]	AF24BC16@SOIC8
AF24BC16@TSOP8 [(SA026)]	
AF24C128 AF24C128@SOIC8 [(SA602A)] [(SA026)]	AF24C128@TSOP8
AF24C256 [(SA602A)]	AF24C256@SOIC8
AF24C256@TSOP8 [(SA026)]	
AF24C32 AF24C32@SOIC8 [(SA602A)] [(SA026)]	AF24C32@TSOP8
AF24C64 [(SA602A)]	AF24C64@SOIC8
AF24C64@TSOP8 [(SA026)] (08bit)	AF93C46
AF93C46(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C46(08bit)@TSOP8
AF93C46(16bit) [(SA602A)]	AF93C46(16bit)@SOIC8
AF93C46(16bit)@TSOP8 [(SA026)] (08bit)	AF93C56
AF93C56(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C56(08bit)@TSOP8
AF93C56(16bit) [(SA602A)]	AF93C56(16bit)@SOIC8
AF93C56(16bit)@TSOP8 [(SA026)] (08bit)	AF93C66
AF93C66(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C66(08bit)@TSOP8
AF93C66(16bit)	AF93C66(16bit)@SOIC8

[(SA602A)]	
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86
(08bit)	
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8
[(SA026)]	
AF93C86(16bit)	AF93C86(16bit)@SOIC8
[(SA602A)]	
AF93C86(16bit)@TSOP8 [(SA026)]	

MICROCONTROLLER

A1000A2	A1000A2@PLCC44
[(SA244)]	
A1000A2@PQFP44 [(SA245A)]	
A1000A3	
A1000A3@PLCC44 [(SA244)]	A1000A3@PQFP44
[(SA245A)]	
AG1001@SDIP42 [(SA028)]	
AG89F516	
AG89F516@PLCC44 [(SA244)]	AG89F516@PQFP44
[(SA245A)]	
AG89F54	AG89F54@PLCC44
[(SA244)]	
AG89F54@PQFP44 [(SA245A)]	
AG89P51	
AG89P51@PLCC44 [(SA244)]	AG89P51@PQFP44
[(SA675)]	
AG89P516	AG89P516@PLCC44
[(SA244)]	
AG89P516@PQFP44 [(SA675)]	
AG89P51A	
AG89P51A@PLCC44 [(SA244)]	AG89P51A@PQFP44
[(SA675)]	
AG89P52	AG89P52@PLCC44
[(SA244)]	
AG89P52@PQFP44 [(SA675)]	

ALI(Acer)

E (E) PROM/FRAM/NVRAM

M8720
[(SA015A1T)]

M8720@PLCC32

MICROCONTROLLER

M6759
M6759@PLCC44 [ordering number is marked above]
M6759@TQFP44 [ordering number is marked above]

ALL 24 SERIES(ISP)

E (E) PROM / FRAM / NVRAM

24C01 (ISP) [ISP-HEADER01] HEADER01]	24C02 (ISP) [ISP-
24C04 (ISP) [ISP-HEADER01] HEADER01]	24C08 (ISP) [ISP-
24C128 (ISP) [ISP-HEADER01] HEADER01]	24C16 (ISP) [ISP-
24C256 (ISP) [ISP-HEADER01] HEADER01]	24C32 (ISP) [ISP-
24C64 (ISP) [ISP-HEADER01]	

ALLIANCE

E (E) PROM / FRAM / NVRAM

AS29F200@PSOP44 [(SA638-B006)] B005)]	AS29F200@TSOP48 [(SA247-
AS29F200B@PSOP44 [(SA638-B006)] B005)]	AS29F200B@TSOP48 [(SA247-
AS29F200T@PSOP44 [(SA638-B006)] B005)]	AS29F200T@TSOP48 [(SA247-

ALTERA

E (E) PROM / FRAM / NVRAM

EPC1(LC)@PLCC20 [(SA001A)]	EPC1(LI)@PLCC20
[(SA001A)]	
EPC1(PC)	EPC1
(PI)	
EPC1441(LC)@PLCC20 [(SA001A)]	EPC1441(LI)@PLCC20
[(SA001A)]	
EPC1441(PC)	EPC1441
(PI)	
EPC1441(TC)@TQFP32 [(SA663)]	EPC1441(TI)@TQFP32
[(SA663)]	
EPC2(LC)@PLCC20 [(SA001A)]	EPC2(LI)@PLCC20
[(SA001A)]	
EPC2(TC)@TQFP32 [(SA663)]	EPC2(TI)@TQFP32
[(SA663)]	
EPCS16SI16@SOIC16 [(SA404)]	EPCS16SI8N@SOIC8
[(SA602A)]	
EPCS1SI8@SOIC8 [(SA602A)]	EPCS4SI8@SOIC8
[(SA602A)]	
EPCS64SI16@SOIC16 [(SA404)]	

PLD

EP310	EP310@PLCC20
[(SA001A)]	
EP320	EP320@PLCC20
[(SA001A)]	
EP330	EP330@PLCC20
[(SA001A)]	
EP600	EP600@PLCC28
[(SA008A)]	
EP600@SOIC24 [(SA404)]	
EP600I	
EP600I@PLCC28 [(SA008A)]	EP600I@SOIC24
[(SA404)]	
EP610	EP610@PLCC28
[(SA008A)]	
EP610@SOIC24 [(SA404)]	
EP610A	
EP610A@PLCC28 [(SA008A)]	EP610A@SOIC24
[(SA404)]	
EP610I	EP610I@PLCC28
[(SA008A)]	

EP610I@SOIC24 [(SA404)]
 EP610T
 EP610T@PLCC28 [(SA008A)] EP610T@SOIC24
 [(SA404)]
 EP630 EP630@PLCC28
 [(SA008A)]
 EP630@SOIC24 [(SA404)]
 EP900
 EP900@PLCC44 [(SA244)]
 EP900I
 EP900I@PLC44 [(SA244)]
 EP910
 EP910@PLCC44 [(SA244)]
 EP910A
 EP910A@PLCC44 [(SA244)]
 EP910I
 EP910I@PLCC44 [(SA244)]
 EP910T
 EP910T@PLCC44 [(SA244)] EPM3032A@PLCC44
 [(SA244)]
 EPM3032A@TQFP44 [(SA245A)] EPM3064A@PLCC44
 [(SA244)]
 EPM3064A@TQFP44 [(SA245A)] EPM7032@PLCC44
 [(SA244)]
 EPM7032@TQFP44 [(SA245A)]
 EPM7032AE@JLCC44 (7032 mode) [(SA244)]
 EPM7032AE@PLCC44 (7032 mode) [(SA244)]
 EPM7032AE@PLCC44 (7032AE mode) [(SA244)]
 EPM7032AE@PLCC44 (7032S mode) [(SA244)]
 EPM7032AE@PQFP44 (7032 mode) [(SA245A)]
 EPM7032AE@TQFP44 (7032 mode) [(SA245A)]
 EPM7032AE@TQFP44 (7032AE mode) [(SA245A)]
 EPM7032AE@TQFP44 (7032S mode) [(SA245A)]
 EPM7032B@PLCC44 (7032AE mode) [(SA244)]
 EPM7032B@PLCC44 (7032B mode) [(SA244)]
 EPM7032B@PLCC44 (7032S mode) [(SA244)]
 EPM7032B@TQFP44 (7032AE mode) [(SA245A)]
 EPM7032B@TQFP44 (7032B mode) [(SA245A)]
 EPM7032B@TQFP44 (7032S mode) [(SA245A)]
 EPM7032B@TQFP48 (7032AE mode) [(SA248)]
 EPM7032B@TQFP48 (7032B mode) [(SA248)]
 EPM7032B@TQFP48 (7032S mode) [(SA248)]
 EPM7032S@PLCC44 (7032 mode) [(SA244)]

```

EPM7032S@PLCC44      (7032S mode) [(SA244)]
EPM7032S@TQFP44      (7032 mode) [(SA245A)]
EPM7032S@TQFP44      (7032S mode) [(SA245A)]
EPM7032V@PLCC44 [(SA244)]      EPM7032V@TQFP44
[(SA245A)]
EPM7064@PLCC44 [(SA244)]      EPM7064@TQFP44
[(SA245A)]
EPM7064AE@PLCC44      (7064S)(ISP) [ISP-HEADER01]
EPM7064AE@PLCC44      (7064AE mode) [(SA244)]
EPM7064AE@PLCC44      (7064AE)(ISP) [ISP-HEADER01]
EPM7064AE@PLCC44      (7064S mode) [(SA244)]
EPM7064AE@TQFP44      (7064S)(ISP) [ISP-HEADER01]
EPM7064AE@TQFP44      (7064AE mode) [(SA245A)]
EPM7064AE@TQFP44      (7064AE)(ISP) [ISP-HEADER01]
EPM7064AE@TQFP44      (7064S mode) [(SA245A)]
EPM7064B@PLCC44      (7064AE mode) [(SA244)]
EPM7064B@PLCC44      (7064B mode) [(SA244)]
EPM7064B@PLCC44      (7064S mode) [(SA244)]
EPM7064B@TQFP44      (7064AE mode) [(SA245A)]
EPM7064B@TQFP44      (7064B mode) [(SA245A)]
EPM7064B@TQFP44      (7064S mode) [(SA245A)]
EPM7064B@TQFP48      (7064AE mode) [(SA248)]
EPM7064B@TQFP48      (7064B mode) [(SA248)]
EPM7064B@TQFP48      (7064S mode) [(SA248)]
EPM7064S@PLCC44      (7064 mode) [(SA244)]
EPM7064S@PLCC44      (7064S mode) [(SA244)]
EPM7064S@TQFP44      (7064 mode) [(SA245A)]
EPM7064S@TQFP44      (7064S mode) [(SA245A)]

```

AMD

E (E) PROM / FRAM / NVRAM

```

1736      1736@SOIC8
[(SA602A)]
1765      1765@SOIC8
[(SA602A)]
AM25FL005D@SOIC8 [(SA602A)]      AM25FL005D@USON8
[(SA683)]
AM25FL010D@SOIC8 [(SA602A)]      AM25FL010D@USON8
[(SA683)]
AM25FL016A@SOIC16 [(SA404)]

```

AM25FL016A@SOIC16(ISP) [ISP-HEADER01]
AM25FL016A@WSON8 [(SA684)]
AM25FL016A@WSON8(ISP) [ISP-HEADER01]
AM25FL020D@SOIC8 [(SA602A)] AM25FL020D@USON8
[(SA683)]
AM25FL032A@SOIC16 [(SA404)]
AM25FL032A@SOIC16(ISP) [ISP-HEADER01]
AM25FL032A@WSON8 [(SA684)]
AM25FL032A@WSON8(ISP) [ISP-HEADER01]
AM25FL040D@SOIC8 [(SA602A)] AM25FL040D@USON8
[(SA683)]
AM25FL080D@SOIC8 [(SA602A)] AM25FL080D@USON8
[(SA683)]
AM27128 AM27128
(DC)
AM27128(DC)@PLCC32 [(SA015A1T)] AM27128@PLCC32
[(SA015A1T)]
AM27128A AM27128A
(F)
AM27128A(F)@PLCC32 [(SA015A1T)] AM27128A
(PC)
AM27128A(PC)@PLCC32 [(SA015A1T)] AM27128A@PLCC32
[(SA015A1T)]
AM2716
AM2716B
AM27256 AM27256@PLCC32
[(SA015A1T)]
AM27256AP AM27256AP@PLCC32
[(SA015A1T)]
AM27256F AM27256F@PLCC32
[(SA015A1T)]
AM27256PC AM27256PC@PLCC32
[(SA015A1T)]
AM2732
AM2732A
AM2732B
AM27512
AM27512@PLCC32 [(SA015A1T)]
AM27512DC
AM27512DC@PLCC32 [(SA015A1T)]
AM27512F
AM27512F@PLCC32 [(SA015A1T)]
AM27512PC

AM27512PC@PLCC32 [(SA015A1T)]	
AM27513	
AM2764	AM2764@PLCC32
[(SA015A1T)]	
AM2764A	AM2764A
(DC)	
AM2764A(DC)@PLCC32 [(SA015A1T)]	AM2764A
(DCB)	
AM2764A(DI)	AM2764A
(DIB)	
AM2764A(F)	AM2764A(F)@PLCC32
[(SA015A1T)]	
AM2764A(JC)	AM2764A
(LC)	
AM2764A(LCB)	AM2764A
(LE)	
AM2764A(LEB)	AM2764A
(PC)	
AM2764A(PC)@PLCC32 [(SA015A1T)]	AM2764A@PLCC32
[(SA015A1T)]	
AM27C010	AM27C010@PLCC32
[(SA015A1T)]	
AM27C010@TSOP32 [(SA410T)]	
AM27C020	
AM27C020@PLCC32 [(SA015A1T)]	AM27C020@TSOP32
[(SA410T)]	
AM27C040	AM27C040@PLCC32
[(SA015A1T)]	
AM27C040@TSOP32 [(SA410T)]	
AM27C080	
AM27C080@PLCC32 [(SA015A1T)]	AM27C080@TSOP32
[(SA410T)]	
AM27C100	AM27C100@PLCC32
[(SA015A1T)]	
AM27C100@TSOP32 [(SA410T)]	
AM27C1024	
AM27C1024@PLCC44 [(SA244)]	
AM27C128	
AM27C128@PLCC32 [(SA015A1T)]	
AM27C2048	
AM27C2048@PLCC44 [(SA244)]	AM27C2048@TSOP40
[(SA409T)]	
AM27C256	AM27C256

(F)	
AM27C256(F)@PLCC32 [(SA015A1T)]	AM27C256
(PC)	
AM27C256(PC)@PLCC32 [(SA015A1T)]	AM27C256@PLCC32
[(SA015A1T)]	
AM27C400	AM27C400@PLCC44
[(SA244)]	
AM27C4096	AM27C4096@PLCC44
[(SA244)]	
AM27C512	AM27C512
(P)	
AM27C512(P)@PLCC32 [(SA015A1T)]	AM27C512@PLCC32
[(SA015A1T)]	
AM27C64	AM27C64@PLCC32
[(SA015A1T)]	
AM27H010	AM27H010@PLCC32
[(SA015A1T)]	
AM27H010@TSOP32 [(SA410T)]	
AM27H256	
AM27H256@PLCC32 [(SA015A1T)]	
AM27HB010	
AM27HB010@PLCC32 [(SA015A1T)]	AM27HB010@TSOP32
[(SA410T)]	
AM27LV010	AM27LV010@PLCC32
[(SA015A1T)]	
AM27LV010@TSOP32 [(SA410T)]	
AM27LV010B	
AM27LV010B@PLCC32 [(SA015A1T)]	AM27LV010B@TSOP32
[(SA410T)]	
AM27LV020	AM27LV020@PLCC32
[(SA015A1T)]	
AM27LV020@TSOP32 [(SA410T)]	
AM27LV020B	
AM27LV020B@PLCC32 [(SA015A1T)]	AM27LV020B@TSOP32
[(SA410T)]	
AM2816A	
AM2817A	
AM2817A@PLCC32 [(SA015A1T)]	AM2817A@SOIC28
[(SA404)]	
AM2864A	AM2864A
(E)	
AM2864A(E)@PLCC32 [(SA015A1T)]	AM2864A@PLCC32
[(SA015A1T)]	

AM2864B	AM2864B
(E)	
AM2864B(E)@PLCC32 [(SA015A1T)]	AM2864B@PLCC32
[(SA015A1T)]	
AM28F001	AM28F001@PLCC32
[(SA015A1T)]	
AM28F001@TSOP32 [(SA410T)]	
AM28F010	
AM28F010@PLCC32 [(SA015A1T)]	AM28F010@TSOP32
[(SA410T)]	
AM28F010A	AM28F010A@PLCC32
[(SA015A1T)]	
AM28F010A@TSOP32 [(SA410T)]	
AM28F020	
AM28F020@PLCC32 [(SA015A1T)]	AM28F020@TSOP32
[(SA410T)]	
AM28F020A	AM28F020A@PLCC32
[(SA015A1T)]	
AM28F020A@TSOP32 [(SA410T)]	
AM28F256	
AM28F256@PLCC32 [(SA015A1T)]	AM28F256@TSOP32
[(SA410T)]	
AM28F256A	AM28F256A@PLCC32
[(SA015A1T)]	
AM28F256A@TSOP32 [(SA410T)]	
AM28F512	
AM28F512(F)	AM28F512(F)@PLCC32
[(SA015A1T)]	
AM28F512(F)@TSOP32 [(SA410T)]	AM28F512@PLCC32
[(SA015A1T)]	
AM28F512@TSOP32 [(SA410T)]	
AM28F512A	
AM28F512A(F)	AM28F512A(F)@PLCC32
[(SA015A1T)]	
AM28F512A(F)@TSOP32 [(SA410T)]	AM28F512A@PLCC32
[(SA015A1T)]	
AM28F512A@TSOP32 [(SA410T)]	
AM29BL162CB@SSOP56 [(SA629A-B022)]	
AM29BL802CB@SSOP56 [(SA629A-B022)]	
AM29DL161DB@FBGA48 [(SA642B-B026A-Y072F001)]	
AM29DL161DB@FBGA63 [(SA642C-B026A-Y056F001)]	
AM29DL161DB@FBGA64 [(SA655A-B044A-T064N001)]	
AM29DL161DB@TSOP48 [(SA247-B005)]	

AM29DL161DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL161DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL161DT@TSOP48 [(SA247-B005)]
AM29DL161DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CB@TSOP48 [(SA247-B005)]
AM29DL162CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CT@TSOP48 [(SA247-B005)]
AM29DL162DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL162DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL162DB@TSOP48 [(SA247-B005)]
AM29DL162DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL162DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL162DT@TSOP48 [(SA247-B005)]
AM29DL162DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CB@TSOP48 [(SA247-B005)]
AM29DL163CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CT@TSOP48 [(SA247-B005)]
AM29DL163DB@FBGA48 [(SA642HH-B026A-T048F001Y)]
AM29DL163DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL163DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL163DB@TSOP48 [(SA247-B005)]
AM29DL163DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163DT@FBGA48 [(SA642HH-B026A-T048F001Y)]
AM29DL163DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL163DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL163DT@TSOP48 [(SA247-B005)]
AM29DL163DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164CB@TSOP48 [(SA247-B005)]
AM29DL164CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164CT@TSOP48 [(SA247-B005)]
AM29DL164DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL164DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL164DB@TSOP48 [(SA247-B005)]
AM29DL164DB@VFBGA48 [(SA642B-B026A-Y072F001)]

AM29DL164DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL164DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL164DT@TSOP48 [(SA247-B005)]
AM29DL164DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL320GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL320GB@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL320GB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL320GB@TSOP48 [(SA247-B005)]
AM29DL320GT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL320GT@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL320GT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL320GT@TSOP48 [(SA247-B005)]
AM29DL321CB@TSOP48 [(SA247-B005)]
AM29DL321CT@TSOP48 [(SA247-B005)]
AM29DL322CB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322CB@TSOP48 [(SA247-B005)]
AM29DL322CT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322CT@TSOP48 [(SA247-B005)]
AM29DL322DB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322DB@TSOP48 [(SA247-B005)]
AM29DL322DT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322DT@TSOP48 [(SA247-B005)]
AM29DL322GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL322GB@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL322GB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL322GB@TSOP48 [(SA247-B005)]
AM29DL322GT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL322GT@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL322GT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL322GT@TSOP48 [(SA247-B005)]
AM29DL323CB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL323CB@TSOP48 [(SA247-B005)]
AM29DL323CT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL323CT@TSOP48 [(SA247-B005)]
AM29DL323DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL323DB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL323DB@TSOP48 [(SA247-B005)]
AM29DL323DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL323DT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL323DT@TSOP48 [(SA247-B005)]
AM29DL323GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL323GB@FBGA63 [(SA642A-B026A-Y096F001)]

AM29DL323GB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL323GB@TSOP48 [(SA247-B005)]
AM29DL323GT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL323GT@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL323GT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL323GT@TSOP48 [(SA247-B005)]
AM29DL324CB@TSOP48 [(SA247-B005)]
AM29DL324CT@TSOP48 [(SA247-B005)]
AM29DL324DB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL324DB@TSOP48 [(SA247-B005)]
AM29DL324DT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL324DT@TSOP48 [(SA247-B005)]
AM29DL324GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL324GB@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL324GB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL324GB@TSOP48 [(SA247-B005)]
AM29DL324GT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL324GT@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL324GT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL324GT@TSOP48 [(SA247-B005)]
AM29DL400BB@PSOP44 [(SA638-B006)]
AM29DL400BB@TSOP48 [(SA247-B005)]
AM29DL400BT@PLCC44 [(SA638-B006)]
AM29DL400BT@TSOP48 [(SA247-B005)]
AM29DL640D@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL640D@TSOP48 [(SA247-B005)]
AM29DL640G@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL640G@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL640G@TSOP48 [(SA247-B005)]
AM29DL642G@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL800B@PSOP44 [(SA638-B006)] AM29DL800B@TSOP48 [(SA247-B005)]
AM29DL800BB@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29DL800BB@PSOP44 [(SA638)]
AM29DL800BB@TSOP48 [(SA247-B005)]
AM29DL800BT@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29DL800BT@PSOP44 [(SA638)]
AM29DL800BT@TSOP48 [(SA247-B005)]
AM29DL800T@PSOP44 [(SA638-B006)] AM29DL800T@TSOP48 [(SA247-B005)]
AM29DS163CB@TSOP48 [(SA247-B005)]
AM29DS163CT@TSOP48 [(SA247-B005)]
AM29DS163DB@FBGA48 [(SA642B-B026A-Y072F001)]

AM29DS163DB@TSOP48 [(SA247-B005)]
 AM29DS163DT@FBGA48 [(SA642B-B026A-Y072F001)]
 AM29DS163DT@TSOP48 [(SA247-B005)]
 AM29DS323DB@FBGA48 [(SA642B-B026A-Y072F001)]
 AM29DS323DB@TSOP48 [(SA247-B005)]
 AM29DS323DT@FBGA48 [(SA642B-B026A-Y072F001)]
 AM29DS323DT@TSOP48 [(SA247-B005)]
 AM29F002B AM29F002B@PLCC32
 [(SA015A1T)]
 AM29F002B@TSOP32 [(SA410T)]
 AM29F002BB
 AM29F002BB@PLCC32 [(SA015A1T)] AM29F002BB@TSOP32
 [(SA410T)]
 AM29F002BT AM29F002BT@PLCC32
 [(SA015A1T)]
 AM29F002BT@TSOP32 [(SA410T)]
 AM29F002NB
 AM29F002NB@PLCC32 [(SA015A1T)] AM29F002NB@TSOP32
 [(SA410T)]
 AM29F002NBB AM29F002NBB@PLCC32
 [(SA015A1T)]
 AM29F002NBB@TSOP32 [(SA410T)]
 AM29F002NBT
 AM29F002NBT@PLCC32 [(SA015A1T)] AM29F002NBT@TSOP32
 [(SA410T)]
 AM29F002NT AM29F002NT@PLCC32
 [(SA015A1T)]
 AM29F002NT@TSOP32 [(SA410T)]
 AM29F002T
 AM29F002T@PLCC32 [(SA015A1T)] AM29F002T@TSOP32
 [(SA410T)]
 AM29F004BB@PLCC32 [(SA015A1T)] AM29F004BB@TSOP32
 [(SA410T)]
 AM29F004BT@PLCC32 [(SA015A1T)] AM29F004BT@TSOP32
 [(SA410T)]
 AM29F010 AM29F010@PLCC32
 [(SA015A1T)]
 AM29F010@TSOP32 [(SA410T)]
 AM29F010A
 AM29F010A@PLCC32 [(SA015A1T)] AM29F010A@TSOP32
 [(SA410T)]
 AM29F010B AM29F010B@PLCC32
 [(SA015A1T)]

AM29F010B@TSOP32 [(SA410T)] AM29F016@PSOP44
[(SA638)]
AM29F016@TSOP40 [(SA409T)] AM29F016@TSOP48 [(SA247-
B005)]
AM29F016B(REVERSE)@TSOP48 [(SA247-B005)]
AM29F016B@PSOP44 [(SA638)] AM29F016B@TSOP40
[(SA409T)]
AM29F016B@TSOP48 [(SA247-B005)]
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]
AM29F016D@PSOP44 [(SA638)] AM29F016D@TSOP40
[(SA409T)]
AM29F016D@TSOP48 [(SA247-B005)] AM29F017B@TSOP48 [(SA247-
B005)]
AM29F017D@TSOP40 [(SA409T)] AM29F017D@TSOP48 [(SA247-
B005)]
AM29F032B@PSOP44 [(SA638)] AM29F032B@TSOP40
[(SA409T)]
AM29F040 AM29F040@PLCC32
[(SA015A1T)]
AM29F040@TSOP32 [(SA410T)]
AM29F040A AM29F040A@TSOP32
AM29F040A@PLCC32 [(SA015A1T)]
[(SA410T)]
AM29F040B AM29F040B(Reverse)@TSOP32 [(SA410T)]
AM29F040B@PLCC32 [(SA015A1T)] AM29F040B@TSOP32
[(SA410T)]
AM29F080@PSOP44 [(SA638)] AM29F080@TSOP40
[(SA409T)]
AM29F080B@PSOP44 [(SA638)] AM29F080B@TSOP40
[(SA409T)]
AM29F100BE@PSOP44 [(SA638-B006)] AM29F100BE@TSOP48 [(SA247-
B005)]
AM29F100BS@PSOP44 [(SA638-B006)] AM29F100BS@TSOP48 [(SA247-
B005)]
AM29F100TE@PSOP44 [(SA638-B006)] AM29F100TE@TSOP48 [(SA247-
B005)]
AM29F100TS@PSOP44 [(SA638-B006)] AM29F100TS@TSOP48 [(SA247-
B005)]
AM29F160DB@TSOP48 [(SA247-B005)] AM29F160DT@TSOP48 [(SA247-
B005)]
AM29F200AB@PSOP44 [(SA638-B006)] AM29F200AB@TSOP48 [(SA247-
B005)]

AM29F200AT@PSOP44 [(SA638-B006)]	AM29F200AT@TSOP48 [(SA247-B005)]
AM29F200BB@PSOP44 [(SA638-B006)]	AM29F200BB@TSOP48 [(SA247-B005)]
AM29F200BE@PSOP44 [(SA638-B006)]	AM29F200BE@TSOP48 [(SA247-B005)]
AM29F200BS@PSOP44 [(SA638-B006)]	AM29F200BS@TSOP48 [(SA247-B005)]
AM29F200BT@PSOP44 [(SA638-B006)]	AM29F200BT@TSOP48 [(SA247-B005)]
AM29F200TE@PSOP44 [(SA638-B006)]	AM29F200TE@TSOP48 [(SA247-B005)]
AM29F200TS@PSOP44 [(SA638-B006)]	AM29F200TS@TSOP48 [(SA247-B005)]
AM29F400AB@PSOP44 [(SA638-B006)]	AM29F400AB@TSOP48 [(SA247-B005)]
AM29F400AT@PSOP44 [(SA638-B006)]	AM29F400AT@TSOP48 [(SA247-B005)]
AM29F400BB@PSOP44 [(SA638-B006)]	AM29F400BB@TSOP48 [(SA247-B005)]
AM29F400BBE@PSOP44 [(SA638-B006)]	
AM29F400BBE@TSOP48 [(SA247-B005)]	
AM29F400BBF@PSOP44 [(SA638-B006)]	
AM29F400BBF@TSOP48 [(SA247-B005)]	
AM29F400BBS@PSOP44 [(SA638-B006)]	
AM29F400BBS@TSOP48 [(SA247-B005)]	
AM29F400BE@PSOP44 [(SA638-B006)]	AM29F400BE@TSOP48 [(SA247-B005)]
AM29F400BF@PSOP44 [(SA638-B006)]	AM29F400BF@TSOP48 [(SA247-B005)]
AM29F400BS@PSOP44 [(SA638-B006)]	AM29F400BS@TSOP48 [(SA247-B005)]
AM29F400BT@PSOP44 [(SA638-B006)]	AM29F400BT@TSOP48 [(SA247-B005)]
AM29F400BTE@PSOP44 [(SA638-B006)]	
AM29F400BTE@TSOP48 [(SA247-B005)]	
AM29F400BTF@PSOP44 [(SA638-B006)]	
AM29F400BTF@TSOP48 [(SA247-B005)]	
AM29F400BTS@PSOP44 [(SA638-B006)]	
AM29F400BTS@TSOP48 [(SA247-B005)]	
AM29F800B@PSOP44 [(SA638-B006)]	AM29F800B@TSOP48 [(SA247-B005)]
AM29F800BB@PSOP44 [(SA638-B006)]	AM29F800BB@TSOP48 [(SA247-B005)]

B005)]
AM29F800BBF@PSOP44 [(SA638-B006)]
AM29F800BBF@TSOP48 [(SA247-B005)]
AM29F800BF@PSOP44 [(SA638-B006)] AM29F800BF@TSOP48 [(SA247-B005)]
AM29F800BT@PSOP44 [(SA638-B006)] AM29F800BT@TSOP48 [(SA247-B005)]
AM29F800BTF@PSOP44 [(SA638-B006)]
AM29F800BTF@TSOP48 [(SA247-B005)]
AM29F800T@PSOP44 [(SA638-B006)] AM29F800T@TSOP48 [(SA247-B005)]
AM29F800TB@PSOP44 [(SA638-B006)] AM29F800TB@TSOP48 [(SA247-B005)]
AM29F800TF@PSOP44 [(SA638-B006)] AM29F800TF@TSOP48 [(SA247-B005)]
AM29LL800B@TSOP48 [(SA247-B005)]
AM29LL800BB@TSOP48 [(SA247-B005)]
AM29LL800BT@TSOP48 [(SA247-B005)]
AM29LL800T@TSOP48 [(SA247-B005)] AM29LV001BB@PLCC32 [(SA015A1T)]
AM29LV001BB@TSOP32 [(SA410T)] AM29LV001BT@PLCC32 [(SA015A1T)]
AM29LV001BT@TSOP32 [(SA410T)] AM29LV002@TSOP40 [(SA409T)]
AM29LV002B@TSOP40 [(SA409T)] AM29LV002BB@TSOP40 [(SA409T)]
AM29LV002BT@TSOP40 [(SA409T)] AM29LV004B@PSOP44 [(SA638)]
AM29LV004B@TSOP40 [(SA409T)] AM29LV004BB@TSOP40 [(SA409T)]
AM29LV004BT@TSOP40 [(SA409T)] AM29LV004T@PSOP44 [(SA638)]
AM29LV004T@TSOP40 [(SA409T)] AM29LV008B@PSOP44 [(SA638)]
AM29LV008B@TSOP40 [(SA409T)] AM29LV008BB@TSOP40 [(SA409T)]
AM29LV008BT@TSOP40 [(SA409T)] AM29LV008T@PSOP44 [(SA638)]
AM29LV008T@TSOP40 [(SA409T)] AM29LV010B@PLCC32 [(SA015A1T)]
AM29LV010B@TSOP32 [(SA410T)] AM29LV017B@TSOP40 [(SA409T)]
AM29LV017D@FBGA48 [(SA642B-B026A-Y072F001)]

AM29LV017D@TSOP40 [(SA409T)] AM29LV020B@PLCC32
[(SA015A1T)]
AM29LV020B@TSOP32 [(SA410T)]
AM29LV033C@FBGA63 [(SA642A-B026A-Y096N001)]
AM29LV033C@TSOP40 [(SA409T)]
AM29LV033MU@FBGA48 [(SA642B-B026A-Y072F001)]
AM29LV033MU@TSOP40 [(SA409T)] AM29LV040B@PLCC32
[(SA015A1T)]
AM29LV040B@TSOP32 [(SA410T)] AM29LV040E@PLCC32
[(SA015A1T)]
AM29LV040E@TSOP32 [(SA410T)] AM29LV040J@PLCC32
[(SA015A1T)]
AM29LV040J@TSOP32 [(SA410T)]
AM29LV065D@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV065D@TSOP48 [(SA247-B005)]
AM29LV065MU@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV065MU@TSOP48 [(SA247-B005)]
AM29LV080@TSOP40 [(SA409T)] AM29LV081@TSOP40
[(SA409T)]
AM29LV081B@TSOP40 [(SA409T)] AM29LV116BB@TSOP40
[(SA409T)]
AM29LV116BT@TSOP40 [(SA409T)] AM29LV116DB@TSOP40
[(SA409T)]
AM29LV116DT@TSOP40 [(SA409T)]
AM29LV128MH@FBGA64 [(SA655F-B099A-W064F001Y)]
AM29LV128MH@TSOP56 [(SA628-B067)]
AM29LV128ML@FBGA64 [(SA655F-B099A-W064F001Y)]
AM29LV128ML@TSOP56 [(SA628-B067)]
AM29LV160BB@FBGA48 [(SA642B-B026A-Y072F001N)]
AM29LV160BB@PSOP44 [(SA638)]
AM29LV160BB@TSOP48 [(SA247-B005)]
AM29LV160BT@FBGA48 [(SA642B-B026A-Y072F001N)]
AM29LV160BT@PSOP44 [(SA638)]
AM29LV160BT@TSOP48 [(SA247-B005)]
AM29LV160DB(REVERSE)@TSOP48 [(SA247-B005)]
AM29LV160DB@FBGA48 [(SA642B-B026A-Y072F001N)]
AM29LV160DB@PSOP44 [(SA638)]
AM29LV160DB@TSOP48 [(SA247-B005)]
AM29LV160DT(REVERSE)@TSOP48 [(SA247-B005)]
AM29LV160DT@FBGA48 [(SA642B-B026A-Y072F001N)]
AM29LV160DT@PSOP44 [(SA638)]
AM29LV160DT@TSOP48 [(SA247-B005)]
AM29LV160MB@FBGA48 [(SA642B-B026A-Y072F001)]

AM29LV160MB@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV160MB@PSOP44 [(SA638)]
AM29LV160MB@TSOP48 [(SA247-B005)]
AM29LV160MT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29LV160MT@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV160MT@PSOP44 [(SA638)]
AM29LV160MT@TSOP48 [(SA247-B005)]
AM29LV200B@PSOP44 [(SA638-B006)] AM29LV200B@TSOP48 [(SA247-B005)]
AM29LV200BB@PSOP44 [(SA638-B006)]
AM29LV200BB@TSOP48 [(SA247-B005)]
AM29LV200BE@PSOP44 [(SA638-B006)]
AM29LV200BE@TSOP48 [(SA247-B005)]
AM29LV200BF@PSOP44 [(SA638-B006)]
AM29LV200BF@TSOP48 [(SA247-B005)]
AM29LV200BS@PSOP44 [(SA638-B006)]
AM29LV200BS@TSOP48 [(SA247-B005)]
AM29LV200BT@PSOP44 [(SA638-B006)]
AM29LV200BT@TSOP48 [(SA247-B005)]
AM29LV200T@PSOP44 [(SA638-B006)] AM29LV200T@TSOP48 [(SA247-B005)]
AM29LV200TE@PSOP44 [(SA638-B006)]
AM29LV200TE@TSOP48 [(SA247-B005)]
AM29LV200TF@PSOP44 [(SA638-B006)]
AM29LV200TF@TSOP48 [(SA247-B005)]
AM29LV200TS@PSOP44 [(SA638-B006)]
AM29LV200TS@TSOP48 [(SA247-B005)]
AM29LV256MH@FBGA64 [(SA655F-B099A-W064F001Y)]
AM29LV256MH@TSOP56 [(SA628-B067)]
AM29LV256ML@FBGA64 [(SA655F-B099A-W064F001Y)]
AM29LV256ML@TSOP56 [(SA628-B067)]
AM29LV320DB@FBGA48 [(SA642E-B026A-T072F001)]
AM29LV320DB@TSOP48 [(SA247-B005)]
AM29LV320DT@FBGA48 [(SA642E-B026A-T072F001)]
AM29LV320DT@TSOP48 [(SA247-B005)]
AM29LV320FB@TSOP48 [(SA247-B005)]
AM29LV320FT@TSOP48 [(SA247-B005)]
AM29LV320MB@FBGA48 [(SA642F-B026A-T064F001)]
AM29LV320MB@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV320MB@TSOP48 [(SA247-B005)]
AM29LV320MH@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV320MH@TSOP56 [(SA628-B067)]
AM29LV320ML@FBGA64 [(SA655A-B044A-T064N001)]

AM29LV320ML@TSOP56 [(SA628-B067)]
AM29LV320MT@FBGA48 [(SA642F-B026A-T064F001)]
AM29LV320MT@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV320MT@TSOP48 [(SA247-B005)]
AM29LV400B@PSOP44 [(SA638-B006)] AM29LV400B@TSOP48 [(SA247-B005)]
AM29LV400BB@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BB@PSOP44 [(SA638-B006)]
AM29LV400BB@TSOP48 [(SA247-B005)]
AM29LV400BT@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BT@PSOP44 [(SA638-B006)]
AM29LV400BT@TSOP48 [(SA247-B005)]
AM29LV400T@PSOP44 [(SA638-B006)] AM29LV400T@TSOP48 [(SA247-B005)]
AM29LV640DH@SSOP56 [(SA629A-B020)]
AM29LV640DL@SSOP56 [(SA629A-B020)]
AM29LV640DU@FBGA63 [(SA642M-B026A-W048F001Y)]
AM29LV640DU@FBGA64 [(SA655D-B044A-W064F001)]
AM29LV640GU@FBGA63 [(SA642M-B026A-W048F001Y)]
AM29LV640GU@FBGA64 [(SA655D-B044A-W064F001)]
AM29LV640MB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV640MB@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV640MB@TSOP48 [(SA247-B005)]
AM29LV640MH@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV640MH@TSOP56 [(SA628-B067)]
AM29LV640ML@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV640ML@TSOP56 [(SA628-B067)]
AM29LV640MT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV640MT@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV640MT@TSOP48 [(SA247-B005)]
AM29LV640MU@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV640MU@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV641DH@TSOP48 [(SA247-B005)]
AM29LV641DHR@TSOP48 [(SA247-B005)]
AM29LV641DL@TSOP48 [(SA247-B005)]
AM29LV641DLR@TSOP48 [(SA247-B005)]
AM29LV641GH@TSOP48 [(SA247-B005)]
AM29LV641GHR@TSOP48 [(SA247-B005)]
AM29LV641GL@TSOP48 [(SA247-B005)]
AM29LV641GLR@TSOP48 [(SA247-B005)]
AM29LV641MH@TSOP48 [(SA247-B005)]
AM29LV641ML@TSOP48 [(SA247-B005)]
AM29LV642G@FBGA64 [(SA655A-B038A-T064N001)]

AM29LV652D@FBGA63 [(SA642M-B026A-W048F001Y)]
AM29LV800B@PSOP44 [(SA638-B006)] AM29LV800B@TSOP48 [(SA247-B005)]
AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800BB@PSOP44 [(SA638-B006)]
AM29LV800BB@TSOP48 [(SA247-B005)]
AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800BT@PSOP44 [(SA638-B006)]
AM29LV800BT@TSOP48 [(SA247-B005)]
AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29LV800DB@PSOP44 [(SA638)]
AM29LV800DB@TSOP48 [(SA247-B005)]
AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29LV800DT@PSOP44 [(SA638)]
AM29LV800DT@TSOP48 [(SA247-B005)]
AM29LV800T@PSOP44 [(SA638-B006)] AM29LV800T@TSOP48 [(SA247-B005)]
AM29PDS322DB@FBGA48 [(SA642E-B026A-T072F001)]
AM29PDS322DT@FBGA48 [(SA642E-B026A-T072F001)]
AM29PL160CB@PSOP44 [(SA638-B006)]
AM29PL160CB@TSOP48 [(SA247-B005)]
AM29PL160CT@PSOP44 [(SA638-B006)]
AM29PL160CT@TSOP48 [(SA247-B005)]
AM29SL160CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29SL160CB@TSOP48 [(SA247-B005)]
AM29SL160CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29SL160CT@TSOP48 [(SA247-B005)]
AM29SL400CB@TSOP48 [(SA247-B005)]
AM29SL400CT@TSOP48 [(SA247-B005)]
AM29SL800BB@TSOP48 [(SA247-B005)]
AM29SL800BT@TSOP48 [(SA247-B005)]
AM29SL800CB@TSOP48 [(SA247-B005)]
AM29SL800CT@TSOP48 [(SA247-B005)]
AM29SL800DB@TSOP48 [(SA247-B005)]
AM29SL800DBUF@FBGA48 [(SA716A-B119B-M048F001Y)]
AM29SL800DBVG@FBGA48 [(SA716A-B119B-M048F001Y)]
AM29SL800DBVU@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29SL800DBWA@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29SL800DBWC@FBGA48 [(SA642R-B026A-W080F001N)]
AM29SL800DT@TSOP48 [(SA247-B005)]
AM29SL800DTUF@FBGA48 [(SA716A-B119B-M048F001Y)]

AM29SL800DTV@FBGA48 [(SA716A-B119B-M048F001Y)]
AM29SL800DTVU@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29SL800DTWA@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29SL800DTWC@FBGA48 [(SA642R-B026A-W080F001N)]
AM9716
AM9732
AM9732A
AM9764
AM9764@PLCC32 [(SA015A1T)]
BS128HD8V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]
BS128HD9V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]
BS128HE8V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]
BS128HE9V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]
BS128HF8V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]
BS128HF9V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]
BS640HD8V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]
BS640HD9V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]
BS640HE8V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]
BS640HE9V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]
BS640HF8V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]
BS640HF9V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]
DS42514(AM29DL163DB)@FBGA69 [(SA642B-B032A-Y072F001)]
DS42515(AM29DL164)@FBGA69 [(SA642B-B032A-Y072F001)]
DS42516(AM29DL324)@FBGA73 [(SA642A-B032A-Y096F001)]
DS42546(AM29DL163)@FBGA69 [(SA642B-B032A-Y072F001)]
DS42553(AM29DL323)@FBGA73 [(SA642A-B032A-Y096F001)]
DS42585(AM29DL323D)@FBGA73 [(SA642A-B032A-Y096F001)]
DS42587(AM29DL324D)@FBGA73 [(SA642A-B032A-Y096F001)]
DS42629(AM29DL640G)@VFBGA48 [(SA634A-B005A-Y048F001)]
DS42677(AM29LV128MH/L)@FBGA88 [(SA642A-B058A-Y096N001)]
DS42678(AM29LV320MT)@FBGA67 [(SA642E-B041A-T072F001)]
DS42689(AM29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
DS42690(AM29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]
DS42695(AM29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
DS42696(AM29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]
DS42701(AM29LV640MU)@FBGA88 [(SA642W-B116A-W088F001Y)]
DS42725(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]
DS42772A(AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]
M410000000(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M410000001(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M410000002(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M410000003(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M410000004(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]

M410000005 (AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M410000006 (AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M410000007 (AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M410000008 (AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M410000009 (AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M41000000A (AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M41000000B (AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M41000000C (AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M41000000D (AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M41000000E (AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M41000000F (AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M41000000G (AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000000H (AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000001W (AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000001X (AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000001Y (AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000001Z (AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M410000020 (AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M410000021 (AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M410000022 (AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M410000023 (AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M410000024 (AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M410000025 (AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M410000026 (AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M410000027 (AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002L (AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002M (AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002N (AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002O (AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002P (AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002Q (AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002R (AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002S (AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002T (AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002U (AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002V (AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000002W (AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000003D (AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000003E (AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000003F (AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000003G (AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M410000095 (AM41LV3204MT)@FBGA69 [(SA642A-B032A-Y096F001)]
M410000096 (AM41LV3204MB)@FBGA69 [(SA642A-B032A-Y096F001)]

M41000009B (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000009C (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
M41000009D (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000000 (AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000001 (AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000004 (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M420000005 (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M420000006 (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M420000007 (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000I (AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000J (AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000K (AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000L (AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000M (AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000N (AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000O (AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000P (AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000Q (AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000R (AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000S (AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000T (AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000U (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000V (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000W (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000000X (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001A (AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001B (AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001C (AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001D (AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001E (AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001F (AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001G (AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001H (AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001I (AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001J (AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001K (AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001L (AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001M (AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001N (AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001O (AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]
M42000001P (AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]
M420000022 (AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000023 (AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]

M420000024 (AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000025 (AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000026 (AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000027 (AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000028 (AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000029 (AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000002A (AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000002B (AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000002C (AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000002D (AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000002U (AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000002V (AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000002Y (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]
M42000002Z (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000030 (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000031 (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000032 (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000033 (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000034 (AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000035 (AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]
M42000004Y (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]
M42000004Z (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000050 (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000051 (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000052 (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000053 (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000054 (AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]
M420000055 (AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]
M42000005M (AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000005N (AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000005W (AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000005X (AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000005Y (AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M42000005Z (AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000060 (AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000061 (AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000070 (AM42BDS6408HE8)@BGA89 [(SA642A-B072A-Y096F001)]
M420000071 (AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]
M420000072 (AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]
M420000073 (AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]
M420000074 (AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]
M420000075 (AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]
M420000076 (AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]

M420000077 (AM42BDS6408HD4)@BG89 [(SA642A-B072A-Y096F001)]
M420000078 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
M420000079 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
M450000000 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]
M450000001 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]
M450000008 (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M450000009 (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000000A (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000000B (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000000S (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000000T (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000000U (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000000V (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000001C (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000001D (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000001E (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000001F (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000001W (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000001X (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000001Y (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]
M45000001Z (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]
M490000000 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]
M490000001 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000G (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000H (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000J (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000K (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000L (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000M (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000N (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000O (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000P (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000Q (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000R (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000S (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000T (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000000U (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000001A (AM49DL320BGB)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000001B (AM49DL320BGB)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000001Y (AM49PDL640AG)@FBGA73 [(SA642A-B032A-Y096N001)]
M49000001Z (AM49PDL640AG)@FBGA73 [(SA642A-B032A-Y096N001)]
M490000025 (AM49DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]
M490000026 (AM49DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]

M490000028 (AM49PDL127BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M490000029 (AM49PDL127BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M49000002I (AM49PDL127AH)@FBGA73 [(SA642A-B039A-Y096F001)]
M49000002J (AM49PDL127AH)@FBGA73 [(SA642A-B039A-Y096F001)]
M49000002T (AM49LV6408MT)@FBGA69 [(SA642A-B032A-Y096F001)]
M49000002U (AM49LV6408MB)@FBGA69 [(SA642A-B032A-Y096F001)]
M49000002V (AM49LV6408MT)@FBGA69 [(SA642A-B032A-Y096F001)]
M49000002X (AM49LV6408MB)@FBGA69 [(SA642A-B032A-Y096F001)]
M490000030 (AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M490000031 (AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M490000032 (AM49DL3208GB)@FBGA69 [(SA642A-B032A-Y096F001)]
M490000032 (AM49DL3208GT)@FBGA69 [(SA642A-B032A-Y096F001)]
M490000034 (AM49DL3208GT)@FBGA69 [(SA642A-B032A-Y096F001)]
M490000035 (AM49DL3208GB)@FBGA69 [(SA642A-B032A-Y096F001)]
M49000003A (AM49DL640BH)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003B (AM49DL640BH)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003C (AM49DL640BH)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003D (AM49DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003E (AM49DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003F (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003G (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003H (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003I (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003J (AM49DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003X (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003Y (AM49DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
M49000003Z (AM49LV6408MT)@FBGA69 [(SA642A-B032A-Y096F001)]
M49000004A (AM49LV6408MB)@FBGA69 [(SA642A-B032A-Y096F001)]
M49000004B (AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]
M49000004C (AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]
M49000004D (AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]
M49000004E (AM49BDS640AH)@FBGA89 [(SA642A-B072A-Y096F001)]
M49000004H (AM49LV128BMH)@FBGA64 [(SA642C-B039A-Y056F001)]
M49000004J (AM49LV128BML)@FBGA64 [(SA642C-B039A-Y056F001)]
M49000004K (AM49LV128BMH)@FBGA64 [(SA642C-B039A-Y056F001)]
M49000004L (AM49LV128BML)@FBGA64 [(SA642C-B039A-Y056F001)]
M49000004S (AM49LV128BMaH)@FBGA64 [(SA642C-B039A-Y056F001)]
M49000004T (AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]
M49000004U (AM49LV128BMaH)@FBGA64 [(SA642C-B039A-Y056F001)]
M49000004V (AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]
M4900000K (AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]
M4900000L (AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]
M500000000 (AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]

M500000001 (AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]
M500000008 (AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]
M500000009 (AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]
M50000004J (AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M50000004K (AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M50000004L (AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M50000004M (AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]
M50000004N (AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]
M50000004P (AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]
M550000000 (AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]
M550000001 (AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]
PDL127H53V (AM29PDL127H53)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL127H63V (AM29PDL127H63)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL127H68V (AM29PDL127H68)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL127H88V (AM29PDL127H88)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H53V (AM29PDL129H53)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H63V (AM29PDL129H63)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H68V (AM29PDL129H68)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H88V (AM29PDL129H88)@FBGA80 [(SA642A-B070A-Y096N001)]

PLD

M4A3-32/32@PLCC44 [(SA244)] [(SA245A)]	M4A3-32/32@TQFP44
M4A3-32/32@TQFP48 [(SA248)] [(SA244)]	M4A3-64/32@PLCC44
M4A3-64/32@TQFP44 [(SA245A)] [(SA248)]	M4A3-64/32@TQFP48
M4A5-32/32@PLCC44 [(SA244)] [(SA245A)]	M4A5-32/32@TQFP44
M4A5-32/32@TQFP48 [(SA248)] [(SA244)]	M4A5-64/32@PLCC44
M4A5-64/32@TQFP44 [(SA245A)] [(SA248)]	M4A5-64/32@TQFP48
PALC16L8Q [(SA001A)]	PALC16L8Q@PLCC20
PALC16L8Z [(SA001A)]	PALC16L8Z@PLCC20
PALC16R4Q [(SA001A)]	PALC16R4Q@PLCC20
PALC16R4Z [(SA001A)]	PALC16R4Z@PLCC20

PALC16R6Q [(SA001A)]	PALC16R6Q@PLCC20
PALC16R6Z [(SA001A)]	PALC16R6Z@PLCC20
PALC16R8Q [(SA001A)]	PALC16R8Q@PLCC20
PALC16R8Z [(SA001A)]	PALC16R8Z@PLCC20
PALCE16V8H [(SA001A)]	PALCE16V8H@PLCC20
PALCE16V8H@SOIC20 [(SA404)]	
PALCE16V8Q PALCE16V8Q@PLCC20 [(SA001A)] [(SA404)]	PALCE16V8Q@SOIC20
PALCE16V8Z [(SA001A)]	PALCE16V8Z@PLCC20
PALCE16V8Z@SOIC20 [(SA404)]	
PALCE20RA10 PALCE20RA10@PLCC28 [(SA008A)] [(SA404)]	PALCE20RA10@SOIC24
PALCE20RA10H [(SA008A)]	PALCE20RA10H@PLCC28
PALCE20RA10H@SOIC24 [(SA404)]	
PALCE20RA10Q PALCE20RA10Q@PLCC28 [(SA008A)] [(SA404)]	PALCE20RA10Q@SOIC24
PALCE20V8H [(SA008A)]	PALCE20V8H@PLCC28
PALCE20V8H@SOIC24 [(SA404)]	
PALCE20V8Q PALCE20V8Q@PLCC28 [(SA008A)] [(SA404)]	PALCE20V8Q@SOIC24
PALCE22V10H [(SA008A)]	PALCE22V10H@PLCC28
PALCE22V10H@SOIC24 [(SA404)]	
PALCE22V10Q PALCE22V10Q@PLCC28 [(SA008A)] [(SA404)]	PALCE22V10Q@SOIC24
PALCE22V10Z [(SA008A)]	PALCE22V10Z@PLCC28
PALCE22V10Z@SOIC24 [(SA404)]	
PALLV16V8 PALLV16V8@PLCC20 [(SA001A)]	PALLV16V8@SOIC20

[(SA404)]
PALLV16V8Z
[(SA001A)]
PALLV16V8Z@SOIC20 [(SA404)]

PALLV16V8Z@PLCC20

MICROCONTROLLER

AM87C51
[(SA244)]
AM87C51@TQFP44 [(SA245A)]
AM87C521
AM87C521@PLCC44 [(SA244)]
[(SA245A)]
AM87C541
[(SA244)]
AM87C541@TQFP44 [(SA245A)]

AM87C51@PLCC44

AM87C521@TQFP44

AM87C541@PLCC44

AMI SEMICONDUCTOR

E (E) PROM / FRAM / NVRAM

N256S0818HDA
[(SA602A)]
N256S0818HDA@TSSOP8 [(SA026)]
N256S0830HDA
N256S0830HDA@SOIC8 [(SA602A)]
[(SA026)]
N64S0818HDA
[(SA602A)]
N64S0818HDA@TSSOP8 [(SA026)]
N64S0830HDA
N64S0830HDA@SOIC8 [(SA602A)]
[(SA026)]

N256S0818HDA@SOIC8

N256S0830HDA@TSSOP8

N64S0818HDA@SOIC8

N64S0830HDA@TSSOP8

AMIC

E (E) PROM / FRAM / NVRAM

A25L010

A25L010[150mil]@SOP8

[(SA602A)]
A25L010[209mil]@SOP8 [(SA605A)]
A25L016
A25L016@SOP8 [(SA023A)]
A25L020
A25L020[150mil]@SOP8 [(SA602A)] A25L020[209mil]@SOP8
[(SA605A)]
A25L032 A25L032@SOP8
[(SA023A)]
A25L040P A25L040P@QFN8
[(SA683)]
A25L040P@SOP16 [(SA404)] A25L040P@SOP8
[(SA602A)]
A25L05P(Bottom) A25L05P(Bottom)@QFN8
[(SA683)]
A25L05P(Bottom)[150mil]@SOP8 [(SA602A)]
A25L05P(Bottom)[209mil]@SOP8 [(SA605A)]
A25L05P(Top) A25L05P(Top)@QFN8
[(SA683)]
A25L05P(Top)[150mil]@SOP8 [(SA602A)]
A25L05P(Top)[209mil]@SOP8 [(SA605A)]
A25L080P A25L080P@QFN8
[(SA683)]
A25L080P@SOP16 [(SA404)] A25L080P@SOP8
[(SA023A)]
A25L10P(Bottom) A25L10P(Bottom)@QFN8
[(SA683)]
A25L10P(Bottom)[150mil]@SOP8 [(SA602A)]
A25L10P(Bottom)[209mil]@SOP8 [(SA605A)]
A25L10P(Top) A25L10P(Top)@QFN8
[(SA683)]
A25L10P(Top)[150mil]@SOP8 [(SA602A)]
A25L10P(Top)[209mil]@SOP8 [(SA605A)]
A25L16P(Bottom)@QFN8 [(SA683)]
A25L16P(Bottom)@QFN8(ISP) [ISP-HEADER01]
A25L16P(Bottom)@SOP16 [(SA404)]
A25L16P(Bottom)@SOP16(ISP) [ISP-HEADER01]
A25L16P(Bottom)@SOP8 [(SA023A)]
A25L16P(Bottom)@SOP8(ISP) [ISP-HEADER01]
A25L16P(Top)@QFN8 [(SA683)]
A25L16P(Top)@QFN8(ISP) [ISP-HEADER01]
A25L16P(Top)@SOP16 [(SA404)]
A25L16P(Top)@SOP16(ISP) [ISP-HEADER01]

A25L16P(Top)@SOP8 [(SA023A)]
 A25L16P(Top)@SOP8(ISP) [ISP-HEADER01]
 A25L20P(Bottom) A25L20P(Bottom)@QFN8
 [(SA683)]
 A25L20P(Bottom)[150mil]@SOP8 [(SA602A)]
 A25L20P(Bottom)[209mil]@SOP8 [(SA605A)]
 A25L20P(Top) A25L20P(Top)@QFN8
 [(SA683)]
 A25L20P(Top)[150mil]@SOP8 [(SA602A)]
 A25L20P(Top)[209mil]@SOP8 [(SA605A)]
 A25L40P(Bottom Boot)
 A25L40P(Bottom Boot)@QFN8 [(SA683)]
 A25L40P(Bottom Boot)@SOP16 [(SA404)]
 A25L40P(Bottom Boot)@SOP8 [(SA602A)]
 A25L40P(Top Boot) A25L40P(Top Boot)@QFN8
 [(SA683)]
 A25L40P(Top Boot)@SOP16 [(SA404)]
 A25L40P(Top Boot)@SOP8 [(SA602A)]
 A25L42P(Bottom Boot)
 A25L42P(Bottom Boot)@QFN8 [(SA683)]
 A25L42P(Bottom Boot)@SOP16 [(SA404)]
 A25L42P(Bottom Boot)@SOP8 [(SA602A)]
 A25L42P(Top Boot) A25L42P(Top Boot)@QFN8
 [(SA683)]
 A25L42P(Top Boot)@SOP16 [(SA404)]
 A25L42P(Top Boot)@SOP8 [(SA602A)]
 A25L512 A25L512[150mil]@SOP8
 [(SA602A)]
 A25L512[209mil]@SOP8 [(SA605A)]
 A25L80P
 A25L80P@QFN8 [(SA683)] A25L80P@SOP16
 [(SA404)]
 A25L80P@SOP8 [(SA023A)] A25L82P(Bottom
 Boot)
 A25L82P(Bottom Boot)@QFN8 [(SA683)]
 A25L82P(Bottom Boot)@SOP16 [(SA404)]
 A25L82P(Bottom Boot)@SOP8 [(SA023A)]
 A25L82P(Top Boot) A25L82P(Top Boot)@QFN8
 [(SA683)]
 A25L82P(Top Boot)@SOP16 [(SA404)]
 A25L82P(Top Boot)@SOP8 [(SA023A)]
 A25LS080P A25LS080P@QFN8
 [(SA683)]

A25LS080P@SOP16 [(SA404)]	A25LS080P@SOP8
[(SA023A)]	
A27020	A27020@PLCC32
[(SA015A1T)]	
A27020@TSOP32 [(SA410T)]	
A27020L	
A27020L@PLCC32 [(SA015A1T)]	A27020L@TSOP32
[(SA410T)]	
A275308	A275308@PLCC32
[(SA015A1T)]	
A276308	A276308
(E)	
A276308(E)@PLCC32 [(SA015A1T)]	A276308(E)@SOIC28
[(SA404)]	
A276308@PLCC32 [(SA015A1T)]	A276308@SOIC28
[(SA404)]	
A276308A	A276308A
(L)	
A276308A(L)@PLCC32 [(SA015A1T)]	A276308A(L)@SOIC28
[(SA404)]	
A276308A@PLCC32 [(SA015A1T)]	A276308A@SOIC28
[(SA404)]	
A277308	A277308@PLCC32
[(SA015A1T)]	
A277308A	A277308A@PLCC32
[(SA015A1T)]	
A278308	A278308@PLCC32
[(SA015A1T)]	
A278308A	A278308A
(L)	
A278308A(L)@PLCC32 [(SA015A1T)]	A278308A@PLCC32
[(SA015A1T)]	
A279308	A279308@PLCC32
[(SA015A1T)]	
A290011T	A290011T@PLCC32
[(SA015A1T)]	
A290011T@TSOP32 [(SA410T)]	
A290011U	
A290011U@PLCC32 [(SA015A1T)]	A290011U@TSOP32
[(SA410T)]	
A29001T	A29001T@PLCC32
[(SA015A1T)]	
A29001T@TSOP32 [(SA410T)]	

A29001U	
A29001U@PLCC32 [(SA015A1T)]	A29001U@TSOP32
[(SA410T)]	
A290021T	A290021T@PLCC32
[(SA015A1T)]	
A290021T@TSOP32 [(SA410T)]	
A290021U	
A290021U@PLCC32 [(SA015A1T)]	A290021U@TSOP32
[(SA410T)]	
A29002T	A29002T@PLCC32
[(SA015A1T)]	
A29002T@TSOP32 [(SA410T)]	
A29002U	
A29002U@PLCC32 [(SA015A1T)]	A29002U@TSOP32
[(SA410T)]	
A29010	A29010@PLCC32
[(SA015A1T)]	
A29010@TSOP32 [(SA410T)]	
A29040	
A29040@PLCC32 [(SA015A1T)]	A29040@TSOP32
[(SA410T)]	
A29040A	A29040A@PLCC32
[(SA015A1T)]	
A29040A@TSOP32 [(SA410T)]	
A29040B	
A29040B@PLCC32 [(SA015A1T)]	A29040B@TSOP32
[(SA410T)]	
A29400TM@PSOP44 [(SA638)]	A29400TV@TSOP48 [(SA247-
B005)]	
A29400UM@PSOP44 [(SA638)]	A29400UV@TSOP48 [(SA247-
B005)]	
A29512	A29512@PLCC32
[(SA015A1T)]	
A29512@TSOP32 [(SA410T)]	
A29512A	
A29512A@PLCC32 [(SA015A1T)]	A29512A@TSOP32
[(SA410T)]	
A29800TM@PSOP44 [(SA638)]	A29800TV@TSOP48 [(SA247-
B005)]	
A29800UM@PSOP44 [(SA638)]	A29800UV@TSOP48 [(SA247-
B005)]	
A29DL162TG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29DL162TV@TSOP48 [(SA247-B005)]	

A29DL162UG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL162UV@TSOP48 [(SA247-B005)]
A29DL163TG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL163TV@TSOP48 [(SA247-B005)]
A29DL163UG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL163UV@TSOP48 [(SA247-B005)]
A29DL164TG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL164TV@TSOP48 [(SA247-B005)]
A29DL164UG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL164UV@TSOP48 [(SA247-B005)]
A29DL320FTV@TSOP48 [(SA247-B005)]
A29DL320FUV@TSOP48 [(SA247-B005)]
A29DL322TG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL322TV@TSOP48 [(SA247-B005)]
A29DL322UG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL322UV@TSOP48 [(SA247-B005)]
A29DL323TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL323TG@FBGA63 [(SA642A-B026A-Y096F001)]
A29DL323TV(New)@TSOP48 [(SA247-B005)]
A29DL323TV@TSOP48 [(SA247-B005)]
A29DL323UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL323UG@FBGA63 [(SA642A-B026A-Y096F001)]
A29DL323UV(New)@TSOP48 [(SA247-B005)]
A29DL323UV@TSOP48 [(SA247-B005)]
A29DL324TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL324TG@FBGA63 [(SA642A-B026A-Y096F001)]
A29DL324TV(New)@TSOP48 [(SA247-B005)]
A29DL324TV@TSOP48 [(SA247-B005)]
A29DL324UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]
A29DL324UG@FBGA63 [(SA642A-B026A-Y096F001)]
A29DL324UV(New)@TSOP48 [(SA247-B005)]
A29DL324UV@TSOP48 [(SA247-B005)] A29L004ATL@PLCC32
[(SA015A1T)]
A29L004ATV@TSOP32 [(SA410T)] A29L004ATW@TSOP40
[(SA409T)]
A29L004ATY@VSOP32 [(SA620)] A29L004AUL@PLCC32
[(SA015A1T)]
A29L004AUV@TSOP32 [(SA410T)] A29L004AUW@TSOP40
[(SA409T)]
A29L004AUY@VSOP32 [(SA620)] A29L004T@PLCC32
[(SA015A1T)]
A29L004T@TSOP32 [(SA410T)] A29L004T@TSOP40
[(SA409T)]

B005)]
A29L400AUG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29L400AUM@PSOP44 [(SA638)] A29L400AUV@TSOP48 [(SA247-
B005)]
A29L400TG@FBGA48 [(SA642B-B026A-Y072F001)]
A29L400TM@PSOP44 [(SA638)] A29L400TV@TSOP48 [(SA247-
B005)]
A29L400UG@FBGA48 [(SA642B-B026A-Y072F001)]
A29L400UM@PSOP44 [(SA638)] A29L400UV@TSOP48 [(SA247-
B005)]
A29L800ATG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29L800ATM@PSOP44 [(SA638)] A29L800ATV@TSOP48 [(SA247-
B005)]
A29L800AUG@FBGA48 [(SA642G-B026A-T048F001Y)]
A29L800AUM@PSOP44 [(SA638)] A29L800AUV@TSOP48 [(SA247-
B005)]
A29L800HTG@FBGA48 [(SA642B-B026A-Y072F001)]
A29L800HTM@PSOP44 [(SA638)] A29L800HTV@TSOP48 [(SA247-
B005)]
A29L800HUG@FBGA48 [(SA642B-B026A-Y072F001)]
A29L800HUM@PSOP44 [(SA638)] A29L800HUV@TSOP48 [(SA247-
B005)]
A29L800TG@FBGA48 [(SA642B-B026A-Y072F001)]
A29L800TM@PSOP44 [(SA638)] A29L800TV@TSOP48 [(SA247-
B005)]
A29L800UG@FBGA48 [(SA642B-B026A-Y072F001)]
A29L800UM@PSOP44 [(SA638)] A29L800UV@TSOP48 [(SA247-
B005)]
A49LF004@PLCC32 [(SA015A1T)] A49LF004@VSOP32
[(SA620)]
A49LF004M@PLCC32 [(SA015A1T)] A49LF004M@VSOP32
[(SA620)]
A49LF040ATL@PLCC32 [(SA015A1T)] A49LF040ATX@VSOP32
[(SA620)]
A49LF040ATY@VSOP32 [(SA620)] A49LF040TL@PLCC32
[(SA015A1T)]
A49LF040TX@VSOP32 [(SA620)] A50FW040@PLCC32
[(SA015A1T)]
A50FW040@VSOP32 [(SA620)] A50FW040M@PLCC32
[(SA015A1T)]
A50FW040M@VSOP32 [(SA620)] A50LPW040@PLCC32
[(SA015A1T)]
A50LPW040@TSOP32 [(SA410T)]

A617308
A617308@TSOP32 [(SA410T)]
A61L5308
A61L5308@TSOP28 [(SA430T)] A623308
(M)
A623308(R)@TSOP28 [(SA430T)] A623308(V)@TSOP28
[(SA430T)]
A625308(M) A625308(R)@TSOP28
[(SA430T)]
A625308(V)@TSOP28 [(SA430T)]
A62L256
A62L256(M) A62L256(R)@TSOP28
[(SA430T)]
A62L256(V)@TSOP28 [(SA430T)] A62S6308
(M)
A62S6308(X)@TSOP32 [(SA410T)] A62S7308A
(M)
A62S7308A(X)@TSOP32 [(SA410T)] A62S8308A
(M)
A62S8308A(X)@TSOP32 [(SA410T)] A62W5308
(M)
A62W5308(R)@TSOP28 [(SA430T)] A62W5308(V)@TSOP28
[(SA430T)]
A81L801TG@FBGA69 [(SA642A-B078A-Y096F001Y)]
A81L801UG@FBGA69 [(SA642A-B078A-Y096F001Y)]
A82DL1622TG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1622UG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1624TG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1624UG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1632TG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1632UG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1634TG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1634UG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1642TG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1642UG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1644TG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL1644UG@FBGA69 [(SA642A-B032A-Y096F001Y)]
A82DL32216TG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL32216UG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3224TG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3224UG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3228TG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3228UG@FBGA69 [(SA642A-B254A-Y096F001Y)]

A82DL32316TG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL32316UG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3234TG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3234UG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3238TG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3238UG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL32416TG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL32416UG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3244TG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3244UG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3248TG@FBGA69 [(SA642A-B254A-Y096F001Y)]
A82DL3248UG@FBGA69 [(SA642A-B254A-Y096F001Y)]

ANACHIP

E (E) PROM / FRAM / NVRAM

27CX010	27CX010@PLCC32
[(SA015A1T)]	
27CX010@TSOP32 [(SA410T)]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[(SA602A)]	
93C46A	93C46A@SOIC8
[(SA602A)]	
93C56A	93C56A@SOIC8
[(SA602A)]	
93C66A	93C66A@SOIC8
[(SA602A)]	
93CX46	93CX46@SOIC8
[(SA602A)]	
93CX56	93CX56@SOIC8
[(SA602A)]	
93CX66	93CX66@SOIC8
[(SA602A)]	
AM24LC02	AM24LC02@SOIC8

[(SA602A)]	
AM24LC02@TSSOP8 [(SA026)]	
AM24LC04	
AM24LC04@SOIC8 [(SA602A)]	AM24LC04@TSSOP8
[(SA026)]	
AM24LC08	
[(SA602A)]	
AM24LC08@TSSOP8 [(SA026)]	AM24LC08@SOIC8
AM24LC16	
AM24LC16@SOIC8 [(SA602A)]	AM24LC16@TSSOP8
[(SA026)]	
AM24LC21	
[(SA602A)]	
AM24LC21@TSSOP8 [(SA026)]	AM24LC21@SOIC8
AM24LC21B	
AM24LC21B@SOIC8 [(SA602A)]	AM24LC21B@TSSOP8
[(SA026)]	
AM93LC46(08bit)	AM93LC46(08bit)@SOIC8
[(SA602A)]	
AM93LC46(08bit)@TSOP8 [(SA026)]	AM93LC46
(16bit)	
AM93LC46(16bit)@SOIC8 [(SA602A)]	AM93LC46(16bit)@TSOP8
[(SA026)]	
AM93LC56(08bit)	AM93LC56(08bit)@SOIC8
[(SA602A)]	
AM93LC56(08bit)@TSOP8 [(SA026)]	AM93LC56
(16bit)	
AM93LC56(16bit)@SOIC8 [(SA602A)]	AM93LC56(16bit)@TSOP8
[(SA026)]	
AM93LC66(08bit)	AM93LC66(08bit)@SOIC8
[(SA602A)]	
AM93LC66(08bit)@TSOP8 [(SA026)]	AM93LC66
(16bit)	
AM93LC66(16bit)@SOIC8 [(SA602A)]	AM93LC66(16bit)@TSOP8
[(SA026)]	
AM93LC86(08bit)	AM93LC86(08bit)@SOIC8
[(SA602A)]	
AM93LC86(08bit)@TSOP8 [(SA026)]	AM93LC86
(16bit)	
AM93LC86(16bit)@SOIC8 [(SA602A)]	AM93LC86(16bit)@TSOP8
[(SA026)]	

PLD

PA7024	PA7024(J)@PLCC28
[(SA008A)]	
PA7024(JN)@PLCC28 [(SA008A)]	PA7024@SOIC24
[(SA404)]	
PA7128	PA7128@PLCC28
[(SA008A)]	
PA7128@SOIC28 [(SA404)]	
PA7140	
PA7140@PLCC44 [(SA244)]	PA7140@TQFP44
[(SA245A)]	
PA7536	PA7536@PLCC28
[(SA008A)]	
PA7536@SOIC28 [(SA404)]	
PA7540	
PA7540(J)@PLCC28 [(SA008A)]	PA7540(JN)@PLCC28
[(SA008A)]	
PA7572	PA7572@PLCC44
[(SA244)]	
PA7572@TQFP44 [(SA245A)]	
PEEL18CV8Z	
PEEL18CV8Z@PLCC20 [(SA001A)]	PEEL18CV8Z@SOIC20
[(SA404)]	
PEEL18CV8Z@TSOP20 [(SA026)]	
PEEL18LV8Z	
PEEL18LV8Z@PLCC20 [(SA001A)]	PEEL18LV8Z@SOIC20
[(SA404)]	
PEEL18LV8Z@TSOP20 [(SA026)]	
PEEL22CV10A	
PEEL22CV10A@PLCC28 [(SA008A)]	PEEL22CV10A@SOIC24
[(SA404)]	
PEEL22CV10A@TSOP24 [(SA026)]	PEEL22CV10A
+	
PEEL22CV10A+@PLCC28 [(SA008A)]	PEEL22CV10A+@SOIC24
[(SA404)]	
PEEL22CV10A+@TSOP24 [(SA026)]	PEEL22CV10A+
+	
PEEL22CV10A++@PLCC28 [(SA008A)]	PEEL22CV10A++@SOIC24
[(SA404)]	
PEEL22CV10A++@TSOP24 [(SA026)]	
PEEL22CV10AZ	
PEEL22CV10AZ@PLCC28 [(SA008A)]	PEEL22CV10AZ@SOIC24

[(SA404)]	
PEEL22CV10AZ@TSOP24 [(SA026)]	PEEL22CV10AZ
+	
PEEL22CV10AZ+@PLCC28 [(SA008A)]	PEEL22CV10AZ+@SOIC24
[(SA404)]	
PEEL22CV10AZ+@TSOP24 [(SA026)]	PEEL22CV10AZ+
+	
PEEL22CV10AZ++@PLCC28 [(SA008A)]	PEEL22CV10AZ++@SOIC24
[(SA404)]	
PEEL22CV10AZ++@TSOP24 [(SA026)]	
PEEL22LV10AZ	
PEEL22LV10AZ@PLCC28 [(SA008A)]	PEEL22LV10AZ@SOIC24
[(SA404)]	
PEEL22LV10AZ@TSOP24 [(SA026)]	PEEL22LV10AZ
+	
PEEL22LV10AZ+@PLCC28 [(SA008A)]	PEEL22LV10AZ+@SOIC24
[(SA404)]	
PEEL22LV10AZ+@TSOP24 [(SA026)]	PEEL22LV10AZ+
+	
PEEL22LV10AZ++@PLCC28 [(SA008A)]	PEEL22LV10AZ++@SOIC24
[(SA404)]	
PEEL22LV10AZ++@TSOP24 [(SA026)]	

APLUS FLASH

E (E) PROM / FRAM / NVRAM

AF24BC01	AF24BC01@SOIC8
[(SA602A)]	
AF24BC01@TSSOP8 [(SA026)]	
AF24BC02	
AF24BC02@SOIC8 [(SA602A)]	AF24BC02@TSSOP8
[(SA026)]	
AF24BC04	AF24BC04@SOIC8
[(SA602A)]	
AF24BC04@TSSOP8 [(SA026)]	
AF24BC08	
AF24BC08@SOIC8 [(SA602A)]	AF24BC08@TSSOP8
[(SA026)]	
AF24BC128	AF24BC128@SOIC8
[(SA602A)]	
AF24BC128@TSOP8 [(SA026)]	

AF24BC16	
AF24BC16@SOIC8 [(SA602A)]	AF24BC16@TSSOP8
[(SA026)]	
AF24BC256	AF24BC256@SOIC8
[(SA602A)]	
AF24BC256@TSOP8 [(SA026)]	
AF24BC32	
AF24BC32@SOIC8 [(SA602A)]	AF24BC32@TSOP8
[(SA026)]	
AF24BC64	AF24BC64@SOIC8
[(SA602A)]	
AF24BC64@TSOP8 [(SA026)]	
AF24C128	
AF24C128@SOIC8 [(SA602A)]	AF24C128@TSOP8
[(SA026)]	
AF24C256	AF24C256@SOIC8
[(SA602A)]	
AF24C256@TSOP8 [(SA026)]	
AF24C32	
AF24C32@SOIC8 [(SA602A)]	AF24C32@TSOP8
[(SA026)]	
AF24C64	AF24C64@SOIC8
[(SA602A)]	
AF24C64@TSOP8 [(SA026)]	
AF25BC128	
AF25BC128@SOIC8 [(SA602A)]	AF25BC128@TSOP8
[(SA026)]	
AF25BC256	AF25BC256@SOIC8
[(SA602A)]	
AF25BC256@TSOP8 [(SA026)]	AF93BC46
(08bit)	
AF93BC46(08bit)@SOIC8 [(SA602A)]	AF93BC46(08bit)@TSOP8
[(SA026)]	
AF93BC46(16bit)	AF93BC46(16bit)@SOIC8
[(SA602A)]	
AF93BC46(16bit)@TSOP8 [(SA026)]	AF93BC56
(08bit)	
AF93BC56(08bit)@SOIC8 [(SA602A)]	AF93BC56(08bit)@TSOP8
[(SA026)]	
AF93BC56(16bit)	AF93BC56(16bit)@SOIC8
[(SA602A)]	
AF93BC56(16bit)@TSOP8 [(SA026)]	AF93BC66
(08bit)	

AF93BC66(08bit)@SOIC8 [(SA602A)]	AF93BC66(08bit)@TSOP8
[(SA026)]	
AF93BC66(16bit)	AF93BC66(16bit)@SOIC8
[(SA602A)]	
AF93BC66(16bit)@TSOP8 [(SA026)]	AF93BC86
(08bit)	
AF93BC86(08bit)@SOIC8 [(SA602A)]	AF93BC86(08bit)@TSOP8
[(SA026)]	
AF93BC86(16bit)	AF93BC86(16bit)@SOIC8
[(SA602A)]	
AF93BC86(16bit)@TSOP8 [(SA026)]	AF93C46
(08bit)	
AF93C46(08bit)@SOIC8 [(SA602A)]	AF93C46(08bit)@TSOP8
[(SA026)]	
AF93C46(16bit)	AF93C46(16bit)@SOIC8
[(SA602A)]	
AF93C46(16bit)@TSOP8 [(SA026)]	AF93C56
(08bit)	
AF93C56(08bit)@SOIC8 [(SA602A)]	AF93C56(08bit)@TSOP8
[(SA026)]	
AF93C56(16bit)	AF93C56(16bit)@SOIC8
[(SA602A)]	
AF93C56(16bit)@TSOP8 [(SA026)]	AF93C66
(08bit)	
AF93C66(08bit)@SOIC8 [(SA602A)]	AF93C66(08bit)@TSOP8
[(SA026)]	
AF93C66(16bit)	AF93C66(16bit)@SOIC8
[(SA602A)]	
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86
(08bit)	
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8
[(SA026)]	
AF93C86(16bit)	AF93C86(16bit)@SOIC8
[(SA602A)]	
AF93C86(16bit)@TSOP8 [(SA026)]	

ARTSCHIP

E(E) PROM/FRAM/NVRAM

24AA02	24AA02@MSOP8
[(SA666)]	

24AA02@SOIC8 [(SA602A)]	24AA02@SOT5
[(SA698)]	
24AA02@TSSOP8 [(SA026)]	
24LC01A	
24LC01A@SOIC8 [(SA602A)]	24LC01A@SOT5
[(SA698)]	
24LC01A@TSSOP8 [(SA026)]	
24LC01B	
24LC01B@SOIC8 [(SA602A)]	24LC01B@SOT5
[(SA698)]	
24LC01B@TSSOP8 [(SA026)]	
24LC02A	
24LC02A@SOIC8 [(SA602A)]	24LC02A@SOT5
[(SA698)]	
24LC02A@TSSOP8 [(SA026)]	
24LC02B	
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8
[(SA602A)]	
24LC02B@SOT5 [(SA698)]	24LC02B@TSSOP8
[(SA026)]	
24LC04A	24LC04A@SOIC8
[(SA602A)]	
24LC04A@SOT5 [(SA698)]	24LC04A@TSSOP8
[(SA026)]	
24LC04B	24LC04B@MSOP8
[(SA666)]	
24LC04B@SOIC8 [(SA602A)]	24LC04B@SOT5
[(SA698)]	
24LC04B@TSSOP8 [(SA026)]	
24LC08A	
24LC08A@SOIC8 [(SA602A)]	24LC08A@SOT5
[(SA698)]	
24LC08A@TSSOP8 [(SA026)]	
24LC08B	
24LC08B@MSOP8 [(SA666)]	24LC08B@SOIC8
[(SA602A)]	
24LC08B@SOT5 [(SA698)]	24LC08B@TSSOP8
[(SA026)]	
24LC16A	24LC16A@SOIC8
[(SA602A)]	
24LC16A@SOT5 [(SA698)]	24LC16A@TSSOP8
[(SA026)]	
24LC32	24LC32@SOIC14

[(SA026)]	
24LC32@SOIC8 [(SA602A)]	24LC32@TSSOP8
[(SA026)]	
24LC64	24LC64@SOIC14
[(SA026)]	
24LC64@SOIC8 [(SA602A)]	24LC64@TSSOP8
[(SA026)]	

ASAHI KASEI(AKM)

E (E) PROM / FRAM / NVRAM

AK27CX161	
AK27CX162	
AK27CX321	
AK27CX322	
AK27CX641	
AK27CX642	
AK6002A(F)@SOP8 [(SA602A)]	AK6002A(V)@TSSOP8
[(SA026)]	
AK6003A(V)@TSSOP8 [(SA026)]	AK6004A(F)@SOP8
[(SA602A)]	
AK6004A(M)@SSOP8 [(SA605A)]	AK6008A(F)@SOP8
[(SA602A)]	
AK6010A(F)@SOP8 [(SA602A)]	AK6012A(F)@SOP8
[(SA602A)]	
AK6416A(M)@SSOP8 [(SA026)]	AK6416C(F)@SOP8
[(SA602A)]	
AK6420A(F)@SOP8 [(SA602A)]	AK6420A(M)@SSOP8
[(SA605A)]	
AK6420B(H)@MSOP8 [(SA666)]	AK6440A(F)@SOP8
[(SA602A)]	
AK6440A(M)@SSOP8 [(SA605A)]	AK6440B(H)@MSOP8
[(SA666)]	
AK6480A(F)@SOP8 [(SA602A)]	AK6480A(M)@SSOP8
[(SA605A)]	
AK6480B(H)@MSOP8 [(SA666)]	AK6480C(F)@SOP8
[(SA602A)]	
AK6480C(H)@MSOP8 [(SA666)]	AK6480C(L)
@SON8	
AK6480C(M)@SSOP8 [(SA605A)]	AK6481C(H)@MSOP8
[(SA666)]	

AK6481C(M)@SSOP8 [(SA605A)]	AK6508C(T)@MSOP8
[(SA666)]	
AK6508C(U)@USON8	AK6510C(L)
@SONW8	
AK6510C(M)@SSOP8 [(SA026)]	AK6512C(L)
@SONW8	
AK6512C(M)@SSOP8 [(SA026)]	AK6514C(F)@SOP8
[(SA602A)]	
AK6514C(N)@QFN20 [(SA692)]	AK6516C(F)@SOP8
[(SA602A)]	
AK93C10A(F)@SOP8 [(SA602A)]	AK93C41A(V)@TSSOP8
[(SA026)]	
AK93C45	AK93C45(F)@SOP8
[(SA602A)]	
AK93C45A(F)@SOP8 [(SA602A)]	AK93C45A(NF)@SOP8
[(SA602A)]	
AK93C45A(V)@TSSOP8 [(SA026)]	AK93C45B(H)@MSOP8
[(SA666)]	
AK93C45B(L)@SON8	AK93C45C(T)@MSOP8
[(SA666)]	
AK93C45C(U)@USON8	
AK93C45L	
AK93C45L(F)@SOP8 [(SA602A)]	
AK93C46	
AK93C46(F)@SOP8 [(SA602A)]	AK93C46A(F)@SOP8
[(SA602A)]	
AK93C46A(NF)@SOP8 [(SA602A)]	AK93C46A(V)@TSSOP8
[(SA026)]	
AK93C46B(H)@MSOP8 [(SA666)]	AK93C46B(L)
@SON8	
AK93C46C(T)@MSOP8 [(SA666)]	AK93C46C(U)
@USON8	
AK93C46L	AK93C46L(F)@SOP8
[(SA602A)]	
AK93C51A(V)@TSSOP8 [(SA026)]	
AK93C55	
AK93C55(F)@SOP8 [(SA602A)]	AK93C55A(F)@SOP8
[(SA602A)]	
AK93C55A(NF)@SOP8 [(SA602A)]	AK93C55A(V)@TSSOP8
[(SA026)]	
AK93C55B(H)@MSOP8 [(SA666)]	AK93C55B(L)
@SON8	
AK93C55C(T)@MSOP8 [(SA666)]	AK93C55C(U)

@USON8	
AK93C55L	AK93C55L(F)@SOP8
[(SA602A)]	
AK93C56	AK93C56(F)@SOP8
[(SA602A)]	
AK93C56A(F)@SOP8 [(SA602A)]	AK93C56A(NF)@SOP8
[(SA602A)]	
AK93C56A(V)@TSSOP8 [(SA026)]	AK93C56B(H)@MSOP8
[(SA666)]	
AK93C56B(L)@SON8	AK93C56C(T)@MSOP8
[(SA666)]	
AK93C56C(U)@USON8	
AK93C56L	
AK93C56L(F)@SOP8 [(SA602A)]	AK93C61A(V)@TSSOP8
[(SA026)]	
AK93C65	AK93C65(F)@SOP8
[(SA602A)]	
AK93C65A(F)@SOP8 [(SA602A)]	AK93C65A(NF)@SOP8
[(SA602A)]	
AK93C65A(V)@TSSOP8 [(SA026)]	AK93C65B(H)@MSOP8
[(SA666)]	
AK93C65B(L)@SON8	AK93C65C(T)@MSOP8
[(SA666)]	
AK93C65C(U)@USON8	
AK93C65L	
AK93C65L(F)@SOP8 [(SA602A)]	
AK93C66	
AK93C66(F)@SOP8 [(SA602A)]	AK93C66A(F)@SOP8
[(SA602A)]	
AK93C66A(NF)@SOP8 [(SA602A)]	AK93C66A(V)@TSSOP8
[(SA026)]	
AK93C66B(H)@MSOP8 [(SA666)]	AK93C66B(L)
@SON8	
AK93C66C(T)@MSOP8 [(SA666)]	AK93C66C(U)
@USON8	
AK93C66L	AK93C66L(F)@SOP8
[(SA602A)]	
AK93C75	AK93C75(F)@SOP8
[(SA602A)]	
AK93C75A(F)@SOP8 [(SA602A)]	AK93C75A(NF)@SOP8
[(SA602A)]	
AK93C75A(V)@TSSOP8 [(SA026)]	AK93C75B(H)@MSOP8
[(SA666)]	

AK93C75L [(SA602A)]	AK93C75L (F)@SOP8
AK93C85 [(SA602A)]	AK93C85 (F)@SOP8
AK93C85L [(SA602A)]	AK93C85L (F)@SOP8
AK93C95A (F)@SOP8 [(SA602A)] [(SA026)]	AK9822 (M)@SSOP8
AK9824 (M)@SSOP8 [(SA026)] [(SA602)]	AK9844@SOIC14

ASD

E (E) PROM / FRAM / NVRAM

AE29F1008
AE29F2008

ASI

E (E) PROM / FRAM / NVRAM

AS58C1001 [(SA015A1T)]	AS58C1001@PLCC32
AS58C1001@SSOP32 [(SA438T)]	

ASP

MICROCONTROLLER

AP827C51 [(SA244)]	AP827C51@PLCC44
AP827C52 [(SA244)]	AP827C52@PLCC44
AP827C54 [(SA244)]	AP827C54@PLCC44
AP827C58 [(SA244)]	AP827C58@PLCC44

ATC

E (E) PROM / FRAM / NVRAM

ATC24C02 [(SA602A)]	ATC24C02@SOIC8
ATC24C02@TSSOP8 [(SA026)]	
ATC24C04 ATC24C04@SOIC8 [(SA602A)]	ATC24C04@TSSOP8
[(SA026)]	
ATC24C08 [(SA602A)]	ATC24C08@SOIC8
ATC24C08@TSSOP8 [(SA026)]	
ATC24C16 ATC24C16@SOIC8 [(SA602A)]	ATC24C16@TSSOP8
[(SA026)]	
ATC24LC02 [(SA602A)]	ATC24LC02@SOIC8
ATC24LC02@TSSOP8 [(SA026)]	
ATC24LC02A ATC24LC02A@SOIC8 [(SA602A)]	ATC24LC02A@TSSOP8
[(SA026)]	
ATC24LC04 [(SA602A)]	ATC24LC04@SOIC8
ATC24LC04@TSSOP8 [(SA026)]	
ATC24LC08 ATC24LC08@SOIC8 [(SA602A)]	ATC24LC08@TSSOP8
[(SA026)]	
ATC24LC16 [(SA602A)]	ATC24LC16@SOIC8
ATC24LC16@TSSOP8 [(SA026)]	
(08bit)	ATC93C46
ATC93C46(08bit)@SOIC8 [(SA602A)]	ATC93C46
(16bit)	
ATC93C46(16bit)@SOIC8 [(SA602A)]	
ATC93C46R(08bit)@SOIC8 [(SA602A)]	
ATC93C46R(16bit)@SOIC8 [(SA602A)]	
ATC93C56(08bit) [(SA602A)]	ATC93C56(08bit)@SOIC8
ATC93C56(16bit) [(SA602A)]	ATC93C56(16bit)@SOIC8
ATC93C56R(08bit)@SOIC8 [(SA602A)]	

ATC93C56R(16bit)@SOIC8 [(SA602A)]	
ATC93C66(08bit)	ATC93C66(08bit)@SOIC8
[(SA602A)]	
ATC93C66(16bit)	ATC93C66(16bit)@SOIC8
[(SA602A)]	
ATC93C66R(08bit)@SOIC8 [(SA602A)]	
ATC93C66R(16bit)@SOIC8 [(SA602A)]	
ATC93LC46(08bit)	
ATC93LC46(08bit)@SOIC8 [(SA602A)]	
ATC93LC46(16bit)	
ATC93LC46(16bit)@SOIC8 [(SA602A)]	
ATC93LC46R(08bit)@SOIC8 [(SA602A)]	
ATC93LC46R(16bit)@SOIC8 [(SA602A)]	
ATC93LC56(08bit)	
ATC93LC56(08bit)@SOIC8 [(SA602A)]	
ATC93LC56(16bit)	
ATC93LC56(16bit)@SOIC8 [(SA602A)]	
ATC93LC56R(08bit)@SOIC8 [(SA602A)]	
ATC93LC56R(16bit)@SOIC8 [(SA602A)]	
ATC93LC66(08bit)	
ATC93LC66(08bit)@SOIC8 [(SA602A)]	
ATC93LC66(16bit)	
ATC93LC66(16bit)@SOIC8 [(SA602A)]	
ATC93LC66R(08bit)@SOIC8 [(SA602A)]	
ATC93LC66R(16bit)@SOIC8 [(SA602A)]	

ATMEL

E(E) PROM/FRAM/NVRAM

AT17C002@PLCC20 [(SA001A)]	AT17C002@PLCC44
[(SA244)]	
AT17C002@SOIC20 [(SA404)]	AT17C002@TQFP44
[(SA245A)]	
AT17C002A@PLCC20 [(SA001A)]	AT17C002A@TQFP32
[(SA663)]	
AT17C010	AT17C010@PLCC20
[(SA001A)]	
AT17C010A	AT17C010A@PLCC20
[(SA001A)]	
AT17C040@PLCC44 [(SA244)]	AT17C040@TQFP44
[(SA245A)]	

AT17C128 [(SA001A)]	AT17C128@PLCC20
AT17C128@SOIC20 [(SA404)] [(SA602A)]	AT17C128@SOIC8
AT17C128A@PLCC20 [(SA001A)] AT17C256	
AT17C256@PLCC20 [(SA001A)] [(SA404)]	AT17C256@SOIC20
AT17C256@SOIC8 [(SA602A)] [(SA001A)]	AT17C256A@PLCC20
AT17C512 [(SA001A)]	AT17C512@PLCC20
AT17C512A [(SA001A)]	AT17C512A@PLCC20
AT17C65 [(SA001A)]	AT17C65@PLCC20
AT17C65@SOIC20 [(SA404)] [(SA602A)]	AT17C65@SOIC8
AT17C65A@PLCC20 [(SA001A)] [(SA760)]	AT17F040@LAP8
AT17F040@PLCC20 [(SA001A)] AT17F040@PLCC20(Virtex Pinout) [(SA001A)]	
AT17F040A@LAP8 [(SA760)] [(SA001A)]	AT17F040A@PLCC20
AT17F040A@TQFP32 [(SA663)] [(SA760)]	AT17F080@LAP8
AT17F080@PLCC20 [(SA001A)] [(SA244)]	AT17F080@PLCC44
AT17F080@TQFP44 [(SA245A)] [(SA760)]	AT17F080A@LAP8
AT17F080A@PLCC20 [(SA001A)] [(SA001A)]	AT17F080A@TQFP32
AT17F16@LAP8 [(SA760)] [(SA001A)]	AT17F16@PLCC20
AT17F16@PLCC44 [(SA244)] [(SA245A)]	AT17F16@TQFP44
AT17F16A@LAP8 [(SA760)] [(SA001A)]	AT17F16A@PLCC20
AT17F32@PLCC44 [(SA244)] [(SA244)]	AT17F32A@PLCC44
AT17LV002@PLCC20 [(SA001A)] [(SA244)]	AT17LV002@PLCC44
AT17LV002@SOIC20 [(SA404)]	AT17LV002@TQFP44

[(SA245A)]	
AT17LV002A@PLCC20 [(SA001A)]	AT17LV002A@TQFP32
[(SA663)]	
AT17LV010	AT17LV010@PLCC20
[(SA001A)]	
AT17LV010A	AT17LV010A@PLCC20
[(SA001A)]	
AT17LV040@PLCC44 [(SA244)]	AT17LV040@TQFP44
[(SA245A)]	
AT17LV128	AT17LV128@PLCC20
[(SA001A)]	
AT17LV128@SOIC20 [(SA404)]	AT17LV128@SOIC8
[(SA602A)]	
AT17LV128A@PLCC20 [(SA001A)]	
AT17LV256	
AT17LV256@PLCC20 [(SA001A)]	AT17LV256@SOIC20
[(SA404)]	
AT17LV256@SOIC8 [(SA602A)]	AT17LV256A@PLCC20
[(SA001A)]	
AT17LV512	AT17LV512@PLCC20
[(SA001A)]	
AT17LV512A	AT17LV512A@PLCC20
[(SA001A)]	
AT17LV65	AT17LV65@PLCC20
[(SA001A)]	
AT17LV65@SOIC20 [(SA404)]	AT17LV65@SOIC8
[(SA602A)]	
AT17LV65A@PLCC20 [(SA001A)]	AT17N002@SOIC20
[(SA404)]	
AT17N002@TQFP44 [(SA245A)]	
AT17N010	
AT17N010@SOIC20 [(SA404)]	AT17N040@TQFP44
[(SA245A)]	
AT17N256	AT17N256@SOIC20
[(SA404)]	
AT17N256@SOIC8 [(SA602A)]	
AT17N512	
AT17N512@SOIC20 [(SA404)]	
AT24C01	
AT24C01@MSOP8 [(SA666)]	AT24C01@SOIC8
[(SA602A)]	
AT24C01@TSSOP8 [(SA026)]	
AT24C01A	

AT24C01A@MAP8 [(SA724)]	AT24C01A@SOIC8
[(SA602A)]	
AT24C01A@SOT23-5 [(SA717)]	AT24C01A@TSSOP8
[(SA026)]	
AT24C01B	
AT24C01B@dBGA2	
AT24C01B@MAP8 [(SA724)]	AT24C01B@SOIC8
[(SA602A)]	
AT24C01B@SOT23 [(SA717)]	AT24C01B@TSSOP8
[(SA026)]	
AT24C02	AT24C02@SOIC8
[(SA602A)]	
AT24C02@TSSOP8 [(SA026)]	
AT24C02A	
AT24C02A@SOIC8 [(SA602A)]	AT24C02A@TSSOP8
[(SA026)]	
AT24C02B	
AT24C02B@dBGA2	
AT24C02B@MAP8 [(SA724)]	AT24C02B@SOIC8
[(SA602A)]	
AT24C02B@SOT23 [(SA717)]	AT24C02B@TSSOP8
[(SA026)]	
AT24C04	AT24C04@MAP8
[(SA724)]	
AT24C04@SOIC8 [(SA602A)]	AT24C04@SOT23-5
[(SA717)]	
AT24C04@TSSOP8 [(SA026)]	
AT24C04A	
AT24C04A@MAP8 [(SA724)]	AT24C04A@SOIC8
[(SA602A)]	
AT24C04A@TSSOP8 [(SA026)]	
AT24C08	
AT24C08@MAP8 [(SA724)]	AT24C08@SOIC8
[(SA602A)]	
AT24C08@TSSOP8 [(SA026)]	
AT24C08A	
AT24C08A@MAP8 [(SA724)]	AT24C08A@SOIC8
[(SA602A)]	
AT24C08A@TSSOP8 [(SA026)]	
AT24C1024	
AT24C1024@LAP8 [(SA724)]	AT24C1024@SAP8
[(SA684)]	
AT24C1024@SOIC8 [(SA023A)]	AT24C1024B

(1.8V)	
AT24C1024B(1.8V)@LAP8 [(SA724)]	AT24C1024B(1.8V)@SAP8
[(SA684)]	
AT24C1024B(1.8V)@SOIC8 [(SA023A)]	
AT24C1024B(1.8V)@TSSOP8 [(SA026)]	
AT24C1024B(2.5V)	AT24C1024B(2.5V)@LAP8
[(SA724)]	
AT24C1024B(2.5V)@SAP8 [(SA684)]	
AT24C1024B(2.5V)@SOIC8 [(SA023A)]	
AT24C1024B(2.5V)@TSSOP8 [(SA026)]	
AT24C11	AT24C11@SOIC8
[(SA602A)]	
AT24C11@TSSOP8 [(SA026)]	AT24C128
(1.8V)	
AT24C128(1.8V)@MAP8 [(SA724)]	AT24C128(1.8V)@SAP8
[(SA683)]	
AT24C128(1.8V)@SOIC8 [(SA602A)]	AT24C128(1.8V)@TSSOP8
[(SA026)]	
AT24C128(2.7V)	AT24C128(2.7V)@MAP8
[(SA724)]	
AT24C128(2.7V)@SAP8 [(SA683)]	AT24C128(2.7V)@SOIC8
[(SA602A)]	
AT24C128(2.7V)@TSSOP8 [(SA026)]	
AT24C128B	
AT24C128B@MAP8 [(SA724)]	AT24C128B@SAP8
[(SA683)]	
AT24C128B@SOIC8 [(SA602A)]	AT24C128B@TSSOP8
[(SA026)]	
AT24C16	AT24C16@SOIC8
[(SA602A)]	
AT24C16@TSSOP8 [(SA026)]	
AT24C164	
AT24C164@SOIC8 [(SA602A)]	
AT24C16A	
AT24C16A@MAP8 [(SA724)]	AT24C16A@SOIC8
[(SA602A)]	
AT24C16A@TSSOP8 [(SA026)]	
AT24C16B	
AT24C16B@MAP8 [(SA724)]	AT24C16B@SOIC8
[(SA602A)]	
AT24C16B@TSSOP8 [(SA026)]	
AT24C21	
AT24C21@SOIC8 [(SA602A)]	AT24C256

(1.8V)	
AT24C256(1.8V)@MAP8 [(SA724)]	AT24C256(1.8V)@SAP8
[(SA683)]	
AT24C256(1.8V)@SOIC8 [(SA602A)]	AT24C256(1.8V)@TSSOP8
[(SA026)]	
AT24C256(2.7V)	AT24C256(2.7V)@MAP8
[(SA724)]	
AT24C256(2.7V)@SAP8 [(SA683)]	AT24C256(2.7V)@SOIC8
[(SA602A)]	
AT24C256(2.7V)@TSSOP8 [(SA026)]	
AT24C256B	
AT24C256B@MAP8 [(SA724)]	AT24C256B@SAP8
[(SA683)]	
AT24C256B@SOIC8 [(SA602A)]	AT24C256B@TSSOP8
[(SA026)]	
AT24C32	AT24C32@SOIC8
[(SA602A)]	
AT24C32@TSSOP8 [(SA026)]	
AT24C32A	
AT24C32A@MAP8 [(SA724)]	AT24C32A@SOIC8
[(SA602A)]	
AT24C32A@TSSOP8 [(SA026)]	
AT24C32C	
AT24C32C@dBG8 [(BBB)]	AT24C32C@MAP8
[(SA724)]	
AT24C32C@SAP8 [(SA683)]	AT24C32C@SOIC8
[(SA602A)]	
AT24C32C@TSSOP8 [(SA026)]	AT24C512
(1.8V)	
AT24C512(1.8V)@LAP8 [(SA684)]	AT24C512(1.8V)@SAP8
[(SA683)]	
AT24C512(1.8V)@SOIC8 [(SA602A)]	AT24C512(1.8V)@TSSOP8
[(SA026)]	
AT24C512(2.7V)	AT24C512(2.7V)@LAP8
[(SA684)]	
AT24C512(2.7V)@SAP8 [(SA683)]	AT24C512(2.7V)@SOIC8
[(SA602A)]	
AT24C512(2.7V)@TSSOP8 [(SA026)]	
AT24C512B	
AT24C512B@LAP8 [(SA684)]	AT24C512B@SAP8
[(SA683)]	
AT24C512B@SOIC8 [(SA602A)]	AT24C512B@TSSOP8
[(SA026)]	

AT24C64 [(SA602A)]	AT24C64@SOIC8
AT24C64@TSSOP8 [(SA026)]	
AT24C64A	
AT24C64A@MAP8 [(SA724)] [(SA602A)]	AT24C64A@SOIC8
AT24C64A@TSSOP8 [(SA026)]	
AT24C64B	
AT24C64B@SOIC8 [(SA602A)] [(SA026)]	AT24C64B@TSSOP8
AT24C64C [(BBBB)]	AT24C64C@dBGA8
AT24C64C@MAP8 [(SA724)] [(SA683)]	AT24C64C@SAP8
AT24C64C@SOIC8 [(SA602A)] [(SA026)]	AT24C64C@TSSOP8
AT24CS128 [(SA602A)]	AT24CS128@SOIC8
AT24HC02B [(SA602A)]	AT24HC02B@SOIC8
AT24HC02B@TSSOP8 [(SA026)] [(SA602A)]	AT24RF08AN@SOIC8
AT24RF08AT@TSSOP14 [(SA026)] [(SA602A)]	AT24RF08BN@SOIC8
AT24RF08BT@TSSOP14 [(SA026)] [(SA602A)]	AT24RF08CN@SOIC8
AT24RF08CT@TSSOP14 [(SA026)]	
AT25010	
AT25010@SOIC8 [(SA602A)]	
AT25010A	
AT25010A@SOIC8 [(SA602A)] [(SA026)]	AT25010A@TSSOP8
AT25020 [(SA602A)]	AT25020@SOIC8
AT25020A [(SA602A)]	AT25020A@SOIC8
AT25020A@TSSOP8 [(SA026)]	
AT25040	
AT25040(ISP) [ISP-HEADER01] [(SA602A)]	AT25040@SOIC8
AT25040@SOIC8(ISP) [ISP-HEADER01]	
AT25040A HEADER01]	AT25040A(ISP) [ISP-

AT25040A@SOIC8 [(SA602A)]	
AT25040A@SOIC8(ISP) [ISP-HEADER01]	
AT25080	AT25080@SOIC8
[(SA602A)]	
AT25080@TSSOP14 [(SA026)]	AT25080@TSSOP20
[(SA026)]	
AT25080A	AT25080A@SOIC8
[(SA602A)]	
AT25080A@TSSOP14 [(SA026)]	
AT25128	
AT25128@SOIC16 [(SA602)]	AT25128@SOIC8
[(SA602A)]	
AT25128@TSSOP14 [(SA026)]	AT25128@TSSOP20
[(SA026)]	
AT25128A	AT25128A@dBGA8
[(BBBB)]	
AT25128A@SAP8 [(SA683)]	AT25128A@SOIC8(4.0)
[(SA602A)]	
AT25128A@SOIC8(5.4) [(SA605A)]	AT25128A@TSSOP14
[(SA026)]	
AT25128A@TSSOP8 [(SA026)]	
AT25160	
AT25160@SOIC8 [(SA602A)]	AT25160@TSSOP14
[(SA026)]	
AT25160@TSSOP20 [(SA026)]	
AT25160A	
AT25160A@SOIC8 [(SA602A)]	AT25160A@TSSOP14
[(SA026)]	
AT25256	AT25256@SOIC16
[(SA602)]	
AT25256@SOIC8 [(SA602A)]	AT25256@TSSOP14
[(SA026)]	
AT25256@TSSOP20 [(SA026)]	
AT25256A	
AT25256A@dBGA8 [(BBBB)]	AT25256A@SAP8
[(SA683)]	
AT25256A@SOIC8(4.0) [(SA602A)]	AT25256A@SOIC8(5.4)
[(SA605A)]	
AT25256A@TSSOP14 [(SA026)]	AT25256A@TSSOP8
[(SA026)]	
AT25320	AT25320@SOIC8
[(SA602A)]	
AT25320@TSSOP14 [(SA026)]	AT25320@TSSOP20

[(SA026)]	
AT25320A	AT25320A@SOIC8
[(SA602A)]	
AT25320A@TSSOP14 [(SA026)]	
AT25640	
AT25640@SOIC8 [(SA602A)]	AT25640@TSSOP14
[(SA026)]	
AT25640@TSSOP20 [(SA026)]	
AT25640A	
AT25640A@SOIC8 [(SA602A)]	AT25640A@TSSOP14
[(SA026)]	
AT25DF041A@MLF8 [(SA683)]	AT25DF041A@SOIC8(4.0)
[(SA602A)]	
AT25DF041A@SOIC8(5.4) [(SA605A)]	AT25DF321@SOIC16
[(SA404)]	
AT25DF321@SOIC8 [(SA605A)]	AT25DF641@SOIC16
[(SA404)]	
AT25DF641@VDFN8 [(SA683)]	
AT25F1024	
AT25F1024(W)@SOIC8 [(SA605A)]	AT25F1024(W)@VQFPN8
[(SA684)]	
AT25F1024@SOIC8 [(SA602A)]	AT25F1024@VQFPN8
[(SA683)]	
AT25F1024A	AT25F1024A(W)@SOIC8
[(SA605A)]	
AT25F1024A(W)@VQFPN8 [(SA684)]	AT25F1024A@SOIC8
[(SA602A)]	
AT25F1024A@VQFPN8 [(SA683)]	
AT25F2048	
AT25F2048(W)@SOIC8 [(SA605A)]	AT25F2048(W)@VQFPN8
[(SA684)]	
AT25F2048@SOIC8 [(SA602A)]	AT25F2048@VQFPN8
[(SA683)]	
AT25F2048A	AT25F2048A(W)@SOIC8
[(SA605A)]	
AT25F2048A(W)@VQFPN8 [(SA684)]	AT25F2048A@SOIC8
[(SA602A)]	
AT25F2048A@VQFPN8 [(SA683)]	
AT25F4096	
AT25F4096(W)@SOIC8 [(SA605A)]	AT25F4096(W)@VQFPN8
[(SA684)]	
AT25F4096@SOIC8 [(SA602A)]	AT25F4096@VQFPN8
[(SA683)]	

AT25F4096A [(SA605A)]	AT25F4096A(W)@SOIC8
AT25F4096A(W)@VQFPN8 [(SA684)] [(SA602A)]	AT25F4096A@SOIC8
AT25F4096A@VQFPN8 [(SA683)]	
AT25F512 AT25F512(W)@SOIC8 [(SA605A)] [(SA684)]	AT25F512(W)@VQFPN8
AT25F512@SOIC8 [(SA602A)] [(SA683)]	AT25F512@VQFPN8
AT25F512A [(SA605A)]	AT25F512A(W)@SOIC8
AT25F512A(W)@VQFPN8 [(SA684)] [(SA602A)]	AT25F512A@SOIC8
AT25F512A@VQFPN8 [(SA683)] [(SA683)]	AT25FS010@SAP8
AT25FS010@SOIC8 [(SA602A)] [(SA683)]	AT25FS040@SAP8
AT25FS040@SOIC8 [(SA602A)]	
AT25HP256 AT25HP256(W)@VQFPN8 [(SA684)] [(SA404)]	AT25HP256@SOIC16
AT25HP256@SOIC8 [(SA602A)] [(SA683)]	AT25HP256@VQFPN8
AT25HP512 [(SA684)]	AT25HP512(W)@VQFPN8
AT25HP512@SOIC16 [(SA404)] [(SA602A)]	AT25HP512@SOIC8
AT25HP512@VQFPN8 [(SA683)] [(SA404)]	AT25P1024@SOIC20
AT25P1024@VQFPN8 [(SA684)] [(SA683)]	AT26DF041@MLF8
AT26DF041@SOIC8(4.0) [(SA602A)] [(SA605A)]	AT26DF041@SOIC8(5.4)
AT26DF081@SOIC8(4.0) [(SA602A)] [(SA605A)]	AT26DF081@SOIC8(5.4)
AT26DF081A@SOIC8(4.0) [(SA602A)] [(SA605A)]	AT26DF081A@SOIC8(5.4)
AT26DF161@MLF8 [(SA683)] [(SA605A)]	AT26DF161@SOIC8
AT26DF161A@MLF8 [(SA683)] [(SA605A)]	AT26DF161A@SOIC8
AT26DF321@MLF8(5*6mm) [(SA683)]	AT26DF321@MLF8(6*8mm)

[(SA684)]	
AT26DF321@SOIC16 [(SA404)]	AT26DF321@SOIC8
[(SA605A)]	
AT26F004@MLF8 [(SA683)]	AT26F004@SOIC8(4.0)
[(SA602A)]	
AT26F004@SOIC8(5.4) [(SA605A)]	
AT27011	
AT27011@PLCC32 [(SA015A1T)]	
AT27256	
AT2732A	
AT27BV010	
AT27BV010@PLCC32 [(SA015A1T)]	AT27BV010@TSOP32
[(SA620)]	
AT27BV020	AT27BV020@PLCC32
[(SA015A1T)]	
AT27BV020@TSOP32 [(SA620)]	
AT27BV040	
AT27BV040@PLCC32 [(SA015A1T)]	AT27BV040@TSOP32
[(SA620)]	
AT27BV1024@PLCC44 [(SA244)]	AT27BV1024@TSOP40
[(SA623)]	
AT27BV256	AT27BV256@PLCC32
[(SA015A1T)]	
AT27BV256@TSOP28 [(SA430T)]	
AT27BV4096	
AT27BV4096@PLCC44 [(SA244)]	AT27BV4096@TSOP40
[(SA623)]	
AT27BV512	AT27BV512@PLCC32
[(SA015A1T)]	
AT27BV512@SOIC28 [(SA630)]	AT27BV512@TSOP28
[(SA430T)]	
AT27BV520@SOIC20 [(SA404)]	AT27BV520@TSOP28
[(SA430T)]	
AT27BV520@TSSOP20 [(SA026)]	
AT27C010	
AT27C010@PLCC32 [(SA015A1T)]	AT27C010@TSOP32
[(SA410T)]	
AT27C010L	AT27C010L@PLCC32
[(SA015A1T)]	
AT27C010L@TSOP32 [(SA410T)]	
AT27C020	
AT27C020@PLCC32 [(SA015A1T)]	AT27C020@TSOP32
[(SA410T)]	

AT27C040 [(SA015A1T)]	AT27C040@PLCC32
AT27C040@TSOP32 [(SA410T)]	
AT27C080 AT27C080@PLCC32 [(SA015A1T)] [(SA410T)]	AT27C080@TSOP32
AT27C1024 [(SA244)]	AT27C1024@PLCC44
AT27C1024@TSOP40 [(SA623)] AT27C1024L AT27C1024L@PLCC44 [(SA244)]	
AT27C128 AT27C128@PLCC32 [(SA015A1T)]	
AT27C2048 AT27C2048@PLCC44 [(SA244)] [(SA623)]	AT27C2048@TSOP40
AT27C256 [(SA015A1T)]	AT27C256@PLCC32
AT27C256R [(SA015A1T)]	AT27C256R@PLCC32
AT27C256R@SOIC28 [(SA630)] [(SA430T)]	AT27C256R@TSOP28
AT27C4096 [(SA244)]	AT27C4096@PLCC44
AT27C4096@TSOP40 [(SA623)]	
AT27C512 AT27C512@PLCC32 [(SA015A1T)]	
AT27C512R AT27C512R@PLCC32 [(SA015A1T)] [(SA630)]	AT27C512R@SOIC28
AT27C512R@TSOP28 [(SA430T)]	
AT27C513 AT27C513@PLCC32 [(SA015A1T)] [(SA630)]	AT27C513@SOIC28
AT27C513R [(SA015A1T)]	AT27C513R@PLCC32
AT27C513R@SOIC28 [(SA630)]	
AT27C515 AT27C515@PLCC32 [(SA015A1T)]	
AT27C516 AT27C516@PLCC44 [(SA244)] [(SA623)]	AT27C516@TSOP40
AT27C520@SOIC20 [(SA404)]	AT27C520@TSOP28

[(SA430T)]
AT27C520@TSSOP20 [(SA026)]
AT27C64
AT27C800 AT27C800@PLCC44
[(SA244)]
AT27C800@PSOP44 [(SA638)]
AT27HC1024
AT27HC1024@PLCC44 [(SA244)]
AT27HC256
AT27HC256@PLCC32 [(SA015A1T)]
AT27HC256L
AT27HC256L@PLCC32 [(SA015A1T)]
AT27HC256R
AT27HC256R@PLCC32 [(SA015A1T)]
AT27HC256RL
AT27HC256RL@PLCC32 [(SA015A1T)]
AT27HC64
AT27HC64@PLCC32 [(SA015A1T)]
AT27HC641
AT27HC641@PLCC28 [(SA008A)]
AT27HC641R
AT27HC641R@PLCC28 [(SA008A)]
AT27HC642
AT27HC642@PLCC28 [(SA008A)]
AT27HC642R
AT27HC642R@PLCC28 [(SA008A)]
AT27HC64L
AT27HC64L@PLCC32 [(SA015A1T)]
AT27LV010
AT27LV010@PLCC32 [(SA015A1T)] AT27LV010@TSOP32
[(SA620)]
AT27LV010A AT27LV010A@PLCC32
[(SA015A1T)]
AT27LV010A@TSOP32 [(SA620)]
AT27LV020A
AT27LV020A@PLCC32 [(SA015A1T)] AT27LV020A@TSOP32
[(SA620)]
AT27LV040 AT27LV040@PLCC32
[(SA015A1T)]
AT27LV040@TSOP32 [(SA620)]
AT27LV040A
AT27LV040A@PLCC32 [(SA015A1T)] AT27LV040A@TSOP32
[(SA620)]

AT27LV1024 [(SA244)]	AT27LV1024@PLCC44
AT27LV256A [(SA015A1T)]	AT27LV256A@PLCC32
AT27LV256A@SOIC28 [(SA630)] [(SA430T)]	AT27LV256A@TSOP28
AT27LV256R [(SA015A1T)]	AT27LV256R@PLCC32
AT27LV256R@SOIC28 [(SA630)] [(SA430T)]	AT27LV256R@TSOP28
AT27LV4096 [(SA244)]	AT27LV4096@PLCC44
AT27LV512A [(SA015A1T)]	AT27LV512A@PLCC32
AT27LV512A@SOIC28 [(SA630)] [(SA430T)]	AT27LV512A@TSOP28
AT27LV512R [(SA015A1T)]	AT27LV512R@PLCC32
AT27LV512R@TSOP28 [(SA430T)] [(SA404)]	AT27LV520@SOIC20
AT27LV520@TSOP28 [(SA430T)] [(SA026)]	AT27LV520@TSSOP20
AT27LV800 [(SA638)]	AT27LV800@PSOP44
AT28BV16 [(SA015A1T)]	AT28BV16@PLCC32
AT28BV16@SOIC24 [(SA404)] [(SA430T)]	AT28BV16@TSOP28
AT28BV256 [(SA015A1T)]	AT28BV256@PLCC32
AT28BV256@SOIC28 [(SA404)] [(SA430T)]	AT28BV256@TSOP28
AT28BV64 [(SA015A1T)]	AT28BV64@PLCC32
AT28BV64@SOIC28 [(SA404)] [(SA430T)]	AT28BV64@TSOP28
AT28BV64B [(SA015A1T)]	AT28BV64B@PLCC32
AT28BV64B@SOIC28 [(SA404)] [(SA430T)]	AT28BV64B@TSOP28
AT28C010 [(SA015A1T)]	AT28C010@PLCC32
AT28C010@PLCC44 [(SA244)]	AT28C010@TSOP32

[(SA410T)]	
AT28C010E	AT28C010E@PLCC32
[(SA015A1T)]	
AT28C010E@PLCC44 [(SA244)]	AT28C010E@TSOP32
[(SA410T)]	
AT28C04	AT28C04@PLCC32
[(SA015A1T)]	
AT28C040	AT28C040@PLCC32
[(SA015A1T)]	
AT28C04E	AT28C04E@PLCC32
[(SA015A1T)]	
AT28C04F	AT28C04F@PLCC32
[(SA015A1T)]	
AT28C16	AT28C16@PLCC32
[(SA015A1T)]	
AT28C16@SOIC24 [(SA404)]	AT28C16@TSOP28
[(SA430T)]	
AT28C16E	AT28C16E@PLCC32
[(SA015A1T)]	
AT28C16F	AT28C16F@PLCC32
[(SA015A1T)]	
AT28C17	AT28C17@PLCC32
[(SA015A1T)]	
AT28C17@SOIC28 [(SA404)]	
AT28C17E	
AT28C17E@PLCC32 [(SA015A1T)]	
AT28C17F	
AT28C17F@PLCC32 [(SA015A1T)]	
AT28C256	
AT28C256@PLCC32 [(SA015A1T)]	AT28C256@SOIC28
[(SA404)]	
AT28C256@TSOP28 [(SA430T)]	
AT28C256E	
AT28C256E@PLCC32 [(SA015A1T)]	
AT28C256F	
AT28C256F@PLCC32 [(SA015A1T)]	
AT28C64	
AT28C64@PLCC32 [(SA015A1T)]	AT28C64@SOIC28
[(SA404)]	
AT28C64@TSOP28 [(SA430T)]	
AT28C64B	
AT28C64B@PLCC32 [(SA015A1T)]	AT28C64B@SOIC28
[(SA404)]	

AT28C64B@TSOP28 [(SA430T)]
AT28C64E
AT28C64E@PLCC32 [(SA015A1T)] AT28C64E@TSOP28
[(SA430T)]
AT28C64F AT28C64F@PLCC32
[(SA015A1T)]
AT28C64F@TSOP28 [(SA430T)]
AT28C64X
AT28C64X@PLCC32 [(SA015A1T)] AT28C64X@SOIC28
[(SA404)]
AT28C64X@TSOP28 [(SA430T)]
AT28HC04
AT28HC16
AT28HC16L
AT28HC191
AT28HC191L
AT28HC256 AT28HC256@PLCC32
[(SA015A1T)]
AT28HC256@TSOP28 [(SA430T)]
AT28HC256E
AT28HC256E@PLCC32 [(SA015A1T)]
AT28HC256F
AT28HC256F@PLCC32 [(SA015A1T)]
AT28HC256L
AT28HC256L@PLCC32 [(SA015A1T)]
AT28HC256LE
AT28HC256LE@PLCC32 [(SA015A1T)]
AT28HC291
AT28HC291@PLCC28 [(SA008A)]
AT28HC291L
AT28HC291L@PLCC28 [(SA008A)]
AT28HC64
AT28HC64@PLCC32 [(SA015A1T)] AT28HC64@TSOP28
[(SA430T)]
AT28HC64B AT28HC64B@PLCC32
[(SA015A1T)]
AT28HC64B@SOIC28 [(SA404)] AT28HC64B@TSOP28
[(SA430T)]
AT28HC64BF AT28HC64BF@PLCC32
[(SA015A1T)]
AT28HC64BF@SOIC28 [(SA404)] AT28HC64BF@TSOP28
[(SA430T)]
AT28HC64L AT28HC64L@PLCC32

[(SA015A1T)]	
AT28HC64L@TSOP28 [(SA430T)]	
AT28LV010	
AT28LV010@PLCC32 [(SA015A1T)]	AT28LV010@TSOP32
[(SA410T)]	
AT28LV256	AT28LV256@PLCC32
[(SA015A1T)]	
AT28LV256@TSOP28 [(SA430T)]	
AT28LV64	
AT28LV64@PLCC32 [(SA015A1T)]	
AT28LV64B	
AT28LV64B@PLCC32 [(SA015A1T)]	AT28LV64B@SOIC28
[(SA404)]	
AT28LV64B@TSOP28 [(SA430T)]	
AT28MC010	
AT28MC010@PLCC32 [(SA015A1T)]	AT28MC010@PLCC44
[(SA244)]	
AT28MC010@TSOP32 [(SA410T)]	
AT28MC020	
AT28MC020@PLCC32 [(SA015A1T)]	AT28MC020@PLCC44
[(SA244)]	
AT28MC020@TSOP32 [(SA410T)]	
AT28MC040	
AT28MC040@PLCC32 [(SA015A1T)]	AT28MC040@PLCC44
[(SA244)]	
AT28MC040@TSOP32 [(SA410T)]	
AT28PC64	
AT28PC64@PLCC32 [(SA015A1T)]	AT28PC64@TSOP28
[(SA430T)]	
AT28PC64E	AT28PC64E@PLCC32
[(SA015A1T)]	
AT28PC64E@TSOP28 [(SA430T)]	AT29BV010A@PLCC32
[(SA015A1T)]	
AT29BV010A@TSOP32 [(SA410T)]	AT29BV020@PLCC32
[(SA015A1T)]	
AT29BV020@TSOP32 [(SA410T)]	AT29BV040A@TSOP32
[(SA410T)]	
AT29C010	AT29C010@PLCC32
[(SA015A1T)]	
AT29C010@TSOP32 [(SA410T)]	
AT29C010A	
AT29C010A@PLCC32 [(SA015A1T)]	AT29C010A@TSOP32
[(SA410T)]	

AT29C020 [(SA015A1T)]	AT29C020@PLCC32
AT29C020@TSOP32 [(SA410T)]	
AT29C040 AT29C040@PLCC32 [(SA015A1T)] [(SA410T)]	AT29C040@TSOP32
AT29C040A [(SA015A1T)]	AT29C040A@PLCC32
AT29C040A@TSOP32 [(SA410T)] [(SA244)]	AT29C1024@PLCC44
AT29C1024@TSOP48 [(SA247-B005)]	
AT29C256 AT29C256@PLCC32 [(SA015A1T)] [(SA430T)]	AT29C256@TSOP28
AT29C257 [(SA015A1T)]	AT29C257@PLCC32
AT29C512 [(SA015A1T)]	AT29C512@PLCC32
AT29C512@TSOP32 [(SA410T)]	
AT29LV010 AT29LV010@PLCC32 [(SA015A1T)] [(SA410T)]	AT29LV010@TSOP32
AT29LV010A@PLCC32 [(SA015A1T)] [(SA410T)]	AT29LV010A@TSOP32
AT29LV020 [(SA015A1T)]	AT29LV020@PLCC32
AT29LV020@TSOP32 [(SA410T)] [(SA410T)]	AT29LV040@TSOP32
AT29LV040A [(SA015A1T)]	AT29LV040A@PLCC32
AT29LV040A@TSOP32 [(SA410T)] [(SA244)]	AT29LV1024@PLCC44
AT29LV1024@TSOP48 [(SA247-B005)]	
AT29LV256 AT29LV256@PLCC32 [(SA015A1T)] [(SA430T)]	AT29LV256@TSOP28
AT29LV512 [(SA015A1T)]	AT29LV512@PLCC32
AT29LV512@TSOP32 [(SA410T)]	
AT32C16 AT32C16@PLCC44 [(SA244)]	
AT34C02 AT34C02@SOIC8 [(SA602A)]	AT34C02@TSSOP8

[(SA026)]
 AT34C02B AT34C02B@SOIC8
 [(SA602A)]
 AT34C02B@TSSOP8 [(SA026)]
 AT34C02C
 AT34C02C@dBGA8 [(BBBB)] AT34C02C@MAP8
 [(SA724)]
 AT34C02C@SOIC8 [(SA602A)] AT34C02C@TSSOP8
 [(SA026)]
 AT45BCM021D(page256)@SOIC8 [(SA605A)]
 AT45BCM021D(page256)@SOIC8(ISP) [ISP-HEADER01]
 AT45BCM021D(page264)@SOIC8 [(SA605A)]
 AT45BCM021D(page264)@SOIC8(ISP) [ISP-HEADER01]
 AT45D011@PLCC32 [(SA015A1T)] AT45D011@SOIC8
 [(SA605A)]
 AT45D011@TSSOP14 [(SA026)] AT45D021@PLCC32
 [(SA015A1T)]
 AT45D021@SOIC28 [(SA630)] AT45D021@TSOP28
 [(SA430T)]
 AT45D041@PLCC32 [(SA015A1T)] AT45D041@SOIC28
 [(SA630)]
 AT45D041@TSOP28 [(SA430T)] AT45D081@SOIC28
 [(SA630)]
 AT45D081@TSOP32 [(SA410T)] AT45D161@PLCC32
 [(SA015A1T)]
 AT45D161@SOIC28 [(SA630)] AT45D161@TSOP28
 [(SA430T)]
 AT45DB011@PLCC32 [(SA015A1T)] AT45DB011@SOIC8
 [(SA605A)]
 AT45DB011@TSSOP14 [(SA026)] AT45DB011B@PLCC32
 [(SA015A1T)]
 AT45DB011B@PLCC32(ISP) [ISP-HEADER01]
 AT45DB011B@SOIC8 [(SA605A)]
 AT45DB011B@SOIC8(ISP) [ISP-HEADER01]
 AT45DB011B@TSSOP14 [(SA026)]
 AT45DB011B@TSSOP14(ISP) [ISP-HEADER01]
 AT45DB011D(page264)@QFN8 [ordering number is marked above]
 AT45DB011D(page264)@QFN8(ISP) [ISP-HEADER01]
 AT45DB011D(page264)@SOIC8 [ordering number is marked above]
 AT45DB011D(page264)@SOIC8(ISP) [ISP-HEADER01]
 AT45DB021@PLCC32 [(SA015A1T)] AT45DB021@SOIC28
 [(SA630)]
 AT45DB021@TSOP28 [(SA430T)] AT45DB021A@PLCC32

[(SA015A1T)]
AT45DB021A@PLCC32 (ISP) [ISP-HEADER01]
AT45DB021A@SOIC28 [(SA630)]
AT45DB021A@SOIC28 (ISP) [ISP-HEADER01]
AT45DB021A@TSOP28 [(SA430T)]
AT45DB021A@TSOP28 (ISP) [ISP-HEADER01]
AT45DB021B@CBGA9 [(SA677A-B089A-K080F001N)]
AT45DB021B@CBGA9 (ISP) [ISP-HEADER01]
AT45DB021B@SOIC28 [(SA630)]
AT45DB021B@SOIC28 (ISP) [ISP-HEADER01]
AT45DB021B@SOIC8 [(SA023A)]
AT45DB021B@SOIC8 (ISP) [ISP-HEADER01]
AT45DB021B@TSOP28 [(SA430T)]
AT45DB021B@TSOP28 (ISP) [ISP-HEADER01]
AT45DB021D6(page264)@CASON8 [ordering number is marked above]
AT45DB021D6(page264)@CASON8 (ISP) [ISP-HEADER01]
AT45DB021D6(page264)@SOIC8 [ordering number is marked above]
AT45DB021D6(page264)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB041@PLCC32 [(SA015A1T)] AT45DB041@SOIC28
[(SA630)]
AT45DB041@TSOP28 [(SA430T)] AT45DB041A@PLCC32
[(SA015A1T)]
AT45DB041A@PLCC32 (ISP) [ISP-HEADER01]
AT45DB041A@SOIC28 [(SA630)]
AT45DB041A@SOIC28 (ISP) [ISP-HEADER01]
AT45DB041A@TSOP28 [(SA430T)]
AT45DB041A@TSOP28 (ISP) [ISP-HEADER01]
AT45DB041B@CASON8 [(SA684)] AT45DB041B@CASON8 (ISP)
[(SA684)]
AT45DB041B@CBGA14 [(SA677A-B089A-K080F001N)]
AT45DB041B@CBGA14 (ISP) [ISP-HEADER01]
AT45DB041B@SOIC28 [(SA630)]
AT45DB041B@SOIC28 (ISP) [ISP-HEADER01]
AT45DB041B@SOIC8 [(SA605A)]
AT45DB041B@SOIC8 (ISP) [ISP-HEADER01]
AT45DB041B@TSOP28 [(SA430T)]
AT45DB041B@TSOP28 (ISP) [ISP-HEADER01]
AT45DB041D(page256)@QFN8 [(SA683)]
AT45DB041D(page256)@QFN8 (ISP) [ISP-HEADER01]
AT45DB041D(page256)@SOIC8 [(SA605A)]
AT45DB041D(page256)@SOIC8 (ISP) [ISP-HEADER01]
AT45DB041D(page264)@QFN8 [(SA683)]
AT45DB041D(page264)@QFN8 (ISP) [ISP-HEADER01]

AT45DB041D(page264)@SOIC8 [(SA605A)]
AT45DB041D(page264)@SOIC8(ISP) [ISP-HEADER01]
AT45DB081@SOIC28 [(SA630)] AT45DB081@TSOP32
[(SA410T)]
AT45DB081A@PLCC32 [(SA015A1T)]
AT45DB081A@PLCC32(ISP) [ISP-HEADER01]
AT45DB081A@SOIC28 [(SA630)]
AT45DB081A@SOIC28(ISP) [ISP-HEADER01]
AT45DB081A@TSOP28 [(SA430T)]
AT45DB081A@TSOP28(ISP) [ISP-HEADER01]
AT45DB081B@CASON8 [(SA684)] AT45DB081B@CASON8(ISP)
[(SA684)]
AT45DB081B@CBGA14 [(SA677A-B089A-K080F001N)]
AT45DB081B@CBGA14(ISP) [ISP-HEADER01]
AT45DB081B@SOIC28 [(SA630)]
AT45DB081B@SOIC28(ISP) [ISP-HEADER01]
AT45DB081B@SOIC8 [(SA605A)]
AT45DB081B@SOIC8(ISP) [ISP-HEADER01]
AT45DB081B@TSOP28 [(SA430T)]
AT45DB081B@TSOP28(ISP) [ISP-HEADER01]
AT45DB081D(page256)@MLF8 [(SA683)]
AT45DB081D(page256)@QFN8(ISP) [ISP-HEADER01]
AT45DB081D(page256)@SOIC8 [(SA023A)]
AT45DB081D(page256)@SOIC8(ISP) [ISP-HEADER01]
AT45DB081D(page264)@MLF8 [(SA683)]
AT45DB081D(page264)@QFN8(ISP) [ISP-HEADER01]
AT45DB081D(page264)@SOIC8 [(SA023A)]
AT45DB081D(page264)@SOIC8(ISP) [ISP-HEADER01]
AT45DB161@PLCC32 [(SA015A1T)] AT45DB161@SOIC28
[(SA630)]
AT45DB161@TSOP28 [(SA430T)]
AT45DB161B@CASON8(ISP) [ISP-HEADER01]
AT45DB161B@CASON8 [(SA684)] AT45DB161B@SOIC28
[(SA630)]
AT45DB161B@SOIC28(ISP) [ISP-HEADER01]
AT45DB161B@TSOP28 [(SA430T)]
AT45DB161B@TSOP28(ISP) [ISP-HEADER01]
AT45DB161D(page512)@QFN8 [(SA683)]
AT45DB161D(page512)@QFN8(ISP) [ISP-HEADER01]
AT45DB161D(page512)@SOIC8 [(SA605A)]
AT45DB161D(page512)@SOIC8(ISP) [ISP-HEADER01]
AT45DB161D(page512)@TSOP28 [(SA430T)]
AT45DB161D(page512)@TSOP28(ISP) [ISP-HEADER01]

AT45DB161D(page528)@QFN8 [(SA683)]
AT45DB161D(page528)@QFN8(ISP) [ISP-HEADER01]
AT45DB161D(page528)@SOIC8 [(SA605A)]
AT45DB161D(page528)@SOIC8(ISP) [ISP-HEADER01]
AT45DB161D(page528)@TSOP28 [(SA430T)]
AT45DB161D(page528)@TSOP28(ISP) [ISP-HEADER01]
AT45DB321@TSOP32 [(SA410T)] AT45DB321B@SOIC28
[(SA630)]
AT45DB321B@SOIC28(ISP) [ISP-HEADER01]
AT45DB321B@TSOP32 [(SA410T)]
AT45DB321B@TSOP32(ISP) [ISP-HEADER01]
AT45DB321C@CAS0N8 [(SA684)]
AT45DB321C@CAS0N8(ISP) [ISP-HEADER01]
AT45DB321C@SOIC28 [(SA630)]
AT45DB321C@SOIC28(ISP) [ISP-HEADER01]
AT45DB321C@TSOP28 [(SA430T)]
AT45DB321C@TSOP28(ISP) [ISP-HEADER01]
AT45DB321D(page512)@QFN8 [(SA683)]
AT45DB321D(page512)@QFN8(ISP) [ISP-HEADER01]
AT45DB321D(page512)@SOIC8 [(SA023A)]
AT45DB321D(page512)@SOIC8(ISP) [ISP-HEADER01]
AT45DB321D(page512)@TSOP28 [(SA430T)]
AT45DB321D(page512)@TSOP28(ISP) [ISP-HEADER01]
AT45DB321D(page528)@QFN8 [(SA683)]
AT45DB321D(page528)@QFN8(ISP) [ISP-HEADER01]
AT45DB321D(page528)@SOIC8 [(SA023A)]
AT45DB321D(page528)@SOIC8(ISP) [ISP-HEADER01]
AT45DB321D(page528)@TSOP28 [(SA430T)]
AT45DB321D(page528)@TSOP28(ISP) [ISP-HEADER01]
AT45DB642@TSOP40 [(SA409T)]
AT45DB642@TSOP40(ISP) [ISP-HEADER01]
AT45DB642D(page1024)@CAS0N8 [(SA684)]
AT45DB642D(page1024)@CAS0N8(ISP) [(ISP-HEADER01)]
AT45DB642D(page1024)@TSOP28 [(SA430)]
AT45DB642D(page1024)@TSOP28(ISP) [(ISP-HEADER01)]
AT45DB642D(page1056)@CAS0N8 [(SA684)]
AT45DB642D(page1056)@CAS0N8(ISP) [(ISP-HEADER01)]
AT45DB642D(page1056)@TSOP28 [(SA430)]
AT45DB642D(page1056)@TSOP28(ISP) [(ISP-HEADER01)]
AT45DCB002 [(CARD005-B005)] AT45DCB002(ISP) [ISP-
HEADER01]
AT45DCB004 [(CARD005-B005)] AT45DCB004(ISP) [ISP-
HEADER01]

AT45DCB004C [(CARD005-B005)] HEADER01]	AT45DCB004C(ISP) [ISP- HEADER01]
AT45DCB008 [(CARD005-B005)] HEADER01]	AT45DCB008(ISP) [ISP- HEADER01]
AT45DCB008D4(page1024) [(CARD005-B005)]	
AT45DCB008D4(page1024)(ISP) [(ISP-HEADER01)]	
AT45DCB008D6(page1056) [(CARD005-B005)]	
AT45DCB008D6(page1056)(ISP) [(ISP-HEADER01)]	
AT49BV001 [(SA015A1T)]	AT49BV001@PLCC32
AT49BV001@TSOP32 [(SA410T)] [(SA620)]	AT49BV001@VSOP32
AT49BV001A [(SA015A1T)]	AT49BV001A@PLCC32
AT49BV001A@TSOP32 [(SA410T)] [(SA620)]	AT49BV001A@VSOP32
AT49BV001AN [(SA015A1T)]	AT49BV001AN@PLCC32
AT49BV001AN@TSOP32 [(SA410T)] [(SA620)]	AT49BV001AN@VSOP32
AT49BV001ANT [(SA015A1T)]	AT49BV001ANT@PLCC32
AT49BV001ANT@TSOP32 [(SA410T)] [(SA620)]	AT49BV001ANT@VSOP32
AT49BV001AT [(SA015A1T)]	AT49BV001AT@PLCC32
AT49BV001AT@TSOP32 [(SA410T)] [(SA620)]	AT49BV001AT@VSOP32
AT49BV001N [(SA015A1T)]	AT49BV001N@PLCC32
AT49BV001N@TSOP32 [(SA410T)] [(SA620)]	AT49BV001N@VSOP32
AT49BV001NT [(SA015A1T)]	AT49BV001NT@PLCC32
AT49BV001NT@TSOP32 [(SA410T)] [(SA620)]	AT49BV001NT@VSOP32
AT49BV001T [(SA015A1T)]	AT49BV001T@PLCC32
AT49BV001T@TSOP32 [(SA410T)] [(SA620)]	AT49BV001T@VSOP32
AT49BV002 [(SA015A1T)]	AT49BV002@PLCC32
AT49BV002@TSOP32 [(SA410T)]	AT49BV002@VSOP32

[(SA620)]	
AT49BV002A	AT49BV002A@PLCC32
[(SA015A1T)]	
AT49BV002A@TSOP32 [(SA410T)]	AT49BV002A@VSOP32
[(SA620)]	
AT49BV002AN	AT49BV002AN@PLCC32
[(SA015A1T)]	
AT49BV002AN@TSOP32 [(SA410T)]	AT49BV002AN@VSOP32
[(SA620)]	
AT49BV002ANT	AT49BV002ANT@PLCC32
[(SA015A1T)]	
AT49BV002ANT@TSOP32 [(SA410T)]	AT49BV002ANT@VSOP32
[(SA620)]	
AT49BV002AT	AT49BV002AT@PLCC32
[(SA015A1T)]	
AT49BV002AT@TSOP32 [(SA410T)]	AT49BV002AT@VSOP32
[(SA620)]	
AT49BV002N	AT49BV002N@PLCC32
[(SA015A1T)]	
AT49BV002N@TSOP32 [(SA410T)]	AT49BV002N@VSOP32
[(SA620)]	
AT49BV002NT	AT49BV002NT@PLCC32
[(SA015A1T)]	
AT49BV002NT@TSOP32 [(SA410T)]	AT49BV002NT@VSOP32
[(SA620)]	
AT49BV002T	AT49BV002T@PLCC32
[(SA015A1T)]	
AT49BV002T@TSOP32 [(SA410T)]	AT49BV002T@VSOP32
[(SA620)]	
AT49BV008@TSOP40 [(SA409T)]	AT49BV008A@TSOP40
[(SA409T)]	
AT49BV008A@uBGA48 [(SA634)]	AT49BV008AT@TSOP40
[(SA409T)]	
AT49BV008AT@uBGA48 [(SA634)]	
AT49BV010	
AT49BV010@PLCC32 [(SA015A1T)]	AT49BV010@TSOP32
[(SA410T)]	
AT49BV020	AT49BV020@PLCC32
[(SA015A1T)]	
AT49BV020@TSOP32 [(SA410T)]	
AT49BV040	
AT49BV040@PLCC32 [(SA015A1T)]	AT49BV040@TSOP32
[(SA410T)]	

AT49BV040A@PLCC32 [(SA015A1T)] AT49BV040A@TSOP32
[(SA410T)]
AT49BV040A@VSOP32 [(SA620)]
AT49BV040B@PLCC32 [(SA015A1T-B001)]
AT49BV040B@TSOP32 [(SA410T-B003)]
AT49BV040B@VSOP32 [(SA620-B005)]
AT49BV040T
AT49BV040T@PLCC32 [(SA015A1T)] AT49BV040T@TSOP32
[(SA410T)]
AT49BV080@PSOP44 [(SA638)] AT49BV080@TSOP40
[(SA409T)]
AT49BV080T@PSOP44 [(SA638)] AT49BV080T@TSOP40
[(SA409T)]
AT49BV1024A@TSOP40 [(SA623)] AT49BV160@TSOP48 [(SA247-
B005)]
AT49BV160@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV1604@TSOP48 [(SA247-B005)]
AT49BV1604@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV1604A@TSOP48 [(SA247-B005)]
AT49BV1604A@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV1604AT@TSOP48 [(SA247-B005)]
AT49BV1604AT@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV1604T@TSOP48 [(SA247-B005)]
AT49BV1604T@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV160C@TSOP48 [(SA247-B005)]
AT49BV160C@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV160CT@TSOP48 [(SA247-B005)]
AT49BV160CT@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV160D@TSOP48 [(SA247-B005)]
AT49BV160DT@TSOP48 [(SA247-B005)]
AT49BV160S@FBGA64 [(SA705A-B147A-W064F001Y)]
AT49BV160ST@FBGA64 [(SA705A-B147A-W064F001Y)]
AT49BV160T@TSOP48 [(SA247-B005)]
AT49BV160T@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV161@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV161@TSOP48 [(SA247-B005)]
AT49BV1614@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV1614@TSOP48 [(SA247-B005)]
AT49BV1614A@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV1614A@TSOP48 [(SA247-B005)]
AT49BV1614AT@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV1614AT@TSOP48 [(SA247-B005)]
AT49BV1614T@CBGA48 [(SA642F-B026A-T064F001)]

AT49BV1614T@TSOP48 [(SA247-B005)]
AT49BV1618@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV1618@TSOP48 [(SA247-B005)]
AT49BV1618T@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV1618T@TSOP48 [(SA247-B005)]
AT49BV161T@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV161T@TSOP48 [(SA247-B005)]
AT49BV162A@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV162A@TSOP48 [(SA247-B005)]
AT49BV162AT@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV162AT@TSOP48 [(SA247-B005)]
AT49BV163A@CBGA48 [(SA642G-B026A-T048F001Y)]
AT49BV163A@TSOP48 [(SA247-B005)]
AT49BV163AT@CBGA48 [(SA642G-B026A-T048F001Y)]
AT49BV163AT@TSOP48 [(SA247-B005)]
AT49BV163D@FBGA48 [(SA642G-B026A-T048F001Y)]
AT49BV163D@TSOP48 [(SA247-B005)]
AT49BV163DT@FBGA48 [(SA642G-B026A-T048F001Y)]
AT49BV163DT@TSOP48 [(SA247-B005)]
AT49BV2048@PSOP44 [(SA638)] AT49BV2048@TSOP48 [(SA247-B005)]
AT49BV2048A@PSOP44 [(SA638)]
AT49BV2048A@TSOP48 [(SA247-B005)]
AT49BV2048B@TSOP48 [(SA247-B005)]
AT49BV320@TSOP48 [(SA247-B005)]
AT49BV320@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV320C@TSOP48 [(SA247-B005)]
AT49BV320C@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV320CT@TSOP48 [(SA247-B005)]
AT49BV320CT@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV320D@FBGA48 [(SA634A-B005A-Y048F001Y)]
AT49BV320D@TSOP48 [(SA247-B005)]
AT49BV320DT@FBGA48 [(SA634A-B005A-Y048F001Y)]
AT49BV320DT@TSOP48 [(SA247-B005)]
AT49BV320S@FBGA64 [(SA705A-B147A-W064F001Y)]
AT49BV320ST@FBGA64 [(SA705A-B147A-W064F001Y)]
AT49BV320T@TSOP48 [(SA247-B005)]
AT49BV320T@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV321@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV321@TSOP48 [(SA247-B005)]
AT49BV3218@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV3218@TSOP48 [(SA247-B005)]
AT49BV3218T@CBGA48 [(SA642F-B026A-T064F001)]

AT49BV3218T@TSOP48 [(SA247-B005)]
AT49BV321T@CBGA48 [(SA642F-B026A-T064F001)]
AT49BV321T@TSOP48 [(SA247-B005)]
AT49BV322A@FBGA48 [(SA642F-B026A-T064F001)]
AT49BV322A@TSOP48 [(SA247-B005)]
AT49BV322AT@FBGA48 [(SA642F-B026A-T064F001)]
AT49BV322AT@TSOP48 [(SA247-B005)]
AT49BV322D@FBGA48 [(SA642U-B026A-T064F001Y)]
AT49BV322D@TSOP48 [(SA247-B005)]
AT49BV322DT@FBGA48 [(SA642U-B026A-T064F001Y)]
AT49BV322DT@TSOP48 [(SA247-B005)]
AT49BV4096@PSOP44 [(SA638)] AT49BV4096@TSOP48 [(SA247-B005)]
AT49BV4096A@PSOP44 [(SA638)]
AT49BV4096A@TSOP48 [(SA247-B005)]
AT49BV4096A@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV512 AT49BV512@PLCC32
[(SA015A1T)]
AT49BV512@TSOP32 [(SA410T)] AT49BV512@VSOP32
[(SA620)]
AT49BV640D@FBGA48 [(SA634A-B005A-Y048F001Y)]
AT49BV640D@TSOP56 [(SA628-B131)]
AT49BV640DT@FBGA48 [(SA634A-B005A-Y048F001Y)]
AT49BV640DT@TSOP56 [(SA628-B131)]
AT49BV640S@FBGA64 [(SA705A-B147A-W064F001Y)]
AT49BV640ST@FBGA64 [(SA705A-B147A-W064F001Y)]
AT49BV6416@TSOP48 [(SA247-B005)]
AT49BV6416T@TSOP48 [(SA247-B005)]
AT49BV642D@TSOP48 [(SA247-B005)]
AT49BV642DT@TSOP48 [(SA247-B005)]
AT49BV8004@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV8004@TSOP48 [(SA247-B005)]
AT49BV8004T@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV8004T@TSOP48 [(SA247-B005)]
AT49BV8011@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV8011@TSOP48 [(SA247-B005)]
AT49BV8011T@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV8011T@TSOP48 [(SA247-B005)]
AT49BV802A@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV802A@TSOP48 [(SA247-B005)]
AT49BV802AT@CBGA48 [(SA642B-B026A-Y072F001)]
AT49BV802AT@TSOP48 [(SA247-B005)]
AT49BV802D@CBGA48 [(SA642G-B026A-T048F001Y)]

AT49BV802D@TSOP48 [(SA247)]
AT49BV802DT@CBGA48 [(SA642G-B026A-T048F001Y)]
AT49BV802DT@TSOP48 [(SA247)] AT49BV8192@PSOP44
[(SA638)]
AT49BV8192@TSOP48 [(SA247-B005)]
AT49BV8192A@TSOP48 [(SA247-B005)]
AT49BV8192A@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV8192AT@TSOP48 [(SA247-B005)]
AT49BV8192AT@uBGA48 [(SA634A-B005A-Y048F001)]
AT49BV8192T@PSOP44 [(SA638)]
AT49BV8192T@TSOP48 [(SA247-B005)]
AT49F001 AT49F001@PLCC32
[(SA015A1T)]
AT49F001@TSOP32 [(SA410T)] AT49F001@VSOP32
[(SA620)]
AT49F001A AT49F001A@PLCC32
[(SA015A1T)]
AT49F001A@TSOP32 [(SA410T)] AT49F001A@VSOP32
[(SA620)]
AT49F001AN AT49F001AN@PLCC32
[(SA015A1T)]
AT49F001AN@TSOP32 [(SA410T)] AT49F001AN@VSOP32
[(SA620)]
AT49F001ANT AT49F001ANT@PLCC32
[(SA015A1T)]
AT49F001ANT@TSOP32 [(SA410T)] AT49F001ANT@VSOP32
[(SA620)]
AT49F001AT AT49F001AT@PLCC32
[(SA015A1T)]
AT49F001AT@TSOP32 [(SA410T)] AT49F001AT@VSOP32
[(SA620)]
AT49F001N AT49F001N@PLCC32
[(SA015A1T)]
AT49F001N@TSOP32 [(SA410T)] AT49F001N@VSOP32
[(SA620)]
AT49F001NT AT49F001NT@PLCC32
[(SA015A1T)]
AT49F001NT@TSOP32 [(SA410T)] AT49F001NT@VSOP32
[(SA620)]
AT49F001T AT49F001T@PLCC32
[(SA015A1T)]
AT49F001T@TSOP32 [(SA410T)] AT49F001T@VSOP32
[(SA620)]

AT49F002 [(SA015A1T)]	AT49F002@PLCC32
AT49F002@TSOP32 [(SA410T)] [(SA620)]	AT49F002@VSOP32
AT49F002A [(SA015A1T)]	AT49F002A@PLCC32
AT49F002A@TSOP32 [(SA410T)] [(SA620)]	AT49F002A@VSOP32
AT49F002AN [(SA015A1T)]	AT49F002AN@PLCC32
AT49F002AN@TSOP32 [(SA410T)] [(SA620)]	AT49F002AN@VSOP32
AT49F002ANT [(SA015A1T)]	AT49F002ANT@PLCC32
AT49F002ANT@TSOP32 [(SA410T)] [(SA620)]	AT49F002ANT@VSOP32
AT49F002AT [(SA015A1T)]	AT49F002AT@PLCC32
AT49F002AT@TSOP32 [(SA410T)] [(SA620)]	AT49F002AT@VSOP32
AT49F002N [(SA015A1T)]	AT49F002N@PLCC32
AT49F002N@TSOP32 [(SA410T)] [(SA620)]	AT49F002N@VSOP32
AT49F002NT [(SA015A1T)]	AT49F002NT@PLCC32
AT49F002NT@TSOP32 [(SA410T)] [(SA620)]	AT49F002NT@VSOP32
AT49F002T [(SA015A1T)]	AT49F002T@PLCC32
AT49F002T@TSOP32 [(SA410T)] [(SA620)]	AT49F002T@VSOP32
AT49F008@TSOP40 [(SA409T)] [(SA409T)]	AT49F008A@TSOP40
AT49F008AT@TSOP40 [(SA409T)]	
AT49F010 AT49F010@PLCC32 [(SA015A1T)] [(SA410T)]	AT49F010@TSOP32
AT49F020 [(SA015A1T)]	AT49F020@PLCC32
AT49F020@TSOP32 [(SA410T)]	
AT49F040 AT49F040@PLCC32 [(SA015A1T)]	AT49F040@TSOP32

[(SA410T)]
 AT49F040A AT49F040A@PLCC32
 [(SA015A1T)]
 AT49F040A@TSOP32 [(SA410T)] AT49F080@PSOP44
 [(SA638)]
 AT49F080@TSOP40 [(SA409T)] AT49F080T@PSOP44
 [(SA638)]
 AT49F080T@TSOP40 [(SA409T)] AT49F1024@TSOP40
 [(SA623)]
 AT49F1024A@TSOP40 [(SA623)] AT49F1025@PLCC44
 [(SA244)]
 AT49F1604@TSOP48 [(SA247-B005)]
 AT49F1604@uBGA48 [(SA634A-B005A-Y048F001)]
 AT49F1604T@TSOP48 [(SA247-B005)]
 AT49F1604T@uBGA48 [(SA634A-B005A-Y048F001)]
 AT49F1614@CBGA48 [(SA642F-B026A-T064F001)]
 AT49F1614@TSOP48 [(SA247-B005)]
 AT49F1614T@CBGA48 [(SA642F-B026A-T064F001)]
 AT49F1614T@TSOP48 [(SA247-B005)] AT49F2048@PSOP44
 [(SA638)]
 AT49F2048@TSOP48 [(SA247-B005)] AT49F2048A@PSOP44
 [(SA638)]
 AT49F2048A@TSOP48 [(SA247-B005)] AT49F4096@PSOP44
 [(SA638)]
 AT49F4096@TSOP48 [(SA247-B005)]
 AT49F4096A@CBGA48 [(SA642F-B026A-T064F001)]
 AT49F4096A@PSOP44 [(SA638)] AT49F4096A@TSOP48 [(SA247-
 B005)]
 AT49F4096A@uBGA48 [(SA634A-B005A-Y048F001)]
 AT49F512 AT49F512@PLCC32
 [(SA015A1T)]
 AT49F512@TSOP32 [(SA410T)] AT49F512@VSOP32
 [(SA620)]
 AT49F516@PLCC44 [(SA244)] AT49F516@TSOP40
 [(SA623)]
 AT49F8004@CBGA48 [(SA642B-B026A-Y072F001)]
 AT49F8004@TSOP48 [(SA247-B005)]
 AT49F8004T@CBGA48 [(SA642B-B026A-Y072F001)]
 AT49F8004T@TSOP48 [(SA247-B005)]
 AT49F8011@CBGA48 [(SA642B-B026A-Y072F001)]
 AT49F8011@TSOP48 [(SA247-B005)]
 AT49F8011T@CBGA48 [(SA642B-B026A-Y072F001)]
 AT49F8011T@TSOP48 [(SA247-B005)] AT49F8192@PSOP44

[(SA638)]	
AT49F8192@TSOP48 [(SA247-B005)]	AT49F8192A@PSOP44
[(SA638)]	
AT49F8192A@TSOP48 [(SA247-B005)]	AT49F8192AT@PSOP44
[(SA638)]	
AT49F8192AT@TSOP48 [(SA247-B005)]	
AT49F8192T@PSOP44 [(SA638)]	AT49F8192T@TSOP48 [(SA247-B005)]
AT49HBV010	AT49HBV010@PLCC32
[(SA015A1T)]	
AT49HBV010@TSOP32 [(SA410T)]	
AT49HF010	
AT49HF010@PLCC32 [(SA015A1T)]	AT49HF010@TSOP32
[(SA410T)]	
AT49HLV010	AT49HLV010@PLCC32
[(SA015A1T)]	
AT49HLV010@TSOP32 [(SA410T)]	AT49LH002@PLCC32
[(SA015A1T)]	
AT49LH002@TSOP40 [(SA409T)]	AT49LH004@PLCC32
[(SA015A1T)]	
AT49LH004@TSOP40 [(SA409T)]	AT49LH00B4@PLCC32
[(SA015A1T)]	
AT49LH00B4@TSOP40 [(SA409T)]	AT49LL020@PLCC32
[(SA015A1T)]	
AT49LL020@TSOP40 [(SA409T)]	AT49LL040@PLCC32
[(SA015A1T)]	
AT49LL040@TSOP40 [(SA409T)]	AT49LL080@PLCC32
[(SA015A1T)]	
AT49LL080@TSOP40 [(SA409T)]	
AT49LV001	
AT49LV001@PLCC32 [(SA015A1T)]	AT49LV001@TSOP32
[(SA410T)]	
AT49LV001@VSOP32 [(SA620)]	
AT49LV001N	
AT49LV001N@PLCC32 [(SA015A1T)]	AT49LV001N@TSOP32
[(SA410T)]	
AT49LV001N@VSOP32 [(SA620)]	
AT49LV001NT	
AT49LV001NT@PLCC32 [(SA015A1T)]	AT49LV001NT@TSOP32
[(SA410T)]	
AT49LV001NT@VSOP32 [(SA620)]	
AT49LV001T	
AT49LV001T@PLCC32 [(SA015A1T)]	AT49LV001T@TSOP32

[(SA410T)]
AT49LV001T@VSOP32 [(SA620)]
AT49LV002
AT49LV002@PLCC32 [(SA015A1T)] AT49LV002@TSOP32
[(SA410T)]
AT49LV002@VSOP32 [(SA620)]
AT49LV002N
AT49LV002N@PLCC32 [(SA015A1T)] AT49LV002N@TSOP32
[(SA410T)]
AT49LV002N@VSOP32 [(SA620)]
AT49LV002NT
AT49LV002NT@PLCC32 [(SA015A1T)] AT49LV002NT@TSOP32
[(SA410T)]
AT49LV002NT@VSOP32 [(SA620)]
AT49LV002T
AT49LV002T@PLCC32 [(SA015A1T)] AT49LV002T@TSOP32
[(SA410T)]
AT49LV002T@VSOP32 [(SA620)] AT49LV008@TSOP40
[(SA409T)]
AT49LV008A@TSOP40 [(SA409T)] AT49LV008A@uBGA48
[(SA634)]
AT49LV008AT@TSOP40 [(SA409T)] AT49LV008AT@uBGA48
[(SA634)]
AT49LV010 AT49LV010@PLCC32
[(SA015A1T)]
AT49LV010@TSOP32 [(SA410T)]
AT49LV020
AT49LV020@PLCC32 [(SA015A1T)] AT49LV020@TSOP32
[(SA410T)]
AT49LV040 AT49LV040@PLCC32
[(SA015A1T)]
AT49LV040@TSOP32 [(SA410T)]
AT49LV040T
AT49LV040T@PLCC32 [(SA015A1T)] AT49LV040T@TSOP32
[(SA410T)]
AT49LV080@PSOP44 [(SA638)] AT49LV080@TSOP40
[(SA409T)]
AT49LV080T@PSOP44 [(SA638)] AT49LV080T@TSOP40
[(SA409T)]
AT49LV1024@TSOP40 [(SA623)] AT49LV1024A@TSOP40
[(SA623)]
AT49LV1025@PLCC44 [(SA244)] AT49LV160@TSOP48 [(SA247-
B005)]

AT49LV160@uBGA48 [(SA634A-B005A-Y048F001)]
AT49LV1604@TSOP48 [(SA247-B005)]
AT49LV1604@uBGA48 [(SA634A-B005A-Y048F001)]
AT49LV1604T@TSOP48 [(SA247-B005)]
AT49LV1604T@uBGA48 [(SA634A-B005A-Y048F001)]
AT49LV161@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV161@TSOP48 [(SA247-B005)]
AT49LV1614@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV1614@TSOP48 [(SA247-B005)]
AT49LV1614A@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV1614A@TSOP48 [(SA247-B005)]
AT49LV1614AT@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV1614AT@TSOP48 [(SA247-B005)]
AT49LV1614T@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV1614T@TSOP48 [(SA247-B005)]
AT49LV161T@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV161T@TSOP48 [(SA247-B005)] AT49LV2048@PSOP44
[(SA638)]
AT49LV2048@TSOP48 [(SA247-B005)] AT49LV2048A@PSOP44
[(SA638)]
AT49LV2048A@TSOP48 [(SA247-B005)]
AT49LV2048B@TSOP48 [(SA247-B005)]
AT49LV320@TSOP48 [(SA247-B005)]
AT49LV320@uBGA48 [(SA634A-B005A-Y048F001)]
AT49LV320T@TSOP48 [(SA247-B005)]
AT49LV320T@uBGA48 [(SA634A-B005A-Y048F001)]
AT49LV321@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV321@TSOP48 [(SA247-B005)]
AT49LV3218@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV3218@TSOP48 [(SA247-B005)]
AT49LV3218T@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV3218T@TSOP48 [(SA247-B005)]
AT49LV321T@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV321T@TSOP48 [(SA247-B005)]
AT49LV4096A@CBGA48 [(SA642F-B026A-T064F001)]
AT49LV4096A@PSOP44 [(SA638)]
AT49LV4096A@TSOP48 [(SA247-B005)]
AT49LV4096A@uBGA48 [(SA634A-B005A-Y048F001)]
AT49LV8011@CBGA48 [(SA642B-B026A-Y072F001)]
AT49LV8011@TSOP48 [(SA247-B005)]
AT49LV8011T@CBGA48 [(SA642B-B026A-Y072F001)]
AT49LV8011T@TSOP48 [(SA247-B005)]
AT49LV8192@PSOP44 [(SA638)] AT49LV8192@TSOP48 [(SA247-

B005)]
AT49LV8192A@TSOP48 [(SA247-B005)]
AT49LV8192A@uBGA48 [(SA634A-B005A-Y048F001)]
AT49LV8192AT@TSOP48 [(SA247-B005)]
AT49LV8192AT@uBGA48 [(SA634A-B005A-Y048F001)]
AT49LW040@PLCC32 [(SA015A1T)] AT49LW040@TSOP40
[(SA409T)]
AT49LW080@PLCC32 [(SA015A1T)] AT49LW080@TSOP40
[(SA409T)]
AT49SV163D@FBGA48 [(SA642U-B026A-T064F001Y)]
AT49SV163D@TSOP48 [(SA247-B005)]
AT49SV163DT@FBGA48 [(SA642U-B026A-T064F001Y)]
AT49SV163DT@TSOP48 [(SA247-B005)]
AT49SV322A@CBGA48 [(SA642U-B026A-T064F001Y)]
AT49SV322A@TSOP48 [(SA247-B005)]
AT49SV322AT@CBGA48 [(SA642U-B026A-T064F001Y)]
AT49SV322AT@TSOP48 [(SA247-B005)]
AT49SV322D@FBGA48 [(SA642U-B026A-T064F001Y)]
AT49SV322D@TSOP48 [(SA247-B005)]
AT49SV322DT@FBGA48 [(SA642U-B026A-T064F001Y)]
AT49SV322DT@TSOP48 [(SA247-B005)]
AT49SV802A@CBGA48 [(SA642G-B026A-T048F001Y)]
AT49SV802A@TSOP48 [(SA247-B005)]
AT49SV802AT@CBGA48 [(SA642G-B026A-T048F001Y)]
AT49SV802AT@TSOP48 [(SA247-B005)]
AT52BC1660A@FBGA66 [(SA642R-B023A-T096F001Y)]
AT52BC1660AT@FBGA66 [(SA642R-B023A-T096F001Y)]
AT52BC1661A@FBGA66 [(SA642R-B023A-T096F001Y)]
AT52BC1661AT@FBGA66 [(SA642R-B023A-T096F001Y)]
AT52BC3221A@FBGA66 [(SA642R-B023A-T080F001Y)]
AT52BC3221AT@FBGA66 [(SA642R-B023A-T080F001Y)]
AT52BC3221D@FBGA66 [(SA642R-B023A-T080F001Y)]
AT52BC3221DT@FBGA66 [(SA642R-B023A-T080F001Y)]
AT52BC6402A@FBGA66 [(SA642B-B023A-Y072F001Y)]
AT52BC6402AT@FBGA66 [(SA642B-B023A-Y072F001Y)]
AT52BR1662@CBGA66 [(SA642E-B023A-T072F001Y)]
AT52BR1662A@CBGA66 [(SA642E-B023A-T072F001Y)]
AT52BR1662AT@CBGA66 [(SA642E-B023A-T072F001Y)]
AT52BR1662T@CBGA66 [(SA642E-B023A-T072F001Y)]
AT52BR1664@CBGA66 [(SA642E-B023A-T072F001Y)]
AT52BR1664A@CBGA66 [(SA642E-B023A-T072F001Y)]
AT52BR1664AT@CBGA66 [(SA642E-B023A-T072F001Y)]
AT52BR1664T@CBGA66 [(SA642E-B023A-T072F001Y)]

AT52BR1672@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR1672T@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR1674@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR1674T@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3224@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3224A@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3224AT@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3224T@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3228@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3228A@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3228AT@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3228T@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3244@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3244T@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3248@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR3248T@CBGA66 [(SA642E-B023A-T072F001Y)]
 AT52BR6408A@CSP66 [(SA642E-B023A-T072F001Y)]
 AT52BR6408AT@CSP66 [(SA642E-B023A-T072F001Y)]
 AT59C11 AT59C11@SOIC8
 [(SA602A)]
 AT59C12 AT59C12@SOIC8
 [(SA602A)]
 AT59C13 AT59C13@SOIC8
 [(SA602A)]
 AT59C22 AT59C22@SOIC8
 [(SA602A)]
 AT93C46(08bit) AT93C46(08bit)@SOIC8
 [(SA602A)]
 AT93C46(08bit)@TSSOP8 [(SA026)] AT93C46
 (16bit)
 AT93C46(16bit)@SOIC8 [(SA602A)] AT93C46(16bit)@TSSOP8
 [(SA026)]
 AT93C46A AT93C46A@SOIC8
 [(SA602A)]
 AT93C46A@TSSOP8 [(SA026)]
 AT93C46C
 AT93C46C@SOIC8 [(SA602A)] AT93C46C@TSSOP8
 [(SA026)]
 AT93C46D(08bit) AT93C46D(08bit)@dBGA8
 [(BBBB)]
 AT93C46D(08bit)@MAP8 [(SA724)] AT93C46D(08bit)@SOIC8
 [(SA602A)]
 AT93C46D(08bit)@TSSOP8 [(SA026)] AT93C46D

(16bit)	
AT93C46D(16bit)@dBGA8 [(BBBB)]	AT93C46D(16bit)@MAP8
[(SA724)]	
AT93C46D(16bit)@SOIC8 [(SA602A)]	AT93C46D(16bit)@TSSOP8
[(SA026)]	
AT93C46E	AT93C46E@SOIC8
[(SA602A)]	
AT93C46E@TSSOP8 [(SA026)]	AT93C56
(08bit)	
AT93C56(08bit)@SOIC8 [(SA602A)]	AT93C56
(16bit)	
AT93C56(16bit)@SOIC8 [(SA602A)]	AT93C56A
(08bit)	
AT93C56A(08bit)@SOIC8 [(SA602A)]	AT93C56A(08bit)@TSSOP8
[(SA026)]	
AT93C56A(16bit)	AT93C56A(16bit)@SOIC8
[(SA602A)]	
AT93C56A(16bit)@TSSOP8 [(SA026)]	
AT93C57	
AT93C57@SOIC8 [(SA602A)]	AT93C66
(08bit)	
AT93C66(08bit)@SOIC8 [(SA602A)]	AT93C66
(16bit)	
AT93C66(16bit)@SOIC8 [(SA602A)]	AT93C66A
(08bit)	
AT93C66A(08bit)@SOIC8 [(SA602A)]	AT93C66A(08bit)@TSSOP8
[(SA026)]	
AT93C66A(16bit)	AT93C66A(16bit)@SOIC8
[(SA602A)]	
AT93C66A(16bit)@TSSOP8 [(SA026)]	AT93C86
(08bit)	
AT93C86(08bit)@SOIC8 [(SA602A)]	AT93C86(08bit)@TSSOP8
[(SA026)]	
AT93C86(16bit)	AT93C86(16bit)@SOIC8
[(SA602A)]	
AT93C86(16bit)@TSSOP8 [(SA026)]	AT93C86A
(08bit)	
AT93C86A(08bit)@SOIC8 [(SA602A)]	AT93C86A(08bit)@TSSOP8
[(SA026)]	
AT93C86A(16bit)	AT93C86A(16bit)@SOIC8
[(SA602A)]	
AT93C86A(16bit)@TSSOP8 [(SA026)]	

DRAM & SRAM

AT3864L
[(SA643)]
AT38H256
[(SA643)]

AT3864L@TSOP28

AT38H256@TSOP28

PLD

ATF16LV8C
[(SA001A)]
ATF16LV8C@SOIC20 [(SA404)]
[(SA026)]
ATF16LV8CEXT
[(SA001A)]
ATF16LV8CEXT@SOIC20 [(SA404)]
[(SA026)]
ATF16V8B
[(SA001A)]
ATF16V8B@SOIC20 [(SA404)]
[(SA026)]
ATF16V8BL
[(SA001A)]
ATF16V8BL@SOIC20 [(SA404)]
[(SA026)]
ATF16V8BQ
[(SA001A)]
ATF16V8BQ@SOIC20 [(SA404)]
[(SA026)]
ATF16V8BQL
[(SA001A)]
ATF16V8BQL@SOIC20 [(SA404)]
[(SA026)]
ATF16V8C
[(SA001A)]
ATF16V8C@SOIC20 [(SA404)]
[(SA026)]
ATF16V8CEXT
[(SA001A)]
ATF16V8CEXT@SOIC20 [(SA404)]
[(SA026)]

ATF16LV8C@PLCC20

ATF16LV8C@TSOP20

ATF16LV8CEXT@PLCC20

ATF16LV8CEXT@TSOP20

ATF16V8B@PLCC20

ATF16V8B@TSOP20

ATF16V8BL@PLCC20

ATF16V8BL@TSOP20

ATF16V8BQ@PLCC20

ATF16V8BQ@TSOP20

ATF16V8BQL@PLCC20

ATF16V8BQL@TSOP20

ATF16V8C@PLCC20

ATF16V8C@TSOP20

ATF16V8CEXT@PLCC20

ATF16V8CEXT@TSOP20

ATF16V8CZ [(SA001A)]	ATF16V8CZ@PLCC20
ATF16V8CZ@SOIC20 [(SA404)] [(SA026)]	ATF16V8CZ@TSOP20
ATF20V8B [(SA008A)]	ATF20V8B@PLCC28
ATF20V8B@SOIC24 [(SA404)]	
ATF20V8BL ATF20V8BL@PLCC28 [(SA008A)] [(SA404)]	ATF20V8BL@SOIC24
ATF20V8BQ [(SA008A)]	ATF20V8BQ@PLCC28
ATF20V8BQ@SOIC24 [(SA404)]	
ATF20V8BQL ATF20V8BQL@PLCC28 [(SA008A)] [(SA404)]	ATF20V8BQL@SOIC24
ATF22LV10C (UES)	ATF22LV10C
ATF22LV10C(UES)@PLCC28 [(SA008A)]	
ATF22LV10C(UES)@SOIC24 [(SA404)]	
ATF22LV10C(UES)@TSSOP24 [(SA643)]	
ATF22LV10C@PLCC28 [(SA008A)] [(SA404)]	ATF22LV10C@SOIC24
ATF22LV10C@TSSOP24 [(SA643)]	
ATF22LV10CEXT ATF22LV10CEXT@PLCC28 [(SA008A)] [(SA404)]	ATF22LV10CEXT@SOIC24
ATF22LV10CEXT@TSSOP24 [(SA643)]	
ATF22LV10CQ ATF22LV10CQ(UES)	
ATF22LV10CQ(UES)@PLCC28 [(SA008A)]	
ATF22LV10CQ(UES)@SOIC24 [(SA404)]	
ATF22LV10CQ(UES)@TSSOP24 [(SA643)]	
ATF22LV10CQ@PLCC28 [(SA008A)] [(SA404)]	ATF22LV10CQ@SOIC24
ATF22LV10CQ@TSSOP24 [(SA643)]	
ATF22LV10CQZ ATF22LV10CQZ(UES)	
ATF22LV10CQZ(UES)@PLCC28 [(SA008A)]	
ATF22LV10CQZ(UES)@SOIC24 [(SA404)]	
ATF22LV10CQZ(UES)@TSSOP24 [(SA643)]	
ATF22LV10CQZ@PLCC28 [(SA008A)] [(SA404)]	ATF22LV10CQZ@SOIC24

ATF22LV10CQZ@TSSOP24 [(SA643)]
ATF22LV10CZ
ATF22LV10CZ(UES)
ATF22LV10CZ(UES)@PLCC28 [(SA008A)]
ATF22LV10CZ(UES)@SOIC24 [(SA404)]
ATF22LV10CZ(UES)@TSSOP24 [(SA643)]
ATF22LV10CZ@PLCC28 [(SA008A)] ATF22LV10CZ@SOIC24
[(SA404)]
ATF22LV10CZ@TSSOP24 [(SA643)]
ATF22V10B
ATF22V10B(UES) ATF22V10B(UES)@PLCC28
[(SA008A)]
ATF22V10B(UES)@SOIC24 [(SA404)] ATF22V10B@PLCC28
[(SA008A)]
ATF22V10B@SOIC24 [(SA404)]
ATF22V10BL
ATF22V10BL(UES)
ATF22V10BL(UES)@PLCC28 [(SA008A)]
ATF22V10BL(UES)@SOIC24 [(SA404)] ATF22V10BL@PLCC28
[(SA008A)]
ATF22V10BL@SOIC24 [(SA404)]
ATF22V10BQ
ATF22V10BQ(UES)
ATF22V10BQ(UES)@PLCC28 [(SA008A)]
ATF22V10BQ(UES)@SOIC24 [(SA404)] ATF22V10BQ@PLCC28
[(SA008A)]
ATF22V10BQ@SOIC24 [(SA404)]
ATF22V10BQL
ATF22V10BQL(UES)
ATF22V10BQL(UES)@PLCC28 [(SA008A)]
ATF22V10BQL(UES)@SOIC24 [(SA404)]
ATF22V10BQL@PLCC28 [(SA008A)] ATF22V10BQL@SOIC24
[(SA404)]
ATF22V10C ATF22V10C
(UES)
ATF22V10C(UES)@PLCC28 [(SA008A)] ATF22V10C(UES)@SOIC24
[(SA404)]
ATF22V10C(UES)@TSSOP24 [(SA643)] ATF22V10C@PLCC28
[(SA008A)]
ATF22V10C@SOIC24 [(SA404)] ATF22V10C@TSSOP24
[(SA643)]
ATF22V10CEXT ATF22V10CEXT@PLCC28
[(SA008A)]

ATF22V10CEXT@SOIC24 [(SA404)]		ATF22V10CEXT@TSSOP24	
[(SA643)]			
ATF22V10CQ		ATF22V10CQ	
(UES)			
ATF22V10CQ(UES)@PLCC28 [(SA008A)]			
ATF22V10CQ(UES)@SOIC24 [(SA404)]			
ATF22V10CQ(UES)@TSSOP24 [(SA643)]			
ATF22V10CQ@PLCC28 [(SA008A)]		ATF22V10CQ@SOIC24	
[(SA404)]			
ATF22V10CQ@TSSOP24 [(SA643)]			
ATF22V10CQZ			
ATF22V10CQZ(UES)			
ATF22V10CQZ(UES)@PLCC28 [(SA008A)]			
ATF22V10CQZ(UES)@SOIC24 [(SA404)]			
ATF22V10CQZ(UES)@TSSOP24 [(SA643)]			
ATF22V10CQZ@PLCC28 [(SA008A)]		ATF22V10CQZ@SOIC24	
[(SA404)]			
ATF22V10CQZ@TSSOP24 [(SA643)]			
ATF22V10CZ			
ATF22V10CZ(UES)			
ATF22V10CZ(UES)@PLCC28 [(SA008A)]			
ATF22V10CZ(UES)@SOIC24 [(SA404)]			
ATF22V10CZ(UES)@TSSOP24 [(SA643)]			
ATF22V10CZ@PLCC28 [(SA008A)]		ATF22V10CZ@SOIC24	
[(SA404)]			
ATF22V10CZ@TSSOP24 [(SA643)]			
mode)		ATF750C	(ATF750C
ATF750C	(ATV750 mode)	ATF750C	(ATV750B
mode)			
ATF750C@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750C@PLCC28	(ATV750 mode) [(SA008A)]		
ATF750C@PLCC28	(ATV750B mode) [(SA008A)]		
ATF750C@SOIC24	(ATF750C mode) [(SA404)]		
ATF750C@SOIC24	(ATV750 mode) [(SA404)]		
ATF750C@SOIC24	(ATV750B mode) [(SA404)]		
ATF750CEXT	(ATF750C mode)		
ATF750CEXT@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750CEXT@SOIC24	(ATF750C mode) [(SA404)]		
ATF750CL	(ATV750 mode)	ATF750CL	(ATV750B
mode)			
ATF750CL@PLCC28	(ATV750 mode) [(SA008A)]		
ATF750CL@PLCC28	(ATV750B mode) [(SA008A)]		
ATF750CL@SOIC24	(ATV750 mode) [(SA404)]		

ATF750CL@SOIC24 (ATV750B mode) [(SA404)]
 ATF750LVC (ATF750C mode) ATF750LVC (ATV750 mode)
 ATF750LVC (ATV750B mode)
 ATF750LVC@PLCC28 (ATF750C mode) [(SA008A)]
 ATF750LVC@PLCC28 (ATV750 mode) [(SA008A)]
 ATF750LVC@PLCC28 (ATV750B mode) [(SA008A)]
 ATF750LVC@SOIC24 (ATF750C mode) [(SA404)]
 ATF750LVC@SOIC24 (ATV750 mode) [(SA404)]
 ATF750LVC@SOIC24 (ATV750B mode) [(SA404)]
 ATF750LVCEXT (ATF750C mode)
 ATF750LVCEXT@PLCC28 (ATF750C mode) [(SA008A)]
 ATF750LVCEXT@SOIC24 (ATF750C mode) [(SA404)]
 ATF750LVCL (ATF750C mode) ATF750LVCL (ATV750 mode)
 ATF750LVCL (ATV750B mode)
 ATF750LVCL@PLCC28 (ATF750C mode) [(SA008A)]
 ATF750LVCL@PLCC28 (ATV750 mode) [(SA008A)]
 ATF750LVCL@PLCC28 (ATV750B mode) [(SA008A)]
 ATF750LVCL@SOIC24 (ATF750C mode) [(SA404)]
 ATF750LVCL@SOIC24 (ATV750 mode) [(SA404)]
 ATF750LVCL@SOIC24 (ATV750B mode) [(SA404)]
 ATV750 ATF750@PLCC28
 [(SA008A)]
 ATV750@SOIC24 [(SA404)]
 ATV750B ATF750B@SOIC24
 ATF750B@PLCC28 [(SA008A)] [(SA404)]
 ATV750BL ATF750BL@PLCC28
 [(SA008A)]
 ATV750BL@SOIC24 [(SA404)]
 ATV750L ATF750L@SOIC24
 ATV750L@PLCC28 [(SA008A)] [(SA404)]

MICROCONTROLLER

AT80F51 AT80F51@PLCC44
 [(SA244)]
 AT80F51@TQFP44 [(SA245A)]
 AT80F52 AT80F52@TQFP44
 AT80F52@PLCC44 [(SA244)]

[(SA245A)]
AT87F51 AT87F51@PLCC44
[(SA244)]
AT87F51@TQFP44 [(SA245A)]
AT87F51RC
AT87F51RC@PLCC44 [(SA244)] AT87F51RC@TQFP44
[(SA245A)]
AT87F52 AT87F52@PLCC44
[(SA244)]
AT87F52@TQFP44 [(SA245A)]
AT87F55
AT87F55@PLCC44 [(SA244)] AT87F55@TQFP44
[(SA245A)]
AT87F55WD AT87F55WD@PLCC44
[(SA244)]
AT87F55WD@TQFP44 [(SA245A)]
AT87LV51
AT87LV51@PLCC44 [(SA244)] AT87LV51@TQFP44
[(SA245A)]
AT87LV52 AT87LV52@PLCC44
[(SA244)]
AT87LV52@TQFP44 [(SA245A)]
AT89C1051
AT89C1051@SOIC20 [(SA404)]
AT89C1051U
AT89C1051U@SOIC20 [(SA404)]
AT89C2051
AT89C2051@SOIC20 [(SA404)]
AT89C2051X2
AT89C2051X2@SOIC20 [(SA404)]
AT89C4051
AT89C4051@SOIC20 [(SA404)]
AT89C51
AT89C51@PLCC44 [(SA244)] AT89C51@TQFP44
[(SA245A)]
AT89C5130A@QFN32 [(SA686)] AT89C5130A@SOIC28
[(SA404)]
AT89C5130AM@QFN32 [(SA686)] AT89C5130AM@SOIC28
[(SA404)]
AT89C5131@MLF48 [(SA696)] AT89C5131@SOIC28
[(SA404)]
AT89C5131A@QFN32 [(SA701)] AT89C5131A@SOIC28
[(SA404)]

AT89C5131AL@QFN32 [(SA701)]	AT89C5131AL@SOIC28
[(SA404)]	
AT89C5131AM@QFN32 [(SA701)]	AT89C5131AM@SOIC28
[(SA404)]	
AT89C51AC2@PLCC44 [(SA244)]	AT89C51AC2@TQFP44
[(SA245A)]	
AT89C51AC3@PLCC44 [(SA244)]	AT89C51AC3@TQFP44
[(SA245A)]	
AT89C51CC01@PLCC44 [(SA244)]	AT89C51CC01@TQFP44
[(SA245A)]	
AT89C51CC03C@PLCC44 [(SA244)]	AT89C51CC03C@TQFP44
[(SA245A)]	
AT89C51CC03U@PLCC44 [(SA244)]	AT89C51CC03U@TQFP44
[(SA245A)]	
AT89C51ED2	AT89C51ED2@PLCC44
[(SA244)]	
AT89C51ED2@TQFP44 [(SA245A)]	AT89C51IC2@PLCC44
[(SA244)]	
AT89C51IC2@TQFP44 [(SA245A)]	
AT89C51ID2	
AT89C51ID2@PLCC44 [(SA244)]	AT89C51ID2@TQFP44
[(SA245A)]	
AT89C51RB2	AT89C51RB2@PLCC44
[(SA244)]	
AT89C51RB2@TQFP44 [(SA245A)]	
AT89C51RC	
AT89C51RC@PLCC44 [(SA244)]	AT89C51RC@TQFP44
[(SA245A)]	
AT89C51RC2	AT89C51RC2@PLCC44
[(SA244)]	
AT89C51RC2@TQFP44 [(SA245A)]	
AT89C51RD2	
AT89C51RD2@PLCC44 [(SA244)]	AT89C51RD2@TQFP44
[(SA245A)]	
AT89C51RE2@PLCC44 [(SA244)]	AT89C51RE2@TQFP44
[(SA675)]	
AT89C52	AT89C52@PLCC44
[(SA244)]	
AT89C52@TQFP44 [(SA245A)]	
AT89C55	
AT89C55@PLCC44 [(SA244)]	AT89C55@TQFP44
[(SA245A)]	
AT89C55WD	AT89C55WD@PLCC44

[(SA244)]
AT89C55WD@TQFP44 [(SA245A)]
AT89LP2051
AT89LP2051@SOIC20 [(SA404)] AT89LP2051@TSSOP20
[(SA026)]
AT89LP2052 AT89LP2052(ISP) [ISP-
HEADER01]
AT89LP2052@SOIC20 [(SA404)]
AT89LP2052@SOIC20(ISP) [ISP-HEADER01]
AT89LP2052@TSSOP20 [(SA026)]
AT89LP2052@TSSOP20(ISP) [ISP-HEADER01]
AT89LP213 AT89LP213(ISP) [ISP-
HEADER01]
AT89LP213@TSSOP14 [(SA026)]
AT89LP213@TSSOP14(ISP) [ISP-HEADER01]
AT89LP214 AT89LP214(ISP) [ISP-
HEADER01]
AT89LP214@TSSOP14 [(SA026)]
AT89LP214@TSSOP14(ISP) [ISP-HEADER01]
AT89LP216 AT89LP216(ISP) [ISP-
HEADER01]
AT89LP216@TSSOP16 [(SA026)]
AT89LP216@TSSOP16(ISP) [ISP-HEADER01]
AT89LP4051 AT89LP4051@SOIC20
[(SA404)]
AT89LP4051@TSSOP20 [(SA026)]
AT89LP4052
AT89LP4052(ISP) [ISP-HEADER01] AT89LP4052@SOIC20
[(SA404)]
AT89LP4052@SOIC20(ISP) [ISP-HEADER01]
AT89LP4052@TSSOP20 [(SA026)]
AT89LP4052@TSSOP20(ISP) [ISP-HEADER01]
AT89LS51 AT89LS51(ISP) [ISP-
HEADER01]
AT89LS51@PLCC44 [(SA244)]
AT89LS51@PLCC44(ISP) [ISP-HEADER01]
AT89LS51@TQFP44 [(SA245A)]
AT89LS51@TQFP44(ISP) [ISP-HEADER01]
AT89LS52 AT89LS52(ISP) [ISP-
HEADER01]
AT89LS52@PLCC44 [(SA244)]
AT89LS52@PLCC44(ISP) [ISP-HEADER01]
AT89LS52@TQFP44 [(SA245A)]

AT89LS52@TQFP44(ISP) [ISP-HEADER01]
AT89LS53 AT89LS53(ISP) [ISP-
HEADER01]
AT89LS53@PLCC44 [(SA244)]
AT89LS53@PLCC44(ISP) [ISP-HEADER01]
AT89LS53@TQFP44 [(SA245A)]
AT89LS53@TQFP44(ISP) [ISP-HEADER01]
AT89LS8252 AT89LS8252(ISP) [ISP-
HEADER01]
AT89LS8252@PLCC44 [(SA244)]
AT89LS8252@PLCC44(ISP) [ISP-HEADER01]
AT89LS8252@TQFP44 [(SA245A)]
AT89LS8252@TQFP44(ISP) [ISP-HEADER01]
AT89LV51 AT89LV51@PLCC44
[(SA244)]
AT89LV51@TQFP44 [(SA245A)]
AT89LV52
AT89LV52@PLCC44 [(SA244)] AT89LV52@TQFP44
[(SA245A)]
AT89LV55 AT89LV55@PLCC44
[(SA244)]
AT89LV55@TQFP44 [(SA245A)]
AT89S2051
AT89S2051@SOIC20 [(SA404)]
AT89S4051
AT89S4051@SOIC20 [(SA404)]
AT89S51
AT89S51(ISP) [ISP-HEADER01] AT89S51@PLCC44
[(SA244)]
AT89S51@PLCC44(ISP) [ISP-HEADER01]
AT89S51@TQFP44 [(SA245A)]
AT89S51@TQFP44(ISP) [ISP-HEADER01]
AT89S52 AT89S52(ISP) [ISP-
HEADER01]
AT89S52@PLCC44 [(SA244)]
AT89S52@PLCC44(ISP) [ISP-HEADER01]
AT89S52@TQFP44 [(SA245A)]
AT89S52@TQFP44(ISP) [ISP-HEADER01]
AT89S53 AT89S53(ISP) [ISP-
HEADER01]
AT89S53@PLCC44 [(SA244)]
AT89S53@PLCC44(ISP) [ISP-HEADER01]
AT89S53@TQFP44 [(SA245A)]

AT89S53@TQFP44 (ISP) [ISP-HEADER01]
AT89S54 AT89S54@PLCC44
[(SA244)]
AT89S54@TQFP44 [(SA245A)]
AT89S58 AT89S58@TQFP44
AT89S58@PLCC44 [(SA244)]
[(SA245A)]
AT89S64 AT89S64@PLCC44
[(SA244)]
AT89S64@TQFP44 [(SA245A)]
AT89S8252 AT89S8252@PLCC44
AT89S8252 (ISP) [ISP-HEADER01]
[(SA244)]
AT89S8252@PLCC44 (ISP) [ISP-HEADER01]
AT89S8252@TQFP44 [(SA245A)]
AT89S8252@TQFP44 (ISP) [ISP-HEADER01]
AT89S8253 AT89S8253 (ISP) [ISP-
HEADER01]
AT89S8253@PLCC44 [(SA244)]
AT89S8253@PLCC44 (ISP) [ISP-HEADER01]
AT89S8253@TQFP44 [(SA245A)]
AT89S8253@TQFP44 (ISP) [ISP-HEADER01]
AT90CAN128@QFN64 (ISP) [ISP-HEADER01]
AT90CAN128@TQFP64 (ISP) [ISP-HEADER01]
AT90CAN32@QFN64 (ISP) [ISP-HEADER01]
AT90CAN32@TQFP64 (ISP) [ISP-HEADER01]
AT90CAN64@QFN64 (ISP) [ISP-HEADER01]
AT90CAN64@TQFP64 (ISP) [ISP-HEADER01]
AT90LS2323 AT90LS2323 (ISP) [ISP-
HEADER01]
AT90LS2323@SOIC8 [(SA605A)]
AT90LS2323@SOIC8 (ISP) [ISP-HEADER01]
AT90LS2333 AT90LS2333 (ISP) [ISP-
HEADER01]
AT90LS2333@TQFP32 [(SA663)]
AT90LS2333@TQFP32 (ISP) [ISP-HEADER01]
AT90LS2343 AT90LS2343 (ISP) [ISP-
HEADER01]
AT90LS2343@SOIC8 [(SA605A)]
AT90LS2343@SOIC8 (ISP) [ISP-HEADER01]
AT90LS4433 AT90LS4433 (ISP) [ISP-
HEADER01]
AT90LS4433@TQFP32 [(SA663)]

AT90LS4433@TQFP32 (ISP) [ISP-HEADER01]
AT90LS4434 AT90LS4434 (ISP) [ISP-
HEADER01]
AT90LS4434@PLCC44 [(SA244)]
AT90LS4434@PLCC44 (ISP) [ISP-HEADER01]
AT90LS4434@TQFP44 [(SA245A)]
AT90LS4434@TQFP44 (ISP) [ISP-HEADER01]
AT90LS8535 AT90LS8535 (ISP) [ISP-
HEADER01]
AT90LS8535@PLCC44 [(SA244)]
AT90LS8535@PLCC44 (ISP) [ISP-HEADER01]
AT90LS8535@TQFP44 [(SA245A)]
AT90LS8535@TQFP44 (ISP) [ISP-HEADER01]
AT90PWM1@SOIC24 [(SA404)] AT90PWM2@SOIC24
[(SA404)]
AT90PWM2@SOIC24 (ISP) [ISP-HEADER01]
AT90PWM216@SOIC24 [(SA404)] AT90PWM2B@SOIC24
[(SA404)]
AT90PWM2B@SOIC24 (ISP) [ISP-HEADER01]
AT90PWM3@QFN32 [(SA701)]
AT90PWM3@QFN32 (ISP) [ISP-HEADER01]
AT90PWM3@SOIC32 [(SA715)]
AT90PWM3@SOIC32 (ISP) [ISP-HEADER01]
AT90PWM316@QFN32 [(SA701)] AT90PWM316@SOIC32
[(SA715)]
AT90PWM3B@QFN32 [(SA701)]
AT90PWM3B@QFN32 (ISP) [ISP-HEADER01]
AT90PWM3B@SOIC32 [(SA715)]
AT90PWM3B@SOIC32 (ISP) [ISP-HEADER01]
AT90S1200 AT90S1200 (ISP) [ISP-
HEADER01]
AT90S1200@SOIC20 [(SA404)]
AT90S1200@SOIC20 (ISP) [ISP-HEADER01]
AT90S1200@SSOP20 [(SA626A)]
AT90S1200@SSOP20 (ISP) [ISP-HEADER01]
AT90S1200A AT90S1200A (ISP) [ISP-
HEADER01]
AT90S1200A@SOIC20 [(SA404)]
AT90S1200A@SOIC20 (ISP) [ISP-HEADER01]
AT90S1200A@SSOP20 [(SA626A)]
AT90S1200A@SSOP20 (ISP) [ISP-HEADER01]
AT90S2313 AT90S2313 (ISP) [ISP-
HEADER01]

AT90S2313@SOIC20 [(SA404)]
AT90S2313@SOIC20(ISP) [ISP-HEADER01]
AT90S2323 AT90S2323(ISP) [ISP-
HEADER01]
AT90S2323@SOIC8 [(SA605A)]
AT90S2323@SOIC8(ISP) [ISP-HEADER01]
AT90S2333 AT90S2333(ISP) [ISP-
HEADER01]
AT90S2333@TQFP32 [(SA663)]
AT90S2333@TQFP32(ISP) [ISP-HEADER01]
AT90S2343 AT90S2343(ISP) [ISP-
HEADER01]
AT90S2343@SOIC8 [(SA605A)]
AT90S2343@SOIC8(ISP) [ISP-HEADER01]
AT90S4414 AT90S4414(ISP) [ISP-
HEADER01]
AT90S4414@PLCC44 [(SA244)]
AT90S4414@PLCC44(ISP) [ISP-HEADER01]
AT90S4414@TQFP44 [(SA245A)]
AT90S4414@TQFP44(ISP) [ISP-HEADER01]
AT90S4433 AT90S4433(ISP) [ISP-
HEADER01]
AT90S4433@TQFP32 [(SA663)]
AT90S4433@TQFP32(ISP) [ISP-HEADER01]
AT90S4434 AT90S4434(ISP) [ISP-
HEADER01]
AT90S4434@PLCC44 [(SA244)]
AT90S4434@PLCC44(ISP) [ISP-HEADER01]
AT90S4434@TQFP44 [(SA245A)]
AT90S4434@TQFP44(ISP) [ISP-HEADER01]
AT90S8515 AT90S8515(ISP) [ISP-
HEADER01]
AT90S8515@PLCC44 [(SA244)]
AT90S8515@PLCC44(ISP) [ISP-HEADER01]
AT90S8515@TQFP44 [(SA245A)]
AT90S8515@TQFP44(ISP) [ISP-HEADER01]
AT90S8535 AT90S8535(ISP) [ISP-
HEADER01]
AT90S8535@PLCC44 [(SA244)]
AT90S8535@PLCC44(ISP) [ISP-HEADER01]
AT90S8535@TQFP44 [(SA245A)]
AT90S8535@TQFP44(ISP) [ISP-HEADER01]
AT90USB1286@QFN64(ISP) [ISP-HEADER01]

AT90USB1286@TQFP64(ISP) [ISP-HEADER01]
AT90USB1287@QFN64(ISP) [ISP-HEADER01]
AT90USB1287@TQFP64(ISP) [ISP-HEADER01]
AT90USB646@QFN64(ISP) [ISP-HEADER01]
AT90USB646@TQFP64(ISP) [ISP-HEADER01]
AT90USB647@QFN64(ISP) [ISP-HEADER01]
AT90USB647@TQFP64(ISP) [ISP-HEADER01]
ATAM862@SSO24 [(SA026)] ATAM893@SSO20
[(SA026)]
ATAM894@SSO24 [(SA026)]
ATMEGA128@QFN64(ISP) [ISP-HEADER01]
ATMEGA128@TQFP64(ISP) [ISP-HEADER01]
ATMEGA1280@TQFP100(ISP) [ISP-HEADER01]
ATMEGA1280V@TQFP100(ISP) [ISP-HEADER01]
ATMEGA128L@QFN64(ISP) [ISP-HEADER01]
ATMEGA128L@TQFP64(ISP) [ISP-HEADER01]
ATMEGA16 ATMEGA16
(fast)
ATMEGA16(fast)@MLF44 [(SA712)] ATMEGA16(fast)@TQFP44
[(SA245A)]
ATMEGA16(ISP) [ISP-HEADER01] ATMEGA16@MLF44
[(SA712)]
ATMEGA16@MLF44(ISP) [ISP-HEADER01]
ATMEGA16@TQFP44 [(SA245A)]
ATMEGA16@TQFP44(ISP) [ISP-HEADER01]
ATMEGA161 ATMEGA161@TQFP44
[(SA245A)]
ATMEGA161L ATMEGA161L@TQFP44
[(SA245A)]
ATMEGA162 ATMEGA162(ISP) [ISP-
HEADER01]
ATMEGA162@PLCC44(ISP) [ISP-HEADER01]
ATMEGA162@TQFP44 [(SA245A)]
ATMEGA162@TQFP44(ISP) [ISP-HEADER01]
ATMEGA162V ATMEGA162V@TQFP44
[(SA245A)]
ATMEGA163 ATMEGA163@TQFP44
[(SA245A)]
ATMEGA163L ATMEGA163L@TQFP44
[(SA245A)]
ATMEGA164P ATMEGA164P@MLP44
[(SA712)]
ATMEGA164P@TQFP44 [(SA245A)]

ATMEGA164PL
ATMEGA164PL@MLP44 [(SA712)] ATMEGA164PL@TQFP44
[(SA245A)]
ATMEGA165@QFN64(ISP) [ISP-HEADER01]
ATMEGA165@TQFP64(ISP) [ISP-HEADER01]
ATMEGA168 ATMEGA168(ISP) [ISP-
HEADER01]
ATMEGA168@MLP32 [(SA686)]
ATMEGA168@MLP32(ISP) [ISP-HEADER01]
ATMEGA168@TQFP32 [(SA663)]
ATMEGA168@TQFP32(ISP) [ISP-HEADER01]
ATMEGA168P ATMEGA168P(ISP) [ISP-
HEADER01]
ATMEGA168P@MLP32 [(SA686)]
ATMEGA168P@MLP32(ISP) [ISP-HEADER01]
ATMEGA168P@TQFP32 [(SA663)]
ATMEGA168P@TQFP32(ISP) [ISP-HEADER01]
ATMEGA168PV ATMEGA168PV(ISP) [ISP-
HEADER01]
ATMEGA168PV@MLP32 [(SA686)]
ATMEGA168PV@MLP32(ISP) [ISP-HEADER01]
ATMEGA168PV@TQFP32 [(SA663)]
ATMEGA168PV@TQFP32(ISP) [ISP-HEADER01]
ATMEGA168V ATMEGA168V(ISP) [ISP-
HEADER01]
ATMEGA168V@MLP32 [(SA686)]
ATMEGA168V@MLP32(ISP) [ISP-HEADER01]
ATMEGA168V@TQFP32 [(SA663)]
ATMEGA168V@TQFP32(ISP) [ISP-HEADER01]
ATMEGA169@MLF64(ISP) [ISP-HEADER01]
ATMEGA169@TQFP64(ISP) [ISP-HEADER01]
ATMEGA169PV@MLF64(ISP) [ISP-HEADER01]
ATMEGA169PV@TQFP64(ISP) [ISP-HEADER01]
ATMEGA16L ATMEGA16L
(fast)
ATMEGA16L(fast)@MLF44 [(SA712)]
ATMEGA16L(fast)@TQFP44 [(SA245A)]
ATMEGA16L(ISP) [ISP-HEADER01] ATMEGA16L@MLF44
[(SA712)]
ATMEGA16L@MLF44(ISP) [ISP-HEADER01]
ATMEGA16L@TQFP44 [(SA245A)]
ATMEGA16L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA2560@TQFP100(ISP) [ISP-HEADER01]

ATMEGA2560V@TQFP100(ISP) [ISP-HEADER01]
ATMEGA2561@QFN64(ISP) [ISP-HEADER01]
ATMEGA2561@TQFP64(ISP) [ISP-HEADER01]
ATMEGA2561V@QFN64(ISP) [ISP-HEADER01]
ATMEGA2561V@TQFP64(ISP) [ISP-HEADER01]
ATMEGA32 ATMEGA32(ISP) [ISP-
HEADER01]
ATMEGA32(new) ATMEGA32(new)
(fast)
ATMEGA32(new)(fast)@MLF44 [(SA712)]
ATMEGA32(new)(fast)@PLCC44 [(SA244)]
ATMEGA32(new)(fast)@TQFP44 [(SA245A)]
ATMEGA32(new)@MLF44 [(SA712)] ATMEGA32(new)@PLCC44
[(SA244)]
ATMEGA32(new)@TQFP44 [(SA245A)] ATMEGA32@MLF44
[(SA712)]
ATMEGA32@MLF44(ISP) [ISP-HEADER01]
ATMEGA32@PLCC44 [(SA244)] ATMEGA32@TQFP44
[(SA245A)]
ATMEGA32@TQFP44(ISP) [ISP-HEADER01]
ATMEGA323 ATMEGA323@TQFP44
[(SA245A)]
ATMEGA323L ATMEGA323L@TQFP44
[(SA245A)]
ATMEGA324P ATMEGA324P@MLP44
[(SA712)]
ATMEGA324P@TQFP44 [(SA245A)]
ATMEGA324PL ATMEGA324PL@TQFP44
ATMEGA324PL@MLP44 [(SA712)]
[(SA245A)]
ATMEGA3250@TQFP100(ISP) [ISP-HEADER01]
ATMEGA325P@TQFP64(ISP) [ISP-HEADER01]
ATMEGA325V@QFN64(ISP) [ISP-HEADER01]
ATMEGA328P ATMEGA328P(ISP) [ISP-
HEADER01]
ATMEGA328P@MLP32 [(SA686)]
ATMEGA328P@MLP32(ISP) [ISP-HEADER01]
ATMEGA328P@TQFP32 [(SA663)]
ATMEGA328P@TQFP32(ISP) [ISP-HEADER01]
ATMEGA328PV ATMEGA328PV(ISP) [ISP-
HEADER01]
ATMEGA328PV@MLP32 [(SA686)]
ATMEGA328PV@MLP32(ISP) [ISP-HEADER01]

ATMEGA328PV@TQFP32 [(SA663)]
ATMEGA328PV@TQFP32(ISP) [ISP-HEADER01]
ATMEGA329@QFN64(ISP) [ISP-HEADER01]
ATMEGA3290@TQFP100(ISP) [ISP-HEADER01]
ATMEGA329P@TQFP64(ISP) [ISP-HEADER01]
ATMEGA32L ATMEGA32L(ISP) [ISP-
HEADER01]
ATMEGA32L(new) ATMEGA32L(new)
(fast)
ATMEGA32L(new)(fast)@MLF44 [(SA712)]
ATMEGA32L(new)(fast)@PLCC44 [(SA244)]
ATMEGA32L(new)(fast)@TQFP44 [(SA245A)]
ATMEGA32L(new)@MLF44 [(SA712)] ATMEGA32L(new)@PLCC44
[(SA244)]
ATMEGA32L(new)@TQFP44 [(SA245A)] ATMEGA32L@MLF44
[(SA712)]
ATMEGA32L@MLF44(ISP) [ISP-HEADER01]
ATMEGA32L@PLCC44 [(SA244)] ATMEGA32L@TQFP44
[(SA245A)]
ATMEGA32L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA406@LQFP48 [(SA248)]
ATMEGA48
ATMEGA48(ISP) [ISP-HEADER01] ATMEGA48@MLP32
[(SA686)]
ATMEGA48@MLP32(ISP) [ISP-HEADER01]
ATMEGA48@TQFP32 [(SA663)]
ATMEGA48@TQFP32(ISP) [ISP-HEADER01]
ATMEGA48P ATMEGA48P@MLP32
[(SA686)]
ATMEGA48P@TQFP32 [(SA663)]
ATMEGA48PV
ATMEGA48PV@MLP32 [(SA686)] ATMEGA48PV@TQFP32
[(SA663)]
ATMEGA48V ATMEGA48V(ISP) [ISP-
HEADER01]
ATMEGA48V@MLP32 [(SA686)]
ATMEGA48V@MLP32(ISP) [ISP-HEADER01]
ATMEGA48V@TQFP32 [(SA663)]
ATMEGA48V@TQFP32(ISP) [ISP-HEADER01]
ATMEGA64@QFN64(ISP) [ISP-HEADER01]
ATMEGA64@TQFP64(ISP) [ISP-HEADER01]
ATMEGA644 ATMEGA644(ISP) [ISP-
HEADER01]

ATMEGA644@MLF44 [(SA712)]
ATMEGA644@MLF44(ISP) [ISP-HEADER01]
ATMEGA644@TQFP44 [(SA245A)]
ATMEGA644@TQFP44(ISP) [ISP-HEADER01]
ATMEGA644P ATMEGA644P(ISP) [ISP-
HEADER01]
ATMEGA644P@MLF44 [(SA712)]
ATMEGA644P@MLF44(ISP) [ISP-HEADER01]
ATMEGA644P@TQFP44 [(SA245A)]
ATMEGA644P@TQFP44(ISP) [ISP-HEADER01]
ATMEGA644PV ATMEGA644PV(ISP) [ISP-
HEADER01]
ATMEGA644PV@MLF44 [(SA712)]
ATMEGA644PV@MLF44(ISP) [ISP-HEADER01]
ATMEGA644PV@TQFP44 [(SA245A)]
ATMEGA644PV@TQFP44(ISP) [ISP-HEADER01]
ATMEGA644V ATMEGA644V(ISP) [ISP-
HEADER01]
ATMEGA644V@MLF44 [(SA712)]
ATMEGA644V@MLF44(ISP) [ISP-HEADER01]
ATMEGA644V@TQFP44 [(SA245A)]
ATMEGA644V@TQFP44(ISP) [ISP-HEADER01]
ATMEGA645@QFN64(ISP) [ISP-HEADER01]
ATMEGA645@TQFP64(ISP) [ISP-HEADER01]
ATMEGA6450@TQFP100(ISP) [ISP-HEADER01]
ATMEGA649@TQFP64(ISP) [ISP-HEADER01]
ATMEGA6490@TQFP100(ISP) [ISP-HEADER01]
ATMEGA649V@QFN64(ISP) [ISP-HEADER01]
ATMEGA64L@QFN64(ISP) [ISP-HEADER01]
ATMEGA64L@TQFP64(ISP) [ISP-HEADER01]
ATMEGA8 ATMEGA8
(fast)
ATMEGA8(fast)@TQFP32 [(SA663)] ATMEGA8(ISP) [ISP-
HEADER01]
ATMEGA8@MLF32 [(SA686)]
ATMEGA8@MLF32(ISP) [ISP-HEADER01]
ATMEGA8@TQFP32 [(SA663)]
ATMEGA8@TQFP32(ISP) [ISP-HEADER01]
ATMEGA8515 ATMEGA8515
(fast)
ATMEGA8515(fast)@PLCC44 [(SA244)]
ATMEGA8515(fast)@TQFP44 [(SA245A)]
ATMEGA8515(ISP) [ISP-HEADER01] ATMEGA8515@PLCC44

[(SA244)]
ATMEGA8515@PLCC44 (ISP) [ISP-HEADER01]
ATMEGA8515@TQFP44 [(SA245A)]
ATMEGA8515@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA8515L ATMEGA8515L
(fast)
ATMEGA8515L(fast)@PLCC44 [(SA244)]
ATMEGA8515L(fast)@TQFP44 [(SA245A)]
ATMEGA8515L (ISP) [ISP-HEADER01] ATMEGA8515L@PLCC44
[(SA244)]
ATMEGA8515L@PLCC44 (ISP) [ISP-HEADER01]
ATMEGA8515L@TQFP44 [(SA245A)]
ATMEGA8515L@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA8535 ATMEGA8535
(fast)
ATMEGA8535(fast)@MLF44 [(SA712)]
ATMEGA8535(fast)@PLCC44 [(SA244)]
ATMEGA8535(fast)@TQFP44 [(SA245A)]
ATMEGA8535 (ISP) [ISP-HEADER01] ATMEGA8535@PLCC44
[(SA244)]
ATMEGA8535@PLCC44 (ISP) [ISP-HEADER01]
ATMEGA8535@TQFP44 [(SA245A)]
ATMEGA8535@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA8535L ATMEGA8535L
(fast)
ATMEGA8535L(fast)@MLF44 [(SA712)]
ATMEGA8535L(fast)@PLCC44 [(SA244)]
ATMEGA8535L(fast)@TQFP44 [(SA245A)]
ATMEGA8535L (ISP) [ISP-HEADER01] ATMEGA8535L@PLCC44
[(SA244)]
ATMEGA8535L@PLCC44 (ISP) [ISP-HEADER01]
ATMEGA8535L@TQFP44 [(SA245A)]
ATMEGA8535L@TQFP44 (ISP) [ISP-HEADER01]
ATMEGA88 ATMEGA88 (ISP) [ISP-
HEADER01]
ATMEGA88@MLP32 [(SA686)]
ATMEGA88@MLP32 (ISP) [ISP-HEADER01]
ATMEGA88@TQFP32 [(SA663)]
ATMEGA88@TQFP32 (ISP) [ISP-HEADER01]
ATMEGA88P ATMEGA88P@MLP32
[(SA686)]
ATMEGA88P@TQFP32 [(SA663)]
ATMEGA88PV

ATMEGA88PV@MLP32 [(SA686)]	ATMEGA88PV@TQFP32
[(SA663)]	
ATMEGA88V	ATMEGA88V(ISP) [ISP-
HEADER01]	
ATMEGA88V@MLP32 [(SA686)]	
ATMEGA88V@MLP32(ISP) [ISP-HEADER01]	
ATMEGA88V@TQFP32 [(SA663)]	
ATMEGA88V@TQFP32(ISP) [ISP-HEADER01]	
ATMEGA8L	ATMEGA8L
(fast)	
ATMEGA8L(fast)@TQFP32 [(SA663)]	ATMEGA8L(ISP) [ISP-
HEADER01]	
ATMEGA8L@MLF32 [(SA686)]	
ATMEGA8L@MLF32(ISP) [ISP-HEADER01]	
ATMEGA8L@TQFP32 [(SA663)]	
ATMEGA8L@TQFP32(ISP) [ISP-HEADER01]	
ATtiny10	ATtiny10(ISP) [ISP-
HEADER01]	
ATtiny10@SOIC8 [(SA605A)]	
ATtiny10@SOIC8(ISP) [ISP-HEADER01]	
ATtiny11	ATtiny11(ISP) [ISP-
HEADER01]	
ATtiny11@SOIC8 [(SA605A)]	
ATtiny11@SOIC8(ISP) [ISP-HEADER01]	
ATtiny11L	ATtiny11L(ISP) [ISP-
HEADER01]	
ATtiny11L@SOIC8 [(SA605A)]	
ATtiny11L@SOIC8(ISP) [ISP-HEADER01]	
ATtiny12	ATtiny12(ISP) [ISP-
HEADER01]	
ATtiny12@SOIC8 [(SA605A)]	
ATtiny12@SOIC8(ISP) [ISP-HEADER01]	
ATtiny12L	ATtiny12L(ISP) [ISP-
HEADER01]	
ATtiny12L@SOIC8 [(SA605A)]	
ATtiny12L@SOIC8(ISP) [ISP-HEADER01]	
ATtiny12V	ATtiny12V(ISP) [ISP-
HEADER01]	
ATtiny12V@SOIC8 [(SA605A)]	
ATtiny12V@SOIC8(ISP) [ISP-HEADER01]	
ATtiny13	ATtiny13
(Fuse)	
ATtiny13(Fuse)@QFN10 [(SA695A)]	ATtiny13(Fuse)@QFN20

[(SA692)]
ATtiny13(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13(ISP) [ISP-HEADER01] ATtiny13@QFN10
[(SA695A)]
ATtiny13@QFN10(ISP) [ISP-HEADER01]
ATtiny13@QFN20 [(SA692)]
ATtiny13@QFN20(ISP) [ISP-HEADER01]
ATtiny13@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
ATtiny13@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
ATtiny13V ATtiny13V
(Fuse)
ATtiny13V(Fuse)@QFN10 [(SA695A)] ATtiny13V(Fuse)@QFN20
[(SA692)]
ATtiny13V(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13V(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13V(ISP) [ISP-HEADER01] ATtiny13V@QFN10
[(SA695A)]
ATtiny13V@QFN10(ISP) [ISP-HEADER01]
ATtiny13V@QFN20 [(SA692)]
ATtiny13V@QFN20(ISP) [ISP-HEADER01]
ATtiny13V@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13V@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
ATtiny13V@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13V@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
ATtiny15 ATtiny15(ISP) [ISP-
HEADER01]
ATtiny15@SOIC8 [(SA605A)]
ATtiny15@SOIC8(ISP) [ISP-HEADER01]
ATtiny15L ATtiny15L(ISP) [ISP-
HEADER01]
ATtiny15L@SOIC8 [(SA605A)]
ATtiny15L@SOIC8(ISP) [ISP-HEADER01]
ATtiny2313 ATtiny2313(ISP) [ISP-
HEADER01]
ATtiny2313@SOIC20 [(SA404)]
ATtiny2313@SOIC20(ISP) [ISP-HEADER01]
ATtiny2313V ATtiny2313V(ISP) [ISP-
HEADER01]
ATtiny2313V@SOIC20 [(SA404)]
ATtiny2313V@SOIC20(ISP) [ISP-HEADER01]

[(SA404)]
ATtiny26L(new)@SOIC20(ISP) [ISP-HEADER01]
ATtiny26L(new)@TSSOP20 [(SA026)]
ATtiny26L(new)@TSSOP20(ISP) [ISP-HEADER01]
ATtiny26L@QFN32 [(SA686)] ATtiny26L@SOIC20
[(SA404)]
ATtiny26L@SOIC20(ISP) [ISP-HEADER01]
ATtiny26L@TSSOP20 [(SA026)]
ATtiny26L@TSSOP20(ISP) [ISP-HEADER01]
ATtiny28L ATtiny28L@TQFP32
[(SA663)]
ATtiny28V ATtiny28V@TQFP32
[(SA663)]
ATtiny44 ATtiny44(ISP) [ISP-
HEADER01]
ATtiny44@QFN20 [(SA692)]
ATtiny44@QFN20(ISP) [ISP-HEADER01]
ATtiny44@SOIC14 [(SA602)]
ATtiny44@SOIC14(ISP) [ISP-HEADER01]
ATtiny45
ATtiny45(ISP)(12V) [ISP-HEADER01]
ATtiny45(ISP)(5V) [ISP-HEADER01] ATtiny45@QFN20
[(SA692)]
ATtiny45@QFN20(ISP)(12V) [ISP-HEADER01]
ATtiny45@QFN20(ISP)(5V) [ISP-HEADER01]
ATtiny45@SOIC8 [(S605)]
ATtiny45@SOIC8(ISP)(12V) [ISP-HEADER01]
ATtiny45@SOIC8(ISP)(5V) [ISP-HEADER01]
ATtiny461 ATtiny461@MLP32
[(SA686)]
ATtiny461@SOIC20 [(SA404)]
ATtiny461V ATtiny461V@SOIC20
ATtiny461V@MLP32 [(SA686)]
[(SA404)]
ATtiny84 ATtiny84(ISP) [ISP-
HEADER01]
ATtiny84@QFN20 [(SA692)]
ATtiny84@QFN20(ISP) [ISP-HEADER01]
ATtiny84@SOIC14 [(SA602)]
ATtiny84@SOIC14(ISP) [ISP-HEADER01]
ATtiny85
ATtiny85(ISP)(12V) [ISP-HEADER01]
ATtiny85(ISP)(5V) [ISP-HEADER01] ATtiny85@QFN20

[(SA692)]
ATtiny85@QFN20(ISP)(12V) [ISP-HEADER01]
ATtiny85@QFN20(ISP)(5V) [ISP-HEADER01]
ATtiny85@SOIC8 [(S605)]
ATtiny85@SOIC8(ISP)(12V) [ISP-HEADER01]
ATtiny85@SOIC8(ISP)(5V) [ISP-HEADER01]
ATtiny861 ATtiny861@MLP32
[(SA686)]
ATtiny861@SOIC20 [(SA404)]
ATtiny861V
ATtiny861V@MLP32 [(SA686)] ATtiny861V@SOIC20
[(SA404)]
T89F64 T89F64@PLCC44
[(SA244)]
T89F64@TQFP44 [(SA245A)]

ATMEL W&M

MICROCONTROLLER

AT89C5115@PLCC28 [(SA008A)] AT89C5115@SOIC28
[(SA404)]
AT89C5115@TQFP32 [(SA663)] AT89C51CC02@PLCC28
[(SA008A)]
AT89C51CC02@SOIC28 [(SA404)] AT89C51CC02@TQFP32
[(SA663)]
T89C5115@PLCC28 [(SA008A)] T89C5115@SOIC28
[(SA404)]
T89C5115@TQFP32 [(SA663)] T89C51AC2@PLCC44
[(SA244)]
T89C51AC2@TQFP44 [(SA245A)] T89C51CC01@PLCC44
[(SA244)]
T89C51CC01@TQFP44 [(SA245A)] T89C51CC02@PLCC28
[(SA008A)]
T89C51CC02@SOIC24 [(SA404)] T89C51CC02@SOIC28
[(SA404)]
T89C51CC02@TQFP32 [(SA663)] T89C51IB2@PLCC44
[(SA244)]
T89C51IB2@TQFP44 [(SA245A)] T89C51IC2@PLCC44
[(SA244)]
T89C51IC2@TQFP44 [(SA245A)]
T89C51RB2

T89C51RB2@PLCC44 [(SA244)]	T89C51RB2@TQFP44
[(SA245A)]	
T89C51RC2	T89C51RC2@PLCC44
[(SA244)]	
T89C51RC2@TQFP44 [(SA245A)]	
T89C51RD2	
T89C51RD2@PLCC44 [(SA244)]	T89C51RD2@TQFP44
[(SA245A)]	
T89F64	T89F64@PLCC44
[(SA244)]	
T89F64@TQFP44 [(SA245A)]	
TS87C51RB2	
TS87C51RB2@PLCC44 [(SA244)]	TS87C51RB2@TQFP44
[(SA245A)]	
TS87C51RC2	TS87C51RC2@PLCC44
[(SA244)]	
TS87C51RC2@TQFP44 [(SA245A)]	
TS87C51RD2	
TS87C51RD2@PLCC44 [(SA244)]	TS87C51RD2@TQFP44
[(SA245A)]	
TS87C51U2	TS87C51U2@PLCC44
[(SA244)]	
TS87C51U2@TQFP44 [(SA245A)]	
TS87C52X2	
TS87C52X2@PLCC44 [(SA244)]	TS87C52X2@TQFP44
[(SA245A)]	
TS87C54X2	TS87C54X2@PLCC44
[(SA244)]	
TS87C54X2@TQFP44 [(SA245A)]	
TS87C58X2	
TS87C58X2@PLCC44 [(SA244)]	TS87C58X2@TQFP44
[(SA245A)]	
TSC87251A1@PLCC44 [(SA244)]	
TSC87251G1	
TSC87251G1@PLCC44 [(SA244)]	
TSC87251G1A	
TSC87251G1A@PLCC44 [(SA244)]	
TSC87251G2D	
TSC87251G2D@PLCC44 [(SA244)]	TSC87251G2D@TQFP44
[(SA245A)]	
TSC87C51	TSC87C51@PLCC44
[(SA244)]	
TSC87C51@TQFP44 [(SA245A)]	

ATMEL-CUSTOMER

E (E) PROM / FRAM / NVRAM

AT24C01
AT24C02
AT24C04
AT24C08
AT24C16

AUSTIN

E (E) PROM / FRAM / NVRAM

AS8E512K8
[(SA661)]

AS8E512K8@SOJ32

BELLING-SYSTRON

MICROCONTROLLER

CM5001

BENCHMARK

E (E) PROM / FRAM / NVRAM

BQ4010
BQ4010Y
BQ4011
BQ4011Y
BQ4013
BQ4013Y
BQ4014
BQ4014Y
BQ4015

CATALYST

E (E) PROM/FRAM/NVRAM

CAT1021(L)	CAT1021
(P)	
CAT1021(R)@MSOP8 [(SA026)]	CAT1021(S)@SOIC8
[(SA602A)]	
CAT1021(U)@TSSOP8 [(SA026)]	CAT1021(V)@SOIC8
[(SA602A)]	
CAT1021(Y)@TSSOP8 [(SA026)]	CAT1021(Z)@MSOP8
[(SA026)]	
CAT1022(L)	CAT1022
(P)	
CAT1022(R)@MSOP8 [(SA026)]	CAT1022(S)@SOIC8
[(SA602A)]	
CAT1022(U)@TSSOP8 [(SA026)]	CAT1022(V)@SOIC8
[(SA602A)]	
CAT1022(Y)@TSSOP8 [(SA026)]	CAT1022(Z)@MSOP8
[(SA026)]	
CAT1023(L)	CAT1023
(P)	
CAT1023(R)@MSOP8 [(SA026)]	CAT1023(S)@SOIC8
[(SA602A)]	
CAT1023(U)@TSSOP8 [(SA026)]	CAT1023(V)@SOIC8
[(SA602A)]	
CAT1023(Y)@TSSOP8 [(SA026)]	CAT1023(Z)@MSOP8
[(SA026)]	
CAT1024(L)	CAT1024
(P)	
CAT1024(R)@MSOP8 [(SA026)]	CAT1024(S)@SOIC8
[(SA602A)]	
CAT1024(U)@TSSOP8 [(SA026)]	CAT1024(V)@SOIC8
[(SA602A)]	
CAT1024(Y)@TSSOP8 [(SA026)]	CAT1024(Z)@MSOP8
[(SA026)]	
CAT1025(L)	CAT1025
(P)	
CAT1025(R)@MSOP8 [(SA026)]	CAT1025(S)@SOIC8
[(SA602A)]	
CAT1025(U)@TSSOP8 [(SA026)]	CAT1025(V)@SOIC8

[(SA602A)]	
CAT1025(Y)@TSSOP8 [(SA026)]	CAT1025(Z)@MSOP8
[(SA026)]	
CAT1026(L)	CAT1026
(P)	
CAT1026(R)@MSOP8 [(SA026)]	CAT1026(S)@SOIC8
[(SA602A)]	
CAT1026(U)@TSSOP8 [(SA026)]	CAT1026(V)@SOIC8
[(SA602A)]	
CAT1026(Y)@TSSOP8 [(SA026)]	CAT1026(Z)@MSOP8
[(SA026)]	
CAT1027(L)	CAT1027
(P)	
CAT1027(R)@MSOP8 [(SA026)]	CAT1027(S)@SOIC8
[(SA602A)]	
CAT1027(U)@TSSOP8 [(SA026)]	CAT1027(V)@SOIC8
[(SA602A)]	
CAT1027(Y)@TSSOP8 [(SA026)]	CAT1027(Z)@MSOP8
[(SA026)]	
CAT1161(J)@SOIC8 [(SA602A)]	CAT1161
(P)	
CAT1162(J)@SOIC8 [(SA602A)]	CAT1162
(P)	
CAT1163(J)@SOIC8 [(SA602A)]	CAT1163
(P)	
CAT2210	CAT2210@SOIC16
[(SA404)]	
CAT2210I	CAT2210I@SOIC16
[(SA404)]	
CAT2212	CAT2212@SOIC20
[(SA404)]	
CAT2212I	CAT2212I@SOIC20
[(SA404)]	
CAT22C10	CAT22C10@SOIC16
[(SA404)]	
CAT22C10I	CAT22C10I@SOIC16
[(SA404)]	
CAT22C12	CAT22C12@SOIC20
[(SA404)]	
CAT22C12I	CAT22C12I@SOIC20
[(SA404)]	
CAT24AC128	CAT24AC128@SOIC8
[(SA602A)]	

CAT24AC128@TSSOP14 [(SA026)]	
CAT24C00	
CAT24C00@SOIC8 [(SA602A)]	CAT24C00@TSSOP8
[(SA026)]	
CAT24C01	CAT24C01@SOIC14
[(SA602)]	
CAT24C01@SOIC8 [(SA602A)]	CAT24C01@TSSOP8
[(SA026)]	
CAT24C01B(J)@SOIC8 [(SA602A)]	CAT24C01B
(L)	
CAT24C01B(P)	CAT24C01B(R)@MSOP8
[(SA026)]	
CAT24C01B(U)@TSSOP8 [(SA026)]	CAT24C01B(W)@SOIC8
[(SA602A)]	
CAT24C01B(Y)@TSSOP8 [(SA026)]	CAT24C01B(Z)@MSOP8
[(SA026)]	
CAT24C02	CAT24C02@SOIC14
[(SA602)]	
CAT24C02@SOIC8 [(SA602A)]	CAT24C02@TSSOP8
[(SA026)]	
CAT24C021	
CAT24C022	
CAT24C023	
CAT24C03	
CAT24C03@SOIC8 [(SA602A)]	CAT24C03@TSSOP8
[(SA026)]	
CAT24C04	CAT24C04@SOIC14
[(SA602)]	
CAT24C04@SOIC8 [(SA602A)]	CAT24C04@TSSOP8
[(SA026)]	
CAT24C041	
CAT24C042	
CAT24C043	
CAT24C05	
CAT24C05@SOIC8 [(SA602A)]	CAT24C05@TSSOP8
[(SA026)]	
CAT24C08	CAT24C08@SOIC14
[(SA602)]	
CAT24C08@SOIC8 [(SA602A)]	CAT24C08@TSSOP8
[(SA026)]	
CAT24C081	
CAT24C082	
CAT24C083	

CAT24C08I
CAT24C08I@SOIC8 [(SA602A)]
CAT24C09
CAT24C09@SOIC8 [(SA602A)] CAT24C09@TSSOP8
[(SA026)]
CAT24C128 CAT24C128@SOIC8
[(SA602A)]
CAT24C16 CAT24C16@SOIC14
[(SA602)]
CAT24C16@SOIC8 [(SA602A)] CAT24C16@TSSOP8
[(SA026)]
CAT24C161
CAT24C162
CAT24C163
CAT24C164
CAT24C164@SOIC8 [(SA602A)] CAT24C164@TSSOP8
[(SA026)]
CAT24C16I CAT24C16I@SOIC8
[(SA602A)]
CAT24C208(J)@SOIC8 [(SA602A)] CAT24C208
(L)
CAT24C208(P) CAT24C208(R)@MSOP8
[(SA666)]
CAT24C208(U)@TSSOP8 [(SA026)] CAT24C208(W)@SOIC8
[(SA602A)]
CAT24C208(Y)@TSSOP8 [(SA026)] CAT24C208(Z)@MSOP8
[(SA666)]
CAT24C21 CAT24C21@SOIC8
[(SA602A)]
CAT24C21@TSSOP8 [(SA026)]
CAT24C256
CAT24C256@SOIC8 [(SA602A)] CAT24C256@TDFN8
[(SA683)]
CAT24C256@TSSOP8 [(SA026)]
CAT24C32
CAT24C32@SOIC8 [(SA602A)]
CAT24C44
CAT24C44@SOIC8 [(SA602A)]
CAT24C64
CAT24C64@SOIC8 [(SA602A)]
CAT24F32
CAT24F32@SOIC8 [(SA602A)] CAT24F32@TSSOP8
[(SA026)]

CAT24F32A	CAT24F32A@SOIC8
[(SA602A)]	
CAT24F32A@TSSOP8 [(SA026)]	
CAT24FC01	
CAT24FC01@SOIC14 [(SA602)]	CAT24FC01@SOIC8
[(SA602A)]	
CAT24FC01@TSSOP8 [(SA026)]	
CAT24FC02	
CAT24FC02@SOIC14 [(SA602)]	CAT24FC02@SOIC8
[(SA602A)]	
CAT24FC02@TSSOP8 [(SA026)]	
CAT24FC16	
CAT24FC16@SOIC14 [(SA602)]	CAT24FC16@SOIC8
[(SA602A)]	
CAT24FC16@TSSOP8 [(SA026)]	
CAT24FC17	
CAT24FC17@SOIC8 [(SA602A)]	CAT24FC17@TSSOP8
[(SA026)]	
CAT24FC256	CAT24FC256@SOIC8
[(SA602A)]	
CAT24FC256@TDFN8 [(SA683)]	CAT24FC256@TSSOP8
[(SA026)]	
CAT24FC32	CAT24FC32@SOIC8
[(SA602A)]	
CAT24FC32@TDFN8 [(SA683)]	CAT24FC32@TSSOP8
[(SA026)]	
CAT24FC64	CAT24FC64@SOIC8
[(SA602A)]	
CAT24FC64@TDFN8 [(SA683)]	CAT24FC64@TSSOP8
[(SA026)]	
CAT24FC65	CAT24FC65@SOIC8
[(SA602A)]	
CAT24FC65@TDFN8 [(SA683)]	CAT24FC65@TSSOP8
[(SA026)]	
CAT24FC66	CAT24FC66@SOIC8
[(SA602A)]	
CAT24FC66@TDFN8 [(SA683)]	CAT24FC66@TSSOP8
[(SA026)]	
CAT24LC02	CAT24LC02@SOIC8
[(SA602A)]	
CAT24LC02@TSSOP8 [(SA026)]	
CAT24WC01	
CAT24WC01@SOIC8 [(SA602A)]	CAT24WC01@TSSOP8

[(SA026)]	
CAT24WC02	CAT24WC02@SOIC8
[(SA602A)]	
CAT24WC02@TSSOP8 [(SA026)]	
CAT24WC03	
CAT24WC03@SOIC8 [(SA602A)]	CAT24WC03@TSSOP8
[(SA026)]	
CAT24WC04	CAT24WC04@SOIC8
[(SA602A)]	
CAT24WC04@TSSOP8 [(SA026)]	
CAT24WC05	
CAT24WC05@SOIC8 [(SA602A)]	CAT24WC05@TSSOP8
[(SA026)]	
CAT24WC08	CAT24WC08@SOIC8
[(SA602A)]	
CAT24WC08@TSSOP8 [(SA026)]	
CAT24WC09	
CAT24WC09@SOIC8 [(SA602A)]	CAT24WC09@TSSOP8
[(SA026)]	
CAT24WC128	CAT24WC128@SOIC8
[(SA602A)]	
CAT24WC129	CAT24WC129@SOIC8
[(SA602A)]	
CAT24WC16	CAT24WC16@SOIC8
[(SA602A)]	
CAT24WC16@TSSOP8 [(SA026)]	
CAT24WC164	
CAT24WC164@SOIC8 [(SA602A)]	CAT24WC164@TSSOP8
[(SA026)]	
CAT24WC17	CAT24WC17@SOIC8
[(SA602A)]	
CAT24WC17@TSSOP8 [(SA026)]	
CAT24WC256	
CAT24WC256@SOIC8 [(SA602A)]	CAT24WC256@TDFN8
[(SA683)]	
CAT24WC256@TSSOP8 [(SA026)]	
CAT24WC257	
CAT24WC257@SOIC8 [(SA605A)]	
CAT24WC32	
CAT24WC32@SOIC8 [(SA602A)]	
CAT24WC33	
CAT24WC33@SOIC8 [(SA602A)]	
CAT24WC64	

CAT24WC64@SOIC8 [(SA602A)]	
CAT24WC65	
CAT24WC65@SOIC8 [(SA602A)]	
CAT24WC66	
CAT24WC66@SOIC8 [(SA602A)]	
CAT25010	
CAT25010(S)@SOIC8 [(SA605A)]	CAT25010(U)@TSSOP8
[(SA602A)]	
CAT25020	CAT25020(S)@SOIC8
[(SA605A)]	
CAT25020(U)@TSSOP8 [(SA602A)]	
CAT25040	
CAT25040(S)@SOIC8 [(SA605A)]	CAT25040(U)@TSSOP8
[(SA602A)]	
CAT25080	CAT25080@SOIC8
[(SA602A)]	
CAT25080@TDFN8 [(SA724)]	CAT25080@TSSOP8
[(SA026)]	
CAT25080@UDFN8 [(BBBB)]	
CAT25128	
CAT25128@SOIC8 [(SA602A)]	CAT25128@TDFN8
[(SA724)]	
CAT25128@TSSOP8 [(SA026)]	
CAT25160	
CAT25160@SOIC8 [(SA602A)]	CAT25160@TDFN8
[(SA724)]	
CAT25160@TSSOP8 [(SA026)]	CAT25160@UDFN8
[(BBBB)]	
CAT25256	CAT25256@SOIC8
[(SA602A)]	
CAT25256@TDFN8 [(SA602A)]	CAT25256@TSSOP8
[(SA026)]	
CAT25320	CAT25320@SOIC8
[(SA602A)]	
CAT25320@TDFN8 [(SA724)]	CAT25320@TSSOP8
[(SA026)]	
CAT25640	CAT25640@SOIC8
[(SA602A)]	
CAT25640@TDFN8 [(SA724)]	CAT25640@TSSOP8
[(SA026)]	
CAT25C01	CAT25C01@SOIC16
[(SA602)]	
CAT25C01@SOIC8 [(SA602A)]	CAT25C01@TSSOP14

[(SA026)]	
CAT25C01@TSSOP8 [(SA026)]	
CAT25C02	
CAT25C02@SOIC16 [(SA602)]	CAT25C02@SOIC8
[(SA602A)]	
CAT25C02@TSSOP14 [(SA026)]	CAT25C02@TSSOP8
[(SA026)]	
CAT25C03	CAT25C03@SOIC8
[(SA602A)]	
CAT25C03@TSSOP14 [(SA026)]	CAT25C03@TSSOP8
[(SA026)]	
CAT25C04	CAT25C04@SOIC16
[(SA602)]	
CAT25C04@SOIC8 [(SA602A)]	CAT25C04@TSSOP14
[(SA026)]	
CAT25C04@TSSOP8 [(SA026)]	
CAT25C05	
CAT25C05@SOIC8 [(SA602A)]	CAT25C05@TSSOP14
[(SA026)]	
CAT25C05@TSSOP8 [(SA026)]	
CAT25C08	
CAT25C08@SOIC16 [(SA602)]	CAT25C08@SOIC8
[(SA602A)]	
CAT25C08@TSSOP14 [(SA026)]	CAT25C08@TSSOP8
[(SA026)]	
CAT25C09	CAT25C09@SOIC8
[(SA602A)]	
CAT25C09@TSSOP14 [(SA026)]	CAT25C09@TSSOP8
[(SA026)]	
CAT25C11	CAT25C11@SOIC8
[(SA602A)]	
CAT25C11@TSSOP14 [(SA026)]	CAT25C11@TSSOP8
[(SA026)]	
CAT25C128	CAT25C128@SOIC16
[(SA602)]	
CAT25C128@SOIC8 [(SA602A)]	CAT25C128@TSSOP14
[(SA026)]	
CAT25C128@TSSOP20 [(SA026)]	
CAT25C16	
CAT25C16@SOIC16 [(SA602)]	CAT25C16@SOIC8
[(SA602A)]	
CAT25C16@TSSOP14 [(SA026)]	CAT25C16@TSSOP8
[(SA026)]	

CAT25C17	CAT25C17@SOIC8
[(SA602A)]	
CAT25C17@TSSOP14 [(SA026)]	CAT25C17@TSSOP8
[(SA026)]	
CAT25C256	CAT25C256@SOIC16
[(SA602)]	
CAT25C256@SOIC8 [(SA602A)]	CAT25C256@TSSOP14
[(SA026)]	
CAT25C256@TSSOP20 [(SA026)]	
CAT25C32	
CAT25C32@SOIC8 [(SA602A)]	CAT25C32@TSSOP14
[(SA026)]	
CAT25C32@TSSOP20 [(SA026)]	
CAT25C33	
CAT25C33@SOIC8 [(SA602A)]	CAT25C33@TSSOP14
[(SA026)]	
CAT25C64	CAT25C64@SOIC8
[(SA602A)]	
CAT25C64@TSSOP14 [(SA026)]	CAT25C64@TSSOP20
[(SA026)]	
CAT25C65	CAT25C65@SOIC8
[(SA602A)]	
CAT25C65@TSSOP14 [(SA026)]	
CAT27010	
CAT27010@PLCC32 [(SA015A1T)]	CAT27010@TSOP32
[(SA410T)]	
CAT27128A	
CAT27256	
CAT27512	CAT27512@PLCC32
[(SA015A1T)]	
CAT2764A	
CAT27C16A	
CAT27C210	CAT27C210@PLCC44
[(SA244)]	
CAT27HC256	CAT27HC256@PLCC32
[(SA015A1T)]	
CAT27HC256I	CAT27HC256I@PLCC32
[(SA015A1T)]	
CAT28C16A	CAT28C16A@PLCC32
[(SA015A1T)]	
CAT28C16A@SOIC24 [(SA404)]	
CAT28C16AI	
CAT28C16AI@PLCC32 [(SA015A1T)]	CAT28C16AI@SOIC24

[(SA404)]	
CAT28C17A	CAT28C17A@PLCC32
[(SA015A1T)]	
CAT28C17AI	CAT28C17AI@PLCC32
[(SA015A1T)]	
CAT28C256	CAT28C256@PLCC32
[(SA015A1T)]	
CAT28C256@TSOP28 [(SA430T)]	
CAT28C256I	
CAT28C256I@PLCC32 [(SA015A1T)]	CAT28C256I@TSOP28
[(SA430T)]	
CAT28C257	CAT28C257@PLCC32
[(SA015A1T)]	
CAT28C257@TSOP28 [(SA430T)]	
CAT28C512	
CAT28C512@PLCC32 [(SA015A1T)]	CAT28C512@TSOP32
[(SA410T)]	
CAT28C512@TSOP40 [(SA409T)]	CAT28C513@PLCC32
[(SA015A1T)]	
CAT28C64A	CAT28C64A@PLCC32
[(SA015A1T)]	
CAT28C64A@SOIC28 [(SA404)]	
CAT28C64AI	
CAT28C64AI@PLCC32 [(SA015A1T)]	CAT28C64AI@SOIC28
[(SA404)]	
CAT28C64B	CAT28C64B@PLCC32
[(SA015A1T)]	
CAT28C64B@TSOP28 [(SA430T)]	
CAT28C64BI	
CAT28C64BI@PLCC32 [(SA015A1T)]	CAT28C64BI@TSOP28
[(SA430T)]	
CAT28C65B	CAT28C65B@PLCC32
[(SA015A1T)]	
CAT28C65B@TSOP28 [(SA430T)]	
CAT28C65BI	
CAT28C65BI@PLCC32 [(SA015A1T)]	CAT28C65BI@TSOP28
[(SA430T)]	
CAT28F001N-B@PLCC32 [(SA015A1T)]	CAT28F001N-T@PLCC32
[(SA015A1T)]	
CAT28F001P-B	CAT28F001P-
T	
CAT28F001T-B@TSOP32 [(SA410T)]	CAT28F001T-T@TSOP32
[(SA410T)]	

CAT28F002	CAT28F002@TSOP40
[(SA409T)]	
CAT28F010	CAT28F010@PLCC32
[(SA015A1T)]	
CAT28F010@TSOP32	[(SA410T)]
CAT28F010I	
CAT28F010I@PLCC32	CAT28F010I@TSOP32
[(SA410T)]	
CAT28F020	CAT28F020@PLCC32
[(SA015A1T)]	
CAT28F020@TSOP32	[(SA410T)]
CAT28F020I	
CAT28F020I@PLCC32	CAT28F020I@TSOP32
[(SA410T)]	
CAT28F102	CAT28F102@PLCC44
[(SA244)]	
CAT28F102@TSOP40	[(SA409T)]
CAT28F512	
CAT28F512@PLCC32	CAT28F512@TSOP32
[(SA410T)]	
CAT28F512I	CAT28F512I@PLCC32
[(SA015A1T)]	
CAT28F512I@TSOP32	[(SA410T)]
CAT28LV256	
CAT28LV256@PLCC32	CAT28LV256@TSOP28
[(SA430T)]	
CAT28LV64	CAT28LV64@PLCC32
[(SA015A1T)]	
CAT28LV64@TSOP28	[(SA430T)]
CAT28LV65	
CAT28LV65@PLCC32	CAT28LV65@TSOP28
[(SA430T)]	
CAT33C101(08bit)	
CAT33C101(08bit)@SOIC8	[(SA602A)]
CAT33C101(16bit)	
CAT33C101(16bit)@SOIC8	[(SA602A)]
CAT33C101H(08bit)	
CAT33C101H(08bit)@SOIC8	[(SA602A)]
CAT33C101H(16bit)	
CAT33C101H(16bit)@SOIC8	[(SA602A)]
CAT33C101I(08bit)	
CAT33C101I(08bit)@SOIC8	[(SA602A)]
CAT33C101I(16bit)	

CAT33C101I(16bit)@SOIC8 [(SA602A)]	
CAT33C104(08bit)	
CAT33C104(08bit)@SOIC8 [(SA602A)]	
CAT33C104(16bit)	
CAT33C104(16bit)@SOIC8 [(SA602A)]	
CAT33C104I(08bit)	
CAT33C104I(08bit)@SOIC8 [(SA602A)]	
CAT33C104I(16bit)	
CAT33C104I(16bit)@SOIC8 [(SA602A)]	
CAT34AC02	CAT34AC02@SOIC8
[(SA602A)]	
CAT34AC02@TSSOP8 [(SA026)]	
CAT34C02	
CAT34C02@SOIC8 [(SA602A)]	CAT34C02@TDFN8
[(SA694)]	
CAT34C02@TSSOP8 [(SA026)]	
CAT34FC02	
CAT34FC02@SOIC8 [(SA602A)]	CAT34FC02@TDFN8
[(SA694)]	
CAT34FC02@TSSOP8 [(SA026)]	
CAT34RC02	
CAT34RC02@SOIC8 [(SA602A)]	CAT34RC02@TDFN8
[(SA694)]	
CAT34RC02@TSSOP8 [(SA026)]	
CAT34WC02	
CAT34WC02@SOIC8 [(SA602A)]	CAT34WC02@TDFN8
[(SA694)]	
CAT34WC02@TSSOP8 [(SA026)]	
CAT35C102	
CAT35C102H	
CAT35C102I	
CAT35C104(08bit)	
CAT35C104(08bit)@SOIC8 [(SA602A)]	
CAT35C104(16bit)	
CAT35C104(16bit)@SOIC8 [(SA602A)]	
CAT35C104H(08bit)	
CAT35C104H(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(08bit)	
CAT35C104I(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(16bit)	
CAT35C104I(16bit)@SOIC8 [(SA602A)]	
CAT59C11	CAT59C11@SOIC8
[(SA602A)]	

CAT59C11A [(SA602A)]	CAT59C11A@SOIC8
CAT59C11H [(SA602A)]	CAT59C11H@SOIC8
CAT59C11I [(SA602A)]	CAT59C11I@SOIC8
CAT64LC10(J)@SOIC8 [(SA602A)] (P)	CAT64LC10
CAT64LC10(S)@SOIC8 [(SA602A)] [(SA026)]	CAT64LC10(U)@TSSOP8
CAT64LC10(UR)@TSSOP8 [(SA026)] [(SA602A)]	CAT64LC20(J)@SOIC8
CAT64LC20(P) [(SA602A)]	CAT64LC20(S)@SOIC8
CAT64LC20(U)@TSSOP8 [(SA026)] [(SA026)]	CAT64LC20(UR)@TSSOP8
CAT64LC40(J)@SOIC8 [(SA602A)] (P)	CAT64LC40
CAT64LC40(S)@SOIC8 [(SA602A)] [(SA026)]	CAT64LC40(U)@TSSOP8
CAT64LC40(UR)@TSSOP8 [(SA026)] (08bit)	CAT93C46
CAT93C46(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C46(16bit)	
CAT93C46(16bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(16bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(U)@TSSOP8 [(SA026)]	
CAT93C46A (08bit)	CAT93C56
CAT93C56(08bit)@SOIC8 [(SA602A)] (16bit)	CAT93C56
CAT93C56(16bit)@SOIC8 [(SA602A)]	
CAT93C56A	
CAT93C57 (08bit)	CAT93C66
CAT93C66(08bit)@SOIC8 [(SA602A)] [(SA026)]	CAT93C66(08bit)@TSSOP8
CAT93C66(16bit) [(SA602A)]	CAT93C66(16bit)@SOIC8

CAT93C66(16bit)@TSSOP8 [(SA026)]
CAT93C66A
CAT93C76(08bit)
CAT93C76(08bit)(J)@SOIC8 [(SA602A)]
CAT93C76(08bit)(K)@SOIC8 [(SA605A)]
CAT93C76(08bit)(S)@SOIC8 [(SA602A)]
CAT93C76(08bit)(U)@TSSOP8 [(SA026)]
CAT93C76(16bit)
CAT93C76(16bit)(J)@SOIC8 [(SA602A)]
CAT93C76(16bit)(K)@SOIC8 [(SA605A)]
CAT93C76(16bit)(S)@SOIC8 [(SA602A)]
CAT93C76(16bit)(U)@TSSOP8 [(SA026)]
CAT93C86(08bit)
CAT93C86(08bit)(J)@SOIC8 [(SA602A)]
CAT93C86(08bit)(K)@SOIC8 [(SA605A)]
CAT93C86(08bit)(S)@SOIC8 [(SA602A)]
CAT93C86(08bit)(U)@TSSOP8 [(SA026)]
CAT93C86(16bit)
CAT93C86(16bit)(J)@SOIC8 [(SA602A)]
CAT93C86(16bit)(K)@SOIC8 [(SA605A)]
CAT93C86(16bit)(S)@SOIC8 [(SA602A)]
CAT93C86(16bit)(U)@TSSOP8 [(SA026)]
CAT93H46(08bit)
CAT93H46(08bit)(J)@SOIC8 [(SA602A)]
CAT93H46(08bit)(K)@SOIC8 [(SA605A)]
CAT93H46(08bit)(S)@SOIC8 [(SA602A)]
CAT93H46(08bit)(U)@TSSOP8 [(SA026)]
CAT93H46(16bit)
CAT93H46(16bit)(J)@SOIC8 [(SA602A)]
CAT93H46(16bit)(K)@SOIC8 [(SA605A)]
CAT93H46(16bit)(S)@SOIC8 [(SA602A)]
CAT93H46(16bit)(U)@TSSOP8 [(SA026)]
CAT93HC46(08bit)
CAT93HC46(08bit)(J)@SOIC8 [(SA602A)]
CAT93HC46(08bit)(K)@SOIC8 [(SA605A)]
CAT93HC46(08bit)(S)@SOIC8 [(SA602A)]
CAT93HC46(08bit)(U)@TSSOP8 [(SA026)]
CAT93HC46(16bit)
CAT93HC46(16bit)(J)@SOIC8 [(SA602A)]
CAT93HC46(16bit)(K)@SOIC8 [(SA605A)]
CAT93HC46(16bit)(S)@SOIC8 [(SA602A)]
CAT93HC46(16bit)(U)@TSSOP8 [(SA026)]

DRAM & SRAM

CAT71C256

[(SA643)]

CAT71C256L

[(SA643)]

CAT71C256@TSOP28

CAT71C256L@TSOP28

CERAMATE

E (E) PROM / FRAM / NVRAM

24LC02

[(SA602A)]

24LC02@TSSOP8 [(SA026)]

24LC08

24LC08@SOIC8 [(SA602A)]

[(SA026)]

24LC16

[(SA602A)]

24LC16@TSSOP8 [(SA026)]

24LLC02

24LLC02@SOIC8 [(SA602A)]

[(SA026)]

24LLC08

[(SA602A)]

24LLC08@TSSOP8 [(SA026)]

93LC46

93LC46@SOIC8 [(SA602A)]

93LC46R

93LC46R@SOIC8 [(SA602A)]

93LC56

93LC56@SOIC8 [(SA602A)]

93LC66

93LC66@SOIC8 [(SA602A)]

24LC02@SOIC8

24LC08@TSSOP8

24LC16@SOIC8

24LLC02@TSSOP8

24LLC08@SOIC8

CHINA CORE

MICROCONTROLLER

CCM89C51

CCM89C51@PLCC44

[(SA244)]
CCM89C51@TQFP44 [(SA245A)]
CCM89C52
CCM89C52@PLCC44 [(SA244)] CCM89C52@TQFP44
[(SA245A)]

CHINGIS

E (E) PROM / FRAM / NVRAM

PM24C64 [(SA602A)]	PM24C64@SOIC8
PM24C64@TSOP8 [(SA026)] [(SA023A)]	PM25LV010 (B) @SOIC8
PM25LV010 (Q) @WSON8 [(SA683)] [(SA602A)]	PM25LV010 (S) @SOIC8
PM25LV010A@SOIC8 [(SA602A)] [(SA683)]	PM25LV010A@WSON8
PM25LV016@SOIC8 [(SA605A)] [(SA683)]	PM25LV016@WSON8
PM25LV016A@SOIC8 [(SA605A)] [(SA683)]	PM25LV016A@WSON8
PM25LV020 (B) @SOIC8 [(SA023A)] [(SA683)]	PM25LV020 (Q) @WSON8
PM25LV020 (S) @SOIC8 [(SA602A)] [(SA023A)]	PM25LV040 (B) @SOIC8
PM25LV040 (Q) @WSON8 [(SA683)] [(SA602A)]	PM25LV040 (S) @SOIC8
PM25LV080@SOIC8 [(SA605A)] [(SA683)]	PM25LV080@WSON8
PM25LV080A@SOIC8 [(SA605A)] [(SA683)]	PM25LV080A@WSON8
PM25LV512 (B) @SOIC8 [(SA023A)] [(SA683)]	PM25LV512 (Q) @WSON8
PM25LV512 (S) @SOIC8 [(SA602A)]	
PM29F002B	
PM29F002B@PLCC32 [(SA015A1T)]	
PM29F002T	
PM29F002T@PLCC32 [(SA015A1T)]	
PM29F004B	
PM29F004B@PLCC32 [(SA015A1T)]	
PM29F004T	

PM29F004T@PLCC32 [(SA015A1T)]
PM29LV002B
PM29LV002B@PLCC32 [(SA015A1T)] PM29LV002B@VSOP32
[(SA620)]
PM29LV002T PM29LV002T@PLCC32
[(SA015A1T)]
PM29LV002T@VSOP32 [(SA620)] PM29LV004B@PLCC32
[(SA015A1T)]
PM29LV004B@VSOP32 [(SA620)] PM29LV004T@PLCC32
[(SA015A1T)]
PM29LV004T@VSOP32 [(SA620)] PM29LV104RB@PLCC32
[(SA015A1T)]
PM29LV104RB@VSOP32 [(SA620)] PM29LV104RT@PLCC32
[(SA015A1T)]
PM29LV104RT@VSOP32 [(SA620)]
PM37LV512
PM37LV512@PLCC32 [(SA015A1T)] PM37LV512@VSOP32
[(SA620)]
PM39F010 PM39F010@PLCC32
[(SA015A1T)]
PM39F010@VSOP32 [(SA620)]
PM39F020
PM39F020@PLCC32 [(SA015A1T)] PM39F020@VSOP32
[(SA620)]
PM39F040 PM39F040@PLCC32
[(SA015A1T)]
PM39F040@VSOP32 [(SA620)] PM39LV010@PLCC32
[(SA015A1T)]
PM39LV010@VSOP32 [(SA620)] PM39LV010R@PLCC32
[(SA015A1T)]
PM39LV010R@VSOP32 [(SA620)] PM39LV020@PLCC32
[(SA015A1T)]
PM39LV020@VSOP32 [(SA620)] PM39LV040@PLCC32
[(SA015A1T)]
PM39LV040@VSOP32 [(SA620)] PM39LV512@PLCC32
[(SA015A1T)]
PM39LV512@VSOP32 [(SA620)] PM39LV512R@PLCC32
[(SA015A1T)]
PM39LV512R@VSOP32 [(SA620)] PM49FL002T@PLCC32
[(SA015A1T)]
PM49FL002T@VSOP32 [(SA620)]
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]
PM49FL004T(Low)@VSOP32 [(SA620-B005)]

PM49FL004T@PLCC32 [(SA015A1T)]
[(SA620)]
PM49FL008T@PLCC32 [(SA015A1T)]
[(SA620)]
PM49LP002T@PLCC32 [(SA015A1T)]
[(SA620)]

PM49FL004T@VSOP32
PM49FL008T@VSOP32
PM49LP002T@VSOP32

CHIPCON

MICROCONTROLLER

CC1010@TQFP64 (ISP) [ISP-HEADER01]

CHIPSWINNER

E (E) PROM / FRAM / NVRAM

CW24C02
[(SA602A)]
CW24C04
[(SA602A)]
CW24C08
[(SA602A)]
CW24C16
[(SA602A)]
CW24C32
[(SA602A)]
CW24C64
[(SA602A)]

CW24C02@SOIC8
CW24C04@SOIC8
CW24C08@SOIC8
CW24C16@SOIC8
CW24C32@SOIC8
CW24C64@SOIC8

MICROCONTROLLER

CW88CS028@SDIP28 [(SA653)]
[(SA653)]
CW88CS128@SDIP28 [(SA653)]
[(SA653)]
CW89F1050
CW89F2050
CW89F4050@SDIP28 [(SA653)]

CW88CS032@SDIP32
CW88CS132@SDIP32
CW89F4050@SOP28

[(SA404)]
CW89F52
[(SA675)]
CW89F54
[(SA675)]

CW89F52@LQFP44

CW89F54@LQFP44

CORERIVER

E (E) PROM / FRAM / NVRAM

CR24C02LI
[(SA602)]
CR24C08LI
[(SA602)]
CR24C16LI
[(SA602)]
CR24C256LI
[(SA602)]
CR24C32LI
[(SA602)]
CR24C64LI
[(SA602)]

CR24C02WI@SOIC8

CR24C08WI@SOIC8

CR24C16WI@SOIC8

CR24C256WI@SOIC8

CR24C32WI@SOIC8

CR24C64WI@SOIC8

CWI

E (E) PROM / FRAM / NVRAM

39LV040@VSOP32 [(SA620)]

CYGNAL

MICROCONTROLLER

C8051F000@TQFP64 (ISP) [(PEP+S616)]
C8051F001@TQFP48 (ISP) [(SA248)]
[(SA663)]
C8051F005@TQFP64 (ISP) [(PEP+S616)]
C8051F006@TQFP48 (ISP) [(SA248)]
[(SA663)]

C8051F002@TQFP32 (ISP)

C8051F007@TQFP32 (ISP)

C8051F010@TQFP64(ISP) [(PEP+S616)]
C8051F011@TQFP48(ISP) [(SA248)] C8051F012@TQFP32(ISP)
[(SA663)]
C8051F015@TQFP64(ISP) [(PEP+S616)]
C8051F016@TQFP48(ISP) [(SA248)] C8051F017@TQFP32(ISP)
[(SA663)]
C8051F018@TQFP64(ISP) [(PEP+S616)]
C8051F019@TQFP48(ISP) [(SA248)]
C8051F020@TQFP100(ISP) [ISP-HEADER01]
C8051F021@TQFP64(ISP) [ISP-HEADER01]
C8051F022@TQFP100(ISP) [ISP-HEADER01]
C8051F023@TQFP64(ISP) [ISP-HEADER01]
C8051F040@TQFP100(ISP) [ISP-HEADER01]
C8051F041@TQFP64(ISP) [ISP-HEADER01]
C8051F042@TQFP100(ISP) [ISP-HEADER01]
C8051F043@TQFP64(ISP) [ISP-HEADER01]
C8051F044@TQFP100(ISP) [ISP-HEADER01]
C8051F045@TQFP64(ISP) [ISP-HEADER01]
C8051F046@TQFP100(ISP) [ISP-HEADER01]
C8051F047@TQFP64(ISP) [ISP-HEADER01]
C8051F206@TQFP48 [(SA248)] C8051F220@TQFP48
[(SA248)]
C8051F221@TQFP32 [(SA663)] C8051F226@TQFP48
[(SA248)]
C8051F230@TQFP48 [(SA248)] C8051F231@TQFP32
[(SA663)]
C8051F236@TQFP48 [(SA248)] C8051F300
[(SA695A)]
C8051F301 [(SA695A)] C8051F302
[(SA695A)]
C8051F303 [(SA695A)] C8051F304
[(SA695A)]
C8051F305 [(SA695A)] C8051F310@TQFP32
[(SA663)]
C8051F310-GQ@TQFP32 [(SA663)] C8051F311@QFN28 [(SA697-
B006)]
C8051F311-GM@QFN28 [(SA697-B006)]
C8051F312@TQFP32 [(SA663)] C8051F312-GQ@TQFP32
[(SA663)]
C8051F313@QFN28 [(SA697-B006)]
C8051F313-GM@QFN28 [(SA697-B006)]
C8051F314@TQFP32 [(SA663)] C8051F314-GQ@TQFP32
[(SA663)]

C8051F315@QFN28 [(SA697-B006)]
C8051F315-GM@QFN28 [(SA697-B006)]
C8051F316-GM@QFN24 [(SA710-B006)]
C8051F317-GM@QFN24 [(SA710-B006)]
C8051F320@TQFP32 [(SA663)] C8051F321@QFN28 [(SA697-B006)]
C8051F326@QFN28 [(SA697-B006)]
C8051F326-GQ@QFN28 [(SA697-B006)]
C8051F327@QFN28 [(SA697-B006)]
C8051F327-GQ@QFN28 [(SA697-B006)]
C8051F330@MLP20 [(SA692)]
C8051F330D
C8051F331@MLP20 [(SA692)] C8051F332-GM@MLP20
[(SA692)]
C8051F333-GM@MLP20 [(SA692)] C8051F334-GM@MLP20
[(SA692)]
C8051F335-GM@MLP20 [(SA692)] C8051F336-GM@QFN20
[(SA692)]
C8051F337-GM@QFN20 [(SA692)] C8051F338-GM@QFN24
[(SA710)]
C8051F339-GM@QFN24 [(SA710)] C8051F340-GQ@TQFP48
[(SA248)]
C8051F341-GQ@TQFP48 [(SA248)] C8051F342-GQ@LQFP32
[(SA663)]
C8051F343-GQ@LQFP32 [(SA663)] C8051F344-GQ@TQFP48
[(SA248)]
C8051F345-GQ@TQFP48 [(SA248)] C8051F346-GQ@LQFP32
[(SA663)]
C8051F347-GQ@LQFP32 [(SA663)] C8051F350-GQ@LQFP32
[(SA663)]
C8051F351-GM@QFN28 [(SA697-B006)]
C8051F352-GQ@LQFP32 [(SA663)]
C8051F353-GM@QFN28 [(SA697-B006)]
C8051F360@QFP48 [(SA248)] C8051F361@QFP32
[(SA663)]
C8051F362@QFN28 [(SA697)] C8051F363@QFP48
[(SA248)]
C8051F364@QFP32 [(SA663)] C8051F365@QFN28
[(SA697)]
C8051F366@QFP32 [(SA663)] C8051F367@QFN28
[(SA697)]
C8051F368@QFP32 [(SA663)] C8051F369@QFN28
[(SA697)]

C8051F410-GQ@LQFP32 [ordering number is marked above]	
C8051F411-GM@QFN28 [ordering number is marked above]	
C8051F412-GQ@LQFP32 [ordering number is marked above]	
C8051F413-GM@QFN28 [ordering number is marked above]	
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10
[(SA695A)]	
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10
[(SA695A)]	
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10
[(SA695A)]	
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20
[(SA026)]	
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20
[(SA026)]	
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20
[(SA026)]	
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20
[(SA026)]	
C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20
[(SA026)]	
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20
[(SA026)]	
C8051F610-GQ@QFP32 [(SA663)]	
C8051F611-GM@QFN28 [(SA697-B006)]	
C8051F612-GQ@QFP32 [(SA663)]	
C8051F613-GM@QFN28 [(SA697-B006)]	
C8051F614-GQ@QFP32 [(SA663)]	
C8051F615-GM@QFN28 [(SA697-B006)]	
C8051F616-GM@QFN24 [(SA710-B006)]	
C8051F617-GM@QFN24 [(SA710-B006)]	
SI8250@LQFP32 [(SA663)]	SI8250@QFN28
[(SA697)]	
SI8251@LQFP32 [(SA663)]	SI8251@QFN28
[(SA697)]	
SI8252@LQFP32 [(SA663)]	SI8252@QFN28
[(SA697)]	

CYPRESS

E (E) PROM / FRAM / NVRAM

CY14B256L@SOIC32 [(SA715)]

CY27C010
CY27C010@PLCC32 [(SA015A1T)] CY27C010@TSOP32
[(SA410T)]
CY27C020 CY27C020@PLCC32
[(SA015A1T)]
CY27C020@TSOP32 [(SA410T)]
CY27C040
CY27C040@PLCC32 [(SA015A1T)] CY27C040@TSOP32
[(SA410T)]
CY27C128 CY27C128@PLCC32
[(SA015A1T)]
CY27C256 CY27C256@PLCC32
[(SA015A1T)]
CY27C256@TSOP28 [(SA430T)]
CY27C512
CY27C512@PLCC32 [(SA015A1T)] CY27C512@TSOP28
[(SA430T)]
CY27H010 CY27H010@PLCC32
[(SA015A1T)]
CY27H010@TSOP32 [(SA410T)]
CY27H256
CY27H256@PLCC32 [(SA015A1T)] CY27H256@TSOP28
[(SA430T)]
CY27H512 CY27H512@PLCC32
[(SA015A1T)]
CY27H512@TSOP28 [(SA430T)]
CY7C225A
CY7C225A@PLCC28 [(SA008A)]
CY7C243
CY7C243@PLCC28 [(SA008A)]
CY7C244
CY7C244@PLCC28 [(SA008A)]
CY7C245
CY7C245@PLCC28 [(SA008A)]
CY7C245A
CY7C245A@PLCC28 [(SA008A)]
CY7C251
CY7C251@PLCC32 [(SA015A1T)]
CY7C254
CY7C254@PLCC32 [(SA015A1T)]
CY7C256
CY7C256@PLCC32 [(SA015A1T)]
CY7C261

CY7C261@PLCC28 [(SA008A)]
CY7C263
CY7C263@PLCC28 [(SA008A)]
CY7C264
CY7C264@PLCC28 [(SA008A)]
CY7C265
CY7C265@PLCC28 [(SA008A)]
CY7C266
CY7C266@PLCC32 [(SA015A1T)]
CY7C268
CY7C268@PLCC32 [(SA015A1T)]
CY7C271
CY7C271@PLCC32 [(SA015A1T)]
CY7C271A
CY7C271A@PLCC32 [(SA015A1T)]
CY7C274
CY7C274@PLCC32 [(SA015A1T)] [(SA244)]
CY7C276(25JC)@PLCC44 [(SA244)]
CY7C276(25HC)@PLCC44
CY7C276(30JC)@PLCC44
CY7C281
CY7C281@PLCC28
[(SA008A)]
CY7C281A
CY7C281A@PLCC28
[(SA008A)]
CY7C282
CY7C282@PLCC28
[(SA008A)]
CY7C282A
CY7C282A@PLCC28
[(SA008A)]
CY7C285
CY7C285@PLCC32
[(SA015A1T)]
CY7C286
CY7C286@PLCC32
[(SA015A1T)]
CY7C287
CY7C287@PLCC32
[(SA015A1T)]
CY7C291
CY7C291@PLCC28
[(SA008A)]
CY7C291A
CY7C291A@PLCC28
[(SA008A)]
CY7C292
CY7C292@PLCC28
[(SA008A)]
CY7C292A
CY7C292A@PLCC28
[(SA008A)]
CY7C293A
CY7C293A@PLCC28

[(SA008A)]
 CY8C9520@SSOP28 [(SA626A)] CY8C9540@SSOP48
 [(SA669)]

DRAM & SRAM

CY62128@SOIC32 [(SA687)] CY62128@SOJ32
 [(SA661)]
 CY62128@VSOP32 [(SA620)] CY62128L@SOIC32
 [(SA687)]
 CY62128L@SOJ32 [(SA661)] CY62128L@VSOP32
 [(SA620)]
 CY62128LL@SOIC32 [(SA687)] CY62128LL@SOJ32
 [(SA661)]
 CY62128LL@VSOP32 [(SA620)] CY7C1011@TSOP44
 [(SA645)]
 CY7C1020@TSOP44 [(SA645)] CY7C1021@TSOP44
 [(SA645)]
 CY7C1049@SOJ36 [(SA027)] CY7C1049@TSOP44
 [(SA645)]
 CY7C107 CY7C107@SOJ28
 [(SA661)]
 CY7C147
 CY7C167
 CY7C167@PLCC20 [(SA001A)]
 CY7C167A
 CY7C167A@PLCC20 [(SA001A)]
 CY7C185
 CY7C185@SOIC28 [(SA404)] CY7C185@SOJ28
 [(SA646)]
 CY7C186
 CY7C187
 CY7C187@SOJ24 [(SA646)]
 CY7C187A
 CY7C187A@SOJ24 [(SA646)]
 CY7C193
 CY7C193@SOJ28 [(SA646)]
 CY7C199
 CY7C199@PLCC28 [(SA008A)] CY7C199@SOJ28
 [(SA646)]
 CY7C199@TSOP28 [(SA430T)]

PLD

CY2291@SOIC20 [(SA404)]	CY2292@SOIC16
[(SA602)]	
CY2295@SSOP28 [(SA626A)]	CY37032@PLCC44
[(SA244)]	
CY37032@TQFP44 [(SA245A)]	CY37032V@PLCC44
[(SA244)]	
CY37032V@TQFP44 [(SA245A)]	CY37064@PLCC44
[(SA244)]	
CY37064@PLCC44(ISP) [ISP-HEADER01]	
CY37064@TQFP44 [(SA245A)]	
CY37064@TQFP44(ISP) [ISP-HEADER01]	
CY37064V@PLCC44 [(SA244)]	
CY37064V@PLCC44(ISP) [ISP-HEADER01]	
CY37064V@TQFP44 [(SA245A)]	
CY37064V@TQFP44(ISP) [ISP-HEADER01]	
CY7C371@PLCC44 [(SA244)]	CY7C371@TQFP44
[(SA245A)]	
CY7C371I@PLCC44 [(SA244)]	CY7C371I@TQFP44
[(SA245A)]	
CY7C372@PLCC44 [(SA244)]	CY7C372@TQFP44
[(SA245A)]	
CY7C372I@PLCC44 [(SA244)]	CY7C372I@TQFP44
[(SA245A)]	
PALC16L8	PALC16L8@PLCC20
[(SA001A)]	
PALC16L8L	PALC16L8L@PLCC20
[(SA001A)]	
PALC16R4	PALC16R4@PLCC20
[(SA001A)]	
PALC16R4L	PALC16R4L@PLCC20
[(SA001A)]	
PALC16R6	PALC16R6@PLCC20
[(SA001A)]	
PALC16R6L	PALC16R6L@PLCC20
[(SA001A)]	
PALC16R8	PALC16R8@PLCC20
[(SA001A)]	
PALC16R8L	PALC16R8L@PLCC20
[(SA001A)]	
PALC22V10	

PALC22V10@PLCC28 [ordering number is marked above]
PALC22V10A
PALC22V10A@PLCC28 [ordering number is marked above]
PALC22V10B
PALC22V10B@PLCC28 [ordering number is marked above]
PALC22V10D PALC22V10D@PLCC28
[(SA008A)]
PALC22V10L
PALC22V10L@PLCC28 [ordering number is marked above]
PALCE16V8 PALCE16V8@PLCC20
[(SA001A)]
PALCE20V8 PALCE20V8@PLCC28
[(SA008A)]
PALCE20V8L PALCE20V8L@PLCC28
[(SA008A)]
PALCE22V10 PALCE22V10@PLCC28
[(SA008A)]

MICROCONTROLLER

CY7C63722 CY7C63722@SOIC18
[(SA404)]
CY7C63722C CY7C63722C@SOIC18
[(SA404)]
CY7C63723 CY7C63723@SOIC18
[(SA404)]
CY7C63723C CY7C63723C@SOIC18
[(SA404)]
CY7C63742 CY7C63742@QSOP24
[(SA674)]
CY7C63742@SOIC24 [(SA404)]
CY7C63742C
CY7C63742C@QSOP24 [(SA674)]
[(SA404)]
CY7C63743 CY7C63743@QSOP24
[(SA674)]
CY7C63743@SOIC24 [(SA404)]
CY7C63743C
CY7C63743C@QSOP24 [(SA674)]
[(SA404)]
CY7C63813 CY7C63813@SOIC18
[(SA404)]

DALLAS

E (E) PROM/FRAM/NVRAM

DS1073M-100	DS1073M-
60	
DS1073M-66	DS1073M-
80	
DS1073Z-100@SOIC8 [(SA602A)]	DS1073Z-60@SOIC8
[(SA602A)]	
DS1073Z-66@SOIC8 [(SA602A)]	DS1073Z-80@SOIC8
[(SA602A)]	
DS1077LZ-40@SOIC8 [(SA602A)]	DS1077LZ-50@SOIC8
[(SA602A)]	
DS1077LZ-60@SOIC8 [(SA602A)]	DS1077LZ-66@SOIC8
[(SA602A)]	
DS1077Z-40@SOIC8 [(SA602A)]	DS1077Z-50@SOIC8
[(SA602A)]	
DS1077Z-60@SOIC8 [(SA602A)]	DS1077Z-66@SOIC8
[(SA602A)]	
DS1220AB	
DS1220AD	
DS1220Y	
DS1225AB	
DS1225AD	
DS1225D	
DS1225E	
DS1225Y	
DS1230AB	
DS1230W	
DS1230Y	
DS1235AB	
DS1235Y	
DS1243Y	
DS1244	
DS1244Y	
DS1245AB	
DS1245EE	
DS1245P	
DS1245W	
DS1245Y	

DS1248P
DS1248W
DS1248Y
DS1249AB
DS1249W
DS1249Y
DS1250AB
DS1250W
DS1250Y
DS1251AB
DS1251W
DS1251Y
DS1256P
DS1256W
DS1256Y
DS1265AB
DS1265W
DS1265Y
DS1270AB
DS1270W
DS1270Y
DS1284
DS1284N
DS1284Q@PLCC28 [(SA008A)] DS1284QN@PLCC28
[(SA008A)]
DS1286
DS1286I
DS1287
DS1287A
DS12887
DS12887A
DS12C887
DS12C887A
DS1330AB
DS1330WP
DS1330Y
DS1345AB
DS1345P
DS1345W
DS1345Y
DS1350AB
DS1350P
DS1350W

DS1350Y DS1386
(32K)
DS1386 (8K)
DS14285
DS14287
DS1485
DS1485@SOIC28 [(SA630)]
DS1486
DS1488
DS1553
DS1553W
DS1554
DS1554W
DS1556
DS1630AB
DS1630Y
DS1642
DS1643
DS1644
DS1644P [ordering number is marked above]
DS1644PS [(PEP+S414T)]
DS1645AB
DS1645EE
DS1645Y
DS1646
DS1647
DS1647LPM
DS1650AB
DS1650Y DS1687-
3
DS1687-5 DS17287-
3
DS17287-5
DS1742
DS1742W
DS1743
DS1743P
DS1743W
DS1743WP
DS1744
DS1744P
DS1744W
DS1744WP

DS1746
 DS1747
 DS1747P [ordering number is marked above]
 DS1747PS [(PEP+S414T)]
 DS1747W
 DS1747WP [ordering number is marked above]
 DS1747WPS [(PEP+S414T)] DS17487-
 3
 DS17487-5 DS17887-
 3
 DS17887-5 DS2406@TO-
 92
 DS2406P@TSOC6 DS2430A@TO-
 92
 DS2430AP@TSOC6 [(SA602A)] DS2431@TO-
 92
 DS2431P@TSOC6 [(SA602A)] DS2432P@TSOC6
 [(SA602A)]
 DS2433@PR-35 DS2433S(3.9)@SOIC8
 [(SA602A)]
 DS2433S(5.5)@SOIC8 [(SA605A)]
 DS2502
 DS2502P@TSOC6 [(SA602A)] DS2502S@SOIC8
 [(SA602A)]
 DS2502UNW DS2502UNW@SOIC8
 [(SA602A)]
 DS2502UNW@TSOC6 [(SA602A)]
 DS2506
 DS2506S@SOIC8 [(SA023A)]
 DS4510@uSOP10
 DS4520@TSSOP16 [(SA026)] DS4550@TSSOP20
 [(SA026)]

MICROCONTROLLER

DS87C520 DS87C520@PLCC44
 [(SA244)]
 DS87C520@TQFP44 [(SA245A)]
 DS89C420
 DS89C420(rev.A) DS89C420(rev.A)@PLCC44
 [(SA244)]
 DS89C420(rev.A)@TQFP44 [(SA245A)]

DS89C420@PLCC44 [(SA244)]	DS89C420@TQFP44
[(SA245A)]	
DS89C430	DS89C430@PLCC44
[(SA244)]	
DS89C430@TQFP44 [(SA245A)]	
DS89C440	
DS89C440@PLCC44 [(SA244)]	DS89C440@TQFP44
[(SA245A)]	
DS89C450	DS89C450@PLCC44
[(SA244)]	
DS89C450@TQFP44 [(SA245A)]	

DENSE-PAC

E (E) PROM / FRAM / NVRAM

DPV27C101	DPV27C101@PLCC32
[(SA015A1T)]	
DPV27C256	DPV27C256@PLCC32
[(SA015A1T)]	
DPV27C512	DPV27C512@PLCC32
[(SA015A1T)]	

DEUTRON

E (E) PROM / FRAM / NVRAM

AC25LV010	AC25LV010@SOIC8
[(SA602A)]	
AC25LV512	AC25LV512@SOIC8
[(SA602A)]	
P439LV010@PLCC32 [(SA015A1T)]	P439LV010@VSOP32
[(SA620)]	
P439LV040@PLCC32 [(SA015A1T)]	P439LV040@VSOP32
[(SA620)]	
P439LV088@TSOP48 [(SA247-B005)]	P439VF800@TSOP48 [(SA247-
B005)]	

EFST

E (E) PROM / FRAM / NVRAM

EM25LV010@SOIC8 [(SA602A)]	EM25LV010@VFQFPN8
[(SA684)]	
EM25LV512@SOIC8 [(SA602A)]	EM25LV512@VFQFPN8
[(SA684)]	
F25L004A@SOIC8 [(SA602A)]	
F49B002UA	
F49B002UA@PLCC32 [(SA015A1T)]	F49L004BA@PLCC32
[(SA015A1T)]	
F49L004BA@TSOP40 [(SA409T)]	F49L004UA@PLCC32
[(SA015A1T)]	
F49L004UA@TSOP40 [(SA409T)]	F49L040A@PLCC32
[(SA015A1T)]	
F49L040A@VSOP32 [(SA620)]	F49L400BA@TSOP48 [(SA247-
B005)]	
F49L400UA@TSOP48 [(SA247-B005)]	F49L800BA@TSOP48
[(SA247)]	
F49L800UA@TSOP48 [(SA247)]	

ELECTRONIC ARRAYS

E (E) PROM / FRAM / NVRAM

EA2716

EM

MICROCONTROLLER

EM6503@SOIC24 [(SA404)]
EM6503@SOIC24 (ISP) [ISP-HEADER01]
EM6504@SOIC24 [(SA404)]
EM6504@SOIC24 (ISP) [ISP-HEADER01]
EM6505@SOIC24 [(SA404)]
EM6505@SOIC24 (ISP) [ISP-HEADER01]
EM6517@SOIC28 [(SA404)]
EM6517@SOIC28 (ISP) [ISP-HEADER01]
EM6520@TQFP44 [(SA245A)]
EM6520@TQFP44 (ISP) [ISP-HEADER01]

EM6521@TQFP52(ISP) [ISP-HEADER01]
EM6522@TQFP64(ISP) [ISP-HEADER01]
EM6540@SOIC18 [(SA404)]
EM6540@SOIC18(ISP) [ISP-HEADER01]
EM6580
EM6580(ISP) [ISP-
HEADER01]
EM6580@SOIC14 [(SA602)]
EM6580@SOIC14(ISP) [ISP-HEADER01]
EM6580@SOIC8 [(SA602A)]
EM6580@SOIC8(ISP) [ISP-
HEADER01]
EM6580@TSSOP14 [(SA026)]
EM6580@TSSOP14(ISP) [ISP-HEADER01]
EM6812_2K
EM6812_2K(ISP) [ISP-
HEADER01]
EM6812_2K@SOIC24 [(SA404)]
EM6812_2K@SOIC24(ISP) [ISP-HEADER01]
EM6812_2K@TSSOP24 [(SA026)]
EM6812_2K@TSSOP24(ISP) [ISP-HEADER01]
EM6812_4K
EM6812_4K(ISP) [ISP-
HEADER01]
EM6812_4K@SOIC24 [(SA404)]
EM6812_4K@SOIC24(ISP) [ISP-HEADER01]
EM6812_4K@TSSOP24 [(SA026)]
EM6812_4K@TSSOP24(ISP) [ISP-HEADER01]
EM6812_8K
EM6812_8K(ISP) [ISP-
HEADER01]
EM6812_8K@SOIC24 [(SA404)]
EM6812_8K@SOIC24(ISP) [ISP-HEADER01]
EM6812_8K@TSSOP24 [(SA026)]
EM6812_8K@TSSOP24(ISP) [ISP-HEADER01]

EMTC

E (E) PROM/FRAM/NVRAM

EM24C02
[(SA602A)]
EM24C02@TSSOP8 [(SA026)]
EM24C04
EM24C04@SOIC8 [(SA602A)]
[(SA026)]
EM24C08
EM24C02@SOIC8
EM24C04@TSSOP8
EM24C08@SOIC8

[(SA602A)]
 EM24C08@TSSOP8 [(SA026)]
 EM24C16
 EM24C16@SOIC8 [(SA602A)] EM24C16@TSSOP8
 [(SA026)]
 EM25SL512@SOIC8 [(SA602A)]
 EM29SF002AB
 EM29SF002AB@PLCC32 [(SA015A1T)] EM29SF002AB@TSOP32
 [(SA410T)]
 EM29SF002AT EM29SF002AT@PLCC32
 [(SA015A1T)]
 EM29SF002AT@TSOP32 [(SA410T)]
 EM29SF002NAB
 EM29SF002NAB@PLCC32 [(SA015A1T)] EM29SF002NAB@TSOP32
 [(SA410T)]
 EM29SF002NAT EM29SF002NAT@PLCC32
 [(SA015A1T)]
 EM29SF002NAT@TSOP32 [(SA410T)]

EON

E (E) PROM / FRAM / NVRAM

EN25B05 (Bottom Boot)@SOP8(4.0) [(SA602A)]
 EN25B05 (Bottom Boot)@SOP8(5.4) [(SA605A)]
 EN25B05 (Bottom Boot)@VDFN8 [(SA683)]
 EN25B05 (Top Boot)@SOP8(4.0) [(SA602A)]
 EN25B05 (Top Boot)@SOP8(5.4) [(SA605A)]
 EN25B05 (Top Boot)@VDFN8 [(SA683)]
 EN25B10 (Bottom Boot)@SOP8(4.0) [(SA602A)]
 EN25B10 (Bottom Boot)@SOP8(5.4) [(SA605A)]
 EN25B10 (Bottom Boot)@VDFN8 [(SA683)]
 EN25B10 (Top Boot)@SOP8(4.0) [(SA602A)]
 EN25B10 (Top Boot)@SOP8(5.4) [(SA605A)]
 EN25B10 (Top Boot)@VDFN8 [(SA683)]
 EN25B16 (Bottom Boot)@SOP8 [(SA605A)]
 EN25B16 (Bottom Boot)@SOP8 (ISP) [ISP-HEADER01]
 EN25B16 (Bottom Boot)@VFQFN8 (ISP) [ISP-HEADER01]
 EN25B16 (Bottom Boot)@VFQFPN8 [(SA684)]
 EN25B16 (Top Boot)@SOP8 [(SA605A)]
 EN25B16 (Top Boot)@SOP8 (ISP) [ISP-HEADER01]
 EN25B16 (Top Boot)@VFQFN8 (ISP) [ISP-HEADER01]

EN25B16(Top Boot)@VFQFPN8 [(SA684)]
EN25B20(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B20(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B20(Bottom Boot)@VDFN8 [(SA683)]
EN25B20(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B20(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B20(Top Boot)@VDFN8 [(SA683)]
EN25B32(Bottom Boot)@SOIC16 [(SA404)]
EN25B32(Bottom Boot)@SOIC16(ISP) [(SA404)]
EN25B32(Bottom Boot)@SOP8 [(SA605A)]
EN25B32(Bottom Boot)@SOP8(ISP) [(SA605A)]
EN25B32(Bottom Boot)@VDFN8 [(SA684)]
EN25B32(Bottom Boot)@VDFN8(ISP) [(SA684)]
EN25B32(Top Boot)@SOIC16 [(SA404)]
EN25B32(Top Boot)@SOIC16(ISP) [(SA404)]
EN25B32(Top Boot)@SOP8 [(SA605A)]
EN25B32(Top Boot)@SOP8(ISP) [(SA605A)]
EN25B32(Top Boot)@VDFN8 [(SA684)]
EN25B32(Top Boot)@VDFN8(ISP) [(SA684)]
EN25B40(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B40(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B40(Bottom Boot)@VDFN8 [(SA683)]
EN25B40(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B40(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B40(Top Boot)@VDFN8 [(SA683)]
EN25B64(Bottom Boot)@SOIC16 [(SA404)]
EN25B64(Bottom Boot)@SOIC16(ISP) [ISP-HEADER01]
EN25B64(Bottom Boot)@VDFN8 [(SA683)]
EN25B64(Bottom Boot)@VDFN8(ISP) [ISP-HEADER01]
EN25B64(Top Boot)@SOIC16 [(SA404)]
EN25B64(Top Boot)@SOIC16(ISP) [ISP-HEADER01]
EN25B64(Top Boot)@VDFN8 [(SA683)]
EN25B64(Top Boot)@VDFN8(ISP) [ISP-HEADER01]
EN25B80(Bottom Boot)@SOP8(4.0) [(SA602A)]
EN25B80(Bottom Boot)@SOP8(5.4) [(SA605A)]
EN25B80(Bottom Boot)@VDFN8 [(SA683)]
EN25B80(Top Boot)@SOP8(4.0) [(SA602A)]
EN25B80(Top Boot)@SOP8(5.4) [(SA605A)]
EN25B80(Top Boot)@VDFN8 [(SA683)]
EN25D16
[(SA404)] EN25D16@SOP16
EN25D16@SOP8 [(SA605A)] EN25D16@VDFN8
[(SA684)]

EN25D80	EN25D80@SOP8
[(SA605A)]	
EN25D80@VDFN8 [(SA683)]	EN25F05@SOP8(4.0)
[(SA602A)]	
EN25F05@SOP8(5.4) [(SA605A)]	EN25F05@VDFN8
[(SA683)]	
EN25F10@SOP8(4.0) [(SA602A)]	EN25F10@SOP8(5.4)
[(SA605A)]	
EN25F10@VDFN8 [(SA683)]	
EN25F16	
EN25F16@SOP16 [(SA404)]	EN25F16@SOP8
[(SA605A)]	
EN25F16@VDFN8 [(SA684)]	EN25F20@SOP8
[(SA605A)]	
EN25F20@VDFN8 [(SA683)]	EN25F40@SOP8(150mil)
[(SA602A)]	
EN25F40@SOP8(209mil) [(SA605A)]	EN25F40@VDFN8
[(SA683)]	
EN25F80	EN25F80@SOP8
[(SA605A)]	
EN25F80@VDFN8 [(SA683)]	EN25LF05@SOP8(4.0)
[(SA602A)]	
EN25LF05@SOP8(5.4) [(SA605A)]	EN25LF05@VDFN8
[(SA683)]	
EN25LF10@SOP8(4.0) [(SA602A)]	EN25LF10@SOP8(5.4)
[(SA605A)]	
EN25LF10@VDFN8 [(SA683)]	EN25LV010@SOIC8
[(SA602A)]	
EN25LV010@VFQFPN8 [(SA684)]	EN25LV020@SOIC8
[(SA602A)]	
EN25LV020@VFQFPN8 [(SA684)]	EN25LV040@SOIC8
[(SA602A)]	
EN25LV040@VFQFPN8 [(SA684)]	EN25LV080@SOIC8
[(SA602A)]	
EN25LV080@VFQFPN8 [(SA684)]	EN25LV160@SOIC8
[(SA602A)]	
EN25LV160@SOIC8(ISP) [ISP-HEADER01]	
EN25LV160@VFQFPN8 [(SA683)]	
EN25LV160@VFQFPN8(ISP) [ISP-HEADER01]	
EN25LV512@SOIC8 [(SA602A)]	EN25LV512@VFQFPN8
[(SA684)]	
EN25P05@SOP8(4.0) [(SA602A)]	EN25P05@SOP8(5.4)
[(SA605A)]	

EN25P05@VDFN8 [(SA683)]	EN25P10@SOP8(4.0)
[(SA602A)]	
EN25P10@SOP8(5.4) [(SA605A)]	EN25P10@VDFN8
[(SA683)]	
EN25P16@SOP8 [(SA605A)]	EN25P16@SOP8(ISP) [ISP-
HEADER01]	
EN25P16@VFQFPN8 [(SA684)]	
EN25P16@VFQFPN8(ISP) [ISP-HEADER01]	
EN25P20@SOP8(4.0) [(SA602A)]	EN25P20@SOP8(5.4)
[(SA605A)]	
EN25P20@VDFN8 [(SA683)]	EN25P32@SOIC16
[(SA404)]	
EN25P32@SOIC16(ISP) [(SA404)]	EN25P32@SOP8
[(SA605A)]	
EN25P32@SOP8(ISP) [(SA605A)]	EN25P32@VDFN8
[(SA684)]	
EN25P32@VDFN8(ISP) [(SA684)]	EN25P40@SOP8(4.0)
[(SA602A)]	
EN25P40@SOP8(5.4) [(SA605A)]	EN25P40@VDFN8
[(SA683)]	
EN25P64@SOIC16 [(SA404)]	
EN25P64@SOIC16(ISP) [ISP-HEADER01]	
EN25P64@VDFN8 [(SA683)]	
EN25P64@VDFN8(ISP) [ISP-HEADER01]	
EN25P80@SOP8(4.0) [(SA602A)]	EN25P80@SOP8(5.4)
[(SA605A)]	
EN25P80@VDFN8 [(SA683)]	EN25S16@SOP8
[(SA605A)]	
EN25S16@VFQFPN8 [(SA684)]	
EN25S32(Bottom Boot)@SOIC16 [(SA404)]	
EN25S32(Bottom Boot)@SOIC16(ISP) [(SA404)]	
EN25S32(Bottom Boot)@SOP8 [(SA605A)]	
EN25S32(Bottom Boot)@SOP8(ISP) [(SA605A)]	
EN25S32(Bottom Boot)@VDFN8 [(SA684)]	
EN25S32(Bottom Boot)@VDFN8(ISP) [(SA684)]	
EN25S32(Top Boot)@SOIC16 [(SA404)]	
EN25S32(Top Boot)@SOIC16(ISP) [(SA404)]	
EN25S32(Top Boot)@SOP8 [(SA605A)]	
EN25S32(Top Boot)@SOP8(ISP) [(SA605A)]	
EN25S32(Top Boot)@VDFN8 [(SA684)]	
EN25S32(Top Boot)@VDFN8(ISP) [(SA684)]	
EN25T16@SOP8 [(SA605A)]	EN25T16@VFQFPN8
[(SA684)]	

EN25T80	EN25T80@SOP8
[(SA605A)]	
EN25T80@VDFN8 [(SA683)]	
EN27C010	
EN27C010@PLCC32 [(SA015A1T)]	
EN27C512	
EN27C512@PLCC32 [(SA015A1T)]	
EN29F002AB	
EN29F002AB@PLCC32 [(SA015A1T)]	EN29F002AB@TSOP32
[(SA410T)]	
EN29F002ANB	EN29F002ANB@PLCC32
[(SA015A1T)]	
EN29F002ANB@TSOP32 [(SA410T)]	
EN29F002ANT	
EN29F002ANT@PLCC32 [(SA015A1T)]	EN29F002ANT@TSOP32
[(SA410T)]	
EN29F002AT	EN29F002AT@PLCC32
[(SA015A1T)]	
EN29F002AT@TSOP32 [(SA410T)]	
EN29F002B	
EN29F002B@PLCC32 [(SA015A1T)]	EN29F002B@TSOP32
[(SA410T)]	
EN29F002NB	EN29F002NB@PLCC32
[(SA015A1T)]	
EN29F002NB@TSOP32 [(SA410T)]	
EN29F002NT	
EN29F002NT@PLCC32 [(SA015A1T)]	EN29F002NT@TSOP32
[(SA410T)]	
EN29F002T	EN29F002T@PLCC32
[(SA015A1T)]	
EN29F002T@TSOP32 [(SA410T)]	
EN29F010	
EN29F010@PLCC32 [(SA015A1T)]	EN29F010@TSOP32
[(SA410T)]	
EN29F010@VSOP32 [(SA620)]	
EN29F040	
EN29F040@PLCC32 [(SA015A1T)]	EN29F040@TSOP32
[(SA410T)]	
EN29F040A	EN29F040A@PLCC32
[(SA015A1T)]	
EN29F040A@TSOP32 [(SA410T)]	EN29F080@TSOP40
[(SA409T)]	
EN29F512	EN29F512@PLCC32

[(SA015A1T)]
 EN29F512@TSOP32 [(SA410T)] EN29F512@VSOP32
 [(SA620)]
 EN29F800B@TSOP48 [(SA247-B005)] EN29F800T@TSOP48 [(SA247-B005)]
 EN29LV010@PLCC32 [(SA015A1T)] EN29LV010@TSOP32
 [(SA410T)]
 EN29LV010@VSOP32 [(SA620)] EN29LV040@PLCC32
 [(SA015A1T)]
 EN29LV040@TSOP32 [(SA410T)] EN29LV040@VSOP32
 [(SA620)]
 EN29LV040A@PLCC32 [(SA015A1T)] EN29LV040A@TSOP32
 [(SA410T)]
 EN29LV040A@VSOP32 [(SA620)]
 EN29LV160AB@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV160AB@TSOP48 [(SA247-B005)]
 EN29LV160AT@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV160AT@TSOP48 [(SA247-B005)]
 EN29LV160B@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV160B@TSOP48 [(SA247-B005)]
 EN29LV160T@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV160T@TSOP48 [(SA247-B005)]
 EN29LV320AB@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV320AB@TSOP48 [(SA247-B005)]
 EN29LV320AT@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV320AT@TSOP48 [(SA247-B005)]
 EN29LV320B@FBGA48 [(SA642G-B026A-T048F001)]
 EN29LV320B@TSOP48 [(SA247-B005)]
 EN29LV320T@FBGA48 [(SA642G-B026A-T048F001)]
 EN29LV320T@TSOP48 [(SA247-B005)]
 EN29LV400AB@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV400AB@TSOP48 [(SA247-B005)]
 EN29LV400AT@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV400AT@TSOP48 [(SA247-B005)]
 EN29LV400B@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV400B@TSOP48 [(SA247-B005)]
 EN29LV400T@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV400T@TSOP48 [(SA247-B005)] EN29LV512@PLCC32
 [(SA015A1T)]
 EN29LV512@TSOP32 [(SA410T)] EN29LV512@VSOP32
 [(SA620)]
 EN29LV640B@FBGA48 [(SA642G-B026A-T048F001Y)]
 EN29LV640B@TSOP48 [(SA247-B005)]

EN29LV640H@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV640H@TSOP48 [(SA247-B005)]
EN29LV640L@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV640L@TSOP48 [(SA247-B005)]
EN29LV640T@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV640T@TSOP48 [(SA247-B005)]
EN29LV641H@FBGA63 [(SA642M-B026A-W048F001Y)]
EN29LV641H@TSOP48 [(SA247-B005)]
EN29LV641L@FBGA63 [(SA642M-B026A-W048F001Y)]
EN29LV641L@TSOP48 [(SA247-B005)]
EN29LV800AB@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV800AB@TSOP48 [(SA247-B005)]
EN29LV800AT@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29LV800AT@TSOP48 [(SA247-B005)]
EN29LV800B@TSOP48 [(SA247-B005)]
EN29LV800BB(Low)@TSOP48 [(SA247-B005)]
EN29LV800BB@FBGA48 [(SA642G-B026A-T048F001)]
EN29LV800BB@TSOP48 [(SA247-B005)]
EN29LV800BT(Low)@TSOP48 [(SA247-B005)]
EN29LV800BT@FBGA48 [(SA642G-B026A-T048F001)]
EN29LV800BT@TSOP48 [(SA247-B005)]
EN29LV800T@TSOP48 [(SA247-B005)]
EN29SL160B@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29SL160B@TSOP48 [(SA247-B005)]
EN29SL160T@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29SL160T@TSOP48 [(SA247-B005)]
EN29SL400B@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29SL400B@TSOP48 [(SA247-B005)]
EN29SL400T@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29SL400T@TSOP48 [(SA247-B005)]
EN29SL800B@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29SL800B@TSOP48 [(SA247-B005)]
EN29SL800T@FBGA48 [(SA642G-B026A-T048F001Y)]
EN29SL800T@TSOP48 [(SA247-B005)]

EPSON

E (E) PROM / FRAM / NVRAM

S1H0H324B2B1@FBGA66 [(SA642E-B023A-T072F001)]
S1H0H324B2T1@FBGA66 [(SA642E-B023A-T072F001)]
S1H0H326B2B1@FBGA66 [(SA642E-B023A-T072F001)]

S1H0H326B2T1@FBGA66 [(SA642E-B023A-T072F001)]
S1H0H328B2B2@FBGA66 [(SA642E-B023A-T072F001)]
S1H0H328B2T2@FBGA66 [(SA642E-B023A-T072F001)]
S1H0J642B2B3@FBGA68 [(SA642E-B023A-T072F001)]
S1H0J642B2T3@FBGA68 [(SA642E-B023A-T072F001)]
S1H0J646B2B3@FBGA68 [(SA642E-B023A-T072F001)]
S1H0J646B2T3@FBGA68 [(SA642E-B023A-T072F001)]
S1H0J648B2B2@FBGA68 [(SA642E-B023A-T072F001)]
S1H0J648B2T2@FBGA68 [(SA642E-B023A-T072F001)]

ESMT

E (E) PROM / FRAM / NVRAM

EM25LV010@SOIC8 [(SA602A)] EM25LV010@VFQFPN8
[(SA684)]
EM25LV512@SOIC8 [(SA602A)] EM25LV512@VFQFPN8
[(SA684)]
F25L004AB
F25L004AB@SOIC8(150mil) [(SA602A)]
F25L004AB@SOIC8(200mil) [(SA605A)]
F25L004AT
F25L004AT@SOIC8(150mil) [(SA602A)]
F25L004AT@SOIC8(200mil) [(SA605A)]
F25L008AB@SOIC8 [(SA605A)] F25L008AT@SOIC8
[(SA605A)]
F25L016AB@SOIC8 [(SA605A)] F25L016AT@SOIC8
[(SA605A)]
F25L04UA@SOIC8 [(SA602A)]
F25L08PA(AAI-PROGRAM)@SOIC8 [(SA605A)]
F25L08PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]
F25L16PA(AAI-PROGRAM)@SOIC8 [(SA605A)]
F25L16PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]
F49B002UA F49B002UA@PLCC32
[(SA015A1T)]
F49L004BA@PLCC32 [(SA015A1T)] F49L004BA@TSOP40
[(SA409T)]
F49L004UA@PLCC32 [(SA015A1T)] F49L004UA@TSOP40
[(SA409T)]
F49L040A@PLCC32 [(SA015A1T)] F49L040A@VSOP32
[(SA620)]
F49L160BA@TSOP48 [(SA247)] F49L160UA@TSOP48

[(SA247)]	
F49L320BA@TSOP48 [(SA247)]	F49L320UA@TSOP48
[(SA247)]	
F49L400BA@TSOP48 [(SA247-B005)]	F49L400UA@TSOP48 [(SA247-B005)]
F49L800BA@TSOP48 [(SA247)]	F49L800UA@TSOP48
[(SA247)]	

EXCELSEMI

E (E) PROM / FRAM / NVRAM

ES25M16 [(SA404)]	ES25M16@SOP16
ES25M16@SOP8[150 mil] [(SA602A)] [(SA605A)]	ES25M16@SOP8[208 mil]
ES25M40 [(SA404)]	ES25M40@SOP16
ES25M40@SOP8[150 mil] [(SA602A)] [(SA605A)]	ES25M40@SOP8[208 mil]
ES25M80 [(SA404)]	ES25M80@SOP16
ES25M80@SOP8[150 mil] [(SA602A)] [(SA605A)]	ES25M80@SOP8[208 mil]
ES25P16@SOP8 [(SA605A)] [(SA605A)]	ES25P40@SOP8
ES25P80@SOP8 [(SA605A)]	
ES29LV160DB@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160DB@PSOP44 [(SA638)]	
ES29LV160DB@TSOP48 [(SA247-B005)]	
ES29LV160DT@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160DT@PSOP44 [(SA638)]	
ES29LV160DT@TSOP48 [(SA247-B005)]	
ES29LV160EB@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160EB@TSOP48 [(SA247-B005)]	
ES29LV160ET@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160ET@TSOP48 [(SA247-B005)]	
ES29LV160FB@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160FB@TSOP48 [(SA247-B005)]	
ES29LV160FT@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160FT@TSOP48 [(SA247-B005)]	
ES29LV320DB@FBGA48 [(SA642G-B026A-T048F001Y)]	

ES29LV320DB@TSOP48 [(SA247-B005)]
ES29LV320DT@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV320DT@TSOP48 [(SA247-B005)]
ES29LV320EB@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV320EB@TSOP48 [(SA247-B005)]
ES29LV320ET@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV320ET@TSOP48 [(SA247-B005)]
ES29LV320FB@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV320FB@TSOP48 [(SA247-B005)]
ES29LV320FT@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV320FT@TSOP48 [(SA247-B005)]
ES29LV400DB@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV400DB@TSOP48 [(SA247-B005)]
ES29LV400DT@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV400DT@TSOP48 [(SA247-B005)]
ES29LV400EB@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV400EB@TSOP48 [(SA247-B005)]
ES29LV400ET@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV400ET@TSOP48 [(SA247-B005)]
ES29LV800DB@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV800DB@PSOP44 [(SA638)]
ES29LV800DB@TSOP48 [(SA247-B005)]
ES29LV800DT@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV800DT@PSOP44 [(SA638)]
ES29LV800DT@TSOP48 [(SA247-B005)]
ES29LV800EB@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV800EB@TSOP48 [(SA247-B005)]
ES29LV800ET@FBGA48 [(SA642G-B026A-T048F001Y)]
ES29LV800ET@TSOP48 [(SA247-B005)]

EXEL

E (E) PROM / FRAM / NVRAM

XL24C01A
XL24C02
XL24C04
XL24C16
XL24C16@SOIC8 [(SA602A)]
XL24C32
XL28C256
XL28C256@PLCC32
[(SA015A1T)]

XL28C256@TSOP28 [(SA430T)]
XL9010
XL9010(F) [(SA602A)]
XL9020
XL9020(F) [(SA602A)]
XL9040
XL9040(F) [(SA602A)]
XL9346
XL9346@SOIC8 [(SA602A)]
XL93CS56
XL93CS56@SOIC8 [(SA602A)] XL93CS56@TSSOP8
[(SA026)]
XL93CS66 XL93CS66@SOIC8
[(SA602A)]
XL93CS66@TSSOP8 [(SA026)]
XL93LC46
XL93LC46@SOIC8 [(SA602A)]
XL93LC46A
XL93LC46A@SOIC8 [(SA602A)]
XL93LC56
XL93LC56@SOIC8 [(SA602A)]
XL93LC56A
XL93LC56A@SOIC8 [(SA602A)]
XL93LC66A
XL93LC66A@SOIC8 [(SA602A)]
XL9764
XLE28C16A XLE28C16A@PLCC32
[(SA015A1T)]
XLE28C16B XLE28C16B@PLCC32
[(SA015A1T)]
XLE28C16B@SOIC24 [(SA404)]
XLM28C16A
XLM28C16A@PLCC32 [(SA015A1T)]
XLM46C15
XLM46P15
XLS2804A
XLS2816A XLS2816A@PLCC32
[(SA015A1T)]
XLS2817A
XLS28C16A
XLS28C16A@PLCC32 [(SA015A1T)]
XLS28C16B
XLS28C16B@PLCC32 [(SA015A1T)] XLS28C16B@SOIC24

[(SA404)]

XLS28C64B

XLS28C64B@PLCC32

[(SA015A1T)]

XLS28C64B@SOIC28 [(SA404)]

XLS46C15

XLS46P15

XLS93C46

XLS93C46@SOIC8 [(SA602A)]

XLS93C56

XLS93C56@SOIC8 [(SA602A)]

XLS93C66

XLS93C66@SOIC8 [(SA602A)]

XLS93CS46

XLS93CS46@SOIC8 [(SA602A)]

XLS93CS46@TSSOP8

[(SA026)]

XLS93LC06

XLS93LC06@SOIC8

[(SA602A)]

XLS93LC66

XLS93LC66@SOIC8

[(SA602A)]

PLD

XLE78C800P-25

XLE78C800P-

35

XLE78C800P-45

XLE78C800S-

25

XLE78C800S-35

XLE78C800S-

45

XLM78C800S-35

XLM78C800S-

45

XLS78C800P-25

XLS78C800P-

35

XLS78C800P-45

XLS78C800S-

25

XLS78C800S-35

XLS78C800S-

45

FAIRCHILD

E (E) PROM / FRAM / NVRAM

FM24C02(M8)@SOIC8 [(SA602A)]	FM24C02(MT8)@TSSOP8
[(SA026)]	
FM24C02(N)	FM24C03(M8)@SOIC8
[(SA602A)]	
FM24C03(MT8)@TSSOP8 [(SA026)]	FM24C03
(N)	
FM24C04(M8)@SOIC8 [(SA602A)]	FM24C04(MT8)@TSSOP8
[(SA026)]	
FM24C04(N)	FM24C05(M8)@SOIC8
[(SA602A)]	
FM24C05(MT8)@TSSOP8 [(SA026)]	FM24C05
(N)	
FM24C08(M8)@SOIC8 [(SA602A)]	FM24C08(MT8)@TSSOP8
[(SA026)]	
FM24C08(N)	FM24C09(M8)@SOIC8
[(SA602A)]	
FM24C09(MT8)@TSSOP8 [(SA026)]	FM24C09
(N)	
FM24C128(MT8)@TSSOP8 [(SA026)]	FM24C128(MW8)@SOIC8
[(SA602A)]	
FM24C128(N)	FM24C16(M8)@SOIC8
[(SA602A)]	
FM24C16(MT8)@TSSOP8 [(SA026)]	FM24C16
(N)	
FM24C17(M8)@SOIC8 [(SA602A)]	FM24C17(MT8)@TSSOP8
[(SA026)]	
FM24C17(N)	FM24C256(M8)@SOIC8
[(SA602A)]	
FM24C256(N)	FM24C32(M8)@SOIC8
[(SA602A)]	
FM24C32(N)	
FM27C010	
FM27C010@PLCC32 [(SA015A1T)]	FM27C010@TSOP32
[(SA410T)]	
FM27C040	FM27C040@PLCC32
[(SA015A1T)]	
FM27C040@TSOP32 [(SA410T)]	
FM27C256	
FM27C256@PLCC32 [(SA015A1T)]	
FM27C256Q	
FM27C256Q@PLCC32 [(SA015A1T)]	
FM27C512	
FM27C512@PLCC32 [(SA015A1T)]	

FM93C06(M8)(08bit)@SOIC8 [(SA602A)]
FM93C06(M8)(16bit)@SOIC8 [(SA602A)]
FM93C06(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C06(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C06(N)(08bit) FM93C06(N)
(16bit)
FM93C14(16bit) FM93C46(M8)@SOIC8
[(SA602A)]
FM93C46(MT8)@TSSOP8 [(SA026)] FM93C46
(N)
FM93C46A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C46A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C46A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C46A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C46A(N)(08bit) FM93C46A(N)
(16bit)
FM93C56(M8)@SOIC8 [(SA602A)] FM93C56(MT8)@TSSOP8
[(SA026)]
FM93C56(N)
FM93C56A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C56A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C56A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C56A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C56A(N)(08bit) FM93C56A(N)
(16bit)
FM93C66(M8)@SOIC8 [(SA602A)] FM93C66(MT8)@TSSOP8
[(SA026)]
FM93C66(N)
FM93C66A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C66A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C66A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C66A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C66A(N)(08bit) FM93C66A(N)
(16bit)
FM93C76(M8)(16bit)@SOIC8 [(SA602A)]
FM93C76(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C76(N)(16bit)
FM93C76A(M8)(08bit)@SOIC8 [(SA602A)]
FM93C76A(M8)(16bit)@SOIC8 [(SA602A)]
FM93C76A(MT8)(08bit)@TSSOP8 [(SA026)]
FM93C76A(MT8)(16bit)@TSSOP8 [(SA026)]
FM93C76A(N)(08bit) FM93C76A(N)
(16bit)

FM93C86(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86(N)(16bit)	
FM93C86A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C86A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C86A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86A(N)(08bit)	FM93C86A(N)
(16bit)	
FM93CS06(M8)@SOIC8 [(SA602A)]	FM93CS06(MT8)@TSSOP8
[(SA026)]	
FM93CS06(N)	FM93CS46(M8)@SOIC8
[(SA602A)]	
FM93CS46(MT8)@TSSOP8 [(SA026)]	FM93CS46
(N)	
FM93CS56(M8)@SOIC8 [(SA602A)]	FM93CS56(MT8)@TSSOP8
[(SA026)]	
FM93CS56(N)	FM93CS66(M8)@SOIC8
[(SA602A)]	
FM93CS66(MT8)@TSSOP8 [(SA026)]	FM93CS66
(N)	
FM93S46(M8)@SOIC8 [(SA602A)]	FM93S46(MT8)@TSSOP8
[(SA026)]	
FM93S46(N)	FM93S56(M8)@SOIC8
[(SA602A)]	
FM93S56(MT8)@TSSOP8 [(SA026)]	FM93S56
(N)	
FM93S66(M8)@SOIC8 [(SA602A)]	FM93S66(MT8)@TSSOP8
[(SA026)]	
FM93S66(N)	
MM2716	
MM2716E	NM24C02(M8)@SOIC8
[(SA602A)]	
NM24C02(MT8)@TSSOP8 [(SA026)]	NM24C02
(N)	
NM24C02L(M8)@SOIC8 [(SA602A)]	NM24C02L(MT8)@TSSOP8
[(SA026)]	
NM24C02L(N)	NM24C03(M8)@SOIC8
[(SA602A)]	
NM24C03(MT8)@TSSOP8 [(SA026)]	NM24C03
(N)	
NM24C04(M8)@SOIC8 [(SA602A)]	NM24C04(MT8)@TSSOP8
[(SA026)]	

NM24C04(N) [(SA602A)]	NM24C05(M8)@SOIC8
NM24C05(MT8)@TSSOP8 [(SA026)] (N)	NM24C05
NM24C08(M8)@SOIC8 [(SA602A)] [(SA026)]	NM24C08(MT8)@TSSOP8
NM24C08(N) [(SA602A)]	NM24C09(M8)@SOIC8
NM24C09(MT8)@TSSOP8 [(SA026)] (N)	NM24C09
NM24C16(M8)@SOIC8 [(SA602A)] [(SA026)]	NM24C16(MT8)@TSSOP8
NM24C16(N) [(SA602A)]	NM24C17(M8)@SOIC8
NM24C17(MT8)@TSSOP8 [(SA026)] (N)	NM24C17
NM24C65(M8)SOIC8 [(SA602A)] (N)	NM24C65
NM27C010 [(SA015A1T)]	NM27C010@PLCC32
NM27C010@TSOP32 [(SA410T)]	
NM27C020 [(SA015A1T)]	NM27C020@TSOP32
NM27C020@PLCC32 [(SA410T)]	
NM27C020Q [(SA015A1T)]	NM27C020Q@PLCC32
NM27C020Q@TSOP32 [(SA410T)]	
NM27C040 [(SA015A1T)]	NM27C040@TSOP32
NM27C040@PLCC32 [(SA410T)]	
NM27C128 [(SA015A1T)]	NM27C128@PLCC32
NM27C210 [(SA244)]	NM27C210@PLCC44
NM27C240 [(SA244)]	NM27C240@PLCC44
NM27C256 [(SA015A1T)]	NM27C256@PLCC32
NM27C512 [(SA015A1T)]	NM27C512@PLCC32
NM27C64Q [(SA015A1T)]	NM27C64Q@PLCC32
NM27LC256	NM27LC256@PLCC32

[(SA015A1T)]	
NM27LC512	NM27LC512@PLCC32
[(SA015A1T)]	
NM27LV010	NM27LV010@PLCC32
[(SA015A1T)]	
NM27LV010@TSOP32 [(SA410T)]	
NM27LV210	
NM27LV210@PLCC44 [(SA244)]	
NM27LV512	
NM27LV512@PLCC32 [(SA015A1T)]	
NM27P040	
NM27P040@PLCC32 [(SA015A1T)]	NM27P040@TSOP32
[(SA410T)]	
NM27P210	NM27P210@PLCC44
[(SA244)]	
NM27P512	NM27P512@PLCC32
[(SA015A1T)]	
NM93C66(M8)(16bit)@SOIC8 [(SA602A)]	
NM93C66(MT8)(16bit)@TSSOP8 [(SA026)]	
NM93C66(N)(16bit)	NM93CS06(M8)@SOIC8
[(SA602A)]	
NM93CS06(MT8)@TSSOP8 [(SA026)]	NM93CS06
(N)	
NM93CS46(M8)@SOIC8 [(SA602A)]	NM93CS46(MT8)@TSSOP8
[(SA026)]	
NM93CS46(N)	NM93CS56(M8)@SOIC8
[(SA602A)]	
NM93CS56(MT8)@TSSOP8 [(SA026)]	NM93CS56
(N)	
NM93CS66(M8)@SOIC8 [(SA602A)]	NM93CS66(MT8)@TSSOP8
[(SA026)]	
NM93CS66(N)	
NMC2732	
NMC27C010	NMC27C010@PLCC32
[(SA015A1T)]	
NMC27C010@TSOP32 [(SA410T)]	
NMC27C1024	
NMC27C1024@PLCC44 [(SA244)]	
NMC27C128B	
NMC27C128B@PLCC32 [(SA015A1T)]	
NMC27C128BN	
NMC27C128BN@PLCC32 [(SA015A1T)]	
NMC27C128BQ	

NMC27C128BQ@PLCC32 [(SA015A1T)]
NMC27C128CQ
NMC27C16
NMC27C16BQ
NMC27C16BQE
NMC27C16H
NMC27C16HQ
NMC27C16Q
NMC27C256 NMC27C256@PLCC32
[(SA015A1T)]
NMC27C256B NMC27C256B@PLCC32
[(SA015A1T)]
NMC27C256Q NMC27C256Q@PLCC32
[(SA015A1T)]
NMC27C32
NMC27C32B
NMC27C32BQ
NMC27C32E
NMC27C32EH
NMC27C32H
NMC27C512 NMC27C512@PLCC32
[(SA015A1T)]
NMC27C512A NMC27C512A@PLCC32
[(SA015A1T)]
NMC27C512AN NMC27C512AN@PLCC32
[(SA015A1T)]
NMC27C64 NMC27C64
(BN)
NMC27C64(N)
NMC27CP128
NMC87C257Q NMC87C257Q@PLCC32
[(SA015A1T)]
NMC87C257V NMC87C257V@PLCC32
[(SA015A1T)]
NMC9346(M8)(16bit)@SOIC8 [(SA602A)]
NMC9346(MT8)(16bit)@TSSOP8 [(SA026)]
NMC9346(N)(16bit)
NMC93C46(M8)(16bit)@SOIC8 [(SA602A)]
NMC93C46(MT8)(16bit)@TSSOP8 [(SA026)]
NMC93C46(N)(16bit)
NMC93C46A(M8)(16bit)@SOIC8 [(SA602A)]
NMC93C46A(MT8)(16bit)@TSSOP8 [(SA026)]
NMC93C46A(N)(16bit)

NMC93C56(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C56(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C56(N)(16bit)	
NMC93C66(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C66(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C66(N)(16bit)	NMC93CS06(M8)@SOIC8
[(SA602A)]	
NMC93CS06(MT8)@TSSOP8 [(SA026)]	NMC93CS06
(N)	
NMC93CS46(M8)@SOIC8 [(SA602A)]	NMC93CS46(MT8)@TSSOP8
[(SA026)]	
NMC93CS46(N)	NMC93CS56(M8)@SOIC8
[(SA602A)]	
NMC93CS56(MT8)@TSSOP8 [(SA026)]	NMC93CS56
(N)	
NMC93CS66(M8)@SOIC8 [(SA602A)]	NMC93CS66(MT8)@TSSOP8
[(SA026)]	
NMC93CS66(N)	
NMC9817	

DRAM & SRAM

F1600	F1600@SOJ24
[(SA646)]	
F1601	F1601@SOJ24
[(SA646)]	
F1620	
F1621	

MICROCONTROLLER

ACE1001(M8)@SOIC8 [(SA602A)]	ACE1001(M8X)@SOIC8
[(SA602A)]	
ACE1001(MT8)@TSSOP8 [(SA026)]	ACE1001(MT8X)@TSSOP8
[(SA026)]	
ACE1001E(M8)@SOIC8 [(SA602A)]	ACE1001E(M8X)@SOIC8
[(SA602A)]	
ACE1001E(MT8)@TSSOP8 [(SA026)]	ACE1001E(MT8X)@TSSOP8
[(SA026)]	
ACE1001L(M8)@SOIC8 [(SA602A)]	ACE1001L(M8X)@SOIC8
[(SA602A)]	

ACE1001L(MT8)@TSSOP8 [(SA026)]	ACE1001L(MT8X)@TSSOP8
[(SA026)]	
ACE1101(EMT8)@TSSOP8 [(SA026)]	ACE1101(EMT8X)@TSSOP8
[(SA026)]	
ACE1101(EN)	ACE1101
(EN14)	
ACE1101(LMT8)@TSSOP8 [(SA026)]	ACE1101(LMT8X)@TSSOP8
[(SA026)]	
ACE1101(LN)	ACE1101
(LN14)	
ACE1101(MT8)@TSSOP8 [(SA026)]	ACE1101(MT8X)@TSSOP8
[(SA026)]	
ACE1101(N)	ACE1101
(N14)	
ACE1101(VMT8)@TSSOP8 [(SA026)]	ACE1101(VMT8X)@TSSOP8
[(SA026)]	
ACE1101(VN)	ACE1101
(VN14)	
ACE1101B(EMT8)@TSSOP8 [(SA026)]	ACE1101B(EMT8X)@TSSOP8
[(SA026)]	
ACE1101B(EN)	ACE1101B
(EN14)	
ACE1101B(MT8)@TSSOP8 [(SA026)]	ACE1101B(MT8X)@TSSOP8
[(SA026)]	
ACE1101B(N)	ACE1101B
(N14)	
ACE1101B(VMT8)@TSSOP8 [(SA026)]	ACE1101B(VMT8X)@TSSOP8
[(SA026)]	
ACE1101B(VN)	ACE1101B
(VN14)	
ACE1202(dip14)	ACE1202
(dip8)	
ACE1202(M14)@SOIC14 [(SA602)]	ACE1202(M8)@SOIC8
[(SA602A)]	
ACE12022(dip14)	ACE12022
(dip8)	
ACE12022(M14)@SOIC14 [(SA602)]	ACE12022(M8)@SOIC8
[(SA602A)]	
ACE12022B(dip14)	ACE12022B
(dip8)	
ACE12022B(M14)@SOIC14 [(SA602)]	ACE12022B(M8)@SOIC8
[(SA602A)]	
ACE12022BE(dip14)	ACE12022BE

(dip8)	
ACE12022BE(M14)@SOIC14 [(SA602)]	ACE12022BE(M8)@SOIC8
[(SA602A)]	
ACE12022BV(dip14)	ACE12022BV
(dip8)	
ACE12022BV(M14)@SOIC14 [(SA602)]	ACE12022BV(M8)@SOIC8
[(SA602A)]	
ACE12022E(dip14)	ACE12022E
(dip8)	
ACE12022E(M14)@SOIC14 [(SA602)]	ACE12022E(M8)@SOIC8
[(SA602A)]	
ACE1202B(dip14)	ACE1202B
(dip8)	
ACE1202B(M14)@SOIC14 [(SA602)]	ACE1202B(M8)@SOIC8
[(SA602A)]	
ACE1202BE(dip14)	ACE1202BE
(dip8)	
ACE1202BE(M14)@SOIC14 [(SA602)]	ACE1202BE(M8)@SOIC8
[(SA602A)]	
ACE1202BV(dip14)	ACE1202BV
(dip8)	
ACE1202BV(M14)@SOIC14 [(SA602)]	ACE1202BV(M8)@SOIC8
[(SA602A)]	
ACE1202E(dip14)	ACE1202E
(dip8)	
ACE1202E(M14)@SOIC14 [(SA602)]	ACE1202E(M8)@SOIC8
[(SA602A)]	
ACE1202L(dip14)	ACE1202L
(dip8)	
ACE1202L(M14)@SOIC14 [(SA602)]	ACE1202L(M8)@SOIC8
[(SA602A)]	
ACE1202V(dip8)	ACE1202V(M14)@SOIC14
[(SA602)]	
ACE1202V(M8)@SOIC8 [(SA602A)]	ACE1501(EM)@SOIC14
[(SA602)]	
ACE1501(EM8)@SOIC8 [(SA602A)]	ACE1501(EM8X)@SOIC8
[(SA602A)]	
ACE1501(EMT)@TSOP14 [(SA026)]	ACE1501(EMT8)@TSSOP8
[(SA026)]	
ACE1501(EMT8X)@TSSOP8 [(SA026)]	ACE1501(EMTX)@TSOP14
[(SA026)]	
ACE1501(EMX)@SOIC14 [(SA602)]	ACE1501
(EN)	

ACE1501(EN14) [(SA602)]	ACE1501(VM)@SOIC14
ACE1501(VM8)@SOIC8 [(SA602A)] [(SA602A)]	ACE1501(VM8X)@SOIC8
ACE1501(VMT)@TSOP14 [(SA026)] [(SA026)]	ACE1501(VMT8)@TSSOP8
ACE1501(VMT8X)@TSSOP8 [(SA026)] [(SA026)]	ACE1501(VMTX)@TSOP14
ACE1501(VMX)@SOIC14 [(SA602)] (VN)	ACE1501
ACE1501(VN14) [(SA602)]	ACE1502(EM)@SOIC14
ACE1502(EM8)@SOIC8 [(SA602A)] [(SA026)]	ACE1502(EMT)@TSOP14
ACE1502(EMT8)@TSSOP8 [(SA026)] (EN)	ACE1502
ACE1502(EN14) [(SA602)]	ACE1502(VM)@SOIC14
ACE1502(VM8)@SOIC8 [(SA602A)] [(SA026)]	ACE1502(VMT)@TSOP14
ACE1502(VMT8)@TSSOP8 [(SA026)] (VN)	ACE1502
ACE1502(VN14) [(SA602A)]	ACE8000(M8)@SOIC8
ACE8000(M8X)@SOIC8 [(SA602A)] [(SA602A)]	ACE8000E(M8)@SOIC8
ACE8000E(M8X)@SOIC8 [(SA602A)] [(SA602A)]	ACE8001(M8)@SOIC8
ACE8001(M8X)@SOIC8 [(SA602A)] [(SA026)]	ACE8001(MT8)@TSSOP8
ACE8001(MT8X)@TSSOP8 [(SA026)] [(SA602A)]	ACE8001E(M8)@SOIC8
ACE8001E(M8X)@SOIC8 [(SA602A)] [(SA026)]	ACE8001E(MT8)@TSSOP8
ACE8001E(MT8X)@TSSOP8 [(SA026)] [(SA602A)]	FMS7401L(EM8X)@SOIC8
FMS7401L(EMT8X)@TSSOP8 [(SA026)] [(SA026)]	FMS7401L(EMTX)@TSSOP14
FMS7401L(EMX)@SOIC14 [(SA602)] (EN)	FMS7401L
FMS7401L(EN14) (VN)	FMS7401L
FMS7401L(VN14)	

FORCE TECHNOLOGIES

E (E) PROM / FRAM / NVRAM

FT24C01 [(SA602A)] FT24C01@TSOP8 [(SA026)] FT24C01A FT24C01A@SOIC8 [(SA602A)] [(SA026)]	FT24C01@SOIC8 FT24C01A@TSOP8
FT24C02 [(SA602A)] FT24C02@TSSOP8 [(SA026)] FT24C02A FT24C02A@SOP8 [(SA602A)] [(SA026)]	FT24C02@SOP8 FT24C02A@TSSOP8
FT24C04 [(SA602A)] FT24C04@TSSOP8 [(SA026)] FT24C04A FT24C04A@SOP8 [(SA602A)] [(SA026)]	FT24C04@SOP8 FT24C04A@TSSOP8
FT24C08 [(SA602A)] FT24C08@TSOP8 [(SA026)] FT24C08A FT24C08A@SOIC8 [(SA602A)] [(SA026)]	FT24C08@SOIC8 FT24C08A@TSOP8
FT24C128 [(SA602A)] FT24C128@TSOP8 [(SA026)] FT24C128A FT24C128A@SOIC8 [(SA602A)] [(SA026)]	FT24C128@SOIC8 FT24C128A@TSOP8
FT24C16 [(SA602A)] FT24C16@TSOP8 [(SA026)] FT24C16A FT24C16A@SOIC8 [(SA602A)] [(SA026)]	FT24C16@SOIC8 FT24C16A@TSOP8
FT24C256	FT24C256@SOIC8

[(SA602A)]	
FT24C256@TSOP8 [(SA026)]	
FT24C256A	
FT24C256A@SOIC8 [(SA602A)]	FT24C256A@TSOP8
[(SA026)]	
FT24C32	FT24C32@SOIC8
[(SA602A)]	
FT24C32@TSOP8 [(SA026)]	
FT24C32A	
FT24C32A@SOIC8 [(SA602A)]	FT24C32A@TSOP8
[(SA026)]	
FT24C64	FT24C64@SOIC8
[(SA602A)]	
FT24C64@TSOP8 [(SA026)]	
FT24C64A	
FT24C64A@SOIC8 [(SA602A)]	FT24C64A@TSOP8
[(SA026)]	
FT27C010	FT27C010@PLCC32
[(SA015A1T)]	
FT27C010@TSOP32 [(SA410T)]	
FT27C020	
FT27C020@PLCC32 [(SA015A1T)]	FT27C020@TSOP32
[(SA410T)]	
FT27C040	FT27C040@PLCC32
[(SA015A1T)]	
FT27C040@TSOP32 [(SA410T)]	
FT27C16	
FT27C256	FT27C256@PLCC32
[(SA015A1T)]	
FT27C64	FT27C64@PLCC32
[(SA015A1T)]	
FT27HC256	FT27HC256@PLCC32
[(SA015A1T)]	
FT27HC64	FT27HC64@PLCC32
[(SA015A1T)]	
FT28C010	FT28C010@JLCC32
[(SA412A)]	
FT28C010@PLCC32 [(SA015A1T)]	FT28C010@PLCC44
[(SA244)]	
FT28C010@TSOP32 [(SA410T)]	
FT28C010E	
FT28C010E@JLCC32 [(SA412A)]	FT28C010E@PLCC32
[(SA015A1T)]	

FT28C010E@PLCC44 [(SA244)]	FT28C010E@TSOP32
[(SA410T)]	
FT28C020	FT28C020@JLCC32
[(SA412A)]	
FT28C020@PLCC32 [(SA015A1T)]	FT28C020@PLCC44
[(SA244)]	
FT28C020@TSOP32 [(SA410T)]	
FT28C040	
FT28C040@JLCC32 [(SA412A)]	FT28C040@PLCC32
[(SA015A1T)]	
FT28C040@PLCC44 [(SA244)]	FT28C040@TSOP32
[(SA410T)]	
FT28C16	FT28C16@PLCC32
[(SA015A1T)]	
FT28C256	FT28C256@JLCC32
[(SA412A)]	
FT28C256@PLCC32 [(SA015A1T)]	FT28C256@SOIC28
[(SA404)]	
FT28C256@TSOP28 [(SA430T)]	
FT28C256B	
FT28C256B@JLCC32 [(SA412A)]	FT28C256B@PLCC32
[(SA015A1T)]	
FT28C256B@SOIC28 [(SA404)]	FT28C256B@TSOP28
[(SA430T)]	
FT28C64	FT28C64@PLCC32
[(SA015A1T)]	
FT28C64@SOIC28 [(SA404)]	FT28C64@TSOP28
[(SA430T)]	
FT28C64B	FT28C64B@JLCC32
[(SA412A)]	
FT28C64B@PLCC32 [(SA015A1T)]	FT28C64B@SOIC28
[(SA404)]	
FT28C64B@TSOP28 [(SA430T)]	
FT28C64X	
FT28C64X@PLCC32 [(SA015A1T)]	FT28C64X@SOIC28
[(SA404)]	
FT28C64X@TSOP28 [(SA430T)]	
FT28HC64	
FT28HC64@PLCC32 [(SA015A1T)]	FT28HC64@TSOP28
[(SA430T)]	
FT58C1001	FT58C1001@SSOP32
[(SA438T)]	
FT58C1001@VSOP32 [(SA620)]	

FORWARD

E (E) PROM / FRAM / NVRAM

24LC01 [(SA602A)]	24LC01@SOIC8
24LC02 [(SA602A)]	24LC02@SOIC8
24LC04 [(SA602A)]	24LC04@SOIC8
24LC08 [(SA602A)]	24LC08@SOIC8
24LC16 [(SA602A)]	24LC16@SOIC8
24LC32 [(SA602A)]	24LC32@SOIC8
24LC64 [(SA602A)]	24LC64@SOIC8

FREESCALE

MICROCONTROLLER

MC56F8011VFAE@QFP32	[(SA663+B005)]
MC56F8013VFAE@QFP32	[(SA663+B005)]
MC56F8014VFAE@QFP32	[(SA663+B005)]
MC56F8023MFAE@QFP32	[(SA663+B005)]
MC56F8023VFAE@QFP32	[(SA663+B005)]
MC56F8025VLD@QFP44	[(SA245A+B005)]
MC56F8036MFAE@QFP48	[(SA248+B005)]
MC56F8036VFAE@QFP48	[(SA248+B005)]
MC56F8037VLH@QFP64	[(PEP+S616)]
MC68HC908AP16CB(S)@SDIP42	[(SA028)]
MC68HC908AP16CB@SDIP42	[(SA028)]
MC68HC908AP16CFA(S)@LQFP48	[(SA248)]
MC68HC908AP16CFA@LQFP48	[(SA248)]
MC68HC908AP16CFB(S)@TQFP44	[(SA675)]
MC68HC908AP16CFB@TQFP44	[(SA675)]
MC68HC908AP32CB(S)@SDIP42	[(SA028)]

MC68HC908AP32CB@SDIP42 [(SA028)]
MC68HC908AP32CFA(S)@LQFP48 [(SA248)]
MC68HC908AP32CFA@LQFP48 [(SA248)]
MC68HC908AP32CFB(S)@TQFP44 [(SA675)]
MC68HC908AP32CFB@TQFP44 [(SA675)]
MC68HC908AP64CB@SDIP42 [(SA028)]
MC68HC908AP64CFA@LQFP48 [(SA248)]
MC68HC908AP64CFB@TQFP44 [(SA675)]
MC68HC908AP8CB(S)@SDIP42 [(SA028)]
MC68HC908AP8CB@SDIP42 [(SA028)]
MC68HC908AP8CFA(S)@@LQFP48 [(SA248)]
MC68HC908AP8CFA@@LQFP48 [(SA248)]
MC68HC908AP8CFB(S)@TQFP44 [(SA675)]
MC68HC908AP8CFB@TQFP44 [(SA675)]
MC68HC908EY16CFA@TQFP32 [(SA663)]
MC68HC908EY16MFA@TQFP32 [(SA663)]
MC68HC908EY16VFA@TQFP32 [(SA663)]
MC68HC908EY8CFA@TQFP32 [(SA663)] MC68HC908EY8MFA@TQFP32
[(SA663)]
MC68HC908EY8VFA@TQFP32 [(SA663)]
MC68HC908GP32
MC68HC908GP32@SDIP42 [(SA028)] MC68HC908GP32@TQFP44
[(SA675)]
MC68HC908GR16CFA@TQFP48 [(SA248)]
MC68HC908GR16CFJ@TQFP32 [(SA663)]
MC68HC908GR16MFA@TQFP48 [(SA248)]
MC68HC908GR16MFJ@TQFP32 [(SA663)]
MC68HC908GR16VFA@TQFP48 [(SA248)]
MC68HC908GR16VFJ@TQFP32 [(SA663)]
MC68HC908GR4CDW@SOIC28 [(SA404)] MC68HC908GR4CFA@TQFP32
[(SA663)]
MC68HC908GR4CP MC68HC908GR4MDW@SOIC28
[(SA404)]
MC68HC908GR4MFA@TQFP32 [(SA663)]
MC68HC908GR4MP
MC68HC908GR4VDW@SOIC28 [(SA404)] MC68HC908GR4VFA@TQFP32
[(SA663)]
MC68HC908GR4VP MC68HC908GR8CDW@SOIC28
[(SA404)]
MC68HC908GR8CFA@TQFP32 [(SA663)]
MC68HC908GR8CP
MC68HC908GR8MDW@SOIC28 [(SA404)] MC68HC908GR8MFA@TQFP32
[(SA663)]

MC68HC908GR8MP
[(SA404)]
MC68HC908GR8VFA@TQFP32 [(SA663)]
MC68HC908GR8VP
MC68HC908JK1CDW@SOIC20 [(SA404)]
MC68HC908JK1CP
MC68HC908JK1ECDW@SOIC20 [(SA404)]
MC68HC908JK1ECP
MC68HC908JK1EMDW@SOIC20 [(SA404)]
MC68HC908JK1EMP
[(SA404)]
MC68HC908JK1MP
[(SA404)]
MC68HC908JK3CP
MC68HC908JK3ECDW@SOIC20 [(SA404)]
MC68HC908JK3ECP
MC68HC908JK3EMDW@SOIC20 [(SA404)]
MC68HC908JK3EMP
[(SA404)]
MC68HC908JK3MP
[(SA404)]
MC68HC908JL3CFA@TQFP48 [(SA248)]
MC68HC908JL3CP
MC68HC908JL3ECDW@SOIC28 [(SA404)]
MC68HC908JL3ECFA@TQFP48 [(SA248)]
MC68HC908JL3ECP
MC68HC908JL3EMDW@SOIC28 [(SA404)]
MC68HC908JL3EMFA@TQFP48 [(SA248)]
MC68HC908JL3EMP
[(SA404)]
MC68HC908JL3MFA@TQFP48 [(SA248)]
MC68HC908JL3MP
MC68HC908LB8CDWE (S)@SOIC20
(S)
MC68HC908LB8MDWE (S)@SOIC20
(S)
MC68HC908LB8VDWE (S)@SOIC20
(S)
MC68HC908QT1CDW@SOIC8 [(SA605A)]
MC68HC908QT1CP
MC68HC908QT1MDW@SOIC8 [(SA605A)]
MC68HC908QT1MP
MC68HC908QT1VDW@SOIC8 [(SA605A)]

MC68HC908GR8VDW@SOIC28

MC68HC908JK1MDW@SOIC20

MC68HC908JK3CDW@SOIC20

MC68HC908JK3MDW@SOIC20

MC68HC908JL3CDW@SOIC28

MC68HC908JL3MDW@SOIC28

MC68HC908LB8CPE

MC68HC908LB8MPE

MC68HC908LB8VPE

MC68HC908QT1VP
MC68HC908QT2CDW@SOIC8 [(SA605A)]
MC68HC908QT2CP
MC68HC908QT2MDW@SOIC8 [(SA605A)]
MC68HC908QT2MP
MC68HC908QT2VDW@SOIC8 [(SA605A)]
MC68HC908QT2VP
MC68HC908QT4CDW@SOIC8 [(SA605A)]
MC68HC908QT4CP
MC68HC908QT4MDW@SOIC8 [(SA605A)]
MC68HC908QT4MP
MC68HC908QT4VDW@SOIC8 [(SA605A)]
MC68HC908QT4VP
MC68HC908QY1CDT@TSSOP16 [(SA026)]
MC68HC908QY1CDW@SOIC16 [(SA404)]
MC68HC908QY1CP
MC68HC908QY1MDT@TSSOP16 [(SA026)]
MC68HC908QY1MDW@SOIC16 [(SA404)]
MC68HC908QY1MP
MC68HC908QY1VDT@TSSOP16 [(SA026)]
MC68HC908QY1VDW@SOIC16 [(SA404)]
MC68HC908QY1VP
MC68HC908QY2CDT@TSSOP16 [(SA026)]
MC68HC908QY2CDW@SOIC16 [(SA404)]
MC68HC908QY2CP
MC68HC908QY2MDT@TSSOP16 [(SA026)]
MC68HC908QY2MDW@SOIC16 [(SA404)]
MC68HC908QY2MP
MC68HC908QY2VDT@TSSOP16 [(SA026)]
MC68HC908QY2VDW@SOIC16 [(SA404)]
MC68HC908QY2VP
MC68HC908QY4CDT@TSSOP16 [(SA026)]
MC68HC908QY4CDW@SOIC16 [(SA404)]
MC68HC908QY4CP
MC68HC908QY4MDT@TSSOP16 [(SA026)]
MC68HC908QY4MDW@SOIC16 [(SA404)]
MC68HC908QY4MP
MC68HC908QY4VDT@TSSOP16 [(SA026)]
MC68HC908QY4VDW@SOIC16 [(SA404)]
MC68HC908QY4VP
MC68HRC908JK1CDW@SOIC20 [(SA404)]
MC68HRC908JK1CP
MC68HRC908JK1ECDW@SOIC20 [(SA404)]

MC68HRC908JK1ECP
MC68HRC908JK1EMDW@SOIC20 [(SA404)]
MC68HRC908JK1EMP
MC68HRC908JK1MDW@SOIC20 [(SA404)]
MC68HRC908JK1MP
MC68HRC908JK3CDW@SOIC20 [(SA404)]
MC68HRC908JK3CP
MC68HRC908JK3ECDW@SOIC20 [(SA404)]
MC68HRC908JK3ECP
MC68HRC908JK3EMDW@SOIC20 [(SA404)]
MC68HRC908JK3EMP
MC68HRC908JK3MDW@SOIC20 [(SA404)]
MC68HRC908JK3MP
MC68HRC908JL3CDW@SOIC28 [(SA404)]
MC68HRC908JL3CFA@TQFP48 [(SA248)]
MC68HRC908JL3CP
MC68HRC908JL3ECDW@SOIC28 [(SA404)]
MC68HRC908JL3ECFA@TQFP48 [(SA248)]
MC68HRC908JL3ECP
MC68HRC908JL3EMDW@SOIC28 [(SA404)]
MC68HRC908JL3EMFA@TQFP48 [(SA248)]
MC68HRC908JL3EMP
MC68HRC908JL3MDW@SOIC28 [(SA404)]
MC68HRC908JL3MFA@TQFP48 [(SA248)]
MC68HRC908JL3MP
[(SA028)]
MC908AP16CFAE@LQFP48 [(SA248)]
[(SA675)]
MC908AP32CBE@SDIP42 [(SA028)]
[(SA248)]
MC908AP32CFBE@TQFP44 [(SA675)]
[(SA028)]
MC908AP64CFAE@LQFP48 [(SA248)]
[(SA675)]
MC908AP8CBE@SDIP42 [(SA028)]
[(SA248)]
MC908AP8CFBE@TQFP44 [(SA675)]
[(SA663)]
MC908EY16AKFJE@TQFP32 [(SA663)]
[(SA663)]
MC908EY16AVFJE@TQFP32 [(SA663)]
[(SA663)]
MC908EY8AKFJE@TQFP32 [(SA663)]

MC908AP16CBE@SDIP42
MC908AP16CFBE@TQFP44
MC908AP32CFAE@LQFP48
MC908AP64CBE@SDIP42
MC908AP64CFBE@TQFP44
MC908AP8CFAE@@@LQFP48
MC908EY16ACFJE@TQFP32
MC908EY16AMFJE@TQFP32
MC908EY8ACFJE@TQFP32
MC908EY8AMFJE@TQFP32

[(SA663)]		
MC908EY8AVFJE@TQFP32 [(SA663)]		MC908JL16CDWE@SOIC28
[(SA404)]		
MC908JL16CFJE@LQFP32 [(SA663)]		
MC908JL16CPE		
MC908JL16CSPE@SDIP32 [(SA653)]		MC908QT1ACDWE@SOIC8
[(SA605A)]		
MC908QT1ACPE		MC908QT1AMDWE@SOIC8
[(SA605A)]		
MC908QT1AMPE		MC908QT1AVDWE@SOIC8
[(SA605A)]		
MC908QT1AVPE		MC908QT2ACDWE@SOIC8
[(SA605A)]		
MC908QT2ACPE		MC908QT2AMDWE@SOIC8
[(SA605A)]		
MC908QT2AMPE		MC908QT2AVDWE@SOIC8
[(SA605A)]		
MC908QT2AVPE		MC908QT4ACDWE@SOIC8
[(SA605A)]		
MC908QT4ACPE		MC908QT4AMDWE@SOIC8
[(SA605A)]		
MC908QT4AMPE		MC908QT4AVDWE@SOIC8
[(SA605A)]		
MC908QT4AVPE		MC908QY1ACDTE@TSSOP16
[(SA026)]		
MC908QY1ACDWE@SOIC16 [(SA404)]		
MC908QY1ACPE		
MC908QY1AMDTE@TSSOP16 [(SA026)]		MC908QY1AMDWE@SOIC16
[(SA404)]		
MC908QY1AMPE		MC908QY1AVDTE@TSSOP16
[(SA026)]		
MC908QY1AVDWE@SOIC16 [(SA404)]		
MC908QY1AVPE		
MC908QY2ACDTE@TSSOP16 [(SA026)]		MC908QY2ACDWE@SOIC16
[(SA404)]		
MC908QY2ACPE		MC908QY2AMDTE@TSSOP16
[(SA026)]		
MC908QY2AMDWE@SOIC16 [(SA404)]		
MC908QY2AMPE		
MC908QY2AVDTE@TSSOP16 [(SA026)]		MC908QY2AVDWE@SOIC16
[(SA404)]		
MC908QY2AVPE		MC908QY4ACDTE@TSSOP16
[(SA026)]		

MC908QY4ACDWE@SOIC16 [(SA404)]
MC908QY4ACPE
MC908QY4AMDTE@TSSOP16 [(SA026)] MC908QY4AMDWE@SOIC16
[(SA404)]
MC908QY4AMPE MC908QY4AVDTE@TSSOP16
[(SA026)]
MC908QY4AVDWE@SOIC16 [(SA404)]
MC908QY4AVPE
MC9S08GT16ACB@SDIP42 [(SA028-B167)]
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]
MC9S08GT16ACFD@QFN48 [(SA696-B166)]
MC9S08GT16AMB@SDIP42 [(SA028-B167)]
MC9S08GT16AMFB@LQFP44 [(SA675-B168)]
MC9S08GT16AMFD@QFN48 [(SA696-B166)]
MC9S08GT16CB@SDIP42 [(SA028-B167)]
MC9S08GT16CBE@SDIP42 [(SA028-B167)]
MC9S08GT16CFB@LQFP44 [(SA675-B168)]
MC9S08GT16CFBE@LQFP44 [(SA675-B168)]
MC9S08GT16CFD@QFN48 [(SA696-B166)]
MC9S08GT16CFDE@QFN48 [(SA696-B166)]
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]
MC9S08GT32ACFD@QFN48 [(SA696-B166)]
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]
MC9S08GT32CB@SDIP42 [(SA028-B167)]
MC9S08GT32CBE@SDIP42 [(SA028-B167)]
MC9S08GT32CFB@LQFP44 [(SA675-B168)]
MC9S08GT32CFBE@LQFP44 [(SA675-B168)]
MC9S08GT32CFD@QFN48 [(SA696-B166)]
MC9S08GT32CFDE@QFN48 [(SA696-B166)]
MC9S08GT8ACB@SDIP42 [(SA028-B167)]
MC9S08GT8ACFB@LQFP44 [(SA675-B168)]
MC9S08GT8ACFD@QFN48 [(SA696-B166)]
MC9S08GT8AMB@SDIP42 [(SA028-B167)]
MC9S08GT8AMFB@LQFP44 [(SA675-B168)]
MC9S08GT8AMFD@QFN48 [(SA696-B166)]
PC56F8011VFAE@QFP32 [(SA663+B005)]
PC56F8013VFAE@QFP32 [(SA663+B005)]
PC56F8014VFAE@QFP32 [(SA663+B005)]

Fremont Micro Devices

E (E) PROM / FRAM / NVRAM

FT24C02	FT24C02@SOP8
[(SA602A)]	
FT24C02@TSSOP8 [(SA026)]	
FT24C02A	
FT24C02A@SOP8 [(SA602A)]	FT24C02A@TSSOP8
[(SA026)]	
FT24C04	FT24C04@SOP8
[(SA602A)]	
FT24C04@TSSOP8 [(SA026)]	
FT24C04A	
FT24C04A@SOP8 [(SA602A)]	FT24C04A@TSSOP8
[(SA026)]	
FT24C08	FT24C08@SOP8
[(SA602A)]	
FT24C08@TSSOP8 [(SA026)]	
FT24C08A	
FT24C08A@SOP8 [(SA602A)]	FT24C08A@TSSOP8
[(SA026)]	
FT24C1024	FT24C1024@SOP8
[(SA023A)]	
FT24C1024@TSSOP8 [(SA026)]	
FT24C1024A	
FT24C1024A@SOP8 [(SA023A)]	FT24C1024A@TSSOP8
[(SA026)]	
FT24C128	FT24C128@SOP8
[(SA602A)]	
FT24C128@TSSOP8 [(SA026)]	
FT24C128A	
FT24C128A@SOP8 [(SA602A)]	FT24C128A@TSSOP8
[(SA026)]	
FT24C16	FT24C16@SOP8
[(SA602A)]	
FT24C16@TSSOP8 [(SA026)]	
FT24C16A	
FT24C16A@SOP8 [(SA602A)]	FT24C16A@TSSOP8
[(SA026)]	
FT24C256	FT24C256@SOP8
[(SA602A)]	
FT24C256@TSSOP8 [(SA026)]	
FT24C256A	
FT24C256A@SOP8 [(SA602A)]	FT24C256A@TSSOP8

[(SA026)]	
FT24C32	FT24C32@SOP8
[(SA602A)]	
FT24C32@TSSOP8 [(SA026)]	
FT24C32A	
FT24C32A@SOP8 [(SA602A)]	FT24C32A@TSSOP8
[(SA026)]	
FT24C512	FT24C512@SOP8
[(SA602A)]	
FT24C512@TSSOP8 [(SA026)]	
FT24C512A	
FT24C512A@SOP8 [(SA602A)]	FT24C512A@TSSOP8
[(SA026)]	
FT24C64	FT24C64@SOP8
[(SA602A)]	
FT24C64@TSSOP8 [(SA026)]	
FT24C64A	
FT24C64A@SOP8 [(SA602A)]	FT24C64A@TSSOP8
[(SA026)]	
FT34C02	FT34C02@SOP8
[(SA602A)]	
FT34C02@TSSOP8 [(SA026)]	
FT34C02A	
FT34C02A@SOP8 [(SA602A)]	FT34C02A@TSSOP8
[(SA026)]	
FT93C46(08bit)	FT93C46(08bit)@SOP8
[(SA602A)]	
FT93C46(08bit)@TSSOP8 [(SA026)]	FT93C46
(16bit)	
FT93C46(16bit)@SOP8 [(SA602A)]	FT93C46(16bit)@TSSOP8
[(SA026)]	
FT93C46A(08bit)	FT93C46A(08bit)@SOP8
[(SA602A)]	
FT93C46A(08bit)@TSSOP8 [(SA026)]	FT93C46A
(16bit)	
FT93C46A(16bit)@SOP8 [(SA602A)]	FT93C46A(16bit)@TSSOP8
[(SA026)]	
FT93C56(08bit)	FT93C56(08bit)@SOP8
[(SA602A)]	
FT93C56(08bit)@TSSOP8 [(SA026)]	FT93C56
(16bit)	
FT93C56(16bit)@SOP8 [(SA602A)]	FT93C56(16bit)@TSSOP8
[(SA026)]	

FT93C56A(08bit) [(SA602A)]	FT93C56A(08bit)@SOP8
FT93C56A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C56A
FT93C56A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C56A(16bit)@TSSOP8
FT93C66(08bit) [(SA602A)]	FT93C66(08bit)@SOP8
FT93C66(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C66
FT93C66(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C66(16bit)@TSSOP8
FT93C66A(08bit) [(SA602A)]	FT93C66A(08bit)@SOP8
FT93C66A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C66A
FT93C66A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C66A(16bit)@TSSOP8
FT93C86(08bit) [(SA602A)]	FT93C86(08bit)@SOP8
FT93C86(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C86
FT93C86(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C86(16bit)@TSSOP8
FT93C86A(08bit) [(SA602A)]	FT93C86A(08bit)@SOP8
FT93C86A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C86A
FT93C86A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C86A(16bit)@TSSOP8

FUJITSU

E(E) PROM/FRAM/NVRAM

MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21082@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21082EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21083@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21083EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21084@FBGA61 [(SA642C-B032A-Y056F001)]

MB84VD21084EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21091@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21091EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21092@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21092EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21093@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21093EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21094@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21094EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21181DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21181EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21181EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21182DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21182EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21182EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21183DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21183EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21183EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21184DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21184EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21184EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21191DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21191EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21191EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21192DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21192EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21192EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21193DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21193EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21193EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21194DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21194EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21194EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD22180FA@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22180FM@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22181A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22181EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22181EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22181FM@FBGA56 [(SA642F-B032A-T064F001)]
MB84VD22182A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22182EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22182EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22183A@FBGA77 [(SA642A-B032A-Y096N001)]

MB84VD22183EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22183EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22184A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22184EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22184EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22184FM@FBGA56 [(SA642E-B032A-T072F001)]
MB84VD22190FA@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22190FM@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22191A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22191EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22191EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22191FM@FBGA56 [(SA642F-B032A-T064F001)]
MB84VD22192A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22192EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22192EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22193A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22193EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22193EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22194A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22194EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22194EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22194FM@FBGA56 [(SA642E-B032A-T072F001)]
MB84VD22280FE@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22282EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22283EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22284EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22290FM@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22292EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22293EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22294EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22386EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22387EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22388EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22396EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22397EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22398EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD23180FM@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD23280EA@FBGA101 [(SA642A-B032A-Y096N001)]
MB84VD23280EE@FBGA101 [(SA642A-B032A-Y096N001)]
MB84VD23280FA@FBGA65 [(SA642A-B032A-Y096N001)]
MB84VD23381EJ@FBGA101 [(SA642A-B032A-Y096N001)]
MB84VD23381FJ@FBGA65 [(SA642A-B032A-Y096N001)]
MB84VD23381HJ@FBGA56 [(SA642F-B032A-T064F001)]

MB84VD23481FJ@FBGA65 [(SA642A-B032A-Y096N001)]
MB84VF5F5FF4J2@BGA107 [(SA642D-B062A-Y088F001)]
MB84VP23481FK@FBGA65 [(SA642JJ-B032A-W064F001Y)]
MB84VP24481HK@FBGA73 [(SA642A-B039A-Y096F001)]
MB84VP24491HK@FBGA73 [(SA642A-B039A-Y096F001)]
MB85R256@SOP28 [(SA630)] MB85R256@TSOP28
[(SA430T)]
MB85R256A@SOP28 [(SA630)] MB85R256A@TSOP28
[(SA430T)]
MBM271001 MBM271001@PLCC32
[(SA015A1T)]
MBM271001@TSOP32 [(SA410T)]
MBM27128
MBM27128@PLCC32 [(SA015A1T)]
MBM2716
MBM2716H
MBM27256
MBM27256@PLCC32 [(SA015A1T)]
MBM2732
MBM2732A
MBM2764
MBM2764@PLCC32 [(SA015A1T)]
MBM27C1000
MBM27C1000@PLCC32 [(SA015A1T)] MBM27C1000@TSOP32
[(SA410T)]
MBM27C1001 MBM27C1001@PLCC32
[(SA015A1T)]
MBM27C1001@TSOP32 [(SA410T)]
MBM27C1024
MBM27C1024@PLCC44 [(SA244)]
MBM27C1028
MBM27C1028@PLCC32 [(SA015A1T)]
MBM27C128
MBM27C128@PLCC32 [(SA015A1T)]
MBM27C128P
MBM27C128P@PLCC32 [(SA015A1T)]
MBM27C2000
MBM27C2000@PLCC32 [(SA015A1T)] MBM27C2000@TSOP32
[(SA410T)]
MBM27C2001 MBM27C2001@PLCC32
[(SA015A1T)]
MBM27C2001@TSOP32 [(SA410T)]
MBM27C2048

MBM27C256 MBM27C256@PLCC32
[(SA015A1T)]
MBM27C256A MBM27C256A@PLCC32
[(SA015A1T)]
MBM27C256AP MBM27C256AP@PLCC32
[(SA015A1T)]
MBM27C256H MBM27C256H@PLCC32
[(SA015A1T)]
MBM27C32A
MBM27C4001
MBM27C4001@PLCC32 [(SA015A1T)] MBM27C4001@TSOP32
[(SA410T)]
MBM27C4096
MBM27C512
MBM27C512@PLCC32 [(SA015A1T)]
MBM27C512P
MBM27C512P@PLCC32 [(SA015A1T)]
MBM27C64
MBM27C64@PLCC32 [(SA015A1T)]
MBM28C64
MBM28C65
MBM28F010
MBM28F010@PLCC32 [(SA015A1T)] MBM28F010@TSOP32
[(SA410T)]
MBM29DL161BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL161BD@TSOP48 [(SA247-B005)]
MBM29DL161BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL161TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL161TD@TSOP48 [(SA247-B005)]
MBM29DL161TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162BD@TSOP48 [(SA247-B005)]
MBM29DL162BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162BE@TSOP48 [(SA247-B005)]
MBM29DL162TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162TD@TSOP48 [(SA247-B005)]
MBM29DL162TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162TE@TSOP48 [(SA247-B005)]
MBM29DL163BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163BD@TSOP48 [(SA247-B005)]
MBM29DL163BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163BE@TSOP48 [(SA247-B005)]
MBM29DL163TD@FBGA48 [(SA642B-B026A-Y072F001)]

MBM29DL163TD@TSOP48 [(SA247-B005)]
MBM29DL163TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163TE@TSOP48 [(SA247-B005)]
MBM29DL164BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164BD@TSOP48 [(SA247-B005)]
MBM29DL164BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164BE@TSOP48 [(SA247-B005)]
MBM29DL164TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164TD@TSOP48 [(SA247-B005)]
MBM29DL164TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164TE@TSOP48 [(SA247-B005)]
MBM29DL320BF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL320BF@TSOP48 [(SA247-B005)]
MBM29DL320TF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL320TF@TSOP48 [(SA247-B005)]
MBM29DL321BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL321BD@TSOP48 [(SA247-B005)]
MBM29DL321BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL321TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL321TD@TSOP48 [(SA247-B005)]
MBM29DL321TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL322BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL322BD@TSOP48 [(SA247-B005)]
MBM29DL322BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL322BE@TSOP48 [(SA247-B005)]
MBM29DL322TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL322TD@TSOP48 [(SA247-B005)]
MBM29DL322TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL322TE@TSOP48 [(SA247-B005)]
MBM29DL323BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL323BD@TSOP48 [(SA247-B005)]
MBM29DL323BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL323BE@TSOP48 [(SA247-B005)]
MBM29DL323BF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL323BF@TSOP48 [(SA247-B005)]
MBM29DL323TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL323TD@TSOP48 [(SA247-B005)]
MBM29DL323TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL323TE@TSOP48 [(SA247-B005)]
MBM29DL323TF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL323TF@TSOP48 [(SA247-B005)]
MBM29DL324BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL324BD@TSOP48 [(SA247-B005)]

MBM29DL324BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL324BE@TSOP48 [(SA247-B005)]
MBM29DL324TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL324TD@TSOP48 [(SA247-B005)]
MBM29DL324TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL324TE@TSOP48 [(SA247-B005)]
MBM29DL32BF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL32BF@TSOP48 [(SA247-B005)]
MBM29DL32TF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL32TF@TSOP48 [(SA247-B005)]
MBM29DL34BF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL34BF@TSOP48 [(SA247-B005)]
MBM29DL34TF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL34TF@TSOP48 [(SA247-B005)]
MBM29DL400BB@PSOP44 [(SA638-B006)]
MBM29DL400BB@TSOP48 [(SA247-B005)]
MBM29DL400BC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL400BC@PSOP44 [(SA638)]
MBM29DL400BC@TSOP48 [(SA247-B005)]
MBM29DL400BT@PSOP44 [(SA638-B006)]
MBM29DL400BT@TSOP48 [(SA247-B005)]
MBM29DL400TC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL400TC@PSOP44 [(SA638)]
MBM29DL400TC@TSOP48 [(SA247-B005)]
MBM29DL640E@FBGA63 [(SA642C-B026A-Y056F001)]
MBM29DL640E@TSOP48 [(SA247-B005)]
MBM29DL64DF@FBGA48 [(SA642F-B026A-T064F001)]
MBM29DL64DF@TSOP48 [(SA247-B005)]
MBM29DL800B@PSOP44 [(SA638-B006)]
MBM29DL800B@TSOP48 [(SA247-B005)]
MBM29DL800BA@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL800BA@TSOP48 [(SA247-B005)]
MBM29DL800BB@PSOP44 [(SA638-B006)]
MBM29DL800BB@TSOP48 [(SA247-B005)]
MBM29DL800BT@PSOP44 [(SA638-B006)]
MBM29DL800BT@TSOP48 [(SA247-B005)]
MBM29DL800T@PSOP44 [(SA638-B006)]
MBM29DL800T@TSOP48 [(SA247-B005)]
MBM29DL800TA@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL800TA@TSOP48 [(SA247-B005)]
MBM29DS163BE@FBGA48 [(SA642Z-B026A-W048F001Y)]
MBM29DS163BE@TSOP48 [(SA247-B005)]
MBM29DS163TE@FBGA48 [(SA642Z-B026A-W048F001Y)]

MBM29DS163TE@TSOP48 [(SA247-B005)]
MBM29F001B MBM29F001B@PLCC32
[(SA015A1T)]
MBM29F001B@TSOP32 [(SA410T)]
MBM29F001T MBM29F001T@TSOP32
MBM29F001T@PLCC32 [(SA015A1T)]
[(SA410T)]
MBM29F002B MBM29F002B@PLCC32
[(SA015A1T)]
MBM29F002B@TSOP32 [(SA410T)]
MBM29F002NB MBM29F002NB@TSOP32
MBM29F002NB@PLCC32 [(SA015A1T)]
[(SA410T)]
MBM29F002NT MBM29F002NT@PLCC32
[(SA015A1T)]
MBM29F002NT@TSOP32 [(SA410T)]
MBM29F002T MBM29F002T@TSOP32
MBM29F002T@PLCC32 [(SA015A1T)]
[(SA410T)]
MBM29F010 MBM29F010@PLCC32
[(SA015A1T)]
MBM29F010@TSOP32 [(SA410T)]
MBM29F010A MBM29F010A@TSOP32
MBM29F010A@PLCC32 [(SA015A1T)]
[(SA410T)]
MBM29F016@PSOP44 [(SA638)] MBM29F016@TSOP40
[(SA409T)]
MBM29F016@TSOP48 [(SA247-B005)] MBM29F016A@PSOP44
[(SA638)]
MBM29F016A@TSOP40 [(SA409T)] MBM29F016A@TSOP48 [(SA247-
B005)]
MBM29F016B@PSOP44 [(SA638)] MBM29F016B@TSOP40
[(SA409T)]
MBM29F016B@TSOP48 [(SA247-B005)] MBM29F017B@TSOP48 [(SA247-
B005)]
MBM29F017D@TSOP40 [(SA409T)] MBM29F017D@TSOP48 [(SA247-
B005)]
MBM29F032B@PSOP44 [(SA638)] MBM29F032B@TSOP40
[(SA409T)]
MBM29F033C@TSOP40 [(SA409T)]
MBM29F040 MBM29F040@TSOP32
MBM29F040@PLCC32 [(SA015A1T)]
[(SA410T)]

MBM29F040B [(SA015A1T)]	MBM29F040B@PLCC32
MBM29F040B@TSOP32 [(SA410T)] [(SA015A1T)]	MBM29F040C@PLCC32
MBM29F040C@TSOP32 [(SA410T)] [(SA638)]	MBM29F080@PSOP44
MBM29F080@TSOP40 [(SA409T)] B005)]	MBM29F080A@TSOP48 [(SA247-
MBM29F080B@PSOP44 [(SA638)] [(SA409T)]	MBM29F080B@TSOP40
MBM29F100B@PSOP44 [(SA638-B006)] B005)]	MBM29F100B@TSOP48 [(SA247-
MBM29F100T@PSOP44 [(SA638-B006)] B005)]	MBM29F100T@TSOP48 [(SA247-
MBM29F160BE@TSOP48 [(SA247-B005)]	
MBM29F160TE@TSOP48 [(SA247-B005)]	
MBM29F200AB@PSOP44 [(SA638-B006)]	
MBM29F200AB@TSOP48 [(SA247-B005)]	
MBM29F200AT@PSOP44 [(SA638-B006)]	
MBM29F200AT@TSOP48 [(SA247-B005)]	
MBM29F200B@PSOP44 [(SA638-B006)] B005)]	MBM29F200B@TSOP48 [(SA247-
MBM29F200T@PSOP44 [(SA638-B006)] B005)]	MBM29F200T@TSOP48 [(SA247-
MBM29F400AB@PSOP44 [(SA638-B006)]	
MBM29F400AB@TSOP48 [(SA247-B005)]	
MBM29F400AT@PSOP44 [(SA638-B006)]	
MBM29F400AT@TSOP48 [(SA247-B005)]	
MBM29F400B@PSOP44 [(SA638-B006)] B005)]	MBM29F400B@TSOP48 [(SA247-
MBM29F400BB@PSOP44 [(SA638-B006)]	
MBM29F400BB@TSOP48 [(SA247-B005)]	
MBM29F400BT@PSOP44 [(SA638-B006)]	
MBM29F400BT@TSOP48 [(SA247-B005)]	
MBM29F400T@PSOP44 [(SA638-B006)] B005)]	MBM29F400T@TSOP48 [(SA247-
MBM29F800B@PSOP44 [(SA638-B006)] B005)]	MBM29F800B@TSOP48 [(SA247-
MBM29F800BA@PSOP44 [(SA638-B006)]	
MBM29F800BA@TSOP48 [(SA247-B005)]	
MBM29F800BB@PSOP44 [(SA638-B006)]	
MBM29F800BB@TSOP48 [(SA247-B005)]	
MBM29F800BT@PSOP44 [(SA638-B006)]	

MBM29F800BT@TSOP48 [(SA247-B005)]
MBM29F800T@PSOP44 [(SA638-B006)] MBM29F800T@TSOP48 [(SA247-B005)]
MBM29F800TA@PSOP44 [(SA638-B006)]
MBM29F800TA@TSOP48 [(SA247-B005)]
MBM29LL800B@TSOP48 [(SA247-B005)]
MBM29LL800BB@TSOP48 [(SA247-B005)]
MBM29LL800BT@TSOP48 [(SA247-B005)]
MBM29LL800T@TSOP48 [(SA247-B005)]
MBM29LV001B@PLCC32 [(SA015A1T)] MBM29LV001BB@PLCC32
[(SA015A1T)]
MBM29LV001BB@TSOP32 [(SA410T)] MBM29LV001BC@PLCC32
[(SA015A1T)]
MBM29LV001BC@TSOP32 [(SA410T)] MBM29LV001BT@PLCC32
[(SA015A1T)]
MBM29LV001BT@TSOP32 [(SA410T)] MBM29LV001T@TSOP32
[(SA410T)]
MBM29LV001TC@PLCC32 [(SA015A1T)] MBM29LV001TC@TSOP32
[(SA410T)]
MBM29LV002B@TSOP40 [(SA409T)] MBM29LV002T@TSOP40
[(SA409T)]
MBM29LV004B@PSOP44 [(SA638)] MBM29LV004B@TSOP40
[(SA409T)]
MBM29LV004BB@TSOP40 [(SA409T)] MBM29LV004BT@TSOP40
[(SA409T)]
MBM29LV004T@PSOP44 [(SA638)] MBM29LV004T@TSOP40
[(SA409T)]
MBM29LV008B@PSOP44 [(SA638)] MBM29LV008B@TSOP40
[(SA409T)]
MBM29LV008BB@TSOP40 [(SA409T)] MBM29LV008BT@TSOP40
[(SA409T)]
MBM29LV008T@PSOP44 [(SA638)] MBM29LV008T@TSOP40
[(SA409T)]
MBM29LV016/B@TSOP40 [(SA409T)] MBM29LV016/T@TSOP40
[(SA409T)]
MBM29LV016B@TSOP40 [(SA409T)]
MBM29LV017@FBGA48 [(SA642O-B026A-T064F001)]
MBM29LV017@TSOP40 [(SA409T)] MBM29LV017B@TSOP40
[(SA409T)]
MBM29LV017E@TSOP40 [(SA409T)] MBM29LV033C@TSOP40
[(SA409T)]
MBM29LV080@TSOP40 [(SA409T)] MBM29LV081@TSOP40
[(SA409T)]

MBM29LV081B@TSOP40 [(SA409T)] MBM29LV116B@TSOP40
[(SA409T)]
MBM29LV160B@SON46 [(SA631)] MBM29LV160B@SON46
(*)
MBM29LV160BB@PSOP44 [(SA638-B006)]
MBM29LV160BB@TSOP48 [(SA247-B005)]
MBM29LV160BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160BE@TSOP48 [(SA247-B005)]
MBM29LV160BM@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160BM@TSOP48 [(SA247-B005)]
MBM29LV160BT@PSOP44 [(SA638-B006)]
MBM29LV160BT@TSOP48 [(SA247-B005)]
MBM29LV160T@SON46 [(SA631)] MBM29LV160T@SON46
(*)
MBM29LV160TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160TE@TSOP48 [(SA247-B005)]
MBM29LV160TM@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160TM@TSOP48 [(SA247-B005)]
MBM29LV200B@PSOP44 [(SA638-B006)]
MBM29LV200B@TSOP48 [(SA247-B005)]
MBM29LV200BB@PSOP44 [(SA638-B006)]
MBM29LV200BB@TSOP48 [(SA247-B005)]
MBM29LV200BC@PSOP44 [(SA638)]
MBM29LV200BC@TSOP48 [(SA247-B005)]
MBM29LV200BT@PSOP44 [(SA638-B006)]
MBM29LV200BT@TSOP48 [(SA247-B005)]
MBM29LV200T@PSOP44 [(SA638-B006)]
MBM29LV200T@TSOP48 [(SA247-B005)]
MBM29LV200TC@PSOP44 [(SA638)]
MBM29LV200TC@TSOP48 [(SA247-B005)]
MBM29LV320BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29LV320BE@TSOP48 [(SA247-B005)]
MBM29LV320TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29LV320TE@TSOP48 [(SA247-B005)]
MBM29LV400B@PSOP44 [(SA638-B006)]
MBM29LV400B@TSOP48 [(SA247-B005)]
MBM29LV400BB@PSOP44 [(SA638-B006)]
MBM29LV400BB@TSOP48 [(SA247-B005)]
MBM29LV400BC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29LV400BC@PSOP44 [(SA638)]
MBM29LV400BC@TSOP48 [(SA247-B005)]
MBM29LV400BT@PSOP44 [(SA638-B006)]
MBM29LV400BT@TSOP48 [(SA247-B005)]

MBM29LV400T@PSOP44 [(SA638-B006)]
MBM29LV400T@TSOP48 [(SA247-B005)]
MBM29LV400TC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29LV400TC@PSOP44 [(SA638)]
MBM29LV400TC@TSOP48 [(SA247-B005)]
MBM29LV650UE@TSOP48 [(SA247-B005)]
MBM29LV651UE@TSOP48 [(SA247-B005)]
MBM29LV652UE@FBGA63 [(SA642C-B026A-Y056F001)]
MBM29LV800B@PSOP44 [(SA638-B006)]
MBM29LV800B@SON46 [(SA631)] MBM29LV800B@SON46
(*)
MBM29LV800B@TSOP48 [(SA247-B005)]
MBM29LV800BA@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV800BA@PSOP44 [(SA638)]
MBM29LV800BA@TSOP48 [(SA247-B005)]
MBM29LV800BB@PSOP44 [(SA638-B006)]
MBM29LV800BB@TSOP48 [(SA247-B005)]
MBM29LV800BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV800BE@PSOP44 [(SA638)]
MBM29LV800BE@TSOP48 [(SA247-B005)]
MBM29LV800BT@PSOP44 [(SA638-B006)]
MBM29LV800BT@TSOP48 [(SA247-B005)]
MBM29LV800T@PSOP44 [(SA638-B006)]
MBM29LV800T@SON46 [(SA631)] MBM29LV800T@SON46
(*)
MBM29LV800T@TSOP48 [(SA247-B005)]
MBM29LV800TA@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV800TA@PSOP44 [(SA638)]
MBM29LV800TA@TSOP48 [(SA247-B005)]
MBM29LV800TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV800TE@PSOP44 [(SA638)]
MBM29LV800TE@TSOP48 [(SA247-B005)]
MBM29PDS323B@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29PDS323T@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29PL160BD@PSOP44 [(SA638)]
MBM29PL160BD@TSOP48 [(SA247-B005)]
MBM29PL160TD@PSOP44 [(SA638)]
MBM29PL160TD@TSOP48 [(SA247-B005)]
MBM29PL32BM@FBGA48 [(SA642G-B026A-T048F001)]
MBM29PL32BM@TSOP48 [(SA247-B005)]
MBM29PL32TM@FBGA48 [(SA642G-B026A-T048F001)]
MBM29PL32TM@TSOP48 [(SA247-B005)]
MBM29PL64LM@TSOP48 [(SA247-B005)]

MBM29PL64LM@TSOP56 [(SA628-B067)]
MBM29QM12DH@FBGA88 [(SA642J-B101A-W080F001)]
MBM29QM12DH@TSOP56 [(SA628-B097)]
MBM29SL160BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29SL160BD@TSOP48 [(SA247-B005)]
MBM29SL160TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29SL160TD@TSOP48 [(SA247-B005)]
MBM29SL800BB@TSOP48 [(SA247-B005)]
MBM29SL800BT@TSOP48 [(SA247-B005)]

DRAM & SRAM

MB81C78A MB81C78A@SOIC28
[(SA630)]

MICROCONTROLLER

MB89F202@SDIP32 [(SA653)] MB89F202@SSOP34
[(SA689)]
MB89F202RA@QFP32 [(SA663)] MB89F202RA@SDIP32
[(SA653)]
MB89F202RA@SSOP34 [(SA689)] MB89F482AS@LQFP44
[(SA245A)]
MB89F482AS@SDIP42 [(SA028)] MB89F482AW@LQFP44
[(SA245A)]
MB89F482AW@SDIP42 [(SA028)] MB89F482HS@LQFP44
[(SA245A)]
MB89F482HS@SDIP42 [(SA028)] MB89F482HW@LQFP44
[(SA245A)]
MB89F482HW@SDIP42 [(SA028)]
MB89P195
MB89P195(F)@SOIC28 [(SA630)]
MB89P195AP
MB89P195AP(F)@SOIC28 [(SA630)]
MB89P195P
MB89P195P(F)@SOIC28 [(SA630)]

GENCORE

MICROCONTROLLER

GC87C520A0 [(SA244)]	GC87C520A0@PLCC44
GC87C520A0@TQFP44 [(SA245A)]	
GC87C520G0 GC87C520G0@PLCC44 [(SA244)]	GC87C520G0@TQFP44
[(SA245A)]	

GENERAL(GI)

E (E) PROM / FRAM / NVRAM

27256
27C128
27C128@PLCC32 [(SA015A1T)]
27C256
27C256@PLCC32 [(SA015A1T)]
27C512
27C513
27C64
27C64@PLCC32 [(SA015A1T)]
27HC191
27HC291
27HC64
27HC641
27HC641L
27HC64L
28C04
28C04A
28C04F
28C16
28C16A
28C16F
28C17
28C17F
ER5911
ER5911@SOIC8 [(SA602A)]
GI5911
GI5911@SOIC8 [(SA602A)]
GI59C11
GI59C11@SOIC8 [(SA602A)]
GI59C12

GI59C12@SOIC8 [(SA602A)]
GR27C513

GENERIC

E (E) PROM / FRAM / NVRAM

27128 (21V) (12.5V)	27128A
2716 (25V) (12.5V)	27256
2732 (25V) (21V)	2732A
2732B (12.5V) (12.5V)	27512
27512 (21V) (21V)	2764
2764A (12.5V) (12.5V)	27C128
27C128 (21V) (25V)	27C16
27C256 (12.5V) (25V)	27C32
27C512 (12.5V) (12.5V)	27C64
27C64 (21V)	

GOAL

MICROCONTROLLER

VRS1000 [(SA244)]	VRS1000@PLCC44
VRS1000@TQFP44 [(SA245A)]	
VRS1050 VRS1050@PLCC44 [(SA244)] [(SA675)]	VRS1050@TQFP44
VRS1100 [(SA244)]	VRS1100@PLCC44
VRS1100@TQFP44 [(SA245A)]	

VRS540	
VRS540@PLCC44 [(SA244)]	VRS540@TQFP44
[(SA245A)]	
VRS550	VRS550@PLCC44
[(SA244)]	
VRS550@TQFP44 [(SA245A)]	
VRS560	
VRS560@PLCC44 [(SA244)]	VRS560@TQFP44
[(SA245A)]	
VRS570	VRS570@PLCC44
[(SA244)]	
VRS570@TQFP44 [(SA245A)]	
VRS580	
VRS580@PLCC44 [(SA244)]	VRS580@TQFP44
[(SA245A)]	
VRS700	VRS700@PLCC44
[(SA244)]	
VRS700@TQFP44 [(SA245A)]	
VRS900	
VRS900@PLCC44 [(SA244)]	VRS900@TQFP44
[(SA245A)]	

GREENWICH

E (E) PROM / FRAM / NVRAM

GR27128
GR27256
GR27512
GR2764

HAIER

MICROCONTROLLER

HCM87CP311SP@SDIP42 [(SA028)]	
HR6P60P2DL	
HR6P60P2EL	HR6P60P2SL@SOP20
[(SA404)]	
HR6P60P2SL@SSOP20 [(SA626A)]	HR6P60P2XL@SOP18

[(SA404)]
HR6P60P2YL@SOP14 [(SA404)]
HR6P62P4D
HR6P62P4DH
HR6P62P4DHL
HR6P62P4DHL(INTOSC)
HR6P62P4NHL(INTOSC)@SSOP20 [(SA626A)]
HR6P62P4NHL@SSOP20 [(SA626A)]
HR6P62P4RHL(INTOSC)@SSOP20 [(SA626A)]
HR6P62P4RHL@SSOP20 [(SA626A)] HR6P62P4SH@SOP20 [(SA404
+B003)]
HR6P62P4SHL(INTOSC)@SOP20 [(SA404)]
HR6P62P4SHL@SOP20 [(SA404)]
HR6P62P4XHL(INTOSC)@SOP18 [(SA404)]
HR6P62P4XHL@SOP18 [(SA404)] HR6P62P4YHL@SOIC14
[(SA602)]
HR6P67P4D
HR6P67P4DL
HR6P67P4DL(REVERSE)
HR6P67P4SL(REVERSE)@SOP14 [(SA404+B003)]
HR6P67P4SL@SOP14 [(SA404+B003)]
HR6P71F8D
HR6P71F8D(REVERSE)
HR6P71F8S(REVERSE)@SOP20 [(SA404)]
HR6P71F8S@SOP20 [(SA404)]
HR6P72P4D
HR6P72P4DL HR6P72P4S@SOP28 [(SA404
+B003)]
HR6P72P4SL@SOP28 [(SA404+B003)]
HR6P73P8DB
HR6P73P8DBL HR6P73P8SB@SOP28 [(SA404
+B003)]
HR6P73P8SBL@SOP28 [(SA404-B003)]
HR6P73PGD
HR6P73PGDH
HR6P73PGDHL
HR6P73PGS@SOP28 [(SA404+B003)] HR6P73PGSH@SOP28 [(SA404
+B003)]
HR6P73PGSHL@SOP28 [(SA404-B003)]
HR6P76PGD
HR6P76PGDL HR6P76PGS@SOP28 [(SA404
+B003)]
HR6P76PGSL@SOP28 [(SA404-B003)]

HR6P77PGD	
HR6P77PGDL +B005)]	HR6P77PGL@LQFP44 [(SA245
HR6P77PGLL@LQFP44 [(SA245-B005)] +B006)]	HR6P78P4SL@SOP32 [(SA715
HR6P90FGD [(SA404)]	HR6P90FGS@SOP28
HR6P90FHD [(SA404)]	HR6P90FHS@SOP28
HR6P91FGS@SOP32 [(SA715)] [(SA715)]	HR6P91FHS@SOP32
HR6P92FGD [(SA245A)]	HR6P92FGL@LQFP44
HR6P92FHD [(SA245A)]	HR6P92FHL@LQFP44
HR6P95F8D [(SA404)]	HR6P95F8S@SOP28
HR6P97FGD [(SA404)]	HR6P97FGS@SOP28
HR6P98FGD [(SA245A)]	HR6P98FGL@LQFP44
HR7T46P8V@SDIP42 [(SA028)] +B005)]	HR7T46PGV@SDIP42 [(SA028
HR7T47P8L@LQFP44 [(SA245A)] +B005)]	HR7T47PGL@LQFP44 [(SA245A

HARRIS

DRAM & SRAM

HM6516 [(SA015A1T)]	HM6516@PLCC32
HM65162 [(SA015A1T)]	HM65162@PLCC32
HM65642 [(SA643)]	HM65642@TSOP28

HITACHI

E (E) PROM / FRAM / NVRAM

HN27128AG
HN27128AP
HN27256G
HN27256P
HN27512G
HN27512P
HN27C101AG
HN27C101AP
HN27C101G
HN27C101P
HN27C1024HG
HN27C1024HG@PLCC44
[(SA244)]
HN27C256AG
HN27C256FP
HN27C256G
HN27C256HG
HN27C301AG
HN27C301AP
HN27C301G
HN27C301P
HN27C4000FP
HN27C4000G
HN27C4001
HN27C4001@TSOP32
[(SA410T)]
HN27C4001G
HN27C4096A
HN27C4096A@PLCC44 [(SA244)]
HN27C4096FP
HN27C4096FP@PLCC44 [(SA244)]
HN27C4096G
HN27C4096G@PLCC44 [(SA244)]
HN27C512G
HN27C512G@PLCC32 [(SA015A1T)]
HN27C64G
HN28F101
HN28F101@PLCC32
[(SA015A1T)]
HN28F101@SOP32 [(SA438T)]
HN28F101@TSOP32
[(SA410T)]
HN29A128A0A@CSP95 [(SA642A-B066A-Y096N001)]
HN29A128A0A@TSOP48 [(SA247-B005)]
HN29V128A0A@CSP95 [(SA642A-B066A-Y096N001)]
HN29V128A0A@TSOP48 [(SA247-B005)]
HN29V128A0E@CSP95 [(SA642A-B066A-Y096N001)]

HN29V51211@TSOP48 [(SA247-B005)]

HN462716G

HN462732G

(P)

HN4827128G

HN4827128P

HN482732AG

HN482764G

HN482764P

[(SA404)]

HN58064(P)

[(SA438T)]

HN58C1001(P)

[(SA620)]

HN58C256A(FP)@SOP28 [(SA630)]

(P)

HN58C256A(T)@TSOP28 [(SA643)]

[(SA620)]

HN58C65(FP)@SOIC28 [(SA404)]

(P)

HN58C66

[(SA630)]

HN58C66@TSOP28 [(SA430T)]

HN58V24256

HN58V24256@SOIC8 [(SA602A)]

[(SA026)]

HN58V24512

[(SA602A)]

HN58V256A

[(SA430T)]

HN58V65A

[(SA630)]

HN58V65A@TSOP28 [(SA430T)]

HN58V66A

HN58V66A@SOIC28 [(SA630)]

[(SA430T)]

HN58W241000

[(SA602A)]

HN58X2402

[(SA602A)]

HN58X2402@TSSOP8 [(SA026)]

HN58X2404

HN58X2404@SOIC8 [(SA602A)]

HN48016

HN58064(FP)@SOIC28

HN58C1001(FP)@SSOP32

HN58C1001(T)@VSOP32

HN58C256A

HN58C257A(T)@TSOP32

HN58C65

HN58C66@SOP28

HN58V24256@TSSOP14

HN58V24512@SOIC8

HN58V256A@TSOP28

HN58V65A@SOIC28

HN58V66A@TSOP28

HN58W241000@SOIC8

HN58X2402@SOIC8

HN58X2404@TSSOP8

[(SA026)]	
HN58X2408	HN58X2408@SOIC8
[(SA602A)]	
HN58X2408@TSSOP8 [(SA026)]	
HN58X24128	
HN58X24128@SOIC8 [(SA602A)]	
HN58X2416	
HN58X2416@SOIC8 [(SA602A)]	HN58X2416@TSSOP8
[(SA026)]	
HN58X24256	HN58X24256@SOIC8
[(SA602A)]	
HN58X2432	HN58X2432@SOIC8
[(SA602A)]	
HN58X2432@TSSOP8 [(SA026)]	
HN58X24512	
HN58X24512@SOIC8 [(SA602A)]	
HN58X2464	
HN58X2464@SOIC8 [(SA602A)]	HN58X2464@TSSOP8
[(SA026)]	
HN58X2502@SOIC8 [(SA602A)]	HN58X2502@TSSOP8
[(SA026)]	
HN58X2504@SOIC8 [(SA602A)]	HN58X2504@TSSOP8
[(SA026)]	
HN58X25128@SOIC8 [(SA602A)]	HN58X25128@TSSOP14
[(SA026)]	
HN58X25256@SOIC8 [(SA602A)]	HN58X25256@TSSOP14
[(SA026)]	
HN58X2532@SOIC8 [(SA602A)]	HN58X2532@TSSOP8
[(SA026)]	
HN58X2564@SOIC8 [(SA602A)]	HN58X2564@TSSOP8
[(SA026)]	
HT29VB800@TSOP48 [(SA247-B005)]	HT29VT800@TSOP48 [(SA247-B005)]
HT29WB800@TSOP48 [(SA247-B005)]	HT29WT800@TSOP48 [(SA247-B005)]
V128128A0E@CSP95 [(SA642A-B105A-Y096N001)]	

DRAM & SRAM

HM6116	HM6116@PLCC32
[(SA015A1T)]	
HM6116A	HM6116A@PLCC32

[(SA015A1T)]	
HM6208	HM6208@SOJ24
[(SA646)]	
HM6208H	HM6208H@SOJ24
[(SA646)]	
HM62256	HM62256@TSOP28
[(SA643)]	
HM62256B	HM62256B@TSOP28
[(SA643)]	
HM624256	HM624256@SOJ28
[(SA646)]	
HM6264A	HM6264A@TSOP28
[(SA643)]	
HM6267	
HM6268	
HM628128	HM628128@TSOP32
[(SA410T)]	
HM628128A	HM628128A@TSOP32
[(SA410T)]	
HM62832	HM62832@TSOP28
[(SA643)]	
HM62832H	HM62832H@TSOP28
[(SA643)]	
HM628512	HM628512@TSOP32
[(SA729)]	
HM6287	
HM6287HP	
HM6288	HM6288@SOJ22
[(SA646)]	
HM65256B	HM65256B@TSOP28
[(SA643)]	
HM658128	HM658128@TSOP32
[(SA410T)]	
HM66204	HM66204@TSOP32
[(SA410T)]	
HM6707	HM6707@SOJ24
[(SA646)]	
HM6707A	HM6707A@SOJ24
[(SA646)]	
HM6708	HM6708@SOJ24
[(SA646)]	
HM6708A	HM6708A@SOJ24
[(SA646)]	

HM6716 [(SA015A1T)]	HM6716@PLCC32
HM6787 HM6787HP HM6788 [(SA646)]	HM6788@SOJ22
HM6788H [(SA646)]	HM6788H@SOJ22
HM6788HA [(SA646)]	HM6788HA@SOJ22

MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)] [(SA404)]	HD4074344@SOIC28
HD4074394@SDIP28 [(SA022A)] [(SA404)]	HD4074394@SOIC28
HD64F3694FX@TQFP48 [(SA671)] [(SA248)]	HD64F3694FY@TQFP48
HD64F3694GFX@TQFP48 [(SA671)] [(SA248)]	HD64F3694GFY@TQFP48

HOLTEK

E (E) PROM / FRAM / NVRAM

HT24C01 [(SA602A)]	HT24C01@SOIC8
HT24C02 [(SA602A)]	HT24C02@SOIC8
HT24C04 [(SA602A)]	HT24C04@SOIC8
HT24C08 HT24C16 HT24LC01 [(SA602A)]	HT24LC01@SOIC8
HT24LC01@TSSOP8 [(SA026)]	
HT24LC02 HT24LC02@SOIC8 [(SA602A)] [(SA026)]	HT24LC02@TSSOP8
HT24LC04	HT24LC04@SOIC8

[(SA602A)]	
HT24LC08	HT24LC08@SOIC8
[(SA602A)]	
HT24LC16	HT24LC16@SOIC8
[(SA602A)]	
HT24LC32	HT24LC32@SOIC8
[(SA602A)]	
HT24LC64	HT24LC64@SOIC8
[(SA602A)]	
HT25LC512@SOIC8 [(SA602A)]	
HT27C010	
HT27C010@PLCC32 [(SA015A1T)]	HT27C010@TSOP32
[(SA410T)]	
HT27C020	HT27C020@PLCC32
[(SA015A1T)]	
HT27C020@TSOP32 [(SA410T)]	
HT27C040	
HT27C040@PLCC32 [(SA015A1T)]	HT27C040@TSOP32
[(SA410T)]	
HT27C4096	HT27C4096@PLCC44
[(SA244)]	
HT27C512	HT27C512@PLCC32
[(SA015A1T)]	
HT27C512@TSOP28 [(SA430T)]	
HT27LC010	
HT27LC010@PLCC32 [(SA015A1T)]	HT27LC010@TSOP32
[(SA410T)]	
HT27LC020	HT27LC020@PLCC32
[(SA015A1T)]	
HT27LC020@TSOP32 [(SA410T)]	
HT27LC040	
HT27LC040@PLCC32 [(SA015A1T)]	HT27LC040@TSOP32
[(SA410T)]	
HT27LC4096	HT27LC4096@PLCC44
[(SA244)]	
HT27LC512	HT27LC512@PLCC32
[(SA015A1T)]	
HT27LC512@TSOP28 [(SA430T)]	HT93C46
(16bit)	
HT93C46(16bit)@SOP8-A [(SA602A)]	HT93C46(16bit)@SOP8-B
[(SA602A)]	
HT93C46(16bit)@TSSOP8 [(SA026)]	HT93C56
(16bit)	

HT93C56(16bit)@SOP8-A [(SA602A)]	HT93C56(16bit)@SOP8-B
[(SA602A)]	
HT93C56(16bit)@TSSOP8 [(SA026)]	HT93C66
(16bit)	
HT93C66(16bit)@SOP8-A [(SA602A)]	HT93C66(16bit)@SOP8-B
[(SA602A)]	
HT93C66(16bit)@TSSOP8 [(SA026)]	HT93LC46A
(08bit)	
HT93LC46A(08bit)@SOP8-A [(SA602A)]	
HT93LC46A(08bit)@SOP8-B [(SA602A)]	
HT93LC46A(08bit)@TSSOP8 [(SA026)]	
HT93LC46A(16bit)	
HT93LC46A(16bit)@SOP8-A [(SA602A)]	
HT93LC46A(16bit)@SOP8-B [(SA602A)]	
HT93LC46A(16bit)@TSSOP8 [(SA026)]	
HT93LC46B(08bit)	
HT93LC46B(08bit)@SOP8-A [(SA602A)]	
HT93LC46B(08bit)@SOP8-B [(SA602A)]	
HT93LC46B(08bit)@TSSOP8 [(SA026)]	
HT93LC46B(16bit)	
HT93LC46B(16bit)@SOP8-A [(SA602A)]	
HT93LC46B(16bit)@SOP8-B [(SA602A)]	
HT93LC46B(16bit)@TSSOP8 [(SA026)]	
HT93LC56A(08bit)	
HT93LC56A(08bit)@SOP8-A [(SA602A)]	
HT93LC56A(08bit)@SOP8-B [(SA602A)]	
HT93LC56A(08bit)@TSSOP8 [(SA026)]	
HT93LC56A(16bit)	
HT93LC56A(16bit)@SOP8-A [(SA602A)]	
HT93LC56A(16bit)@SOP8-B [(SA602A)]	
HT93LC56A(16bit)@TSSOP8 [(SA026)]	
HT93LC56B(08bit)	
HT93LC56B(08bit)@SOP8-A [(SA602A)]	
HT93LC56B(08bit)@SOP8-B [(SA026)]	
HT93LC56B(08bit)@TSSOP8 [(SA026)]	
HT93LC56B(16bit)	
HT93LC56B(16bit)@SOP8-A [(SA602A)]	
HT93LC56B(16bit)@SOP8-B [(SA602A)]	
HT93LC56B(16bit)@TSSOP8 [(SA026)]	
HT93LC66A(08bit)	
HT93LC66A(08bit)@SOP8-A [(SA602A)]	
HT93LC66A(08bit)@SOP8-B [(SA602A)]	
HT93LC66A(08bit)@TSSOP8 [(SA026)]	

HT93LC66A(16bit)
 HT93LC66A(16bit)@SOP8-A [(SA602A)]
 HT93LC66A(16bit)@SOP8-B [(SA602A)]
 HT93LC66A(16bit)@TSSOP8 [(SA026)]
 HT93LC66B(08bit)
 HT93LC66B(08bit)@SOP8-A [(SA602A)]
 HT93LC66B(08bit)@SOP8-B [(SA026)]
 HT93LC66B(08bit)@TSSOP8 [(SA026)]
 HT93LC66B(16bit)
 HT93LC66B(16bit)@SOP8-A [(SA602A)]
 HT93LC66B(16bit)@SOP8-B [(SA602A)]
 HT93LC66B(16bit)@TSSOP8 [(SA026)]
 HT93LC76(08bit)
 HT93LC76(08bit)@SOP8-A [(SA602A)]
 HT93LC76(08bit)@SOP8-B [(SA602A)]
 HT93LC76(08bit)@TSSOP8 [(SA026)] HT93LC76
 (16bit)
 HT93LC76(16bit)@SOP8-A [(SA602A)]
 HT93LC76(16bit)@SOP8-B [(SA602A)]
 HT93LC76(16bit)@TSSOP8 [(SA026)] HT93LC86
 (08bit)
 HT93LC86(08bit)@SOP8-A [(SA602A)]
 HT93LC86(08bit)@SOP8-B [(SA602A)]
 HT93LC86(08bit)@TSSOP8 [(SA026)] HT93LC86
 (16bit)
 HT93LC86(16bit)@SOP8-A [(SA602A)]
 HT93LC86(16bit)@SOP8-B [(SA602A)]
 HT93LC86(16bit)@TSSOP8 [(SA026)]

MICROCONTROLLER

HT46R22 HT46R22@SOP24
 [(SA404)]
 HT46R23(dip24) HT46R23
 (dip28)
 HT46R23@SOP24 [(SA404)] HT46R23@SOP28
 [(SA404)]
 HT46R24 HT46R24@SOP28
 [(SA404)]
 HT46R24@SSOP48 [(SA669)] HT46R46
 (dip18)
 HT46R46(dip20) HT46R46@SOP18

[(SA404)]	
HT46R46@SOP20 [(SA404)]	HT46R46E
(dip18)	
HT46R46E@SOP18 [(SA404)]	HT46R46-
H	
HT46R46-H@SOP18 [(SA404)]	HT46R47
(dip18)	
HT46R47(dip20)	HT46R47@SOP18
[(SA404)]	
HT46R47@SOP20 [(SA404)]	HT46R47@SSOP20
[(SA674)]	
HT46R47E(dip18)	HT46R47E@SOP18
[(SA404)]	
HT46R47-H	HT46R47-H@SOP18
[(SA404)]	
HT46R48(dip20)	HT46R48
(dip24)	
HT46R48@SOP20 [(SA404)]	HT46R48@SOP24
[(SA404)]	
HT46R48@SSOP24 [(SA674)]	HT46R48E
(dip24)	
HT46R48E@SOP24 [(SA404)]	HT46R48E@SSOP24
[(SA674)]	
HT46R51A(dip18)	HT46R51A@SOP20
[(SA404)]	
HT46R51A@SSOP20 [(SA674)]	HT46R52A
(dip18)	
HT46R52A@SOP20 [(SA404)]	HT46R52A@SSOP20
[(SA674)]	
HT46R53A(dip28)	HT46R53A@SOP28
[(SA404)]	
HT46R54A(dip28)	HT46R54A@SOP28
[(SA404)]	
HT46R65@PQFP100 [(PEP+S427)]	HT46R65@SSOP56
[(SA669)]	
HT46R71D@SSOP48 [(SA669)]	
HT46RB70	
HT46RB70@SOP28 [(SA404)]	HT46RB70@SSOP48
[(SA669)]	
HT46RU22(dip24)	HT46RU22@SOP24
[(SA404)]	
HT46RU22@SSOP24 [(SA674)]	HT47R10A@QFP44
[(SA245)]	

HT48R05A [(SA026)]	HT48R05A@SOP16
HT48R05A@SOP18 [(SA404)]	
HT48R06A HT48R06A@SOP16 [(SA026)] [(SA404)]	HT48R06A@SOP18
HT48R07A [(SA404)]	HT48R07A@SOP24
HT48R07A@SSOP24 [(SA674)]	
HT48R08A HT48R08A@SOP16 [(SA026)] [(SA404)]	HT48R08A@SOP18
HT48R09A [(SA404)]	HT48R09A@SOP24
HT48R09A@SSOP24 [(SA674)]	
HT48R10A HT48R10A@SOP24 [(SA404)] (dip24)	HT48R30A
HT48R30A(dip28) [(SA404)]	HT48R30A@SOP24
HT48R30A@SOP28 [(SA404)]	
HT48R50A HT48R50A@SOP28 [(SA404)] [(SA669)]	HT48R50A@SSOP48
HT48R52A@QFP44 [(SA245A)] [(SA669)]	HT48R70A@SSOP48
HT48RA0-1 [(SA404)]	HT48RA0-1@SOP24
HT48RA0-2 [(SA404)]	HT48RA0-2@SOP20
HT48RA0-2@SSOP20 [(SA674)] 3	HT48RA0-
HT48RA0-3@SOP20 [(SA404)] [(SA404)]	HT48RA1@SOP28
HT48RA1@SSOP28 [(SA626A)] (dip28)	HT48RA3
HT48RA3@SOP28 [(SA404)] [(SA626A)]	HT48RA3@SSOP28
HT48RA5(dip28) [(SA404)]	HT48RA5@SOP28
HT48RA5@SSOP28 [(SA626A)]	
HT48RB50 HT48RB50@SOP28 [(SA404)]	HT48RB50@SSOP48

[(SA669)]	
HT48RB8@SOP28 [(SA404)]	HT48RB8@SSOP48
[(SA669)]	
HT49R30A@SSOP48 [(SA669)]	HT49R50A@SSOP48
[(SA669)]	
HT49RV5@SSOP56 [(SA669)]	HT82A821R@SOP24
[(SA404)]	
HT82A821R@SSOP24 [(SA674)]	HT82A822R@SSOP48
[(SA669)]	
HT82A832R@QFP48 [(SA248)]	HT82A832R@SSOP48
[(SA669)]	
HT82K68E	HT82K68E@SOP20
[(SA404)]	
HT82K68E@SOP28 [(SA404)]	HT82K68E@SSOP48
[(SA669)]	
HT82K94E@SSOP48 [(SA669)]	HT82K96E
(dip20)	
HT82K96E(dip40)	HT82K96E@SOP20
[(SA404)]	
HT82K96E@SOP28 [(SA404)]	HT82K96E@SSOP48
[(SA669)]	
HT82M99E(dip18)	HT82M99E
(dip20)	
HT82M99E@SOP18 [(SA404)]	HT82M99E@SOP20
[(SA404)]	
HT82M9AE@SOP20 [(SA404)]	HT82M9AE@SOP24
[(SA404)]	
HT82M9AE@SSOP20 [(SA674)]	HT82M9AE@SSOP24
[(SA674)]	
HT82M9BE@SOP24 [(SA404)]	HT82M9BE@SOP28
[(SA404)]	
HT82M9BE@SSOP24 [(SA674)]	HT82M9BE@SSOP28
[(SA626A)]	
HT95A100@SOP28 [(SA404)]	HT95A10P@SOP28
[(SA404)]	
HT95A200@SSOP48 [(SA669)]	HT95A20P@SSOP48
[(SA669)]	
HT95A300@SSOP48 [(SA669)]	HT95A30P@SSOP48
[(SA669)]	

HONGKONG

E (E) PROM / FRAM / NVRAM

HK1215
HK1225
HK1235
HK1245
HK1255
HK1265
HK1275
HK1285
HK1295
HK12A5
HK12B5
OKS1225
OKS1235
OKS1245
OKS1255
OKS1265
OKS1275
OKS1285
OKS1295
OKS12A5
OKS12B5

HYNIX

E (E) PROM / FRAM / NVRAM

HY2764
HY27C64A
HY27SF081G2A@FBGA63 [(SA642KK-B026A-W048F001Y)]
HY27UA081G1M@TSOP48 [(SA247-B005)]
HY27UF081G2A@FBGA63 [(SA642KK-B026-W048F001Y)]
HY27UF081G2A@TSOP48 [(SA247-B005)]
HY27UF081G2M@TSOP48 [(SA247-B005)]
HY27UF082G2A@TSOP48 [(SA247-B005)]
HY27UF082G2B@TSOP48 [(SA247-B005)]
HY27UF082G2M@TSOP48 [(SA247-B005)]
HY27UF084G2M@TSOP48 [(SA247-B005)]
HY27UG082G2M@TSOP48 [(SA247-B005)]
HY27UG088G5M@TSOP48 [(SA247+B005)]
HY27US08121M@TSOP48 [(SA247-B005)]

HY27US08281A@TSOP48 [(SA247-B005)]
 HY27US08561A@FBGA63 [(SA642KK-B026A-W048F001Y)]
 HY27US08561A@TSOP48 [(SA247-B005)]
 HY27US08561M@TSOP48 [(SA247-B005)]
 HY27UT084G2M@TSOP48 [(SA247-B005)]
 HY27UT088G2M@TSOP48 [(SA247-B005)]
 HY27UV08BG5M@TSOP48 [(SA247-B005)]
 HY29DL162BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DL162BT@TSOP48 [(SA247-B005)]
 HY29DL162TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DL162TT@TSOP48 [(SA247-B005)]
 HY29DL163BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DL163BT@TSOP48 [(SA247-B005)]
 HY29DL163TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DL163TT@TSOP48 [(SA247-B005)]
 HY29DS162BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DS162BT@TSOP48 [(SA247-B005)]
 HY29DS162TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DS162TT@TSOP48 [(SA247-B005)]
 HY29DS163BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DS163BT@TSOP48 [(SA247-B005)]
 HY29DS163TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DS163TT@TSOP48 [(SA247-B005)]
 HY29F002T HY29F002T@PLCC32
 [(SA015A1T)]
 HY29F002T@TSOP32 [(SA410T)]
 HY29F040
 HY29F040@PLCC32 [(SA015A1T)] HY29F040@TSOP32
 [(SA410T)]
 HY29F040A HY29F040A@PLCC32
 [(SA015A1T)]
 HY29F040A@TSOP32 [(SA410T)] HY29F080@TSOP40
 [(SA409T)]
 HY29F200B@PSOP44 [(SA638-B006)] HY29F200B@TSOP48 [(SA247-
 B005)]
 HY29F200T@PSOP44 [(SA638-B006)] HY29F200T@TSOP48 [(SA247-
 B005)]
 HY29F400ABG@PSOP44 [(SA638)]
 HY29F400ABT@TSOP48 [(SA247-B005)]
 HY29F400ATG@PSOP44 [(SA638)]
 HY29F400ATT@TSOP48 [(SA247-B005)]
 HY29F400BG@PSOP44 [(SA638)] HY29F400BT@TSOP48 [(SA247-
 B005)]

HY29F400TG@PSOP44 [(SA638)] HY29F400TT@TSOP48 [(SA247-
 B005)]
 HY29F800ABG@PSOP44 [(SA638)]
 HY29F800ABT@TSOP48 [(SA247-B005)]
 HY29F800ATG@PSOP44 [(SA638)]
 HY29F800ATT@TSOP48 [(SA247-B005)]
 HY29F800BG@PSOP44 [(SA638)] HY29F800BT@TSOP48 [(SA247-
 B005)]
 HY29F800TG@PSOP44 [(SA638)] HY29F800TT@TSOP48 [(SA247-
 B005)]
 HY29LV160BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29LV160BT@TSOP48 [(SA247-B005)]
 HY29LV160TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29LV160TT@TSOP48 [(SA247-B005)]
 HY29LV320BF@FBGA48 [(SA642E-B026A-T072F001)]
 HY29LV320BF@FBGA63 [(SA642E-B026A-T072F001)]
 HY29LV320BT@TSOP48 [(SA247-B005)]
 HY29LV320TF@FBGA48 [(SA642E-B026A-T072F001)]
 HY29LV320TF@FBGA63 [(SA642E-B026A-T072F001)]
 HY29LV320TT@TSOP48 [(SA247-B005)]
 HY29LV400BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29LV400BT@TSOP48 [(SA247-B005)]
 HY29LV400TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29LV400TT@TSOP48 [(SA247-B005)]
 HY29LV800BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29LV800BG@PSOP44 [(SA638)]
 HY29LV800BT@TSOP48 [(SA247-B005)]
 HY29LV800TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29LV800TG@PSOP44 [(SA638)]
 HY29LV800TT@TSOP48 [(SA247-B005)]
 HY93C46 HY93C46@SOIC8
 [(SA602A)]
 HY93C56 HY93C56@SOIC8
 [(SA602A)]
 HY93C66 HY93C66@SOIC8
 [(SA602A)]
 HY93C76 HY93C76@SOIC8
 [(SA602A)]
 HY93C86 HY93C86@SOIC8
 [(SA602A)]
 HYC0SEH0AF3P@FBGA137 [(SA700E-B153A-M137F001Y)]
 HYD0SFE0BF1P@BGA149 [(SA700I-B308-T149F001Y)]
 HYD0SFG0MF1P@BGA149 [(SA700I-B308-T149F001Y)]

HYG0SEG0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]

HYG0UEG0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]

DRAM & SRAM

HY62256A [(SA643)]	HY62256A@TSOP28
HY6264A [(SA643)]	HY6264A@TSOP28
HY628100A [(SA438T)]	HY628100A@SOP32
HY628100A@TSOP32 [(SA410T)]	
HY628100B HY628100B@SOP32 [(SA438T)] [(SA410T)]	HY628100B@TSOP32
HY628400 [(SA438T)]	HY628400@SOP32
HY628400@TSOP32 [(SA410T)]	
HY628400A HY628400A@SOP32 [(SA438T)] [(SA410T)]	HY628400A@TSOP32
HY62CT08081E [(SA438T)]	HY62CT08081E@SOP28
HY62CT08081E@TSOP28 [(SA643)]	
HY62KT08081E HY62KT08081E@SOP28 [(SA438T)] [(SA643)]	HY62KT08081E@TSOP28
HY62U8100B [(SA438T)]	HY62U8100B@SOP32
HY62U8100B@TSOP32 [(SA410T)]	
HY62U8200B HY62U8200B@SOP32 [(SA438T)] [(SA410T)]	HY62U8200B@TSOP32
HY62U8400A [(SA438T)]	HY62U8400A@SOP32
HY62U8400A@TSOP32 [(SA410T)]	
HY62UT08081E HY62UT08081E@SOP28 [(SA438T)] [(SA643)]	HY62UT08081E@TSOP28
HY62V8100B [(SA438T)]	HY62V8100B@SOP32
HY62V8100B@TSOP32 [(SA410T)]	

HY62V8200B	
HY62V8200B@SOP32 [(SA438T)]	HY62V8200B@TSOP32
[(SA410T)]	
HY62V8400A	HY62V8400A@SOP32
[(SA438T)]	
HY62V8400A@TSOP32 [(SA410T)]	
HY62VT08081E	
HY62VT08081E@SOP28 [(SA438T)]	HY62VT08081E@TSOP28
[(SA643)]	
HY62WT08081E	HY62WT08081E@SOP28
[(SA438T)]	
HY62WT08081E@TSOP28 [(SA643)]	

MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20
[(SA404)]	
GMS97C2051	GMS97C2051@SOIC20
[(SA404)]	
GMS97C51	GMS97C51@PLCC44
[(SA244)]	
GMS97C51@TQFP44 [(SA245A)]	
GMS97C52	
GMS97C52@PLCC44 [(SA244)]	GMS97C52@TQFP44
[(SA245A)]	
GMS97C54	GMS97C54@PLCC44
[(SA244)]	
GMS97C54@TQFP44 [(SA245A)]	
GMS97C56	
GMS97C56@PLCC44 [(SA244)]	GMS97C56@TQFP44
[(SA245A)]	
GMS97C58	GMS97C58@PLCC44
[(SA244)]	
GMS97C58@TQFP44 [(SA245A)]	
GMS97L1051	
GMS97L1051@SOIC20 [(SA404)]	
GMS97L2051	
GMS97L2051@SOIC20 [(SA404)]	
GMS97L51	
GMS97L51@PLCC44 [(SA244)]	GMS97L51@TQFP44
[(SA245A)]	
GMS97L52	GMS97L52@PLCC44

[(SA244)]
GMS97L52@TQFP44 [(SA245A)]
GMS97L54
GMS97L54@PLCC44 [(SA244)] GMS97L54@TQFP44
[(SA245A)]
GMS97L56 GMS97L56@PLCC44
[(SA244)]
GMS97L56@TQFP44 [(SA245A)]
GMS97L58
GMS97L58@PLCC44 [(SA244)] GMS97L58@TQFP44
[(SA245A)]
GMS99C52 GMS99C52@PLCC44
[(SA244)]
GMS99C52@TQFP44 [(SA245A)]
GMS99C58
GMS99C58@PLCC44 [(SA244)] GMS99C58@TQFP44
[(SA245A)]
HMS99C52 HMS99C52@PLCC44
[(SA244)]
HMS99C52@TQFP44 [(SA245A)]
HMS99C58
HMS99C58@PLCC44 [(SA244)] HMS99C58@TQFP44
[(SA245A)]

HYNIX-CUSTOMER

E (E) PROM / FRAM / NVRAM

HY27UF081G2A(DD)@TSOP48 [(SA247-B005)]
HY27UF081G2A(DD5)@TSOP48 [(SA247+B005)]
HY27UF081G2A(MLT)@TSOP48 [(SA247-B005)]
HY27UF082G2A(AMLOGIC)@TSOP48 [(SA247-B005)]
HY27UF082G2A(MLT)@TSOP48 [(SA247-B005)]
HY27US08281A(WS)@TSOP48 [(SA247-B005)]
HY27UT088G2M(OMB)@TSOP48 [(SA247-B005)]

HYUNDAI

E (E) PROM / FRAM / NVRAM

HY2764
 HY27C64A
 HY29DL162BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DL162BT@TSOP48 [(SA247-B005)]
 HY29DL162TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DL162TT@TSOP48 [(SA247-B005)]
 HY29DL163BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DL163BT@TSOP48 [(SA247-B005)]
 HY29DL163TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DL163TT@TSOP48 [(SA247-B005)]
 HY29DS162BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DS162BT@TSOP48 [(SA247-B005)]
 HY29DS162TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DS162TT@TSOP48 [(SA247-B005)]
 HY29DS163BF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DS163BT@TSOP48 [(SA247-B005)]
 HY29DS163TF@FBGA48 [(SA642F-B026A-T064F001)]
 HY29DS163TT@TSOP48 [(SA247-B005)]
 HY29F002T HY29F002T@PLCC32
 [(SA015A1T)]
 HY29F002T@TSOP32 [(SA410T)]
 HY29F040
 HY29F040@PLCC32 [(SA015A1T)] HY29F040@TSOP32
 [(SA410T)]
 HY29F040A HY29F040A@PLCC32
 [(SA015A1T)]
 HY29F040A@TSOP32 [(SA410T)] HY29F080@TSOP40
 [(SA409T)]
 HY29F200B@PSOP44 [(SA638-B006)] HY29F200B@TSOP48 [(SA247-
 B005)]
 HY29F200T@PSOP44 [(SA638-B006)] HY29F200T@TSOP48 [(SA247-
 B005)]
 HY29F400ABG@PSOP44 [(SA638)]
 HY29F400ABT@TSOP48 [(SA247-B005)]
 HY29F400ATG@PSOP44 [(SA638)]
 HY29F400ATT@TSOP48 [(SA247-B005)]
 HY29F400BG@PSOP44 [(SA638)] HY29F400BT@TSOP48 [(SA247-
 B005)]
 HY29F400TG@PSOP44 [(SA638)] HY29F400TT@TSOP48 [(SA247-
 B005)]
 HY29F800ABG@PSOP44 [(SA638)]
 HY29F800ABT@TSOP48 [(SA247-B005)]
 HY29F800ATG@PSOP44 [(SA638)]

HY29F800ATT@TSOP48 [(SA247-B005)]	
HY29F800BG@PSOP44 [(SA638)]	HY29F800BT@TSOP48 [(SA247-B005)]
HY29F800TG@PSOP44 [(SA638)]	HY29F800TT@TSOP48 [(SA247-B005)]
HY29LV160BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV160BT@TSOP48 [(SA247-B005)]	
HY29LV160TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV160TT@TSOP48 [(SA247-B005)]	
HY29LV320BF@FBGA48 [(SA642E-B026A-T072F001)]	
HY29LV320BF@FBGA63 [(SA642E-B026A-T072F001)]	
HY29LV320BT@TSOP48 [(SA247-B005)]	
HY29LV320TF@FBGA48 [(SA642E-B026A-T072F001)]	
HY29LV320TF@FBGA63 [(SA642E-B026A-T072F001)]	
HY29LV320TT@TSOP48 [(SA247-B005)]	
HY29LV400BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV400BT@TSOP48 [(SA247-B005)]	
HY29LV400TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV400TT@TSOP48 [(SA247-B005)]	
HY29LV800BF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV800BG@PSOP44 [(SA638)]	
HY29LV800BT@TSOP48 [(SA247-B005)]	
HY29LV800TF@FBGA48 [(SA642F-B026A-T064F001)]	
HY29LV800TG@PSOP44 [(SA638)]	
HY29LV800TT@TSOP48 [(SA247-B005)]	
HY93C46 [(SA602A)]	HY93C46@SOIC8
HY93C56 [(SA602A)]	HY93C56@SOIC8
HY93C66 [(SA602A)]	HY93C66@SOIC8
HY93C76 [(SA602A)]	HY93C76@SOIC8
HY93C86 [(SA602A)]	HY93C86@SOIC8

DRAM & SRAM

HY62256A [(SA643)]	HY62256A@TSOP28
HY6264A [(SA643)]	HY6264A@TSOP28

HY628100A	HY628100A@SOP32
[(SA438T)]	
HY628100A@TSOP32 [(SA410T)]	
HY628100B	
HY628100B@SOP32 [(SA438T)]	HY628100B@TSOP32
[(SA410T)]	
HY628400	HY628400@SOP32
[(SA438T)]	
HY628400@TSOP32 [(SA410T)]	
HY628400A	
HY628400A@SOP32 [(SA438T)]	HY628400A@TSOP32
[(SA410T)]	
HY62CT08081E	HY62CT08081E@SOP28
[(SA438T)]	
HY62CT08081E@TSOP28 [(SA643)]	
HY62KT08081E	
HY62KT08081E@SOP28 [(SA438T)]	HY62KT08081E@TSOP28
[(SA643)]	
HY62U8100B	HY62U8100B@SOP32
[(SA438T)]	
HY62U8100B@TSOP32 [(SA410T)]	
HY62U8200B	
HY62U8200B@SOP32 [(SA438T)]	HY62U8200B@TSOP32
[(SA410T)]	
HY62U8400A	HY62U8400A@SOP32
[(SA438T)]	
HY62U8400A@TSOP32 [(SA410T)]	
HY62UT08081E	
HY62UT08081E@SOP28 [(SA438T)]	HY62UT08081E@TSOP28
[(SA643)]	
HY62V8100B	HY62V8100B@SOP32
[(SA438T)]	
HY62V8100B@TSOP32 [(SA410T)]	
HY62V8200B	
HY62V8200B@SOP32 [(SA438T)]	HY62V8200B@TSOP32
[(SA410T)]	
HY62V8400A	HY62V8400A@SOP32
[(SA438T)]	
HY62V8400A@TSOP32 [(SA410T)]	
HY62VT08081E	
HY62VT08081E@SOP28 [(SA438T)]	HY62VT08081E@TSOP28
[(SA643)]	
HY62WT08081E	HY62WT08081E@SOP28

[(SA438T)]
HY62WT08081E@TSOP28 [(SA643)]

MICROCONTROLLER

GMS97C1051 [(SA404)]	GMS97C1051@SOIC20
GMS97C2051 [(SA404)]	GMS97C2051@SOIC20
GMS97C51 [(SA244)]	GMS97C51@PLCC44
GMS97C51@TQFP44 [(SA245A)]	
GMS97C52 GMS97C52@PLCC44 [(SA244)]	GMS97C52@TQFP44
[(SA245A)]	
GMS97C54 [(SA244)]	GMS97C54@PLCC44
GMS97C54@TQFP44 [(SA245A)]	
GMS97C56 GMS97C56@PLCC44 [(SA244)]	GMS97C56@TQFP44
[(SA245A)]	
GMS97C58 [(SA244)]	GMS97C58@PLCC44
GMS97C58@TQFP44 [(SA245A)]	
GMS97L1051 GMS97L1051@SOIC20 [(SA404)]	
GMS97L2051 GMS97L2051@SOIC20 [(SA404)]	
GMS97L51 GMS97L51@PLCC44 [(SA244)]	GMS97L51@TQFP44
[(SA245A)]	
GMS97L52 [(SA244)]	GMS97L52@PLCC44
GMS97L52@TQFP44 [(SA245A)]	
GMS97L54 GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44
[(SA245A)]	
GMS97L56 [(SA244)]	GMS97L56@PLCC44
GMS97L56@TQFP44 [(SA245A)]	
GMS97L58 GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44

[(SA245A)]	
GMS99C52	GMS99C52@PLCC44
[(SA244)]	
GMS99C52@TQFP44 [(SA245A)]	
GMS99C58	
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44
[(SA245A)]	
HMS99C52	HMS99C52@PLCC44
[(SA244)]	
HMS99C52@TQFP44 [(SA245A)]	
HMS99C58	
HMS99C58@PLCC44 [(SA244)]	HMS99C58@TQFP44
[(SA245A)]	

ICE

E (E) PROM / FRAM / NVRAM

ICE25P05	ICE25P05@SOIC8
[(SA602A)]	
ICE27C010	ICE27C010@PLCC32
[(SA015A1T)]	
ICE27C010@TSOP32 [(SA410T)]	
ICE27C020	
ICE27C020@PLCC32 [(SA015A1T)]	ICE27C020@TSOP32
[(SA410T)]	
ICE27C512	ICE27C512@PLCC32
[(SA015A1T)]	
ICE27C512@TSOP28 [(SA430T)]	
ICE27LC010	
ICE27LC010@PLCC32 [(SA015A1T)]	ICE27LC010@TSOP32
[(SA410T)]	
ICE27LC020	ICE27LC020@PLCC32
[(SA015A1T)]	
ICE27LC020@TSOP32 [(SA410T)]	
ICE27LC512	
ICE27LC512@PLCC32 [(SA015A1T)]	ICE27LC512@TSOP28
[(SA430T)]	
ICE28LF010	ICE28LF010@PLCC32
[(SA015A1T)]	
ICE37C512	ICE37C512@PLCC32
[(SA015A1T)]	

ICE37C512@TSOP32 [(SA410T)]

ICE37LC512

ICE37LC512@PLCC32 [(SA015A1T)]

ICE37LC512@TSOP32

[(SA410T)]

ICMIC

E(E) PROM/FRAM/NVRAM

X76F101

X76F101@SOIC8

[(SA602A)]

X76F400@SOIC8 [(SA602A)]

X76F400@TSSOP8

[(SA026)]

ICSI

E(E) PROM/FRAM/NVRAM

IC71V08F32AS04@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32AS04@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32AS08@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32BS04@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32BS04@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32BS08@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32CS04@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32CS04@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32CS08@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32DS04@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32DS04@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32DS08@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32ES04@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32ES04@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32ES08@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]

IC71V08F32FS04@FBGA64 [(SA642A-B032A-Y096F001)]

IC71V08F32FS04@FBGA73 [(SA642A-B032A-Y096F001)]

[(SA244)]	
IS89C51A@TQFP44 [(SA245A)]	
IS89C52A	
IS89C52A@PLCC44 [(SA244)]	IS89C52A@TQFP44
[(SA245A)]	
IS89C54	IS89C54@PLCC44
[(SA244)]	
IS89C54@TQFP44 [(SA245A)]	
IS89C58	
IS89C58@PLCC44 [(SA244)]	IS89C58@TQFP44
[(SA245A)]	
IS89C64	IS89C64@PLCC44
[(SA244)]	
IS89C64@TQFP44 [(SA245A)]	
IS89E54	
IS89E54@PLCC44 [(SA244)]	IS89E54@TQFP44
[(SA245A)]	
IS89E58	IS89E58@PLCC44
[(SA244)]	
IS89E58@TQFP44 [(SA245A)]	
IS89E64	
IS89E64@PLCC44 [(SA244)]	IS89E64@TQFP44
[(SA245A)]	

ICT

E (E) PROM / FRAM / NVRAM

27CX010	27CX010@PLCC32
[(SA015A1T)]	
27CX010@TSOP32 [(SA410T)]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[(SA602A)]	
93C46A	93C46A@SOIC8
[(SA602A)]	

93C56A	93C56A@SOIC8
[(SA602A)]	
93C66A	93C66A@SOIC8
[(SA602A)]	
93CX46	93CX46@SOIC8
[(SA602A)]	
93CX56	93CX56@SOIC8
[(SA602A)]	
93CX66	93CX66@SOIC8
[(SA602A)]	

PLD

PA7024	PA7024(J)@PLCC28
[(SA008A)]	
PA7024(JN)@PLCC28 [(SA008A)]	PA7024@SOIC24
[(SA404)]	
PA7128	PA7128@PLCC28
[(SA008A)]	
PA7128@SOIC28 [(SA404)]	
PA7140	
PA7140@PLCC44 [(SA244)]	PA7140@TQFP44
[(SA245A)]	
PA7536	PA7536@PLCC28
[(SA008A)]	
PA7536@SOIC28 [(SA404)]	
PA7540	
PA7540(J)@PLCC28 [(SA008A)]	PA7540(JN)@PLCC28
[(SA008A)]	
PA7572	PA7572@PLCC44
[(SA244)]	
PA7572@TQFP44 [(SA245A)]	
PEEL18CV8Z	
PEEL18CV8Z@PLCC20 [(SA001A)]	PEEL18CV8Z@SOIC20
[(SA404)]	
PEEL18CV8Z@TSOP20 [(SA026)]	
PEEL18LV8Z	
PEEL18LV8Z@PLCC20 [(SA001A)]	PEEL18LV8Z@SOIC20
[(SA404)]	
PEEL18LV8Z@TSOP20 [(SA026)]	
PEEL22CV10	
PEEL22CV10@PLCC28 [(SA008A)]	

PEEL22CV10A

PEEL22CV10A@PLCC28 [(SA008A)]
[(SA404)]

PEEL22CV10A@TSOP24 [(SA026)]

+

PEEL22CV10A+@PLCC28 [(SA008A)]
[(SA404)]

PEEL22CV10A+@TSOP24 [(SA026)]

+

PEEL22CV10A++@PLCC28 [(SA008A)]
[(SA404)]

PEEL22CV10A++@TSOP24 [(SA026)]

PEEL22CV10AZ

PEEL22CV10AZ@PLCC28 [(SA008A)]
[(SA404)]

PEEL22CV10AZ@TSOP24 [(SA026)]

+

PEEL22CV10AZ+@PLCC28 [(SA008A)]
[(SA404)]

PEEL22CV10AZ+@TSOP24 [(SA026)]

+

PEEL22CV10AZ++@PLCC28 [(SA008A)]
[(SA404)]

PEEL22CV10AZ++@TSOP24 [(SA026)]

PEEL22LV10AZ

PEEL22LV10AZ@PLCC28 [(SA008A)]
[(SA404)]

PEEL22LV10AZ@TSOP24 [(SA026)]

+

PEEL22LV10AZ+@PLCC28 [(SA008A)]
[(SA404)]

PEEL22LV10AZ+@TSOP24 [(SA026)]

+

PEEL22LV10AZ++@PLCC28 [(SA008A)]
[(SA404)]

PEEL22LV10AZ++@TSOP24 [(SA026)]

PEEL22CV10A@SOIC24

PEEL22CV10A

PEEL22CV10A+@SOIC24

PEEL22CV10A+

PEEL22CV10A++@SOIC24

PEEL22CV10AZ@SOIC24

PEEL22CV10AZ

PEEL22CV10AZ+@SOIC24

PEEL22CV10AZ+

PEEL22CV10AZ++@SOIC24

PEEL22LV10AZ@SOIC24

PEEL22LV10AZ

PEEL22LV10AZ+@SOIC24

PEEL22LV10AZ+

PEEL22LV10AZ++@SOIC24

IMT

E (E) PROM / FRAM / NVRAM

IM29F001B

IM29F001B@PLCC32

[(SA015A1T)]	
IM29F001B@TSOP32 [(SA410T)]	IM29F001B@VSOP32
[(SA620)]	
IM29F001T	IM29F001T@PLCC32
[(SA015A1T)]	
IM29F001T@TSOP32 [(SA410T)]	IM29F001T@VSOP32
[(SA620)]	
IM29F002B	IM29F002B@PLCC32
[(SA015A1T)]	
IM29F002B@TSOP32 [(SA410T)]	IM29F002B@VSOP32
[(SA620)]	
IM29F002T	IM29F002T@PLCC32
[(SA015A1T)]	
IM29F002T@TSOP32 [(SA410T)]	IM29F002T@VSOP32
[(SA620)]	
IM29F004B	IM29F004B@PLCC32
[(SA015A1T)]	
IM29F004B@TSOP32 [(SA410T)]	IM29F004B@VSOP32
[(SA620)]	
IM29F004T	IM29F004T@PLCC32
[(SA015A1T)]	
IM29F004T@TSOP32 [(SA410T)]	IM29F004T@VSOP32
[(SA620)]	
IM29LV004B	IM29LV004B@PLCC32
[(SA015A1T)]	
IM29LV004B@TSOP32 [(SA410T)]	IM29LV004B@VSOP32
[(SA620)]	
IM29LV004T	IM29LV004T@PLCC32
[(SA015A1T)]	
IM29LV004T@TSOP32 [(SA410T)]	IM29LV004T@VSOP32
[(SA620)]	
IM29LV400B@PSOP44 [(SA638)]	IM29LV400B@TSOP48 [(SA247-
B005)]	
IM29LV400T@PSOP44 [(SA638)]	IM29LV400T@TSOP48 [(SA247-
B005)]	

INTEL

E (E) PROM / FRAM / NVRAM

27010	27010@PLCC32
[(SA015A1T)]	

27010@TSOP32 [(SA410T)]
27128
27128A
27128B
2716
27210
27256
2732
2732A
27512
2764
2764A
27C010 27C010@PLCC32
[(SA015A1T)]
27C010@TSOP32 [(SA410T)]
27C010A
27C010A@PLCC32 [(SA015A1T)] 27C010A@TSOP32
[(SA410T)]
27C020 27C020@PLCC32
[(SA015A1T)]
27C020@TSOP32 [(SA410T)]
27C040
27C040@PLCC32 [(SA015A1T)] 27C040@TSOP32
[(SA410T)]
27C100 27C100@PLCC32
[(SA015A1T)]
27C100@TSOP32 [(SA410T)]
27C128
27C128@PLCC32 [(SA015A1T)]
27C210
27C210@PLCC44 [(SA244)]
27C220
27C220@PLCC44 [(SA244)]
27C240
27C240@PLCC44 [(SA244)]
27C256
27C256@PLCC32 [(SA015A1T)]
27C400
27C400@PLCC44 [(SA244)]
27C512
27C512@PLCC32 [(SA015A1T)]
27C64
27C64@PLCC32 [(SA015A1T)]

27C800
27S512
2816A
2817A
2864A
68C257 68C257@PLCC32
[(SA015A1T)]
87C256
87C257
87C257@PLCC32 [(SA015A1T)]
87C64
D27011
D27513
D27C011
D27C513
D28F256
D28F256A
D28F512
DA28F016SA@SSOP56 [(SA629A-B013)]
DA28F016SV@SSOP56 [(SA629A-B013)]
DA28F320J5(low)@SSOP56 [(SA629-B013)]
DA28F320J5@SSOP56 [(SA629A-B013)]
DA28F320J5A(low)@SSOP56 [(SA629-B013)]
DA28F320J5A@SSOP56 [(SA629A-B013)]
DA28F640J5@SSOP56 [(SA629A-B013)]
DA28F640J5A@SSOP56 [(SA629A-B013)]
DD28F032SA@TSOP56 [(SA628-B011)]
DT28F016SA@SSOP56 [(SA629A-B013)]
DT28F016SA@TSOP56 [(SA628-B011)]
DT28F016SV@SSOP56 [(SA629A-B013)]
DT28F016SV@TSOP56 [(SA628-B011)]
DT28F160F3B@SSOP56 [(SA629A-B015)]
DT28F160F3T@SSOP56 [(SA629A-B015)]
DT28F160S3@SSOP56 [(SA629A-B013)]
DT28F160S5@SSOP56 [(SA629A-B013)]
DT28F320J5@SSOP56 [(SA629A-B013)]
DT28F320J5A@SSOP56 [(SA629A-B013)]
DT28F320S3@SSOP56 [(SA629A-B013)]
DT28F320S5@SSOP56 [(SA629A-B013)]
DT28F640J5@SSOP56 [(SA629A-B013)]
DT28F640J5A@SSOP56 [(SA629A-B013)]
DT28F800F3B@SSOP56 [(SA629A-B015)]
DT28F800F3T@SSOP56 [(SA629A-B015)]

E28F001BX-B@TSOP32 [(SA410T)] [(SA410T)]	E28F001BX-T@TSOP32
E28F002BCT@TSOP40 [(SA409T)] [(SA409T)]	E28F002BEB@TSOP40
E28F002BET@TSOP40 [(SA409T)] [(SA409T)]	E28F002BLB@TSOP40
E28F002BLT@TSOP40 [(SA409T)] [(SA409T)]	E28F002BVB@TSOP40
E28F002BVT@TSOP40 [(SA409T)] [(SA409T)]	E28F002BXB@TSOP40
E28F002BXT@TSOP40 [(SA409T)] [(SA409T)]	E28F004B5B@TSOP40
E28F004B5T@TSOP40 [(SA409T)] [(SA409T)]	E28F004BEB@TSOP40
E28F004BET@TSOP40 [(SA409T)] [(SA409T)]	E28F004BLB@TSOP40
E28F004BLT@TSOP40 [(SA409T)] [(SA409T)]	E28F004BVB@TSOP40
E28F004BVT@TSOP40 [(SA409T)] [(SA409T)]	E28F004BXB@TSOP40
E28F004BXT@TSOP40 [(SA409T)] [(SA409T)]	E28F004S3@TSOP40
E28F004S5@TSOP40 [(SA409T)] [(SA409T)]	E28F004SC@TSOP40
E28F008BEB@TSOP40 [(SA409T)] [(SA409T)]	E28F008BET@TSOP40
E28F008BLB@TSOP40 [(SA409T)] [(SA409T)]	E28F008BLT@TSOP40
E28F008BVB@TSOP40 [(SA409T)] [(SA409T)]	E28F008BVT@TSOP40
E28F008BXB@TSOP40 [(SA409T)] [(SA409T)]	E28F008BXT@TSOP40
E28F008S3@TSOP40 [(SA409T)] [(SA409T)]	E28F008S5@TSOP40
E28F008SA@TSOP40 [(SA409T)] [(SA409T)]	E28F008SA-L@TSOP40
E28F008SC@TSOP40 [(SA409T)] [(SA410T)]	E28F010@TSOP32
E28F016S3@TSOP40 [(SA409T)] [(SA409T)]	E28F016S5@TSOP40
E28F016SA@TSOP56 [(SA628-B011)] [(SA409T)]	E28F016SC@TSOP40
E28F016SV@TSOP56 [(SA628-B011)]	E28F020@TSOP32

[(SA410T)]
E28F128J3A@TSOP56 [(SA628-B018)] E28F200B5B@TSOP48 [(SA247-B005)]
E28F200B5T@TSOP48 [(SA247-B005)] E28F200BVB@TSOP56 [(SA628-B012)]
E28F200BVT@TSOP56 [(SA628-B012)] E28F200BXB@TSOP56 [(SA628-B012)]
E28F200BXT@TSOP56 [(SA628-B012)] E28F200CVB@TSOP48 [(SA247-B005)]
E28F200CVT@TSOP48 [(SA247-B005)] E28F256@TSOP32
[(SA410T)]
E28F256A@TSOP32 [(SA410T)] E28F320J3A@TSOP56 [(SA628-B018)]
E28F320J5(low)@TSOP56 [(SA628-B011)]
E28F320J5@TSOP56 [(SA628-B011)]
E28F320J5A(low)@TSOP56 [(SA628-B011)]
E28F320J5A@TSOP56 [(SA628-B011)] E28F400B5B@TSOP48 [(SA247-B005)]
E28F400B5T@TSOP48 [(SA247-B005)] E28F400BVB@TSOP56 [(SA628-B012)]
E28F400BVT@TSOP56 [(SA628-B012)] E28F400BXB@TSOP56 [(SA628-B012)]
E28F400BXT@TSOP56 [(SA628-B012)] E28F400CVB@TSOP48 [(SA247-B005)]
E28F400CVT@TSOP48 [(SA247-B005)] E28F512@TSOP32
[(SA410T)]
E28F640J3A@TSOP56 [(SA628-B018)] E28F800B5B@TSOP48 [(SA247-B005)]
E28F800B5T@TSOP48 [(SA247-B005)] E28F800CEB@TSOP48 [(SA247-B005)]
E28F800CET@TSOP48 [(SA247-B005)] E28F800CVB@TSOP48 [(SA247-B005)]
E28F800CVT@TSOP48 [(SA247-B005)] E82802AA@TSOP40
[(SA409T)]
E82802AB@TSOP40 [(SA409T)] E82802AC@TSOP40
[(SA409T)]
F28F010@TSOP32 [(SA410T)] F28F020@TSOP32
[(SA410T)]
F28F256@TSOP32 [(SA410T)] F28F256A@TSOP32
[(SA410T)]
F28F512@TSOP32 [(SA410T)]
G28F640J5@uBGA56 [(SA644A-B028A-Y072F001Y)]
G28F640J5A@uBGA56 [(SA644A-B028A-Y072F001Y)]

GE28F008B3BA@uBGA48 [(SA634)] GE28F008B3TA@uBGA48
[(SA634)]
GE28F128K18C@FBGA56 [(SA656D-B085A-T056F001Y)]
GE28F128K3C@FBGA56 [(SA656D-B085A-T056F001Y)]
GE28F128L18B@VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F128L18T@VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F128L30B@VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F128L30T@VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]
GE28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]
GE28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]
GE28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]
GE28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]
GE28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]
GE28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]
GE28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]
GE28F128W30BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]
GE28F128W30BC@VFBGA56 [(SA656A-B085A-Y056F001)]
GE28F128W30BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]
GE28F128W30BD@VFBGA56 [(SA656E-B085A-W056F001)]
GE28F128W30TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]
GE28F128W30TC@VFBGA56 [(SA656A-B085A-Y056F001)]
GE28F128W30TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]
GE28F128W30TD@VFBGA56 [(SA656E-B085A-W056F001)]
GE28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F160B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F160B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F160C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F160C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F160C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F160C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F256K18C@FBGA79 [(SA656B-B103A-T063F001Y)]
GE28F256K3C@FBGA79 [(SA656B-B103A-T063F001Y)]
GE28F256L18B@VFBGA79 [(SA656B-B103A-T063F001)]
GE28F256L18T@VFBGA79 [(SA656B-B103A-T063F001)]
GE28F256L30B@VFBGA79 [(SA656B-B103A-T063F001)]

GE28F256L30T@VFBGA79 [(SA656B-B103A-T063F001)]
GE28F320B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F320B3TC@uBGA48 [(SA634A-B005A-Y048F001)]
GE28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]
GE28F320C3BC(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F320C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F320C3BD(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F320C3TC(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F320C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F320C3TD(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F320J3A@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F320J3C@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F320W18BC(NO EFP)VFBGA56 [(SA656C-B104A-T056F001Y)]
GE28F320W18BC@VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]
GE28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]
GE28F320W18TC(NO EFP)VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F320W18TC@VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]
GE28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]
GE28F320W30BC(NO EFP)VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F320W30BC@VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F320W30TC(NO EFP)VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F320W30TC@VFBGA56 [(SA644A-B025B-Y072F001)]
GE28F640B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F640B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F640C3BC(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F640C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F640C3TC(Moto)VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F640C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F640J3C@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F640K18C@FBGA56 [(SA644A-B025B-Y072F001Y)]
GE28F640K3C@FBGA56 [(SA644A-B025B-Y072F001Y)]
GE28F640L18B@VFBGA56 [(SA644A-B025A-Y056F001)]
GE28F640L18T@VFBGA56 [(SA644A-B025A-Y056F001)]
GE28F640L30B@VFBGA56 [(SA644A-B025A-Y056F001)]
GE28F640L30T@VFBGA56 [(SA644A-B025A-Y056F001)]
GE28F640W18BC(NO EFP)uBGA56 [(SA644A-B025B-Y072F001)]
GE28F640W18BC@uBGA56 [(SA644A-B025B-Y072F001)]
GE28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]

GE28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]
GE28F640W18TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]
GE28F640W18TC@uBGA56 [(SA644A-B025B-Y072F001)]
GE28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]
GE28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]
GE28F640W30BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]
GE28F640W30BC@uBGA56 [(SA644A-B025B-Y072F001)]
GE28F640W30TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]
GE28F640W30TC@uBGA56 [(SA644A-B025B-Y072F001)]
GE28F800B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F800B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]
GE28F800C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F800C3BA@VFBGA48 [(SA634A-B005A-Y048F001)]
GE28F800C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GE28F800C3TA@VFBGA48 [(SA634A-B005A-Y048F001)]
GT28F016C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F016C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F032C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F032C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F128W30BC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]
GT28F128W30BC@uBGA56 [(SA656A-B085A-Y056F001)]
GT28F128W30BD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]
GT28F128W30BD@uBGA56 [(SA656E-B085A-W056F001)]
GT28F128W30TC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]
GT28F128W30TC@uBGA56 [(SA656A-B085A-Y056F001)]
GT28F128W30TD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]
GT28F128W30TD@uBGA56 [(SA656E-B085A-W056F001)]
GT28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F160B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F160B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F160C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GT28F160C3BA@uBGA48 [(SA634A-B005A-Y048F001)]
GT28F160C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GT28F160C3TA@uBGA48 [(SA634A-B005A-Y048F001)]
GT28F320B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F320B3T@uBGA48 [(SA634A-B005A-Y048F001)]
GT28F320C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GT28F320C3BA@uBGA48 [(SA634A-B005A-Y048F001)]
GT28F320C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
GT28F320C3TA@uBGA48 [(SA634A-B005A-Y048F001)]
GT28F800B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]
GT28F800B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]

JS28F128J3C@TSOP56 [(SA628-B018)]
JS28F128J3D@TSOP56 [(SA628-B018)]
JS28F128P30B@TSOP56 [(SA628-B131)]
JS28F128P30T@TSOP56 [(SA628-B131)]
JS28F128P33B@TSOP56 [(SA628-B131)]
JS28F128P33T@TSOP56 [(SA628-B131)]
JS28F160B3BD@TSOP48 [(SA247-B005)]
JS28F160B3TD@TSOP48 [(SA247-B005)]
JS28F160C3BD@TSOP48 [(SA247-B005)]
JS28F160C3TD@TSOP48 [(SA247-B005)]
JS28F256P30B@TSOP56 [(SA628-B131)]
JS28F256P30T@TSOP56 [(SA628-B131)]
JS28F256P33B@TSOP56 [(SA628-B131)]
JS28F256P33T@TSOP56 [(SA628-B131)]
JS28F320B3BD@TSOP48 [(SA247-B005)]
JS28F320B3TD@TSOP48 [(SA247-B005)]
JS28F320C3BD@TSOP48 [(SA247-B005)]
JS28F320C3TD@TSOP48 [(SA247-B005)]
JS28F320J3C@TSOP56 [(SA628-B018)]
JS28F320J3D@TSOP56 [(SA628-B018)]
JS28F640J3C@TSOP56 [(SA628-B018)]
JS28F640J3D@TSOP56 [(SA628-B018)]
JS28F640P30B(Low)@TSOP56 [(SA628-B131)]
JS28F640P30B@TSOP56 [(SA628-B131)]
JS28F640P30T@TSOP56 [(SA628-B131)]
JS28F640P33B@TSOP56 [(SA628-B131)]
JS28F640P33T@TSOP56 [(SA628-B131)]
JS28F800C3BD@TSOP48 [(SA247-B005)]
JS28F800C3TD@TSOP48 [(SA247-B005)]
JZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
JZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
JZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
JZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
LZ38F4060L0YBB0@FBGA103 [(SA664F-B157A-W108F001Y)]
LZ38F4060L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]
M28F010 M28F010@PLCC32
[(SA015A1T)]
M28F010@TSOP32 [(SA410T)] N28F001BN-B@PLCC32
[(SA015A1T)]
N28F001BN-T@PLCC32 [(SA015A1T)] N28F001BX-B@PLCC32
[(SA015A1T)]
N28F001BX-T@PLCC32 [(SA015A1T)] N28F010@PLCC32
[(SA015A1T)]

N28F020@PLCC32 [(SA015A1T)]	N28F256@PLCC32
[(SA015A1T)]	
N28F256A@PLCC32 [(SA015A1T)]	N28F512@PLCC32
[(SA015A1T)]	
N82802AA@PLCC32 [(SA015A1T)]	N82802AB@PLCC32
[(SA015A1T)]	
N82802AC@PLCC32 [(SA015A1T)]	
NZ48F4000LOYBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]	
NZ48F4000LOYTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]	
NZ48F4000LOZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]	
NZ48F4000LOZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]	
P27011	
P27128A	
P27128A@PLCC32 [(SA015A1T)]	
P27128B	
P27128B@PLCC32 [(SA015A1T)]	
P27256	
P27256@PLCC32 [(SA015A1T)]	
P27512	
P27513	
P2764A	
P2764A@PLCC32 [(SA015A1T)]	
P27C011	
P27C128	P27C128@PLCC32
[(SA015A1T)]	
P27C256	P27C256@PLCC32
[(SA015A1T)]	
P27C513	
P27C64	
P27C64@PLCC32 [(SA015A1T)]	P28F001BX-
B	
P28F001BX-T	P28F002BCT@TSOP40
[(SA409T)]	
P28F010	
P28F020	
P28F256	
P28F256A	
P28F512	
P87C64	
P87C64@PLCC32 [(SA015A1T)]	PA28F004S3@PSOP44
[(SA638)]	
PA28F004S5@PSOP44 [(SA638)]	PA28F004SC@PSOP44
[(SA638)]	

PA28F008S3@PSOP44 [(SA638)]	PA28F008S5@PSOP44
[(SA638)]	
PA28F008SA@PSOP44 [(SA638)]	PA28F008SA-L@PSOP44
[(SA638)]	
PA28F008SC@PSOP44 [(SA638)]	PA28F016S3@PSOP44
[(SA638)]	
PA28F016S5@PSOP44 [(SA638)]	PA28F016SC@PSOP44
[(SA638)]	
PA28F200B5B@PSOP44 [(SA638)]	PA28F200B5T@PSOP44
[(SA638)]	
PA28F200BVB@PSOP44 [(SA638)]	PA28F200BVT@PSOP44
[(SA638)]	
PA28F200BXB@PSOP44 [(SA638)]	PA28F200BXT@PSOP44
[(SA638)]	
PA28F400B5B@PSOP44 [(SA638)]	PA28F400B5T@PSOP44
[(SA638)]	
PA28F400BVB@PSOP44 [(SA638)]	PA28F400BVT@PSOP44
[(SA638)]	
PA28F400BXB@PSOP44 [(SA638)]	PA28F400BXT@PSOP44
[(SA638)]	
PA28F800B5B@PSOP44 [(SA638)]	PA28F800B5T@PSOP44
[(SA638)]	
PA28F800BVB@PSOP44 [(SA638)]	PA28F800BVT@PSOP44
[(SA638)]	
PC28F128J3C@FBGA64 [(SA655A-B054A-T064F001Y)]	
PC28F128J3D@FBGA64 [(SA655A-B054A-T064F001Y)]	
PC28F128P30B@EBGA64 [(SA655G-B122A-T064F001Y)]	
PC28F128P30T@EBGA64 [(SA655G-B122A-T064F001Y)]	
PC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]	
PC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]	
PC28F160C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]	
PC28F160C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]	
PC28F256P30B@EBGA64 [(SA655G-B122A-T064F001Y)]	
PC28F256P30T@EBGA64 [(SA655G-B122A-T064F001Y)]	
PC28F256P33B@EBGA64 [(SA655G-B122A-T064F001Y)]	
PC28F256P33T@EBGA64 [(SA655G-B122A-T064F001Y)]	
PC28F320C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]	
PC28F320C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]	
PC28F320J3C@FBGA64 [(SA655A-B054A-T064F001Y)]	
PC28F320J3D@FBGA64 [(SA655A-B054A-T064F001Y)]	
PC28F640J3C@FBGA64 [(SA655A-B054A-T064F001Y)]	
PC28F640J3D@FBGA64 [(SA655A-B054A-T064F001Y)]	
PC28F640P30B@EBGA64 [(SA655G-B122A-T064F001Y)]	

PC28F640P30T@EBGA64 [(SA655G-B122A-T064F001Y)]
PC28F640P33B@EBGA64 [(SA655K-B122A-T064F001Y)]
PC28F640P33T@EBGA64 [(SA655K-B122A-T064F001Y)]
PC28F800C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]
PC28F800C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]
PF38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1030C0ZBL0@FBGA72 [(SA642R-B041A-T096F001Y)]
PF38F1030C0ZTL0@FBGA72 [(SA642R-B041A-T096F001Y)]
PF38F1030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1030W0YCQ3@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F1030W0YCQE@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F1030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1030W0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F1030W0YUQE@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F1030W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1030W0ZTQ0 (SLOW) @FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F1030W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2020W0ZBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2020W0ZTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0YCQ3@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2030W0YCQE@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2030W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2030W0YUQE@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2030W0ZBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2030W0ZTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2040W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F2040W0YCQ1@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2040W0YCQ3@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2040W0YCQE@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2040W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]

PF38F2040W0YUQ1@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2040W0YUQ3@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2040W0YUQE@FBGA88 [(SA642R-B180A-T096F001Y)]
PF38F2040W0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F2040W0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F3040L0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F3040L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3040L0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F3040L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3040L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3040L0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
PF38F3040L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3040L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F3040L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3040L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F3040M0Y1QE@FBGA88 [(SA642R-B303A-T096F001Y)]
PF38F3040M0Y3QE@FBGA88 [(SA642R-B303A-T096F001Y)]
PF38F3050L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3050L0YBQ2@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3050L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3050L0YTQ2@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3050L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F3050L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]
PF38F3050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F3350LLZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
PF38F3350W0ZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
PF38F3350WWZDQ1@FBGA88 [(SA642R-B137A-T096F001Y)]
PF38F4050L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4050L0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4050L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4050L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4050L0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4050L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4050L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4050L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4055L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4055L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
PF38F4060L0YBB0@FBGA103 [(SA664F-B157A-W108F001Y)]
PF38F4060L0YBB1@FBGA103 [(SA664F-B157A-W108F001Y)]
PF38F4060L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]

PF38F4060L0YTB1@FBGA103 [(SA664F-B157A-W108F001Y)]
PF38F4450LLYBQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]
PF38F4450LLYTQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]
PF38F4450LVYBQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]
PF38F4450LVYBQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]
PF38F4450LVYTQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]
PF38F4450LVYTQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]
PF38F4466LVYBQ0@FBGA88 [(SA642A-B125A-Y096N001N)]
PF38F4466LVYTQ0@FBGA88 [(SA642A-B125A-Y096N001N)]
PF48F2000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
PF48F2000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
PF48F2000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
PF48F2000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
PF48F3000L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]
PF48F3000L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]
PF48F3000L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]
PF48F3000L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]
PF48F3000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
PF48F3000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
PF48F3000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
PF48F3000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
PF48F3000W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
PF48F3000W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
PF48F3000W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
PF48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
PF48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
PF48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
PF48F3300W0YTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
PF48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
PF48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
PF48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
PF48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
PF48F4040LVYBQ0 (BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]
PF48F4040LVYBQ0 (BP)@FBGA88 [(SA642A-B113A-Y096F001)]
PF48F4040LVYTQ0 (BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]
PF48F4040LVYTQ0 (BP)@FBGA88 [(SA642A-B113A-Y096F001)]
PF48F5000M0Y1B0@FBGA105 [(SA664F-B301A-W108F001N)]
PH28F128W18BC (NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]
PH28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]
PH28F128W18BD (NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]
PH28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]
PH28F128W18TC (NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]
PH28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]

PH28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]
PH28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]
PH28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]
PH28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]
PH28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
PH28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]
PH28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
PH28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]
PH28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]
PH28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]
PH28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
PH28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]
PH28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]
PH28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]
PH28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]
PH28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]
PH28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]
PH28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]
PH28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]
PH28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]
PH28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]
PH28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]
QB25F016S33B60@SOIC8 [(SA605A)] QB25F016S33T60@SOIC8
[(SA605A)]
QB25F160S33B60@SOIC16 [(SA404)] QB25F160S33T60@SOIC16
[(SA404)]
QB25F320S33B60@SOIC16 [(SA404)] QB25F320S33T60@SOIC16
[(SA404)]
QB25F640S33B60@SOIC16 [(SA404)] QB25F640S33T60@SOIC16
[(SA404)]
QH25F016S33B60@SOIC8 [(SA605A)] QH25F016S33T60@SOIC8
[(SA605A)]
QH25F160S33B60@SOIC16 [(SA404)] QH25F160S33T60@SOIC16
[(SA404)]
QH25F320S33B60@SOIC16 [(SA404)] QH25F320S33T60@SOIC16
[(SA404)]
QH25F640S33B60@SOIC16 [(SA404)] QH25F640S33T60@SOIC16
[(SA404)]
RC28F128J3A@FBGA64 [(SA655A-B054A-T064F001)]
RC28F128J3C@FBGA64 [(SA655A-B054A-T064F001)]
RC28F128J3D@FBGA64 [(SA655A-B054A-T064F001Y)]
RC28F128K18C@FBGA64 [(SA655G-B122A-T064F001Y)]
RC28F128K3C@FBGA64 [(SA655G-B122A-T064F001Y)]

RC28F128P30B@EBGA64 [(SA655G-B122A-T064F001Y)]
RC28F128P30T@EBGA64 [(SA655G-B122A-T064F001Y)]
RC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]
RC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]
RC28F160C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F160C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F160C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F160C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F160C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F160C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F256J3A@FBGA96 [(SA642A-B273-Y096N001N)]
RC28F256J3C@FBGA64 [(SA655M-B054A-T064F001Y)]
RC28F256K18C@FBGA64 [(SA655L-B286A-T064F001Y)]
RC28F256K3C@FBGA64 [(SA655L-B286A-T064F001Y)]
RC28F256P30B@EBGA64 [(SA655G-B122A-T064F001Y)]
RC28F256P30T@EBGA64 [(SA655G-B122A-T064F001Y)]
RC28F256P33B@EBGA64 [(SA655G-B122A-T064F001Y)]
RC28F256P33T@EBGA64 [(SA655G-B122A-T064F001Y)]
RC28F320C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F320C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F320C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F320C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F320C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F320C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F320J3A@FBGA64 [(SA655A-B054A-T064F001)]
RC28F320J3C@FBGA64 [(SA655A-B054A-T064F001)]
RC28F320J3D@FBGA64 [(SA655A-B054A-T064F001Y)]
RC28F640C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F640C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F640J3A@FBGA64 [(SA655A-B054A-T064F001)]
RC28F640J3C@FBGA64 [(SA655A-B054A-T064F001)]
RC28F640J3D@FBGA64 [(SA655A-B054A-T064F001Y)]
RC28F640K18C@FBGA64 [(SA655G-B122A-T064F001Y)]
RC28F640K3C@FBGA64 [(SA655G-B122A-T064F001Y)]
RC28F640P30B@EBGA64 [(SA655G-B122A-T064F001Y)]
RC28F640P30T@EBGA64 [(SA655G-B122A-T064F001Y)]
RC28F640P33B@EBGA64 [(SA655K-B122A-T064F001Y)]
RC28F640P33T@EBGA64 [(SA655K-B122A-T064F001Y)]
RC28F800C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F800C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F800C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]
RC28F800C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]
RD28F1602C3B@FBGA72 [(SA642E-B041A-T072F001)]

RD28F1602C3T@FBGA72 [(SA642E-B041A-T072F001)]
RD28F1604C3B@FBGA72 [(SA642E-B041A-T072F001)]
RD28F1604C3T@FBGA72 [(SA642E-B041A-T072F001)]
RD28F3204C3B@FBGA72 [(SA642E-B041A-T072F001)]
RD28F3204C3T@FBGA72 [(SA642E-B041A-T072F001)]
RD28F3204W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F3204W18B@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F3204W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F3204W18T@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F3204W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F3204W30B@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F3204W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F3204W30T@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F3208C3B@FBGA72 [(SA642E-B041A-T072F001)]
RD28F3208C3T@FBGA72 [(SA642E-B041A-T072F001)]
RD28F6408W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F6408W18B@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F6408W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F6408W18T@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F6408W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F6408W30B@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F6408W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]
RD28F6408W30T@FBGA96 [(SA642L-B082A-W080F001Y)]
RD38F1010C0ZB@FBGA72 [(SA642E-B041A-T072F001)]
RD38F1010C0ZT@FBGA72 [(SA642E-B041A-T072F001)]
RD38F1010W0YTL0@FBGA67 [(SA642E-B041A-T072F001N)]
RD38F1020C0ZB@FBGA72 [(SA642E-B041A-T072F001)]
RD38F1020C0ZT@FBGA72 [(SA642E-B041A-T072F001)]
RD38F1020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F1020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F1030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F1030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F1030W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F1030W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2010W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2010W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2010W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2010W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2020W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]

RD38F2020W0ZBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2020W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2020W0ZTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0ZBQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZBQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2030W0ZTQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZTQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2030W0ZTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F2040W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2040W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F2220WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2220WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2230WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]

RD38F2240WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F2240WWZDQ1@FBGA88 [(SA642A-B113A-Y096F001Y)]
RD38F2240WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD38F3040L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F3040L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]
RD38F3040L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3040L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0YBQ2@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0YTQ2@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F3050L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD38F3050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F3340LLYDQ1@FBGA88 [(SA642A-B091A-Y096F001)]
RD38F3350LLZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
RD38F3350W0ZDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
RD38F3350WWZDQ1@FBGA88 [(SA642R-B137A-T096F001Y)]
RD38F4050L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4050L0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4055L0YBQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4055L0YTQ2@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4055L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4055L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD38F4450LVYBQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]
RD38F4450LVYBQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]
RD38F4450LVYTQ0@FBGA88 [(SA642A-B125A-Y096F001Y)]
RD38F4450LVYTQ2@FBGA88 [(SA642A-B125A-Y096F001Y)]

RD48F2000L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD48F2000L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD48F2000L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD48F2000L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD48F2000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
RD48F2000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
RD48F2000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
RD48F2000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
RD48F2000W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD48F2000W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD48F2000W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD48F2000W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]
RD48F2100W0YBQ0@FBGA88 [(SA642A-B113A-Y096F001Y)]
RD48F2100W0YDQE@FBGA88 [(SA642A-B113A-Y096F001Y)]
RD48F2100W0YTQ0@FBGA88 [(SA642A-B113A-Y096F001Y)]
RD48F2200W0YBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD48F2200W0YDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD48F2200W0YTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD48F2200W0ZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD48F2200W0ZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD48F2200W0ZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]
RD48F3000L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD48F3000L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD48F3000L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD48F3000L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]
RD48F3000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
RD48F3000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
RD48F3000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
RD48F3000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
RD48F3000W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD48F3000W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD48F3000W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]
RD48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
RD48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
RD48F3300W0YTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]
RD48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
RD48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]
RD48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
RD48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]
RD48F4040LVYBQ0 (BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]
RD48F4040LVYBQ0 (BP)@FBGA88 [(SA642A-B113A-Y096F001)]
RD48F4040LVYTQ0 (BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]

RD48F4040LVYTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]
RD48F4040LVZBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]
RD48F4040LVZBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]
RD48F4040LVZTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]
RD48F4040LVZTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]
TB28F004S3@PSOP44 [(SA638)] TB28F004S5@PSOP44
[(SA638)]
TB28F004SC@PSOP44 [(SA638)] TB28F008S3@PSOP44
[(SA638)]
TB28F008S5@PSOP44 [(SA638)] TB28F008SA@PSOP44
[(SA638)]
TB28F008SA-L@PSOP44 [(SA638)] TB28F008SC@PSOP44
[(SA638)]
TB28F016S3@PSOP44 [(SA638)] TB28F016S5@PSOP44
[(SA638)]
TB28F016SC@PSOP44 [(SA638)] TB28F200B5B@PSOP44
[(SA638)]
TB28F200B5T@PSOP44 [(SA638)] TB28F200BVB@PSOP44
[(SA638)]
TB28F200BVT@PSOP44 [(SA638)] TB28F200BXB@PSOP44
[(SA638)]
TB28F200BXT@PSOP44 [(SA638)] TB28F400B5B@PSOP44
[(SA638)]
TB28F400B5T@PSOP44 [(SA638)] TB28F400BVB@PSOP44
[(SA638)]
TB28F400BVT@PSOP44 [(SA638)] TB28F400BXB@PSOP44
[(SA638)]
TB28F400BXT@PSOP44 [(SA638)] TB28F800B5B@PSOP44
[(SA638)]
TB28F800B5T@PSOP44 [(SA638)] TB28F800BVB@PSOP44
[(SA638)]
TB28F800BVT@PSOP44 [(SA638)] TE28F002BEB@TSOP40
[(SA409T)]
TE28F002BET@TSOP40 [(SA409T)] TE28F002BVB@TSOP40
[(SA409T)]
TE28F002BVT@TSOP40 [(SA409T)] TE28F002BXB@TSOP40
[(SA409T)]
TE28F002BXT@TSOP40 [(SA409T)] TE28F004BEB@TSOP40
[(SA409T)]
TE28F004BET@TSOP40 [(SA409T)] TE28F004BVB@TSOP40
[(SA409T)]
TE28F004BVT@TSOP40 [(SA409T)] TE28F004BXB@TSOP40
[(SA409T)]

TE28F004BXT@TSOP40 [(SA409T)]	TE28F004S3@TSOP40
[(SA409T)]	
TE28F004S5@TSOP40 [(SA409T)]	TE28F004SC@TSOP40
[(SA409T)]	
TE28F008B3B@TSOP40 [(SA409T)]	TE28F008B3BA@TSOP40
[(SA409T)]	
TE28F008B3T@TSOP40 [(SA409T)]	TE28F008B3TA@TSOP40
[(SA409T)]	
TE28F008BEB@TSOP40 [(SA409T)]	TE28F008BET@TSOP40
[(SA409T)]	
TE28F008BVB@TSOP40 [(SA409T)]	TE28F008BVT@TSOP40
[(SA409T)]	
TE28F008C3BA@TSOP40 [(SA409T)]	TE28F008C3TA@TSOP40
[(SA409T)]	
TE28F008S3@TSOP40 [(SA409T)]	TE28F008S5@TSOP40
[(SA409T)]	
TE28F008SA@TSOP40 [(SA409T)]	TE28F008SA-L@TSOP40
[(SA409T)]	
TE28F008SC@TSOP40 [(SA409T)]	TE28F016B3B@TSOP40
[(SA409T)]	
TE28F016B3T@TSOP40 [(SA409T)]	TE28F016C3BA@TSOP40
[(SA409T)]	
TE28F016C3TA@TSOP40 [(SA409T)]	TE28F016S3@TSOP40
[(SA409T)]	
TE28F016S5@TSOP40 [(SA409T)]	TE28F016SC@TSOP40
[(SA409T)]	
TE28F128J3C@TSOP56 [(SA628-B018)]	
TE28F128J3D@TSOP56 [(SA628-B018)]	
TE28F128P30B@TSOP56 [(SA628-B131)]	
TE28F128P30T@TSOP56 [(SA628-B131)]	
TE28F128P33B@TSOP56 [(SA628-B131)]	
TE28F128P33T@TSOP56 [(SA628-B131)]	
TE28F160B3B@TSOP48 [(SA247-B005)]	
TE28F160B3BA@TSOP48 [(SA247-B005)]	
TE28F160B3BC@TSOP48 [(SA247-B005)]	
TE28F160B3BD@TSOP48 [(SA247-B005)]	
TE28F160B3T@TSOP48 [(SA247-B005)]	
TE28F160B3TA@TSOP48 [(SA247-B005)]	
TE28F160B3TC@TSOP48 [(SA247-B005)]	
TE28F160B3TD@TSOP48 [(SA247-B005)]	
TE28F160C3BA@TSOP48 [(SA247-B005)]	
TE28F160C3BC@TSOP48 [(SA247-B005)]	
TE28F160C3BD@TSOP48 [(SA247-B005)]	

TE28F160C3TA@TSOP48 [(SA247-B005)]
TE28F160C3TC@TSOP48 [(SA247-B005)]
TE28F160C3TD@TSOP48 [(SA247-B005)]
TE28F160F3B@TSOP56 [(SA628-B014)]
TE28F160F3T@TSOP56 [(SA628-B014)]
TE28F160S3@TSOP56 [(SA628-B011)] TE28F160S5@TSOP56 [(SA628-B011)]
TE28F200B5B@TSOP48 [(SA247-B005)]
TE28F200B5T@TSOP48 [(SA247-B005)]
TE28F200BVB@TSOP56 [(SA628-B012)]
TE28F200BVT@TSOP56 [(SA628-B012)]
TE28F200BXB@TSOP56 [(SA628-B012)]
TE28F200BXT@TSOP56 [(SA628-B012)]
TE28F200CEB@TSOP56 [(SA628-B012)]
TE28F200CET@TSOP56 [(SA628-B012)]
TE28F200CVB@TSOP48 [(SA247-B005)]
TE28F200CVT@TSOP48 [(SA247-B005)]
TE28F256J3C@TSOP56 [(SA628-B018)]
TE28F256P30B@TSOP56 [(SA628-B131)]
TE28F256P30T@TSOP56 [(SA628-B131)]
TE28F256P33B@TSOP56 [(SA628-B131)]
TE28F256P33T@TSOP56 [(SA628-B131)]
TE28F320B3B@TSOP48 [(SA247-B005)]
TE28F320B3BA@TSOP48 [(SA247-B005)]
TE28F320B3BC@TSOP48 [(SA247-B005)]
TE28F320B3BD@TSOP48 [(SA247-B005)]
TE28F320B3T@TSOP48 [(SA247-B005)]
TE28F320B3TA@TSOP48 [(SA247-B005)]
TE28F320B3TC@TSOP48 [(SA247-B005)]
TE28F320B3TD@TSOP48 [(SA247-B005)]
TE28F320C3BA@TSOP48 [(SA247-B005)]
TE28F320C3BC@TSOP48 [(SA247-B005)]
TE28F320C3BD@TSOP48 [(SA247-B005)]
TE28F320C3TA@TSOP48 [(SA247-B005)]
TE28F320C3TC@TSOP48 [(SA247-B005)]
TE28F320C3TD@TSOP48 [(SA247-B005)]
TE28F320J3C@TSOP56 [(SA628-B018)]
TE28F320J3D@TSOP56 [(SA628-B018)]
TE28F400B3B@TSOP48 [(SA247-B005)]
TE28F400B3T@TSOP48 [(SA247-B005)]
TE28F400B5B@TSOP48 [(SA247-B005)]
TE28F400B5T@TSOP48 [(SA247-B005)]
TE28F400BVB@TSOP56 [(SA628-B012)]

TE28F400BVT@TSOP56 [(SA628-B012)]
TE28F400BXB@TSOP56 [(SA628-B012)]
TE28F400BXT@TSOP56 [(SA628-B012)]
TE28F400CEB@TSOP48 [(SA247-B005)]
TE28F400CET@TSOP48 [(SA247-B005)]
TE28F400CVB@TSOP48 [(SA247-B005)]
TE28F400CVT@TSOP48 [(SA247-B005)]
TE28F640B3BC@TSOP48 [(SA247-B005)]
TE28F640B3TC@TSOP48 [(SA247-B005)]
TE28F640C3BC@TSOP48 [(SA247-B005)]
TE28F640C3TC@TSOP48 [(SA247-B005)]
TE28F640J3C@TSOP56 [(SA628-B018)]
TE28F640J3D@TSOP56 [(SA628-B018)]
TE28F640P30B@TSOP56 [(SA628-B131)]
TE28F640P30T@TSOP56 [(SA628-B131)]
TE28F640P33B@TSOP56 [(SA628-B131)]
TE28F640P33T@TSOP56 [(SA628-B131)]
TE28F800B3B@TSOP48 [(SA247-B005)]
TE28F800B3BA@TSOP48 [(SA247-B005)]
TE28F800B3T@TSOP48 [(SA247-B005)]
TE28F800B3TA@TSOP48 [(SA247-B005)]
TE28F800B5B@TSOP48 [(SA247-B005)]
TE28F800B5T@TSOP48 [(SA247-B005)]
TE28F800C3BA@TSOP48 [(SA247-B005)]
TE28F800C3BD@TSOP48 [(SA247-B005)]
TE28F800C3TA@TSOP48 [(SA247-B005)]
TE28F800C3TD@TSOP48 [(SA247-B005)]
TE28F800CEB@TSOP48 [(SA247-B005)]
TE28F800CET@TSOP48 [(SA247-B005)]
TE28F800CVB@TSOP48 [(SA247-B005)]
TE28F800CVT@TSOP48 [(SA247-B005)]
TE28F800F3B@TSOP56 [(SA628-B014)]
TE28F800F3T@TSOP56 [(SA628-B014)]

PLD

5C031 [(SA001A)]	5C031@PLCC20
5C032 [(SA001A)]	5C032@PLCC20
5C090 [(SA244)]	5C090@PLCC44

85C090 [(SA244)]	85C090-P44
85C220 [(SA001A)]	85C220@PLCC20
IPLD910 [(SA244)]	IPLD910-P44

MICROCONTROLLER

8751BH [(SA244)]	8751BH@PLCC44
8752BH [(SA244)]	8752BH@PLCC44
8796BH@PLCC68 (*) [(SA648-B6803)]	8796JF@PLCC68 (*) [(SA648-B6803)]
8797BH@PGA68 (*) [(SA650-B6804)]	8797BH@PLCC68 (*) [(SA648-B6803)]
8797JF@PGA68 (*) [(SA650-B6804)]	8797JF@PLCC68 (*) [(SA648-B6803)]
87C151SA [(SA244)]	87C151SA@PLCC44
87C151SB [(SA244)]	87C151SB@PLCC44
87C196CA@PLCC68 (*) [(SA648-B6805)]	
87C196JQ@PLCC52 (*) [(SA647-B5201)]	
87C196JR@PLCC52 (*) [(SA647-B5201)]	
87C196JT@PLCC52 (*) [(SA647-B5201)]	
87C196JV@PLCC52 (*) [(SA647-B5201)]	
87C196KB@PLCC68 (*) [(SA648-B6801)]	
87C196KC@PLCC68 (*) [(SA648-B6801)]	
87C196KD@PLCC68 (*) [(SA648-B6801)]	
87C196KQ@PLCC68 (*) [(SA648-B6802)]	
87C196KR@PLCC68 (*) [(SA648-B6802)]	
87C196KS@PLCC68 (*) [(SA648-B6802)]	
87C196KT@PLCC68 (*) [(SA648-B6802)]	
87C196LA@PLCC52 (*) [(SA647-B5201)]	
87C196MC@PLCC84 (*) [(SA649-B8401)]	
87C196MC@PQFP80 (*) [(TA026-B006)]	
87C196MC@SDIP64 (*) [(SA651)]	
87C196MH@PLCC84 (*) [(SA649-B8401)]	
87C196MH@PQFP80 (*) [(TA026-B006)]	
87C196MH@SDIP64 (*) [(SA651)]	

87C251SA
87C251SA@PLCC44 [(SA244)]
87C251SB
87C251SB@PLCC44 [(SA244)]
87C251SP
87C251SP@PLCC44 [(SA244)]
87C251SQ
87C251SQ@PLCC44 [(SA244)]
87C51
87C51@PLCC44 [(SA244)]
[(SA245A)]
87C51FA
87C51FA@PLCC44
[(SA244)]
87C51FA@TQFP44 [(SA245A)]
87C51FB
87C51FB@PLCC44 [(SA244)]
[(SA245A)]
87C51FC
87C51FC@PLCC44
[(SA244)]
87C51FC@TQFP44 [(SA245A)]
87C51RA
87C51RA@PLCC44 [(SA244)]
[(SA245A)]
87C51RB
87C51RB@PLCC44
[(SA244)]
87C51RB@TQFP44 [(SA245A)]
87C51RC
87C51RC@PLCC44 [(SA244)]
[(SA245A)]
87C52
87C52@PLCC44
[(SA244)]
87C52@TQFP44 [(SA245A)]
87C54
87C54@PLCC44 [(SA244)]
[(SA245A)]
87C58
87C58@PLCC44
[(SA244)]
87C58@TQFP44 [(SA245A)]
[(SA244)]
87L51FA@PLCC44
[(SA244)]
87L51FA@TQFP44 [(SA245A)]
[(SA244)]
87L51FB@PLCC44
[(SA244)]
87L51FB@TQFP44 [(SA245A)]
[(SA244)]
87L51FC@PLCC44

87L51FC@TQFP44 [(SA245A)]
[(SA244)]
87L52@TQFP44 [(SA245A)]
[(SA244)]
87L54@TQFP44 [(SA245A)]
[(SA244)]
87L58@TQFP44 [(SA245A)]

87L52@PLCC44
87L54@PLCC44
87L58@PLCC44

INTEL-CUSTOMER

E (E) PROM / FRAM / NVRAM

TE28F800C3TD@TSOP48 [(SA247-B005)]

INTELSIL

E (E) PROM / FRAM / NVRAM

HS-6617RH
[(SA404)]
HS-6617RH-T
[(SA404)]
HS-6883RH
[(SA404)]
HS-6883RH-T
[(SA404)]

HS-6617RH@SOIC24
HS-6617RH-T@SOIC24
HS-6883RH@SOIC24
HS-6883RH-T@SOIC24

ISSI

E (E) PROM / FRAM / NVRAM

IS24C01
[(SA666)]
IS24C01@SOIC8 [(SA602A)]
[(SA026)]
IS24C01B
[(SA666)]
IS24C01B@SOIC8 [(SA602A)]
[(SA026)]

IS24C01@MSOP8
IS24C01@TSSOP8
IS24C01B@MSOP8
IS24C01B@TSSOP8

IS24C02 [(SA666)]	IS24C02@MSOP8
IS24C02@SOIC8 [(SA602A)] [(SA026)]	IS24C02@TSSOP8
IS24C02A IS24C02A@DFN8	
IS24C02A@MSOP8 [(SA666)] [(SA602A)]	IS24C02A@SOIC8
IS24C02A@TSSOP8 [(SA026)]	
IS24C02B IS24C02B@DFN8	
[(SA666)]	IS24C02B@MSOP8
IS24C02B@SOIC8 [(SA602A)] [(SA026)]	IS24C02B@TSSOP8
IS24C04 [(SA666)]	IS24C04@MSOP8
IS24C04@SOIC8 [(SA602A)] [(SA026)]	IS24C04@TSSOP8
IS24C04A IS24C04A@DFN8	
IS24C04A@MSOP8 [(SA666)] [(SA602A)]	IS24C04A@SOIC8
IS24C04A@TSSOP8 [(SA026)]	
IS24C08 IS24C08@MSOP8 [(SA666)] [(SA602A)]	IS24C08@SOIC8
IS24C08@TSSOP8 [(SA026)]	
IS24C08A IS24C08A@DFN8	
[(SA666)]	IS24C08A@MSOP8
IS24C08A@SOIC8 [(SA602A)] [(SA026)]	IS24C08A@TSSOP8
IS24C128 [(SA602A)]	IS24C128@SOIC8
IS24C128@TSSOP14 [(SA026)]	
IS24C16 IS24C16@MSOP8 [(SA666)] [(SA602A)]	IS24C16@SOIC8
IS24C16@TSSOP8 [(SA026)]	
IS24C16A IS24C16A@MSOP8 [(SA666)] [(SA602A)]	IS24C16A@SOIC8
IS24C16A@TSSOP8 [(SA026)]	

IS24C256	
IS24C256@SOIC8 [(SA602A)]	IS24C256@TSSOP14
[(SA026)]	
IS24C256A	IS24C256A@SOIC8
[(SA602A)]	
IS24C256A@TSSOP14 [(SA026)]	
IS24C32	
IS24C32@SOIC8 [(SA602A)]	IS24C32@TSSOP8
[(SA026)]	
IS24C32A	IS24C32A@MSOP8
[(SA666)]	
IS24C32A@SOIC8 [(SA602A)]	IS24C32A@TSSOP8
[(SA026)]	
IS24C32B	IS24C32B@SOIC8
[(SA602A)]	
IS24C32B@TSSOP8 [(SA026)]	
IS24C64	
IS24C64@SOIC8 [(SA602A)]	IS24C64@TSSOP8
[(SA026)]	
IS24C64A	IS24C64A@MSOP8
[(SA666)]	
IS24C64A@SOIC8 [(SA602A)]	IS24C64A@TSSOP8
[(SA026)]	
IS24C64B	IS24C64B@SOIC8
[(SA602A)]	
IS24C64B@TSSOP8 [(SA026)]	
IS24L128	
IS24L128@SOIC8(150mil) [(SA602A)]	
IS24L128@SOIC8(200mil) [(SA605A)]	
IS24L256	
IS24L256@SOIC8(150mil) [(SA602A)]	
IS24L256@SOIC8(200mil) [(SA605A)]	
IS25C01	IS25C01@SOIC8
[(SA602A)]	
IS25C01@TSSOP8 [(SA026)]	
IS25C02	
IS25C02@SOIC8 [(SA602A)]	IS25C02@TSSOP8
[(SA026)]	
IS25C04	IS25C04@SOIC8
[(SA602A)]	
IS25C04@TSSOP8 [(SA026)]	
IS25C08	
IS25C08@SOIC8 [(SA602A)]	IS25C08@TSSOP8

[(SA026)]	
IS25C128@SOIC8 [(SA602A)]	IS25C128@TSSOP8
[(SA026)]	
IS25C16	IS25C16@SOIC8
[(SA602A)]	
IS25C16@TSSOP8 [(SA026)]	IS25C256@SOIC8
[(SA602A)]	
IS25C256@TSSOP8 [(SA026)]	
IS25C32A	
IS25C32A@SOIC8 [(SA602A)]	IS25C32A@TSSOP8
[(SA026)]	
IS25C64A	IS25C64A@SOIC8
[(SA602A)]	
IS25C64A@TSSOP8 [(SA026)]	
IS27C010	
IS27C010@PLCC32 [(SA015A1T)]	IS27C010@TSOP32
[(SA410T)]	
IS27C020	IS27C020@PLCC32
[(SA015A1T)]	
IS27C020@TSOP32 [(SA410T)]	
IS27C256	
IS27C256@PLCC32 [(SA015A1T)]	
IS27C512	
IS27C512@PLCC32 [(SA015A1T)]	IS27C512@TSOP28
[(SA430T)]	
IS27HC010	IS27HC010@PLCC32
[(SA015A1T)]	
IS27HC010@TSOP32 [(SA410T)]	
IS27HC020	
IS27HC020@PLCC32 [(SA015A1T)]	IS27HC020@TSOP32
[(SA410T)]	
IS27HC256	IS27HC256@PLCC32
[(SA015A1T)]	
IS27HC512	IS27HC512@PLCC32
[(SA015A1T)]	
IS27HC512@TSOP28 [(SA430T)]	
IS27LV010	
IS27LV010@PLCC32 [(SA015A1T)]	IS27LV010@TSOP32
[(SA410T)]	
IS27LV512	IS27LV512@PLCC32
[(SA015A1T)]	
IS27LV512@TSOP28 [(SA430T)]	
IS28F010	

IS28F010@PLCC32 [(SA015A1T)] IS28F010@TSOP32
[(SA410T)]
IS28F010A IS28F010A@PLCC32
[(SA015A1T)]
IS28F010A@TSOP32 [(SA410T)]
IS28F020
IS28F020@PLCC32 [(SA015A1T)] IS28F020@TSOP32
[(SA410T)]
IS29F010 IS29F010@PLCC32
[(SA015A1T)]
IS29F010@TSOP32 [(SA410T)]
IS34C02
IS34C02@MSOP8 [(SA666)] IS34C02@SOIC8
[(SA602A)]
IS34C02@TSSOP8 [(SA026)]
IS34C02B@DFN8
IS34C02B@TSSOP8 [(SA026)]
IS71V08F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F32ESB08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F32EST08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F32GSB08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F32GST08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V08F64GS08@FBGA101 [(SA642C-B032A-Y056F001)]
IS71V08F64GS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32B04@FBGA56 [(SA642A-B032A-Y096F001)]
IS71V16F32B04@FBGA59 [(SA642A-B032A-Y096F001)]
IS71V16F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32ESB08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32EST08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32GSB08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32GST08@FBGA73 [(SA642A-B032A-Y096F001)]
IS71V16F32T04@FBGA56 [(SA642A-B032A-Y096F001)]
IS71V16F32T04@FBGA59 [(SA642A-B032A-Y096F001)]

IS71V16F64GS08@FBGA101	[(SA642C-B032A-Y056F001)]
IS71V16F64GS08@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32AS04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32BS04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32CS04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32DS04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32ES04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32FS04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF64GS08@FBGA73	[(SA642C-B032A-Y056F001)]
IS75V16F64GS16@FBGA65	[(SA642C-B032A-Y056F001)]
IS75V16F64GS32@FBGA65	[(SA642C-B032A-Y056F001)]
IS93C46	IS93C46@SOIC8
[(SA602A)]	
IS93C46A(08bit)	IS93C46A(08bit)@SOIC8
[(SA602A)]	
IS93C46A(08bit)@TSSOP8	[(SA026)]
(16bit)	IS93C46A
IS93C46A(16bit)@SOIC8	[(SA602A)]
[(SA026)]	IS93C46A(16bit)@TSSOP8
IS93C46B	IS93C46B@SOIC8
[(SA602A)]	
IS93C46B@TSSOP8	[(SA026)]
(08bit)	IS93C46D
IS93C46D(08bit)@SOIC8	[(SA602A)]
[(SA026)]	IS93C46D(08bit)@TSSOP8
IS93C46D(16bit)	IS93C46D(16bit)@SOIC8
[(SA602A)]	
IS93C46D(16bit)@TSSOP8	[(SA026)]
IS93C56	
IS93C56@SOIC8	[(SA602A)]
(08bit)	IS93C56A
IS93C56A(08bit)@SOIC8	[(SA602A)]
[(SA026)]	IS93C56A(08bit)@TSSOP8
IS93C56A(16bit)	IS93C56A(16bit)@SOIC8
[(SA602A)]	
IS93C56A(16bit)@TSSOP8	[(SA026)]
IS93C66	
IS93C66@SOIC8	[(SA602A)]
(08bit)	IS93C66A
IS93C66A(08bit)@SOIC8	[(SA602A)]
[(SA026)]	IS93C66A(08bit)@TSSOP8
IS93C66A(16bit)	IS93C66A(16bit)@SOIC8
[(SA602A)]	

IS93C66A(16bit)@TSSOP8 [(SA026)] (08bit)	IS93C76A
IS93C76A(08bit)@SOIC8 [(SA602A)] [(SA026)]	IS93C76A(08bit)@TSSOP8
IS93C76A(16bit) [(SA602A)]	IS93C76A(16bit)@SOIC8
IS93C76A(16bit)@TSSOP8 [(SA026)] (08bit)	IS93C86A
IS93C86A(08bit)@SOIC8 [(SA602A)] [(SA026)]	IS93C86A(08bit)@TSSOP8
IS93C86A(16bit) [(SA602A)]	IS93C86A(16bit)@SOIC8
IS93C86A(16bit)@TSSOP8 [(SA026)]	

DRAM & SRAM

IS61C1024 [(SA646)]	IS61C1024(300m)@SOJ32
IS61C1024(400m)@SOJ32 [(SA661)] [(SA410T)]	IS61C1024@TSOP32
IS61C1024L [(SA646)]	IS61C1024L(300m)@SOJ32
IS61C1024L(400m)@SOJ32 [(SA661)] [(SA410T)]	IS61C1024L@TSOP32
IS61C256AH [(SA646)]	IS61C256AH@SOJ28
IS61C256AH@TSOP28 [(SA430T)]	
IS61C512	
IS61C512(300m)@SOJ32 [(SA646)] [(SA661)]	IS61C512(400m)@SOJ32
IS61C512@TSOP32 [(SA410T)]	
IS61C64AH	
IS61C64AH@SOJ28 [(SA646)] [(SA430T)]	IS61C64AH@TSOP28
IS61LV256 [(SA646)]	IS61LV256@SOJ28
IS61LV256@TSOP28 [(SA430T)]	
IS61M256	
IS61M256@SOJ28 [(SA646)] [(SA430T)]	IS61M256@TSOP28
IS62C1024 [(SA646)]	IS62C1024(300m)@SOJ32

IS62C1024(400m)@SOJ32 [(SA661)]
[(SA410T)]
IS62C256
[(SA646)]
IS62C256@TSOP28 [(SA430T)]
IS62C512
IS62C512(300m)@SOJ32 [(SA646)]
[(SA661)]
IS62C512@TSOP32 [(SA410T)]
IS62C64
IS62C64@SOJ28 [(SA646)]
[(SA430T)]
IS62LV256
[(SA646)]
IS62LV256@TSOP28 [(SA430T)]

IS62C1024@TSOP32

IS62C256@SOJ28

IS62C512(400m)@SOJ32

IS62C64@TSOP28

IS62LV256@SOJ28

MICROCONTROLLER

IS89C51A
[(SA244)]
IS89C51A@TQFP44 [(SA245A)]
IS89C52A
IS89C52A@PLCC44 [(SA244)]
[(SA245A)]

IS89C51A@PLCC44

IS89C52A@TQFP44

ITHINKO

MICROCONTROLLER

AX5012
[(SA404)]
AX5012(5.5V)@SOP24 [(SA404)]
[(SA404)]
AX5012@SOP24 [(SA404)]
AX5012@SOP32

AX5012(5.0V)@SOP24

AX5012(6.0V)@SOP24

LATTICE

PLD

GAL16LV8 [(SA001A)]	GAL16LV8@PLCC20
GAL16LV8C [(SA001A)]	GAL16LV8C@PLCC20
GAL16LV8D [(SA001A)]	GAL16LV8D@PLCC20
GAL16LV8Z [(SA001A)]	GAL16LV8Z@PLCC20
GAL16LV8ZD [(SA001A)]	GAL16LV8ZD@PLCC20
GAL16V8 [(SA001A)]	GAL16V8@PLCC20
GAL16V8@SOIC20 [(SA404)]	
GAL16V8A GAL16V8A@PLCC20 [(SA001A)] [(SA404)]	GAL16V8A@SOIC20
GAL16V8B [(SA001A)]	GAL16V8B@PLCC20
GAL16V8B@SOIC20 [(SA404)]	
GAL16V8C GAL16V8C@PLCC20 [(SA001A)] [(SA404)]	GAL16V8C@SOIC20
GAL16V8D [(SA001A)]	GAL16V8D@PLCC20
GAL16V8D@SOIC20 [(SA404)]	
GAL16V8Z GAL16V8Z@PLCC20 [(SA001A)] [(SA404)]	GAL16V8Z@SOIC20
GAL18V10 [(SA001A)]	GAL18V10@PLCC20
GAL18V10B [(SA001A)]	GAL18V10B@PLCC20
GAL20LV8 [(SA008A)]	GAL20LV8@PLCC28
GAL20LV8Z [(SA008A)]	GAL20LV8Z@PLCC28
GAL20LV8ZD [(SA008A)]	GAL20LV8ZD@PLCC28
GAL20RA10 [(SA008A)]	GAL20RA10@PLCC28
GAL20RA10B [(SA008A)]	GAL20RA10B@PLCC28
GAL20V8	GAL20V8@PLCC28

[(SA008A)]	
GAL20V8A	GAL20V8A@PLCC28
[(SA008A)]	
GAL20V8B	GAL20V8B@PLCC28
[(SA008A)]	
GAL20V8C	GAL20V8C@PLCC28
[(SA008A)]	
GAL20V8Z	GAL20V8Z@PLCC28
[(SA008A)]	
GAL20XV10	GAL20XV10@PLCC28
[(SA008A)]	
GAL20XV10B	GAL20XV10B@PLCC28
[(SA008A)]	
GAL22LV10C	GAL22LV10C@PLCC28
[(SA008A)]	
GAL22LV10C@SOIC24 [(SA404)]	GAL22LV10C@TSOP24
[(SA643)]	
GAL22LV10D	GAL22LV10D@PLCC28
[(SA008A)]	
GAL22LV10D@SOIC24 [(SA404)]	GAL22LV10D@TSOP24
[(SA643)]	
GAL22LV10Z	GAL22LV10Z@PLCC28
[(SA008A)]	
GAL22LV10Z@SOIC24 [(SA404)]	GAL22LV10Z@TSOP24
[(SA643)]	
GAL22LV10ZD	GAL22LV10ZD@PLCC28
[(SA008A)]	
GAL22LV10ZD@SOIC24 [(SA404)]	GAL22LV10ZD@TSOP24
[(SA643)]	
GAL22V10	GAL22V10@PLCC28
[(SA008A)]	
GAL22V10@SOIC24 [(SA404)]	
GAL22V10A	
GAL22V10A@PLCC28 [(SA008A)]	GAL22V10A@SOIC24
[(SA404)]	
GAL22V10B	GAL22V10B@PLCC28
[(SA008A)]	
GAL22V10B@SOIC24 [(SA404)]	
GAL22V10BQ	
GAL22V10BQ@PLCC28 [(SA008A)]	GAL22V10BQ@SOIC24
[(SA404)]	
GAL22V10C	GAL22V10C@PLCC28
[(SA008A)]	

GAL22V10C@SOIC24 [(SA404)]
GAL22V10D
GAL22V10D@PLCC28 [(SA008A)] GAL22V10D@SOIC24
[(SA404)]
GAL26CLV12 GAL26CLV12@PLCC28
[(SA008A)]
GAL26CLV12@SOIC28 [(SA404)] GAL26CLV12@TSOP28
[(SA643)]
GAL26CLV12B GAL26CLV12B@PLCC28
[(SA008A)]
GAL26CLV12B@SOIC28 [(SA404)] GAL26CLV12B@TSOP28
[(SA643)]
GAL26CLV12C GAL26CLV12C@PLCC28
[(SA008A)]
GAL26CLV12C@SOIC28 [(SA404)] GAL26CLV12C@TSOP28
[(SA643)]
GAL26CLV12D GAL26CLV12D@PLCC28
[(SA008A)]
GAL26CLV12D@SOIC28 [(SA404)] GAL26CLV12D@TSOP28
[(SA643)]
GAL26CLV12Z GAL26CLV12Z@PLCC28
[(SA008A)]
GAL26CLV12Z@SOIC28 [(SA404)] GAL26CLV12Z@TSOP28
[(SA643)]
GAL26CLV12ZD GAL26CLV12ZD@PLCC28
[(SA008A)]
GAL26CLV12ZD@SOIC28 [(SA404)] GAL26CLV12ZD@TSOP28
[(SA643)]
GAL26CV12 GAL26CV12@PLCC28
[(SA008A)]
GAL26CV12B GAL26CV12B@PLCC28
[(SA008A)]
GAL26CV12C GAL26CV12C@PLCC28
[(SA008A)]
GAL26V12C GAL26V12C@PLCC28
[(SA008A)]
ispGAL22LV10 ispGAL22LV10(ISP) [ISP-
HEADER01]
ispGAL22LV10@PLCC28 [(SA008A)]
ispGAL22LV10@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10@SSOP28 [(SA626A)]
ispGAL22LV10@SSOP28(ISP) [ISP-HEADER01]
ispGAL22LV10A

ispGAL22LV10A(ISP) [ISP-HEADER01]
ispGAL22LV10A@PLCC28 [(SA008A)]
ispGAL22LV10A@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10A@SSOP28 [(SA626A)]
ispGAL22LV10A@SSOP28(ISP) [ISP-HEADER01]
ispGAL22LV10B
ispGAL22LV10B(ISP) [ISP-HEADER01]
ispGAL22LV10B@PLCC28 [(SA008A)]
ispGAL22LV10B@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10B@SSOP28 [(SA626A)]
ispGAL22LV10B@SSOP28(ISP) [ISP-HEADER01]
ispGAL22LV10C
ispGAL22LV10C(ISP) [ISP-HEADER01]
ispGAL22LV10C@PLCC28 [(SA008A)]
ispGAL22LV10C@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10C@SSOP28 [(SA626A)]
ispGAL22LV10C@SSOP28(ISP) [ISP-HEADER01]
ispGAL22LV10D
ispGAL22LV10D(ISP) [ISP-HEADER01]
ispGAL22LV10D@PLCC28 [(SA008A)]
ispGAL22LV10D@PLCC28(ISP) [ISP-HEADER01]
ispGAL22LV10D@SSOP28 [(SA626A)]
ispGAL22LV10D@SSOP28(ISP) [ISP-HEADER01]
ispGAL22V10AB@PLCC28 [(SA008A)] ispGAL22V10AB@QFN32
[(SA686)]
ispGAL22V10AC@PLCC28 [(SA008A)] ispGAL22V10AC@QFN32
[(SA686)]
ispGAL22V10AV@PLCC28 [(SA008A)] ispGAL22V10AV@QFN32
[(SA686)]
ispGAL22V10C(UES)@PLCC28 [(SA008A)]
ispGAL22V10C@PLCC28 [(SA008A)] ispLSI1016@PLCC44
[(SA244)]
ispLSI1016@TQFP44 [(SA245A)] ispLSI1016E@PLCC44
[(SA244)]
ispLSI1016E@TQFP44 [(SA245A)] ispLSI1016EA@PLCC44
[(SA244)]
ispLSI1016EA@TQFP44 [(SA245A)] ispLSI2032@PLCC44
[(SA244)]
ispLSI2032@TQFP44 [(SA245A)] ispLSI2032A@PLCC44
[(SA244)]
ispLSI2032A@TQFP44 [(SA245A)] ispLSI2032A@TQFP48
[(SA248)]
ispLSI2032E@PLCC44 [(SA244)] ispLSI2032E@TQFP44

[(SA245A)]
ispLSI2032E@TQFP48 [(SA248)] ispLSI2032V@PLCC44
[(SA244)]
ispLSI2032V@TQFP44 [(SA245A)] ispLSI2032V@TQFP48
[(SA248)]
ispLSI2032VE@PLCC44 [(SA244)] ispLSI2032VE@TQFP44
[(SA245A)]
ispLSI2064A@PLCC44 [(SA244)] ispLSI2064A@TQFP44
[(SA245A)]
ispLSI2064V@PLCC44 [(SA244)] ispLSI2064V@TQFP44
[(SA245A)]
ispLSI2064VE@PLCC44 [(SA244)] ispLSI2064VE@TQFP44
[(SA245A)]
LC4032B@TQFP44 [(SA245A)]
LC4032B@TQFP44(ISP) [ISP-HEADER01]
LC4032B@TQFP48 [(SA248)]
LC4032B@TQFP48(ISP) [ISP-HEADER01]
LC4032C@TQFP44 [(SA245A)]
LC4032C@TQFP44(ISP) [ISP-HEADER01]
LC4032C@TQFP48 [(SA248)]
LC4032C@TQFP48(ISP) [ISP-HEADER01]
LC4032V@TQFP44 [(SA245A)]
LC4032V@TQFP44(ISP) [ISP-HEADER01]
LC4032V@TQFP48 [(SA248)]
LC4032V@TQFP48(ISP) [ISP-HEADER01]
LC4032ZC@csBGA56 [(SA699+B161)]
LC4032ZC@csBGA56(ISP) [ISP-HEADER01]
LC4032ZC@TQFP48 [(SA248)]
LC4032ZC@TQFP48(ISP) [ISP-HEADER01]
LC4064B@TQFP44 [(SA245A)]
LC4064B@TQFP44(ISP) [ISP-HEADER01]
LC4064B@TQFP48 [(SA248)]
LC4064B@TQFP48(ISP) [ISP-HEADER01]
LC4064C@TQFP44 [(SA245A)]
LC4064C@TQFP44(ISP) [ISP-HEADER01]
LC4064C@TQFP48 [(SA248)]
LC4064C@TQFP48(ISP) [ISP-HEADER01]
LC4064V@TQFP44 [(SA245A)]
LC4064V@TQFP44(ISP) [ISP-HEADER01]
LC4064V@TQFP48 [(SA248)]
LC4064V@TQFP48(ISP) [ISP-HEADER01]
LC4064ZC@TQFP48 [(SA248)]
LCMX01200C-FT256(ISP) [ISP-HEADER01]

LCMXO1200C-FT324(ISP) [ISP-HEADER01]
LCMXO1200C-FTN256(ISP) [ISP-HEADER01]
LCMXO1200C-FTN324(ISP) [ISP-HEADER01]
LCMXO1200C-M100(ISP) [ISP-HEADER01]
LCMXO1200C-M132(ISP) [ISP-HEADER01]
LCMXO1200C-MN100(ISP) [ISP-HEADER01]
LCMXO1200C-MN132(ISP) [ISP-HEADER01]
LCMXO1200C-T100(ISP) [ISP-HEADER01]
LCMXO1200C-T144(ISP) [ISP-HEADER01]
LCMXO1200C-TN100(ISP) [ISP-HEADER01]
LCMXO1200C-TN144(ISP) [ISP-HEADER01]
LCMXO1200E-FT256(ISP) [ISP-HEADER01]
LCMXO1200E-FT324(ISP) [ISP-HEADER01]
LCMXO1200E-FTN256(ISP) [ISP-HEADER01]
LCMXO1200E-FTN324(ISP) [ISP-HEADER01]
LCMXO1200E-M100(ISP) [ISP-HEADER01]
LCMXO1200E-M132(ISP) [ISP-HEADER01]
LCMXO1200E-MN100(ISP) [ISP-HEADER01]
LCMXO1200E-MN132(ISP) [ISP-HEADER01]
LCMXO1200E-T100(ISP) [ISP-HEADER01]
LCMXO1200E-T144(ISP) [ISP-HEADER01]
LCMXO1200E-TN100(ISP) [ISP-HEADER01]
LCMXO1200E-TN144(ISP) [ISP-HEADER01]
LCMXO2280C-FT256(ISP) [ISP-HEADER01]
LCMXO2280C-FT324(ISP) [ISP-HEADER01]
LCMXO2280C-FTN256(ISP) [ISP-HEADER01]
LCMXO2280C-FTN324(ISP) [ISP-HEADER01]
LCMXO2280C-M100(ISP) [ISP-HEADER01]
LCMXO2280C-M132(ISP) [ISP-HEADER01]
LCMXO2280C-MN100(ISP) [ISP-HEADER01]
LCMXO2280C-MN132(ISP) [ISP-HEADER01]
LCMXO2280C-T100(ISP) [ISP-HEADER01]
LCMXO2280C-T144(ISP) [ISP-HEADER01]
LCMXO2280C-TN100(ISP) [ISP-HEADER01]
LCMXO2280C-TN144(ISP) [ISP-HEADER01]
LCMXO2280E-FT256(ISP) [ISP-HEADER01]
LCMXO2280E-FT324(ISP) [ISP-HEADER01]
LCMXO2280E-FTN256(ISP) [ISP-HEADER01]
LCMXO2280E-FTN324(ISP) [ISP-HEADER01]
LCMXO2280E-M100(ISP) [ISP-HEADER01]
LCMXO2280E-M132(ISP) [ISP-HEADER01]
LCMXO2280E-MN100(ISP) [ISP-HEADER01]
LCMXO2280E-MN132(ISP) [ISP-HEADER01]

LCMXO2280E-T100 (ISP) [ISP-HEADER01]
LCMXO2280E-T144 (ISP) [ISP-HEADER01]
LCMXO2280E-TN100 (ISP) [ISP-HEADER01]
LCMXO2280E-TN144 (ISP) [ISP-HEADER01]
LCMXO256C-FT256 (ISP) [ISP-HEADER01]
LCMXO256C-FT324 (ISP) [ISP-HEADER01]
LCMXO256C-FTN256 (ISP) [ISP-HEADER01]
LCMXO256C-FTN324 (ISP) [ISP-HEADER01]
LCMXO256C-M100 (ISP) [ISP-HEADER01]
LCMXO256C-M132 (ISP) [ISP-HEADER01]
LCMXO256C-MN100 (ISP) [ISP-HEADER01]
LCMXO256C-MN132 (ISP) [ISP-HEADER01]
LCMXO256C-T100 (ISP) [ISP-HEADER01]
LCMXO256C-T144 (ISP) [ISP-HEADER01]
LCMXO256C-TN100 (ISP) [ISP-HEADER01]
LCMXO256C-TN144 (ISP) [ISP-HEADER01]
LCMXO256E-FT256 (ISP) [ISP-HEADER01]
LCMXO256E-FT324 (ISP) [ISP-HEADER01]
LCMXO256E-FTN256 (ISP) [ISP-HEADER01]
LCMXO256E-FTN324 (ISP) [ISP-HEADER01]
LCMXO256E-M100 (ISP) [ISP-HEADER01]
LCMXO256E-M132 (ISP) [ISP-HEADER01]
LCMXO256E-MN100 (ISP) [ISP-HEADER01]
LCMXO256E-MN132 (ISP) [ISP-HEADER01]
LCMXO256E-T100 (ISP) [ISP-HEADER01]
LCMXO256E-T144 (ISP) [ISP-HEADER01]
LCMXO256E-TN100 (ISP) [ISP-HEADER01]
LCMXO256E-TN144 (ISP) [ISP-HEADER01]
LCMXO640C-FT256 (ISP) [ISP-HEADER01]
LCMXO640C-FT324 (ISP) [ISP-HEADER01]
LCMXO640C-FTN256 (ISP) [ISP-HEADER01]
LCMXO640C-FTN324 (ISP) [ISP-HEADER01]
LCMXO640C-M100 (ISP) [ISP-HEADER01]
LCMXO640C-M132 (ISP) [ISP-HEADER01]
LCMXO640C-MN100 (ISP) [ISP-HEADER01]
LCMXO640C-MN132 (ISP) [ISP-HEADER01]
LCMXO640C-T100 (ISP) [ISP-HEADER01]
LCMXO640C-T144 (ISP) [ISP-HEADER01]
LCMXO640C-TN100 (ISP) [ISP-HEADER01]
LCMXO640C-TN144 (ISP) [ISP-HEADER01]
LCMXO640E-FT256 (ISP) [ISP-HEADER01]
LCMXO640E-FT324 (ISP) [ISP-HEADER01]
LCMXO640E-FTN256 (ISP) [ISP-HEADER01]

LCMXO640E-FTN324(ISP) [ISP-HEADER01]
LCMXO640E-M100(ISP) [ISP-HEADER01]
LCMXO640E-M132(ISP) [ISP-HEADER01]
LCMXO640E-MN100(ISP) [ISP-HEADER01]
LCMXO640E-MN132(ISP) [ISP-HEADER01]
LCMXO640E-T100(ISP) [ISP-HEADER01]
LCMXO640E-T144(ISP) [ISP-HEADER01]
LCMXO640E-TN100(ISP) [ISP-HEADER01]
LCMXO640E-TN144(ISP) [ISP-HEADER01]
LFXP10C-3F256C(ISP) [ISP-HEADER01]
LFXP10C-3F256I(ISP) [ISP-HEADER01]
LFXP10C-3F388C(ISP) [ISP-HEADER01]
LFXP10C-3F388I(ISP) [ISP-HEADER01]
LFXP10C-3FN256C(ISP) [ISP-HEADER01]
LFXP10C-3FN256I(ISP) [ISP-HEADER01]
LFXP10C-3FN388C(ISP) [ISP-HEADER01]
LFXP10C-3FN388I(ISP) [ISP-HEADER01]
LFXP10C-4F256C(ISP) [ISP-HEADER01]
LFXP10C-4F256I(ISP) [ISP-HEADER01]
LFXP10C-4F388C(ISP) [ISP-HEADER01]
LFXP10C-4F388I(ISP) [ISP-HEADER01]
LFXP10C-4FN256C(ISP) [ISP-HEADER01]
LFXP10C-4FN256I(ISP) [ISP-HEADER01]
LFXP10C-4FN388C(ISP) [ISP-HEADER01]
LFXP10C-4FN388I(ISP) [ISP-HEADER01]
LFXP10C-5F256C(ISP) [ISP-HEADER01]
LFXP10C-5F256I(ISP) [ISP-HEADER01]
LFXP10C-5F388C(ISP) [ISP-HEADER01]
LFXP10C-5F388I(ISP) [ISP-HEADER01]
LFXP10C-5FN256C(ISP) [ISP-HEADER01]
LFXP10C-5FN256I(ISP) [ISP-HEADER01]
LFXP10C-5FN388C(ISP) [ISP-HEADER01]
LFXP10C-5FN388I(ISP) [ISP-HEADER01]
LFXP10E-3F256C(ISP) [ISP-HEADER01]
LFXP10E-3F256I(ISP) [ISP-HEADER01]
LFXP10E-3F388C(ISP) [ISP-HEADER01]
LFXP10E-3F388I(ISP) [ISP-HEADER01]
LFXP10E-3FN256C(ISP) [ISP-HEADER01]
LFXP10E-3FN256I(ISP) [ISP-HEADER01]
LFXP10E-3FN388C(ISP) [ISP-HEADER01]
LFXP10E-3FN388I(ISP) [ISP-HEADER01]
LFXP10E-4F256C(ISP) [ISP-HEADER01]
LFXP10E-4F256I(ISP) [ISP-HEADER01]

LFXP10E-4F388C(ISP) [ISP-HEADER01]
LFXP10E-4F388I(ISP) [ISP-HEADER01]
LFXP10E-4FN256C(ISP) [ISP-HEADER01]
LFXP10E-4FN256I(ISP) [ISP-HEADER01]
LFXP10E-4FN388C(ISP) [ISP-HEADER01]
LFXP10E-4FN388I(ISP) [ISP-HEADER01]
LFXP10E-5F256C(ISP) [ISP-HEADER01]
LFXP10E-5F256I(ISP) [ISP-HEADER01]
LFXP10E-5F388C(ISP) [ISP-HEADER01]
LFXP10E-5F388I(ISP) [ISP-HEADER01]
LFXP10E-5FN256C(ISP) [ISP-HEADER01]
LFXP10E-5FN256I(ISP) [ISP-HEADER01]
LFXP10E-5FN388C(ISP) [ISP-HEADER01]
LFXP10E-5FN388I(ISP) [ISP-HEADER01]
LFXP15C-3F256C(ISP) [ISP-HEADER01]
LFXP15C-3F256I(ISP) [ISP-HEADER01]
LFXP15C-3F388C(ISP) [ISP-HEADER01]
LFXP15C-3F388I(ISP) [ISP-HEADER01]
LFXP15C-3F484C(ISP) [ISP-HEADER01]
LFXP15C-3F484I(ISP) [ISP-HEADER01]
LFXP15C-3FN256C(ISP) [ISP-HEADER01]
LFXP15C-3FN256I(ISP) [ISP-HEADER01]
LFXP15C-3FN388C(ISP) [ISP-HEADER01]
LFXP15C-3FN388I(ISP) [ISP-HEADER01]
LFXP15C-3FN484C(ISP) [ISP-HEADER01]
LFXP15C-3FN484I(ISP) [ISP-HEADER01]
LFXP15C-4F256C(ISP) [ISP-HEADER01]
LFXP15C-4F256I(ISP) [ISP-HEADER01]
LFXP15C-4F388C(ISP) [ISP-HEADER01]
LFXP15C-4F388I(ISP) [ISP-HEADER01]
LFXP15C-4F484C(ISP) [ISP-HEADER01]
LFXP15C-4F484I(ISP) [ISP-HEADER01]
LFXP15C-4FN256C(ISP) [ISP-HEADER01]
LFXP15C-4FN256I(ISP) [ISP-HEADER01]
LFXP15C-4FN388C(ISP) [ISP-HEADER01]
LFXP15C-4FN388I(ISP) [ISP-HEADER01]
LFXP15C-4FN484C(ISP) [ISP-HEADER01]
LFXP15C-4FN484I(ISP) [ISP-HEADER01]
LFXP15C-5F256C(ISP) [ISP-HEADER01]
LFXP15C-5F256I(ISP) [ISP-HEADER01]
LFXP15C-5F388C(ISP) [ISP-HEADER01]
LFXP15C-5F388I(ISP) [ISP-HEADER01]
LFXP15C-5F484C(ISP) [ISP-HEADER01]

LFXP15C-5F484I (ISP) [ISP-HEADER01]
LFXP15C-5FN256C (ISP) [ISP-HEADER01]
LFXP15C-5FN256I (ISP) [ISP-HEADER01]
LFXP15C-5FN388C (ISP) [ISP-HEADER01]
LFXP15C-5FN388I (ISP) [ISP-HEADER01]
LFXP15C-5FN484C (ISP) [ISP-HEADER01]
LFXP15C-5FN484I (ISP) [ISP-HEADER01]
LFXP15E-3F256C (ISP) [ISP-HEADER01]
LFXP15E-3F256I (ISP) [ISP-HEADER01]
LFXP15E-3F388C (ISP) [ISP-HEADER01]
LFXP15E-3F388I (ISP) [ISP-HEADER01]
LFXP15E-3F484C (ISP) [ISP-HEADER01]
LFXP15E-3F484I (ISP) [ISP-HEADER01]
LFXP15E-3FN256C (ISP) [ISP-HEADER01]
LFXP15E-3FN256I (ISP) [ISP-HEADER01]
LFXP15E-3FN388C (ISP) [ISP-HEADER01]
LFXP15E-3FN388I (ISP) [ISP-HEADER01]
LFXP15E-3FN484C (ISP) [ISP-HEADER01]
LFXP15E-3FN484I (ISP) [ISP-HEADER01]
LFXP15E-4F256C (ISP) [ISP-HEADER01]
LFXP15E-4F256I (ISP) [ISP-HEADER01]
LFXP15E-4F388C (ISP) [ISP-HEADER01]
LFXP15E-4F388I (ISP) [ISP-HEADER01]
LFXP15E-4F484C (ISP) [ISP-HEADER01]
LFXP15E-4F484I (ISP) [ISP-HEADER01]
LFXP15E-4FN256C (ISP) [ISP-HEADER01]
LFXP15E-4FN256I (ISP) [ISP-HEADER01]
LFXP15E-4FN388C (ISP) [ISP-HEADER01]
LFXP15E-4FN388I (ISP) [ISP-HEADER01]
LFXP15E-4FN484C (ISP) [ISP-HEADER01]
LFXP15E-4FN484I (ISP) [ISP-HEADER01]
LFXP15E-5F256C (ISP) [ISP-HEADER01]
LFXP15E-5F256I (ISP) [ISP-HEADER01]
LFXP15E-5F388C (ISP) [ISP-HEADER01]
LFXP15E-5F388I (ISP) [ISP-HEADER01]
LFXP15E-5F484C (ISP) [ISP-HEADER01]
LFXP15E-5F484I (ISP) [ISP-HEADER01]
LFXP15E-5FN256C (ISP) [ISP-HEADER01]
LFXP15E-5FN256I (ISP) [ISP-HEADER01]
LFXP15E-5FN388C (ISP) [ISP-HEADER01]
LFXP15E-5FN388I (ISP) [ISP-HEADER01]
LFXP15E-5FN484C (ISP) [ISP-HEADER01]
LFXP15E-5FN484I (ISP) [ISP-HEADER01]

LFXP20C-3F256C(ISP) [ISP-HEADER01]
LFXP20C-3F256I(ISP) [ISP-HEADER01]
LFXP20C-3F388C(ISP) [ISP-HEADER01]
LFXP20C-3F388I(ISP) [ISP-HEADER01]
LFXP20C-3F484C(ISP) [ISP-HEADER01]
LFXP20C-3F484I(ISP) [ISP-HEADER01]
LFXP20C-3FN256C(ISP) [ISP-HEADER01]
LFXP20C-3FN256I(ISP) [ISP-HEADER01]
LFXP20C-3FN388C(ISP) [ISP-HEADER01]
LFXP20C-3FN388I(ISP) [ISP-HEADER01]
LFXP20C-3FN484C(ISP) [ISP-HEADER01]
LFXP20C-3FN484I(ISP) [ISP-HEADER01]
LFXP20C-4F256C(ISP) [ISP-HEADER01]
LFXP20C-4F256I(ISP) [ISP-HEADER01]
LFXP20C-4F388C(ISP) [ISP-HEADER01]
LFXP20C-4F388I(ISP) [ISP-HEADER01]
LFXP20C-4F484C(ISP) [ISP-HEADER01]
LFXP20C-4F484I(ISP) [ISP-HEADER01]
LFXP20C-4FN256C(ISP) [ISP-HEADER01]
LFXP20C-4FN256I(ISP) [ISP-HEADER01]
LFXP20C-4FN388C(ISP) [ISP-HEADER01]
LFXP20C-4FN388I(ISP) [ISP-HEADER01]
LFXP20C-4FN484C(ISP) [ISP-HEADER01]
LFXP20C-4FN484I(ISP) [ISP-HEADER01]
LFXP20C-5F256C(ISP) [ISP-HEADER01]
LFXP20C-5F256I(ISP) [ISP-HEADER01]
LFXP20C-5F388C(ISP) [ISP-HEADER01]
LFXP20C-5F388I(ISP) [ISP-HEADER01]
LFXP20C-5F484C(ISP) [ISP-HEADER01]
LFXP20C-5F484I(ISP) [ISP-HEADER01]
LFXP20C-5FN256C(ISP) [ISP-HEADER01]
LFXP20C-5FN256I(ISP) [ISP-HEADER01]
LFXP20C-5FN388C(ISP) [ISP-HEADER01]
LFXP20C-5FN388I(ISP) [ISP-HEADER01]
LFXP20C-5FN484C(ISP) [ISP-HEADER01]
LFXP20C-5FN484I(ISP) [ISP-HEADER01]
LFXP20E-3F256C(ISP) [ISP-HEADER01]
LFXP20E-3F256I(ISP) [ISP-HEADER01]
LFXP20E-3F388C(ISP) [ISP-HEADER01]
LFXP20E-3F388I(ISP) [ISP-HEADER01]
LFXP20E-3F484C(ISP) [ISP-HEADER01]
LFXP20E-3F484I(ISP) [ISP-HEADER01]
LFXP20E-3FN256C(ISP) [ISP-HEADER01]

LFXP20E-3FN256I (ISP) [ISP-HEADER01]
LFXP20E-3FN388C (ISP) [ISP-HEADER01]
LFXP20E-3FN388I (ISP) [ISP-HEADER01]
LFXP20E-3FN484C (ISP) [ISP-HEADER01]
LFXP20E-3FN484I (ISP) [ISP-HEADER01]
LFXP20E-4F256C (ISP) [ISP-HEADER01]
LFXP20E-4F256I (ISP) [ISP-HEADER01]
LFXP20E-4F388C (ISP) [ISP-HEADER01]
LFXP20E-4F388I (ISP) [ISP-HEADER01]
LFXP20E-4F484C (ISP) [ISP-HEADER01]
LFXP20E-4F484I (ISP) [ISP-HEADER01]
LFXP20E-4FN256C (ISP) [ISP-HEADER01]
LFXP20E-4FN256I (ISP) [ISP-HEADER01]
LFXP20E-4FN388C (ISP) [ISP-HEADER01]
LFXP20E-4FN388I (ISP) [ISP-HEADER01]
LFXP20E-4FN484C (ISP) [ISP-HEADER01]
LFXP20E-4FN484I (ISP) [ISP-HEADER01]
LFXP20E-5F256C (ISP) [ISP-HEADER01]
LFXP20E-5F256I (ISP) [ISP-HEADER01]
LFXP20E-5F388C (ISP) [ISP-HEADER01]
LFXP20E-5F388I (ISP) [ISP-HEADER01]
LFXP20E-5F484C (ISP) [ISP-HEADER01]
LFXP20E-5F484I (ISP) [ISP-HEADER01]
LFXP20E-5FN256C (ISP) [ISP-HEADER01]
LFXP20E-5FN256I (ISP) [ISP-HEADER01]
LFXP20E-5FN388C (ISP) [ISP-HEADER01]
LFXP20E-5FN388I (ISP) [ISP-HEADER01]
LFXP20E-5FN484C (ISP) [ISP-HEADER01]
LFXP20E-5FN484I (ISP) [ISP-HEADER01]
LFXP3C-3Q208C (ISP) [ISP-HEADER01]
LFXP3C-3Q208I (ISP) [ISP-HEADER01]
LFXP3C-3QN208C (ISP) [ISP-HEADER01]
LFXP3C-3QN208I (ISP) [ISP-HEADER01]
LFXP3C-3T100C (ISP) [ISP-HEADER01]
LFXP3C-3T100I (ISP) [ISP-HEADER01]
LFXP3C-3T144C (ISP) [ISP-HEADER01]
LFXP3C-3T144I (ISP) [ISP-HEADER01]
LFXP3C-3TN100C (ISP) [ISP-HEADER01]
LFXP3C-3TN100I (ISP) [ISP-HEADER01]
LFXP3C-3TN144C (ISP) [ISP-HEADER01]
LFXP3C-3TN144I (ISP) [ISP-HEADER01]
LFXP3C-4Q208C (ISP) [ISP-HEADER01]
LFXP3C-4Q208I (ISP) [ISP-HEADER01]

LFXP3C-4QN208C(ISP) [ISP-HEADER01]
LFXP3C-4QN208I(ISP) [ISP-HEADER01]
LFXP3C-4T100C(ISP) [ISP-HEADER01]
LFXP3C-4T100I(ISP) [ISP-HEADER01]
LFXP3C-4T144C(ISP) [ISP-HEADER01]
LFXP3C-4T144I(ISP) [ISP-HEADER01]
LFXP3C-4TN100C(ISP) [ISP-HEADER01]
LFXP3C-4TN100I(ISP) [ISP-HEADER01]
LFXP3C-4TN144C(ISP) [ISP-HEADER01]
LFXP3C-4TN144I(ISP) [ISP-HEADER01]
LFXP3C-5Q208C(ISP) [ISP-HEADER01]
LFXP3C-5Q208I(ISP) [ISP-HEADER01]
LFXP3C-5QN208C(ISP) [ISP-HEADER01]
LFXP3C-5QN208I(ISP) [ISP-HEADER01]
LFXP3C-5T100C(ISP) [ISP-HEADER01]
LFXP3C-5T100I(ISP) [ISP-HEADER01]
LFXP3C-5T144C(ISP) [ISP-HEADER01]
LFXP3C-5T144I(ISP) [ISP-HEADER01]
LFXP3C-5TN100C(ISP) [ISP-HEADER01]
LFXP3C-5TN100I(ISP) [ISP-HEADER01]
LFXP3C-5TN144C(ISP) [ISP-HEADER01]
LFXP3C-5TN144I(ISP) [ISP-HEADER01]
LFXP3E-3Q208C(ISP) [ISP-HEADER01]
LFXP3E-3Q208I(ISP) [ISP-HEADER01]
LFXP3E-3QN208C(ISP) [ISP-HEADER01]
LFXP3E-3QN208I(ISP) [ISP-HEADER01]
LFXP3E-3T100C(ISP) [ISP-HEADER01]
LFXP3E-3T100I(ISP) [ISP-HEADER01]
LFXP3E-3T144C(ISP) [ISP-HEADER01]
LFXP3E-3T144I(ISP) [ISP-HEADER01]
LFXP3E-3TN100C(ISP) [ISP-HEADER01]
LFXP3E-3TN100I(ISP) [ISP-HEADER01]
LFXP3E-3TN144C(ISP) [ISP-HEADER01]
LFXP3E-3TN144I(ISP) [ISP-HEADER01]
LFXP3E-4Q208C(ISP) [ISP-HEADER01]
LFXP3E-4Q208I(ISP) [ISP-HEADER01]
LFXP3E-4QN208C(ISP) [ISP-HEADER01]
LFXP3E-4QN208I(ISP) [ISP-HEADER01]
LFXP3E-4T100C(ISP) [ISP-HEADER01]
LFXP3E-4T100I(ISP) [ISP-HEADER01]
LFXP3E-4T144C(ISP) [ISP-HEADER01]
LFXP3E-4T144I(ISP) [ISP-HEADER01]
LFXP3E-4TN100C(ISP) [ISP-HEADER01]

LFXP3E-4TN100I (ISP) [ISP-HEADER01]
LFXP3E-4TN144C (ISP) [ISP-HEADER01]
LFXP3E-4TN144I (ISP) [ISP-HEADER01]
LFXP3E-5Q208C (ISP) [ISP-HEADER01]
LFXP3E-5Q208I (ISP) [ISP-HEADER01]
LFXP3E-5QN208C (ISP) [ISP-HEADER01]
LFXP3E-5QN208I (ISP) [ISP-HEADER01]
LFXP3E-5T100C (ISP) [ISP-HEADER01]
LFXP3E-5T100I (ISP) [ISP-HEADER01]
LFXP3E-5T144C (ISP) [ISP-HEADER01]
LFXP3E-5T144I (ISP) [ISP-HEADER01]
LFXP3E-5TN100C (ISP) [ISP-HEADER01]
LFXP3E-5TN100I (ISP) [ISP-HEADER01]
LFXP3E-5TN144C (ISP) [ISP-HEADER01]
LFXP3E-5TN144I (ISP) [ISP-HEADER01]
LFXP6C-3F256C (ISP) [ISP-HEADER01]
LFXP6C-3F256I (ISP) [ISP-HEADER01]
LFXP6C-3FN256C (ISP) [ISP-HEADER01]
LFXP6C-3FN256I (ISP) [ISP-HEADER01]
LFXP6C-3Q208C (ISP) [ISP-HEADER01]
LFXP6C-3Q208I (ISP) [ISP-HEADER01]
LFXP6C-3QN208C (ISP) [ISP-HEADER01]
LFXP6C-3QN208I (ISP) [ISP-HEADER01]
LFXP6C-3T144C (ISP) [ISP-HEADER01]
LFXP6C-3T144I (ISP) [ISP-HEADER01]
LFXP6C-3TN144C (ISP) [ISP-HEADER01]
LFXP6C-3TN144I (ISP) [ISP-HEADER01]
LFXP6C-4F256C (ISP) [ISP-HEADER01]
LFXP6C-4F256I (ISP) [ISP-HEADER01]
LFXP6C-4FN256C (ISP) [ISP-HEADER01]
LFXP6C-4FN256I (ISP) [ISP-HEADER01]
LFXP6C-4Q208C (ISP) [ISP-HEADER01]
LFXP6C-4Q208I (ISP) [ISP-HEADER01]
LFXP6C-4QN208C (ISP) [ISP-HEADER01]
LFXP6C-4QN208I (ISP) [ISP-HEADER01]
LFXP6C-4T144C (ISP) [ISP-HEADER01]
LFXP6C-4T144I (ISP) [ISP-HEADER01]
LFXP6C-4TN144C (ISP) [ISP-HEADER01]
LFXP6C-4TN144I (ISP) [ISP-HEADER01]
LFXP6C-5F256C (ISP) [ISP-HEADER01]
LFXP6C-5F256I (ISP) [ISP-HEADER01]
LFXP6C-5FN256C (ISP) [ISP-HEADER01]
LFXP6C-5FN256I (ISP) [ISP-HEADER01]

LFXP6C-5Q208C(ISP) [ISP-HEADER01]
LFXP6C-5Q208I(ISP) [ISP-HEADER01]
LFXP6C-5QN208C(ISP) [ISP-HEADER01]
LFXP6C-5QN208I(ISP) [ISP-HEADER01]
LFXP6C-5T144C(ISP) [ISP-HEADER01]
LFXP6C-5T144I(ISP) [ISP-HEADER01]
LFXP6C-5TN144C(ISP) [ISP-HEADER01]
LFXP6C-5TN144I(ISP) [ISP-HEADER01]
LFXP6E-3F256C(ISP) [ISP-HEADER01]
LFXP6E-3F256I(ISP) [ISP-HEADER01]
LFXP6E-3FN256C(ISP) [ISP-HEADER01]
LFXP6E-3FN256I(ISP) [ISP-HEADER01]
LFXP6E-3Q208C(ISP) [ISP-HEADER01]
LFXP6E-3Q208I(ISP) [ISP-HEADER01]
LFXP6E-3QN208C(ISP) [ISP-HEADER01]
LFXP6E-3QN208I(ISP) [ISP-HEADER01]
LFXP6E-3T144C(ISP) [ISP-HEADER01]
LFXP6E-3T144I(ISP) [ISP-HEADER01]
LFXP6E-3TN144C(ISP) [ISP-HEADER01]
LFXP6E-3TN144I(ISP) [ISP-HEADER01]
LFXP6E-4F256C(ISP) [ISP-HEADER01]
LFXP6E-4F256I(ISP) [ISP-HEADER01]
LFXP6E-4FN256C(ISP) [ISP-HEADER01]
LFXP6E-4FN256I(ISP) [ISP-HEADER01]
LFXP6E-4Q208C(ISP) [ISP-HEADER01]
LFXP6E-4Q208I(ISP) [ISP-HEADER01]
LFXP6E-4QN208C(ISP) [ISP-HEADER01]
LFXP6E-4QN208I(ISP) [ISP-HEADER01]
LFXP6E-4T144C(ISP) [ISP-HEADER01]
LFXP6E-4T144I(ISP) [ISP-HEADER01]
LFXP6E-4TN144C(ISP) [ISP-HEADER01]
LFXP6E-4TN144I(ISP) [ISP-HEADER01]
LFXP6E-5F256C(ISP) [ISP-HEADER01]
LFXP6E-5F256I(ISP) [ISP-HEADER01]
LFXP6E-5FN256C(ISP) [ISP-HEADER01]
LFXP6E-5FN256I(ISP) [ISP-HEADER01]
LFXP6E-5Q208C(ISP) [ISP-HEADER01]
LFXP6E-5Q208I(ISP) [ISP-HEADER01]
LFXP6E-5QN208C(ISP) [ISP-HEADER01]
LFXP6E-5QN208I(ISP) [ISP-HEADER01]
LFXP6E-5T144C(ISP) [ISP-HEADER01]
LFXP6E-5T144I(ISP) [ISP-HEADER01]
LFXP6E-5TN144C(ISP) [ISP-HEADER01]

LFXP6E-5TN144I (ISP) [ISP-HEADER01]	
M4A3-32/32@PLCC44 [(SA244)]	M4A3-32/32@TQFP44
[(SA245A)]	
M4A3-32/32@TQFP48 [(SA248)]	M4A3-64/32@PLCC44
[(SA244)]	
M4A3-64/32@TQFP44 [(SA245A)]	M4A3-64/32@TQFP48
[(SA248)]	
M4A5-32/32@PLCC44 [(SA244)]	M4A5-32/32@TQFP44
[(SA245A)]	
M4A5-32/32@TQFP48 [(SA248)]	M4A5-64/32@PLCC44
[(SA244)]	
M4A5-64/32@TQFP44 [(SA245A)]	M4A5-64/32@TQFP48
[(SA248)]	
MACH110@PLCC44 [(SA244)]	
PALCE20RA10	
PALCE20RA10@PLCC28 [(SA008A)]	PALCE20RA10@SOIC24
[(SA404)]	
PALCE20RA10H	PALCE20RA10H@PLCC28
[(SA008A)]	
PALCE20RA10H@SOIC24 [(SA404)]	
PALCE20RA10Q	
PALCE20RA10Q@PLCC28 [(SA008A)]	PALCE20RA10Q@SOIC24
[(SA404)]	
PALCE22V10H	PALCE22V10H@PLCC28
[(SA008A)]	
PALCE22V10H@SOIC24 [(SA404)]	
PALCE22V10Q	
PALCE22V10Q@PLCC28 [(SA008A)]	PALCE22V10Q@SOIC24
[(SA404)]	
PALCE22V10Z	PALCE22V10Z@PLCC28
[(SA008A)]	
PALCE22V10Z@SOIC24 [(SA404)]	

LG Semicon

DRAM & SRAM

GM76C256CL	GM76C256CL@SSOP28
[(SA430T)]	
GM76C256CL@TSOP28 [(SA630)]	
GM76C256CLL	
GM76C256CLL@SSOP28 [(SA430T)]	GM76C256CLL@TSOP28

[(SA630)]
GM76C8128CL GM76C8128CL@SSOP32
[(SA438T)]
GM76C8128CL@TSOP32 [(SA410T)] GM76C8128CL@VSOP32
[(SA620)]
GM76C8128CLL GM76C8128CLL@SSOP32
[(SA438T)]
GM76C8128CLL@TSOP32 [(SA410T)] GM76C8128CLL@VSOP32
[(SA620)]
GM76C88AL GM76C88AL@SSOP28
[(SA430T)]
GM76C88AL@TSOP28 [(SA643)]
GM76U256CL
GM76U256CL@SSOP28 [(SA430T)] GM76U256CL@TSOP28
[(SA643)]
GM76U256CLL GM76U256CLL@SSOP28
[(SA430T)]
GM76U256CLL@TSOP28 [(SA643)]
GM76U8128CL
GM76U8128CL@SSOP32 [(SA438T)] GM76U8128CL@TSOP32
[(SA410T)]
GM76U8128CL@VSOP32 [(SA620)]
GM76U8128CLL
GM76U8128CLL@SSOP32 [(SA438T)] GM76U8128CLL@TSOP32
[(SA410T)]
GM76U8128CLL@VSOP32 [(SA620)]
GM76U8128DL
GM76U8128DL@SSOP32 [(SA438T)] GM76U8128DL@TSOP32
[(SA410T)]
GM76U8128DL@VSOP32 [(SA620)]
GM76U8128DLL
GM76U8128DLL@SSOP32 [(SA438T)] GM76U8128DLL@TSOP32
[(SA410T)]
GM76U8128DLL@VSOP32 [(SA620)]
GM76U8512L
GM76U8512L@SSOP32 [(SA438T)] GM76U8512L@TSOP32
[(SA410T)]
GM76U8512L@VSOP32 [(SA620)]
GM76U8512LL
GM76U8512LL@SSOP32 [(SA438T)] GM76U8512LL@TSOP32
[(SA410T)]
GM76U8512LL@VSOP32 [(SA620)]
GM76V256CL

GM76V256CL@SSOP28 [(SA430T)]	GM76V256CL@TSOP28
[(SA630)]	
GM76V256CLL	GM76V256CLL@SSOP28
[(SA430T)]	
GM76V256CLL@TSOP28 [(SA630)]	
GM76V8128CL	
GM76V8128CL@SSOP32 [(SA438T)]	GM76V8128CL@TSOP32
[(SA410T)]	
GM76V8128CL@VSOP32 [(SA620)]	
GM76V8128CLL	
GM76V8128CLL@SSOP32 [(SA438T)]	GM76V8128CLL@TSOP32
[(SA410T)]	
GM76V8128CLL@VSOP32 [(SA620)]	
GM76V8128DL	
GM76V8128DL@SSOP32 [(SA438T)]	GM76V8128DL@TSOP32
[(SA410T)]	
GM76V8128DL@VSOP32 [(SA620)]	
GM76V8128DLL	
GM76V8128DLL@SSOP32 [(SA438T)]	GM76V8128DLL@TSOP32
[(SA410T)]	
GM76V8128DLL@VSOP32 [(SA620)]	
GM76V8512L	
GM76V8512L@SSOP32 [(SA438T)]	GM76V8512L@TSOP32
[(SA410T)]	
GM76V8512L@VSOP32 [(SA620)]	
GM76V8512LL	
GM76V8512LL@SSOP32 [(SA438T)]	GM76V8512LL@TSOP32
[(SA410T)]	
GM76V8512LL@VSOP32 [(SA620)]	
GM77C8128A	
GM77C8128A@SSOP32 [(SA438T)]	GM77C8128A@TSOP32
[(SA410T)]	
GM77C8128A@VSOP32 [(SA620)]	

MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20
[(SA404)]	
GMS97C2051	GMS97C2051@SOIC20
[(SA404)]	
GMS97C51	GMS97C51@PLCC44
[(SA244)]	

GMS97C51@TQFP44 [(SA245A)]	
GMS97C52	
GMS97C52@PLCC44 [(SA244)]	GMS97C52@TQFP44
[(SA245A)]	
GMS97C54	
[(SA244)]	GMS97C54@PLCC44
GMS97C54@TQFP44 [(SA245A)]	
GMS97C56	
GMS97C56@PLCC44 [(SA244)]	GMS97C56@TQFP44
[(SA245A)]	
GMS97C58	
[(SA244)]	GMS97C58@PLCC44
GMS97C58@TQFP44 [(SA245A)]	
GMS97L1051	
GMS97L1051@SOIC20 [(SA404)]	
GMS97L2051	
GMS97L2051@SOIC20 [(SA404)]	
GMS97L51	
GMS97L51@PLCC44 [(SA244)]	GMS97L51@TQFP44
[(SA245A)]	
GMS97L52	
[(SA244)]	GMS97L52@PLCC44
GMS97L52@TQFP44 [(SA245A)]	
GMS97L54	
GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44
[(SA245A)]	
GMS97L56	
[(SA244)]	GMS97L56@PLCC44
GMS97L56@TQFP44 [(SA245A)]	
GMS97L58	
GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44
[(SA245A)]	
GMS99C52	
[(SA244)]	GMS99C52@PLCC44
GMS99C52@TQFP44 [(SA245A)]	
GMS99C58	
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44
[(SA245A)]	

LINKSMART

E (E) PROM / FRAM / NVRAM

L24C02 [(SA602A)] L24C02@TSOP8 [(SA026)] L24C04 L24C04@SSOP8 [(SA602A)] [(SA026)] L29004C [(SA015A1T)] L29004C@TSOP32 [(SA620)] B005)] L29S160F-B@TSOP48 [(SA247-B005)] [(SA638)] L29S400F@TSOP48 [(SA247-B005)] [(SA638)] L29S400F-B@TSOP48 [(SA247-B005)] B005)] L29S800F-B@TSOP48 [(SA247-B005)] B005)] L29W800E-B@TSOP48 [(SA247-B005)] LST28001 LST28001@PLCC32 [(SA015A1T)] [(SA620)] LST28002 [(SA015A1T)] LST28002@TSOP32 [(SA620)] LST28004 LST28004@PLCC32 [(SA015A1T)] [(SA620)]	L24C02@SSOP8 L24C04@TSOP8 L29004C@PLCC32 L29S160F@TSOP48 [(SA247- L29S400F@PSOP44 L29S400F-B@PSOP44 L29S800F@TSOP48 [(SA247- L29W800E@TSOP48 [(SA247- LST28001@TSOP32 LST28002@PLCC32 LST28004@TSOP32
---	--

MACRONIX

E (E) PROM / FRAM / NVRAM

KH25L1005 HEADER01] KH25L1005@SON8 [(SA683)] KH25L1005@SON8 (ISP) [ISP-HEADER01] KH25L1005@SOP8 [(SA602A)] KH25L1005@SOP8 (ISP) [ISP-HEADER01] KH25L1005A [(SA683)]	KH25L1005 (ISP) [ISP- KH25L1005A@SON8
---	---

KH25L1005A@SOP8 [(SA602A)]
KH25L12805D@SON8(Fast Mode) [(SA684)]
KH25L12805D@SOP16(Fast Mode) [(SA404)]
KH25L12805N@SOP16 [(SA404)]
KH25L12805N@SOP16(Fast Mode) [(SA404)]
KH25L1602@SOP28 [(SA630)] KH25L1605@SON8
[(SA684)]
KH25L1605@SON8(Fast Mode) [(SA684)]
KH25L1605@SOP16 [(SA404)]
KH25L1605@SOP16(Fast Mode) [(SA404)]
KH25L1605A@SON8 [(SA684)]
KH25L1605A@SON8(Fast Mode) [(SA684)]
KH25L1605A@SOP16 [(SA404)]
KH25L1605A@SOP16(Fast Mode) [(SA404)]
KH25L1605A@SOP8 [(SA023A)]
KH25L1605A@SOP8(Fast Mode) [(SA023A)]
KH25L1605D@SON8 [(SA684)]
KH25L1605D@SON8(Fast Mode) [(SA683)]
KH25L1605D@SOP16 [(SA404)]
KH25L1605D@SOP16(Fast Mode) [(SA404)]
KH25L1605D@SOP8(150)(Fast Mode) [(SA602A)]
KH25L1605D@SOP8(200)(Fast Mode) [(SA605B)]
KH25L1636DM1I@SOP8 [(SA602A)] KH25L1636DM2I@SOP8
[(SA605B)]
KH25L1636DMI@SOP16 [(SA404)] KH25L1636DZNI@WSON8
[(SA683)]
KH25L2005 KH25L2005(ISP) [ISP-
HEADER01]
KH25L2005@SON8 [(SA683)]
KH25L2005@SON8(ISP) [ISP-HEADER01]
KH25L2005@SOP8 [(SA602A)]
KH25L2005@SOP8(ISP) [ISP-HEADER01]
KH25L2025 KH25L2025@SON8
[(SA683)]
KH25L2025@SOP8 [(SA602A)] KH25L3202@SOP32
[(SA438T)]
KH25L3205@SOP16 [(SA404)]
KH25L3205@SOP16(Fast Mode) [(SA404)]
KH25L3205@SOP8 [(SA023A)]
KH25L3205@SOP8(Fast Mode) [(SA023A)]
KH25L3205A@SON8 [(SA684)]
KH25L3205A@SON8(Fast Mode) [(SA684)]
KH25L3205A@SOP16 [(SA404)]

KH25L3205A@SOP16(Fast Mode) [(SA404)]
KH25L3205A@SOP8 [(SA023A)]
KH25L3205A@SOP8(Fast Mode) [(SA023A)]
KH25L3205D@SON8(Fast Mode) [(SA683)]
KH25L3205D@SOP16 [(SA404)]
KH25L3205D@SOP16(Fast Mode) [(SA404)]
KH25L3205D@SOP8 [(SA023A)]
KH25L3205D@SOP8(Fast Mode) [(SA605B)]
KH25L3236DM2I@SOP8 [(SA605B)] KH25L3236DMI@SOP16
[(SA404)]
KH25L3236DZNI@WSON8 [(SA683)]
KH25L4005
KH25L4005(150mil)@SOP8 [(SA602A)]
KH25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]
KH25L4005(209mil)@SOP8 [(SA023A)]
KH25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]
KH25L4005(ISP) [ISP-HEADER01] KH25L4005@SON8
[(SA683)]
KH25L4005@SON8(ISP) [ISP-HEADER01]
KH25L4005A
KH25L4005A(150mil)@SOP8 [(SA602A)]
KH25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]
KH25L4005A(209mil)@SOP8 [(SA023A)]
KH25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]
KH25L4005A(ISP) [ISP-HEADER01] KH25L4005A@SON8
[(SA683)]
KH25L4005A@SON8(ISP) [ISP-HEADER01]
KH25L4025A
KH25L4025A(150mil)@SOP8 [(SA602A)]
KH25L4025A(209mil)@SOP8 [(SA023A)]
KH25L4025A@SON8 [(SA683)] KH25L512@SON8
[(SA683)]
KH25L512@SOP8 [(SA602A)]
KH25L512A
KH25L512A@SON8 [(SA683)] KH25L512A@SOP8
[(SA602A)]
KH25L6402@SOP32 [(SA438T)] KH25L6402A@SOP28
[(SA630)]
KH25L6405@SOP16 [(SA404)]
KH25L6405@SOP16(Fast Mode) [(SA404)]
KH25L6405@SOP8 [(SA023A)]
KH25L6405@SOP8(Fast Mode) [(SA023A)]
KH25L6405D@SON8(Fast Mode) [(SA684)]

KH25L6405D@SOP16 [(SA404)]
KH25L6405D@SOP16(Fast Mode) [(SA404)]
KH25L6405D@SOP8 [(SA023A)]
KH25L8005
KH25L8005(150mil)@SOP8 [(SA602A)]
KH25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]
KH25L8005(209mil)@SOP8 [(SA023A)]
KH25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]
KH25L8005(ISP) [ISP-HEADER01] KH25L8005@SON8
[(SA683)]
KH25L8005@SON8(ISP) [ISP-HEADER01]
KH25L802@SOP28 [(SA630)]
KH25L8025
KH25L8025(150mil)@SOP8 [(SA602A)]
KH25L8025(209mil)@SOP8 [(SA023A)]
KH25L8025@SON8 [(SA683)]
KH25L8036D
KH25L8036D@SOP16 [(SA404)]
KH25L8036D@SOP8[150 mil] [(SA602A)]
KH25L8036D@SOP8[200 mil] [(SA023A)]
KH25L8036D@WSON8 [(SA683)] KH29LV004CB@PLCC32
[(SA015A1T)]
KH29LV004CB@TSOP40 [(SA409T)] KH29LV004CT@PLCC32
[(SA015A1T)]
KH29LV004CT@TSOP40 [(SA409T)] KH29LV008CB@TSOP40
[(SA409T)]
KH29LV008CT@TSOP40 [(SA409T)]
KH29LV040C
KH29LV040C@PLCC32 [(SA015A1T)]
KH29LV160CBT@TSOP48 [(SA247-B005)]
KH29LV160CTT@TSOP48 [(SA247-B005)]
KH29LV320CBT@TSOP48 [(SA247-B005)]
KH29LV320CTT@TSOP48 [(SA247-B005)]
KH29LV320DBT@TSOP48 [(SA247-B005)]
KH29LV320DTT@TSOP48 [(SA247-B005)]
KH29LV400CBT@TSOP48 [(SA247-B005)]
KH29LV400CTT@TSOP48 [(SA247-B005)]
KH29LV640DBT@TSOP48 [(SA247-B005)]
KH29LV640DTT@TSOP48 [(SA247-B005)]
KH29LV800CBT@TSOP48 [(SA247-B005)]
KH29LV800CTT@TSOP48 [(SA247-B005)]
MX25L1005 MX25L1005(ISP) [ISP-
HEADER01]

MX25L1005@SON8 [(SA683)]
MX25L1005@SON8(ISP) [ISP-HEADER01]
MX25L1005@SOP8 [(SA602A)]
MX25L1005@SOP8(ISP) [ISP-HEADER01]
MX25L1005A MX25L1005A@SON8
[(SA683)]
MX25L1005A@SOP8 [(SA602A)]
MX25L12805D@SON8(Fast Mode) [(SA684)]
MX25L12805D@SOP16(Fast Mode) [(SA404)]
MX25L12805N@SOP16 [(SA404)]
MX25L12805N@SOP16(Fast Mode) [(SA404)]
MX25L1602@SOP28 [(SA630)] MX25L1605@SON8
[(SA684)]
MX25L1605@SON8(Fast Mode) [(SA684)]
MX25L1605@SOP16 [(SA404)]
MX25L1605@SOP16(Fast Mode) [(SA404)]
MX25L1605A@SON8 [(SA684)]
MX25L1605A@SON8(Fast Mode) [(SA684)]
MX25L1605A@SOP16 [(SA404)]
MX25L1605A@SOP16(Fast Mode) [(SA404)]
MX25L1605A@SOP8 [(SA023A)]
MX25L1605A@SOP8(Fast Mode) [(SA023A)]
MX25L1605D@SON8 [(SA684)]
MX25L1605D@SON8(Fast Mode) [(SA683)]
MX25L1605D@SOP16 [(SA404)]
MX25L1605D@SOP16(Fast Mode) [(SA404)]
MX25L1605D@SOP8(150)(Fast Mode) [(SA602A)]
MX25L1605D@SOP8(200)(Fast Mode) [(SA605B)]
MX25L1615D@SOP16 [(SA404)] MX25L1615D@SOP8
[(SA023A)]
MX25L1635DM1I@SOP8 [(SA602A)] MX25L1635DM2I@SOP8
[(SA605B)]
MX25L1635DMI@SOP16 [(SA404)] MX25L1635DZNI@WSON8
[(SA683)]
MX25L1636DM1I@SOP8 [(SA602A)] MX25L1636DM2I@SOP8
[(SA605B)]
MX25L1636DMI@SOP16 [(SA404)] MX25L1636DZNI@WSON8
[(SA683)]
MX25L2005 MX25L2005(ISP) [ISP-
HEADER01]
MX25L2005@SON8 [(SA683)]
MX25L2005@SON8(ISP) [ISP-HEADER01]
MX25L2005@SOP8 [(SA602A)]

MX25L2005@SOP8 (ISP) [ISP-HEADER01]
MX25L2025 [(SA683)] MX25L2025@SON8
MX25L2025@SOP8 [(SA602A)] MX25L3202@SOP32
[(SA438T)]
MX25L3205@SOP16 [(SA404)]
MX25L3205@SOP16 (Fast Mode) [(SA404)]
MX25L3205@SOP8 [(SA023A)]
MX25L3205@SOP8 (Fast Mode) [(SA023A)]
MX25L3205A@SON8 [(SA684)]
MX25L3205A@SON8 (Fast Mode) [(SA684)]
MX25L3205A@SOP16 [(SA404)]
MX25L3205A@SOP16 (Fast Mode) [(SA404)]
MX25L3205A@SOP16 (Parallel Mode) [(SA404)]
MX25L3205A@SOP8 [(SA023A)]
MX25L3205A@SOP8 (Fast Mode) [(SA023A)]
MX25L3205D@SON8 (Fast Mode) [(SA683)]
MX25L3205D@SOP16 [(SA404)]
MX25L3205D@SOP16 (Fast Mode) [(SA404)]
MX25L3205D@SOP8 [(SA023A)]
MX25L3205D@SOP8 (Fast Mode) [(SA605B)]
MX25L3215D@SOP16 [(SA404)] MX25L3215D@SOP8
[(SA023A)]
MX25L3235DM2I@SOP8 [(SA605B)] MX25L3235DMI@SOP16
[(SA404)]
MX25L3235DZNI@WSON8 [(SA683)] MX25L3236DM2I@SOP8
[(SA605B)]
MX25L3236DMI@SOP16 [(SA404)] MX25L3236DZNI@WSON8
[(SA683)]
MX25L4005
MX25L4005 (150mil)@SOP8 [(SA602A)]
MX25L4005 (150mil)@SOP8 (ISP) [ISP-HEADER01]
MX25L4005 (209mil)@SOP8 [(SA023A)]
MX25L4005 (209mil)@SOP8 (ISP) [ISP-HEADER01]
MX25L4005 (ISP) [ISP-HEADER01] MX25L4005@SON8
[(SA683)]
MX25L4005@SON8 (ISP) [ISP-HEADER01]
MX25L4005A
MX25L4005A (150mil)@SOP8 [(SA602A)]
MX25L4005A (150mil)@SOP8 (ISP) [ISP-HEADER01]
MX25L4005A (209mil)@SOP8 [(SA023A)]
MX25L4005A (209mil)@SOP8 (ISP) [ISP-HEADER01]
MX25L4005A (ISP) [ISP-HEADER01] MX25L4005A@SON8

[(SA683)]
MX25L4005A@SON8 (ISP) [ISP-HEADER01]
MX25L4025A
MX25L4025A(150mil)@SOP8 [(SA602A)]
MX25L4025A(209mil)@SOP8 [(SA023A)]
MX25L4025A@SON8 [(SA683)] MX25L512@SON8
[(SA683)]
MX25L512@SOP8 [(SA602A)]
MX25L512A
MX25L512A@SON8 [(SA683)] MX25L512A@SOP8
[(SA602A)]
MX25L6402@SOP32 [(SA438T)] MX25L6402A@SOP28
[(SA630)]
MX25L6405@SOP16 [(SA404)]
MX25L6405@SOP16(Fast Mode) [(SA404)]
MX25L6405@SOP8 [(SA023A)]
MX25L6405@SOP8(Fast Mode) [(SA023A)]
MX25L6405D@SON8(Fast Mode) [(SA684)]
MX25L6405D@SOP16 [(SA404)]
MX25L6405D@SOP16(Fast Mode) [(SA404)]
MX25L6405D@SOP8 [(SA023A)] MX25L6415D@SOP16
[(SA404)]
MX25L6415D@SOP8 [(SA023A)]
MX25L8005
MX25L8005(150mil)@SOP8 [(SA602A)]
MX25L8005(150mil)@SOP8 (ISP) [ISP-HEADER01]
MX25L8005(209mil)@SOP8 [(SA023A)]
MX25L8005(209mil)@SOP8 (ISP) [ISP-HEADER01]
MX25L8005 (ISP) [ISP-HEADER01] MX25L8005@SON8
[(SA683)]
MX25L8005@SON8 (ISP) [ISP-HEADER01]
MX25L802@SOP28 [(SA630)]
MX25L8025
MX25L8025(150mil)@SOP8 [(SA602A)]
MX25L8025(209mil)@SOP8 [(SA023A)]
MX25L8025@SON8 [(SA683)]
MX25L8036D
MX25L8036D@SOP16 [(SA602A)]
MX25L8036D@SOP8[150 mil] [(SA602A)]
MX25L8036D@SOP8[200 mil] [(SA023A)]
MX25L8036D@WSON8 [(SA683)]
MX26C1000B
MX26C1000B@PLCC32 [(SA015A1T)] MX26C1000B@SOIC32

[(SA603)]
MX26C1000B@TSOP32 [(SA410T)]
MX26C2000B
MX26C2000B@PLCC32 [(SA015A1T)] MX26C2000B@SOIC32
[(SA603)]
MX26C2000B@TSOP32 [(SA410T)]
MX26C512A
MX26C512A@PLCC32 [(SA015A1T)] MX26C512A@SOIC28
[(SA630)]
MX26C512A@TSOP28 [(SA430T)]
MX26F128J3TC@TSOP56 [(SA628-B018)]
MX26F128J3XC@CSP64 [(SA655A-B054A-T064F001)]
MX26F640J3TC@TSOP56 [(SA628-B018)]
MX26F640J3XC@CSP64 [(SA655A-B054A-T064F001)]
MX26L12711MC@PSOP44 [(SA638)] MX26L12811MC@PSOP44
[(SA638)]
MX26L6419T@TSOP48 [(SA247-B005)] MX26L6420@PSOP44
[(SA638)]
MX26L6420@TSOP48 [(SA247-B005)] MX26LV004B@PLCC32
[(SA015A1T)]
MX26LV004B@TSOP40 [(SA409T)] MX26LV004T@PLCC32
[(SA015A1T)]
MX26LV004T@TSOP40 [(SA409T)] MX26LV008B@TSOP40
[(SA409T)]
MX26LV008T@TSOP40 [(SA409T)]
MX26LV040(QC)@PLCC32 [(SA015A1T)]
MX26LV040(TC)@TSOP32 [(SA410T)]
MX26LV160BT@TSOP48 [(SA247-B005)]
MX26LV160BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]
MX26LV160BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]
MX26LV160TT@TSOP48 [(SA247-B005)]
MX26LV160TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]
MX26LV160TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]
MX26LV400BT@TSOP48 [(SA247-B005)]
MX26LV400BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]
MX26LV400BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]
MX26LV400TT@TSOP48 [(SA247-B005)]
MX26LV400TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]
MX26LV400TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]
MX26LV800BM@PSOP44 [(SA638)]
MX26LV800BT@TSOP48 [(SA247-B005)]
MX26LV800BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX26LV800BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]

MX26LV800TM@PSOP44 [(SA638)]
MX26LV800TT@TSOP48 [(SA247-B005)]
MX26LV800TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX26LV800TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX27C1000 MX27C1000@PLCC32
[(SA015A1T)]
MX27C1000@SOIC32 [(SA603)] MX27C1000@TSOP32
[(SA410T)]
MX27C1000A MX27C1000A@PLCC32
[(SA015A1T)]
MX27C1000A@SOIC32 [(SA603)] MX27C1000A@TSOP32
[(SA410T)]
MX27C1001 MX27C1001@PLCC32
[(SA015A1T)]
MX27C1001@SOIC32 [(SA603)] MX27C1001@TSOP32
[(SA410T)]
MX27C1024 MX27C1024@PLCC44
[(SA244)]
MX27C1024@TSOP40 [(SA409T)]
MX27C1024A MX27C1024A@TSOP40
MX27C1024A@PLCC44 [(SA244)]
[(SA409T)]
MX27C1024B MX27C1024B@PLCC44
[(SA244)]
MX27C1024B@TSOP40 [(SA409T)]
MX27C1100
MX27C2000 MX27C2000@PLCC32
[(SA015A1T)]
MX27C2000@SOIC32 [(SA603)] MX27C2000@TSOP32
[(SA410T)]
MX27C2000A MX27C2000A@PLCC32
[(SA015A1T)]
MX27C2000A@SOIC32 [(SA603)] MX27C2000A@TSOP32
[(SA410T)]
MX27C2048 MX27C2048@PLCC44
[(SA244)]
MX27C2048@TSOP40 [(SA409T)]
MX27C2100
MX27C256 MX27C256@PLCC32
[(SA015A1T)]
MX27C4000 MX27C4000@PLCC32
[(SA015A1T)]
MX27C4000@SOIC32 [(SA603)] MX27C4000@TSOP32

[(SA410T)]	
MX27C4000A	MX27C4000A@PLCC32
[(SA015A1T)]	
MX27C4000A@SOIC32 [(SA603)]	MX27C4000A@TSOP32
[(SA410T)]	
MX27C4096	MX27C4096@PLCC44
[(SA244)]	
MX27C4100	
MX27C4111	
MX27C512	MX27C512@PLCC32
[(SA015A1T)]	
MX27C516	MX27C516@PLCC44
[(SA244)]	
MX27C516@TSOP40 [(SA409T)]	
MX27C8000	
MX27C8000@PLCC32 [(SA015A1T)]	MX27C8000@SOIC32
[(SA603)]	
MX27C8000@TSOP32 [(SA410T)]	
MX27C8000A	
MX27C8000A@PLCC32 [(SA015A1T)]	MX27C8000A@SOIC32
[(SA603)]	
MX27C8000A@TSOP32 [(SA410T)]	
MX27C8100	
MX27C8100@PSOP44 [(SA638)]	
MX27C8111	
MX27C8111@PSOP44 [(SA638)]	
MX27L1000	
MX27L1000@PLCC32 [(SA015A1T)]	MX27L1000@TSOP32
[(SA410T)]	
MX27L2000	MX27L2000@PLCC32
[(SA015A1T)]	
MX27L2000@TSOP32 [(SA410T)]	
MX27L256	
MX27L256@PLCC32 [(SA015A1T)]	MX27L256@TSOP32
[(SA430T)]	
MX27L4000	MX27L4000@PLCC32
[(SA015A1T)]	
MX27L4000@TSOP32 [(SA410T)]	
MX27L4096	
MX27L4096@PLCC44 [(SA244)]	
MX27L512	
MX27L512@PLCC32 [(SA015A1T)]	MX27L512@TSOP28
[(SA430T)]	

MX28F002B@TSOP40 [(SA409T)]	MX28F002T@TSOP40
[(SA409T)]	
MX28F1000	MX28F1000@PLCC32
[(SA015A1T)]	
MX28F1000@SOP32 [(SA603)]	MX28F1000@TSOP32
[(SA410T)]	
MX28F1000P	MX28F1000P@PLCC32
[(SA015A1T)]	
MX28F1000P@TSOP32 [(SA410T)]	
MX28F160C3BT@TSOP48 [(SA247-B005)]	
MX28F160C3BX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F160C3TT@TSOP48 [(SA247-B005)]	
MX28F160C3TX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F2000	MX28F2000@PLCC32
[(SA015A1T)]	
MX28F2000@TSOP32 [(SA410T)]	
MX28F2000P	
MX28F2000P@PLCC32 [(SA015A1T)]	MX28F2000P@TSOP32
[(SA410T)]	
MX28F2100B@PSOP44 [(SA638)]	MX28F2100B@TSOP48 [(SA247-
B005)]	
MX28F2100T@PSOP44 [(SA638)]	MX28F2100T@TSOP48 [(SA247-
B005)]	
MX28F4000	MX28F4000@PLCC32
[(SA015A1T)]	
MX28F4000@TSOP32 [(SA410T)]	
MX28F640C3BT@TSOP48 [(SA247-B005)]	
MX28F640C3BX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F640C3TT@TSOP48 [(SA247-B005)]	
MX28F640C3TX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX29F001B	MX29F001B@PLCC32
[(SA015A1T)]	
MX29F001B@TSOP32 [(SA410T)]	
MX29F001T	
MX29F001T@PLCC32 [(SA015A1T)]	MX29F001T@TSOP32
[(SA410T)]	
MX29F002B	MX29F002B@PLCC32
[(SA015A1T)]	
MX29F002B@TSOP32 [(SA410T)]	
MX29F002NB	
MX29F002NB@PLCC32 [(SA015A1T)]	MX29F002NB@TSOP32
[(SA410T)]	
MX29F002NT	MX29F002NT@PLCC32

[(SA015A1T)]
MX29F002NT@TSOP32 [(SA410T)]
MX29F002T
MX29F002T@PLCC32 [(SA015A1T)] MX29F002T@TSOP32
[(SA410T)]
MX29F004B MX29F004B@PLCC32
[(SA015A1T)]
MX29F004B@TSOP32 [(SA410T)]
MX29F004T
MX29F004T@PLCC32 [(SA015A1T)] MX29F004T@TSOP32
[(SA410T)]
MX29F016@PSOP44 [(SA638)] MX29F016@TSOP40
[(SA409T)]
MX29F016@TSOP48 [(SA247-B005)]
MX29F022B
MX29F022B@PLCC32 [(SA015A1T)] MX29F022B@TSOP32
[(SA410T)]
MX29F022NB MX29F022NB@PLCC32
[(SA015A1T)]
MX29F022NB@TSOP32 [(SA410T)]
MX29F022NT
MX29F022NT@PLCC32 [(SA015A1T)] MX29F022NT@TSOP32
[(SA410T)]
MX29F022T MX29F022T@PLCC32
[(SA015A1T)]
MX29F022T@TSOP32 [(SA410T)]
MX29F040
MX29F040@PLCC32 [(SA015A1T)] MX29F040@TSOP32
[(SA410T)]
MX29F040C MX29F040C@PLCC32
[(SA015A1T)]
MX29F040C@TSOP32 [(SA410T)] MX29F080@PSOP44
[(SA638)]
MX29F080@TSOP40 [(SA409T)] MX29F100B@PSOP44 [(SA638-
B006)]
MX29F100B@TSOP48 [(SA247-B005)] MX29F100T@PSOP44 [(SA638-
B006)]
MX29F100T@TSOP48 [(SA247-B005)] MX29F1610@PSOP44
[(SA638)]
MX29F1610@TSOP48 [(SA247-B005)] MX29F1610A@PSOP44
[(SA638)]
MX29F1610A@TSOP48 [(SA247-B005)] MX29F1610B@TSOP48 [(SA247-
B005)]

MX29F1611@PSOP44 [(SA638)]
MX29F1615
MX29F200B@PSOP44 [(SA638-B006)] MX29F200B@TSOP48 [(SA247-B005)]
MX29F200CB@PSOP44 [(SA638)] MX29F200CB@TSOP48 [(SA247-B005)]
MX29F200CT@PSOP44 [(SA638)] MX29F200CT@TSOP48 [(SA247-B005)]
MX29F200T@PSOP44 [(SA638-B006)] MX29F200T@TSOP48 [(SA247-B005)]
MX29F4000 MX29F400B@PSOP44 [(SA638-B006)]
MX29F400B@TSOP48 [(SA247-B005)] MX29F400CB@PSOP44 [(SA638)]
MX29F400CB@TSOP48 [(SA247-B005)] MX29F400CT@PSOP44 [(SA638)]
MX29F400CT@TSOP48 [(SA247-B005)] MX29F400T@PSOP44 [(SA638-B006)]
MX29F400T@TSOP48 [(SA247-B005)] MX29F800B@PSOP44 [(SA638-B006)]
MX29F800B@TSOP48 [(SA247-B005)] MX29F800T@PSOP44 [(SA638-B006)]
MX29F800T@TSOP48 [(SA247-B005)] MX29L1611@PSOP44 [(SA638)]
MX29L1611@TSOP48 [(SA247-B005)]
MX29L1611G
MX29L3211@PSOP44 [(SA638)] MX29L3211@TSOP48 [(SA247-B005)]
MX29LA128MB@TSOP56 [(SA628-B102)]
MX29LA128MT@TSOP56 [(SA628-B102)]
MX29LA129MH@TSOP56 [(SA628-B018)]
MX29LA129ML@TSOP56 [(SA628-B018)]
MX29LA320MB@CFBGA48 [(SA642G-B026A-T048F001Y)]
MX29LA320MB@TSOP48 [(SA247-B005)]
MX29LA320MT@CFBGA48 [(SA642G-B026A-T048F001Y)]
MX29LA320MT@TSOP48 [(SA247-B005)]
MX29LA321MB@FBGA64 [(SA655A-B054A-T064F001Y)]
MX29LA321MB@TSOP56 [(SA628-B018)]
MX29LA321MH@FBGA64 [(SA655A-B054A-T064F001Y)]
MX29LA321MH@TSOP56 [(SA628-B018)]
MX29LA321ML@FBGA64 [(SA655A-B054A-T064F001Y)]
MX29LA321ML@TSOP56 [(SA628-B018)]
MX29LA321MT@FBGA64 [(SA655A-B054A-T064F001Y)]

MX29LA321MT@TSOP56 [(SA628-B018)]
MX29LV002CB@PLCC32 [(SA015A1T)] MX29LV002CB@TSOP32
[(SA410T)]
MX29LV002CT@PLCC32 [(SA015A1T)] MX29LV002CT@TSOP32
[(SA410T)]
MX29LV002NCB@PLCC32 [(SA015A1T)] MX29LV002NCB@TSOP32
[(SA410T)]
MX29LV002NCT@PLCC32 [(SA015A1T)] MX29LV002NCT@TSOP32
[(SA410T)]
MX29LV004B@PLCC32 [(SA015A1T)] MX29LV004B@TSOP40
[(SA409T)]
MX29LV004CB@PLCC32 [(SA015A1T)] MX29LV004CB@TSOP40
[(SA409T)]
MX29LV004CT@PLCC32 [(SA015A1T)] MX29LV004CT@TSOP40
[(SA409T)]
MX29LV004T@PLCC32 [(SA015A1T)] MX29LV004T@TSOP40
[(SA409T)]
MX29LV008B@TSOP40 [(SA409T)] MX29LV008BB@TSOP40
[(SA409T)]
MX29LV008BT@TSOP40 [(SA409T)] MX29LV008CB@TSOP40
[(SA409T)]
MX29LV008CT@TSOP40 [(SA409T)] MX29LV008T@TSOP40
[(SA409T)]
MX29LV017AT@TSOP40 [(SA409T)]
MX29LV017AX@CSP48 [(SA642G-B026A-T048F001)]
MX29LV017BT@TSOP40 [(SA409T)]
MX29LV017BX@CSP48 [(SA642G-B026A-T048F001)]
MX29LV033T@TSOP40 [(SA409T)] MX29LV040@PLCC32
[(SA015A1T)]
MX29LV040@TSOP32 [(SA410T)] MX29LV040C@PLCC32
[(SA015A1T)]
MX29LV040C@TSOP32 [(SA410T)]
MX29LV065BT@TSOP48 [(SA247-B005)]
MX29LV065BXB@FBGA63 [(SA642M-B026A-W048F001)]
MX29LV065M@TSOP48 [(SA247-B005)] MX29LV081@TSOP40
[(SA409T)]
MX29LV128DB@TSOP48 [(SA247-B005)]
MX29LV128DB@TSOP56 [(SA628-B102)]
MX29LV128DT@TSOP48 [(SA247-B005)]
MX29LV128DT@TSOP56 [(SA628-B102)]
MX29LV128MB@TSOP56 [(SA628-B102)]
MX29LV128MH@TSOP56 [(SA628-B102)]
MX29LV128ML@TSOP56 [(SA628-B102)]

MX29LV128MT@TSOP56 [(SA628-B102)]
MX29LV160AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160AB@PSOP44 [(SA638)]
MX29LV160AB@TSOP48 [(SA247-B005)]
MX29LV160AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160AT@PSOP44 [(SA638)]
MX29LV160AT@TSOP48 [(SA247-B005)]
MX29LV160B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160B@PSOP44 [(SA638)] MX29LV160B@TSOP48 [(SA247-B005)]
MX29LV160BB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160BB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160BB@PSOP44 [(SA638)]
MX29LV160BB@TSOP48 [(SA247-B005)]
MX29LV160BT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160BT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160BT@PSOP44 [(SA638)]
MX29LV160BT@TSOP48 [(SA247-B005)]
MX29LV160CBM@PSOP44 [(SA638)]
MX29LV160CBT@TSOP48 [(SA247-B005)]
MX29LV160CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV160CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV160CTM@PSOP44 [(SA638)]
MX29LV160CTT@TSOP48 [(SA247-B005)]
MX29LV160CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV160CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV160DBT@TSOP48 [(SA247-B005)]
MX29LV160DBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV160DTT@TSOP48 [(SA247-B005)]
MX29LV160DTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV160T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV160T@PSOP44 [(SA638)] MX29LV160T@TSOP48 [(SA247-B005)]
MX29LV320ABT@TSOP48 [(SA247-B005)]
MX29LV320ABXB@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV320ABXE@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV320ATT@TSOP48 [(SA247-B005)]
MX29LV320ATXB@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV320ATXE@CSP48 [(SA642B-B026A-Y072F001)]

MX29LV320BT@TSOP48 [(SA247-B005)]
MX29LV320BXB@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV320BXE@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV320CBB@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320CBE@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320CBT@TSOP48 [(SA247-B005)]
MX29LV320CTB@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320CTE@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320CTT@TSOP48 [(SA247-B005)]
MX29LV320DBB@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320DBE@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320DBT@TSOP48 [(SA247-B005)]
MX29LV320DTB@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320DTE@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320DTT@TSOP48 [(SA247-B005)]
MX29LV320MB@CFBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320MB@PSOP44 [(SA638)]
MX29LV320MB@TSOP48 [(SA247-B005)]
MX29LV320MH@TSOP56 [(SA628-B067)]
MX29LV320ML@TSOP56 [(SA628-B067)]
MX29LV320MT@CFBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV320MT@PSOP44 [(SA638)]
MX29LV320MT@TSOP48 [(SA247-B005)]
MX29LV320TT@TSOP48 [(SA247-B005)]
MX29LV320TXB@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV320TXE@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV321DBT@TSOP48 [(SA247-B005)]
MX29LV321DBXB@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV321DTT@TSOP48 [(SA247-B005)]
MX29LV321DTXB@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV400B@PSOP44 [(SA638)] MX29LV400B@TSOP48 [(SA247-B005)]
MX29LV400BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV400BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV400CBM@PSOP44 [(SA638)]
MX29LV400CBT@TSOP48 [(SA247-B005)]
MX29LV400CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV400CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV400CTM@PSOP44 [(SA638)]
MX29LV400CTT@TSOP48 [(SA247-B005)]
MX29LV400CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV400CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV400T@PSOP44 [(SA638)] MX29LV400T@TSOP48 [(SA247-

B005)]
MX29LV400TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV400TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV640BBT@TSOP48 [(SA247-B005)]
MX29LV640BBXB@FBGA63 [(SA642M-B026A-W048F001Y)]
MX29LV640BT@TSOP48 [(SA247-B005)]
MX29LV640BTT@TSOP48 [(SA247-B005)]
MX29LV640BTXB@FBGA63 [(SA642M-B026A-W048F001Y)]
MX29LV640BUT@TSOP48 [(SA247-B005)]
MX29LV640BUXB@FBGA63 [(SA642M-B026A-W048F001)]
MX29LV640BXB@FBGA63 [(SA642C-B026A-Y056F001)]
MX29LV640BXC@FBGA64 [(SA655A-B044A-T064F001)]
MX29LV640DBT@TSOP48 [(SA247-B005)]
MX29LV640DBX@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV640DTT@TSOP48 [(SA247-B005)]
MX29LV640DTX@FBGA48 [(SA642G-B026A-T048F001Y)]
MX29LV640MB@FBGA63 [(SA642M-B026A-W048F001Y)]
MX29LV640MB@TSOP48 [(SA247-B005)]
MX29LV640MH@FBGA64 [(SA655F-B099A-W064F001Y)]
MX29LV640MH@TSOP56 [(SA628-B067)]
MX29LV640ML@FBGA64 [(SA655F-B099A-W064F001Y)]
MX29LV640ML@TSOP56 [(SA628-B067)]
MX29LV640MT@FBGA63 [(SA642M-B026A-W048F001Y)]
MX29LV640MT@TSOP48 [(SA247-B005)]
MX29LV640TT@TSOP48 [(SA247-B005)]
MX29LV640TXB@FBGA63 [(SA642C-B026A-Y056F001)]
MX29LV640TXC@FBGA64 [(SA655A-B044A-T064F001)]
MX29LV641MH@TSOP48 [(SA247-B005)]
MX29LV641ML@TSOP48 [(SA247-B005)]
MX29LV800AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV800AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV800AB@PSOP44 [(SA638)]
MX29LV800AB@TSOP48 [(SA247-B005)]
MX29LV800AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV800AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV800AT@PSOP44 [(SA638)]
MX29LV800AT@TSOP48 [(SA247-B005)]
MX29LV800B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV800B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV800B@PSOP44 [(SA638)] MX29LV800B@TSOP48 [(SA247-B005)]
MX29LV800CBM@PSOP44 [(SA638)]
MX29LV800CBT(Low)@TSOP48 [(SA247-B005)]

MX29LV800CBT@TSOP48 [(SA247-B005)]
MX29LV800CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV800CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV800CTM@PSOP44 [(SA638)]
MX29LV800CTT(Low)@TSOP48 [(SA247-B005)]
MX29LV800CTT@TSOP48 [(SA247-B005)]
MX29LV800CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV800CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29LV800T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV800T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LV800T@PSOP44 [(SA638)] MX29LV800T@TSOP48 [(SA247-B005)]
MX29LW160BT@TSOP48 [(SA247-B005)]
MX29LW160BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]
MX29LW160BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LW160TT@TSOP48 [(SA247-B005)]
MX29LW160TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]
MX29LW160TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LW161BT@TSOP48 [(SA247-B005)]
MX29LW161BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]
MX29LW161BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LW161TT@TSOP48 [(SA247-B005)]
MX29LW161TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]
MX29LW161TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LW320BT@TSOP48 [(SA247-B005)]
MX29LW320BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]
MX29LW320BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LW320TT@TSOP48 [(SA247-B005)]
MX29LW320TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]
MX29LW320TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LW321BT@TSOP48 [(SA247-B005)]
MX29LW321BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]
MX29LW321BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]
MX29LW321TT@TSOP48 [(SA247-B005)]
MX29LW321TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]
MX29LW321TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]
MX29SL800CB@TSOP48 [(SA247-B005)]
MX29SL800CBXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29SL800CBXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29SL800CBXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]
MX29SL800CT@TSOP48 [(SA247-B005)]
MX29SL800CTXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]
MX29SL800CTXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]

MX29SL800CTXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]
MX69F1602C3BX@FBGA72 [(SA642E-B041A-T072F001)]
MX69F1602C3TX@FBGA72 [(SA642E-B041A-T072F001)]
MX69F1604C3BX@FBGA72 [(SA642E-B041A-T072F001)]
MX69F1604C3TX@FBGA72 [(SA642E-B041A-T072F001)]
MX69LW162BXB@CSP69 [(SA642A-B032A-Y096F001)]
MX69LW162TXB@CSP69 [(SA642A-B032A-Y096F001)]
MX69LW164BXB@CSP69 [(SA642A-B032A-Y096F001)]
MX69LW164TXB@CSP69 [(SA642A-B032A-Y096F001)]
MX69LW322BXB@CSP69 [(SA642A-B032A-Y096F001)]
MX69LW322TXB@CSP69 [(SA642A-B032A-Y096F001)]
MX69LW324BXB@CSP69 [(SA642A-B032A-Y096F001)]
MX69LW324TXB@CSP69 [(SA642A-B032A-Y096F001)]

MICROCONTROLLER

MX10E8050I [(SA244)] MX10E8050I@PLCC44
MX10E8050I@TQFP44 [(SA245A)] MX10EXA@PLCC44
[(SA244)]
MX10EXA@TQFP44 [(SA245A)]
MX10F201FC@TQFP100(*) [(TA010-B006)]
MX10F202FC@TQFP100(*) [(TA010-B006)]
MX10FLCD
MX10FMAXD
MX10FMAXD@PLCC44 [(SA244)] MX10FMAXD@TQFP44
[(SA245A)]

MAXIM

E (E) PROM / FRAM / NVRAM

DS1220AB
DS1220AD
DS1220Y
DS1225AB
DS1225AD
DS1225D
DS1225E
DS1225Y
DS1230AB

DS1230W
DS1230Y
DS1235AB
DS1235Y
DS1243Y
DS1244
DS1244Y
DS1245AB
DS1245EE
DS1245P
DS1245W
DS1245Y
DS1248P
DS1248W
DS1248Y
DS1249AB
DS1249W
DS1249Y
DS1250AB
DS1250W
DS1250Y
DS1251AB
DS1251W
DS1251Y
DS1256P
DS1256W
DS1256Y
DS1265AB
DS1265W
DS1265Y
DS1270AB
DS1270W
DS1270Y
DS1284
DS1284N
DS1284Q@PLCC28 [(SA008A)] DS1284QN@PLCC28
[(SA008A)]
DS1286
DS1286I
DS1287
DS1287A
DS12887
DS12887A

DS12C887
DS12C887A
DS1386 (32K)
(8K) DS1386
DS1485 DS1485@SOIC28
[(SA630)]
DS1488
DS1553
DS1553W
DS1554
DS1554W
DS1556
DS1642
DS1643
DS1644
DS1644P [ordering number is marked above]
DS1644PS [(PEP+S414T)]
DS1645AB
DS1645EE
DS1645Y
DS1646
DS1647
DS1647LPM
DS1650AB
DS1650Y DS1687-
3
DS1687-5 DS17287-
3
DS17287-5
DS1742
DS1742W
DS1743
DS1743P
DS1743W
DS1743WP
DS1744
DS1744P
DS1744W
DS1744WP
DS1746
DS1747
DS1747P [ordering number is marked above]
DS1747PS [(PEP+S414T)]

DS1747W	
DS1747WP [ordering number is marked above]	
DS1747WPS [(PEP+S414T)]	DS17487-
3	
DS17487-5	DS17887-
3	
DS17887-5	DS2430A@TO-
92	
DS2430AP@TSOC6 [(SA602A)]	DS2431@TO-
92	
DS2431P@TSOC6 [(SA602A)]	DS2432P@TSOC6
[(SA602A)]	
DS2433@PR-35	DS2433S(3.9)@SOIC8
[(SA602A)]	
DS2433S(5.5)@SOIC8 [(SA605A)]	
DS2502	
DS2502P@TSOC6 [(SA602A)]	DS2502S@SOIC8
[(SA602A)]	
DS2502UNW	DS2502UNW@SOIC8
[(SA602A)]	
DS2502UNW@TSOC6 [(SA602A)]	
DS2506	
DS2506S@SOIC8 [(SA023A)]	
DS4510@uSOP10	
DS4520@TSSOP16 [(SA026)]	DS4550@TSSOP20
[(SA026)]	

MICROCONTROLLER

DS87C520	DS87C520@PLCC44
[(SA244)]	
DS87C520@TQFP44 [(SA245A)]	DS89C420(rev.
A)	
DS89C420(rev.A)@PLCC44 [(SA244)]	
DS89C420(rev.A)@TQFP44 [(SA245A)]	

MAXWELL

E(E) PROM/FRAM/NVRAM

27C010T@LDFP32 [(SA438T)]	
---------------------------	--

28C010	
28C010@PLCC32 [(SA015A1T)]	28C010@TSOP32
[(SA438T)]	
28C010T	28C010T@PLCC32
[(SA015A1T)]	
28C010T@TSOP32 [(SA438T)]	
28C011	
28C011@PLCC32 [(SA015A1T)]	28C011@TSOP32
[(SA438T)]	
28C011T	28C011T@PLCC32
[(SA015A1T)]	
28C011T@TSOP32 [(SA438T)]	

MEGAWIN

E (E) PROM / FRAM / NVRAM

MM25SB512@SOIC8 [(SA602A)]	
MM29F040	
MM29F040@PLCC32 [(SA015A1T)]	MM29F040@TSOP32
[(SA410T)]	
MM29LF040	MM29LF040@PLCC32
[(SA015A1T)]	
MM29LF040@TSOP32 [(SA410T)]	

MICROCONTROLLER

MPC89L516X2	MPC89L516X2@PLCC44
[(SA244)]	
MPC89L516X2@TQFP44 [(SA245A)]	
MPC89L556X2	
MPC89L556X2@PLCC44 [(SA244)]	MPC89L556X2@TQFP44
[(SA245A)]	

MEMOCOM

E (E) PROM / FRAM / NVRAM

KI01602AB (Ga1) @FBGA66 [(SA642R-B023A-T096F001Y)]	
--	--

KI01602AB(Gb1)@FBGA66 [(SA642E-B023A-T072001Y)]
 KI01602AT(Ga1)@FBGA66 [(SA642R-B023A-T096F001Y)]
 KI01602AT(Gb1)@FBGA66 [(SA642E-B023A-T072001Y)]
 KI01604AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
 KI01604AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
 KI01604AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
 KI01604AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
 KI01608AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
 KI01608AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
 KI01608AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
 KI01608AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
 KI03204AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
 KI03204AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
 KI03204AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
 KI03204AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
 KI03208AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
 KI03208AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
 KI03208AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
 KI03208AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
 KS01602AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
 KS01602AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
 KS01604AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
 KS01604AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
 KS03204AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
 KS03204AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
 KS03208AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]
 KS03208AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]

MICON

MICROCONTROLLER

MDT10P21(dip18) (dip20)	MDT10P21
MDT10P21(dip22) [(SA404A)]	MDT10P21@SOP18
MDT10P21@SOP20 [(SA404A)] [(SA404A)]	MDT10P21@SOP24
MDT10P22(dip18) (dip20)	MDT10P22
MDT10P22(dip22) [(SA404A)]	MDT10P22@SOP18

MDT10P22@SOP20 [(SA404A)]	MDT10P22@SOP24
[(SA404A)]	
MDT10P23(dip18)	MDT10P23
(dip20)	
MDT10P23(dip22)	MDT10P23@SOP18
[(SA404A)]	
MDT10P23@SOP20 [(SA404A)]	MDT10P23@SOP24
[(SA404A)]	
MDT10P61	MDT10P61@SOP18
[(SA404A)]	
MDT10P61@SSOP20 [(SA626A)]	
MDT2005	
MDT2005@SOP18 [(SA404A)]	MDT2005@SSOP20
[(SA626A)]	
MDT2010	MDT2010@SOP18
[(SA404A)]	
MDT2010@SSOP20 [(SA626A)]	
MDT2020	
MDT2020@SOP28 [(SA404A)]	MDT2020@SSOP28
[(SA626A)]	
MDT2030	MDT2030@SOP18
[(SA404A)]	
MDT2030@SSOP20 [(SA626A)]	
MDT2050	
MDT2050@SOP18 [(SA404A)]	MDT2050@SSOP20
[(SA626A)]	
MDT2051	MDT2051@SOP18
[(SA404A)]	
MDT2051@SSOP20 [(SA626A)]	
MDT2060	
MDT2060@SOP18 [(SA404A)]	MDT2060@SSOP20
[(SA626A)]	

MICROCHIP

E (E) PROM / FRAM / NVRAM

24AA00	24AA00@SOIC8
[(SA602A)]	
24AA00@SOT-23 [(SA717)]	24AA00@TSSOP8
[(SA026)]	
24AA01	24AA01@SOIC8

[(SA602A)]	
24AA01@TSSOP8 [(SA026)]	
24AA014	
24AA014@SOIC8 [(SA602A)]	24AA014@TSSOP8
[(SA026)]	
24AA02	24AA02@DFN8
[(SA694)]	
24AA02@MSOP8 [(SA666)]	24AA02@SOIC8
[(SA602A)]	
24AA02@SOT-23-5 [(SA717)]	24AA02@TSSOP8
[(SA026)]	
24AA024	24AA024@DFN8
[(SA694)]	
24AA024@MSOP8 [(SA666)]	24AA024@SOIC8
[(SA602A)]	
24AA024@TSSOP8 [(SA026)]	
24AA025	
24AA025@DFN8 [(SA694)]	24AA025@MSOP8
[(SA666)]	
24AA025@SOIC8 [(SA602A)]	24AA025@TSSOP8
[(SA026)]	
24AA04	24AA04@SOIC8
[(SA602A)]	
24AA04@TSSOP8 [(SA026)]	
24AA08	
24AA08@SOIC8 [(SA602A)]	24AA08@TSSOP8
[(SA026)]	
24AA1025	24AA1025@SOIC8
[(SA602A)]	
24AA1025@TSSOP8 [(SA026)]	
24AA128	
24AA128@MSOP8 [(SA666)]	24AA128@SOIC8
[(SA602A)]	
24AA128@TSSOP14 [(SA026)]	24AA128@TSSOP8
[(SA026)]	
24AA16	24AA16@SOIC8
[(SA602A)]	
24AA16@TSSOP8 [(SA026)]	
24AA164	
24AA164@SOIC8 [(SA602A)]	24AA164@TSSOP8
[(SA026)]	
24AA174	24AA174@SOIC8
[(SA602A)]	

24AA174@TSSOP8 [(SA026)]	
24AA256	
24AA256@MSOP8 [(SA666)]	24AA256@SOIC8
[(SA605A)]	
24AA256@TSSOP14 [(SA026)]	24AA256@TSSOP8
[(SA026)]	
24AA32	
[(SA026)]	24AA32(Rotated)@TSSOP8
24AA32@MSOP8 [(SA666)]	24AA32@SOIC8
[(SA602A)]	
24AA32@TSSOP8 [(SA026)]	
24AA32A	
24AA32A(Rotated)@TSSOP8 [(SA026)]	
24AA32A@MSOP8 [(SA666)]	24AA32A@SOIC8
[(SA602A)]	
24AA32A@TSSOP8 [(SA026)]	
24AA512	
24AA512@DFN8 [(SA683)]	24AA512@SOIC8
[(SA605A)]	
24AA512@TSSOP14 [(SA602)]	
24AA515	
24AA515@SOIC8 [(SA605A)]	
24AA52	
24AA52@DFN8 [(SA694)]	24AA52@MSOP8
[(SA666)]	
24AA52@SOIC8 [(SA602A)]	24AA52@TSSOP8
[(SA026)]	
24AA64	24AA64(Rotated)@TSSOP8
[(SA026)]	
24AA64@MSOP8 [(SA666)]	24AA64@SOIC8
[(SA602A)]	
24AA64@TSSOP8 [(SA026)]	
24AA65	
24AA65@SOIC8 [(SA602A)]	24AA65@TSSOP8
[(SA026)]	
24C00	24C00@SOIC8
[(SA602A)]	
24C00@SOT-23 [(SA717)]	24C00@TSSOP8
[(SA026)]	
24C01	
24C01A	
24C01A@SOIC8 [(SA602A)]	
24C01C	

24C01C@SOIC8 [(SA602A)]	24C01C@TSSOP8
[(SA026)]	
24C02	
24C02A	
24C02A@SOIC8 [(SA602A)]	
24C02C	
24C02C@SOIC8 [(SA602A)]	24C02C@TSSOP8
[(SA026)]	
24C04	
24C04A	
24C04A@SOIC8 [(SA602A)]	24C04A@TSSOP8
[(SA026)]	
24C08	24C08@SOIC8
[(SA602A)]	
24C08B	24C08B@SOIC8
[(SA602A)]	
24C16	24C16@SOIC8
[(SA602A)]	
24C16B	24C16B@SOIC8
[(SA602A)]	
24C32	24C32@SOIC8
[(SA602A)]	
24C64	24C64@SOIC8
[(SA602A)]	
24C64@TSSOP8 [(SA026)]	
24C65	
24C65@SOIC8 [(SA602A)]	
24FC1025	
24FC1025@SOIC8 [(SA602A)]	24FC1025@TSSOP8
[(SA026)]	
24FC128	24FC128@MSOP8
[(SA666)]	
24FC128@SOIC8 [(SA602A)]	24FC128@TSSOP14
[(SA026)]	
24FC128@TSSOP8 [(SA026)]	
24FC256	
24FC256@MSOP8 [(SA666)]	24FC256@SOIC8
[(SA605A)]	
24FC256@TSSOP14 [(SA026)]	24FC256@TSSOP8
[(SA026)]	
24FC32	24FC32@SOIC8
[(SA602A)]	
24FC512	24FC512@DFN8

[(SA683)]	
24FC512@SOIC8 [(SA605A)]	24FC512@TSSOP14
[(SA602)]	
24FC515	24FC515@SOIC8
[(SA605A)]	
24FC65	24FC65@SOIC8
[(SA605A)]	
24LC00	24LC00@SOIC8
[(SA602A)]	
24LC00@SOT-23 [(SA717)]	24LC00@TSSOP8
[(SA026)]	
24LC01	
24LC014	
24LC014@SOIC8 [(SA602A)]	24LC014@TSSOP8
[(SA026)]	
24LC01B	24LC01B@SOIC8
[(SA602A)]	
24LC01B@TSSOP8 [(SA026)]	
24LC02	
24LC024	24LC024@SOIC8
[(SA602A)]	
24LC024@TSSOP8 [(SA026)]	
24LC025	
24LC025@SOIC8 [(SA602A)]	24LC025@TSSOP8
[(SA026)]	
24LC02B	24LC02B@DFN8
[(SA694)]	
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8
[(SA602A)]	
24LC02B@SOT-23-5 [(SA717)]	24LC02B@TSSOP8
[(SA026)]	
24LC04	
24LC04B	
24LC04B@SOIC8 [(SA602A)]	24LC04B@TSSOP8
[(SA026)]	
24LC08	
24LC08B	
24LC08B@SOIC8 [(SA602A)]	24LC08B@TSSOP8
[(SA026)]	
24LC1025	24LC1025@SOIC8
[(SA602A)]	
24LC1025@TSSOP8 [(SA026)]	
24LC128	

24LC128@MSOP8 [(SA666)]	24LC128@SOIC8
[(SA605A)]	
24LC128@TSSOP14 [(SA026)]	24LC128@TSSOP8
[(SA026)]	
24LC16	24LC16@MSOP8
[(SA605A)]	
24LC16@SOIC8 [(SA602A)]	
24LC164	
24LC164@SOIC8 [(SA602A)]	
24LC16B	
24LC16B@SOIC8 [(SA602A)]	24LC16B@TSSOP8
[(SA026)]	
24LC174	24LC174@SOIC8
[(SA602A)]	
24LC21	24LC21@SOIC8
[(SA602A)]	
24LC21A	24LC21A@SOIC8
[(SA602A)]	
24LC22A	24LC22A@SOIC8
[(SA602A)]	
24LC256	24LC256@MSOP8
[(SA666)]	
24LC256@SOIC8 [(SA605A)]	24LC256@TSSOP14
[(SA026)]	
24LC256@TSSOP8 [(SA026)]	
24LC32	
24LC32@SOIC8 [(SA602A)]	
24LC32A	
24LC32A@SOIC8 [(SA602A)]	24LC32A@TSSOP8
[(SA026)]	
24LC512	24LC512@DFN8
[(SA683)]	
24LC512@SOIC8 [(SA605A)]	24LC512@TSSOP14
[(SA602)]	
24LC515	24LC515@SOIC8
[(SA605A)]	
24LC64	24LC64(Rotated)@TSSOP8
[(SA026)]	
24LC64@MSOP8 [(SA605A)]	24LC64@SOIC8
[(SA602A)]	
24LC64@TSSOP8 [(SA026)]	
24LC65	
24LC65@SOIC8 [(SA602A)]	

24LCS21
24LCS21@SOIC8 [(SA602A)]
24LCS21A
24LCS21A@SOIC8 [(SA602A)]
24LCS22
24LCS22@SOIC8 [(SA602A)]
24LCS22A
24LCS22A@SOIC8 [(SA602A)]
24LCS52
24LCS52@DFN8 [(SA694)]
[(SA666)]
24LCS52@SOIC8 [(SA602A)]
[(SA026)]
25AA010A
[(SA683)]
25AA010A@MSOP8 [(SA605A)]
[(SA602A)]
25AA010A@SOT-23 [(SA698)]
[(SA026)]
25AA010A[X-Rotated]@TSSOP8 [(SA026)]
25AA020A
[(SA683)]
25AA020A@MSOP8 [(SA605A)]
[(SA602A)]
25AA020A@SOT-23 [(SA698)]
[(SA026)]
25AA020A[X-Rotated]@TSSOP8 [(SA026)]
25AA040
[(SA602A)]
25AA040@TSSOP8 [(SA026)]
25AA040A
25AA040A@DFN8 [(SA683)]
[(SA605A)]
25AA040A@SOIC8 [(SA602A)]
[(SA698)]
25AA040A@TSSOP8 [(SA026)]
25AA040A[X-Rotated]@TSSOP8 [(SA026)]
25AA080
[(SA602A)]
25AA080A
[(SA605A)]
25AA080A@SOIC8 [(SA602A)]
[(SA026)]
24LCS52@MSOP8
24LCS52@TSSOP8
25AA010A@DFN8
25AA010A@SOIC8
25AA010A@TSSOP8
25AA020A@DFN8
25AA020A@SOIC8
25AA020A@TSSOP8
25AA040@SOIC8
25AA040A@MSOP8
25AA040A@SOT-23
25AA080@SOIC8
25AA080A@MSOP8
25AA080A@TSSOP8

25AA080B [(SA605A)]	25AA080B@MSOP8
25AA080B@SOIC8 [(SA602A)] [(SA026)]	25AA080B@TSSOP8
25AA1024 [(SA683)]	25AA1024@DFN8
25AA1024@SOIC8 [(SA602A)] [(SA605)]	25AA1024@SOIJ8
25AA160 [(SA602A)]	25AA160@SOIC8
25AA160A [(SA605A)]	25AA160A@MSOP8
25AA160A@SOIC8 [(SA602A)] [(SA026)]	25AA160A@TSSOP8
25AA160B [(SA605A)]	25AA160B@MSOP8
25AA160B@SOIC8 [(SA602A)] [(SA026)]	25AA160B@TSSOP8
25AA256 [(SA683)]	25AA256@DFN8
25AA256@SOIC8(4.0) [(SA602A)] [(SA605A)]	25AA256@SOIC8(5.4)
25AA256@TSSOP8 [(SA026)]	
25AA256[X-Rotated]@TSSOP8 [(SA026)]	
25AA320 [(SA602A)]	25AA320@SOIC8
25AA320@TSSOP14 [(SA026)] [(SA026)]	25AA320@TSSOP8
25AA512 [(SA683)]	25AA512@DFN8
25AA512@SOIC8 [(SA602A)] [(SA605)]	25AA512@SOIJ8
25AA640 [(SA602A)]	25AA640@SOIC8
25AA640@TSSOP8 [(SA026)]	
25C040 [(SA026)]	
25C040@SOIC8 [(SA602A)] [(SA026)]	25C040@TSSOP8
25C080 [(SA602A)]	25C080@SOIC8
25C160 [(SA602A)]	25C160@SOIC8
25C320	25C320@SOIC8

[(SA602A)]	
25C320@TSSOP14 [(SA026)]	25C320@TSSOP8
[(SA026)]	
25C640	25C640@SOIC8
[(SA602A)]	
25C640@TSSOP8 [(SA026)]	
25LC010A	
25LC010A@DFN8 [(SA683)]	25LC010A@MSOP8
[(SA605A)]	
25LC010A@SOIC8 [(SA602A)]	25LC010A@SOT-23
[(SA698)]	
25LC010A@TSSOP8 [(SA026)]	
25LC010A[X-Rotated]@TSSOP8 [(SA026)]	
25LC020A	25LC020A@DFN8
[(SA683)]	
25LC020A@MSOP8 [(SA605A)]	25LC020A@SOIC8
[(SA602A)]	
25LC020A@SOT-23 [(SA698)]	25LC020A@TSSOP8
[(SA026)]	
25LC020A[X-Rotated]@TSSOP8 [(SA026)]	
25LC040	25LC040@SOIC8
[(SA602A)]	
25LC040@TSSOP8 [(SA026)]	
25LC040A	
25LC040A@DFN8 [(SA683)]	25LC040A@MSOP8
[(SA605A)]	
25LC040A@SOIC8 [(SA602A)]	25LC040A@SOT-23
[(SA698)]	
25LC040A@TSSOP8 [(SA026)]	
25LC040A[X-Rotated]@TSSOP8 [(SA026)]	
25LC080	25LC080@SOIC8
[(SA602A)]	
25LC080A	25LC080A@MSOP8
[(SA605A)]	
25LC080A@SOIC8 [(SA602A)]	25LC080A@TSSOP8
[(SA026)]	
25LC080B	25LC080B@MSOP8
[(SA605A)]	
25LC080B@SOIC8 [(SA602A)]	25LC080B@TSSOP8
[(SA026)]	
25LC1024	25LC1024@DFN8
[(SA683)]	
25LC1024@SOIC8 [(SA602A)]	25LC1024@SOIJ8

[(SA605)]	
25LC160	25LC160@SOIC8
[(SA602A)]	
25LC160A	25LC160A@MSOP8
[(SA605A)]	
25LC160A@SOIC8 [(SA602A)]	25LC160A@TSSOP8
[(SA026)]	
25LC160B	25LC160B@MSOP8
[(SA605A)]	
25LC160B@SOIC8 [(SA602A)]	25LC160B@TSSOP8
[(SA026)]	
25LC256	25LC256@DFN8
[(SA683)]	
25LC256@SOIC8(4.0) [(SA602A)]	25LC256@SOIC8(5.4)
[(SA605A)]	
25LC256@TSSOP8 [(SA026)]	
25LC256[X-Rotated]@TSSOP8 [(SA026)]	
25LC320	25LC320(SN)@SOIC8
[(SA602A)]	
25LC320@TSSOP14 [(SA026)]	25LC320@TSSOP8
[(SA026)]	
25LC512	25LC512@DFN8
[(SA683)]	
25LC512@SOIC8 [(SA602A)]	25LC512@SOIJ8
[(SA605)]	
25LC640	25LC640@SOIC8
[(SA602A)]	
25LC640@TSSOP8 [(SA026)]	
27256	
27256@PLCC32 [(SA015A1T)]	
27C128	
27C128@PLCC32 [(SA015A1T)]	
27C128A	
27C128A@PLCC32 [(SA015A1T)]	
27C256	
27C256@PLCC32 [(SA015A1T)]	
27C32A	
27C512	27C512@PLCC32
[(SA015A1T)]	
27C512A	27C512A@PLCC32
[(SA015A1T)]	
27C513	
27C64	

27C64@PLCC32 [(SA015A1T)]	27C64@SOIC28
[(SA404)]	
27HC1616	27HC1616@PLCC44
[(SA244)]	
27HC1616L	27HC1616L@PLCC44
[(SA244)]	
27HC191	27HC191@PLCC28
[(SA008A)]	
27HC191@SOIC24 [(SA404)]	
27HC256	
27HC256@PLCC32 [(SA015A1T)]	
27HC256L	
27HC256L@PLCC32 [(SA015A1T)]	
27HC291	
27HC291@PLCC28 [(SA008A)]	27HC291@SOIC24
[(SA404)]	
27HC416	
27HC64	
27HC64@PLCC32 [(SA015A1T)]	27HC64@SOIC28
[(SA404)]	
27HC641	27HC641@PLCC28
[(SA008A)]	
27HC641@SOIC24 [(SA404)]	
27HC641L	
27HC641L@PLCC28 [(SA008A)]	27HC641L@SOIC24
[(SA404)]	
27HC64L	27HC64L@PLCC32
[(SA015A1T)]	
27HC64L@SOIC28 [(SA404)]	
27LV256	
27LV256@PLCC32 [(SA015A1T)]	
27LV64	
2817	
2864	
2864@PLCC32 [(SA015A1T)]	
28C04	
28C04@PLCC32 [(SA015A1T)]	28C04@SOIC24
[(SA404)]	
28C04A	28C04A@PLCC32
[(SA015A1T)]	
28C04A@SOIC24 [(SA404)]	
28C04AF	
28C04AF@PLCC32 [(SA015A1T)]	28C04AF@SOIC24

[(SA404)]	
28C04F	28C04F@PLCC32
[(SA015A1T)]	
28C04F@SOIC24 [(SA404)]	
28C16	
28C16@PLCC32 [(SA015A1T)]	28C16@SOIC24
[(SA404)]	
28C16A	28C16A@PLCC32
[(SA015A1T)]	
28C16A@SOIC24 [(SA404)]	
28C16AF	
28C16AF@PLCC32 [(SA015A1T)]	28C16AF@SOIC24
[(SA404)]	
28C16F	28C16F@PLCC32
[(SA015A1T)]	
28C16F@SOIC24 [(SA404)]	
28C17	
28C17@PLCC32 [(SA015A1T)]	28C17@SOIC28
[(SA404)]	
28C17A	28C17A@PLCC32
[(SA015A1T)]	
28C17A@SOIC28 [(SA404)]	
28C17AF	
28C17AF@PLCC32 [(SA015A1T)]	28C17AF@SOIC28
[(SA404)]	
28C17F	28C17F@PLCC32
[(SA015A1T)]	
28C17F@SOIC28 [(SA404)]	
28C256	
28C256@PLCC32 [(SA015A1T)]	
28C256F	
28C256F@PLCC32 [(SA015A1T)]	
28C64A	
28C64A@PLCC32 [(SA015A1T)]	28C64A@SOIC28
[(SA404)]	
28C64A@TSOP32 [(SA410T)]	
28C64AF	
28C64AF@PLCC32 [(SA015A1T)]	28C64AF@SOIC28
[(SA404)]	
28LV64A	28LV64A@PLCC32
[(SA015A1T)]	
28LV64A@SOIC28 [(SA404)]	
28PC64	

28PC64@PLCC32 [(SA015A1T)]	
59C11	
59C11@SOIC8 [(SA602A)]	
85C72	
85C72@SOIC8 [(SA602A)]	
85C82	
85C82@SOIC8 [(SA602A)]	
85C92	
85C92@SOIC8 [(SA602A)]	93AA46
(08bit)	
93AA46(08bit)@SOIC8 [(SA602A)]	93AA46
(16bit)	
93AA46(16bit)@SOIC8 [(SA602A)]	93AA46A
(08bit)	
93AA46A(08bit)@DFN8 [(BBBB)]	93AA46A(08bit)@MSOP8
[(SA666)]	
93AA46A(08bit)@SOIC8 [(SA602A)]	93AA46A(08bit)@SOT-23
[(SA717)]	
93AA46A(08bit)@TSSOP8 [(SA026)]	93AA46B
(16bit)	
93AA46B(16bit)@DFN8 [(BBBB)]	93AA46B(16bit)@MSOP8
[(SA666)]	
93AA46B(16bit)@SOIC8 [(SA602A)]	93AA46B(16bit)@SOT-23
[(SA717)]	
93AA46B(16bit)@TSSOP8 [(SA026)]	93AA46C
(08bit)	
93AA46C(08bit)@DFN8 [(BBBB)]	93AA46C(08bit)@MSOP8
[(SA666)]	
93AA46C(08bit)@SOIC8 [(SA602A)]	93AA46C(08bit)@TSSOP8
[(SA026)]	
93AA46C(16bit)	93AA46C(16bit)@DFN8
[(BBBB)]	
93AA46C(16bit)@MSOP8 [(SA666)]	93AA46C(16bit)@SOIC8
[(SA602A)]	
93AA46C(16bit)@TSSOP8 [(SA026)]	93AA56
(08bit)	
93AA56(08bit)@SOIC8 [(SA602A)]	93AA56
(16bit)	
93AA56(16bit)@SOIC8 [(SA602A)]	93AA56A
(08bit)	
93AA56A(08bit)@DFN8 [(BBBB)]	93AA56A(08bit)@MSOP8
[(SA666)]	
93AA56A(08bit)@SOIC8 [(SA602A)]	93AA56A(08bit)@SOT-23

[(SA717)]	
93AA56A(08bit)@TSSOP8 [(SA026)]	93AA56B
(16bit)	
93AA56B(16bit)@DFN8 [(BBBB)]	93AA56B(16bit)@MSOP8
[(SA666)]	
93AA56B(16bit)@SOIC8 [(SA602A)]	93AA56B(16bit)@SOT-23
[(SA717)]	
93AA56B(16bit)@TSSOP8 [(SA026)]	93AA56C
(08bit)	
93AA56C(08bit)@DFN8 [(BBBB)]	93AA56C(08bit)@MSOP8
[(SA666)]	
93AA56C(08bit)@SOIC8 [(SA602A)]	93AA56C(08bit)@TSSOP8
[(SA026)]	
93AA56C(16bit)	93AA56C(16bit)@DFN8
[(BBBB)]	
93AA56C(16bit)@MSOP8 [(SA666)]	93AA56C(16bit)@SOIC8
[(SA602A)]	
93AA56C(16bit)@TSSOP8 [(SA026)]	93AA66
(08bit)	
93AA66(08bit)@SOIC8 [(SA602A)]	93AA66
(16bit)	
93AA66(16bit)@SOIC8 [(SA602A)]	93AA66A
(08bit)	
93AA66A(08bit)@DFN8 [(BBBB)]	93AA66A(08bit)@MSOP8
[(SA666)]	
93AA66A(08bit)@SOIC8 [(SA602A)]	93AA66A(08bit)@SOT-23
[(SA717)]	
93AA66A(08bit)@TSSOP8 [(SA026)]	93AA66B
(16bit)	
93AA66B(16bit)@DFN8 [(BBBB)]	93AA66B(16bit)@MSOP8
[(SA666)]	
93AA66B(16bit)@SOIC8 [(SA602A)]	93AA66B(16bit)@SOT-23
[(SA717)]	
93AA66B(16bit)@TSSOP8 [(SA026)]	93AA66C
(08bit)	
93AA66C(08bit)@DFN8 [(BBBB)]	93AA66C(08bit)@MSOP8
[(SA666)]	
93AA66C(08bit)@SOIC8 [(SA602A)]	93AA66C(08bit)@TSSOP8
[(SA026)]	
93AA66C(16bit)	93AA66C(16bit)@DFN8
[(BBBB)]	
93AA66C(16bit)@MSOP8 [(SA666)]	93AA66C(16bit)@SOIC8
[(SA602A)]	

93AA66C(16bit)@TSSOP8 [(SA026)] (08bit)	93AA76
93AA76(08bit)@SOIC8 [(SA602A)] (16bit)	93AA76
93AA76(16bit)@SOIC8 [(SA602A)] (08bit)	93AA76A
93AA76A(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA76A(08bit)@MSOP8
93AA76A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA76A(08bit)@SOT-23
93AA76A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA76B
93AA76B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA76B(16bit)@MSOP8
93AA76B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA76B(16bit)@SOT-23
93AA76B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA76C
93AA76C(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA76C(08bit)@MSOP8
93AA76C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA76C(08bit)@TSSOP8
93AA76C(16bit) [(BBBB)]	93AA76C(16bit)@DFN8
93AA76C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93AA76C(16bit)@SOIC8
93AA76C(16bit)@TSSOP8 [(SA026)] (08bit)	93AA86
93AA86(08bit)@SOIC8 [(SA602A)] (16bit)	93AA86
93AA86(16bit)@SOIC8 [(SA602A)] (08bit)	93AA86A
93AA86A(08bit)@DFN8 [(BBBB)] [(SSA666)]	93AA86A(08bit)@MSOP8
93AA86A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA86A(08bit)@SOT-23
93AA86A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA86B
93AA86B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA86B(16bit)@MSOP8
93AA86B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA86B(16bit)@SOT-23
93AA86B(16bit)@TSSOP8 [(SA026)]	93AA86C

(08bit)	
93AA86C(08bit)@DFN8 [(BBBB)]	93AA86C(08bit)@MSOP8
[(SA666)]	
93AA86C(08bit)@SOIC8 [(SA602A)]	93AA86C(08bit)@TSSOP8
[(SA026)]	
93AA86C(16bit)	93AA86C(16bit)@DFN8
[(BBBB)]	
93AA86C(16bit)@MSOP8 [(SA666)]	93AA86C(16bit)@SOIC8
[(SA602A)]	
93AA86C(16bit)@TSSOP8 [(SA026)]	93C06
(08bit)	
93C06(08bit)@SOIC8 [(SA602A)]	93C06
(16bit)	
93C06(16bit)@SOIC8 [(SA602A)]	93C46
(08bit)	
93C46(08bit)@SOIC8 [(SA602A)]	93C46
(16bit)	
93C46(16bit)@SOIC8 [(SA602A)]	93C46A
(08bit)	
93C46A(08bit)@DFN8 [(BBBB)]	93C46A(08bit)@MSOP8
[(SA666)]	
93C46A(08bit)@SOIC8 [(SA602A)]	93C46A(08bit)@SOT-23
[(SA717)]	
93C46A(08bit)@TSSOP8 [(SA026)]	93C46B
(16bit)	
93C46B(16bit)@DFN8 [(BBBB)]	93C46B(16bit)@MSOP8
[(SA666)]	
93C46B(16bit)@SOIC8 [(SA602A)]	93C46B(16bit)@SOT-23
[(SA717)]	
93C46B(16bit)@TSSOP8 [(SA026)]	93C46C
(08bit)	
93C46C(08bit)@DFN8 [(BBBB)]	93C46C(08bit)@MSOP8
[(SA666)]	
93C46C(08bit)@SOIC8 [(SA602A)]	93C46C(08bit)@TSSOP8
[(SA026)]	
93C46C(16bit)	93C46C(16bit)@DFN8
[(BBBB)]	
93C46C(16bit)@MSOP8 [(SA666)]	93C46C(16bit)@SOIC8
[(SA602A)]	
93C46C(16bit)@TSSOP8 [(SA026)]	93C56
(08bit)	
93C56(08bit)@SOIC8 [(SA602A)]	93C56
(16bit)	

93C56(16bit)@SOIC8 [(SA602A)] (08bit)	93C56A
93C56A(08bit)@DFN8 [(BBBB)] [(SA666)]	93C56A(08bit)@MSOP8
93C56A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93C56A(08bit)@SOT-23
93C56A(08bit)@TSSOP8 [(SA026)] (16bit)	93C56B
93C56B(16bit)@DFN8 [(BBBB)] [(SA666)]	93C56B(16bit)@MSOP8
93C56B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C56B(16bit)@SOT-23
93C56B(16bit)@TSSOP8 [(SA026)] (08bit)	93C56C
93C56C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C56C(08bit)@MSOP8
93C56C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93C56C(08bit)@TSSOP8
93C56C(16bit) [(BBBB)]	93C56C(16bit)@DFN8
93C56C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93C56C(16bit)@SOIC8
93C56C(16bit)@TSSOP8 [(SA026)] (08bit)	93C66
93C66(08bit)@SOIC8 [(SA602A)] (16bit)	93C66
93C66(16bit)@SOIC8 [(SA602A)] (08bit)	93C66A
93C66A(08bit)@DFN8 [(BBBB)] [(SA666)]	93C66A(08bit)@MSOP8
93C66A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93C66A(08bit)@SOT-23
93C66A(08bit)@TSSOP8 [(SA026)] (16bit)	93C66B
93C66B(16bit)@DFN8 [(BBBB)] [(SA666)]	93C66B(16bit)@MSOP8
93C66B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C66B(16bit)@SOT-23
93C66B(16bit)@TSSOP8 [(SA026)] (08bit)	93C66C
93C66C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C66C(08bit)@MSOP8
93C66C(08bit)@SOIC8 [(SA602A)]	93C66C(08bit)@TSSOP8

[(SA026)]	
93C66C(16bit)	93C66C(16bit)@DFN8
[(BBBB)]	
93C66C(16bit)@MSOP8 [(SA666)]	93C66C(16bit)@SOIC8
[(SA602A)]	
93C66C(16bit)@TSSOP8 [(SA026)]	93C76
(08bit)	
93C76(08bit)@SOIC8 [(SA602A)]	93C76
(16bit)	
93C76(16bit)@SOIC8 [(SA602A)]	93C76A
(08bit)	
93C76A(08bit)@DFN8 [(BBBB)]	93C76A(08bit)@MSOP8
[(SA666)]	
93C76A(08bit)@SOIC8 [(SA602A)]	93C76A(08bit)@SOT-23
[(SA717)]	
93C76A(08bit)@TSSOP8 [(SA026)]	93C76B
(16bit)	
93C76B(16bit)@DFN8 [(BBBB)]	93C76B(16bit)@MSOP8
[(SA666)]	
93C76B(16bit)@SOIC8 [(SA602A)]	93C76B(16bit)@SOT-23
[(SA717)]	
93C76B(16bit)@TSSOP8 [(SA026)]	93C76C
(08bit)	
93C76C(08bit)@DFN8 [(BBBB)]	93C76C(08bit)@MSOP8
[(SA666)]	
93C76C(08bit)@SOIC8 [(SA602A)]	93C76C(08bit)@TSSOP8
[(SA026)]	
93C76C(16bit)	93C76C(16bit)@DFN8
[(BBBB)]	
93C76C(16bit)@MSOP8 [(SA666)]	93C76C(16bit)@SOIC8
[(SA602A)]	
93C76C(16bit)@TSSOP8 [(SA026)]	93C86
(08bit)	
93C86(08bit)@SOIC8 [(SA602A)]	93C86
(16bit)	
93C86(16bit)@SOIC8 [(SA602A)]	93C86A
(08bit)	
93C86A(08bit)@DFN8 [(BBBB)]	93C86A(08bit)@MSOP8
[(SSA666)]	
93C86A(08bit)@SOIC8 [(SA602A)]	93C86A(08bit)@SOT-23
[(SA717)]	
93C86A(08bit)@TSSOP8 [(SA026)]	93C86B
(16bit)	

93C86B(16bit)@DFN8 [(BBBB)]	93C86B(16bit)@MSOP8
[(SA666)]	
93C86B(16bit)@SOIC8 [(SA602A)]	93C86B(16bit)@SOT-23
[(SA717)]	
93C86B(16bit)@TSSOP8 [(SA026)]	93C86C
(08bit)	
93C86C(08bit)@DFN8 [(BBBB)]	93C86C(08bit)@MSOP8
[(SA666)]	
93C86C(08bit)@SOIC8 [(SA602A)]	93C86C(08bit)@TSSOP8
[(SA026)]	
93C86C(16bit)	93C86C(16bit)@DFN8
[(BBBB)]	
93C86C(16bit)@MSOP8 [(SA666)]	93C86C(16bit)@SOIC8
[(SA602A)]	
93C86C(16bit)@TSSOP8 [(SA026)]	93LC46
(08bit)	
93LC46(08bit)@SOIC8 [(SA602A)]	93LC46
(16bit)	
93LC46(16bit)@SOIC8 [(SA602A)]	93LC46A
(08bit)	
93LC46A(08bit)@DFN8 [(BBBB)]	93LC46A(08bit)@MSOP8
[(SA666)]	
93LC46A(08bit)@SOIC8 [(SA602A)]	93LC46A(08bit)@SOT-23
[(SA717)]	
93LC46A(08bit)@TSSOP8 [(SA026)]	93LC46B
(16bit)	
93LC46B(16bit)@DFN8 [(BBBB)]	93LC46B(16bit)@MSOP8
[(SA666)]	
93LC46B(16bit)@SOIC8 [(SA602A)]	93LC46B(16bit)@SOT-23
[(SA717)]	
93LC46B(16bit)@TSSOP8 [(SA026)]	
93LC46BX	
93LC46BX@SOIC8 [(SA602A)]	93LC46C
(08bit)	
93LC46C(08bit)@DFN8 [(BBBB)]	93LC46C(08bit)@MSOP8
[(SA666)]	
93LC46C(08bit)@SOIC8 [(SA602A)]	93LC46C(08bit)@TSSOP8
[(SA026)]	
93LC46C(16bit)	93LC46C(16bit)@DFN8
[(BBBB)]	
93LC46C(16bit)@MSOP8 [(SA666)]	93LC46C(16bit)@SOIC8
[(SA602A)]	
93LC46C(16bit)@TSSOP8 [(SA026)]	93LC56

(08bit)	
93LC56(08bit)@SOIC8 [(SA602A)]	93LC56
(16bit)	
93LC56(16bit)@SOIC8 [(SA602A)]	93LC56A
(08bit)	
93LC56A(08bit)@DFN8 [(BBBB)]	93LC56A(08bit)@MSOP8
[(SA666)]	
93LC56A(08bit)@SOIC8 [(SA602A)]	93LC56A(08bit)@SOT-23
[(SA717)]	
93LC56A(08bit)@TSSOP8 [(SA026)]	93LC56B
(16bit)	
93LC56B(16bit)@DFN8 [(BBBB)]	93LC56B(16bit)@MSOP8
[(SA666)]	
93LC56B(16bit)@SOIC8 [(SA602A)]	93LC56B(16bit)@SOT-23
[(SA717)]	
93LC56B(16bit)@TSSOP8 [(SA026)]	
93LC56BX	
93LC56BX@SOIC8 [(SA602A)]	93LC56C
(08bit)	
93LC56C(08bit)@DFN8 [(BBBB)]	93LC56C(08bit)@MSOP8
[(SA666)]	
93LC56C(08bit)@SOIC8 [(SA602A)]	93LC56C(08bit)@TSSOP8
[(SA026)]	
93LC56C(16bit)	93LC56C(16bit)@DFN8
[(BBBB)]	
93LC56C(16bit)@MSOP8 [(SA666)]	93LC56C(16bit)@SOIC8
[(SA602A)]	
93LC56C(16bit)@TSSOP8 [(SA026)]	93LC66
(08bit)	
93LC66(08bit)@SOIC8 [(SA602A)]	93LC66
(16bit)	
93LC66(16bit)@SOIC8 [(SA602A)]	93LC66A
(08bit)	
93LC66A(08bit)@DFN8 [(BBBB)]	93LC66A(08bit)@MSOP8
[(SA666)]	
93LC66A(08bit)@SOIC8 [(SA602A)]	93LC66A(08bit)@SOT-23
[(SA717)]	
93LC66A(08bit)@TSSOP8 [(SA026)]	93LC66B
(16bit)	
93LC66B(16bit)@DFN8 [(BBBB)]	93LC66B(16bit)@MSOP8
[(SA666)]	
93LC66B(16bit)@SOIC8 [(SA602A)]	93LC66B(16bit)@SOT-23
[(SA717)]	

93LC66B(16bit)@TSSOP8 [(SA026)]	
93LC66BX	
93LC66BX@SOIC8 [(SA602A)]	93LC66C
(08bit)	
93LC66C(08bit)@DFN8 [(BBBB)]	93LC66C(08bit)@MSOP8
[(SA666)]	
93LC66C(08bit)@SOIC8 [(SA602A)]	93LC66C(08bit)@TSSOP8
[(SA026)]	
93LC66C(16bit)	93LC66C(16bit)@DFN8
[(BBBB)]	
93LC66C(16bit)@MSOP8 [(SA666)]	93LC66C(16bit)@SOIC8
[(SA602A)]	
93LC66C(16bit)@TSSOP8 [(SA026)]	93LC76
(08bit)	
93LC76(08bit)@SOIC8 [(SA602A)]	93LC76
(16bit)	
93LC76(16bit)@SOIC8 [(SA602A)]	93LC76A
(08bit)	
93LC76A(08bit)@DFN8 [(BBBB)]	93LC76A(08bit)@MSOP8
[(SA666)]	
93LC76A(08bit)@SOIC8 [(SA602A)]	93LC76A(08bit)@SOT-23
[(SA717)]	
93LC76A(08bit)@TSSOP8 [(SA026)]	93LC76B
(16bit)	
93LC76B(16bit)@DFN8 [(BBBB)]	93LC76B(16bit)@MSOP8
[(SA666)]	
93LC76B(16bit)@SOIC8 [(SA602A)]	93LC76B(16bit)@SOT-23
[(SA717)]	
93LC76B(16bit)@TSSOP8 [(SA026)]	93LC76C
(08bit)	
93LC76C(08bit)@DFN8 [(BBBB)]	93LC76C(08bit)@MSOP8
[(SA666)]	
93LC76C(08bit)@SOIC8 [(SA602A)]	93LC76C(08bit)@TSSOP8
[(SA026)]	
93LC76C(16bit)	93LC76C(16bit)@DFN8
[(BBBB)]	
93LC76C(16bit)@MSOP8 [(SA666)]	93LC76C(16bit)@SOIC8
[(SA602A)]	
93LC76C(16bit)@TSSOP8 [(SA026)]	93LC86
(08bit)	
93LC86(08bit)@SOIC8 [(SA602A)]	93LC86
(16bit)	
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86A

(08bit)	
93LC86A(08bit)@DFN8 [(BBB)]	93LC86A(08bit)@MSOP8
[(SSA666)]	
93LC86A(08bit)@SOIC8 [(SA602A)]	93LC86A(08bit)@SOT-23
[(SA717)]	
93LC86A(08bit)@TSSOP8 [(SA026)]	93LC86B
(16bit)	
93LC86B(16bit)@DFN8 [(BBB)]	93LC86B(16bit)@MSOP8
[(SA666)]	
93LC86B(16bit)@SOIC8 [(SA602A)]	93LC86B(16bit)@SOT-23
[(SA717)]	
93LC86B(16bit)@TSSOP8 [(SA026)]	93LC86C
(08bit)	
93LC86C(08bit)@DFN8 [(BBB)]	93LC86C(08bit)@MSOP8
[(SA666)]	
93LC86C(08bit)@SOIC8 [(SA602A)]	93LC86C(08bit)@TSSOP8
[(SA026)]	
93LC86C(16bit)	93LC86C(16bit)@DFN8
[(BBB)]	
93LC86C(16bit)@MSOP8 [(SA666)]	93LC86C(16bit)@SOIC8
[(SA602A)]	
93LC86C(16bit)@TSSOP8 [(SA026)]	
93LCS46	
93LCS46@SOIC14 [(SA026)]	93LCS46@SOIC8
[(SA602A)]	
93LCS56	93LCS56@SOIC14
[(SA026)]	
93LCS56@SOIC8 [(SA602A)]	
93LCS66	
93LCS66@SOIC14 [(SA026)]	93LCS66@SOIC8
[(SA602A)]	
ER5911	ER5911@SOIC8
[(SA602A)]	
HCS101	HCS101SN@SOIC8
[(SA602A)]	
HCS200	HCS200SN@SOIC8
[(SA602A)]	
HCS300	HCS300SN@SOIC8
[(SA602A)]	
HCS301	HCS301SN@SOIC8
[(SA602A)]	
HCS320	HCS320SN@SOIC8
[(SA602A)]	

HCS360 HCS360SN@SOIC8
[(SA602A)]
HCS361 HCS361SN@SOIC8
[(SA602A)]

MICROCONTROLLER

MCP25020
MCP25020(150mil)@SOIC14 [(SA602)]
MCP25020(150mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25020(208mil)@SOIC14 [(SA404)]
MCP25020(208mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25020(ISP) [ISP-HEADER01]
MCP25025
MCP25025(150mil)@SOIC14 [(SA602)]
MCP25025(150mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25025(208mil)@SOIC14 [(SA404)]
MCP25025(208mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25025(ISP) [ISP-HEADER01]
MCP25050
MCP25050(150mil)@SOIC14 [(SA602)]
MCP25050(150mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25050(208mil)@SOIC14 [(SA404)]
MCP25050(208mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25050(ISP) [ISP-HEADER01]
MCP25055
MCP25055(150mil)@SOIC14 [(SA602)]
MCP25055(150mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25055(208mil)@SOIC14 [(SA404)]
MCP25055(208mil)@SOIC14(ISP) [ISP-HEADER01]
MCP25055(ISP) [ISP-HEADER01]
PIC10F200
PIC10F200(ISP) [ISP-HEADER01] PIC10F200@SOT6
[(SA717)]
PIC10F200@SOT6(ISP) [ISP-HEADER01]
PIC10F202 PIC10F202(ISP) [ISP-
HEADER01]
PIC10F202@SOT6 [(SA717)]
PIC10F202@SOT6(ISP) [ISP-HEADER01]
PIC10F204 PIC10F204(ISP) [ISP-
HEADER01]
PIC10F204@SOT6 [(SA717)]

PIC10F204@SOT6(ISP) [ISP-HEADER01]
 PIC10F206 PIC10F206(ISP) [ISP-
 HEADER01]
 PIC10F206@SOT6 [(SA717)]
 PIC10F206@SOT6(ISP) [ISP-HEADER01]
 PIC10F220 PIC10F220(ISP) [ISP-
 HEADER01]
 PIC10F220@SOT6 [(SA717)]
 PIC10F220@SOT6(ISP) [ISP-HEADER01]
 PIC10F222 PIC10F222(ISP) [ISP-
 HEADER01]
 PIC10F222@SOT6 [(SA717)]
 PIC10F222@SOT6(ISP) [ISP-HEADER01]
 PIC12C508 PIC12C508(ISP) [ISP-
 HEADER01]
 PIC12C508@SOIC8 [(SA605A)]
 PIC12C508@SOIC8(ISP) [ISP-HEADER01]
 PIC12C508A PIC12C508A(ISP) [ISP-
 HEADER01]
 PIC12C508A(SM)@SOIC8 [(SA605A)]
 PIC12C508A(SM)@SOIC8(ISP) [ISP-HEADER01]
 PIC12C508A(SN)@SOIC8 [(SA602A)]
 PIC12C508A(SN)@SOIC8(ISP) [ISP-HEADER01]
 PIC12C509 PIC12C509(ISP) [ISP-
 HEADER01]
 PIC12C509(SM)@SOIC8 [(SA605A)]
 PIC12C509(SM)@SOIC8(ISP) [ISP-HEADER01]
 PIC12C509(SN)@SOIC8 [(SA602A)]
 PIC12C509(SN)@SOIC8(ISP) [ISP-HEADER01]
 PIC12C509A PIC12C509A(ISP) [ISP-
 HEADER01]
 PIC12C509A(SM)@SOIC8 [(SA605A)]
 PIC12C509A(SM)@SOIC8(ISP) [ISP-HEADER01]
 PIC12C509A(SN)@SOIC8 [(SA602A)]
 PIC12C509A(SN)@SOIC8(ISP) [ISP-HEADER01]
 PIC12C509A@DFN8 [(SA683)]
 PIC12C509A@DFN8(ISP) [ISP-HEADER01]
 PIC12C671 PIC12C671(ISP) [ISP-
 HEADER01]
 PIC12C671@DFN8 [(SA683)]
 PIC12C671@DFN8(ISP) [ISP-HEADER01]
 PIC12C671@SOIC8 [(SA605A)]
 PIC12C671@SOIC8(ISP) [ISP-HEADER01]

PIC12C672 PIC12C672(ISP) [ISP-
HEADER01]
PIC12C672@DFN8 [(SA683)]
PIC12C672@DFN8(ISP) [ISP-HEADER01]
PIC12C672@SOIC8 [(SA605A)]
PIC12C672@SOIC8(ISP) [ISP-HEADER01]
PIC12CE518 PIC12CE518(ISP) [ISP-
HEADER01]
PIC12CE518@SOIC8 [(SA605A)]
PIC12CE518@SOIC8(ISP) [ISP-HEADER01]
PIC12CE519 PIC12CE519(ISP) [ISP-
HEADER01]
PIC12CE519(SM)@SOIC8 [(SA605A)]
PIC12CE519(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12CE519(SN)@SOIC8 [(SA602A)]
PIC12CE519(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12CE673 PIC12CE673(ISP) [ISP-
HEADER01]
PIC12CE673@SOIC8 [(SA605A)]
PIC12CE673@SOIC8(ISP) [ISP-HEADER01]
PIC12CE674 PIC12CE674(ISP) [ISP-
HEADER01]
PIC12CE674@SOIC8 [(SA605A)]
PIC12CE674@SOIC8(ISP) [ISP-HEADER01]
PIC12F508 PIC12F508(ISP) [ISP-
HEADER01]
PIC12F508@MSOP8 [(SA666)]
PIC12F508@MSOP8(ISP) [ISP-HEADER01]
PIC12F508@SOIC8 [(SA602)]
PIC12F508@SOIC8(ISP) [ISP-HEADER01]
PIC12F509 PIC12F509(ISP) [ISP-
HEADER01]
PIC12F509@MSOP8 [(SA666)]
PIC12F509@MSOP8(ISP) [ISP-HEADER01]
PIC12F509@SOIC8 [(SA602)]
PIC12F509@SOIC8(ISP) [ISP-HEADER01]
PIC12F510 PIC12F510(ISP) [ISP-
HEADER01]
PIC12F510@MSOP8 [(SA666)]
PIC12F510@MSOP8(ISP) [ISP-HEADER01]
PIC12F510@SOIC8 [(SA605A)]
PIC12F510@SOIC8(ISP) [ISP-HEADER01]
PIC12F609 PIC12F609(ISP) [ISP-

HEADER01]
PIC12F609@DFN8 [(BBBB)]
PIC12F609@DFN8(ISP) [ISP-HEADER01]
PIC12F609@SOIC8 [(SA602A)]
PIC12F609@SOIC8(ISP) [ISP-HEADER01]
PIC12F615 PIC12F615(ISP) [ISP-
HEADER01]
PIC12F615@DFN8 [(BBBB)]
PIC12F615@DFN8(ISP) [ISP-HEADER01]
PIC12F615@SOIC8 [(SA602A)]
PIC12F615@SOIC8(ISP) [ISP-HEADER01]
PIC12F629 PIC12F629(ISP) [ISP-
HEADER01]
PIC12F629(SM)@SOIC8 [(SA605A)]
PIC12F629(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12F629(SN)@SOIC8 [(SA602A)]
PIC12F629(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12F629@DFN8 [(SA683)]
PIC12F629@DFN8(ISP) [ISP-HEADER01]
PIC12F635 PIC12F635(ISP) [ISP-
HEADER01]
PIC12F635(MD)@DFN8 [(SA744)]
PIC12F635(MD)@DFN8(ISP) [ISP-HEADER01]
PIC12F635(MF)@DFN8 [(SA683)]
PIC12F635(MF)@DFN8(ISP) [ISP-HEADER01]
PIC12F635(SM)@SOIC8 [(SA605A)]
PIC12F635(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12F635(SN)@SOIC8 [(SA602A)]
PIC12F635(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12F675 PIC12F675(ISP) [ISP-
HEADER01]
PIC12F675(SM)@SOIC8 [(SA605A)]
PIC12F675(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12F675(SN)@SOIC8 [(SA602A)]
PIC12F675(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12F675@DFN8 [(SA683)]
PIC12F675@DFN8(ISP) [ISP-HEADER01]
PIC12F675@SSOP20 [(SA626A)]
PIC12F675@SSOP20(ISP) [ISP-HEADER01]
PIC12F683 PIC12F683(ISP) [ISP-
HEADER01]
PIC12F683(MD)@DFN8 [(SA744)]
PIC12F683(MD)@DFN8(ISP) [ISP-HEADER01]

PIC12F683(MF)@DFN8 [(SA683)]
PIC12F683(MF)@DFN8(ISP) [ISP-HEADER01]
PIC12F683(SM)@SOIC8 [(SA605A)]
PIC12F683(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12F683(SN)@SOIC8 [(SA602A)]
PIC12F683(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12HV609 PIC12HV609(ISP) [ISP-
HEADER01]
PIC12HV609@DFN8 [(BBBB)]
PIC12HV609@DFN8(ISP) [ISP-HEADER01]
PIC12HV609@SOIC8 [(SA602A)]
PIC12HV609@SOIC8(ISP) [ISP-HEADER01]
PIC12HV615 PIC12HV615(ISP) [ISP-
HEADER01]
PIC12HV615@DFN8 [(BBBB)]
PIC12HV615@DFN8(ISP) [ISP-HEADER01]
PIC12HV615@SOIC8 [(SA602A)]
PIC12HV615@SOIC8(ISP) [ISP-HEADER01]
PIC12LC508 PIC12LC508(ISP) [ISP-
HEADER01]
PIC12LC508@SOIC8 [(SA605A)]
PIC12LC508@SOIC8(ISP) [ISP-HEADER01]
PIC12LC508A PIC12LC508A(ISP) [ISP-
HEADER01]
PIC12LC508A(SM)@SOIC8 [(SA605A)]
PIC12LC508A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC508A(SN)@SOIC8 [(SA602A)]
PIC12LC508A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509 PIC12LC509(ISP) [ISP-
HEADER01]
PIC12LC509(SM)@SOIC8 [(SA605A)]
PIC12LC509(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509(SN)@SOIC8 [(SA602A)]
PIC12LC509(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509A PIC12LC509A(ISP) [ISP-
HEADER01]
PIC12LC509A(SM)@SOIC8 [(SA605A)]
PIC12LC509A(SM)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC509A(SN)@SOIC8 [(SA602A)]
PIC12LC509A(SN)@SOIC8(ISP) [ISP-HEADER01]
PIC12LC671 PIC12LC671(ISP) [ISP-
HEADER01]
PIC12LC671@DFN8 [(SA683)]

PIC12LC671@DFN8 (ISP) [ISP-HEADER01]
PIC12LC671@SOIC8 [(SA605A)]
PIC12LC671@SOIC8(ISP) [ISP-HEADER01]
PIC12LC672 PIC12LC672(ISP) [ISP-
HEADER01]
PIC12LC672@DFN8 [(SA683)]
PIC12LC672@DFN8(ISP) [ISP-HEADER01]
PIC12LC672@SOIC8 [(SA605A)]
PIC12LC672@SOIC8(ISP) [ISP-HEADER01]
PIC12LF508 PIC12LF508(ISP) [ISP-
HEADER01]
PIC12LF508@MSOP8 [(SA666)]
PIC12LF508@MSOP8(ISP) [ISP-HEADER01]
PIC12LF508@SOIC8 [(SA602)]
PIC12LF508@SOIC8(ISP) [ISP-HEADER01]
PIC12LF509 PIC12LF509(ISP) [ISP-
HEADER01]
PIC12LF509@MSOP8 [(SA666)]
PIC12LF509@MSOP8(ISP) [ISP-HEADER01]
PIC12LF509@SOIC8 [(SA602)]
PIC12LF509@SOIC8(ISP) [ISP-HEADER01]
PIC14000 PIC14000(ISP) [ISP-
HEADER01]
PIC14000@SOIC28 [(SA404)]
PIC14000@SOIC28(ISP) [ISP-HEADER01]
PIC14000@SSOP28 [(SA626A)]
PIC14000@SSOP28(ISP) [ISP-HEADER01]
PIC16C432 PIC16C432(ISP) [ISP-
HEADER01]
PIC16C432@SSOP20 [(SA626A)]
PIC16C432@SSOP20(ISP) [ISP-HEADER01]
PIC16C433 PIC16C433(ISP) [ISP-
HEADER01]
PIC16C433@SOIC18 [(SA404)]
PIC16C433@SOIC18(ISP) [ISP-HEADER01]
PIC16C505 PIC16C505@SOIC14
[(SA602)]
PIC16C52 PIC16C52@SOIC18
[(SA404)]
PIC16C54 PIC16C54@SOIC18
[(SA404)]
PIC16C54A PIC16C54A@SOIC18
[(SA404)]

PIC16C54A@SSOP20 [(SA626A)]
PIC16C54B
PIC16C54B@SOIC18 [(SA404)] PIC16C54B@SSOP20
[(SA626A)]
PIC16C54C PIC16C54C@SOIC18
[(SA404)]
PIC16C54C@SSOP20 [(SA626A)]
PIC16C55
PIC16C55@SOIC28 [(SA404)]
PIC16C554
PIC16C554(ISP) [ISP-HEADER01] PIC16C554@SOIC18
[(SA404)]
PIC16C554@SOIC18(ISP) [ISP-HEADER01]
PIC16C554@SSOP20 [(SA626A)]
PIC16C554@SSOP20(ISP) [ISP-HEADER01]
PIC16C556 PIC16C556(ISP) [ISP-
HEADER01]
PIC16C556@SOIC18 [(SA404)]
PIC16C556@SOIC18(ISP) [ISP-HEADER01]
PIC16C558 PIC16C558(ISP) [ISP-
HEADER01]
PIC16C558@SOIC18 [(SA404)]
PIC16C558@SOIC18(ISP) [ISP-HEADER01]
PIC16C558@SSOP20 [(SA626A)]
PIC16C558@SSOP20(ISP) [ISP-HEADER01]
PIC16C55A PIC16C55A@SOIC28
[(SA404)]
PIC16C55A@SSOP28 [(SA626A)]
PIC16C56
PIC16C56@SOIC18 [(SA404)]
PIC16C56A
PIC16C56A@SOIC18 [(SA404)] PIC16C56A@SSOP20
[(SA626A)]
PIC16C57 PIC16C57@SOIC28
[(SA404)]
PIC16C57@SSOP28 [(SA626A)]
PIC16C57C
PIC16C57C@SOIC28 [(SA404)] PIC16C57C@SSOP28
[(SA626A)]
PIC16C58 PIC16C58@SOIC18
[(SA404)]
PIC16C58A PIC16C58A@SOIC18
[(SA404)]

PIC16C58A@SSOP20 [(SA626A)]
PIC16C58B
PIC16C58B@SOIC18 [(SA404)] PIC16C58B@SSOP20
[(SA626A)]
PIC16C61 PIC16C61(ISP) [ISP-
HEADER01]
PIC16C61@SOIC18 [(SA404)]
PIC16C61@SOIC18(ISP) [ISP-HEADER01]
PIC16C62 PIC16C62(ISP) [ISP-
HEADER01]
PIC16C62@SOIC28 [(SA404)]
PIC16C62@SOIC28(ISP) [ISP-HEADER01]
PIC16C62@SSOP28 [(SA626A)]
PIC16C62@SSOP28(ISP) [ISP-HEADER01]
PIC16C620 PIC16C620(ISP) [ISP-
HEADER01]
PIC16C620@SOIC18 [(SA404)]
PIC16C620@SOIC18(ISP) [ISP-HEADER01]
PIC16C620A PIC16C620A(ISP) [ISP-
HEADER01]
PIC16C620A@SOIC18 [(SA404)]
PIC16C620A@SOIC18(ISP) [ISP-HEADER01]
PIC16C620A@SSOP20 [(SA626A)]
PIC16C620A@SSOP20(ISP) [ISP-HEADER01]
PIC16C621 PIC16C621(ISP) [ISP-
HEADER01]
PIC16C621@SOIC18 [(SA404)]
PIC16C621@SOIC18(ISP) [ISP-HEADER01]
PIC16C621A PIC16C621A(ISP) [ISP-
HEADER01]
PIC16C621A@SOIC18 [(SA404)]
PIC16C621A@SOIC18(ISP) [ISP-HEADER01]
PIC16C621A@SSOP20 [(SA626A)]
PIC16C621A@SSOP20(ISP) [ISP-HEADER01]
PIC16C622 PIC16C622(ISP) [ISP-
HEADER01]
PIC16C622@SOIC18 [(SA404)]
PIC16C622@SOIC18(ISP) [ISP-HEADER01]
PIC16C622A PIC16C622A(ISP) [ISP-
HEADER01]
PIC16C622A@SOIC18 [(SA404)]
PIC16C622A@SOIC18(ISP) [ISP-HEADER01]
PIC16C622A@SSOP20 [(SA626A)]

PIC16C622A@SSOP20(ISP) [ISP-HEADER01]
PIC16C625 PIC16C625(ISP) [ISP-
HEADER01]
PIC16C625@SOIC18 [(SA404)]
PIC16C625@SOIC18(ISP) [ISP-HEADER01]
PIC16C62A PIC16C62A(ISP) [ISP-
HEADER01]
PIC16C62A@SOIC28 [(SA404)]
PIC16C62A@SOIC28(ISP) [ISP-HEADER01]
PIC16C62A@SSOP28 [(SA626A)]
PIC16C62A@SSOP28(ISP) [ISP-HEADER01]
PIC16C62B PIC16C62B(ISP) [ISP-
HEADER01]
PIC16C62B@SOIC28 [(SA404)]
PIC16C62B@SOIC28(ISP) [ISP-HEADER01]
PIC16C62B@SSOP28 [(SA626A)]
PIC16C62B@SSOP28(ISP) [ISP-HEADER01]
PIC16C63 PIC16C63(ISP) [ISP-
HEADER01]
PIC16C63@SOIC28 [(SA404)]
PIC16C63@SOIC28(ISP) [ISP-HEADER01]
PIC16C63A PIC16C63A(ISP) [ISP-
HEADER01]
PIC16C63A@SOIC28 [(SA404)]
PIC16C63A@SOIC28(ISP) [ISP-HEADER01]
PIC16C63A@SSOP28 [(SA626A)]
PIC16C63A@SSOP28(ISP) [ISP-HEADER01]
PIC16C64 PIC16C64(ISP) [ISP-
HEADER01]
PIC16C64@PLCC44 [(SA244)]
PIC16C64@PLCC44(ISP) [ISP-HEADER01]
PIC16C64@TQFP44 [(SA245A)]
PIC16C64@TQFP44(ISP) [ISP-HEADER01]
PIC16C641 PIC16C641@SOIC28
[(SA404)]
PIC16C641@SSOP28 [(SA626A)]
PIC16C642 PIC16C642@SSOP28
[(SA626A)]
PIC16C64A PIC16C64A(ISP) [ISP-
HEADER01]
PIC16C64A@PLCC44 [(SA244)]
PIC16C64A@PLCC44(ISP) [ISP-HEADER01]

PIC16C64A@TQFP44 [(SA245A)]
PIC16C64A@TQFP44(ISP) [ISP-HEADER01]
PIC16C65 PIC16C65(ISP) [ISP-
HEADER01]
PIC16C65@PLCC44 [(SA244)]
PIC16C65@PLCC44(ISP) [ISP-HEADER01]
PIC16C65@TQFP44 [(SA245A)]
PIC16C65@TQFP44(ISP) [ISP-HEADER01]
PIC16C65A PIC16C65A(ISP) [ISP-
HEADER01]
PIC16C65A@PLCC44 [(SA244)]
PIC16C65A@PLCC44(ISP) [ISP-HEADER01]
PIC16C65A@TQFP44 [(SA245A)]
PIC16C65A@TQFP44(ISP) [ISP-HEADER01]
PIC16C65B PIC16C65B(ISP) [ISP-
HEADER01]
PIC16C65B@PLCC44 [(SA244)]
PIC16C65B@PLCC44(ISP) [ISP-HEADER01]
PIC16C65B@TQFP44 [(SA245A)]
PIC16C65B@TQFP44(ISP) [ISP-HEADER01]
PIC16C66 PIC16C66(ISP) [ISP-
HEADER01]
PIC16C66@SOIC28 [(SA404)]
PIC16C66@SOIC28(ISP) [ISP-HEADER01]
PIC16C661 PIC16C661@PLCC44
[(SA244)]
PIC16C661@TQFP44 [(SA245A)]
PIC16C662
PIC16C662@PLCC44 [(SA244)] PIC16C662@TQFP44
[(SA245A)]
PIC16C67 PIC16C67(ISP) [ISP-
HEADER01]
PIC16C67@PLCC44 [(SA244)]
PIC16C67@PLCC44(ISP) [ISP-HEADER01]
PIC16C67@TQFP44 [(SA245A)]
PIC16C67@TQFP44(ISP) [ISP-HEADER01]
PIC16C70 PIC16C70(ISP) [ISP-
HEADER01]
PIC16C70@SOIC18 [(SA404)]
PIC16C70@SOIC18(ISP) [ISP-HEADER01]
PIC16C71 PIC16C71(ISP) [ISP-
HEADER01]
PIC16C71@SOIC18 [(SA404)]

PIC16C71@SOIC18(ISP) [ISP-HEADER01]
PIC16C710 PIC16C710(ISP) [ISP-
HEADER01]
PIC16C710@SOIC18 [(SA404)]
PIC16C710@SOIC18(ISP) [ISP-HEADER01]
PIC16C710@SSOP20 [(SA626A)]
PIC16C710@SSOP20(ISP) [ISP-HEADER01]
PIC16C711 PIC16C711(ISP) [ISP-
HEADER01]
PIC16C711@SOIC18 [(SA404)]
PIC16C711@SOIC18(ISP) [ISP-HEADER01]
PIC16C711@SSOP20 [(SA626A)]
PIC16C711@SSOP20(ISP) [ISP-HEADER01]
PIC16C712 PIC16C712(ISP) [ISP-
HEADER01]
PIC16C712@SOIC18 [(SA404)]
PIC16C712@SOIC18(ISP) [ISP-HEADER01]
PIC16C712@SSOP20 [(SA626A)]
PIC16C712@SSOP20(ISP) [ISP-HEADER01]
PIC16C715 PIC16C715@SOIC18
[(SA404)]
PIC16C715@SSOP20 [(SA626A)]
PIC16C716 PIC16C716@SOIC18
PIC16C716(ISP) [ISP-HEADER01]
[(SA404)]
PIC16C716@SOIC18(ISP) [ISP-HEADER01]
PIC16C716@SSOP20 [(SA626A)]
PIC16C716@SSOP20(ISP) [ISP-HEADER01]
PIC16C717 PIC16C717(ISP) [ISP-
HEADER01]
PIC16C717@SOIC18 [(SA404)]
PIC16C717@SOIC18(ISP) [ISP-HEADER01]
PIC16C717@SSOP20 [(SA626A)]
PIC16C717@SSOP20(ISP) [ISP-HEADER01]
PIC16C71A PIC16C71A(ISP) [ISP-
HEADER01]
PIC16C71A@SOIC18 [(SA404)]
PIC16C71A@SOIC18(ISP) [ISP-HEADER01]
PIC16C72 PIC16C72(ISP) [ISP-
HEADER01]
PIC16C72@SOIC28 [(SA404)]
PIC16C72@SOIC28(ISP) [ISP-HEADER01]
PIC16C72@SSOP28 [(SA626A)]

PIC16C72@SSOP28(ISP) [ISP-HEADER01]
PIC16C72A PIC16C72A(ISP) [ISP-
HEADER01]
PIC16C72A@SOIC28 [(SA404)]
PIC16C72A@SOIC28(ISP) [ISP-HEADER01]
PIC16C72A@SSOP28 [(SA626A)]
PIC16C72A@SSOP28(ISP) [ISP-HEADER01]
PIC16C73 PIC16C73(ISP) [ISP-
HEADER01]
PIC16C73@SOIC28 [(SA404)]
PIC16C73@SOIC28(ISP) [ISP-HEADER01]
PIC16C73A PIC16C73A(ISP) [ISP-
HEADER01]
PIC16C73A@SOIC28 [(SA404)]
PIC16C73A@SOIC28(ISP) [ISP-HEADER01]
PIC16C73B PIC16C73B(ISP) [ISP-
HEADER01]
PIC16C73B@SOIC28 [(SA404)]
PIC16C73B@SOIC28(ISP) [ISP-HEADER01]
PIC16C73B@SSOP28 [(SA626A)]
PIC16C73B@SSOP28(ISP) [ISP-HEADER01]
PIC16C74 PIC16C74(ISP) [ISP-
HEADER01]
PIC16C74@PLCC44 [(SA244)]
PIC16C74@PLCC44(ISP) [ISP-HEADER01]
PIC16C74@TQFP44 [(SA245A)]
PIC16C74@TQFP44(ISP) [ISP-HEADER01]
PIC16C745 PIC16C745(ISP) [ISP-
HEADER01]
PIC16C745@SOIC28 [(SA404)]
PIC16C745@SOIC28(ISP) [ISP-HEADER01]
PIC16C74A PIC16C74A(ISP) [ISP-
HEADER01]
PIC16C74A@PLCC44 [(SA244)]
PIC16C74A@PLCC44(ISP) [ISP-HEADER01]
PIC16C74A@TQFP44 [(SA245A)]
PIC16C74A@TQFP44(ISP) [ISP-HEADER01]
PIC16C74B PIC16C74B(ISP) [ISP-
HEADER01]
PIC16C74B@MQFP44 [(SA675)]
PIC16C74B@MQFP44(ISP) [ISP-HEADER01]
PIC16C74B@PLCC44 [(SA244)]
PIC16C74B@PLCC44(ISP) [ISP-HEADER01]

PIC16C74B@TQFP44 [(SA245A)]
PIC16C74B@TQFP44(ISP) [ISP-HEADER01]
PIC16C76 PIC16C76(ISP) [ISP-
HEADER01]
PIC16C76@SOIC28 [(SA404)]
PIC16C76@SOIC28(ISP) [ISP-HEADER01]
PIC16C765 PIC16C765(ISP) [ISP-
HEADER01]
PIC16C765@PLCC44 [(SA244)]
PIC16C765@PLCC44(ISP) [ISP-HEADER01]
PIC16C765@TQFP44 [(SA245A)]
PIC16C765@TQFP44(ISP) [ISP-HEADER01]
PIC16C77 PIC16C77(ISP) [ISP-
HEADER01]
PIC16C77@PLCC44 [(SA244)]
PIC16C77@PLCC44(ISP) [ISP-HEADER01]
PIC16C77@TQFP44 [(SA245A)]
PIC16C77@TQFP44(ISP) [ISP-HEADER01]
PIC16C770 PIC16C770(ISP) [ISP-
HEADER01]
PIC16C770@SOIC20 [(SA404)]
PIC16C770@SOIC20(ISP) [ISP-HEADER01]
PIC16C770@SSOP20 [(SA626A)]
PIC16C770@SSOP20(ISP) [ISP-HEADER01]
PIC16C771 PIC16C771(ISP) [ISP-
HEADER01]
PIC16C771@SOIC20 [(SA404)]
PIC16C771@SOIC20(ISP) [ISP-HEADER01]
PIC16C771@SSOP20 [(SA626A)]
PIC16C771@SSOP20(ISP) [ISP-HEADER01]
PIC16C773 PIC16C773(ISP) [ISP-
HEADER01]
PIC16C773@SOIC28 [(SA404)]
PIC16C773@SOIC28(ISP) [ISP-HEADER01]
PIC16C773@SSOP28 [(SA626A)]
PIC16C773@SSOP28(ISP) [ISP-HEADER01]
PIC16C774 PIC16C774(ISP) [ISP-
HEADER01]
PIC16C774@PLCC44 [(SA244)]
PIC16C774@PLCC44(ISP) [ISP-HEADER01]
PIC16C774@TQFP44 [(SA675)]
PIC16C774@TQFP44(ISP) [ISP-HEADER01]
PIC16C781 PIC16C781(ISP) [ISP-

HEADER01]
PIC16C781@SOIC20 [(SA404)]
PIC16C781@SOIC20(ISP) [ISP-HEADER01]
PIC16C781@SSOP20 [(SA626A)]
PIC16C781@SSOP20(ISP) [ISP-HEADER01]
PIC16C782 PIC16C782(ISP) [ISP-
HEADER01]
PIC16C782@SOIC20 [(SA404)]
PIC16C782@SOIC20(ISP) [ISP-HEADER01]
PIC16C782@SSOP20 [(SA626A)]
PIC16C782@SSOP20(ISP) [ISP-HEADER01]
PIC16C84 PIC16C84(ISP) [ISP-
HEADER01]
PIC16C84@SOIC18 [(SA404)]
PIC16C84@SOIC18(ISP) [ISP-HEADER01]
PIC16C923@PLCC68(*) [(SA648-B6807)]
PIC16C923@PLCC68(ISP) [ISP-HEADER01]
PIC16C923@SDIP64(ISP) [ISP-HEADER01]
PIC16C923@TQFP64(ISP) [ISP-HEADER01]
PIC16C924@PLCC68(*) [(SA648-B6807)]
PIC16C924@PLCC68(ISP) [ISP-HEADER01]
PIC16C924@SDIP64(ISP) [ISP-HEADER01]
PIC16C924@TQFP64(ISP) [ISP-HEADER01]
PIC16C925@PLCC68(*) [(SA648-B6807)]
PIC16C925@PLCC68(ISP) [ISP-HEADER01]
PIC16C925@TQFP64(ISP) [ISP-HEADER01]
PIC16C926@PLCC68(*) [(SA648-B6807)]
PIC16C926@PLCC68(ISP) [ISP-HEADER01]
PIC16C926@TQFP64(ISP) [ISP-HEADER01]
PIC16CE623 PIC16CE623(ISP) [ISP-
HEADER01]
PIC16CE623@SOIC18 [(SA404)]
PIC16CE623@SOIC18(ISP) [ISP-HEADER01]
PIC16CE624 PIC16CE624(ISP) [ISP-
HEADER01]
PIC16CE624@SOIC18 [(SA404)]
PIC16CE624@SOIC18(ISP) [ISP-HEADER01]
PIC16CE625 PIC16CE625(ISP) [ISP-
HEADER01]
PIC16CE625@SOIC18 [(SA404)]
PIC16CE625@SOIC18(ISP) [ISP-HEADER01]
PIC16CE625@SSOP20 [(SA626A)]
PIC16CE625@SSOP20(ISP) [ISP-HEADER01]

PIC16CR83 PIC16CR83(ISP) [ISP-
HEADER01]
PIC16CR83@SOIC18 [(SA404)]
PIC16CR83@SOIC18(ISP) [ISP-HEADER01]
PIC16CR84 PIC16CR84(ISP) [ISP-
HEADER01]
PIC16CR84@SOIC18 [(SA404)]
PIC16CR84@SOIC18(ISP) [ISP-HEADER01]
PIC16F505 PIC16F505(ISP) [ISP-
HEADER01]
PIC16F505@SOIC14 [(SA602)]
PIC16F505@SOIC14(ISP) [ISP-HEADER01]
PIC16F505@TSSOP14 [(SA026)]
PIC16F505@TSSOP14(ISP) [ISP-HEADER01]
PIC16F506 PIC16F506(ISP) [ISP-
HEADER01]
PIC16F506@SOIC14 [(SA602)]
PIC16F506@SOIC14(ISP) [ISP-HEADER01]
PIC16F506@TSSOP14 [(SA026)]
PIC16F506@TSSOP14(ISP) [ISP-HEADER01]
PIC16F526 PIC16F526@SOIC14
[(SA602)]
PIC16F526@TSSOP14 [(SA026)]
PIC16F54
PIC16F54(ISP) [ISP-HEADER01] PIC16F54@SOIC18
[(SA404)]
PIC16F54@SOIC18(ISP) [ISP-HEADER01]
PIC16F54@SSOP20 [(SA626A)]
PIC16F54@SSOP20(ISP) [ISP-HEADER01]
PIC16F57 PIC16F57(ISP) [ISP-
HEADER01]
PIC16F57@SOIC28 [(SA404)]
PIC16F57@SOIC28(ISP) [ISP-HEADER01]
PIC16F57@SSOP28 [(SA626A)]
PIC16F57@SSOP28(ISP) [ISP-HEADER01]
PIC16F59 PIC16F59(ISP) [ISP-
HEADER01]
PIC16F59@PLCC44 [(SA244)]
PIC16F59@PLCC44(ISP) [ISP-HEADER01]
PIC16F59@TQFP44 [(SA245A)]
PIC16F59@TQFP44(ISP) [ISP-HEADER01]
PIC16F610 PIC16F610(ISP) [ISP-
HEADER01]

PIC16F610@QFN16 [(SA727)]
PIC16F610@QFN16(ISP) [ISP-HEADER01]
PIC16F610@SOIC14 [(SA602)]
PIC16F610@SOIC14(ISP) [ISP-HEADER01]
PIC16F610@TSSOP14 [(SA026)]
PIC16F610@TSSOP14(ISP) [ISP-HEADER01]
PIC16F616 PIC16F616(ISP) [ISP-
HEADER01]
PIC16F616@QFN16 [(SA727)]
PIC16F616@QFN16(ISP) [ISP-HEADER01]
PIC16F616@SOIC14 [(SA602)]
PIC16F616@SOIC14(ISP) [ISP-HEADER01]
PIC16F616@TSSOP14 [(SA026)]
PIC16F616@TSSOP14(ISP) [ISP-HEADER01]
PIC16F627 PIC16F627(ISP) [ISP-
HEADER01]
PIC16F627@SOIC18 [(SA404)]
PIC16F627@SOIC18(ISP) [ISP-HEADER01]
PIC16F627@SSOP20 [(SA626A)]
PIC16F627@SSOP20(ISP) [ISP-HEADER01]
PIC16F627A PIC16F627A(ISP) [ISP-
HEADER01]
PIC16F627A@SOIC18 [(SA404)]
PIC16F627A@SOIC18(ISP) [ISP-HEADER01]
PIC16F627A@SSOP20 [(SA626A)]
PIC16F627A@SSOP20(ISP) [ISP-HEADER01]
PIC16F628 PIC16F628(ISP) [ISP-
HEADER01]
PIC16F628@SOIC18 [(SA404)]
PIC16F628@SOIC18(ISP) [ISP-HEADER01]
PIC16F628@SSOP20 [(SA626A)]
PIC16F628@SSOP20(ISP) [ISP-HEADER01]
PIC16F628A PIC16F628A(ISP) [ISP-
HEADER01]
PIC16F628A@SOIC18 [(SA404)]
PIC16F628A@SOIC18(ISP) [ISP-HEADER01]
PIC16F628A@SSOP20 [(SA626A)]
PIC16F628A@SSOP20(ISP) [ISP-HEADER01]
PIC16F630 PIC16F630(ISP) [ISP-
HEADER01]
PIC16F630@SOIC14 [(SA602)]
PIC16F630@SOIC14(ISP) [ISP-HEADER01]
PIC16F630@TSSOP14 [(SA026)]

PIC16F630@TSSOP14(ISP) [ISP-HEADER01]
PIC16F631 PIC16F631(ISP) [ISP-
HEADER01]
PIC16F631@QFN20 [(SA692)]
PIC16F631@QFN20(ISP) [ISP-HEADER01]
PIC16F631@SOIC20 [(SA404)]
PIC16F631@SOIC20(ISP) [ISP-HEADER01]
PIC16F631@SSOP20 [(SA626A)]
PIC16F631@SSOP20(ISP) [ISP-HEADER01]
PIC16F636 PIC16F636(ISP) [ISP-
HEADER01]
PIC16F636@QFN16 [(SA727)]
PIC16F636@QFN16(ISP) [ISP-HEADER01]
PIC16F636@SOIC14 [(SA602)]
PIC16F636@SOIC14(ISP) [ISP-HEADER01]
PIC16F636@TSSOP14 [(SA026)]
PIC16F636@TSSOP14(ISP) [ISP-HEADER01]
PIC16F639 PIC16F639(ISP) [ISP-
HEADER01]
PIC16F639@QFN20 [(SA692)]
PIC16F639@QFN20(ISP) [ISP-HEADER01]
PIC16F639@SOIC20 [(SA404)]
PIC16F639@SOIC20(ISP) [ISP-HEADER01]
PIC16F639@SSOP20 [(SA626A)]
PIC16F639@SSOP20(ISP) [ISP-HEADER01]
PIC16F648A PIC16F648A(ISP) [ISP-
HEADER01]
PIC16F648A@SOIC18 [(SA404)]
PIC16F648A@SOIC18(ISP) [ISP-HEADER01]
PIC16F648A@SSOP20 [(SA626A)]
PIC16F648A@SSOP20(ISP) [ISP-HEADER01]
PIC16F676 PIC16F676(ISP) [ISP-
HEADER01]
PIC16F676@SOIC14 [(SA602)]
PIC16F676@SOIC14(ISP) [ISP-HEADER01]
PIC16F676@TSSOP14 [(SA026)]
PIC16F676@TSSOP14(ISP) [ISP-HEADER01]
PIC16F677 PIC16F677(ISP) [ISP-
HEADER01]
PIC16F677@QFN20 [(SA692)]
PIC16F677@QFN20(ISP) [ISP-HEADER01]
PIC16F677@SOIC20 [(SA404)]
PIC16F677@SOIC20(ISP) [ISP-HEADER01]

PIC16F677@SSOP20 [(SA626A)]
PIC16F677@SSOP20(ISP) [ISP-HEADER01]
PIC16F684 PIC16F684(ISP) [ISP-
HEADER01]
PIC16F684@QFN16 [(SA727)]
PIC16F684@QFN16(ISP) [ISP-HEADER01]
PIC16F684@SOIC14 [(SA602)]
PIC16F684@SOIC14(ISP) [ISP-HEADER01]
PIC16F684@TSSOP14 [(SA026)]
PIC16F684@TSSOP14(ISP) [ISP-HEADER01]
PIC16F685 PIC16F685(ISP) [ISP-
HEADER01]
PIC16F685@QFN20 [(SA692)]
PIC16F685@QFN20(ISP) [ISP-HEADER01]
PIC16F685@SOIC20 [(SA404)]
PIC16F685@SOIC20(ISP) [ISP-HEADER01]
PIC16F685@SSOP20 [(SA626A)]
PIC16F685@SSOP20(ISP) [ISP-HEADER01]
PIC16F687 PIC16F687(ISP) [ISP-
HEADER01]
PIC16F687@QFN20 [(SA692)]
PIC16F687@QFN20(ISP) [ISP-HEADER01]
PIC16F687@SOIC20 [(SA404)]
PIC16F687@SOIC20(ISP) [ISP-HEADER01]
PIC16F687@SSOP20 [(SA626A)]
PIC16F687@SSOP20(ISP) [ISP-HEADER01]
PIC16F688 PIC16F688(ISP) [ISP-
HEADER01]
PIC16F688@QFN16 [(SA727)]
PIC16F688@QFN16(ISP) [ISP-HEADER01]
PIC16F688@SOIC14 [(SA602)]
PIC16F688@SOIC14(ISP) [ISP-HEADER01]
PIC16F688@TSSOP14 [(SA026)]
PIC16F688@TSSOP14(ISP) [ISP-HEADER01]
PIC16F689 PIC16F689(ISP) [ISP-
HEADER01]
PIC16F689@QFN20 [(SA692)]
PIC16F689@QFN20(ISP) [ISP-HEADER01]
PIC16F689@SOIC20 [(SA404)]
PIC16F689@SOIC20(ISP) [ISP-HEADER01]
PIC16F689@SSOP20 [(SA626A)]
PIC16F689@SSOP20(ISP) [ISP-HEADER01]
PIC16F690 PIC16F690(ISP) [ISP-

```

HEADER01 ]
PIC16F690@QFN20 [(SA692)]
PIC16F690@QFN20(ISP) [ISP-HEADER01]
PIC16F690@SOIC20 [(SA404)]
PIC16F690@SOIC20(ISP) [ISP-HEADER01]
PIC16F690@SSOP20 [(SA626A)]
PIC16F690@SSOP20(ISP) [ISP-HEADER01]
PIC16F716 PIC16F716(ISP) [ISP-
HEADER01]
PIC16F716@SOIC18 [(SA404)]
PIC16F716@SOIC18(ISP) [ISP-HEADER01]
PIC16F716@SSOP20 [(SA626A)]
PIC16F716@SSOP20(ISP) [ISP-HEADER01]
PIC16F72 PIC16F72(ISP) [ISP-
HEADER01]
PIC16F72@QFN28 [(SA685-B006)]
PIC16F72@QFN28(ISP) [ISP-HEADER01]
PIC16F72@SOIC28 [(SA404)]
PIC16F72@SOIC28(ISP) [ISP-HEADER01]
PIC16F72@SSOP28 [(SA626A)]
PIC16F72@SSOP28(ISP) [ISP-HEADER01]
PIC16F722 PIC16F722@QFN28 [(SA685-
B006)]
PIC16F722@SOIC28 [(SA404)] PIC16F722@SSOP28
[(SA626A)]
PIC16F723 PIC16F723@QFN28 [(SA685-
B006)]
PIC16F723@SOIC28 [(SA404)] PIC16F723@SSOP28
[(SA626A)]
PIC16F724 PIC16F724@QFN44
[(SA737)]
PIC16F724@TQFP44 [(SA245A)]
PIC16F726 PIC16F726@SOIC28
PIC16F726@QFN28 [(SA685-B006)]
[(SA404)]
PIC16F726@SSOP28 [(SA626A)]
PIC16F727 PIC16F727@TQFP44
PIC16F727@QFN44 [(SA737)]
[(SA245A)]
PIC16F73 PIC16F73(ISP) [ISP-
HEADER01]
PIC16F73@SOIC28 [(SA404)]
PIC16F73@SOIC28(ISP) [ISP-HEADER01]

```

PIC16F73@SSOP28 [(SA626A)]
PIC16F73@SSOP28(ISP) [ISP-HEADER01]
PIC16F737 PIC16F737(ISP) [ISP-
HEADER01]
PIC16F737@SOIC28 [(SA404)]
PIC16F737@SOIC28(ISP) [ISP-HEADER01]
PIC16F737@SSOP28 [(SA626A)]
PIC16F737@SSOP28(ISP) [ISP-HEADER01]
PIC16F74 PIC16F74(ISP) [ISP-
HEADER01]
PIC16F74@PLCC44 [(SA244)]
PIC16F74@PLCC44(ISP) [ISP-HEADER01]
PIC16F74@TQFP44 [(SA245A)]
PIC16F74@TQFP44(ISP) [ISP-HEADER01]
PIC16F747 PIC16F747(ISP) [ISP-
HEADER01]
PIC16F747@TQFP44 [(SA245A)]
PIC16F747@TQFP44(ISP) [ISP-HEADER01]
PIC16F76 PIC16F76(ISP) [ISP-
HEADER01]
PIC16F76@SOIC28 [(SA404)]
PIC16F76@SOIC28(ISP) [ISP-HEADER01]
PIC16F76@SSOP28 [(SA626A)]
PIC16F76@SSOP28(ISP) [ISP-HEADER01]
PIC16F767 PIC16F767(ISP) [ISP-
HEADER01]
PIC16F767@SOIC28 [(SA404)]
PIC16F767@SOIC28(ISP) [ISP-HEADER01]
PIC16F767@SSOP28 [(SA626A)]
PIC16F767@SSOP28(ISP) [ISP-HEADER01]
PIC16F77 PIC16F77(ISP) [ISP-
HEADER01]
PIC16F77@PLCC44 [(SA244)]
PIC16F77@PLCC44(ISP) [ISP-HEADER01]
PIC16F77@TQFP44 [(SA245A)]
PIC16F77@TQFP44(ISP) [ISP-HEADER01]
PIC16F777 PIC16F777(ISP) [ISP-
HEADER01]
PIC16F777@TQFP44 [(SA245A)]
PIC16F777@TQFP44(ISP) [ISP-HEADER01]
PIC16F785 PIC16F785(ISP) [ISP-
HEADER01]
PIC16F785@QFN20 [(SA692)]

PIC16F785@QFN20(ISP) [ISP-HEADER01]
PIC16F785@SOIC20 [(SA404)]
PIC16F785@SOIC20(ISP) [ISP-HEADER01]
PIC16F785@SSOP20 [(SA626A)]
PIC16F785@SSOP20(ISP) [ISP-HEADER01]
PIC16F818 PIC16F818(ISP) [ISP-
HEADER01]
PIC16F818@QFN28 [(SA685-B006)]
PIC16F818@QFN28(ISP) [ISP-HEADER01]
PIC16F818@SOIC18 [(SA404)]
PIC16F818@SOIC18(ISP) [ISP-HEADER01]
PIC16F818@SSOP20 [(SA626A)]
PIC16F818@SSOP20(ISP) [ISP-HEADER01]
PIC16F819 PIC16F819(ISP) [ISP-
HEADER01]
PIC16F819@QFN28 [(SA685-B006)]
PIC16F819@QFN28(ISP) [ISP-HEADER01]
PIC16F819@SOIC18 [(SA404)]
PIC16F819@SOIC18(ISP) [ISP-HEADER01]
PIC16F819@SSOP20 [(SA626A)]
PIC16F819@SSOP20(ISP) [ISP-HEADER01]
PIC16F83 PIC16F83(ISP) [ISP-
HEADER01]
PIC16F83@SOIC18 [(SA404)]
PIC16F83@SOIC18(ISP) [ISP-HEADER01]
PIC16F84 PIC16F84(ISP) [ISP-
HEADER01]
PIC16F84@SOIC18 [(SA404)]
PIC16F84@SOIC18(ISP) [ISP-HEADER01]
PIC16F84A PIC16F84A(ISP) [ISP-
HEADER01]
PIC16F84A@SOIC18 [(SA404)]
PIC16F84A@SOIC18(ISP) [ISP-HEADER01]
PIC16F84A@SSOP20 [(SA626A)]
PIC16F84A@SSOP20(ISP) [ISP-HEADER01]
PIC16F87 PIC16F87(ISP) [ISP-
HEADER01]
PIC16F87@QFN28 [(SA685-B006)]
PIC16F87@QFN28(ISP) [ISP-HEADER01]
PIC16F87@SOIC18 [(SA404)]
PIC16F87@SOIC18(ISP) [ISP-HEADER01]
PIC16F87@SSOP20 [(SA626A)]
PIC16F87@SSOP20(ISP) [ISP-HEADER01]

PIC16F870 PIC16F870(ISP) [ISP-
HEADER01]
PIC16F870@SOIC28 [(SA404)]
PIC16F870@SOIC28(ISP) [ISP-HEADER01]
PIC16F870@SSOP28 [(SA626A)]
PIC16F870@SSOP28(ISP) [ISP-HEADER01]
PIC16F871 PIC16F871(ISP) [ISP-
HEADER01]
PIC16F871@PLCC44 [(SA244)]
PIC16F871@PLCC44(ISP) [ISP-HEADER01]
PIC16F871@TQFP44 [(SA245A)]
PIC16F871@TQFP44(ISP) [ISP-HEADER01]
PIC16F872 PIC16F872(ISP) [ISP-
HEADER01]
PIC16F872@SOIC28 [(SA404)]
PIC16F872@SOIC28(ISP) [ISP-HEADER01]
PIC16F872@SSOP28 [(SA626A)]
PIC16F872@SSOP28(ISP) [ISP-HEADER01]
PIC16F873 PIC16F873(ISP) [ISP-
HEADER01]
PIC16F873@SOIC28 [(SA404)]
PIC16F873@SOIC28(ISP) [ISP-HEADER01]
PIC16F873A
PIC16F873A(ISP)(High-V) [ISP-HEADER01]
PIC16F873A(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@QFN28 [(SA697-B006)]
PIC16F873A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@SOIC28 [(SA404)]
PIC16F873A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F873A@SSOP28 [(SA626A)]
PIC16F873A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874 PIC16F874(ISP) [ISP-

HEADER01]
PIC16F874@PLCC44 [(SA244)]
PIC16F874@PLCC44(ISP) [ISP-HEADER01]
PIC16F874@TQFP44 [(SA245A)]
PIC16F874@TQFP44(ISP) [ISP-HEADER01]
PIC16F874A
PIC16F874A(ISP)(High-V) [ISP-HEADER01]
PIC16F874A(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874A@PLCC44 [(SA244)]
PIC16F874A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F874A@TQFP44 [(SA245A)]
PIC16F874A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876 PIC16F876(ISP) [ISP-
HEADER01]
PIC16F876@SOIC28 [(SA404)]
PIC16F876@SOIC28(ISP) [ISP-HEADER01]
PIC16F876A
PIC16F876A(ISP)(High-V) [ISP-HEADER01]
PIC16F876A(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876A@QFN28 [(SA697-B006)]
PIC16F876A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F876A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876A@SOIC28 [(SA404)]
PIC16F876A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F876A@SSOP28 [(SA626A)]
PIC16F876A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]

PIC16F876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F877 PIC16F877(ISP) [ISP-
HEADER01]
PIC16F877@PLCC44 [(SA244)]
PIC16F877@PLCC44(ISP) [ISP-HEADER01]
PIC16F877@TQFP44 [(SA245A)]
PIC16F877@TQFP44(ISP) [ISP-HEADER01]
PIC16F877A
PIC16F877A(ISP)(High-V) [ISP-HEADER01]
PIC16F877A(ISP)(Low-V) [ISP-HEADER01]
PIC16F877A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F877A@PLCC44 [(SA244)]
PIC16F877A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16F877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16F877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F877A@TQFP44 [(SA245A)]
PIC16F877A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16F877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16F88 PIC16F88(ISP) [ISP-
HEADER01]
PIC16F88@QFN28 [(SA685-B006)]
PIC16F88@QFN28(ISP) [ISP-HEADER01]
PIC16F88@SOIC18 [(SA404)]
PIC16F88@SOIC18(ISP) [ISP-HEADER01]
PIC16F88@SSOP20 [(SA626A)]
PIC16F88@SSOP20(ISP) [ISP-HEADER01]
PIC16F882
PIC16F882(ISP)(High-V) [ISP-HEADER01]
PIC16F882(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@QFN28 [(SA697-B005)]
PIC16F882@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@SOIC28 [(SA404)]
PIC16F882@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F882@SSOP28 [(SA626A)]
PIC16F882@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F882@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883

PIC16F883(ISP)(High-V) [ISP-HEADER01]
PIC16F883(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@QFN28 [(SA697-B005)]
PIC16F883@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@SOIC28 [(SA404)]
PIC16F883@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F883@SSOP28 [(SA626A)]
PIC16F883@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F883@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F884
PIC16F884(ISP)(High-V) [ISP-HEADER01]
PIC16F884(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@QFN44 [(SA712)]
PIC16F884@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC16F884@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@QFN44(ML) [(SA737)]
PIC16F884@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]
PIC16F884@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC16F884@TQFP44 [(SA245A)]
PIC16F884@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F884@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F886
PIC16F886(ISP)(High-V) [ISP-HEADER01]
PIC16F886(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@QFN28 [(SA697-B005)]
PIC16F886@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@SOIC28 [(SA404)]
PIC16F886@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16F886@SSOP28 [(SA626A)]
PIC16F886@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16F886@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16F887
PIC16F887(ISP)(High-V) [ISP-HEADER01]
PIC16F887(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@QFN44 [(SA712)]
PIC16F887@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC16F887@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@QFN44(ML) [(SA737)]
PIC16F887@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]

PIC16F887@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC16F887@TQFP44 [(SA245A)]
PIC16F887@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16F887@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16F913 PIC16F913(ISP) [ISP-HEADER01]
PIC16F913@QFN28 [(SA697-B006)]
PIC16F913@QFN28(ISP) [ISP-HEADER01]
PIC16F913@SOIC28 [(SA404)]
PIC16F913@SOIC28(ISP) [ISP-HEADER01]
PIC16F913@SSOP28 [(SA626A)]
PIC16F913@SSOP28(ISP) [ISP-HEADER01]
PIC16F914 PIC16F914(ISP) [ISP-HEADER01]
PIC16F914@QFN44 [(SA712)]
PIC16F914@QFN44(ISP) [ISP-HEADER01]
PIC16F914@QFN44(ML) [(SA737)]
PIC16F914@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16F914@TQFP44 [(SA245A)]
PIC16F914@TQFP44(ISP) [ISP-HEADER01]
PIC16F916 PIC16F916(ISP) [ISP-HEADER01]
PIC16F916@QFN28 [(SA697-B006)]
PIC16F916@QFN28(ISP) [ISP-HEADER01]
PIC16F916@SOIC28 [(SA404)]
PIC16F916@SOIC28(ISP) [ISP-HEADER01]
PIC16F916@SSOP28 [(SA626A)]
PIC16F916@SSOP28(ISP) [ISP-HEADER01]
PIC16F917 PIC16F917(ISP) [ISP-HEADER01]
PIC16F917@QFN44 [(SA712)]
PIC16F917@QFN44(ISP) [ISP-HEADER01]
PIC16F917@QFN44(ML) [(SA737)]
PIC16F917@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16F917@TQFP44 [(SA245A)]
PIC16F917@TQFP44(ISP) [ISP-HEADER01]
PIC16F946@TQFP64(ISP) [ISP-HEADER01]
PIC16HV540 PIC16HV540@SOIC18
[(SA404)]
PIC16HV540@SSOP20 [(SA626A)]
PIC16HV610
PIC16HV610(ISP) [ISP-HEADER01] PIC16HV610@QFN16
[(SA727)]

PIC16HV610@QFN16(ISP) [ISP-HEADER01]
PIC16HV610@SOIC14 [(SA602)]
PIC16HV610@SOIC14(ISP) [ISP-HEADER01]
PIC16HV610@TSSOP14 [(SA026)]
PIC16HV610@TSSOP14(ISP) [ISP-HEADER01]
PIC16HV616 PIC16HV616(ISP) [ISP-
HEADER01]
PIC16HV616@QFN16 [(SA727)]
PIC16HV616@QFN16(ISP) [ISP-HEADER01]
PIC16HV616@SOIC14 [(SA602)]
PIC16HV616@SOIC14(ISP) [ISP-HEADER01]
PIC16HV616@TSSOP14 [(SA026)]
PIC16HV616@TSSOP14(ISP) [ISP-HEADER01]
PIC16HV785 PIC16HV785(ISP) [ISP-
HEADER01]
PIC16HV785@QFN20 [(SA692)]
PIC16HV785@QFN20(ISP) [ISP-HEADER01]
PIC16HV785@SOIC20 [(SA404)]
PIC16HV785@SOIC20(ISP) [ISP-HEADER01]
PIC16HV785@SSOP20 [(SA626A)]
PIC16HV785@SSOP20(ISP) [ISP-HEADER01]
PIC16LC505 PIC16LC505@SOIC14
[(SA602)]
PIC16LC54A PIC16LC54A@SOIC18
[(SA404)]
PIC16LC54A@SSOP20 [(SA626A)]
PIC16LC54C PIC16LC54C@SSOP20
PIC16LC54C@SOIC18 [(SA404)]
[(SA626A)]
PIC16LC554 PIC16LC554(ISP) [ISP-
HEADER01]
PIC16LC554@SOIC18 [(SA404)]
PIC16LC554@SOIC18(ISP) [ISP-HEADER01]
PIC16LC558 PIC16LC558(ISP) [ISP-
HEADER01]
PIC16LC558@SOIC18 [(SA404)]
PIC16LC558@SOIC18(ISP) [ISP-HEADER01]
PIC16LC56A PIC16LC56A@SOIC18
[(SA404)]
PIC16LC56A@SSOP20 [(SA626A)]
PIC16LC58A PIC16LC58A@SSOP20
PIC16LC58A@SOIC18 [(SA404)]
[(SA626A)]

PIC16LC58B PIC16LC58B@SOIC18
[(SA404)]
PIC16LC58B@SSOP20 [(SA626A)]
PIC16LC620
PIC16LC620(ISP) [ISP-HEADER01] PIC16LC620@SOIC18
[(SA404)]
PIC16LC620@SOIC18(ISP) [ISP-HEADER01]
PIC16LC620A PIC16LC620A(ISP) [ISP-
HEADER01]
PIC16LC620A@SOIC18 [(SA404)]
PIC16LC620A@SOIC18(ISP) [ISP-HEADER01]
PIC16LC620A@SSOP20 [(SA626A)]
PIC16LC620A@SSOP20(ISP) [ISP-HEADER01]
PIC16LC621A PIC16LC621A(ISP) [ISP-
HEADER01]
PIC16LC621A@SOIC18 [(SA404)]
PIC16LC621A@SOIC18(ISP) [ISP-HEADER01]
PIC16LC621A@SSOP20 [(SA626A)]
PIC16LC621A@SSOP20(ISP) [ISP-HEADER01]
PIC16LC622 PIC16LC622(ISP) [ISP-
HEADER01]
PIC16LC622@SOIC18 [(SA404)]
PIC16LC622@SOIC18(ISP) [ISP-HEADER01]
PIC16LC62A PIC16LC62A(ISP) [ISP-
HEADER01]
PIC16LC62A@SOIC28 [(SA404)]
PIC16LC62A@SOIC28(ISP) [ISP-HEADER01]
PIC16LC62A@SSOP28 [(SA626A)]
PIC16LC62A@SSOP28(ISP) [ISP-HEADER01]
PIC16LC62B PIC16LC62B(ISP) [ISP-
HEADER01]
PIC16LC62B@SOIC28 [(SA404)]
PIC16LC62B@SOIC28(ISP) [ISP-HEADER01]
PIC16LC62B@SSOP28 [(SA626A)]
PIC16LC62B@SSOP28(ISP) [ISP-HEADER01]
PIC16LC63 PIC16LC63(ISP) [ISP-
HEADER01]
PIC16LC63@SOIC28 [(SA404)]
PIC16LC63@SOIC28(ISP) [ISP-HEADER01]
PIC16LC63A PIC16LC63A(ISP) [ISP-
HEADER01]
PIC16LC63A@SOIC28 [(SA404)]
PIC16LC63A@SOIC28(ISP) [ISP-HEADER01]

PIC16LC63A@SSOP28 [(SA626A)]
PIC16LC63A@SSOP28(ISP) [ISP-HEADER01]
PIC16LC64A PIC16LC64A(ISP) [ISP-
HEADER01]
PIC16LC64A@PLCC44 [(SA244)]
PIC16LC64A@PLCC44(ISP) [ISP-HEADER01]
PIC16LC64A@TQFP44 [(SA245A)]
PIC16LC64A@TQFP44(ISP) [ISP-HEADER01]
PIC16LC65A PIC16LC65A(ISP) [ISP-
HEADER01]
PIC16LC65A@PLCC44 [(SA244)]
PIC16LC65A@PLCC44(ISP) [ISP-HEADER01]
PIC16LC65A@TQFP44 [(SA245A)]
PIC16LC65A@TQFP44(ISP) [ISP-HEADER01]
PIC16LC65B PIC16LC65B(ISP) [ISP-
HEADER01]
PIC16LC65B@PLCC44 [(SA244)]
PIC16LC65B@PLCC44(ISP) [ISP-HEADER01]
PIC16LC65B@TQFP44 [(SA245A)]
PIC16LC65B@TQFP44(ISP) [ISP-HEADER01]
PIC16LC66 PIC16LC66(ISP) [ISP-
HEADER01]
PIC16LC66@SOIC28 [(SA404)]
PIC16LC66@SOIC28(ISP) [ISP-HEADER01]
PIC16LC67 PIC16LC67(ISP) [ISP-
HEADER01]
PIC16LC67@PLCC44 [(SA244)]
PIC16LC67@PLCC44(ISP) [ISP-HEADER01]
PIC16LC67@TQFP44 [(SA245A)]
PIC16LC67@TQFP44(ISP) [ISP-HEADER01]
PIC16LC71 PIC16LC71(ISP) [ISP-
HEADER01]
PIC16LC71@SOIC18 [(SA404)]
PIC16LC71@SOIC18(ISP) [ISP-HEADER01]
PIC16LC710 PIC16LC710(ISP) [ISP-
HEADER01]
PIC16LC710@SOIC18 [(SA404)]
PIC16LC710@SOIC18(ISP) [ISP-HEADER01]
PIC16LC710@SSOP20 [(SA626A)]
PIC16LC710@SSOP20(ISP) [ISP-HEADER01]
PIC16LC711 PIC16LC711(ISP) [ISP-
HEADER01]
PIC16LC711@SOIC18 [(SA404)]

PIC16LC711@SOIC18(ISP) [ISP-HEADER01]
PIC16LC711@SSOP20 [(SA626A)]
PIC16LC711@SSOP20(ISP) [ISP-HEADER01]
PIC16LC712 PIC16LC712(ISP) [ISP-
HEADER01]
PIC16LC712@SOIC18 [(SA404)]
PIC16LC712@SOIC18(ISP) [ISP-HEADER01]
PIC16LC712@SSOP20 [(SA626A)]
PIC16LC712@SSOP20(ISP) [ISP-HEADER01]
PIC16LC715 PIC16LC715@SOIC18
[(SA404)]
PIC16LC716 PIC16LC716(ISP) [ISP-
HEADER01]
PIC16LC716@SOIC18 [(SA404)]
PIC16LC716@SOIC18(ISP) [ISP-HEADER01]
PIC16LC716@SSOP20 [(SA626A)]
PIC16LC716@SSOP20(ISP) [ISP-HEADER01]
PIC16LC717 PIC16LC717(ISP) [ISP-
HEADER01]
PIC16LC717@SOIC18 [(SA404)]
PIC16LC717@SOIC18(ISP) [ISP-HEADER01]
PIC16LC717@SSOP20 [(SA626A)]
PIC16LC717@SSOP20(ISP) [ISP-HEADER01]
PIC16LC72 PIC16LC72(ISP) [ISP-
HEADER01]
PIC16LC72@SOIC28 [(SA404)]
PIC16LC72@SOIC28(ISP) [ISP-HEADER01]
PIC16LC72@SSOP28 [(SA626A)]
PIC16LC72@SSOP28(ISP) [ISP-HEADER01]
PIC16LC72A PIC16LC72A(ISP) [ISP-
HEADER01]
PIC16LC72A@SOIC28 [(SA404)]
PIC16LC72A@SOIC28(ISP) [ISP-HEADER01]
PIC16LC72A@SSOP28 [(SA626A)]
PIC16LC72A@SSOP28(ISP) [ISP-HEADER01]
PIC16LC73A PIC16LC73A(ISP) [ISP-
HEADER01]
PIC16LC73A@SOIC28 [(SA404)]
PIC16LC73A@SOIC28(ISP) [ISP-HEADER01]
PIC16LC73B PIC16LC73B(ISP) [ISP-
HEADER01]
PIC16LC73B@SOIC28 [(SA404)]
PIC16LC73B@SOIC28(ISP) [ISP-HEADER01]

PIC16LC73B@SSOP28 [(SA626A)]
PIC16LC73B@SSOP28(ISP) [ISP-HEADER01]
PIC16LC74 PIC16LC74(ISP) [ISP-
HEADER01]
PIC16LC74@PLCC44 [(SA244)]
PIC16LC74@PLCC44(ISP) [ISP-HEADER01]
PIC16LC74@TQFP44 [(SA245A)]
PIC16LC74@TQFP44(ISP) [ISP-HEADER01]
PIC16LC74A PIC16LC74A(ISP) [ISP-
HEADER01]
PIC16LC74A@PLCC44 [(SA244)]
PIC16LC74A@PLCC44(ISP) [ISP-HEADER01]
PIC16LC74A@TQFP44 [(SA245A)]
PIC16LC74A@TQFP44(ISP) [ISP-HEADER01]
PIC16LC74B PIC16LC74B(ISP) [ISP-
HEADER01]
PIC16LC74B@MQFP44 [(SA675)]
PIC16LC74B@MQFP44(ISP) [ISP-HEADER01]
PIC16LC74B@PLCC44 [(SA244)]
PIC16LC74B@PLCC44(ISP) [ISP-HEADER01]
PIC16LC74B@TQFP44 [(SA245A)]
PIC16LC74B@TQFP44(ISP) [ISP-HEADER01]
PIC16LC76 PIC16LC76(ISP) [ISP-
HEADER01]
PIC16LC76@SOIC28 [(SA404)]
PIC16LC76@SOIC28(ISP) [ISP-HEADER01]
PIC16LC77 PIC16LC77(ISP) [ISP-
HEADER01]
PIC16LC77@PLCC44 [(SA244)]
PIC16LC77@PLCC44(ISP) [ISP-HEADER01]
PIC16LC773 PIC16LC773(ISP) [ISP-
HEADER01]
PIC16LC773@SOIC28 [(SA404)]
PIC16LC773@SOIC28(ISP) [ISP-HEADER01]
PIC16LC773@SSOP28 [(SA626A)]
PIC16LC773@SSOP28(ISP) [ISP-HEADER01]
PIC16LC774 PIC16LC774(ISP) [ISP-
HEADER01]
PIC16LC774@PLCC44 [(SA244)]
PIC16LC774@PLCC44(ISP) [ISP-HEADER01]
PIC16LC774@TQFP44 [(SA675)]
PIC16LC774@TQFP44(ISP) [ISP-HEADER01]
PIC16LC84 PIC16LC84(ISP) [ISP-

HEADER01]

PIC16LC84@SOIC18 [(SA404)]

PIC16LC84@SOIC18(ISP) [ISP-HEADER01]

PIC16LC923@PLCC68(*) [(SA648-B6807)]

PIC16LC923@PLCC68(ISP) [ISP-HEADER01]

PIC16LC923@SDIP64(ISP) [ISP-HEADER01]

PIC16LC923@TQFP64(ISP) [ISP-HEADER01]

PIC16LC924@PLCC68(*) [(SA648-B6807)]

PIC16LC924@PLCC68(ISP) [ISP-HEADER01]

PIC16LC924@SDIP64(ISP) [ISP-HEADER01]

PIC16LC924@TQFP64(ISP) [ISP-HEADER01]

PIC16LC925@PLCC68(*) [(SA648-B6807)]

PIC16LC925@PLCC68(ISP) [ISP-HEADER01]

PIC16LC925@TQFP64(ISP) [ISP-HEADER01]

PIC16LC926@PLCC68(*) [(SA648-B6807)]

PIC16LC926@PLCC68(ISP) [ISP-HEADER01]

PIC16LC926@TQFP64(ISP) [ISP-HEADER01]

PIC16LCE623@SOIC18 [(SA404)]

PIC16LCE623@SOIC18(ISP) [ISP-HEADER01]

PIC16LCE623@SSOP20 [(SA626A)]

PIC16LCE623@SSOP20(ISP) [ISP-HEADER01]

PIC16LF505 PIC16LF505(ISP) [ISP-
HEADER01]

PIC16LF505@SOIC14 [(SA602)]

PIC16LF505@SOIC14(ISP) [ISP-HEADER01]

PIC16LF505@TSSOP14 [(SA026)]

PIC16LF505@TSSOP14(ISP) [ISP-HEADER01]

PIC16LF506 PIC16LF506(ISP) [ISP-
HEADER01]

PIC16LF506@SOIC14 [(SA602)]

PIC16LF506@SOIC14(ISP) [ISP-HEADER01]

PIC16LF506@TSSOP14 [(SA026)]

PIC16LF506@TSSOP14(ISP) [ISP-HEADER01]

PIC16LF526 PIC16LF526@SOIC14
[(SA602)]

PIC16LF526@TSSOP14 [(SA026)]

PIC16LF54

PIC16LF54(ISP) [ISP-HEADER01] PIC16LF54@SOIC18
[(SA404)]

PIC16LF54@SOIC18(ISP) [ISP-HEADER01]

PIC16LF54@SSOP20 [(SA626A)]

PIC16LF54@SSOP20(ISP) [ISP-HEADER01]

PIC16LF57 PIC16LF57(ISP) [ISP-

HEADER01]
PIC16LF57@SOIC28 [(SA404)]
PIC16LF57@SOIC28(ISP) [ISP-HEADER01]
PIC16LF57@SSOP28 [(SA626A)]
PIC16LF57@SSOP28(ISP) [ISP-HEADER01]
PIC16LF59 PIC16LF59(ISP) [ISP-
HEADER01]
PIC16LF59@PLCC44 [(SA244)]
PIC16LF59@PLCC44(ISP) [ISP-HEADER01]
PIC16LF59@TQFP44 [(SA245A)]
PIC16LF59@TQFP44(ISP) [ISP-HEADER01]
PIC16LF627 PIC16LF627(ISP) [ISP-
HEADER01]
PIC16LF627@SOIC18 [(SA404)]
PIC16LF627@SOIC18(ISP) [ISP-HEADER01]
PIC16LF627@SSOP20 [(SA626A)]
PIC16LF627@SSOP20(ISP) [ISP-HEADER01]
PIC16LF627A PIC16LF627A(ISP) [ISP-
HEADER01]
PIC16LF627A@SOIC18 [(SA404)]
PIC16LF627A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF627A@SSOP20 [(SA626A)]
PIC16LF627A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF628 PIC16LF628(ISP) [ISP-
HEADER01]
PIC16LF628@SOIC18 [(SA404)]
PIC16LF628@SOIC18(ISP) [ISP-HEADER01]
PIC16LF628@SSOP20 [(SA626A)]
PIC16LF628@SSOP20(ISP) [ISP-HEADER01]
PIC16LF628A PIC16LF628A(ISP) [ISP-
HEADER01]
PIC16LF628A@SOIC18 [(SA404)]
PIC16LF628A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF628A@SSOP20 [(SA626A)]
PIC16LF628A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF631 PIC16LF631(ISP) [ISP-
HEADER01]
PIC16LF631@QFN20 [(SA692)]
PIC16LF631@QFN20(ISP) [ISP-HEADER01]
PIC16LF631@SOIC20 [(SA404)]
PIC16LF631@SOIC20(ISP) [ISP-HEADER01]
PIC16LF631@SSOP20 [(SA626A)]
PIC16LF631@SSOP20(ISP) [ISP-HEADER01]

PIC16LF639 PIC16LF639(ISP) [ISP-
HEADER01]
PIC16LF639@QFN20 [(SA692)]
PIC16LF639@QFN20(ISP) [ISP-HEADER01]
PIC16LF639@SOIC20 [(SA404)]
PIC16LF639@SOIC20(ISP) [ISP-HEADER01]
PIC16LF639@SSOP20 [(SA626A)]
PIC16LF639@SSOP20(ISP) [ISP-HEADER01]
PIC16LF648A PIC16LF648A(ISP) [ISP-
HEADER01]
PIC16LF648A@SOIC18 [(SA404)]
PIC16LF648A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF648A@SSOP20 [(SA626A)]
PIC16LF648A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF677 PIC16LF677(ISP) [ISP-
HEADER01]
PIC16LF677@QFN20 [(SA692)]
PIC16LF677@QFN20(ISP) [ISP-HEADER01]
PIC16LF677@SOIC20 [(SA404)]
PIC16LF677@SOIC20(ISP) [ISP-HEADER01]
PIC16LF677@SSOP20 [(SA626A)]
PIC16LF677@SSOP20(ISP) [ISP-HEADER01]
PIC16LF685 PIC16LF685(ISP) [ISP-
HEADER01]
PIC16LF685@QFN20 [(SA692)]
PIC16LF685@QFN20(ISP) [ISP-HEADER01]
PIC16LF685@SOIC20 [(SA404)]
PIC16LF685@SOIC20(ISP) [ISP-HEADER01]
PIC16LF685@SSOP20 [(SA626A)]
PIC16LF685@SSOP20(ISP) [ISP-HEADER01]
PIC16LF687 PIC16LF687(ISP) [ISP-
HEADER01]
PIC16LF687@QFN20 [(SA692)]
PIC16LF687@QFN20(ISP) [ISP-HEADER01]
PIC16LF687@SOIC20 [(SA404)]
PIC16LF687@SOIC20(ISP) [ISP-HEADER01]
PIC16LF687@SSOP20 [(SA626A)]
PIC16LF687@SSOP20(ISP) [ISP-HEADER01]
PIC16LF689 PIC16LF689(ISP) [ISP-
HEADER01]
PIC16LF689@QFN20 [(SA692)]
PIC16LF689@QFN20(ISP) [ISP-HEADER01]
PIC16LF689@SOIC20 [(SA404)]

PIC16LF689@SOIC20 (ISP) [ISP-HEADER01]
PIC16LF689@SSOP20 [(SA626A)]
PIC16LF689@SSOP20 (ISP) [ISP-HEADER01]
PIC16LF690 PIC16LF690 (ISP) [ISP-
HEADER01]
PIC16LF690@QFN20 [(SA692)]
PIC16LF690@QFN20 (ISP) [ISP-HEADER01]
PIC16LF690@SOIC20 [(SA404)]
PIC16LF690@SOIC20 (ISP) [ISP-HEADER01]
PIC16LF690@SSOP20 [(SA626A)]
PIC16LF690@SSOP20 (ISP) [ISP-HEADER01]
PIC16LF716 PIC16LF716 (ISP) [ISP-
HEADER01]
PIC16LF716@SOIC18 [(SA404)]
PIC16LF716@SOIC18 (ISP) [ISP-HEADER01]
PIC16LF716@SSOP20 [(SA626A)]
PIC16LF716@SSOP20 (ISP) [ISP-HEADER01]
PIC16LF72 PIC16LF72 (ISP) [ISP-
HEADER01]
PIC16LF72@QFN28 [(SA685-B006)]
PIC16LF72@QFN28 (ISP) [ISP-HEADER01]
PIC16LF72@SOIC28 [(SA404)]
PIC16LF72@SOIC28 (ISP) [ISP-HEADER01]
PIC16LF72@SSOP28 [(SA626A)]
PIC16LF72@SSOP28 (ISP) [ISP-HEADER01]
PIC16LF722 PIC16LF722@QFN28 [(SA685-
B006)]
PIC16LF722@SOIC28 [(SA404)] PIC16LF722@SSOP28
[(SA626A)]
PIC16LF723 PIC16LF723@QFN28 [(SA685-
B006)]
PIC16LF723@SOIC28 [(SA404)] PIC16LF723@SSOP28
[(SA626A)]
PIC16LF724 PIC16LF724@QFN44
[(SA737)]
PIC16LF724@TQFP44 [(SA245A)]
PIC16LF726 PIC16LF726@SOIC28
PIC16LF726@QFN28 [(SA685-B006)]
[(SA404)]
PIC16LF726@SSOP28 [(SA626A)]
PIC16LF727 PIC16LF727@TQFP44
PIC16LF727@QFN44 [(SA737)]
[(SA245A)]

PIC16LF73 PIC16LF73(ISP) [ISP-
HEADER01]
PIC16LF73@SOIC28 [(SA404)]
PIC16LF73@SOIC28(ISP) [ISP-HEADER01]
PIC16LF73@SSOP28 [(SA626A)]
PIC16LF73@SSOP28(ISP) [ISP-HEADER01]
PIC16LF737 PIC16LF737(ISP) [ISP-
HEADER01]
PIC16LF737@SOIC28 [(SA404)]
PIC16LF737@SOIC28(ISP) [ISP-HEADER01]
PIC16LF737@SSOP28 [(SA626A)]
PIC16LF737@SSOP28(ISP) [ISP-HEADER01]
PIC16LF74 PIC16LF74(ISP) [ISP-
HEADER01]
PIC16LF74@PLCC44 [(SA244)]
PIC16LF74@PLCC44(ISP) [ISP-HEADER01]
PIC16LF74@TQFP44 [(SA245A)]
PIC16LF74@TQFP44(ISP) [ISP-HEADER01]
PIC16LF747 PIC16LF747(ISP) [ISP-
HEADER01]
PIC16LF747@TQFP44 [(SA245A)]
PIC16LF747@TQFP44(ISP) [ISP-HEADER01]
PIC16LF76 PIC16LF76(ISP) [ISP-
HEADER01]
PIC16LF76@SOIC28 [(SA404)]
PIC16LF76@SOIC28(ISP) [ISP-HEADER01]
PIC16LF76@SSOP28 [(SA626A)]
PIC16LF76@SSOP28(ISP) [ISP-HEADER01]
PIC16LF767 PIC16LF767(ISP) [ISP-
HEADER01]
PIC16LF767@SOIC28 [(SA404)]
PIC16LF767@SOIC28(ISP) [ISP-HEADER01]
PIC16LF767@SSOP28 [(SA626A)]
PIC16LF767@SSOP28(ISP) [ISP-HEADER01]
PIC16LF77 PIC16LF77(ISP) [ISP-
HEADER01]
PIC16LF77@PLCC44 [(SA244)]
PIC16LF77@PLCC44(ISP) [ISP-HEADER01]
PIC16LF77@TQFP44 [(SA245A)]
PIC16LF77@TQFP44(ISP) [ISP-HEADER01]
PIC16LF777 PIC16LF777(ISP) [ISP-
HEADER01]
PIC16LF777@TQFP44 [(SA245A)]

PIC16LF777@TQFP44(ISP) [ISP-HEADER01]
PIC16LF818 PIC16LF818(ISP) [ISP-
HEADER01]
PIC16LF818@QFN28 [(SA685-B006)]
PIC16LF818@QFN28(ISP) [ISP-HEADER01]
PIC16LF818@SOIC18 [(SA404)]
PIC16LF818@SOIC18(ISP) [ISP-HEADER01]
PIC16LF818@SSOP20 [(SA626A)]
PIC16LF818@SSOP20(ISP) [ISP-HEADER01]
PIC16LF819 PIC16LF819(ISP) [ISP-
HEADER01]
PIC16LF819@QFN28 [(SA685-B006)]
PIC16LF819@QFN28(ISP) [ISP-HEADER01]
PIC16LF819@SOIC18 [(SA404)]
PIC16LF819@SOIC18(ISP) [ISP-HEADER01]
PIC16LF819@SSOP20 [(SA626A)]
PIC16LF819@SSOP20(ISP) [ISP-HEADER01]
PIC16LF83 PIC16LF83(ISP) [ISP-
HEADER01]
PIC16LF83@SOIC18 [(SA404)]
PIC16LF83@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84 PIC16LF84(ISP) [ISP-
HEADER01]
PIC16LF84@SOIC18 [(SA404)]
PIC16LF84@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84A PIC16LF84A(ISP) [ISP-
HEADER01]
PIC16LF84A@SOIC18 [(SA404)]
PIC16LF84A@SOIC18(ISP) [ISP-HEADER01]
PIC16LF84A@SSOP20 [(SA626A)]
PIC16LF84A@SSOP20(ISP) [ISP-HEADER01]
PIC16LF87 PIC16LF87(ISP) [ISP-
HEADER01]
PIC16LF87@QFN28 [(SA685-B006)]
PIC16LF87@QFN28(ISP) [ISP-HEADER01]
PIC16LF87@SOIC18 [(SA404)]
PIC16LF87@SOIC18(ISP) [ISP-HEADER01]
PIC16LF87@SSOP20 [(SA626A)]
PIC16LF87@SSOP20(ISP) [ISP-HEADER01]
PIC16LF870 PIC16LF870(ISP) [ISP-
HEADER01]
PIC16LF870@SOIC28 [(SA404)]
PIC16LF870@SOIC28(ISP) [ISP-HEADER01]

PIC16LF870@SSOP28 [(SA626A)]
PIC16LF870@SSOP28(ISP) [ISP-HEADER01]
PIC16LF871 PIC16LF871(ISP) [ISP-
HEADER01]
PIC16LF871@PLCC44 [(SA244)]
PIC16LF871@PLCC44(ISP) [ISP-HEADER01]
PIC16LF871@TQFP44 [(SA245A)]
PIC16LF871@TQFP44(ISP) [ISP-HEADER01]
PIC16LF872 PIC16LF872(ISP) [ISP-
HEADER01]
PIC16LF872@SOIC28 [(SA404)]
PIC16LF872@SOIC28(ISP) [ISP-HEADER01]
PIC16LF872@SSOP28 [(SA626A)]
PIC16LF872@SSOP28(ISP) [ISP-HEADER01]
PIC16LF873 PIC16LF873(ISP) [ISP-
HEADER01]
PIC16LF873@SOIC28 [(SA404)]
PIC16LF873@SOIC28(ISP) [ISP-HEADER01]
PIC16LF873A
PIC16LF873A(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@QFN28 [(SA697-B006)]
PIC16LF873A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@SOIC28 [(SA404)]
PIC16LF873A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF873A@SSOP28 [(SA626A)]
PIC16LF873A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874 PIC16LF874(ISP) [ISP-
HEADER01]
PIC16LF874@PLCC44 [(SA244)]
PIC16LF874@PLCC44(ISP) [ISP-HEADER01]
PIC16LF874@TQFP44 [(SA245A)]

PIC16LF874@TQFP44(ISP) [ISP-HEADER01]
PIC16LF874A
PIC16LF874A(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874A@PLCC44 [(SA244)]
PIC16LF874A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF874A@TQFP44 [(SA245A)]
PIC16LF874A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876 PIC16LF876(ISP) [ISP-
HEADER01]
PIC16LF876@SOIC28 [(SA404)]
PIC16LF876@SOIC28(ISP) [ISP-HEADER01]
PIC16LF876A
PIC16LF876A(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876A@QFN28 [(SA697-B006)]
PIC16LF876A@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876A@SOIC28 [(SA404)]
PIC16LF876A@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF876A@SSOP28 [(SA626A)]
PIC16LF876A@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC16LF876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC16LF876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF877 PIC16LF877(ISP) [ISP-
HEADER01]
PIC16LF877@PLCC44 [(SA244)]

PIC16LF877@PLCC44(ISP) [ISP-HEADER01]
PIC16LF877@TQFP44 [(SA245A)]
PIC16LF877@TQFP44(ISP) [ISP-HEADER01]
PIC16LF877A
PIC16LF877A(ISP)(High-V) [ISP-HEADER01]
PIC16LF877A(ISP)(Low-V) [ISP-HEADER01]
PIC16LF877A(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF877A(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF877A@PLCC44 [(SA244)]
PIC16LF877A@PLCC44(ISP)(High-V) [ISP-HEADER01]
PIC16LF877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF877A@TQFP44 [(SA245A)]
PIC16LF877A@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC16LF877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC16LF877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]
PIC16LF877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]
PIC16LF88 PIC16LF88(ISP) [ISP-
HEADER01]
PIC16LF88@QFN28 [(SA685-B006)]
PIC16LF88@QFN28(ISP) [ISP-HEADER01]
PIC16LF88@SOIC18 [(SA404)]
PIC16LF88@SOIC18(ISP) [ISP-HEADER01]
PIC16LF88@SSOP20 [(SA626A)]
PIC16LF88@SSOP20(ISP) [ISP-HEADER01]
PIC16LF913 PIC16LF913(ISP) [ISP-
HEADER01]
PIC16LF913@QFN28 [(SA697-B006)]
PIC16LF913@QFN28(ISP) [ISP-HEADER01]
PIC16LF913@SOIC28 [(SA404)]
PIC16LF913@SOIC28(ISP) [ISP-HEADER01]
PIC16LF913@SSOP28 [(SA626A)]
PIC16LF913@SSOP28(ISP) [ISP-HEADER01]
PIC16LF914 PIC16LF914(ISP) [ISP-
HEADER01]
PIC16LF914@QFN44 [(SA712)]
PIC16LF914@QFN44(ISP) [ISP-HEADER01]
PIC16LF914@QFN44(ML) [(SA737)]
PIC16LF914@QFN44(ML)(ISP) [ISP-HEADER01]
PIC16LF914@TQFP44 [(SA245A)]
PIC16LF914@TQFP44(ISP) [ISP-HEADER01]
PIC16LF916 PIC16LF916(ISP) [ISP-

HEADER01]

PIC16LF916@QFN28 [(SA697-B006)]

PIC16LF916@QFN28(ISP) [ISP-HEADER01]

PIC16LF916@SOIC28 [(SA404)]

PIC16LF916@SOIC28(ISP) [ISP-HEADER01]

PIC16LF916@SSOP28 [(SA626A)]

PIC16LF916@SSOP28(ISP) [ISP-HEADER01]

PIC16LF917 PIC16LF917(ISP) [ISP-
HEADER01]

PIC16LF917@QFN44 [(SA712)]

PIC16LF917@QFN44(ISP) [ISP-HEADER01]

PIC16LF917@QFN44(ML) [(SA737)]

PIC16LF917@QFN44(ML)(ISP) [ISP-HEADER01]

PIC16LF917@TQFP44 [(SA245A)]

PIC16LF917@TQFP44(ISP) [ISP-HEADER01]

PIC16LF946@TQFP64(ISP) [ISP-HEADER01]

PIC16LV54A PIC16LV54A@SOIC18
[(SA404)]

PIC16LV54A@SSOP20 [(SA626A)]

PIC16LV58A

PIC16LV58A@SOIC18 [(SA404)] PIC16LV58A@SSOP20
[(SA626A)]

PIC17C42 PIC17C42@PLCC44

[(SA244)]

PIC17C42@TQFP44 [(SA245A)]

PIC17C42A

PIC17C42A@PLCC44 [(SA244)] PIC17C42A@TQFP44
[(SA245A)]

PIC17C43 PIC17C43@PLCC44

[(SA244)]

PIC17C43@TQFP44 [(SA245A)]

PIC17C44

PIC17C44@PLCC44 [(SA244)] PIC17C44@TQFP44
[(SA245A)]

PIC17LC42 PIC17LC42@PLCC44

[(SA244)]

PIC17LC42@TQFP44 [(SA245A)]

PIC17LC42A

PIC17LC42A@PLCC44 [(SA244)] PIC17LC42A@TQFP44
[(SA245A)]

PIC17LC43 PIC17LC43@PLCC44

[(SA244)]

PIC17LC43@TQFP44 [(SA245A)]

PIC17LC44
PIC17LC44@PLCC44 [(SA244)] PIC17LC44@TQFP44
[(SA245A)]
PIC18C242 PIC18C242@SOIC28
[(SA404)]
PIC18C252 PIC18C252@SOIC28
[(SA404)]
PIC18C442 PIC18C442@PLCC44
[(SA244)]
PIC18C442@TQFP44 [(SA245A)]
PIC18C452
PIC18C452@PLCC44 [(SA244)] PIC18C452@TQFP44
[(SA245A)]
PIC18F1220 PIC18F1220(ISP) [ISP-
HEADER01]
PIC18F1220@SOIC18 [(SA404)]
PIC18F1220@SOIC18(ISP) [ISP-HEADER01]
PIC18F1220@SSOP20 [(SA626A)]
PIC18F1220@SSOP20(ISP) [ISP-HEADER01]
PIC18F1230 PIC18F1230(ISP) [ISP-
HEADER01]
PIC18F1230@QFN28 [(SA685-B006)]
PIC18F1230@QFN28(ISP) [ISP-HEADER01]
PIC18F1230@SOIC18 [(SA404)]
PIC18F1230@SOIC18(ISP) [ISP-HEADER01]
PIC18F1230@SSOP20 [(SA626A)]
PIC18F1230@SSOP20(ISP) [ISP-HEADER01]
PIC18F1320 PIC18F1320(ISP) [ISP-
HEADER01]
PIC18F1320@SOIC18 [(SA404)]
PIC18F1320@SOIC18(ISP) [ISP-HEADER01]
PIC18F1320@SSOP20 [(SA626A)]
PIC18F1320@SSOP20(ISP) [ISP-HEADER01]
PIC18F1330 PIC18F1330(ISP) [ISP-
HEADER01]
PIC18F1330@QFN28 [(SA685-B006)]
PIC18F1330@QFN28(ISP) [ISP-HEADER01]
PIC18F1330@SOIC18 [(SA404)]
PIC18F1330@SOIC18(ISP) [ISP-HEADER01]
PIC18F1330@SSOP20 [(SA626A)]
PIC18F1330@SSOP20(ISP) [ISP-HEADER01]
PIC18F1330-ICD@QFN28 [(SA685-B006)]
PIC18F1330-ICD@QFN28(ISP) [ISP-HEADER01]

PIC18F2220 PIC18F2220(ISP) [ISP-
HEADER01]
PIC18F2220@SOIC28 [(SA404)]
PIC18F2220@SOIC28(ISP) [ISP-HEADER01]
PIC18F2221
PIC18F2221(ISP)(Low-V) [ISP-HEADER01]
PIC18F2221@QFN28 [(SA685-B006)]
PIC18F2221@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2221@SOIC28 [(SA404)]
PIC18F2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2320 PIC18F2320(ISP) [ISP-
HEADER01]
PIC18F2320@SOIC28 [(SA404)]
PIC18F2320@SOIC28(ISP) [ISP-HEADER01]
PIC18F2321
PIC18F2321(ISP)(Low-V) [ISP-HEADER01]
PIC18F2321@QFN28 [(SA685-B006)]
PIC18F2321@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2321@SOIC28 [(SA404)]
PIC18F2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2331 PIC18F2331(ISP) [ISP-
HEADER01]
PIC18F2331@SOIC28 [(SA404)]
PIC18F2331@SOIC28(ISP) [ISP-HEADER01]
PIC18F23K20
PIC18F23K20(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@QFN28 [(SA685-B006)]
PIC18F23K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@SOIC28 [(SA404)]
PIC18F23K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F23K20@SSOP28 [(SA626A)]
PIC18F23K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F23K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410
PIC18F2410(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410@QFN28 [(SA685-B006)]
PIC18F2410@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2410@SOIC28 [(SA404)]
PIC18F2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F242 PIC18F242(ISP) [ISP-

HEADER01]
PIC18F242@SOIC28 [(SA404)]
PIC18F242@SOIC28(ISP) [ISP-HEADER01]
PIC18F2420
PIC18F2420(ISP)(High-V) [ISP-HEADER01]
PIC18F2420(ISP)(Low-V) [ISP-HEADER01]
PIC18F2420@SOIC28 [(SA404)]
PIC18F2420@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423
PIC18F2423(ISP)(High-V) [ISP-HEADER01]
PIC18F2423(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423@QFN28 [(SA685-B006)]
PIC18F2423@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2423@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2423@SOIC28 [(SA404)]
PIC18F2423@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2423@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2431 PIC18F2431(ISP) [ISP-
HEADER01]
PIC18F2431@SOIC28 [(SA404)]
PIC18F2431@SOIC28(ISP) [ISP-HEADER01]
PIC18F2439 PIC18F2439(ISP) [ISP-
HEADER01]
PIC18F2439@SOIC28 [(SA404)]
PIC18F2439@SOIC28(ISP) [ISP-HEADER01]
PIC18F2450
PIC18F2450(ISP)(Low-V) [ISP-HEADER01]
PIC18F2450@QFN28 [(SA685-B006)]
PIC18F2450@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2450@SOIC28 [(SA404)]
PIC18F2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2455
PIC18F2455(ISP)(High-V) [ISP-HEADER01]
PIC18F2455(ISP)(Low-V) [ISP-HEADER01]
PIC18F2455@SOIC28 [(SA404)]
PIC18F2455@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458
PIC18F2458(ISP)(High-V) [ISP-HEADER01]
PIC18F2458(ISP)(Low-V) [ISP-HEADER01]
PIC18F2458@SOIC28 [(SA404)]
PIC18F2458@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC18F2458@SOIC28 (ISP) (Low-V) [ISP-HEADER01]
PIC18F2458@SSOP28 [(SA626A)]
PIC18F2458@SSOP28 (ISP) (High-V) [ISP-HEADER01]
PIC18F2458@SSOP28 (ISP) (Low-V) [ISP-HEADER01]
PIC18F248 PIC18F248 (ISP) [ISP-
HEADER01]
PIC18F248@SOIC28 [(SA404)]
PIC18F248@SOIC28 (ISP) [ISP-HEADER01]
PIC18F2480
PIC18F2480 (ISP) (High-V) [ISP-HEADER01]
PIC18F2480 (ISP) (Low-V) [ISP-HEADER01]
PIC18F2480@QFN28 [(SA685-B006)]
PIC18F2480@QFN28 (ISP) (High-V) [ISP-HEADER01]
PIC18F2480@QFN28 (ISP) (Low-V) [ISP-HEADER01]
PIC18F2480@SOIC28 [(SA404)]
PIC18F2480@SOIC28 (ISP) (High-V) [ISP-HEADER01]
PIC18F2480@SOIC28 (ISP) (Low-V) [ISP-HEADER01]
PIC18F24J10 PIC18F24J10 (ISP) [ISP-
HEADER01]
PIC18F24J10@QFN28 [(SA685-B006)]
PIC18F24J10@QFN28 (ISP) [ISP-HEADER01]
PIC18F24J10@SOIC28 [(SA404)]
PIC18F24J10@SOIC28 (ISP) [ISP-HEADER01]
PIC18F24J10@SSOP28 [(SA626A)]
PIC18F24J10@SSOP28 (ISP) [ISP-HEADER01]
PIC18F24K20
PIC18F24K20 (ISP) (High-V) [ISP-HEADER01]
PIC18F24K20 (ISP) (Low-V) [ISP-HEADER01]
PIC18F24K20@QFN28 [(SA685-B006)]
PIC18F24K20@QFN28 (ISP) (High-V) [ISP-HEADER01]
PIC18F24K20@QFN28 (ISP) (Low-V) [ISP-HEADER01]
PIC18F24K20@SOIC28 [(SA404)]
PIC18F24K20@SOIC28 (ISP) (High-V) [ISP-HEADER01]
PIC18F24K20@SOIC28 (ISP) (Low-V) [ISP-HEADER01]
PIC18F24K20@SSOP28 [(SA626A)]
PIC18F24K20@SSOP28 (ISP) (High-V) [ISP-HEADER01]
PIC18F24K20@SSOP28 (ISP) (Low-V) [ISP-HEADER01]
PIC18F2510 PIC18F2510 (ISP) [ISP-
HEADER01]
PIC18F2510@QFN28 [(SA685-B006)]
PIC18F2510@QFN28 (ISP) [ISP-HEADER01]
PIC18F2510@SOIC28 [(SA404)]
PIC18F2510@SOIC28 (ISP) [ISP-HEADER01]

PIC18F2515
PIC18F2515(ISP)(Low-V) [ISP-HEADER01]
PIC18F2515@SOIC28 [(SA404)]
PIC18F2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F252 PIC18F252(ISP) [ISP-
HEADER01]
PIC18F252@SOIC28 [(SA404)]
PIC18F252@SOIC28(ISP) [ISP-HEADER01]
PIC18F2520
PIC18F2520(ISP)(High-V) [ISP-HEADER01]
PIC18F2520(ISP)(Low-V) [ISP-HEADER01]
PIC18F2520@SOIC28 [(SA404)]
PIC18F2520@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523
PIC18F2523(ISP)(High-V) [ISP-HEADER01]
PIC18F2523(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523@QFN28 [(SA685-B006)]
PIC18F2523@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2523@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2523@SOIC28 [(SA404)]
PIC18F2523@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2523@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2525
PIC18F2525(ISP)(Low-V) [ISP-HEADER01]
PIC18F2525@SOIC28 [(SA404)]
PIC18F2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2539 PIC18F2539(ISP) [ISP-
HEADER01]
PIC18F2539@SOIC28 [(SA404)]
PIC18F2539@SOIC28(ISP) [ISP-HEADER01]
PIC18F2550
PIC18F2550(ISP)(High-V) [ISP-HEADER01]
PIC18F2550(ISP)(Low-V) [ISP-HEADER01]
PIC18F2550@SOIC28 [(SA404)]
PIC18F2550@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553
PIC18F2553(ISP)(High-V) [ISP-HEADER01]
PIC18F2553(ISP)(Low-V) [ISP-HEADER01]
PIC18F2553@SOIC28 [(SA404)]
PIC18F2553@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2553@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18F2553@SSOP28 [(SA626A)]
PIC18F2553@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2553@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F258 PIC18F258(ISP) [ISP-
HEADER01]
PIC18F258@SOIC28 [(SA404)]
PIC18F258@SOIC28(ISP) [ISP-HEADER01]
PIC18F2580
PIC18F2580(ISP)(High-V) [ISP-HEADER01]
PIC18F2580(ISP)(Low-V) [ISP-HEADER01]
PIC18F2580@QFN28 [(SA685-B006)]
PIC18F2580@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2580@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2580@SOIC28 [(SA404)]
PIC18F2580@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585
PIC18F2585(ISP)(High-V) [ISP-HEADER01]
PIC18F2585(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585@SDIP28 [(SA022A)]
PIC18F2585@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2585@SOIC28 [(SA404)]
PIC18F2585@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25J10 PIC18F25J10(ISP) [ISP-
HEADER01]
PIC18F25J10@QFN28 [(SA685-B006)]
PIC18F25J10@QFN28(ISP) [ISP-HEADER01]
PIC18F25J10@SOIC28 [(SA404)]
PIC18F25J10@SOIC28(ISP) [ISP-HEADER01]
PIC18F25J10@SSOP28 [(SA626A)]
PIC18F25J10@SSOP28(ISP) [ISP-HEADER01]
PIC18F25K20
PIC18F25K20(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@QFN28 [(SA685-B006)]
PIC18F25K20@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@SOIC28 [(SA404)]
PIC18F25K20@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F25K20@SSOP28 [(SA626A)]

PIC18F25K20@SSOP28(ISP)(High-V) [ISP-HEADER01]
PIC18F25K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2610
PIC18F2610(ISP)(Low-V) [ISP-HEADER01]
PIC18F2610@SOIC28 [(SA404)]
PIC18F2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2620
PIC18F2620(ISP)(Low-V) [ISP-HEADER01]
PIC18F2620@SOIC28 [(SA404)]
PIC18F2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680
PIC18F2680(ISP)(High-V) [ISP-HEADER01]
PIC18F2680(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680@SDIP28 [(SA022A)]
PIC18F2680@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18F2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2680@SOIC28 [(SA404)]
PIC18F2680@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682
PIC18F2682(ISP)(High-V) [ISP-HEADER01]
PIC18F2682(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682@QFN28 [(SA685)]
PIC18F2682@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2682@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2682@SOIC28 [(SA404)]
PIC18F2682@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685
PIC18F2685(ISP)(High-V) [ISP-HEADER01]
PIC18F2685(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685@QFN28 [(SA685)]
PIC18F2685@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18F2685@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18F2685@SOIC28 [(SA404)]
PIC18F2685@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18F2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18F4220 PIC18F4220(ISP) [ISP-
HEADER01]
PIC18F4220@QFN44 [(SA712)]
PIC18F4220@QFN44(ISP) [ISP-HEADER01]
PIC18F4220@QFN44(ML) [(SA737)]
PIC18F4220@QFN44(ML)(ISP) [ISP-HEADER01]

PIC18F4220@TQFP44 [(SA245A)]
PIC18F4220@TQFP44(ISP) [ISP-HEADER01]
PIC18F4221
PIC18F4221(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@QFN44 [(SA712)]
PIC18F4221@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@QFN44(ML) [(SA737)]
PIC18F4221@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4221@TQFP44 [(SA245A)]
PIC18F4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4320 PIC18F4320(ISP) [ISP-
HEADER01]
PIC18F4320@QFN44 [(SA712)]
PIC18F4320@QFN44(ISP) [ISP-HEADER01]
PIC18F4320@QFN44(ML) [(SA737)]
PIC18F4320@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4320@TQFP44 [(SA245A)]
PIC18F4320@TQFP44(ISP) [ISP-HEADER01]
PIC18F4321
PIC18F4321(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@QFN44 [(SA712)]
PIC18F4321@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@QFN44(ML) [(SA737)]
PIC18F4321@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4321@TQFP44 [(SA245A)]
PIC18F4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4331 PIC18F4331(ISP) [ISP-
HEADER01]
PIC18F4331@TQFP44 [(SA245A)]
PIC18F4331@TQFP44(ISP) [ISP-HEADER01]
PIC18F43K20
PIC18F43K20(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F43K20@QFN44 [(SA712)]
PIC18F43K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ML) [(SA737)]
PIC18F43K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F43K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F43K20@TQFP44 [(SA245A)]
PIC18F43K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F43K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410

PIC18F4410(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@QFN44 [(SA712)]
PIC18F4410@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@QFN44(ML) [(SA737)]
PIC18F4410@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4410@TQFP44 [(SA245A)]
PIC18F4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F442 PIC18F442(ISP) [ISP-
HEADER01]
PIC18F442@PLCC44 [(SA244)]
PIC18F442@PLCC44(ISP) [ISP-HEADER01]
PIC18F442@TQFP44 [(SA245A)]
PIC18F442@TQFP44(ISP) [ISP-HEADER01]
PIC18F4420
PIC18F4420(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@QFN44 [(SA712)]
PIC18F4420@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@QFN44(ML) [(SA737)]
PIC18F4420@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4420@TQFP44 [(SA245A)]
PIC18F4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423
PIC18F4423(ISP)(High-V) [ISP-HEADER01]
PIC18F4423(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@QFN44 [(SA712)]
PIC18F4423@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4423@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@QFN44(ML) [(SA737)]
PIC18F4423@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4423@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4423@TQFP44 [(SA245A)]
PIC18F4423@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4423@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4431 PIC18F4431(ISP) [ISP-
HEADER01]
PIC18F4431@TQFP44 [(SA245A)]
PIC18F4431@TQFP44(ISP) [ISP-HEADER01]
PIC18F4439 PIC18F4439(ISP) [ISP-
HEADER01]
PIC18F4439@TQFP44 [(SA245A)]
PIC18F4439@TQFP44(ISP) [ISP-HEADER01]
PIC18F4450
PIC18F4450(ISP)(Low-V) [ISP-HEADER01]

PIC18F4450@QFN44 [(SA712)]
PIC18F4450@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@QFN44(ML) [(SA737)]
PIC18F4450@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4450@TQFP44 [(SA245A)]
PIC18F4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455
PIC18F4455(ISP)(High-V) [ISP-HEADER01]
PIC18F4455(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@QFN44 [(SA712)]
PIC18F4455@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4455@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@QFN44(ML) [(SA737)]
PIC18F4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4455@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4455@TQFP44 [(SA245A)]
PIC18F4455@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458
PIC18F4458(ISP)(High-V) [ISP-HEADER01]
PIC18F4458(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458@QFN44 [(SA737)]
PIC18F4458@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4458@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4458@TQFP44 [(SA245A)]
PIC18F4458@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4458@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F448 PIC18F448(ISP) [ISP-
HEADER01]
PIC18F448@PLCC44 [(SA244)]
PIC18F448@PLCC44(ISP) [ISP-HEADER01]
PIC18F448@TQFP44 [(SA245A)]
PIC18F448@TQFP44(ISP) [ISP-HEADER01]
PIC18F4480
PIC18F4480(ISP)(High-V) [ISP-HEADER01]
PIC18F4480(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@QFN44 [(SA712)]
PIC18F4480@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4480@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@QFN44(ML) [(SA737)]
PIC18F4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4480@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4480@TQFP44 [(SA245A)]

PIC18F4480@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F44J10 PIC18F44J10(ISP) [ISP-
HEADER01]
PIC18F44J10@QFN44 [(SA712)]
PIC18F44J10@QFN44(ISP) [ISP-HEADER01]
PIC18F44J10@QFN44(ML) [(SA709)]
PIC18F44J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F44J10@TQFP44 [(SA245A)]
PIC18F44J10@TQFP44(ISP) [ISP-HEADER01]
PIC18F44K20
PIC18F44K20(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F44K20@QFN44 [(SA712)]
PIC18F44K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ML) [(SA737)]
PIC18F44K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F44K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F44K20@TQFP44 [(SA245A)]
PIC18F44K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F44K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4510 PIC18F4510(ISP) [ISP-
HEADER01]
PIC18F4510@QFN44 [(SA712)]
PIC18F4510@QFN44(ISP) [ISP-HEADER01]
PIC18F4510@QFN44(ML) [(SA737)]
PIC18F4510@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F4510@TQFP44 [(SA245A)]
PIC18F4510@TQFP44(ISP) [ISP-HEADER01]
PIC18F4515
PIC18F4515(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@QFN44 [(SA712)]
PIC18F4515@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@QFN44(ML) [(SA737)]
PIC18F4515@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4515@TQFP44 [(SA245A)]
PIC18F4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F452 PIC18F452(ISP) [ISP-
HEADER01]
PIC18F452@PLCC44 [(SA244)]
PIC18F452@PLCC44(ISP) [ISP-HEADER01]
PIC18F452@TQFP44 [(SA245A)]

PIC18F452@TQFP44 (ISP) [ISP-HEADER01]
PIC18F4520 PIC18F4520 (ISP) [ISP-
HEADER01]
PIC18F4520@QFN44 [(SA712)]
PIC18F4520@QFN44 (ISP) [ISP-HEADER01]
PIC18F4520@QFN44 (ML) [(SA737)]
PIC18F4520@QFN44 (ML) (ISP) [ISP-HEADER01]
PIC18F4520@TQFP44 [(SA245A)]
PIC18F4520@TQFP44 (ISP) [ISP-HEADER01]
PIC18F4523
PIC18F4523 (ISP) (High-V) [ISP-HEADER01]
PIC18F4523 (ISP) (Low-V) [ISP-HEADER01]
PIC18F4523@QFN44 [(SA712)]
PIC18F4523@QFN44 (ISP) (High-V) [ISP-HEADER01]
PIC18F4523@QFN44 (ISP) (Low-V) [ISP-HEADER01]
PIC18F4523@QFN44 (ML) [(SA737)]
PIC18F4523@QFN44 (ML) (ISP) (H-V) [ISP-HEADER01]
PIC18F4523@QFN44 (ML) (ISP) (Low-V) [ISP-HEADER01]
PIC18F4523@TQFP44 [(SA245A)]
PIC18F4523@TQFP44 (ISP) (High-V) [ISP-HEADER01]
PIC18F4523@TQFP44 (ISP) (Low-V) [ISP-HEADER01]
PIC18F4525
PIC18F4525 (ISP) (Low-V) [ISP-HEADER01]
PIC18F4525@QFN44 [(SA712)]
PIC18F4525@QFN44 (ISP) (Low-V) [ISP-HEADER01]
PIC18F4525@QFN44 (ML) [(SA737)]
PIC18F4525@QFN44 (ML) (ISP) (Low-V) [ISP-HEADER01]
PIC18F4525@TQFP44 [(SA245A)]
PIC18F4525@TQFP44 (ISP) (Low-V) [ISP-HEADER01]
PIC18F4539 PIC18F4539 (ISP) [ISP-
HEADER01]
PIC18F4539@TQFP44 [(SA245A)]
PIC18F4539@TQFP44 (ISP) [ISP-HEADER01]
PIC18F4550
PIC18F4550 (ISP) (High-V) [ISP-HEADER01]
PIC18F4550 (ISP) (Low-V) [ISP-HEADER01]
PIC18F4550@QFN44 [(SA712)]
PIC18F4550@QFN44 (ISP) (High-V) [ISP-HEADER01]
PIC18F4550@QFN44 (ISP) (Low-V) [ISP-HEADER01]
PIC18F4550@QFN44 (ML) [(SA737)]
PIC18F4550@QFN44 (ML) (ISP) (H-V) [ISP-HEADER01]
PIC18F4550@QFN44 (ML) (ISP) (Low-V) [ISP-HEADER01]
PIC18F4550@TQFP44 [(SA245A)]

PIC18F4550@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553
PIC18F4553(ISP)(High-V) [ISP-HEADER01]
PIC18F4553(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553@QFN44 [(SA737)]
PIC18F4553@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4553@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4553@TQFP44 [(SA245A)]
PIC18F4553@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4553@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F458 PIC18F458(ISP) [ISP-
HEADER01]
PIC18F458@PLCC44 [(SA244)]
PIC18F458@PLCC44(ISP) [ISP-HEADER01]
PIC18F458@TQFP44 [(SA245A)]
PIC18F458@TQFP44(ISP) [ISP-HEADER01]
PIC18F4580
PIC18F4580(ISP)(High-V) [ISP-HEADER01]
PIC18F4580(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@QFN44 [(SA712)]
PIC18F4580@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4580@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@QFN44(ML) [(SA737)]
PIC18F4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4580@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4580@TQFP44 [(SA245A)]
PIC18F4580@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585
PIC18F4585(ISP)(High-V) [ISP-HEADER01]
PIC18F4585(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@QFN44 [(SA712)]
PIC18F4585@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4585@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@QFN44(ML) [(SA737)]
PIC18F4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4585@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4585@TQFP44 [(SA245A)]
PIC18F4585@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F45J10 PIC18F45J10(ISP) [ISP-
HEADER01]

PIC18F45J10@QFN44 [(SA712)]
PIC18F45J10@QFN44(ISP) [ISP-HEADER01]
PIC18F45J10@QFN44(ML) [(SA709)]
PIC18F45J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18F45J10@TQFP44 [(SA245A)]
PIC18F45J10@TQFP44(ISP) [ISP-HEADER01]
PIC18F45K20
PIC18F45K20(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20(ISP)(Low-V) [ISP-HEADER01]
PIC18F45K20@QFN44 [(SA712)]
PIC18F45K20@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ML) [(SA737)]
PIC18F45K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F45K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18F45K20@TQFP44 [(SA245A)]
PIC18F45K20@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F45K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610
PIC18F4610(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@QFN44 [(SA712)]
PIC18F4610@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@QFN44(ML) [(SA737)]
PIC18F4610@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4610@TQFP44 [(SA245A)]
PIC18F4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620
PIC18F4620(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@QFN44 [(SA712)]
PIC18F4620@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@QFN44(ML) [(SA737)]
PIC18F4620@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4620@TQFP44 [(SA245A)]
PIC18F4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680
PIC18F4680(ISP)(High-V) [ISP-HEADER01]
PIC18F4680(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@QFN44 [(SA712)]
PIC18F4680@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4680@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4680@QFN44(ML) [(SA737)]
PIC18F4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4680@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]

PIC18F4680@TQFP44 [(SA245A)]
PIC18F4680@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682
PIC18F4682(ISP)(High-V) [ISP-HEADER01]
PIC18F4682(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@QFN44 [(SA712)]
PIC18F4682@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4682@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@QFN44(ML) [(SA737)]
PIC18F4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4682@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4682@TQFP44 [(SA245A)]
PIC18F4682@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685
PIC18F4685(ISP)(High-V) [ISP-HEADER01]
PIC18F4685(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@QFN44 [(SA712)]
PIC18F4685@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18F4685@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@QFN44(ML) [(SA737)]
PIC18F4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18F4685@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]
PIC18F4685@TQFP44 [(SA245A)]
PIC18F4685@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18F4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18F6310@TQFP64(ISP) [ISP-HEADER01]
PIC18F6390@TQFP64(ISP) [ISP-HEADER01]
PIC18F6393@TQFP64(ISP) [ISP-HEADER01]
PIC18F63J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F63J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6410@TQFP64(ISP) [ISP-HEADER01]
PIC18F6490@TQFP64(ISP) [ISP-HEADER01]
PIC18F6493@TQFP64(ISP) [ISP-HEADER01]
PIC18F64J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F64J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6520@TQFP64(ISP) [ISP-HEADER01]
PIC18F6525@TQFP64(ISP) [ISP-HEADER01]
PIC18F6527@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F6585@PLCC68(ISP) [ISP-HEADER01]
PIC18F6585@TQFP64(ISP) [ISP-HEADER01]

PIC18F65J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F65J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F65J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F65J15@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F65J15@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F65J50@TQFP64(ISP) [ISP-HEADER01]
PIC18F65J90@TQFP64(ISP) [ISP-HEADER01]
PIC18F6620@TQFP64(ISP) [ISP-HEADER01]
PIC18F6621@TQFP64(ISP) [ISP-HEADER01]
PIC18F6622@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F6627@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F6680@PLCC68(ISP) [ISP-HEADER01]
PIC18F6680@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F66J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F66J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J15@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F66J15@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F66J16@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J50@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J55@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J60@TQFP64(ISP) [ISP-HEADER01]
PIC18F66J65@TQFP64(ISP) [ISP-HEADER01]
PIC18F6720@TQFP64(ISP) [ISP-HEADER01]
PIC18F6722@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18F6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18F67J10@TQFP64(ISP)(Disable) [ISP-HEADER01]
PIC18F67J10@TQFP64(ISP)(Enable) [ISP-HEADER01]
PIC18F67J11@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J50@TQFP64(ISP) [ISP-HEADER01]
PIC18F67J60@TQFP64(ISP) [ISP-HEADER01]
PIC18F8310@TQFP80(ISP) [ISP-HEADER01]
PIC18F8390@TQFP80(ISP) [ISP-HEADER01]
PIC18F8393@TQFP80(ISP) [ISP-HEADER01]
PIC18F83J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F83J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8410@TQFP80(ISP) [ISP-HEADER01]
PIC18F8490@TQFP80(ISP) [ISP-HEADER01]
PIC18F8493@TQFP80(ISP) [ISP-HEADER01]
PIC18F84J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F84J90@TQFP80(ISP) [ISP-HEADER01]

PIC18F8520@TQFP80(ISP) [ISP-HEADER01]
PIC18F8525@TQFP80(ISP) [ISP-HEADER01]
PIC18F8527@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8585@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F85J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F85J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J15@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F85J15@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F85J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F85J90@TQFP80(ISP) [ISP-HEADER01]
PIC18F8620@TQFP80(ISP) [ISP-HEADER01]
PIC18F8621@TQFP80(ISP) [ISP-HEADER01]
PIC18F8622@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8627@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F8680@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F86J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F86J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J15@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F86J15@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F86J16@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J55@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J60@TQFP80(ISP) [ISP-HEADER01]
PIC18F86J65@TQFP80(ISP) [ISP-HEADER01]
PIC18F8720@TQFP80(ISP) [ISP-HEADER01]
PIC18F8722@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18F8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18F87J10@TQFP80(ISP)(Disable) [ISP-HEADER01]
PIC18F87J10@TQFP80(ISP)(Enable) [ISP-HEADER01]
PIC18F87J11@TQFP80(ISP) [ISP-HEADER01]
PIC18F87J50@TQFP80(ISP) [ISP-HEADER01]
PIC18F87J60@TQFP80(ISP) [ISP-HEADER01]
PIC18F96J60@TQFP100(ISP) [ISP-HEADER01]
PIC18F96J65@TQFP100(ISP) [ISP-HEADER01]
PIC18F97J60@TQFP100(ISP) [ISP-HEADER01]
PIC18LC452 PIC18LC452@PLCC44
[(SA244)]
PIC18LC452@TQFP44 [(SA245A)]

PIC18LF1220
PIC18LF1220(ISP) [ISP-HEADER01] PIC18LF1220@SOIC18
[(SA404)]
PIC18LF1220@SOIC18(ISP) [ISP-HEADER01]
PIC18LF1220@SSOP20 [(SA626A)]
PIC18LF1220@SSOP20(ISP) [ISP-HEADER01]
PIC18LF1320 PIC18LF1320(ISP) [ISP-
HEADER01]
PIC18LF1320@SOIC18 [(SA404)]
PIC18LF1320@SOIC18(ISP) [ISP-HEADER01]
PIC18LF1320@SSOP20 [(SA626A)]
PIC18LF1320@SSOP20(ISP) [ISP-HEADER01]
PIC18LF2220 PIC18LF2220(ISP) [ISP-
HEADER01]
PIC18LF2220@SOIC28 [(SA404)]
PIC18LF2220@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2221
PIC18LF2221(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2221@QFN28 [(SA685-B006)]
PIC18LF2221@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2221@SOIC28 [(SA404)]
PIC18LF2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2320 PIC18LF2320(ISP) [ISP-
HEADER01]
PIC18LF2320@SOIC28 [(SA404)]
PIC18LF2320@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2321
PIC18LF2321(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2321@QFN28 [(SA685-B006)]
PIC18LF2321@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2321@SOIC28 [(SA404)]
PIC18LF2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2331 PIC18LF2331(ISP) [ISP-
HEADER01]
PIC18LF2331@SOIC28 [(SA404)]
PIC18LF2331@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2410
PIC18LF2410(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2410@QFN28 [(SA685-B006)]
PIC18LF2410@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2410@SOIC28 [(SA404)]
PIC18LF2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF242 PIC18LF242(ISP) [ISP-

HEADER01]
PIC18LF242@SOIC28 [(SA404)]
PIC18LF242@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2420
PIC18LF2420(ISP)(High-V) [ISP-HEADER01]
PIC18LF2420(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2420@SOIC28 [(SA404)]
PIC18LF2420@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2431 PIC18LF2431(ISP) [ISP-
HEADER01]
PIC18LF2431@SOIC28 [(SA404)]
PIC18LF2431@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2439 PIC18LF2439(ISP) [ISP-
HEADER01]
PIC18LF2439@SOIC28 [(SA404)]
PIC18LF2439@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2450
PIC18LF2450(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2450@QFN28 [(SA685-B006)]
PIC18LF2450@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2450@SOIC28 [(SA404)]
PIC18LF2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2455
PIC18LF2455(ISP)(High-V) [ISP-HEADER01]
PIC18LF2455(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2455@SOIC28 [(SA404)]
PIC18LF2455@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF248 PIC18LF248(ISP) [ISP-
HEADER01]
PIC18LF248@SOIC28 [(SA404)]
PIC18LF248@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2480
PIC18LF2480(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2480@QFN28 [(SA685-B006)]
PIC18LF2480@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2480@SOIC28 [(SA404)]
PIC18LF2480@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF24J10 PIC18LF24J10(ISP) [ISP-

HEADER01]
PIC18LF24J10@QFN28 [(SA685-B006)]
PIC18LF24J10@QFN28(ISP) [ISP-HEADER01]
PIC18LF24J10@SOIC28 [(SA404)]
PIC18LF24J10@SOIC28(ISP) [ISP-HEADER01]
PIC18LF24J10@SSOP28 [(SA626A)]
PIC18LF24J10@SSOP28(ISP) [ISP-HEADER01]
PIC18LF2510 PIC18LF2510(ISP) [ISP-
HEADER01]
PIC18LF2510@QFN28 [(SA685-B006)]
PIC18LF2510@QFN28(ISP) [ISP-HEADER01]
PIC18LF2510@SOIC28 [(SA404)]
PIC18LF2510@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2515
PIC18LF2515(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2515@SOIC28 [(SA404)]
PIC18LF2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF252 PIC18LF252(ISP) [ISP-
HEADER01]
PIC18LF252@SOIC28 [(SA404)]
PIC18LF252@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2520
PIC18LF2520(ISP)(High-V) [ISP-HEADER01]
PIC18LF2520(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2520@SOIC28 [(SA404)]
PIC18LF2520@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2525
PIC18LF2525(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2525@SOIC28 [(SA404)]
PIC18LF2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2539 PIC18LF2539(ISP) [ISP-
HEADER01]
PIC18LF2539@SOIC28 [(SA404)]
PIC18LF2539@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2550
PIC18LF2550(ISP)(High-V) [ISP-HEADER01]
PIC18LF2550(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2550@SOIC28 [(SA404)]
PIC18LF2550@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF258 PIC18LF258(ISP) [ISP-
HEADER01]

PIC18LF258@SOIC28 [(SA404)]
PIC18LF258@SOIC28(ISP) [ISP-HEADER01]
PIC18LF2580
PIC18LF2580(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2580@QFN28 [(SA685-B006)]
PIC18LF2580@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2580@SOIC28 [(SA404)]
PIC18LF2580@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2585
PIC18LF2585(ISP)(High-V) [ISP-HEADER01]
PIC18LF2585(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2585@SDIP28 [(SA022A)]
PIC18LF2585@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2585@SOIC28 [(SA404)]
PIC18LF2585@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF25J10 PIC18LF25J10(ISP) [ISP-
HEADER01]
PIC18LF25J10@QFN28 [(SA685-B006)]
PIC18LF25J10@QFN28(ISP) [ISP-HEADER01]
PIC18LF25J10@SOIC28 [(SA404)]
PIC18LF25J10@SOIC28(ISP) [ISP-HEADER01]
PIC18LF25J10@SSOP28 [(SA626A)]
PIC18LF25J10@SSOP28(ISP) [ISP-HEADER01]
PIC18LF2610
PIC18LF2610(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2610@SOIC28 [(SA404)]
PIC18LF2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2620
PIC18LF2620(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2620@SOIC28 [(SA404)]
PIC18LF2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2680
PIC18LF2680(ISP)(High-V) [ISP-HEADER01]
PIC18LF2680(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2680@SDIP28 [(SA022A)]
PIC18LF2680@SDIP28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2680@SOIC28 [(SA404)]

PIC18LF2680@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2682
PIC18LF2682(ISP)(High-V) [ISP-HEADER01]
PIC18LF2682(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2682@QFN28 [(SA685)]
PIC18LF2682@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2682@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2682@SOIC28 [(SA404)]
PIC18LF2682@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2685
PIC18LF2685(ISP)(High-V) [ISP-HEADER01]
PIC18LF2685(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2685@QFN28 [(SA685)]
PIC18LF2685@QFN28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2685@QFN28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF2685@SOIC28 [(SA404)]
PIC18LF2685@SOIC28(ISP)(High-V) [ISP-HEADER01]
PIC18LF2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4220 PIC18LF4220(ISP) [ISP-
HEADER01]
PIC18LF4220@QFN44 [(SA712)]
PIC18LF4220@QFN44(ISP) [ISP-HEADER01]
PIC18LF4220@QFN44(ML) [(SA737)]
PIC18LF4220@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4220@TQFP44 [(SA245A)]
PIC18LF4220@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4221
PIC18LF4221(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4221@QFN44 [(SA712)]
PIC18LF4221@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4221@QFN44(ML) [(SA737)]
PIC18LF4221@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4221@TQFP44 [(SA245A)]
PIC18LF4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4320 PIC18LF4320(ISP) [ISP-
HEADER01]
PIC18LF4320@QFN44 [(SA712)]
PIC18LF4320@QFN44(ISP) [ISP-HEADER01]
PIC18LF4320@QFN44(ML) [(SA737)]
PIC18LF4320@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4320@TQFP44 [(SA245A)]

PIC18LF4320@TQFP44 (ISP) [ISP-HEADER01]
PIC18LF4321
PIC18LF4321 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4321@QFN44 [(SA712)]
PIC18LF4321@QFN44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4321@QFN44 (ML) [(SA737)]
PIC18LF4321@QFN44 (ML) (ISP) (L-V) [ISP-HEADER01]
PIC18LF4321@TQFP44 [(SA245A)]
PIC18LF4321@TQFP44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4331 PIC18LF4331 (ISP) [ISP-
HEADER01]
PIC18LF4331@TQFP44 [(SA245A)]
PIC18LF4331@TQFP44 (ISP) [ISP-HEADER01]
PIC18LF4410
PIC18LF4410 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4410@QFN44 [(SA712)]
PIC18LF4410@QFN44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4410@QFN44 (ML) [(SA737)]
PIC18LF4410@QFN44 (ML) (ISP) (L-V) [ISP-HEADER01]
PIC18LF4410@TQFP44 [(SA245A)]
PIC18LF4410@TQFP44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF442 PIC18LF442 (ISP) [ISP-
HEADER01]
PIC18LF442@PLCC44 [(SA244)]
PIC18LF442@PLCC44 (ISP) [ISP-HEADER01]
PIC18LF442@TQFP44 [(SA245A)]
PIC18LF442@TQFP44 (ISP) [ISP-HEADER01]
PIC18LF4420
PIC18LF4420 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4420@QFN44 [(SA712)]
PIC18LF4420@QFN44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4420@QFN44 (ML) [(SA737)]
PIC18LF4420@QFN44 (ML) (ISP) (L-V) [ISP-HEADER01]
PIC18LF4420@TQFP44 [(SA245A)]
PIC18LF4420@TQFP44 (ISP) (Low-V) [ISP-HEADER01]
PIC18LF4431 PIC18LF4431 (ISP) [ISP-
HEADER01]
PIC18LF4431@TQFP44 [(SA245A)]
PIC18LF4431@TQFP44 (ISP) [ISP-HEADER01]
PIC18LF4439 PIC18LF4439 (ISP) [ISP-
HEADER01]
PIC18LF4439@TQFP44 [(SA245A)]
PIC18LF4439@TQFP44 (ISP) [ISP-HEADER01]

PIC18LF4450
PIC18LF4450(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4450@QFN44 [(SA712)]
PIC18LF4450@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4450@QFN44(ML) [(SA737)]
PIC18LF4450@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4450@TQFP44 [(SA245A)]
PIC18LF4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455
PIC18LF4455(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455@QFN44 [(SA712)]
PIC18LF4455@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ML) [(SA737)]
PIC18LF4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4455@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4455@TQFP44 [(SA245A)]
PIC18LF4455@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF448 PIC18LF448(ISP) [ISP-
HEADER01]
PIC18LF448@PLCC44 [(SA244)]
PIC18LF448@PLCC44(ISP) [ISP-HEADER01]
PIC18LF448@TQFP44 [(SA245A)]
PIC18LF448@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4480
PIC18LF4480(ISP)(High-V) [ISP-HEADER01]
PIC18LF4480(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4480@QFN44 [(SA712)]
PIC18LF4480@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4480@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4480@QFN44(ML) [(SA737)]
PIC18LF4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4480@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4480@TQFP44 [(SA245A)]
PIC18LF4480@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF44J10 PIC18LF44J10(ISP) [ISP-
HEADER01]
PIC18LF44J10@QFN44 [(SA712)]
PIC18LF44J10@QFN44(ISP) [ISP-HEADER01]
PIC18LF44J10@QFN44(ML) [(SA709)]

PIC18LF44J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF44J10@TQFP44 [(SA245A)]
PIC18LF44J10@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4510 PIC18LF4510(ISP) [ISP-
HEADER01]
PIC18LF4510@QFN44 [(SA712)]
PIC18LF4510@QFN44(ISP) [ISP-HEADER01]
PIC18LF4510@QFN44(ML) [(SA737)]
PIC18LF4510@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4510@TQFP44 [(SA245A)]
PIC18LF4510@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4515
PIC18LF4515(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4515@QFN44 [(SA712)]
PIC18LF4515@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4515@QFN44(ML) [(SA737)]
PIC18LF4515@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4515@TQFP44 [(SA245A)]
PIC18LF4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF452 PIC18LF452(ISP) [ISP-
HEADER01]
PIC18LF452@PLCC44 [(SA244)]
PIC18LF452@PLCC44(ISP) [ISP-HEADER01]
PIC18LF452@TQFP44 [(SA245A)]
PIC18LF452@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4520 PIC18LF4520(ISP) [ISP-
HEADER01]
PIC18LF4520@QFN44 [(SA712)]
PIC18LF4520@QFN44(ISP) [ISP-HEADER01]
PIC18LF4520@QFN44(ML) [(SA737)]
PIC18LF4520@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF4520@TQFP44 [(SA245A)]
PIC18LF4520@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4525
PIC18LF4525(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4525@QFN44 [(SA712)]
PIC18LF4525@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4525@QFN44(ML) [(SA737)]
PIC18LF4525@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4525@TQFP44 [(SA245A)]
PIC18LF4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4539 PIC18LF4539(ISP) [ISP-
HEADER01]

PIC18LF4539@TQFP44 [(SA245A)]
PIC18LF4539@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4550
PIC18LF4550(ISP)(High-V) [ISP-HEADER01]
PIC18LF4550(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4550@QFN44 [(SA712)]
PIC18LF4550@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4550@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4550@QFN44(ML) [(SA737)]
PIC18LF4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4550@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4550@TQFP44 [(SA245A)]
PIC18LF4550@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF458 PIC18LF458(ISP) [ISP-
HEADER01]
PIC18LF458@PLCC44 [(SA244)]
PIC18LF458@PLCC44(ISP) [ISP-HEADER01]
PIC18LF458@TQFP44 [(SA245A)]
PIC18LF458@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4580
PIC18LF4580(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4580@QFN44 [(SA712)]
PIC18LF4580@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ML) [(SA737)]
PIC18LF4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4580@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4580@TQFP44 [(SA245A)]
PIC18LF4580@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585
PIC18LF4585(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585@QFN44 [(SA712)]
PIC18LF4585@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ML) [(SA737)]
PIC18LF4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4585@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4585@TQFP44 [(SA245A)]
PIC18LF4585@TQFP44(ISP)(High-V) [ISP-HEADER01]

PIC18LF4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF45J10 PIC18LF45J10(ISP) [ISP-
HEADER01]
PIC18LF45J10@QFN44 [(SA712)]
PIC18LF45J10@QFN44(ISP) [ISP-HEADER01]
PIC18LF45J10@QFN44(ML) [(SA709)]
PIC18LF45J10@QFN44(ML)(ISP) [ISP-HEADER01]
PIC18LF45J10@TQFP44 [(SA245A)]
PIC18LF45J10@TQFP44(ISP) [ISP-HEADER01]
PIC18LF4610
PIC18LF4610(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4610@QFN44 [(SA712)]
PIC18LF4610@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4610@QFN44(ML) [(SA737)]
PIC18LF4610@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4610@TQFP44 [(SA245A)]
PIC18LF4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620
PIC18LF4620(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620@QFN44 [(SA712)]
PIC18LF4620@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4620@QFN44(ML) [(SA737)]
PIC18LF4620@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4620@TQFP44 [(SA245A)]
PIC18LF4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680
PIC18LF4680(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680@QFN44 [(SA712)]
PIC18LF4680@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ML) [(SA737)]
PIC18LF4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4680@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4680@TQFP44 [(SA245A)]
PIC18LF4680@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682
PIC18LF4682(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4682@QFN44 [(SA712)]
PIC18LF4682@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ISP)(Low-V) [ISP-HEADER01]

PIC18LF4682@QFN44(ML) [(SA737)]
PIC18LF4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4682@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4682@TQFP44 [(SA245A)]
PIC18LF4682@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685
PIC18LF4685(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685@QFN44 [(SA712)]
PIC18LF4685@QFN44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ML) [(SA737)]
PIC18LF4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]
PIC18LF4685@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]
PIC18LF4685@TQFP44 [(SA245A)]
PIC18LF4685@TQFP44(ISP)(High-V) [ISP-HEADER01]
PIC18LF4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6310@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6390@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6393@TQFP64(ISP) [ISP-HEADER01]
PIC18LF63J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF63J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6410@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6490@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6493@TQFP64(ISP) [ISP-HEADER01]
PIC18LF64J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF64J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6520@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6525@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6527@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6585@PLCC68(ISP) [ISP-HEADER01]
PIC18LF6585@TQFP64(ISP) [ISP-HEADER01]
PIC18LF65J11@TQFP64(ISP) [ISP-HEADER01]
PIC18LF65J90@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6620@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6621@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6622@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6627@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF6680@PLCC68(ISP) [ISP-HEADER01]

PIC18LF6680@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6720@TQFP64(ISP) [ISP-HEADER01]
PIC18LF6722@TQFP64(ISP)(High-V) [ISP-HEADER01]
PIC18LF6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8310@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8390@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8393@TQFP80(ISP) [ISP-HEADER01]
PIC18LF83J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF83J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8410@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8490@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8493@TQFP80(ISP) [ISP-HEADER01]
PIC18LF84J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF84J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8520@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8525@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8527@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8585@TQFP80(ISP) [ISP-HEADER01]
PIC18LF85J11@TQFP80(ISP) [ISP-HEADER01]
PIC18LF85J90@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8620@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8621@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8622@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8627@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC18LF8680@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8720@TQFP80(ISP) [ISP-HEADER01]
PIC18LF8722@TQFP80(ISP)(High-V) [ISP-HEADER01]
PIC18LF8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]
PIC30F2010 PIC30F2010(ISP) [ISP-
HEADER01]
PIC30F2010@SDIP28 [(SA022A)]
PIC30F2010@SDIP28(ISP) [ISP-HEADER01]
PIC30F2010@SOIC28 [(SA404)]
PIC30F2010@SOIC28(ISP) [ISP-HEADER01]
PIC30F2011(ISP) [ISP-HEADER01]
PIC30F2011@QFN28(ISP) [ISP-HEADER01]
PIC30F2011@SDIP18(ISP) [ISP-HEADER01]
PIC30F2011@SOIC18(ISP) [ISP-HEADER01]
PIC30F2012(ISP) [ISP-HEADER01]
PIC30F2012@QFN28(ISP) [ISP-HEADER01]

PIC30F2012@SDIP28 (ISP) [ISP-HEADER01]
PIC30F2012@SOIC28 (ISP) [ISP-HEADER01]
PIC30F3010 (ISP) [ISP-HEADER01]
PIC30F3010@QFN44 (ISP) [ISP-HEADER01]
PIC30F3010@SDIP28 (ISP) [ISP-HEADER01]
PIC30F3010@SOIC28 (ISP) [ISP-HEADER01]
PIC30F3011 (ISP) [ISP-HEADER01]
PIC30F3011@QFN44 (ISP) [ISP-HEADER01]
PIC30F3011@QFP44 (ISP) [ISP-HEADER01]
PIC30F3012 (ISP) [ISP-HEADER01]
PIC30F3012@QFN44 (ISP) [ISP-HEADER01]
PIC30F3012@SDIP18 (ISP) [ISP-HEADER01]
PIC30F3012@SOIC18 (ISP) [ISP-HEADER01]
PIC30F3013 (ISP) [ISP-HEADER01]
PIC30F3013@QFN44 (ISP) [ISP-HEADER01]
PIC30F3013@SDIP28 (ISP) [ISP-HEADER01]
PIC30F3013@SOIC28 (ISP) [ISP-HEADER01]
PIC30F3014 (ISP) [ISP-HEADER01]
PIC30F3014@QFN44 (ISP) [ISP-HEADER01]
PIC30F3014@QFP44 (ISP) [ISP-HEADER01]
PIC30F4011 (ISP) [ISP-HEADER01]
PIC30F4011@QFN44 (ISP) [ISP-HEADER01]
PIC30F4011@QFP44 (ISP) [ISP-HEADER01]
PIC30F4012 (ISP) [ISP-HEADER01]
PIC30F4012@QFN44 (ISP) [ISP-HEADER01]
PIC30F4012@SDIP28 (ISP) [ISP-HEADER01]
PIC30F4012@SOIC28 (ISP) [ISP-HEADER01]
PIC30F4013 (ISP) [ISP-HEADER01]
PIC30F4013@QFN44 (ISP) [ISP-HEADER01]
PIC30F4013@QFP44 (ISP) [ISP-HEADER01]
PIC30F5011@QFP64 (ISP) [ISP-HEADER01]
PIC30F5013@QFP80 (ISP) [ISP-HEADER01]
PIC30F5015@QFP64 (ISP) [ISP-HEADER01]
PIC30F5016@QFP80 (ISP) [ISP-HEADER01]
PIC30F6010@QFP80 (ISP) [ISP-HEADER01]
PIC30F6010@TQFP80 (ISP) [ISP-HEADER01]
PIC30F6010A@QFP80 (ISP) [ISP-HEADER01]
PIC30F6010A@TQFP80 (ISP) [ISP-HEADER01]
PIC30F6011@QFP64 (ISP) [ISP-HEADER01]
PIC30F6011A@QFP64 (ISP) [ISP-HEADER01]
PIC30F6012@QFP64 (ISP) [ISP-HEADER01]
PIC30F6012A@QFP64 (ISP) [ISP-HEADER01]
PIC30F6013@QFP80 (ISP) [ISP-HEADER01]

PIC30F6013A@QFP80(ISP) [ISP-HEADER01]
PIC30F6014@QFP80(ISP) [ISP-HEADER01]
PIC30F6014@TQFP80(ISP) [ISP-HEADER01]
PIC30F6014A@QFP80(ISP) [ISP-HEADER01]
PIC30F6014A@TQFP80(ISP) [ISP-HEADER01]
PIC30F6015@QFP64(ISP) [ISP-HEADER01]
PS200 PS200(ISP) [ISP-
HEADER01]
PS200@SOIC20 [(SA404)] PS200@SOIC20(ISP) [ISP-
HEADER01]
PS200@SSOP20 [(SA626A)] PS200@SSOP20(ISP) [ISP-
HEADER01]
rfPIC12C509AF@SSOP20 [(SA626A)]
rfPIC12C509AF@SSOP20(ISP) [ISP-HEADER01]
rfPIC12C509AG@SOIC18 [(SA404)]
rfPIC12C509AG@SOIC18(ISP) [ISP-HEADER01]
rfPIC12LC509AF@SSOP20 [(SA626A)]
rfPIC12LC509AF@SSOP20(ISP) [ISP-HEADER01]
rfPIC12LC509AG@SOIC18 [(SA404)]
rfPIC12LC509AG@SOIC18(ISP) [ISP-HEADER01]

MICRON

E(E) PROM/FRAM/NVRAM

MT28F002B1VG-B@TSOP40 [(SA409T)] MT28F002B1VG-T@TSOP40
[(SA409T)]
MT28F002B3VG-B@TSOP40 [(SA409T)] MT28F002B3VG-T@TSOP40
[(SA409T)]
MT28F002B5VG-B@TSOP40 [(SA409T)] MT28F002B5VG-T@TSOP40
[(SA409T)]
MT28F002C1VG-T@TSOP40 [(SA409T)] MT28F002C5VG-T@TSOP40
[(SA409T)]
MT28F002VG-B@TSOP40 [(SA409T)] MT28F002VG-T@TSOP40
[(SA409T)]
MT28F004B1VG-B@TSOP40 [(SA409T)] MT28F004B1VG-T@TSOP40
[(SA409T)]
MT28F004B3VG-B@TSOP40 [(SA409T)] MT28F004B3VG-T@TSOP40
[(SA409T)]
MT28F004B5VG-B@TSOP40 [(SA409T)] MT28F004B5VG-T@TSOP40
[(SA409T)]
MT28F004VG-B@TSOP40 [(SA409T)] MT28F004VG-T@TSOP40

[(SA409T)]
MT28F008B1VG-B@TSOP40 [(SA409T)] MT28F008B1VG-T@TSOP40
[(SA409T)]
MT28F008B3VG-B@TSOP40 [(SA409T)] MT28F008B3VG-T@TSOP40
[(SA409T)]
MT28F008B5VG-B@TSOP40 [(SA409T)] MT28F008B5VG-T@TSOP40
[(SA409T)]
MT28F016S3VG@TSOP40 [(SA409T)] MT28F016S5VG@TSOP40
[(SA409T)]
MT28F1284W18BQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]
MT28F1284W18TQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]
MT28F128J3A(FW203)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F128J3A(FW501)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F128J3A(FW502)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F128J3A(FW503)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F128J3A(INTEL)@TSOP56 [(SA628-B018)]
MT28F128J3A(MICRON)@TSOP56 [(SA628-B018)]
MT28F200B1SGB@PSOP44 [(SA638)] MT28F200B1SGT@PSOP44
[(SA638)]
MT28F200B1WGB@TSOP48 [(SA247-B005)]
MT28F200B1WGT@TSOP48 [(SA247-B005)]
MT28F200B3SGB@PSOP44 [(SA638)] MT28F200B3SGT@PSOP44
[(SA638)]
MT28F200B3WGB@TSOP48 [(SA247-B005)]
MT28F200B3WGT@TSOP48 [(SA247-B005)]
MT28F200B5SGB@PSOP44 [(SA638)] MT28F200B5SGT@PSOP44
[(SA638)]
MT28F200B5WGB@TSOP48 [(SA247-B005)]
MT28F200B5WGT@TSOP48 [(SA247-B005)]
MT28F320J3A(FW201)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F320J3A(FW204)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F320J3A(FW207)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F320J3A(FW208)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F320J3A(INTEL)@TSOP56 [(SA628-B018)]
MT28F320J3A(MICRON)@TSOP56 [(SA628-B018)]
MT28F400B1SGB@PSOP44 [(SA638)] MT28F400B1SGT@PSOP44
[(SA638)]
MT28F400B1WGB@TSOP48 [(SA247-B005)]
MT28F400B1WGT@TSOP48 [(SA247-B005)]
MT28F400B3SGB@PSOP44 [(SA638)] MT28F400B3SGT@PSOP44
[(SA638)]
MT28F400B3WGB@TSOP48 [(SA247-B005)]
MT28F400B3WGT@TSOP48 [(SA247-B005)]

MT28F400B5SGB@PSOP44 [(SA638)] MT28F400B5SGT@PSOP44
[(SA638)]
MT28F400B5WGB@TSOP48 [(SA247-B005)]
MT28F400B5WGT@TSOP48 [(SA247-B005)]
MT28F640J3A(FW202)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F640J3A(FW205)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F640J3A(FW206)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F640J3A(FW209)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F640J3A(FW505)(I.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F640J3A(FW506)(M.)@FBGA64 [(SA655A-B054A-T064F001)]
MT28F640J3A(INTEL)@TSOP56 [(SA628-B018)]
MT28F640J3A(MICRON)@TSOP56 [(SA628-B018)]
MT28F800B1SGB@PSOP44 [(SA638)] MT28F800B1SGT@PSOP44
[(SA638)]
MT28F800B1WGB@TSOP48 [(SA247-B005)]
MT28F800B1WGT@TSOP48 [(SA247-B005)]
MT28F800B3SGB@PSOP44 [(SA638)] MT28F800B3SGT@PSOP44
[(SA638)]
MT28F800B3WGB@TSOP48 [(SA247-B005)]
MT28F800B3WGT@TSOP48 [(SA247-B005)]
MT28F800B5SGB@PSOP44 [(SA638)] MT28F800B5SGT@PSOP44
[(SA638)]
MT28F800B5WGB@TSOP48 [(SA247-B005)]
MT28F800B5WGT@TSOP48 [(SA247-B005)]
MT29F1G08ABAWP@TSOP48 [(SA247-B005)]
MT29F2G08AAAWG@TSOP48 [(SA247-B005)]
MT29F2G08AABWP@TSOP48 [(SA247-B005)]
MT29F2G08AACWP@TSOP48 [(SA247-B005)]
MT29F4G08AAAWP@TSOP48 [(SA247-B005)]
MT29F4G08BAB@TSOP48 [(SA247-B005)]
MT29F8G08DAA@TSOP48 [(SA247-B005)]

DRAM & SRAM

MTSRAM@FBGA48 [(SA634A-B005A-Y048F001)]

MICRONAS

MICROCONTROLLER

SDA555XFL@SDIP52(*) [(SA627-B5603)]

MICRON-CUSTOMER

E (E) PROM / FRAM / NVRAM

MT29F4G08AAWP (sony) @TSOP48 [(SA247+B005)]

mitsubishi

E (E) PROM / FRAM / NVRAM

M5L27128K

M5L2716

M5L27256K

M5L2732

M5L2732A

M5L27512

M5L27512K

M5L2764K

M5L27C512A

M5M27128P

M5M27256P

M5M27512P

M5M2764P

M5M27C100K

M5M27C100K@PLCC32 [(SA015A1T)]

[(SA410T)]

M5M27C100P

[(SA015A1T)]

M5M27C100P@TSOP32 [(SA410T)]

M5M27C101JK

M5M27C101JK@PLCC32 [(SA015A1T)]

[(SA410T)]

M5M27C101K

[(SA015A1T)]

M5M27C101K@TSOP32 [(SA410T)]

M5M27C101P

M5M27C101P@PLCC32 [(SA015A1T)]

[(SA410T)]

M5M27C102K

M5M27C100K@TSOP32

M5M27C100P@PLCC32

M5M27C101JK@TSOP32

M5M27C101K@PLCC32

M5M27C101P@TSOP32

M5M27C102K@PLCC44

[(SA244)]	
M5M27C102P	M5M27C102P@PLCC44
[(SA244)]	
M5M27C128K	
M5M27C201K	
M5M27C201K@PLCC32 [(SA015A1T)]	M5M27C201K@TSOP32
[(SA410T)]	
M5M27C202K	M5M27C202K@PLCC44
[(SA244)]	
M5M27C256 (K)	M5M27C256
(P)	
M5M27C256A (FP)	M5M27C256A
(K)	
M5M27C256A (P)	
M5M27C401K	
M5M27C401K@PLCC32 [(SA015A1T)]	M5M27C401K@TSOP32
[(SA410T)]	
M5M27C402K	M5M27C512
(FP)	
M5M27C512A (FP)	M5M27C512A
(K)	
M5M27C512A (P)	
M5M28F101	
M5M28F101@PLCC32 [(SA015A1T)]	M5M28F101@SOP32
[(SA438T)]	
M5M28F101@TSOP32 [(SA410T)]	
M5M28F101A	
M5M28F101A@PLCC32 [(SA015A1T)]	M5M28F101A@SOIC32
[(SA438T)]	
M5M28F101A@TSOP32 [(SA410T)]	
M5M29FB160A@TSOP48 [(SA247-B005)]	
M5M29FB800 (FP) @PSOP44 [(SA638)]	
M5M29FB800 (VP) @TSOP48 [(SA247-B005)]	
M5M29FT160A@TSOP48 [(SA247-B005)]	
M5M29FT800 (FP) @PSOP44 [(SA638)]	
M5M29FT800 (VP) @TSOP48 [(SA247-B005)]	
M5M29GB160B (VP) @TSOP48 [(SA247-B005)]	
M5M29GB320 (VP) @TSOP48 [(SA247-B005)]	
M5M29GB320 (WG) @CBGA48 [(SA642B-B026A-Y072F001)]	
M5M29GT160B (VP) @TSOP48 [(SA247-B005)]	
M5M29GT320 (VP) @TSOP48 [(SA247-B005)]	
M5M29GT320 (WG) @CBGA48 [(SA642B-B026A-Y072F001)]	
M5M29JB160A@TSOP48 [(SA247-B005)]	

M5M29JT160A@TSOP48 [(SA247-B005)]
M6M80011A [(SA023A)] M6M80011A@SOIC10
M6M80011A@SOIC16 [(SA023A)]
M6M80021 [(SA023A)] M6M80021@SOIC16
M6M80021@SOIC10 [(SA023A)]
M6M80041 [(SA023A)] M6M80041@SOIC10
M6MG3B641S16TP@TSOP52 [(SA657-B036)]
M6MG3T641S16TP@TSOP52 [(SA657-B036)]
M6MGB321S4TP@TSOP52 [(SA657-B036)]
M6MGB321S8TP@TSOP52 [(SA657-B036)]
M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGB331S8KT@TSOP52 [(SA657-B036)]
M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]
M6MGB641S16TP@TSOP52 [(SA657-B036)]
M6MGB641S4TP@TSOP52 [(SA657-B036)]
M6MGB641S8TP@TSOP52 [(SA657-B036)]
M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]
M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]
M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]
M6MGE157S4KT@TSOP52 [(SA657-B055)]
M6MGT321S4TP@TSOP52 [(SA657-B036)]
M6MGT321S8TP@TSOP52 [(SA657-B036)]
M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGT331S8KT@TSOP52 [(SA657-B036)]
M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]
M6MGT641S16TP@TSOP52 [(SA657-B036)]
M6MGT641S4TP@TSOP52 [(SA657-B036)]
M6MGT641S8TP@TSOP52 [(SA657-B036)]
M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]
M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]

MICROCONTROLLER

M30240EFCFP@QFP80 (Renesas) [(PCA7302E1F-80)]
M30620EFCFP@QFP100 (Renesas) [(PCA7412F-100)]
M30620ECFS@QFN100 (Renesas) [(PCA7412L-100)]
M30620ECGP@LQFP100 (Renesas) [(PCA7412G-100)]

M30621ECGP@QFP80 (Renesas) [(PCA7413F-80)]
M30622ECTFP@QFP100 (Renesas) [(PCA7412F-100)]
M30623ECTGP@QFP80 (Renesas) [(PCA7413F-80)]
M306V0EEFP@QFP100 (Renesas) [(PCA7412F-100)]
M306V0EEFS@QFN100 (Renesas) [(PCA7412L-100)]
M306V2EEFP@QFP100 (Renesas) [(PCA7412F-100)]
M306V2EEFS@QFN100 (Renesas) [(PCA7412L-100)]
M34282E2GP [(SA026)] M34283G2GP
[(SA026)]
M34283G2GP (ISP) [ISP-HEADER01]
M34513E4FP@LQFP32 (Renesas) [(PCA7442FPG02)]
M34513E4SP@SDIP32 (Renesas) [(PCA7442SP)]
M34513E8FP@LQFP32 (Renesas) [(PCA7442FPG02)]
M34514E8FP@SSOP42 (Renesas) [(PCA7441)]
M34518E8FP@LQFP32 (Renesas) [(PCA7442FPG02)]
M34518E8SP@SDIP32 (Renesas) [(PCA7442SP)]
M34519E8FP@SSOP42 (Renesas) [(PCA7441)]
M34524EDFP@QFP64 (Renesas) [(PCA7448)]
M34551E8FP@QFP48 (Renesas) [(PCA7414)]
M34554EDFP@QFP64 (Renesas) [(PCA7448)]
M34570E8FP@SSOP36 (Renesas) [(PCA7425)]
M34570EDFP@SSOP36 (Renesas) [(PCA7425)]
M34583EDFP@LQFP32 (Renesas) [(PCA7442FPG02)]
M34584EDFP@SSOP42 (Renesas) [(PCA7441)]
M37150EFFP@SSOP42 (Renesas) [(PCA7450FP)]
M37151EFFP@SSOP42 (Renesas) [(PCA7450FP)]
M37160EFFP@SSOP42 (Renesas) [(PCA7450FP)]
M37161EFFP@SSOP42 (Renesas) [(PCA7450FP)]
M37516E6HKP@QFN44 (Renesas) [(PCA7446)]
M37516E6HP@LQFP48 (Renesas) [(PCA7419)]
M37540E2FP@SSOP36 (Renesas) [(PCA7435FPG02)]
M37540E2GP@LQFP32 (Renesas) [(PCA7435GPG03)]
M37540E2SP@SDIP32 (Renesas) [(PCA7435SPG02)]
M37540E8FP@SSOP36 (Renesas) [(PCA7435FPG02)]
M37540E8GP@LQFP32 (Renesas) [(PCA7435GPG03)]
M37540E8SP@SDIP32 (Renesas) [(PCA7435SPG02)]
M37544G2A (GP)@LQFP32 [(SA663)]
M37544G2A (GP)@LQFP32 (ISP) [ISP-HEADER01]
M37544G2A (SP)@SDIP32 [(SA653)]
M37544G2A (SP)@SDIP32 (ISP) [ISP-HEADER01]
M37545G4 (GP)@LQFP32 [(SA663)] M37545G6 (GP)@LQFP32
[(SA663)]
M37545G8 (GP)@LQFP32 [(SA663)] M37546G2 (FP)@SSOP36

[(SA645)]
 M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]
 M37546G2(GP)@LQFP32 [(SA663)]
 M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]
 M37546G2(SP)@SDIP32 [(SA653)]
 M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]
 M37546G4(FP)@SSOP36 [(SA645)]
 M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]
 M37546G4(GP)@LQFP32 [(SA663)]
 M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]
 M37546G4(SP)@SDIP32 [(SA653)]
 M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]
 M37547G2(FP)@SSOP36 [(SA645)]
 M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]
 M37547G4(FP)@SSOP36 [(SA645)]
 M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]
 M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20
 [(SA026)]
 M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SDIP24
 [(SA653)]
 M37549G2FP@SDIP24 [(SA653)] M37549G3FP@SDIP24
 [(SA653)]
 M37560EFDFP@QFP100(Renesas) [(PCA4738F-100A)]
 M37560EFFP@QFN100(Renesas) [(PCA4738L-100A)]
 M37560EFFP@QFP100(Renesas) [(PCA4738F-100A)]
 M37560EFGP@LQFP100(Renesas) [(PCA4738G-100A)]
 M37630E4FP@QFP44(Renesas) [(PCA7430)]
 M37630E4FS@QFN80(Renesas) [(PCA7431)]
 M37640E8FP@QFP80(Renesas) [(PCA7440FP)]
 M37640E8FS@QFN80(Renesas) [(PCA7440FS)]
 M37733EHBFP@QFP80(Renesas) [(PCA4774G05)]
 M37733EHBFS@QFN80(Renesas) [(PCA4708G05)]
 M37735EHBFP@QFP80(Renesas) [(PCA4774G05)]
 M37735EHBFS@QFN80(Renesas) [(PCA4708G05)]
 M37736EHBGP@QFP100(Renesas) [(PCA7422GPG02)]
 M37736EHBGS@QFN100(Renesas) [(PCA7422GSG02)]
 M37751E6CFP@QFP80(Renesas) [(PCA4774G05)]
 M37751E6CFS@QFN80(Renesas) [(PCA4708G05)]
 M37751F6CFP@QFP80(Renesas) [(PCA4774G05)]
 M38027E8DFP@QFP64(Mitsubishi) [(PCA4738F-64A)]
 M38027E8DSP@DIP64(Mitsubishi) [(BBBB)]
 M38027E8DXXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]
 M38027E8DXXXSP@DIP64(Mitsubishi) [(BBBB)]

M38027E8FS@LCC64(Mitsubishi) [(BBBB)]
M38027E8SP@DIP64(Mitsubishi) [(BBBB)]
M38027E8SS@DIP64(Mitsubishi) [(BBBB)]
M38027E8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]
M38027E8-XXXSP@DIP64(Mitsubishi) [(BBBB)]
M38027M8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]
M38039FFFP@QFP64(Renesas) [(PCA4738FF-64)]
M38039FFHP@LQFP64(Renesas) [(PCA4738HF-64)]
M38039FFSP@SDIP64(Renesas) [(PCA4738SF-64)]
M38049FFFP@QFP64(Renesas) [(PCA4738FF-64)]
M38049FFHP@LQFP64(Renesas) [(PCA4738HF-64)]
M38049FFSP@SDIP64(Renesas) [(PCA4738SF-64)]
M38223E4FP@QFP80(Renesas) [(PCA4738F-80A)]
M38223E4FS@QFN80(Renesas) [(PCA4738L-80A)]
M38223E4GP@QFP80(Renesas) [(PCA4738G-80A)]
M38223E4HP@LQFP80(Renesas) [(PCA4738H-80A)]
M38227ECFP@QFP80(Renesas) [(PCA4738F-80A)]
M38227ECFS@QFN80(Renesas) [(PCA4738L-80A)]
M38227ECHP@LQFP80(Renesas) [(PCA4738H-80A)]
M38267E8FP@QFP100(Renesas) [(PCA4738F-100A)]
M38267E8GP@LQFP100(Renesas) [(PCA4738G-100A)]
M3826AEFFP@QFP100(Renesas) [(PCA4738F-100A)]
M3826AEFFS@QFN100(Renesas) [(PCA4738L-100A)]
M3826AEFGP@LQFP100(Renesas) [(PCA4738G-100A)]
M38504E6FP@SSOP42(Renesas) [(PCA4738F-42A)]
M38504E6SP@SDIP42(Renesas) [(PCA4738S-42A)]
M38504E6SS@SDIP42(Renesas) [(PCA4738S-42A)]
M38514E6FP@SSOP42(Renesas) [(PCA4738F-42A)]
M38514E6SP@SDIP42(Renesas) [(PCA4738S-42A)]
M38514E6SS@SDIP42(Renesas) [(PCA4738S-42A)]
M38867E8AFS@QFN80(Renesas) [(PCA4738L-80A)]
M38867E8AHP@LQFP80(Renesas) [(PCA4738H-80A)]
M38869FFAGP@QFP80(Renesas) [(PCA4738GF-80)]
M38869FFAHP@LQFP80(Renesas) [(PCA4738HF-80)]
M38B79FFFP@QFP100(Renesas) [(PCA7438FF-100)]
M38C13E6FP@LQFP64(Renesas) [(PCA7438F-64A)]
M38C13E6HP@QFP64(Renesas) [(PCA7438H-64A)]
M38C89EFP@LQFP144(Renesas) [(PCA7447FP)]
R5F21102DFP@TQFP32 [(SA663+B005)]
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21102FP@TQFP32 [(SA663+B005)]
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]
R5F21103DFP@TQFP32 [(SA663+B005)]

R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21103FP@TQFP32 [(SA663+B005)]
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]
R5F21104DFP@TQFP32 [(SA663+B005)]
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21104FP@TQFP32 [(SA663+B005)]
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]
R5F21112DFP@TQFP32 [(SA663+B005)]
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21112FP@TQFP32 [(SA663+B005)]
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]
R5F21113DFP@TQFP32 [(SA663+B005)]
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21113FP@TQFP32 [(SA663+B005)]
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]
R5F21114DFP@TQFP32 [(SA663+B005)]
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21114FP@TQFP32 [(SA663+B005)]
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]
R5F21122DFP@TQFP32 [(SA663+B005)]
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21122FP@TQFP32 [(SA663+B005)]
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]
R5F21123DFP@TQFP32 [(SA663+B005)]
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21123FP@TQFP32 [(SA663+B005)]
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]
R5F21124DFP@TQFP32 [(SA663+B005)]
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21124FP@TQFP32 [(SA663+B005)]
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]
R5F21132DFP@TQFP32 [(SA663+B005)]
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21132FP@TQFP32 [(SA663+B005)]
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]
R5F21133DFP@TQFP32 [(SA663+B005)]
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21133FP@TQFP32 [(SA663+B005)]
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]
R5F21134DFP@TQFP32 [(SA663+B005)]
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21134FP@TQFP32 [(SA663+B005)]
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]

R5F21181DD@SDIP20 [(SA725-B005)]
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(single wire) [(SA725-B005)]
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]
R5F21181DSP@TSSOP20 [(SA026-B001)]
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21181SP@TSSOP20 [(SA026-B001)]
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182DD@SDIP20 [(SA725-B005)]
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(single wire) [(SA725-B005)]
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]
R5F21182DSP@TSSOP20 [(SA026-B001)]
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182NP@QFN28 [(SA697-B006)]
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]
R5F21182NP@QFN28(single wire) [(SA697-B006)]
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21182NP@QFN28(UART mode) [(SA697+B006)]
R5F21182SP@TSSOP20 [(SA026-B001)]
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183DD@SDIP20 [(SA725-B005)]
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(single wire) [(SA725-B005)]
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]
R5F21183DSP@TSSOP20 [(SA026-B001)]
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]

R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183NP@QFN28 [(SA697-B006)]
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]
R5F21183NP@QFN28(single wire) [(SA697-B006)]
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21183NP@QFN28(UART mode) [(SA697+B006)]
R5F21183SP@TSSOP20 [(SA026-B001)]
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184DD@SDIP20 [(SA725-B005)]
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(single wire) [(SA725-B005)]
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]
R5F21184DSP@TSSOP20 [(SA026-B001)]
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184NP@QFN28 [(SA697-B006)]
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]
R5F21184NP@QFN28(single wire) [(SA697-B006)]
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21184NP@QFN28(UART mode) [(SA697+B006)]
R5F21184SP@TSSOP20 [(SA026-B001)]
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191DD@SDIP20 [(SA725-B005)]
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(single wire) [(SA725+B005)]
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]
R5F21191DSP@TSSOP20 [(SA026-B001)]
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191SP@TSSOP20 [(SA026-B001)]

R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192DD@SDIP20 [(SA725-B005)]
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(single wire) [(SA725+B005)]
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]
R5F21192DSP@TSSOP20 [(SA026-B001)]
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192NP@QFN28 [(SA697-B006)]
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]
R5F21192NP@QFN28(single wire) [(SA697+B006)]
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21192NP@QFN28(UART mode) [(SA697+B006)]
R5F21192SP@TSSOP20 [(SA026-B001)]
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193DD@SDIP20 [(SA725-B005)]
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(single wire) [(SA725+B005)]
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]
R5F21193DSP@TSSOP20 [(SA026-B001)]
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193NP@QFN28 [(SA697-B006)]
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]
R5F21193NP@QFN28(single wire) [(SA697+B006)]
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21193NP@QFN28(UART mode) [(SA697+B006)]
R5F21193SP@TSSOP20 [(SA026-B001)]
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194DD@SDIP20 [(SA725-B005)]
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(single wire) [(SA725+B005)]
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]
R5F21194DSP@TSSOP20 [(SA026-B001)]
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194NP@QFN28 [(SA697-B006)]
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]
R5F21194NP@QFN28(single wire) [(SA697+B006)]
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21194NP@QFN28(UART mode) [(SA697+B006)]
R5F21194SP@TSSOP20 [(SA026-B001)]
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1DD@SDIP20 [(SA725-B005)]
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A1DSP@TSSOP20 [(SA026-B001)]
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1SP@TSSOP20 [(SA026-B001)]
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2DD@SDIP20 [(SA725-B005)]
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A2DSP@TSSOP20 [(SA026-B001)]
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]

R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2NP@QFN28 [(SA697-B006)]
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(single wire) [(SA697-B006)]
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]
R5F211A2SP@TSSOP20 [(SA026-B001)]
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3DD@SDIP20 [(SA725-B005)]
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A3DSP@TSSOP20 [(SA026-B001)]
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3NP@QFN28 [(SA697-B006)]
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(single wire) [(SA697-B006)]
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]
R5F211A3SP@TSSOP20 [(SA026-B001)]
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4DD@SDIP20 [(SA725-B005)]
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A4DSP@TSSOP20 [(SA026-B001)]
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]

R5F211A4NP@QFN28 [(SA697-B006)]
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(single wire) [(SA697-B006)]
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]
R5F211A4SP@TSSOP20 [(SA026-B001)]
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1DD@SDIP20 [(SA725-B005)]
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B1DSP@TSSOP20 [(SA026-B001)]
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1SP@TSSOP20 [(SA026-B001)]
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2DD@SDIP20 [(SA725-B005)]
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B2DSP@TSSOP20 [(SA026-B001)]
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2NP@QFN28 [(SA697-B006)]
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(single wire) [(SA697+B006)]
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]
R5F211B2SP@TSSOP20 [(SA026-B001)]
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]

R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3DD@SDIP20 [(SA725-B005)]
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B3DSP@TSSOP20 [(SA026-B001)]
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3NP@QFN28 [(SA697-B006)]
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(single wire) [(SA697+B006)]
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]
R5F211B3SP@TSSOP20 [(SA026-B001)]
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4DD@SDIP20 [(SA725-B005)]
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B4DSP@TSSOP20 [(SA026-B001)]
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4NP@QFN28 [(SA697-B006)]
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(single wire) [(SA697+B006)]
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]
R5F211B4SP@TSSOP20 [(SA026-B001)]
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21206JFP@TQFP48 [(SA248-B005)]

R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]
R5F21206KFP@TQFP48 [(SA248-B005)]
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]
R5F21207JFP@TQFP48 [(SA248-B005)]
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]
R5F21207KFP@TQFP48 [(SA248-B005)]
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]
R5F21208JFP@TQFP48 [(SA248-B005)]
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]
R5F21208KFP@TQFP48 [(SA248-B005)]
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AJFP@TQFP48 [(SA248-B005)]
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AKFP@TQFP48 [(SA248-B005)]
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CJFP@TQFP48 [(SA248-B005)]
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CKFP@TQFP48 [(SA248-B005)]
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21216JFP@TQFP48 [(SA248-B005)]
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]
R5F21216KFP@TQFP48 [(SA248-B005)]
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]
R5F21217JFP@TQFP48 [(SA248-B005)]
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]
R5F21217KFP@TQFP48 [(SA248-B005)]
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]
R5F21218JFP@TQFP48 [(SA248-B005)]
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]

R5F21218JFP@TQFP48(single wire) [(SA248-B005)]
R5F21218KFP@TQFP48 [(SA248-B005)]
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AJFP@TQFP48 [(SA248-B005)]
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AKFP@TQFP48 [(SA248-B005)]
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CJFP@TQFP48 [(SA248-B005)]
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CKFP@TQFP48 [(SA248-B005)]
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21226JFP@TQFP48 [(SA248-B005)]
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]
R5F21226KFP@TQFP48 [(SA248-B005)]
R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]
R5F21227JFP@TQFP48 [(SA248-B005)]
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]
R5F21227KFP@TQFP48 [(SA248-B005)]
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]
R5F21228JFP@TQFP48 [(SA248-B005)]
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]
R5F21228KFP@TQFP48 [(SA248-B005)]
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AJFP@TQFP48 [(SA248-B005)]
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AKFP@TQFP48 [(SA248-B005)]
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CJFP@TQFP48 [(SA248-B005)]
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]

R5F2122CKFP@TQFP48 [(SA248-B005)]
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21236JFP@TQFP48 [(SA248-B005)]
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]
R5F21236KFP@TQFP48 [(SA248-B005)]
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]
R5F21237JFP@TQFP48 [(SA248-B005)]
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]
R5F21237KFP@TQFP48 [(SA248-B005)]
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]
R5F21238JFP@TQFP48 [(SA248-B005)]
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]
R5F21238KFP@TQFP48 [(SA248-B005)]
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238KFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AJFP@TQFP48 [(SA248-B005)]
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AKFP@TQFP48 [(SA248-B005)]
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CJFP@TQFP48 [(SA248-B005)]
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CKFP@TQFP48 [(SA248-B005)]
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]

R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21262DFP@QFP32 [(SA663)]
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(single wire) [(SA663)]
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(UART mode) [(SA663)]
R5F21262JFP@QFP32 [(SA663)]
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(single wire) [(SA663)]
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(UART mode) [(SA663)]
R5F21262KFP@QFP32 [(SA663)]
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(single wire) [(SA663)]
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(UART mode) [(SA663)]
R5F21262NFP@QFP32 [(SA663)]
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(single wire) [(SA663)]
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(UART mode) [(SA663)]
R5F21262SDFP@QFP32 [(SA663)]

R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(single wire) [(SA663)]
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(UART mode) [(SA663)]
R5F21262SJFP@QFP32 [(SA663)]
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(single wire) [(SA663)]
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(UART mode) [(SA663)]
R5F21262SKFP@QFP32 [(SA663)]
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(single wire) [(SA663)]
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(UART mode) [(SA663)]
R5F21262SNFP@QFP32 [(SA663)]
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(single wire) [(SA663)]
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(UART mode) [(SA663)]
R5F21264DFP@QFP32 [(SA663)]
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(single wire) [(SA663)]
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(UART mode) [(SA663)]
R5F21264JFP@QFP32 [(SA663)]
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(single wire) [(SA663)]
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(UART mode) [(SA663)]
R5F21264KFP@QFP32 [(SA663)]
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(single wire) [(SA663)]
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(UART mode) [(SA663)]
R5F21264NFP@QFP32 [(SA663)]
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(single wire) [(SA663)]
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(UART mode) [(SA663)]
R5F21264SDFP@QFP32 [(SA663)]
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(single wire) [(SA663)]
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21264SDFP@QFP32(UART mode) [(SA663)]
R5F21264SJFP@QFP32 [(SA663)]
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(single wire) [(SA663)]
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(UART mode) [(SA663)]
R5F21264SKFP@QFP32 [(SA663)]
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(single wire) [(SA663)]
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(UART mode) [(SA663)]
R5F21264SNFP@QFP32 [(SA663)]
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(single wire) [(SA663)]
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(UART mode) [(SA663)]
R5F21265DFP@QFP32 [(SA663)]
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(single wire) [(SA663)]
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(UART mode) [(SA663)]
R5F21265JFP@QFP32 [(SA663)]
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(single wire) [(SA663)]
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(UART mode) [(SA663)]
R5F21265KFP@QFP32 [(SA663)]
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(single wire) [(SA663)]
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(UART mode) [(SA663)]
R5F21265NFP@QFP32 [(SA663)]
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(single wire) [(SA663)]
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(UART mode) [(SA663)]
R5F21265SDFP@QFP32 [(SA663)]
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(single wire) [(SA663)]
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(UART mode) [(SA663)]
R5F21265SJFP@QFP32 [(SA663)]
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]

R5F21265SJFP@QFP32(single wire) [(SA663)]
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(UART mode) [(SA663)]
R5F21265SKFP@QFP32 [(SA663)]
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(single wire) [(SA663)]
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(UART mode) [(SA663)]
R5F21265SNFP@QFP32 [(SA663)]
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(single wire) [(SA663)]
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(UART mode) [(SA663)]
R5F21266DFP@QFP32 [(SA663)]
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(single wire) [(SA663)]
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(UART mode) [(SA663)]
R5F21266JFP@QFP32 [(SA663)]
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(single wire) [(SA663)]
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(UART mode) [(SA663)]
R5F21266KFP@QFP32 [(SA663)]
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(single wire) [(SA663)]
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(UART mode) [(SA663)]
R5F21266NFP@QFP32 [(SA663)]
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(single wire) [(SA663)]
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(UART mode) [(SA663)]
R5F21266SDFP@QFP32 [(SA663)]
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(single wire) [(SA663)]
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(UART mode) [(SA663)]
R5F21266SJFP@QFP32 [(SA663)]
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(single wire) [(SA663)]
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(UART mode) [(SA663)]

R5F21266SKFP@QFP32 [(SA663)]
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(single wire) [(SA663)]
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(UART mode) [(SA663)]
R5F21266SNFP@QFP32 [(SA663)]
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(single wire) [(SA663)]
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(UART mode) [(SA663)]
R5F21272DFP@QFP32 [(SA663)]
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(single wire) [(SA663)]
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(UART mode) [(SA663)]
R5F21272JFP@QFP32 [(SA663)]
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(single wire) [(SA663)]
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(UART mode) [(SA663)]
R5F21272KFP@QFP32 [(SA663)]
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(single wire) [(SA663)]
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(UART mode) [(SA663)]
R5F21272NFP@QFP32 [(SA663)]
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(single wire) [(SA663)]
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(UART mode) [(SA663)]
R5F21272SDFP@QFP32 [(SA663)]
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(single wire) [(SA663)]
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(UART mode) [(SA663)]
R5F21272SJFP@QFP32 [(SA663)]
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(single wire) [(SA663)]
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(UART mode) [(SA663)]
R5F21272SKFP@QFP32 [(SA663)]
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(single wire) [(SA663)]

R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(UART mode) [(SA663)]
R5F21272SNFP@QFP32 [(SA663)]
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(single wire) [(SA663)]
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(UART mode) [(SA663)]
R5F21274DFP@QFP32 [(SA663)]
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(single wire) [(SA663)]
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(UART mode) [(SA663)]
R5F21274JFP@QFP32 [(SA663)]
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(single wire) [(SA663)]
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(UART mode) [(SA663)]
R5F21274KFP@QFP32 [(SA663)]
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(single wire) [(SA663)]
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(UART mode) [(SA663)]
R5F21274NFP@QFP32 [(SA663)]
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(single wire) [(SA663)]
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(UART mode) [(SA663)]
R5F21274SDFP@QFP32 [(SA663)]
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(single wire) [(SA663)]
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(UART mode) [(SA663)]
R5F21274SJFP@QFP32 [(SA663)]
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(single wire) [(SA663)]
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(UART mode) [(SA663)]
R5F21274SKFP@QFP32 [(SA663)]
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(single wire) [(SA663)]
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(UART mode) [(SA663)]
R5F21274SNFP@QFP32 [(SA663)]

R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(single wire) [(SA663)]
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(UART mode) [(SA663)]
R5F21275DFP@QFP32 [(SA663)]
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(single wire) [(SA663)]
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(UART mode) [(SA663)]
R5F21275JFP@QFP32 [(SA663)]
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(single wire) [(SA663)]
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(UART mode) [(SA663)]
R5F21275KFP@QFP32 [(SA663)]
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(single wire) [(SA663)]
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(UART mode) [(SA663)]
R5F21275NFP@QFP32 [(SA663)]
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(single wire) [(SA663)]
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(UART mode) [(SA663)]
R5F21275SDFP@QFP32 [(SA663)]
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(single wire) [(SA663)]
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(UART mode) [(SA663)]
R5F21275SJFP@QFP32 [(SA663)]
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(single wire) [(SA663)]
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(UART mode) [(SA663)]
R5F21275SKFP@QFP32 [(SA663)]
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(single wire) [(SA663)]
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(UART mode) [(SA663)]
R5F21275SNFP@QFP32 [(SA663)]
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(single wire) [(SA663)]
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21275SNFP@QFP32(UART mode) [(SA663)]
R5F21276DFP@QFP32 [(SA663)]
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(single wire) [(SA663)]
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(UART mode) [(SA663)]
R5F21276JFP@QFP32 [(SA663)]
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(single wire) [(SA663)]
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(UART mode) [(SA663)]
R5F21276KFP@QFP32 [(SA663)]
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(single wire) [(SA663)]
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(UART mode) [(SA663)]
R5F21276NFP@QFP32 [(SA663)]
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(single wire) [(SA663)]
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(UART mode) [(SA663)]
R5F21276SDFP@QFP32 [(SA663)]
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(single wire) [(SA663)]
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(UART mode) [(SA663)]
R5F21276SJFP@QFP32 [(SA663)]
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(single wire) [(SA663)]
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(UART mode) [(SA663)]
R5F21276SKFP@QFP32 [(SA663)]
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(single wire) [(SA663)]
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(UART mode) [(SA663)]
R5F21276SNFP@QFP32 [(SA663)]
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(single wire) [(SA663)]
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(UART mode) [(SA663)]
R5F21282DSP@SOIC20 [(SA026)]
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]

R5F21282DSP@SOIC20(single wire) [(SA026)]
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(UART mode) [(SA026)]
R5F21282JSP@SOIC20 [(SA026)]
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(single wire) [(SA026)]
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(UART mode) [(SA026)]
R5F21282KSP@SOIC20 [(SA026)]
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(single wire) [(SA026)]
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(UART mode) [(SA026)]
R5F21282NSP@SOIC20 [(SA026)]
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(single wire) [(SA026)]
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(UART mode) [(SA026)]
R5F21282SDSP@SOIC20 [(SA026)]
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(single wire) [(SA026)]
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(UART mode) [(SA026)]
R5F21282SJSP@SOIC20 [(SA026)]
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(single wire) [(SA026)]
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(UART mode) [(SA026)]
R5F21282SKSP@SOIC20 [(SA026)]
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(single wire) [(SA026)]
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(UART mode) [(SA026)]
R5F21282SNSP@SOIC20 [(SA026)]
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(single wire) [(SA026)]
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(UART mode) [(SA026)]
R5F21284DSP@SOIC20 [(SA026)]
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(single wire) [(SA026)]
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(UART mode) [(SA026)]

R5F21284JSP@SOIC20 [(SA026)]
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(single wire) [(SA026)]
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(UART mode) [(SA026)]
R5F21284KSP@SOIC20 [(SA026)]
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(single wire) [(SA026)]
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(UART mode) [(SA026)]
R5F21284NSP@SOIC20 [(SA026)]
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(single wire) [(SA026)]
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(UART mode) [(SA026)]
R5F21284SDSP@SOIC20 [(SA026)]
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(single wire) [(SA026)]
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(UART mode) [(SA026)]
R5F21284SJSP@SOIC20 [(SA026)]
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(single wire) [(SA026)]
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(UART mode) [(SA026)]
R5F21284SKSP@SOIC20 [(SA026)]
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(single wire) [(SA026)]
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(UART mode) [(SA026)]
R5F21284SNSP@SOIC20 [(SA026)]
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(single wire) [(SA026)]
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(UART mode) [(SA026)]
R5F21292DSP@SOIC20 [(SA026)]
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(single wire) [(SA026)]
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(UART mode) [(SA026)]
R5F21292JSP@SOIC20 [(SA026)]
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(single wire) [(SA026)]

R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(UART mode) [(SA026)]
R5F21292KSP@SOIC20 [(SA026)]
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(single wire) [(SA026)]
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(UART mode) [(SA026)]
R5F21292NSP@SOIC20 [(SA026)]
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(single wire) [(SA026)]
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(UART mode) [(SA026)]
R5F21292SDSP@SOIC20 [(SA026)]
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(single wire) [(SA026)]
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(UART mode) [(SA026)]
R5F21292SJSP@SOIC20 [(SA026)]
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(single wire) [(SA026)]
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(UART mode) [(SA026)]
R5F21292SKSP@SOIC20 [(SA026)]
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(single wire) [(SA026)]
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(UART mode) [(SA026)]
R5F21292SNSP@SOIC20 [(SA026)]
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(single wire) [(SA026)]
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(UART mode) [(SA026)]
R5F21294DSP@SOIC20 [(SA026)]
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(single wire) [(SA026)]
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(UART mode) [(SA026)]
R5F21294JSP@SOIC20 [(SA026)]
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(single wire) [(SA026)]
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(UART mode) [(SA026)]
R5F21294KSP@SOIC20 [(SA026)]

R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(single wire) [(SA026)]
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(UART mode) [(SA026)]
R5F21294NSP@SOIC20 [(SA026)]
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(single wire) [(SA026)]
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(UART mode) [(SA026)]
R5F21294SDSP@SOIC20 [(SA026)]
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(single wire) [(SA026)]
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(UART mode) [(SA026)]
R5F21294SJSP@SOIC20 [(SA026)]
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(single wire) [(SA026)]
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(UART mode) [(SA026)]
R5F21294SKSP@SOIC20 [(SA026)]
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(single wire) [(SA026)]
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(UART mode) [(SA026)]
R5F21294SNSP@SOIC20 [(SA026)]
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(single wire) [(SA026)]
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(UART mode) [(SA026)]
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]

R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]

R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212G4SDFP@QFP32 [(SA663)]
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SDFP@QFP32(single wire) [(SA663)]
R5F212G4SNFP@QFP32 [(SA663)]

R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SNFP@QFP32(single wire) [(SA663)]
R5F212G5SDFP@QFP32 [(SA663)]
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SDFP@QFP32(single wire) [(SA663)]
R5F212G5SNFP@QFP32 [(SA663)]
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SNFP@QFP32(single wire) [(SA663)]
R5F212G6SDFP@QFP32 [(SA663)]
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SDFP@QFP32(single wire) [(SA663)]
R5F212G6SNFP@QFP32 [(SA663)]
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SNFP@QFP32(single wire) [(SA663)]
R5F212H1SDSP@TSSOP20 [(SA026-B001)]
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)]
R5F212H1SNSP@TSSOP20 [(SA026-B001)]
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)]
R5F212H2SDSP@TSSOP20 [(SA725-B005)]
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)]
R5F212H2SNSP@TSSOP20 [(SA725-B005)]
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)]
R5F212J0SDSP@TSSOP20 [(SA026-B001)]
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)]
R5F212J0SNSP@TSSOP20 [(SA026-B001)]
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)]
R5F212J1SDSP@TSSOP20 [(SA026-B001)]
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)]
R5F212J1SNSP@TSSOP20 [(SA026-B001)]
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)]
R5F212K2SDFP@QFP32 [(SA663-B005)]
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SDFP@QFP32(single wire) [(SA663-B005)]
R5F212K2SNFP@QFP32 [(SA663-B005)]
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]

R5F212K2SNFP@QFP32(single wire) [(SA663-B005)]
 R5F212K4SDFP@QFP32 [(SA663-B005)]
 R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]
 R5F212K4SDFP@QFP32(single wire) [(SA663-B005)]
 R5F212K4SNFP@QFP32 [(SA663-B005)]
 R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]
 R5F212K4SNFP@QFP32(single wire) [(SA663-B005)]
 R5F212L2SDFP@QFP32 [(SA663-B005)]
 R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]
 R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]
 R5F212L2SNFP@QFP32 [(SA663-B005)]
 R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]
 R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]
 R5F212L4SDFP@QFP32 [(SA663-B005)]
 R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]
 R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]
 R5F212L4SNFP@QFP32 [(SA663-B005)]
 R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]
 R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]

MOSEL-VITELIC

E (E) PROM / FRAM / NVRAM

V29C31004B [(SA015A1T)]	V29C31004B@PLCC32
V29C31004B@TSOP32 [(SA410T)]	
V29C31004T	
V29C31004T@PLCC32 [(SA015A1T)]	V29C31004T@TSOP32
[(SA410T)]	
V29C51000B	V29C51000B@PLCC32
[(SA015A1T)]	
V29C51000T	V29C51000T@PLCC32
[(SA015A1T)]	
V29C51001B	V29C51001B@PLCC32
[(SA015A1T)]	
V29C51001B@TSOP32 [(SA410T)]	
V29C51001T	
V29C51001T@PLCC32 [(SA015A1T)]	V29C51001T@TSOP32
[(SA410T)]	
V29C51002B	V29C51002B@PLCC32
[(SA015A1T)]	

V29C51002B@TSOP32 [(SA410T)]	
V29C51002T	
V29C51002T@PLCC32 [(SA015A1T)]	V29C51002T@TSOP32
[(SA410T)]	
V29C51004B	V29C51004B@PLCC32
[(SA015A1T)]	
V29C51004B@TSOP32 [(SA410T)]	
V29C51004T	
V29C51004T@PLCC32 [(SA015A1T)]	V29C51004T@TSOP32
[(SA410T)]	
V29LC51000	V29LC51000@PLCC32
[(SA015A1T)]	
V29LC51001	V29LC51001@PLCC32
[(SA015A1T)]	
V29LC51002	V29LC51002@PLCC32
[(SA015A1T)]	

MICROCONTROLLER

MSU1958	MSU1958@PLCC44
[(SA244)]	
MSU1958@TQFP44 [(SA245A)]	
MSU2952	
MSU2952@PLCC44 [(SA244)]	MSU2952@TQFP44
[(SA245A)]	
MSU2958	MSU2958@PLCC44
[(SA244)]	
MSU2958@TQFP44 [(SA245A)]	
MSU2964	
MSU2964@PLCC44 [(SA244)]	MSU2964@TQFP44
[(SA245A)]	

MOSTEK

E (E) PROM / FRAM / NVRAM

ET2716
ETC2716
ETC2732
MK2716
MK2764

MK48C02
MK48C12
MK48T02
MK48T08
MK48T12
MK48T12B
MK48T18
MK48Z02
MK48Z08
MK48Z12
MK48Z12B
MK48Z18

MOTOROLA

E (E) PROM / FRAM / NVRAM

MC68764
MC68766
MCM2716

DRAM & SRAM

MCM2018A [(SA015A1T)]	MCM2018A@PLCC32
MCM60256A [(SA630)]	MCM60256A@SOIC28
MCM60256AC [(SA630)]	MCM60256AC@SOIC28
MCM60256AV [(SA630)]	MCM60256AV@SOIC28
MCM60L256A [(SA630)]	MCM60L256A@SOIC28
MCM60L256AC [(SA630)]	MCM60L256AC@SOIC28
MCM60L256AV [(SA630)]	MCM60L256AV@SOIC28
MCM6206 [(SA630)]	MCM6206@SOIC28
MCM6206C [(SA630)]	MCM6206C@SOIC28

MCM6207	MCM6207@SOJ24
[(SA646)]	
MCM6207C	MCM6207C@SOJ24
[(SA646)]	
MCM6208	MCM6208@SOJ24
[(SA646)]	
MCM6208C	MCM6208C@SOJ24
[(SA646)]	
MCM6209	MCM6209@SOJ28
[(SA646)]	
MCM6209C	MCM6209C@SOJ28
[(SA646)]	
MCM6229	MCM6229 (300m)@SOJ28
[(SA646)]	
MCM6229 (400m)@SOJ28	[(SA661)]
MCM6229A	
MCM6229A (300m)@SOJ28	MCM6229A (400m)@SOJ28
[(SA661)]	
MCM6264	MCM6264@SOIC28
[(SA630)]	
MCM6264C	MCM6264C@SOIC28
[(SA630)]	
MCM6268	
MCM6269	
MCM6287	MCM6287@SOJ24
[(SA646)]	
MCM6288	MCM6288@SOJ22
[(SA646)]	
MCM6288B	MCM6288B@SOJ22
[(SA646)]	
MCM6288C	MCM6288C@SOJ22
[(SA646)]	
MCM6290	MCM6290@SOJ24
[(SA646)]	
MCM6290B	MCM6290B@SOJ24
[(SA646)]	
MCM6290C	MCM6290C@SOJ24
[(SA646)]	
MCM62L07	MCM62L07@SOJ24
[(SA646)]	
MCM62L08	MCM62L08@SOJ24
[(SA646)]	
MCM62L09	MCM62L09@SOJ28

[(SA646)]	
MCM6706	MCM6706@SOIC28
[(SA630)]	
MCM6706A	MCM6706A@SOJ28
[(SA646)]	
MCM6708A	MCM6708A@SOJ24
[(SA646)]	
MCM6709A	MCM6709A@SOJ28
[(SA646)]	

MICROCONTROLLER

MC56F8011VFAE@QFP32 [(SA663+B005)]
MC56F8013VFAE@QFP32 [(SA663+B005)]
MC56F8014VFAE@QFP32 [(SA663+B005)]
MC56F8023MFAE@QFP32 [(SA663+B005)]
MC56F8023VFAE@QFP32 [(SA663+B005)]
MC56F8025VLD@QFP44 [(SA245A+B005)]
MC56F8036MFAE@QFP48 [(SA248+B005)]
MC56F8036VFAE@QFP48 [(SA248+B005)]
MC56F8037VLH@QFP64 [(PEP+S616)]
MC68HC908AP16CB(S)@SDIP42 [(SA028)]
MC68HC908AP16CB@SDIP42 [(SA028)]
MC68HC908AP16CFA(S)@LQFP48 [(SA248)]
MC68HC908AP16CFA@LQFP48 [(SA248)]
MC68HC908AP16CFB(S)@TQFP44 [(SA675)]
MC68HC908AP16CFB@TQFP44 [(SA675)]
MC68HC908AP32CB(S)@SDIP42 [(SA028)]
MC68HC908AP32CB@SDIP42 [(SA028)]
MC68HC908AP32CFA(S)@LQFP48 [(SA248)]
MC68HC908AP32CFA@LQFP48 [(SA248)]
MC68HC908AP32CFB(S)@TQFP44 [(SA675)]
MC68HC908AP32CFB@TQFP44 [(SA675)]
MC68HC908AP64CB@SDIP42 [(SA028)]
MC68HC908AP64CFA@LQFP48 [(SA248)]
MC68HC908AP64CFB@TQFP44 [(SA675)]
MC68HC908AP8CB(S)@SDIP42 [(SA028)]
MC68HC908AP8CB@SDIP42 [(SA028)]
MC68HC908AP8CFA(S)@@LQFP48 [(SA248)]
MC68HC908AP8CFA@@LQFP48 [(SA248)]
MC68HC908AP8CFB(S)@TQFP44 [(SA675)]
MC68HC908AP8CFB@TQFP44 [(SA675)]

MC68HC908EY16CFA@TQFP32 [(SA663)]
MC68HC908EY16MFA@TQFP32 [(SA663)]
MC68HC908EY16VFA@TQFP32 [(SA663)]
MC68HC908EY8CFA@TQFP32 [(SA663)] MC68HC908EY8MFA@TQFP32
[(SA663)]
MC68HC908EY8VFA@TQFP32 [(SA663)]
MC68HC908GP32
MC68HC908GP32@SDIP42 [(SA028)] MC68HC908GP32@TQFP44
[(SA675)]
MC68HC908GR16CFA@TQFP48 [(SA248)]
MC68HC908GR16CFJ@TQFP32 [(SA663)]
MC68HC908GR16MFA@TQFP48 [(SA248)]
MC68HC908GR16MFJ@TQFP32 [(SA663)]
MC68HC908GR16VFA@TQFP48 [(SA248)]
MC68HC908GR16VFJ@TQFP32 [(SA663)]
MC68HC908GR4CDW@SOIC28 [(SA404)] MC68HC908GR4CFA@TQFP32
[(SA663)]
MC68HC908GR4CP MC68HC908GR4MDW@SOIC28
[(SA404)]
MC68HC908GR4MFA@TQFP32 [(SA663)]
MC68HC908GR4MP
MC68HC908GR4VDW@SOIC28 [(SA404)] MC68HC908GR4VFA@TQFP32
[(SA663)]
MC68HC908GR4VP MC68HC908GR8CDW@SOIC28
[(SA404)]
MC68HC908GR8CFA@TQFP32 [(SA663)]
MC68HC908GR8CP
MC68HC908GR8MDW@SOIC28 [(SA404)] MC68HC908GR8MFA@TQFP32
[(SA663)]
MC68HC908GR8MP MC68HC908GR8VDW@SOIC28
[(SA404)]
MC68HC908GR8VFA@TQFP32 [(SA663)]
MC68HC908GR8VP
MC68HC908JK1CDW@SOIC20 [(SA404)]
MC68HC908JK1CP
MC68HC908JK1ECDW@SOIC20 [(SA404)]
MC68HC908JK1ECP
MC68HC908JK1EMDW@SOIC20 [(SA404)]
MC68HC908JK1EMP MC68HC908JK1MDW@SOIC20
[(SA404)]
MC68HC908JK1MP MC68HC908JK3CDW@SOIC20
[(SA404)]
MC68HC908JK3CP

MC68HC908JK3ECDW@SOIC20 [(SA404)]
MC68HC908JK3ECP
MC68HC908JK3EMDW@SOIC20 [(SA404)]
MC68HC908JK3EMP
[(SA404)]
MC68HC908JK3MP
[(SA404)]
MC68HC908JL3CFA@TQFP48 [(SA248)]
MC68HC908JL3CP
MC68HC908JL3ECDW@SOIC28 [(SA404)]
MC68HC908JL3ECFA@TQFP48 [(SA248)]
MC68HC908JL3ECP
MC68HC908JL3EMDW@SOIC28 [(SA404)]
MC68HC908JL3EMFA@TQFP48 [(SA248)]
MC68HC908JL3EMP
[(SA404)]
MC68HC908JL3MFA@TQFP48 [(SA248)]
MC68HC908JL3MP
MC68HC908LB8CDWE(S)@SOIC20
(S)
MC68HC908LB8MDWE(S)@SOIC20
(S)
MC68HC908LB8VDWE(S)@SOIC20
(S)
MC68HC908QT1CDW@SOIC8 [(SA605A)]
MC68HC908QT1CP
MC68HC908QT1MDW@SOIC8 [(SA605A)]
MC68HC908QT1MP
MC68HC908QT1VDW@SOIC8 [(SA605A)]
MC68HC908QT1VP
MC68HC908QT2CDW@SOIC8 [(SA605A)]
MC68HC908QT2CP
MC68HC908QT2MDW@SOIC8 [(SA605A)]
MC68HC908QT2MP
MC68HC908QT2VDW@SOIC8 [(SA605A)]
MC68HC908QT2VP
MC68HC908QT4CDW@SOIC8 [(SA605A)]
MC68HC908QT4CP
MC68HC908QT4MDW@SOIC8 [(SA605A)]
MC68HC908QT4MP
MC68HC908QT4VDW@SOIC8 [(SA605A)]
MC68HC908QT4VP
MC68HC908QY1CDT@TSSOP16 [(SA026)]

MC68HC908JK3MDW@SOIC20

MC68HC908JL3CDW@SOIC28

MC68HC908JL3MDW@SOIC28

MC68HC908LB8CPE

MC68HC908LB8MPE

MC68HC908LB8VPE

MC68HC908QY1CDW@SOIC16 [(SA404)]
MC68HC908QY1CP
MC68HC908QY1MDT@TSSOP16 [(SA026)]
MC68HC908QY1MDW@SOIC16 [(SA404)]
MC68HC908QY1MP
MC68HC908QY1VDT@TSSOP16 [(SA026)]
MC68HC908QY1VDW@SOIC16 [(SA404)]
MC68HC908QY1VP
MC68HC908QY2CDT@TSSOP16 [(SA026)]
MC68HC908QY2CDW@SOIC16 [(SA404)]
MC68HC908QY2CP
MC68HC908QY2MDT@TSSOP16 [(SA026)]
MC68HC908QY2MDW@SOIC16 [(SA404)]
MC68HC908QY2MP
MC68HC908QY2VDT@TSSOP16 [(SA026)]
MC68HC908QY2VDW@SOIC16 [(SA404)]
MC68HC908QY2VP
MC68HC908QY4CDT@TSSOP16 [(SA026)]
MC68HC908QY4CDW@SOIC16 [(SA404)]
MC68HC908QY4CP
MC68HC908QY4MDT@TSSOP16 [(SA026)]
MC68HC908QY4MDW@SOIC16 [(SA404)]
MC68HC908QY4MP
MC68HC908QY4VDT@TSSOP16 [(SA026)]
MC68HC908QY4VDW@SOIC16 [(SA404)]
MC68HC908QY4VP
MC68HRC908JK1CDW@SOIC20 [(SA404)]
MC68HRC908JK1CP
MC68HRC908JK1ECDW@SOIC20 [(SA404)]
MC68HRC908JK1ECP
MC68HRC908JK1EMDW@SOIC20 [(SA404)]
MC68HRC908JK1EMP
MC68HRC908JK1MDW@SOIC20 [(SA404)]
MC68HRC908JK1MP
MC68HRC908JK3CDW@SOIC20 [(SA404)]
MC68HRC908JK3CP
MC68HRC908JK3ECDW@SOIC20 [(SA404)]
MC68HRC908JK3ECP
MC68HRC908JK3EMDW@SOIC20 [(SA404)]
MC68HRC908JK3EMP
MC68HRC908JK3MDW@SOIC20 [(SA404)]
MC68HRC908JK3MP
MC68HRC908JL3CDW@SOIC28 [(SA404)]

MC68HRC908JL3CFA@TQFP48 [(SA248)]
MC68HRC908JL3CP
MC68HRC908JL3ECDW@SOIC28 [(SA404)]
MC68HRC908JL3ECFA@TQFP48 [(SA248)]
MC68HRC908JL3ECP
MC68HRC908JL3EMDW@SOIC28 [(SA404)]
MC68HRC908JL3EMFA@TQFP48 [(SA248)]
MC68HRC908JL3EMP
MC68HRC908JL3MDW@SOIC28 [(SA404)]
MC68HRC908JL3MFA@TQFP48 [(SA248)]
MC68HRC908JL3MP
MC908AP16CBE@SDIP42
[(SA028)]
MC908AP16CFAE@LQFP48 [(SA248)]
[(SA675)]
MC908AP32CBE@SDIP42 [(SA028)]
[(SA248)]
MC908AP32CFBE@TQFP44 [(SA675)]
[(SA028)]
MC908AP64CFAE@LQFP48 [(SA248)]
[(SA675)]
MC908AP8CBE@SDIP42 [(SA028)]
[(SA248)]
MC908AP8CFBE@TQFP44 [(SA675)]
[(SA663)]
MC908EY16AKFJE@TQFP32 [(SA663)]
[(SA663)]
MC908EY16AVFJE@TQFP32 [(SA663)]
[(SA663)]
MC908EY8AKFJE@TQFP32 [(SA663)]
[(SA663)]
MC908EY8AVFJE@TQFP32 [(SA663)]
[(SA404)]
MC908JL16CFJE@LQFP32 [(SA663)]
MC908JL16CPE
MC908JL16CSPE@SDIP32 [(SA653)]
[(SA605A)]
MC908QT1ACPE
[(SA605A)]
MC908QT1AMPE
[(SA605A)]
MC908QT1AVPE
[(SA605A)]
MC908QT2ACPE
MC908AP16CFBE@TQFP44
MC908AP32CFAE@LQFP48
MC908AP64CBE@SDIP42
MC908AP64CFBE@TQFP44
MC908AP8CFAE@@LQFP48
MC908EY16ACFJE@TQFP32
MC908EY16AMFJE@TQFP32
MC908EY8ACFJE@TQFP32
MC908EY8AMFJE@TQFP32
MC908JL16CDWE@SOIC28
MC908QT1ACDWE@SOIC8
MC908QT1AMDWE@SOIC8
MC908QT1AVDWE@SOIC8
MC908QT2ACDWE@SOIC8
MC908QT2AMDWE@SOIC8

[(SA605A)]	
MC908QT2AMPE	MC908QT2AVDWE@SOIC8
[(SA605A)]	
MC908QT2AVPE	MC908QT4ACDWE@SOIC8
[(SA605A)]	
MC908QT4ACPE	MC908QT4AMDWE@SOIC8
[(SA605A)]	
MC908QT4AMPE	MC908QT4AVDWE@SOIC8
[(SA605A)]	
MC908QT4AVPE	MC908QY1ACDTE@TSSOP16
[(SA026)]	
MC908QY1ACDWE@SOIC16 [(SA404)]	
MC908QY1ACPE	
MC908QY1AMDTE@TSSOP16 [(SA026)]	MC908QY1AMDWE@SOIC16
[(SA404)]	
MC908QY1AMPE	MC908QY1AVDTE@TSSOP16
[(SA026)]	
MC908QY1AVDWE@SOIC16 [(SA404)]	
MC908QY1AVPE	
MC908QY2ACDTE@TSSOP16 [(SA026)]	MC908QY2ACDWE@SOIC16
[(SA404)]	
MC908QY2ACPE	MC908QY2AMDTE@TSSOP16
[(SA026)]	
MC908QY2AMDWE@SOIC16 [(SA404)]	
MC908QY2AMPE	
MC908QY2AVDTE@TSSOP16 [(SA026)]	MC908QY2AVDWE@SOIC16
[(SA404)]	
MC908QY2AVPE	MC908QY4ACDTE@TSSOP16
[(SA026)]	
MC908QY4ACDWE@SOIC16 [(SA404)]	
MC908QY4ACPE	
MC908QY4AMDTE@TSSOP16 [(SA026)]	MC908QY4AMDWE@SOIC16
[(SA404)]	
MC908QY4AMPE	MC908QY4AVDTE@TSSOP16
[(SA026)]	
MC908QY4AVDWE@SOIC16 [(SA404)]	
MC908QY4AVPE	
MC9S08GT16ACB@SDIP42 [(SA028-B167)]	
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]	
MC9S08GT16ACFD@QFN48 [(SA696-B166)]	
MC9S08GT16AMB@SDIP42 [(SA028-B167)]	
MC9S08GT16AMFB@LQFP44 [(SA675-B168)]	
MC9S08GT16AMFD@QFN48 [(SA696-B166)]	

MC9S08GT16CB@SDIP42 [(SA028-B167)]
MC9S08GT16CBE@SDIP42 [(SA028-B167)]
MC9S08GT16CFB@LQFP44 [(SA675-B168)]
MC9S08GT16CFBE@LQFP44 [(SA675-B168)]
MC9S08GT16CFD@QFN48 [(SA696-B166)]
MC9S08GT16CFDE@QFN48 [(SA696-B166)]
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]
MC9S08GT32ACFD@QFN48 [(SA696-B166)]
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]
MC9S08GT32CB@SDIP42 [(SA028-B167)]
MC9S08GT32CBE@SDIP42 [(SA028-B167)]
MC9S08GT32CFB@LQFP44 [(SA675-B168)]
MC9S08GT32CFBE@LQFP44 [(SA675-B168)]
MC9S08GT32CFD@QFN48 [(SA696-B166)]
MC9S08GT32CFDE@QFN48 [(SA696-B166)]
MC9S08GT8ACB@SDIP42 [(SA028-B167)]
MC9S08GT8ACFB@LQFP44 [(SA675-B168)]
MC9S08GT8ACFD@QFN48 [(SA696-B166)]
MC9S08GT8AMB@SDIP42 [(SA028-B167)]
MC9S08GT8AMFB@LQFP44 [(SA675-B168)]
MC9S08GT8AMFD@QFN48 [(SA696-B166)]
PC56F8011VF AE@QFP32 [(SA663+B005)]
PC56F8013VF AE@QFP32 [(SA663+B005)]
PC56F8014VF AE@QFP32 [(SA663+B005)]

MYSON

MICROCONTROLLER

MTV212MN32
MTV212MN64I
MTV212MS32@SDIP42 [(SA028)] MTV212MS64I@SDIP42
[(SA028)]
MTV212MV32@PLCC44 [(SA244)] MTV212MV64I@PLCC44
[(SA244)]

NEC

E (E) PROM / FRAM / NVRAM

D2716D	
uPD271000	
uPD271000@PLCC32 [(SA015A1T)]	uPD271000@TSOP32
[(SA410T)]	
uPD27128	uPD27128
(C)	
uPD27128(D)	
uPD2716	
uPD27256	uPD27256
(C)	
uPD27256(D)	
uPD27256A	
uPD27256A(C)	uPD27256A
(D)	
uPD2732	
uPD2732A	
uPD27512	
uPD27512ACT	
uPD27512AD	
uPD2764	
uPD2764C	
uPD2764D	
uPD27C1000	uPD27C1000@PLCC32
[(SA015A1T)]	
uPD27C1000@TSOP32 [(SA410T)]	
uPD27C1000A	
uPD27C1000A@PLCC32 [(SA015A1T)]	uPD27C1000A@TSOP32
[(SA410T)]	
uPD27C1000AD	uPD27C1000AD@PLCC32
[(SA015A1T)]	
uPD27C1000AD@TSOP32 [(SA410T)]	
uPD27C1001	
uPD27C1001@PLCC32 [(SA015A1T)]	uPD27C1001@TSOP32
[(SA410T)]	
uPD27C1001A	uPD27C1001A@PLCC32
[(SA015A1T)]	
uPD27C1001A@TSOP32 [(SA410T)]	
uPD27C1001D	
uPD27C1001D@PLCC32 [(SA015A1T)]	uPD27C1001D@TSOP32
[(SA410T)]	
uPD27C1024	
uPD27C1024A	
uPD27C2001	uPD27C2001@PLCC32

[(SA015A1T)]
uPD27C2001@TSOP32 [(SA410T)]
uPD27C2001D
uPD27C2001D@PLCC32 [(SA015A1T)] uPD27C2001D@TSOP32
[(SA410T)]
uPD27C210
uPD27C256
uPD27C256A
uPD27C400
uPD27C4001 uPD27C4001@PLCC32
[(SA015A1T)]
uPD27C4001@TSOP32 [(SA410T)]
uPD27C4096
uPD27C512 uPD27C64
(C)
uPD27C64(D)
uPD27C8000
uPD27C8001 uPD27C8001@PLCC32
[(SA015A1T)]
uPD27C8001@TSOP32 [(SA410T)]
uPD28C04
uPD28C04@SOIC24 [(SA404)]
uPD28C05
uPD28C05@SOIC24 [(SA404)]
uPD28C256
uPD28C64 uPD28C64@SOIC28
[(SA404)]
uPD29F008CB@TSOP40 [(SA409T)] uPD29F008CT@TSOP40
[(SA409T)]

DRAM & SRAM

PD4361B PD4361B@SOJ24
[(SA646)]

NEXFLASH

E(E) PROM/FRAM/NVRAM

NX25B40(Bottom Boot)@MLP8 [(SA683)]
NX25B40(Bottom Boot)@SOIC8 [(SA602A)]

NX25B40(Top Boot)@MLP8 [(SA683)]	
NX25B40(Top Boot)@SOIC8 [(SA602A)]	
NX25P10@MLP8 [(SA683)]	NX25P10@SOIC8
[(SA602A)]	
NX25P16@MLP8 [(SA683)]	NX25P16@MLP8(ISP) [ISP-
HEADER01]	
NX25P16@SOIC16 [(SA404)]	
NX25P16@SOIC16(ISP) [ISP-HEADER01]	
NX25P16@SOIC8 [(SA023A)]	
NX25P16@SOIC8(ISP) [ISP-HEADER01]	
NX25P20@MLP8 [(SA683)]	NX25P20@SOIC8
[(SA602A)]	
NX25P32@MLP8 [(SA683)]	NX25P32@MLP8(ISP) [ISP-
HEADER01]	
NX25P32@SOIC16 [(SA404)]	
NX25P32@SOIC16(ISP) [ISP-HEADER01]	
NX25P40@MLP8 [(SA683)]	NX25P40@SOIC8
[(SA602A)]	
NX25P64@MLP8 [(SA683)]	NX25P64@MLP8(ISP) [ISP-
HEADER01]	
NX25P64@SOIC16 [(SA404)]	
NX25P64@SOIC16(ISP) [ISP-HEADER01]	
NX25P80@MLP8 [(SA683)]	NX25P80@SOIC8
[(SA602A)]	
NX29F010	NX29F010@PLCC32
[(SA015A1T)]	
NX29F010@TSOP32 [(SA410T)]	

NJRC

E(E) PROM/FRAM/NVRAM

NJU26040V	NJU26040V@SSOP32
[(SA626A)]	

NOVATEK

MICROCONTROLLER

NT68F631@PLCC44 [(SA244)]	NT68F631@SDIP42
---------------------------	-----------------

[(SA028)]	
NT68F631ALG@PLCC44 [(SA244)]	NT68F631AUG@SDIP42
[(SA028)]	
NT68F631L@PLCC44 [(SA244)]	NT68F631LG@PLCC44
[(SA244)]	
NT68F631U@SDIP42 [(SA028)]	NT68F631UG@SDIP42
[(SA028)]	
NT68F632@PLCC44 [(SA244)]	NT68F632@SDIP42
[(SA028)]	
NT68F632ALG@PLCC44 [(SA244)]	NT68F632AUG@SDIP42
[(SA028)]	
NT68F632L@PLCC44 [(SA244)]	NT68F632LG@PLCC44
[(SA244)]	
NT68F632U@SDIP42 [(SA028)]	NT68F632UG@SDIP42
[(SA028)]	
NT68F633@PLCC44 [(SA244)]	NT68F633@SDIP42
[(SA028)]	
NT68F633L@PLCC44 [(SA244)]	NT68F633LG@PLCC44
[(SA244)]	
NT68F633U@SDIP42 [(SA028)]	NT68F633UG@SDIP42
[(SA028)]	
NT68F636@PLCC44 [(SA244)]	NT68F636@SDIP42
[(SA028)]	
NT68F636L@PLCC44 [(SA244)]	NT68F636LG@PLCC44
[(SA244)]	
NT68F636U@SDIP42 [(SA028)]	NT68F636UG@SDIP42
[(SA028)]	
NT68F63L(0444)@PLCC44 [(SA244)]	NT68F63L(0444)@SDIP42
[(SA028)]	
NT68F63L(0448)@PLCC44 [(SA244)]	NT68F63L(0448)@SDIP42
[(SA028)]	
NT68F63L(0523)@PLCC44 [(SA244)]	NT68F63L(0523)@SDIP42
[(SA028)]	
NT68F63L@PLCC44 [(SA244)]	NT68F63LA@PLCC44
[(SA244)]	
NT68F63LG@PLCC44 [(SA244)]	NT68F63LGG@PLCC44
[(SA244)]	
NT68F63U@SDIP42 [(SA028)]	NT68F63UA@SDIP42
[(SA028)]	
NT68F63UG@SDIP42 [(SA028)]	NT68F63UGG@SDIP42
[(SA028)]	

NSC**E (E) PROM / FRAM / NVRAM**

2864	
MM2716	
MM2716E	
NM24C02	
NM24C02@SOIC8 [(SA602A)]	NM24C02@TSOP8
[(SA026)]	
NM24C02L	
[(SA602A)]	NM24C02L@SOIC8
NM24C02L@TSOP8 [(SA026)]	
NM24C03	
NM24C03@SOIC8 [(SA602A)]	NM24C03@TSOP8
[(SA026)]	
NM24C04	
[(SA602A)]	NM24C04@SOIC8
NM24C04@TSOP8 [(SA026)]	
NM24C05	
NM24C05@SOIC8 [(SA602A)]	NM24C05@TSOP8
[(SA026)]	
NM24C08	
[(SA602A)]	NM24C08@SOIC8
NM24C09	
[(SA602A)]	NM24C09@SOIC8
NM24C16	
[(SA602A)]	NM24C16@SOIC8
NM24C17	
[(SA602A)]	NM24C17@SOIC8
NM25C04	
[(SA602)]	NM25C04@SOIC16
NM25C04@SOIC8 [(SA602A)]	NM25C04@TSSOP14
[(SA026)]	
NM25C04@TSSOP8 [(SA026)]	
NM27C010	
NM27C010@PLCC32 [(SA015A1T)]	NM27C010@TSOP32
[(SA410T)]	
NM27C010Q	
[(SA015A1T)]	NM27C010Q@PLCC32
NM27C010Q@TSOP32 [(SA410T)]	
NM27C020	
NM27C020@PLCC32 [(SA015A1T)]	NM27C020@TSOP32

[(SA410T)]	
NM27C020Q	NM27C020Q@PLCC32
[(SA015A1T)]	
NM27C020Q@TSOP32 [(SA410T)]	
NM27C040	
NM27C040@PLCC32 [(SA015A1T)]	NM27C040@TSOP32
[(SA410T)]	
NM27C1023	
NM27C128	
NM27C128@PLCC32 [(SA015A1T)]	
NM27C210	
NM27C210@PLCC44 [(SA244)]	
NM27C210Q	
NM27C210Q@PLCC44 [(SA244)]	
NM27C240	
NM27C240@PLCC44 [(SA244)]	
NM27C256	
NM27C256@PLCC32 [(SA015A1T)]	
NM27C400	
NM27C512	NM27C512@PLCC32
[(SA015A1T)]	
NM27C512Q	NM27C512Q@PLCC32
[(SA015A1T)]	
NM27C64Q	NM27C64Q@PLCC32
[(SA015A1T)]	
NM27CP256	NM27CP256@PLCC32
[(SA015A1T)]	
NM27LC010	NM27LC010@PLCC32
[(SA015A1T)]	
NM27LC010@TSOP32 [(SA410T)]	
NM27LC256	
NM27LC256@PLCC32 [(SA015A1T)]	
NM27LC512	
NM27LC512@PLCC32 [(SA015A1T)]	
NM27LC64	
NM27LC64@PLCC32 [(SA015A1T)]	
NM27LV010	
NM27LV010@PLCC32 [(SA015A1T)]	NM27LV010@TSOP32
[(SA410T)]	
NM27LV210	NM27LV210@PLCC44
[(SA244)]	
NM27LV512	NM27LV512@PLCC32
[(SA015A1T)]	

NM27LV512@TSOP32 [(SA410T)]	
NM27P040	
NM27P040@PLCC32 [(SA015A1T)]	NM27P040@TSOP32
[(SA410T)]	
NM27P210	NM27P210@PLCC44
[(SA244)]	
NM27P512	NM27P512@PLCC32
[(SA015A1T)]	
NM59C11	NM59C11@SOIC8
[(SA602A)]	
NM93C06(08bit)	NM93C06(08bit)@SOIC8
[(SA602A)]	
NM93C06(16bit)	NM93C06(16bit)@SOIC8
[(SA602A)]	
NM93C46	NM93C46@SOIC8
[(SA602A)]	
NM93C46A(08bit)	NM93C46A(08bit)@SOIC8
[(SA602A)]	
NM93C46A(16bit)	NM93C46A(16bit)@SOIC8
[(SA602A)]	
NM93C46AL(08bit)	
NM93C46AL(08bit)@SOIC8 [(SA602A)]	
NM93C46AL(16bit)	
NM93C46AL(16bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(08bit)	
NM93C46ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C46ALZ(16bit)	
NM93C46ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C46L	NM93C46L@SOIC8
[(SA602A)]	
NM93C46LZ	NM93C46LZ@SOIC8
[(SA602A)]	
NM93C56	NM93C56@SOIC8
[(SA602A)]	
NM93C56A(08bit)	NM93C56A(08bit)@SOIC8
[(SA602A)]	
NM93C56A(16bit)	NM93C56A(16bit)@SOIC8
[(SA602A)]	
NM93C56AL(08bit)	
NM93C56AL(08bit)@SOIC8 [(SA602A)]	
NM93C56AL(16bit)	
NM93C56AL(16bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(08bit)	

NM93C56ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(16bit)	
NM93C56ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C56L	NM93C56L@SOIC8
[(SA602A)]	
NM93C56LZ	NM93C56LZ@SOIC8
[(SA602A)]	
NM93C66	NM93C66@SOIC8
[(SA602A)]	
NM93C66A	NM93C66A
(08bit)	
NM93C66A(08bit)@SOIC8 [(SA602A)]	NM93C66A@SOIC8
[(SA602A)]	
NM93C66AL(08bit)	
NM93C66AL(08bit)@SOIC8 [(SA602A)]	
NM93C66AL(16bit)	
NM93C66AL(16bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(08bit)	
NM93C66ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(16bit)	
NM93C66ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C66L	NM93C66L@SOIC8
[(SA602A)]	
NM93C66LZ	NM93C66LZ@SOIC8
[(SA602A)]	
NM93C86(16bit)	NM93C86(16bit)@SOIC8
[(SA602A)]	
NM93C86A	NM93C86A
(08bit)	
NM93C86A(08bit)@SOIC8 [(SA602A)]	NM93C86A@SOIC8
[(SA602A)]	
NM93C86AL(08bit)	
NM93C86AL(08bit)@SOIC8 [(SA602A)]	
NM93C86AL(16bit)	
NM93C86AL(16bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(08bit)	
NM93C86ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C86ALZ(16bit)	
NM93C86ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C86L	NM93C86L@SOIC8
[(SA602A)]	
NM93C86LZ	NM93C86LZ@SOIC8
[(SA602A)]	

NM93CS06(M8)@SOIC8 [(SA602A)]	NM93CS06(MT8)@TSSOP8
[(SA026)]	
NM93CS06(N)	NM93CS46(M8)@SOIC8
[(SA602A)]	
NM93CS46(MT8)@TSSOP8 [(SA026)]	NM93CS46
(N)	
NM93CS56(M8)@SOIC8 [(SA602A)]	NM93CS56(MT8)@TSSOP8
[(SA026)]	
NM93CS56(N)	NM93CS66(M8)@SOIC8
[(SA602A)]	
NM93CS66(MT8)@TSSOP8 [(SA026)]	NM93CS66
(N)	
NMC2732	
NMC2732B	
NMC2732H	
NMC27C010	
NMC27C010@PLCC32 [(SA015A1T)]	NMC27C010@TSOP32
[(SA410T)]	
NMC27C1024	NMC27C1024@PLCC44
[(SA244)]	
NMC27C128B	NMC27C128B@PLCC32
[(SA015A1T)]	
NMC27C128BN	NMC27C128BN@PLCC32
[(SA015A1T)]	
NMC27C128BQ	NMC27C128BQ@PLCC32
[(SA015A1T)]	
NMC27C128CQ	
NMC27C128Q	
NMC27C16	
NMC27C16BQ	
NMC27C16BQE	
NMC27C16H	
NMC27C16HQ	
NMC27C16Q	
NMC27C210	NMC27C210@PLCC44
[(SA244)]	
NMC27C210Q	NMC27C210Q@PLCC44
[(SA244)]	
NMC27C256B	NMC27C256B@PLCC32
[(SA015A1T)]	
NMC27C256BN	
NMC27C256BQE	
NMC27C256BQM	

NMC27C256Q
NMC27C256Q@PLCC32 [(SA015A1T)]
NMC27C32
NMC27C32B
NMC27C32BQ
NMC27C32E
NMC27C32EH
NMC27C32H
NMC27C512
NMC27C512@PLCC32 [(SA015A1T)]
NMC27C512A
NMC27C512A@PLCC32 [(SA015A1T)]
NMC27C512AN
NMC27C512AN@PLCC32 [(SA015A1T)]
NMC27C64
NMC27C64@PLCC32 [(SA015A1T)]
NMC27C64BN
NMC27C64N
NMC27CP128
NMC27CP256
NMC27CP64
NMC59C11 NMC59C11@SOIC8
[(SA602A)]
NMC87C257Q
NMC87C257Q@PLCC32
NMC87C257V
NMC87C257V@PLCC32
NMC9306 NMC9306@SOIC8
[(SA602A)]
NMC9307 NMC9307@SOIC8
[(SA602A)]
NMC9346 NMC9346@SOIC8
[(SA602A)]
NMC93C56 NMC93C56@SOIC14
[(SA602)]
NMC93C56@SOIC8 [(SA602A)]
NMC93C66
NMC93C66@SOIC14 [(SA602)]
NMC93C86A
NMC93C86A@SOIC14 [(SA602)] NMC93C86A@SOIC8
[(SA602A)]
NMC93CS06(M14)@SOIC14 [(SA602)] NMC93CS06
(N)

NMC93CS46 (M14)@SOIC14 [(SA602)] (N)	NMC93CS46
NMC93CS56 (M14)@SOIC14 [(SA602)] (N)	NMC93CS56
NMC93CS66 (M14)@SOIC14 [(SA602)] (N)	NMC93CS66
NMC93S06 (M14)@SOIC14 [(SA602)] (N)	NMC93S06
NMC9817	
NMC9817A	
NS2816A	
NS9816A	

PLD

GAL16V8 [(SA001A)]	GAL16V8@PLCC20
GAL16V8A [(SA001A)]	GAL16V8A@PLCC20
GAL20V8 [(SA008A)]	GAL20V8@PLCC28
GAL20V8A [(SA008A)]	GAL20V8A@PLCC28
GAL20V8QS [(SA008A)]	GAL20V8QS@PLCC28

NTE

E (E) PROM / FRAM / NVRAM

NTE2532
NTE2532A
NTE25L32

NUMONYX

E (E) PROM / FRAM / NVRAM

M25PX32@SOIC16 [(SA404)]	M25PX32@SOIC8
----------------------------	---------------

[(SA023A)]
M25PX32@VFQFPN8 [(SA683)]
[(SA404)]
M25PX64@VDFPN8 [(SA684)]

M25PX64@SOIC16

NXP

MICROCONTROLLER

P83C660X2@PLCC44 [(SA244)]
[(SA245A)]
P83C661X2@PLCC44 [(SA244)]
[(SA245A)]

P83C660X2@TQFP44

P83C661X2@TQFP44

P87C51
[(SA244)]
P87C51@TQFP44 [(SA245A)]

P87C51@PLCC44

P87C51FA
P87C51FA@PLCC44 [(SA244)]
[(SA245A)]

P87C51FA@TQFP44

P87C51FB
[(SA244)]
P87C51FB@TQFP44 [(SA245A)]

P87C51FB@PLCC44

P87C51FC
P87C51FC@PLCC44 [(SA244)]
[(SA245A)]

P87C51FC@TQFP44

P87C51MA2@PLCC44 [(SA244)]
[(SA244)]
P87C51MC2@PLCC44 [(SA244)]

P87C51MB2@PLCC44

P87C51RA

+
P87C51RA+@PLCC44 [(SA244)]
[(SA245A)]

P87C51RA+@TQFP44

P87C51RA2
[(SA244)]
P87C51RA2@TQFP44 [(SA245A)]

P87C51RA2@PLCC44

P87C51RB

+
P87C51RB+@PLCC44 [(SA244)]
[(SA245A)]

P87C51RB+@TQFP44

P87C51RB2
[(SA244)]
P87C51RB2@TQFP44 [(SA245A)]

P87C51RB2@PLCC44

P87C51RC

+
P87C51RC+@PLCC44 [(SA244)]

P87C51RC+@TQFP44

[(SA245A)]	
P87C51RC2	P87C51RC2@PLCC44
[(SA244)]	
P87C51RC2@TQFP44 [(SA245A)]	P87C51RD
+	
P87C51RD+@PLCC44 [(SA244)]	P87C51RD+@TQFP44
[(SA245A)]	
P87C51RD2	P87C51RD2@PLCC44
[(SA244)]	
P87C51RD2@TQFP44 [(SA245A)]	
P87C51SB	
P87C51SB@PLCC44 [(SA244)]	P87C51SB@TQFP44
[(SA245A)]	
P87C51SF	P87C51SF@PLCC44
[(SA244)]	
P87C51SF@TQFP44 [(SA245A)]	
P87C51UB	
P87C51UB@PLCC44 [(SA244)]	P87C51UB@TQFP44
[(SA245A)]	
P87C51UF	P87C51UF@PLCC44
[(SA244)]	
P87C51UF@TQFP44 [(SA245A)]	
P87C51X2	
P87C51X2@PLCC44 [(SA244)]	P87C51X2@TQFP44
[(SA245A)]	
P87C52	P87C52@PLCC44
[(SA244)]	
P87C52@TQFP44 [(SA245A)]	
P87C524	
P87C524@PLCC44 [(SA244)]	P87C524@TQFP44
[(SA245A)]	
P87C528	P87C528@PLCC44
[(SA244)]	
P87C528@TQFP44 [(SA245A)]	
P87C52SB	
P87C52SB@PLCC44 [(SA244)]	P87C52SB@TQFP44
[(SA245A)]	
P87C52SF	P87C52SF@PLCC44
[(SA244)]	
P87C52SF@TQFP44 [(SA675)]	
P87C52UB	
P87C52UB@PLCC44 [(SA244)]	P87C52UB@TQFP44
[(SA245A)]	

P87C52UF [(SA244)]	P87C52UF@PLCC44
P87C52UF@TQFP44 [(SA245A)]	
P87C52X2 P87C52X2@PLCC44 [(SA244)] [(SA245A)]	P87C52X2@TQFP44
P87C54 [(SA244)]	P87C54@PLCC44
P87C54@TQFP44 [(SA245A)]	
P87C54SB P87C54SB@PLCC44 [(SA244)] [(SA245A)]	P87C54SB@TQFP44
P87C54SF [(SA244)]	P87C54SF@PLCC44
P87C54SF@TQFP44 [(SA245A)]	
P87C54UB P87C54UB@PLCC44 [(SA244)] [(SA245A)]	P87C54UB@TQFP44
P87C54UF [(SA244)]	P87C54UF@PLCC44
P87C54UF@TQFP44 [(SA245A)]	
P87C54X2 P87C54X2@PLCC44 [(SA244)] [(SA245A)]	P87C54X2@TQFP44
P87C550 [(SA244)]	P87C550@PLCC44
P87C552@PLCC68 (*) [(SA648-B6806)]	
P87C554@PLCC68 (*) [(SA648-B6806)]	
P87C575 [(SA244)]	P87C575@PLCC44
P87C575@TQFP44 [(SA245A)]	
P87C576 P87C576@PLCC44 [(SA244)] [(SA245A)]	P87C576@TQFP44
P87C58 [(SA244)]	P87C58@PLCC44
P87C58@TQFP44 [(SA245A)]	
P87C58SB P87C58SB@PLCC44 [(SA244)] [(SA245A)]	P87C58SB@TQFP44
P87C58UB [(SA244)]	P87C58UB@PLCC44
P87C58UB@TQFP44 [(SA245A)]	

P87C58X2	
P87C58X2@PLCC44 [(SA244)]	P87C58X2@TQFP44
[(SA245A)]	
P87C591@PLCC44 [(SA244)]	P87C591@TQFP44
[(SA245A)]	
P87C652	P87C652@PLCC44
[(SA244)]	
P87C652@TQFP44 [(SA245A)]	
P87C654	
P87C654@PLCC44 [(SA244)]	P87C654@TQFP44
[(SA245A)]	
P87C660X2@PLCC44 [(SA244)]	P87C660X2@TQFP44
[(SA245A)]	
P87C661X2@PLCC44 [(SA244)]	P87C661X2@TQFP44
[(SA245A)]	
P87C748	P87C748@PLCC28
[(SA008A)]	
P87C749	P87C749@PLCC28
[(SA008A)]	
P87C750	P87C750@PLCC28
[(SA008A)]	
P87C750@SSOP24 [(SA626A)]	
P87C751	
P87C751@PLCC28 [(SA008A)]	P87C751@SSOP24
[(SA626A)]	
P87C752	P87C752@PLCC28
[(SA008A)]	
P87C752@SSOP28 [(SA626A)]	
P87C754	
P87C754@PLCC28 [(SA008A)]	P87C754@SSOP28
[(SA626A)]	
P87CL52X2	P87CL52X2@PLCC44
[(SA244)]	
P87CL52X2@TQFP44 [(SA245A)]	
P87CL54X2	
P87CL54X2@PLCC44 [(SA244)]	P87CL54X2@TQFP44
[(SA245A)]	
P87L51FA	P87L51FA@PLCC44
[(SA244)]	
P87L51FA@TQFP44 [(SA245A)]	
P87L51FB	
P87L51FB@PLCC44 [(SA244)]	P87L51FB@TQFP44
[(SA245A)]	

P87LPC759 P87LPC759 (ISP) [ISP-
HEADER01]
P87LPC760 P87LPC760 (ISP) [ISP-
HEADER01]
P87LPC760@TSSOP14 [(SA026)]
P87LPC760@TSSOP14 (ISP) [ISP-HEADER01]
P87LPC761 P87LPC761 (ISP) [ISP-
HEADER01]
P87LPC762 P87LPC762 (ISP) [ISP-
HEADER01]
P87LPC762@PLCC44 [(SA244)]
P87LPC762@PLCC44 (ISP) [ISP-HEADER01]
P87LPC762@SOIC20 [(SA404)]
P87LPC762@SOIC20 (ISP) [ISP-HEADER01]
P87LPC764 P87LPC764 (ISP) [ISP-
HEADER01]
P87LPC764@PLCC44 [(SA244)]
P87LPC764@PLCC44 (ISP) [ISP-HEADER01]
P87LPC764@SOIC20 [(SA404)]
P87LPC764@SOIC20 (ISP) [ISP-HEADER01]
P87LPC764@TSSOP20 [(SA643)]
P87LPC764@TSSOP20 (ISP) [ISP-HEADER01]
P87LPC767 P87LPC767 (ISP) [ISP-
HEADER01]
P87LPC767@PLCC44 [(SA244)]
P87LPC767@PLCC44 (ISP) [ISP-HEADER01]
P87LPC767@SOIC20 [(SA404)]
P87LPC767@SOIC20 (ISP) [ISP-HEADER01]
P87LPC768 P87LPC768 (ISP) [ISP-
HEADER01]
P87LPC768@SOIC20 [(SA404)]
P87LPC768@SOIC20 (ISP) [ISP-HEADER01]
P87LPC769 P87LPC769 (ISP) [ISP-
HEADER01]
P87LPC769@PLCC44 [(SA244)]
P87LPC769@PLCC44 (ISP) [ISP-HEADER01]
P87LPC769@SOIC20 [(SA404)]
P87LPC769@SOIC20 (ISP) [ISP-HEADER01]
P87LPC778 P87LPC778 (ISP) [ISP-
HEADER01]
P87LPC778@TSSOP20 [(SA026)]
P87LPC778@TSSOP20 (ISP) [ISP-HEADER01]
P87LPC779 P87LPC779 (ISP) [ISP-

HEADER01]

P87LPC779@TSSOP20 [(SA643)]

P87LPC779@TSSOP20 (ISP) [ISP-HEADER01]

P89C138 P89C138@PLCC44

[(SA244)]

P89C138@TQFP44 [(SA245A)]

P89C238

P89C238@PLCC44 [(SA244)] P89C238@TQFP44

[(SA245A)]

P89C51B P89C51B@PLCC44

[(SA244)]

P89C51B@TQFP44 [(SA245A)] P89C51RA

+

P89C51RA+@PLCC44 [(SA244)] P89C51RA+@TQFP44

[(SA245A)]

P89C51RA2B P89C51RA2B@PLCC44

[(SA244)]

P89C51RA2B@TQFP44 [(SA245A)] P89C51RB

+

P89C51RB+@PLCC44 [(SA244)] P89C51RB+@TQFP44

[(SA245A)]

P89C51RB2B P89C51RB2B@PLCC44

[(SA244)]

P89C51RB2B@TQFP44 [(SA245A)]

P89C51RB2H

P89C51RB2H@PLCC44 [(SA244)] P89C51RB2H@TQFP44

[(SA245A)]

P89C51RC+ P89C51RC+@PLCC44

[(SA244)]

P89C51RC+@TQFP44 [(SA245A)]

P89C51RC2B

P89C51RC2B@PLCC44 [(SA244)] P89C51RC2B@TQFP44

[(SA245A)]

P89C51RC2H P89C51RC2H@PLCC44

[(SA244)]

P89C51RC2H@TQFP44 [(SA245A)] P89C51RD

+

P89C51RD+@PLCC44 [(SA244)] P89C51RD+@TQFP44

[(SA245A)]

P89C51RD2B P89C51RD2B@PLCC44

[(SA244)]

P89C51RD2B@TQFP44 [(SA245A)]

P89C51RD2H

P89C51RD2H@PLCC44 [(SA244)]	P89C51RD2H@TQFP44
[(SA245A)]	
P89C51UB	P89C51UB@PLCC44
[(SA244)]	
P89C51UB@TQFP44 [(SA245A)]	
P89C51UF	
P89C51UF@PLCC44 [(SA244)]	P89C51UF@TQFP44
[(SA245A)]	
P89C51X2	P89C51X2@PLCC44
[(SA244)]	
P89C51X2@TQFP44 [(SA245A)]	
P89C51X2B	
P89C51X2B@PLCC44 [(SA244)]	P89C51X2B@TQFP44
[(SA245A)]	
P89C51X2F	P89C51X2F@PLCC44
[(SA244)]	
P89C51X2F@TQFP44 [(SA245A)]	
P89C52	
P89C52@PLCC44 [(SA244)]	P89C52@TQFP44
[(SA245A)]	
P89C52B	P89C52B@PLCC44
[(SA244)]	
P89C52B@TQFP44 [(SA245A)]	
P89C52UB	
P89C52UB@PLCC44 [(SA244)]	P89C52UB@TQFP44
[(SA245A)]	
P89C52UF	P89C52UF@PLCC44
[(SA244)]	
P89C52UF@TQFP44 [(SA245A)]	
P89C52X2	
P89C52X2@PLCC44 [(SA244)]	P89C52X2@TQFP44
[(SA245A)]	
P89C52X2B	P89C52X2B@PLCC44
[(SA244)]	
P89C52X2B@TQFP44 [(SA245A)]	
P89C52X2F	
P89C52X2F@PLCC44 [(SA244)]	P89C52X2F@TQFP44
[(SA245A)]	
P89C536@PLCC44 [(SA244)]	P89C538@PLCC44
[(SA244)]	
P89C54	P89C54@PLCC44
[(SA244)]	
P89C54@TQFP44 [(SA245A)]	

P89C54B	
P89C54B@PLCC44 [(SA244)]	P89C54B@TQFP44
[(SA245A)]	
P89C54UB	P89C54UB@PLCC44
[(SA244)]	
P89C54UB@TQFP44 [(SA245A)]	
P89C54UF	
P89C54UF@PLCC44 [(SA244)]	P89C54UF@TQFP44
[(SA245A)]	
P89C54X2	P89C54X2@PLCC44
[(SA244)]	
P89C54X2@TQFP44 [(SA245A)]	
P89C54X2B	
P89C54X2B@PLCC44 [(SA244)]	P89C54X2B@TQFP44
[(SA245A)]	
P89C54X2F	P89C54X2F@PLCC44
[(SA244)]	
P89C54X2F@TQFP44 [(SA245A)]	
P89C58	
P89C58@PLCC44 [(SA244)]	P89C58@TQFP44
[(SA245A)]	
P89C58B	P89C58B@PLCC44
[(SA244)]	
P89C58B@TQFP44 [(SA245A)]	
P89C58UB	
P89C58UB@PLCC44 [(SA244)]	P89C58UB@TQFP44
[(SA245A)]	
P89C58UF	P89C58UF@PLCC44
[(SA244)]	
P89C58UF@TQFP44 [(SA245A)]	
P89C58X2	
P89C58X2@PLCC44 [(SA244)]	P89C58X2@TQFP44
[(SA245A)]	
P89C58X2B	P89C58X2B@PLCC44
[(SA244)]	
P89C58X2B@TQFP44 [(SA245A)]	
P89C58X2F	
P89C58X2F@PLCC44 [(SA244)]	P89C58X2F@TQFP44
[(SA245A)]	
P89C60X2	P89C60X2@PLCC44
[(SA244)]	
P89C60X2@TQFP44 [(SA245A)]	
P89C61X2	

P89C61X2@PLCC44 [(SA244)]	P89C61X2@TQFP44
[(SA245A)]	
P89C660	P89C660@PLCC44
[(SA244)]	
P89C660@TQFP44 [(SA245A)]	
P89C662	
P89C662@PLCC44 [(SA244)]	P89C662@TQFP44
[(SA245A)]	
P89C664	P89C664@PLCC44
[(SA244)]	
P89C664@TQFP44 [(SA245A)]	
P89C668	
P89C668@PLCC44 [(SA244)]	P89C668@TQFP44
[(SA245A)]	
P89C669	P89C669@LQFP44
[(SA245A)]	
P89C669@PLCC44 [(SA244)]	
P89C738	
P89C738@PLCC44 [(SA244)]	P89C738@TQFP44
[(SA245A)]	
P89C838	P89C838@PLCC44
[(SA244)]	
P89C838@TQFP44 [(SA245A)]	P89CV51RB2@PLCC44
[(SA244)]	
P89CV51RB2@TQFP44 [(SA245A)]	P89CV51RC2@PLCC44
[(SA244)]	
P89CV51RC2@TQFP44 [(SA245A)]	P89CV51RD2@PLCC44
[(SA244)]	
P89CV51RD2@TQFP44 [(SA245A)]	P89LPC901(FD)
[(SA602A)]	
P89LPC901(FD)(ISP) [ISP-HEADER01]	
P89LPC901(FN)	
P89LPC901(FN)(ISP) [ISP-HEADER01]	
P89LPC902(FD) [(SA602A)]	
P89LPC902(FD)(ISP) [ISP-HEADER01]	
P89LPC902(FN)	
P89LPC902(FN)(ISP) [ISP-HEADER01]	
P89LPC903(FD) [(SA602A)]	
P89LPC903(FD)(ISP) [ISP-HEADER01]	
P89LPC904(FD) [(SA605A)]	
P89LPC904(FD)(ISP) [ISP-HEADER01]	
P89LPC904(FN)	
P89LPC904(FN)(ISP) [ISP-HEADER01]	

P89LPC906(FD) [(SA605A)]
P89LPC906(FD)(ISP) [ISP-HEADER01]
P89LPC907(FD) [(SA605A)]
P89LPC907(FD)(ISP) [ISP-HEADER01]
P89LPC908(FD) [(SA605A)]
P89LPC908(FD)(ISP) [ISP-HEADER01]
P89LPC9102(FTK)@HVSON10 [(SA695A)]
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9103(FTK)@HVSON10 [(SA695A)]
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9107(FDH)@TSSOP14 [(SA643)]
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC9107(FN)
P89LPC9107(FN)(ISP) [ISP-HEADER01]
P89LPC912(FDH)@TSSOP14 [(SA643)]
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC913(FDH)@TSSOP14 [(SA643)]
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC914(FDH)@TSSOP14 [(SA643)]
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC915(FDH)@TSSOP14 [(SA643)]
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC916(FDH)@TSSOP16 [(SA643)]
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC917(FDH)@TSSOP16 [(SA643)]
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC920(FDH)@TSSOP20 [(SA643)]
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920(FN)
P89LPC920(FN)(ISP) [ISP-HEADER01]
P89LPC921(FDH)@TSSOP20 [(SA643)]
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921(FN)
P89LPC921(FN)(ISP) [ISP-HEADER01]
P89LPC922(FDH)@TSSOP20 [(SA643)]
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922(FN)
P89LPC922(FN)(ISP) [ISP-HEADER01]
P89LPC9221(FDH)@TSSOP20 [(SA643)]
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221(FN)
P89LPC9221(FN)(ISP) [ISP-HEADER01]
P89LPC924(FDH)@TSSOP20 [(SA643)]

P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924(FN)
P89LPC924(FN)(ISP) [ISP-HEADER01]
P89LPC925(FDH)@TSSOP20 [(SA643)]
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925(FN)
P89LPC925(FN)(ISP) [ISP-HEADER01]
P89LPC930(BA)@PLCC28 [(SA008A)]
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC930(BDH)@TSSOP28 [(SA643)]
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC931(BA)@PLCC28 [(SA008A)]
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC931(BDH)@TSSOP28 [(SA643)]
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28
[(SA643)]
P89LPC93201(BA)@PLCC28 [(SA008A)]
P89LPC93201(BDH)@TSSOP28 [(SA643)]
P89LPC93201(FA)@PLCC28 [(SA008A)]
P89LPC93201(FDH)@TSSOP28 [(SA643)]
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9321(BA)@PLCC28 [(SA008A)]
P89LPC9321(BDH)@TSSOP28 [(SA643)]
P89LPC9321(FA)@PLCC28 [(SA008A)]
P89LPC9321(FDH)@TSSOP28 [(SA643)]
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(BA)@PLCC28 [(SA008A)]
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC932A1(BDH)@TSSOP28 [(SA643)]
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FDH)@TSSOP28 [(SA643)]
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC933(BDH)@TSSOP28 [(SA643)]
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(FDH)@TSSOP28 [(SA643)]
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC934(BDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC934(FDH)@TSSOP28 [(SA643)]
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]

P89LPC935(BA)@PLCC28 [(SA008A)]
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(BDH)@TSSOP28 [(SA643)]
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FA)@PLCC28 [(SA008A)]
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(FDH)@TSSOP28 [(SA643)]
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93501(BA)@PLCC28 [(SA008A)]
P89LPC93501(BDH)@TSSOP28 [(SA643)]
P89LPC93501(FA)@PLCC28 [(SA008A)]
P89LPC93501(FDH)@TSSOP28 [(SA643)]
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9351(BA)@PLCC28 [(SA008A)]
P89LPC9351(BDH)@TSSOP28 [(SA643)]
P89LPC9351(FA)@PLCC28 [(SA008A)]
P89LPC9351(FDH)@TSSOP28 [(SA643)]
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]
P89LPC936(FA)@PLCC28 [(SA008A)]
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC936(FDH)@TSSOP28 [(SA643)]
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC938(FA)@PLCC28 [(SA008A)]
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC938(FDH)@TSSOP28 [(SA643)]
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93801(BA)@PLCC28 [(SA008A)]
P89LPC93801(BDH)@TSSOP28 [(SA643)]
P89LPC93801(FA)@PLCC28 [(SA008A)]
P89LPC93801(FDH)@TSSOP28 [(SA643)]
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9381(BA)@PLCC28 [(SA008A)]
P89LPC9381(BDH)@TSSOP28 [(SA643)]
P89LPC9381(FA)@PLCC28 [(SA008A)]
P89LPC9381(FDH)@TSSOP28 [(SA643)]
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC952@LQFP44 [(SA245A)]

P89LPC952@LQFP44 (ISP) [ISP-HEADER01]
P89LPC952@LQFP48 [(SA248)]
P89LPC952@LQFP48 (ISP) [ISP-HEADER01]
P89LPC952@PLCC44 [(SA244)]
P89LPC952@PLCC44 (ISP) [ISP-HEADER01]
P89LPC954@LQFP44 [(SA245A)]
P89LPC954@LQFP44 (ISP) [ISP-HEADER01]
P89LPC954@LQFP48 [(SA248)]
P89LPC954@LQFP48 (ISP) [ISP-HEADER01]
P89LPC954@PLCC44 [(SA244)]
P89LPC954@PLCC44 (ISP) [ISP-HEADER01]
P89LV51RB2 P89LV51RB2@PLCC44
[(SA244)]
P89LV51RB2@TQFP44 [(SA245A)]
P89LV51RC2
P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44
[(SA245A)]
P89LV51RD2 P89LV51RD2
(new)
P89LV51RD2(new)@PLCC44 [(SA244)]
P89LV51RD2(new)@TQFP44 [(SA245A)]
P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44
[(SA245A)]
P89LV51RD2BA(new)@PLCC44 [(SA244)]
P89LV51RD2BA@PLCC44 [(SA244)]
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]
P89LV51RD2BBC@TQFP44 [(SA245A)]
P89LV51RD2BN
P89LV51RD2BN(new)
P89LV51RD2FA(new)@PLCC44 [(SA244)]
P89LV51RD2FA@PLCC44 [(SA244)]
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]
P89LV51RD2FBC@TQFP44 [(SA245A)]
P89LV51RD2FN
P89LV51RD2FN(new)
P89V51RB2
P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44
[(SA245A)]
P89V51RC2 P89V51RC2@PLCC44
[(SA244)]
P89V51RC2@TQFP44 [(SA245A)]
P89V51RD2
P89V51RD2(new) P89V51RD2(new)@PLCC44

[(SA244)]
P89V51RD2 (new) @TQFP44 [(SA245A)] P89V51RD2@PLCC44
[(SA244)]
P89V51RD2@TQFP44 [(SA245A)]
P89V51RD2BA (new) @PLCC44 [(SA244)]
P89V51RD2BA@PLCC44 [(SA244)]
P89V51RD2BBC (new) @TQFP44 [(SA245A)]
P89V51RD2BBC@TQFP44 [(SA245A)]
P89V51RD2BN
P89V51RD2BN (new)
P89V51RD2FA (new) @PLCC44 [(SA244)]
P89V51RD2FA@PLCC44 [(SA244)]
P89V51RD2FBC (new) @TQFP44 [(SA245A)]
P89V51RD2FBC@TQFP44 [(SA245A)]
P89V51RD2FN
P89V51RD2FN (new)
P89V52X2
P89V52X2 (ISP) [ISP-HEADER01] P89V52X2@PLCC44
[(SA244)]
P89V52X2@PLCC44 (ISP) [ISP-HEADER01]
P89V52X2@TQFP44 [(SA245A)]
P89V52X2@TQFP44 (ISP) [ISP-HEADER01]
P89V660@PLCC44 [(SA244)] P89V660@TQFP44
[(SA245A)]
P89V662@PLCC44 [(SA244)] P89V662@TQFP44
[(SA245A)]
P89V664@PLCC44 [(SA244)] P89V664@TQFP44
[(SA245A)]
PXAC37@PLCC44 [(SA244)] PXAC37@TQFP44
[(SA245A)]
PXAG17@PLCC44 [(SA244)] PXAG17@TQFP44
[(SA245A)]
PXAG27@PLCC44 [(SA244)] PXAG27@TQFP44
[(SA245A)]
PXAG37@PLCC44 [(SA244)] PXAG37@TQFP44
[(SA245A)]
PXAG39@PLCC44 [(SA244)] PXAG39@TQFP44
[(SA245A)]
PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44
[(SA245A)]

OKI

E (E) PROM / FRAM / NVRAM

MR27C1602B [(SA638)]	MR27C1602B@PSOP44
MR27V1602D [(SA638)]	MR27V1602D@PSOP44
MR27V1602D@TSOP44 [(SA645)] B005)]	MR27V1602D@TSOP48 [(SA247-
MR27V1602E [(SA638)]	MR27V1602E@PSOP44
MR27V1602E@TSOP44 [(SA645)] B005)]	MR27V1602E@TSOP48 [(SA247-
MR27V1602F [(SA638)]	MR27V1602F@PSOP44
MR27V1602F@TSOP44 [(SA645)] B005)]	MR27V1602F@TSOP48 [(SA247-
MR27V1652D [(SA638)]	MR27V1652D@PSOP44
MR27V1652D@TSOP44 [(SA645)] B005)]	MR27V1652D@TSOP48 [(SA247-
MR27V3202F@TSOP44 [(SA645)] B005)]	MR27V3202F@TSOP48 [(SA247-
MR27V401D [(SA638)]	MR27V401D@PSOP32
MR27V401D@TSOP32 [(SA620)]	
MR27V401E [(SA620)]	MR27V401E@TSOP32
MR27V402D [(SA661)]	MR27V402D@PSOP40
MR27V402D@TSOP44 [(SA645)]	
MR27V402E [(SA645)]	MR27V402E@TSOP44
MR27V6402D@PSOP44 [(SA638)] [(SA645)]	MR27V6402D@TSOP44
MR27V6402D@TSOP48 [(SA247-B005)] [(SA638)]	MR27V6402G@PSOP44
MR27V6402G@TSOP44 [(SA645)] B005)]	MR27V6402G@TSOP48 [(SA247-
MR27V802D [(SA638)]	MR27V802D@PSOP44

MR27V802D@TSOP44 [(SA645)]	MR27V802F@PSOP44
[(SA638)]	
MR27V802F@TSOP44 [(SA645)]	MR27V802F@TSOP48 [(SA247-
B005)]	
MR27V852D	MR27V852D@PSOP44
[(SA638)]	
MR27V852D@TSOP44 [(SA645)]	
MR27V852E	
MR27V852E@SOJ42 [(SA661)]	MSM16812
(08bit)	
MSM16812(08bit)@SOIC8 [(SA602A)]	
MSM271000	
MSM271000@PLCC32 [(SA015A1T)]	MSM271000@TSOP32
[(SA410T)]	
MSM27128	
MSM27128A	
MSM27128AS	MSM27128AZB-
RS	
MSM2716	
MSM27256	
MSM27256AS	MSM27256ZB-
RS	
MSM2732	
MSM2732A	
MSM27512	
MSM27512AS	
MSM27512ZB-RS	
MSM2764	
MSM2764A	
MSM2764AS	
MSM2764AZB-RS	
MSM2764RS	
MSM27C1024	
MSM27C1024AS	
MSM27C128	MSM27C128AZB-
RS	
MSM27C1602CZ	MSM27C1602CZ@PSOP44
[(SA638)]	
MSM27C1602CZ@TSOP48 [(SA247-B005)]	
MSM27C1652CZ	MSM27C1652CZ@PSOP44
[(SA638)]	
MSM27C1652CZ@TSOP48 [(SA247-B005)]	
MSM27C256	

MSM27C256A
MSM27C256H
MSM27C256HZB
MSM27C256ZB
MSM27C64AS
MSM27C802CZ MSM27C802CZ@PSOP44
[(SA638)]
MSM27C802CZ@TSOP44 [(SA645)]
MSM27C852CZ
MSM27C852CZ@PSOP44 [(SA638)] MSM27C852CZ@TSOP44
[(SA645)]
MSM2816A(RS)
MSM28C16A

DRAM & SRAM

MSM51256 MSM51256@SOIC28
[(SA630)]
MSM51257AL MSM51257AL@SOIC28
[(SA630)]
MSM51257ALL MSM51257ALL@SOIC28
[(SA630)]
MSM5165AL MSM5165AL@SOIC28
[(SA630)]
MSM5188 MSM5188@SOJ22
[(SA646)]

PARALLAX

MICROCONTROLLER

SX20AC/SS/G@SSOP20 [(SA626A)] SX20AC/SS@SSOP20
[(SA626A)]
SX28AC/DP SX28AC/DP/
G
SX28AC/SS/G@SSOP28 [(SA626A)] SX28AC/SS@SSOP28
[(SA626A)]
SX48BD/G@TQFP48 [(SA248)] SX48BD@TQFP48
[(SA248)]

PFLASH(MSTAR)

E (E) PROM / FRAM / NVRAM

PS25LV010A@SOIC8 [(SA602A)]	PS25LV010A@WSON8
[(SA683)]	
PS25LV020@SOIC8 [(SA602A)]	PS25LV020@WSON8
[(SA683)]	
PS25LV040@SOIC8 [(SA605A)]	PS25LV040@WSON8
[(SA683)]	
PS25LV080@SOIC8 [(SA605A)]	PS25LV080@WSON8
[(SA683)]	

PHILIPS

E (E) PROM / FRAM / NVRAM

27C010	27C010@PLCC32
[(SA015A1T)]	
27C010@TSOP32 [(SA410T)]	
27C040	
27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32
[(SA410T)]	
27C210	27C210@PLCC44
[(SA244)]	
27C240	27C240@PLCC44
[(SA244)]	
27C256	27C256@PLCC32
[(SA015A1T)]	
27C32	
27C512	
27C512@PLCC32 [(SA015A1T)]	
27C64	
27C64@PLCC32 [(SA015A1T)]	
27C64A	
27C64A@PLCC32 [(SA015A1T)]	
27C64AF	
27C64AF@PLCC32 [(SA015A1T)]	
27HC641	
27HC641@PLCC28 [(SA008A)]	
27PC32	

PCA24S08@SOIC8 [(SA602A)]	PCA24S08@TSSOP8
[(SA026)]	
PCA8574(P)	PCA8574(T)@SOIC16
[(SA404)]	
PCA8574(TS)@SSOP20 [(SA026)]	PCA8574A
(P)	
PCA8574A(T)@SOIC16 [(SA404)]	PCA8574A(TS)@SSOP20
[(SA026)]	
PCA8581	PCA8581@SOIC8
[(SA602A)]	
PCA8581C	PCA8581C@SOIC8
[(SA602A)]	
PCA8582A	PCA8582A@SOIC8
[(SA602A)]	
PCA8582B	PCA8582B@SOIC8
[(SA602A)]	
PCA8582C	PCA8582C@SOIC8
[(SA602A)]	
PCA8582D	PCA8582D@SOIC8
[(SA602A)]	
PCA8582E	PCA8582E@SOIC8
[(SA602A)]	
PCA9500@HQVFN16	PCA9500@SOIC16
[(SA404)]	
PCA9500@TSSOP16 [(SA026)]	
PCA9501@HQVFN20	
PCA9501@SOIC20 [(SA404)]	PCA9501@TSSOP20
[(SA026)]	
PCA9561D@SOP20 [(SA404)]	PCA9561W@TSSOP20
[(SA026)]	
PCD8581	PCD8581@SOIC8
[(SA602A)]	
PCD8581C	PCD8581C@SOIC8
[(SA602A)]	
PCD8582A	PCD8582A@SOIC8
[(SA602A)]	
PCD8582B	PCD8582B@SOIC8
[(SA602A)]	
PCD8582C	PCD8582C@SOIC8
[(SA602A)]	
PCD8582D	PCD8582D@SOIC8
[(SA602A)]	
PCD8582E	PCD8582E@SOIC8

[(SA602A)]	
PCF85102C	PCF85102C@SOIC8
[(SA602A)]	
PCF85103C	PCF85103C@SOIC8
[(SA602A)]	
PCF85116	PCF85116@SOIC8
[(SA602A)]	
PCF8581	PCF8581@SOIC8
[(SA602A)]	
PCF8581C	PCF8581C@SOIC8
[(SA602A)]	
PCF8582A	PCF8582A@SOIC8
[(SA602A)]	
PCF8582B	PCF8582B@SOIC8
[(SA602A)]	
PCF8582C	PCF8582C@SOIC8
[(SA602A)]	
PCF8582D	PCF8582D@SOIC8
[(SA602A)]	
PCF8582E	PCF8582E@SOIC8
[(SA602A)]	
PCF8594	PCF8594@SOIC8
[(SA626A)]	
PCF8594C	PCF8594C@SOIC8
[(SA626A)]	
PCF8594D	PCF8594D@SOIC8
[(SA626A)]	
PCF8594E	PCF8594E@SOIC8
[(SA626A)]	
PCF8598	PCF8598@SOIC8
[(SA626A)]	
PCF8598C	PCF8598C@SOIC8
[(SA626A)]	
PCF8598D	PCF8598D@SOIC8
[(SA626A)]	
PCF8598E	PCF8598E@SOIC8
[(SA626A)]	

MICROCONTROLLER

P83C660X2@PLCC44 [(SA244)]	P83C660X2@TQFP44
[(SA245A)]	

P83C661X2@PLCC44 [(SA244)]	P83C661X2@TQFP44
[(SA245A)]	
P87C51	P87C51@PLCC44
[(SA244)]	
P87C51@TQFP44 [(SA245A)]	
P87C51FA	
P87C51FA@PLCC44 [(SA244)]	P87C51FA@TQFP44
[(SA245A)]	
P87C51FB	P87C51FB@PLCC44
[(SA244)]	
P87C51FB@TQFP44 [(SA245A)]	
P87C51FC	
P87C51FC@PLCC44 [(SA244)]	P87C51FC@TQFP44
[(SA245A)]	
P87C51MA2@PLCC44 [(SA244)]	P87C51MB2@PLCC44
[(SA244)]	
P87C51MC2@PLCC44 [(SA244)]	P87C51RA
+	
P87C51RA+@PLCC44 [(SA244)]	P87C51RA+@TQFP44
[(SA245A)]	
P87C51RA2	P87C51RA2@PLCC44
[(SA244)]	
P87C51RA2@TQFP44 [(SA245A)]	P87C51RB
+	
P87C51RB+@PLCC44 [(SA244)]	P87C51RB+@TQFP44
[(SA245A)]	
P87C51RB2	P87C51RB2@PLCC44
[(SA244)]	
P87C51RB2@TQFP44 [(SA245A)]	P87C51RC
+	
P87C51RC+@PLCC44 [(SA244)]	P87C51RC+@TQFP44
[(SA245A)]	
P87C51RC2	P87C51RC2@PLCC44
[(SA244)]	
P87C51RC2@TQFP44 [(SA245A)]	P87C51RD
+	
P87C51RD+@PLCC44 [(SA244)]	P87C51RD+@TQFP44
[(SA245A)]	
P87C51RD2	P87C51RD2@PLCC44
[(SA244)]	
P87C51RD2@TQFP44 [(SA245A)]	
P87C51SB	
P87C51SB@PLCC44 [(SA244)]	P87C51SB@TQFP44

[(SA245A)]
P87C51SF P87C51SF@PLCC44
[(SA244)]
P87C51SF@TQFP44 [(SA245A)]
P87C51UB
P87C51UB@PLCC44 [(SA244)] P87C51UB@TQFP44
[(SA245A)]
P87C51UF P87C51UF@PLCC44
[(SA244)]
P87C51UF@TQFP44 [(SA245A)]
P87C51X2
P87C51X2@PLCC44 [(SA244)] P87C51X2@TQFP44
[(SA245A)]
P87C52 P87C52@PLCC44
[(SA244)]
P87C52@TQFP44 [(SA245A)]
P87C524
P87C524@PLCC44 [(SA244)] P87C524@TQFP44
[(SA245A)]
P87C528 P87C528@PLCC44
[(SA244)]
P87C528@TQFP44 [(SA245A)]
P87C52SB
P87C52SB@PLCC44 [(SA244)] P87C52SB@TQFP44
[(SA245A)]
P87C52SF P87C52SF@PLCC44
[(SA244)]
P87C52SF@TQFP44 [(SA675)]
P87C52UB
P87C52UB@PLCC44 [(SA244)] P87C52UB@TQFP44
[(SA245A)]
P87C52UF P87C52UF@PLCC44
[(SA244)]
P87C52UF@TQFP44 [(SA245A)]
P87C52X2
P87C52X2@PLCC44 [(SA244)] P87C52X2@TQFP44
[(SA245A)]
P87C54 P87C54@PLCC44
[(SA244)]
P87C54@TQFP44 [(SA245A)]
P87C54SB
P87C54SB@PLCC44 [(SA244)] P87C54SB@TQFP44
[(SA245A)]

P87C54SF [(SA244)]	P87C54SF@PLCC44
P87C54SF@TQFP44 [(SA245A)]	
P87C54UB P87C54UB@PLCC44 [(SA244)] [(SA245A)]	P87C54UB@TQFP44
P87C54UF [(SA244)]	P87C54UF@PLCC44
P87C54UF@TQFP44 [(SA245A)]	
P87C54X2 P87C54X2@PLCC44 [(SA244)] [(SA245A)]	P87C54X2@TQFP44
P87C550 [(SA244)]	P87C550@PLCC44
P87C552@PLCC68 (*) [(SA648-B6806)]	
P87C554@PLCC68 (*) [(SA648-B6806)]	
P87C575 [(SA244)]	P87C575@PLCC44
P87C575@TQFP44 [(SA245A)]	
P87C576 P87C576@PLCC44 [(SA244)] [(SA245A)]	P87C576@TQFP44
P87C58 [(SA244)]	P87C58@PLCC44
P87C58@TQFP44 [(SA245A)]	
P87C58SB P87C58SB@PLCC44 [(SA244)] [(SA245A)]	P87C58SB@TQFP44
P87C58UB [(SA244)]	P87C58UB@PLCC44
P87C58UB@TQFP44 [(SA245A)]	
P87C58X2 P87C58X2@PLCC44 [(SA244)] [(SA245A)]	P87C58X2@TQFP44
P87C591@PLCC44 [(SA244)] [(SA245A)]	P87C591@TQFP44
P87C652 [(SA244)]	P87C652@PLCC44
P87C652@TQFP44 [(SA245A)]	
P87C654 P87C654@PLCC44 [(SA244)] [(SA245A)]	P87C654@TQFP44
P87C660X2@PLCC44 [(SA244)]	P87C660X2@TQFP44

[(SA245A)]	
P87C661X2@PLCC44 [(SA244)]	P87C661X2@TQFP44
[(SA245A)]	
P87C748	P87C748@PLCC28
[(SA008A)]	
P87C749	P87C749@PLCC28
[(SA008A)]	
P87C750	P87C750@PLCC28
[(SA008A)]	
P87C750@SSOP24 [(SA626A)]	
P87C751	
P87C751@PLCC28 [(SA008A)]	P87C751@SSOP24
[(SA626A)]	
P87C752	P87C752@PLCC28
[(SA008A)]	
P87C752@SSOP28 [(SA626A)]	
P87C754	
P87C754@PLCC28 [(SA008A)]	P87C754@SSOP28
[(SA626A)]	
P87CL52X2	P87CL52X2@PLCC44
[(SA244)]	
P87CL52X2@TQFP44 [(SA245A)]	
P87CL54X2	
P87CL54X2@PLCC44 [(SA244)]	P87CL54X2@TQFP44
[(SA245A)]	
P87L51FA	P87L51FA@PLCC44
[(SA244)]	
P87L51FA@TQFP44 [(SA245A)]	
P87L51FB	
P87L51FB@PLCC44 [(SA244)]	P87L51FB@TQFP44
[(SA245A)]	
P87LPC759	P87LPC759 (ISP) [ISP-
HEADER01]	
P87LPC760	P87LPC760 (ISP) [ISP-
HEADER01]	
P87LPC760@TSSOP14 [(SA026)]	
P87LPC760@TSSOP14 (ISP) [ISP-HEADER01]	
P87LPC761	P87LPC761 (ISP) [ISP-
HEADER01]	
P87LPC762	P87LPC762 (ISP) [ISP-
HEADER01]	
P87LPC762@PLCC44 [(SA244)]	
P87LPC762@PLCC44 (ISP) [ISP-HEADER01]	

P87LPC762@SOIC20 [(SA404)]
P87LPC762@SOIC20(ISP) [ISP-HEADER01]
P87LPC764 P87LPC764(ISP) [ISP-
HEADER01]
P87LPC764@PLCC44 [(SA244)]
P87LPC764@PLCC44(ISP) [ISP-HEADER01]
P87LPC764@SOIC20 [(SA404)]
P87LPC764@SOIC20(ISP) [ISP-HEADER01]
P87LPC764@TSSOP20 [(SA643)]
P87LPC764@TSSOP20(ISP) [ISP-HEADER01]
P87LPC767 P87LPC767(ISP) [ISP-
HEADER01]
P87LPC767@PLCC44 [(SA244)]
P87LPC767@PLCC44(ISP) [ISP-HEADER01]
P87LPC767@SOIC20 [(SA404)]
P87LPC767@SOIC20(ISP) [ISP-HEADER01]
P87LPC768 P87LPC768(ISP) [ISP-
HEADER01]
P87LPC768@SOIC20 [(SA404)]
P87LPC768@SOIC20(ISP) [ISP-HEADER01]
P87LPC769 P87LPC769(ISP) [ISP-
HEADER01]
P87LPC769@PLCC44 [(SA244)]
P87LPC769@PLCC44(ISP) [ISP-HEADER01]
P87LPC769@SOIC20 [(SA404)]
P87LPC769@SOIC20(ISP) [ISP-HEADER01]
P87LPC778 P87LPC778(ISP) [ISP-
HEADER01]
P87LPC778@TSSOP20 [(SA026)]
P87LPC778@TSSOP20(ISP) [ISP-HEADER01]
P87LPC779 P87LPC779(ISP) [ISP-
HEADER01]
P87LPC779@TSSOP20 [(SA643)]
P87LPC779@TSSOP20(ISP) [ISP-HEADER01]
P89C138 P89C138@PLCC44
[(SA244)]
P89C138@TQFP44 [(SA245A)]
P89C238
P89C238@PLCC44 [(SA244)] P89C238@TQFP44
[(SA245A)]
P89C51B P89C51B@PLCC44
[(SA244)]
P89C51B@TQFP44 [(SA245A)] P89C51RA

+

P89C51RA+@PLCC44 [(SA244)]

P89C51RA+@TQFP44

[(SA245A)]

P89C51RA2B

P89C51RA2B@PLCC44

[(SA244)]

P89C51RA2B@TQFP44 [(SA245A)]

P89C51RB

+

P89C51RB+@PLCC44 [(SA244)]

P89C51RB+@TQFP44

[(SA245A)]

P89C51RB2B

P89C51RB2B@PLCC44

[(SA244)]

P89C51RB2B@TQFP44 [(SA245A)]

P89C51RB2H

P89C51RB2H@TQFP44

P89C51RB2H@PLCC44 [(SA244)]

[(SA245A)]

P89C51RC+

P89C51RC+@PLCC44

[(SA244)]

P89C51RC+@TQFP44 [(SA245A)]

P89C51RC2B

P89C51RC2B@TQFP44

P89C51RC2B@PLCC44 [(SA244)]

[(SA245A)]

P89C51RC2H

P89C51RC2H@PLCC44

[(SA244)]

P89C51RC2H@TQFP44 [(SA245A)]

P89C51RD

+

P89C51RD+@PLCC44 [(SA244)]

P89C51RD+@TQFP44

[(SA245A)]

P89C51RD2B

P89C51RD2B@PLCC44

[(SA244)]

P89C51RD2B@TQFP44 [(SA245A)]

P89C51RD2H

P89C51RD2H@TQFP44

P89C51RD2H@PLCC44 [(SA244)]

[(SA245A)]

P89C51UB

P89C51UB@PLCC44

[(SA244)]

P89C51UB@TQFP44 [(SA245A)]

P89C51UF

P89C51UF@TQFP44

P89C51UF@PLCC44 [(SA244)]

[(SA245A)]

P89C51X2

P89C51X2@PLCC44

[(SA244)]

P89C51X2@TQFP44 [(SA245A)]

P89C51X2B

P89C51X2B@PLCC44 [(SA244)]	P89C51X2B@TQFP44
[(SA245A)]	
P89C51X2F	P89C51X2F@PLCC44
[(SA244)]	
P89C51X2F@TQFP44 [(SA245A)]	
P89C52	
P89C52@PLCC44 [(SA244)]	P89C52@TQFP44
[(SA245A)]	
P89C52B	P89C52B@PLCC44
[(SA244)]	
P89C52B@TQFP44 [(SA245A)]	
P89C52UB	
P89C52UB@PLCC44 [(SA244)]	P89C52UB@TQFP44
[(SA245A)]	
P89C52UF	P89C52UF@PLCC44
[(SA244)]	
P89C52UF@TQFP44 [(SA245A)]	
P89C52X2	
P89C52X2@PLCC44 [(SA244)]	P89C52X2@TQFP44
[(SA245A)]	
P89C52X2B	P89C52X2B@PLCC44
[(SA244)]	
P89C52X2B@TQFP44 [(SA245A)]	
P89C52X2F	
P89C52X2F@PLCC44 [(SA244)]	P89C52X2F@TQFP44
[(SA245A)]	
P89C536@PLCC44 [(SA244)]	P89C538@PLCC44
[(SA244)]	
P89C54	P89C54@PLCC44
[(SA244)]	
P89C54@TQFP44 [(SA245A)]	
P89C54B	
P89C54B@PLCC44 [(SA244)]	P89C54B@TQFP44
[(SA245A)]	
P89C54UB	P89C54UB@PLCC44
[(SA244)]	
P89C54UB@TQFP44 [(SA245A)]	
P89C54UF	
P89C54UF@PLCC44 [(SA244)]	P89C54UF@TQFP44
[(SA245A)]	
P89C54X2	P89C54X2@PLCC44
[(SA244)]	
P89C54X2@TQFP44 [(SA245A)]	

P89C54X2B	
P89C54X2B@PLCC44 [(SA244)]	P89C54X2B@TQFP44
[(SA245A)]	
P89C54X2F	P89C54X2F@PLCC44
[(SA244)]	
P89C54X2F@TQFP44 [(SA245A)]	
P89C58	
P89C58@PLCC44 [(SA244)]	P89C58@TQFP44
[(SA245A)]	
P89C58B	P89C58B@PLCC44
[(SA244)]	
P89C58B@TQFP44 [(SA245A)]	
P89C58UB	
P89C58UB@PLCC44 [(SA244)]	P89C58UB@TQFP44
[(SA245A)]	
P89C58UF	P89C58UF@PLCC44
[(SA244)]	
P89C58UF@TQFP44 [(SA245A)]	
P89C58X2	
P89C58X2@PLCC44 [(SA244)]	P89C58X2@TQFP44
[(SA245A)]	
P89C58X2B	P89C58X2B@PLCC44
[(SA244)]	
P89C58X2B@TQFP44 [(SA245A)]	
P89C58X2F	
P89C58X2F@PLCC44 [(SA244)]	P89C58X2F@TQFP44
[(SA245A)]	
P89C60X2	P89C60X2@PLCC44
[(SA244)]	
P89C60X2@TQFP44 [(SA245A)]	
P89C61X2	
P89C61X2@PLCC44 [(SA244)]	P89C61X2@TQFP44
[(SA245A)]	
P89C660	P89C660@PLCC44
[(SA244)]	
P89C660@TQFP44 [(SA245A)]	
P89C662	
P89C662@PLCC44 [(SA244)]	P89C662@TQFP44
[(SA245A)]	
P89C664	P89C664@PLCC44
[(SA244)]	
P89C664@TQFP44 [(SA245A)]	
P89C668	

P89C668@PLCC44 [(SA244)] P89C668@TQFP44
[(SA245A)]
P89C669 P89C669@LQFP44
[(SA245A)]
P89C669@PLCC44 [(SA244)]
P89C738 P89C738@TQFP44
P89C738@PLCC44 [(SA244)]
[(SA245A)]
P89C838 P89C838@PLCC44
[(SA244)]
P89C838@TQFP44 [(SA245A)] P89CV51RB2@PLCC44
[(SA244)]
P89CV51RB2@TQFP44 [(SA245A)] P89CV51RC2@PLCC44
[(SA244)]
P89CV51RC2@TQFP44 [(SA245A)] P89CV51RD2@PLCC44
[(SA244)]
P89CV51RD2@TQFP44 [(SA245A)] P89LPC901(FD)
[(SA602A)]
P89LPC901(FD)(ISP) [ISP-HEADER01]
P89LPC901(FN)
P89LPC901(FN)(ISP) [ISP-HEADER01]
P89LPC902(FD) [(SA602A)]
P89LPC902(FD)(ISP) [ISP-HEADER01]
P89LPC902(FN)
P89LPC902(FN)(ISP) [ISP-HEADER01]
P89LPC903(FD) [(SA602A)]
P89LPC903(FD)(ISP) [ISP-HEADER01]
P89LPC904(FD) [(SA605A)]
P89LPC904(FD)(ISP) [ISP-HEADER01]
P89LPC904(FN)
P89LPC904(FN)(ISP) [ISP-HEADER01]
P89LPC906(FD) [(SA605A)]
P89LPC906(FD)(ISP) [ISP-HEADER01]
P89LPC907(FD) [(SA605A)]
P89LPC907(FD)(ISP) [ISP-HEADER01]
P89LPC908(FD) [(SA605A)]
P89LPC908(FD)(ISP) [ISP-HEADER01]
P89LPC9102(FTK)@HVSON10 [(SA695A)]
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9103(FTK)@HVSON10 [(SA695A)]
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]
P89LPC9107(FDH)@TSSOP14 [(SA643)]
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]

P89LPC9107(FN)
P89LPC9107(FN)(ISP) [ISP-HEADER01]
P89LPC912(FDH)@TSSOP14 [(SA643)]
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC913(FDH)@TSSOP14 [(SA643)]
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC914(FDH)@TSSOP14 [(SA643)]
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC915(FDH)@TSSOP14 [(SA643)]
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]
P89LPC916(FDH)@TSSOP16 [(SA643)]
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC917(FDH)@TSSOP16 [(SA643)]
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]
P89LPC920(FDH)@TSSOP20 [(SA643)]
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC920(FN)
P89LPC920(FN)(ISP) [ISP-HEADER01]
P89LPC921(FDH)@TSSOP20 [(SA643)]
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC921(FN)
P89LPC921(FN)(ISP) [ISP-HEADER01]
P89LPC922(FDH)@TSSOP20 [(SA643)]
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC922(FN)
P89LPC922(FN)(ISP) [ISP-HEADER01]
P89LPC9221(FDH)@TSSOP20 [(SA643)]
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC9221(FN)
P89LPC9221(FN)(ISP) [ISP-HEADER01]
P89LPC924(FDH)@TSSOP20 [(SA643)]
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC924(FN)
P89LPC924(FN)(ISP) [ISP-HEADER01]
P89LPC925(FDH)@TSSOP20 [(SA643)]
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]
P89LPC925(FN)
P89LPC925(FN)(ISP) [ISP-HEADER01]
P89LPC930(BA)@PLCC28 [(SA008A)]
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC930(BDH)@TSSOP28 [(SA643)]
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC931(BA)@PLCC28 [(SA008A)]

P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC931(BDH)@TSSOP28 [(SA643)]
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28
[(SA643)]
P89LPC93201(BA)@PLCC28 [(SA008A)]
P89LPC93201(BDH)@TSSOP28 [(SA643)]
P89LPC93201(FA)@PLCC28 [(SA008A)]
P89LPC93201(FDH)@TSSOP28 [(SA643)]
P89LPC93201(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9321(BA)@PLCC28 [(SA008A)]
P89LPC9321(BDH)@TSSOP28 [(SA643)]
P89LPC9321(FA)@PLCC28 [(SA008A)]
P89LPC9321(FDH)@TSSOP28 [(SA643)]
P89LPC9321(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(BA)@PLCC28 [(SA008A)]
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC932A1(BDH)@TSSOP28 [(SA643)]
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FDH)@TSSOP28 [(SA643)]
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC933(BDH)@TSSOP28 [(SA643)]
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC933(FDH)@TSSOP28 [(SA643)]
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC934(BDH)@TSSOP28 [(SA643)]
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC934(FDH)@TSSOP28 [(SA643)]
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(BA)@PLCC28 [(SA008A)]
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(BDH)@TSSOP28 [(SA643)]
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FA)@PLCC28 [(SA008A)]
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC935(FDH)@TSSOP28 [(SA643)]
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93501(BA)@PLCC28 [(SA008A)]
P89LPC93501(BDH)@TSSOP28 [(SA643)]

P89LPC93501(FA)@PLCC28 [(SA008A)]
P89LPC93501(FDH)@TSSOP28 [(SA643)]
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9351(BA)@PLCC28 [(SA008A)]
P89LPC9351(BDH)@TSSOP28 [(SA643)]
P89LPC9351(FA)@PLCC28 [(SA008A)]
P89LPC9351(FDH)@TSSOP28 [(SA643)]
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]
P89LPC936(FA)@PLCC28 [(SA008A)]
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC936(FDH)@TSSOP28 [(SA643)]
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC938(FA)@PLCC28 [(SA008A)]
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]
P89LPC938(FDH)@TSSOP28 [(SA643)]
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]
P89LPC93801(BA)@PLCC28 [(SA008A)]
P89LPC93801(BDH)@TSSOP28 [(SA643)]
P89LPC93801(FA)@PLCC28 [(SA008A)]
P89LPC93801(FDH)@TSSOP28 [(SA643)]
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9381(BA)@PLCC28 [(SA008A)]
P89LPC9381(BDH)@TSSOP28 [(SA643)]
P89LPC9381(FA)@PLCC28 [(SA008A)]
P89LPC9381(FDH)@TSSOP28 [(SA643)]
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]
P89LPC952@LQFP44 [(SA245A)]
P89LPC952@LQFP44(ISP) [ISP-HEADER01]
P89LPC952@LQFP48 [(SA248)]
P89LPC952@LQFP48(ISP) [ISP-HEADER01]
P89LPC952@PLCC44 [(SA244)]
P89LPC952@PLCC44(ISP) [ISP-HEADER01]
P89LPC954@LQFP44 [(SA245A)]
P89LPC954@LQFP44(ISP) [ISP-HEADER01]
P89LPC954@LQFP48 [(SA248)]
P89LPC954@LQFP48(ISP) [ISP-HEADER01]
P89LPC954@PLCC44 [(SA244)]
P89LPC954@PLCC44(ISP) [ISP-HEADER01]
P89LV51RB2 P89LV51RB2@PLCC44

[(SA244)]
P89LV51RB2@TQFP44 [(SA245A)]
P89LV51RC2
P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44
[(SA245A)]
P89LV51RD2 P89LV51RD2
(new)
P89LV51RD2(new)@PLCC44 [(SA244)]
P89LV51RD2(new)@TQFP44 [(SA245A)]
P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44
[(SA245A)]
P89LV51RD2BA(new)@PLCC44 [(SA244)]
P89LV51RD2BA@PLCC44 [(SA244)]
P89LV51RD2BBC(new)@TQFP44 [(SA245A)]
P89LV51RD2BBC@TQFP44 [(SA245A)]
P89LV51RD2BN
P89LV51RD2BN(new)
P89LV51RD2FA(new)@PLCC44 [(SA244)]
P89LV51RD2FA@PLCC44 [(SA244)]
P89LV51RD2FBC(new)@TQFP44 [(SA245A)]
P89LV51RD2FBC@TQFP44 [(SA245A)]
P89LV51RD2FN
P89LV51RD2FN(new)
P89V51RB2
P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44
[(SA245A)]
P89V51RC2 P89V51RC2@PLCC44
[(SA244)]
P89V51RC2@TQFP44 [(SA245A)]
P89V51RD2
P89V51RD2(new) P89V51RD2(new)@PLCC44
[(SA244)]
P89V51RD2(new)@TQFP44 [(SA245A)] P89V51RD2@PLCC44
[(SA244)]
P89V51RD2@TQFP44 [(SA245A)]
P89V51RD2BA(new)@PLCC44 [(SA244)]
P89V51RD2BA@PLCC44 [(SA244)]
P89V51RD2BBC(new)@TQFP44 [(SA245A)]
P89V51RD2BBC@TQFP44 [(SA245A)]
P89V51RD2BN
P89V51RD2BN(new)
P89V51RD2FA(new)@PLCC44 [(SA244)]
P89V51RD2FA@PLCC44 [(SA244)]

P89V51RD2FBC(new)@TQFP44 [(SA245A)]
P89V51RD2FBC@TQFP44 [(SA245A)]
P89V51RD2FN
P89V51RD2FN(new)
P89V52X2
P89V52X2(ISP) [ISP-HEADER01] P89V52X2@PLCC44
[(SA244)]
P89V52X2@PLCC44(ISP) [ISP-HEADER01]
P89V52X2@TQFP44 [(SA245A)]
P89V52X2@TQFP44(ISP) [ISP-HEADER01]
P89V660@PLCC44 [(SA244)] P89V660@TQFP44
[(SA245A)]
P89V662@PLCC44 [(SA244)] P89V662@TQFP44
[(SA245A)]
P89V664@PLCC44 [(SA244)] P89V664@TQFP44
[(SA245A)]
PXAC37@PLCC44 [(SA244)] PXAC37@TQFP44
[(SA245A)]
PXAG17@PLCC44 [(SA244)] PXAG17@TQFP44
[(SA245A)]
PXAG27@PLCC44 [(SA244)] PXAG27@TQFP44
[(SA245A)]
PXAG37@PLCC44 [(SA244)] PXAG37@TQFP44
[(SA245A)]
PXAG39@PLCC44 [(SA244)] PXAG39@TQFP44
[(SA245A)]
PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44
[(SA245A)]

PJ

E (E) PROM/FRAM/NVRAM

PJ24C02 P89V52X2@SOIC8
[(SA602A)]
PJ24C02@TSSOP8 [(SA026)]

PMC

E (E) PROM/FRAM/NVRAM

PM24C64	PM24C64@SOIC8
[(SA602A)]	
PM24C64@TSOP8 [(SA026)]	PM25LV010(B)@SOIC8
[(SA023A)]	
PM25LV010(Q)@WSON8 [(SA683)]	PM25LV010(S)@SOIC8
[(SA602A)]	
PM25LV010A@SOIC8 [(SA602A)]	PM25LV010A@WSON8
[(SA683)]	
PM25LV016@SOIC8 [(SA605A)]	PM25LV016@WSON8
[(SA683)]	
PM25LV016A@SOIC8 [(SA605A)]	PM25LV016A@WSON8
[(SA683)]	
PM25LV020(B)@SOIC8 [(SA023A)]	PM25LV020(Q)@WSON8
[(SA683)]	
PM25LV020(S)@SOIC8 [(SA602A)]	PM25LV040(B)@SOIC8
[(SA023A)]	
PM25LV040(Q)@WSON8 [(SA683)]	PM25LV040(S)@SOIC8
[(SA602A)]	
PM25LV080@SOIC8 [(SA605A)]	PM25LV080@WSON8
[(SA683)]	
PM25LV080A@SOIC8 [(SA605A)]	PM25LV080A@WSON8
[(SA683)]	
PM25LV512(B)@SOIC8 [(SA023A)]	PM25LV512(Q)@WSON8
[(SA683)]	
PM25LV512(S)@SOIC8 [(SA602A)]	
PM29F002B	
PM29F002B@PLCC32 [(SA015A1T)]	
PM29F002T	
PM29F002T@PLCC32 [(SA015A1T)]	
PM29F004B	
PM29F004B@PLCC32 [(SA015A1T)]	
PM29F004T	
PM29F004T@PLCC32 [(SA015A1T)]	
PM29LV002B	
PM29LV002B@PLCC32 [(SA015A1T)]	PM29LV002B@VSOP32
[(SA620)]	
PM29LV002T	PM29LV002T@PLCC32
[(SA015A1T)]	
PM29LV002T@VSOP32 [(SA620)]	PM29LV004B@PLCC32
[(SA015A1T)]	
PM29LV004B@VSOP32 [(SA620)]	PM29LV004T@PLCC32
[(SA015A1T)]	
PM29LV004T@VSOP32 [(SA620)]	PM29LV104RB@PLCC32

[(SA015A1T)]	
PM29LV104RB@VSOP32 [(SA620)]	PM29LV104RT@PLCC32
[(SA015A1T)]	
PM29LV104RT@VSOP32 [(SA620)]	
PM37LV512	
PM37LV512@PLCC32 [(SA015A1T)]	PM37LV512@VSOP32
[(SA620)]	
PM39F010	PM39F010@PLCC32
[(SA015A1T)]	
PM39F010@VSOP32 [(SA620)]	
PM39F020	
PM39F020@PLCC32 [(SA015A1T)]	PM39F020@VSOP32
[(SA620)]	
PM39F040	PM39F040@PLCC32
[(SA015A1T)]	
PM39F040@VSOP32 [(SA620)]	PM39LV010@PLCC32
[(SA015A1T)]	
PM39LV010@VSOP32 [(SA620)]	PM39LV010R@PLCC32
[(SA015A1T)]	
PM39LV010R@VSOP32 [(SA620)]	PM39LV020@PLCC32
[(SA015A1T)]	
PM39LV020@VSOP32 [(SA620)]	PM39LV040@PLCC32
[(SA015A1T)]	
PM39LV040@VSOP32 [(SA620)]	PM39LV512@PLCC32
[(SA015A1T)]	
PM39LV512@VSOP32 [(SA620)]	PM39LV512R@PLCC32
[(SA015A1T)]	
PM39LV512R@VSOP32 [(SA620)]	PM49FL002T@PLCC32
[(SA015A1T)]	
PM49FL002T@VSOP32 [(SA620)]	
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]	
PM49FL004T(Low)@VSOP32 [(SA620-B005)]	
PM49FL004T@PLCC32 [(SA015A1T)]	PM49FL004T@VSOP32
[(SA620)]	
PM49FL008T@PLCC32 [(SA015A1T)]	PM49FL008T@VSOP32
[(SA620)]	
PM49LP002T@PLCC32 [(SA015A1T)]	PM49LP002T@VSOP32
[(SA620)]	

PSS

E (E) PROM / FRAM / NVRAM

PS24C256
[(SA602A)]
PS29FS001
[(SA015A1T)]
PS29FS001@TSOP32 [(SA410T)]
[(SA620)]
PS29LP001
[(SA015A1T)]
PS29LP001@VSOP32 [(SA620)]

PS24C256@SOIC8
PS29FS001@PLCC32
PS29FS001@VSOP32
PS29LP001@PLCC32

PTC

E (E) PROM / FRAM / NVRAM

PT28C020
[(SA015A1T)]
PT28C040
[(SA015A1T)]
PT29C020
[(SA015A1T)]
PT29C040
[(SA015A1T)]

PT28C020@PLCC32
PT28C040@PLCC32
PT29C020@PLCC32
PT29C040@PLCC32

MICROCONTROLLER

PT89316
[(SA244)]
PT89316@TQFP44 [(SA245A)]
PT8932
PT8932@PLCC44 [(SA244)]
[(SA245)]
PT8936
[(SA244)]
PT8936@TQFP44 [(SA245A)]
PT8956
PT8956@PLCC44 [(SA244)]
[(SA245A)]

PT89316@PLCC44
PT8932@TQFP44
PT8936@PLCC44
PT8956@TQFP44

QIXIN

MICROCONTROLLER

LS2051
[(SA404)]

LS2051@SOIC20

Quick Pulse

E (E) PROM / FRAM / NVRAM

27010
27011
27040
27128A
27210
27256
27512
2764A

RAMTRON

E (E) PROM / FRAM / NVRAM

FM1208
[(SA404)]
FM1608
[(SA404)]
FM1808
[(SA404)]
FM18L08
[(SA404)]
FM24164
[(SA602A)]
FM24C04 (P)
[(SA602A)]
FM24C04A (P)
[(SA602A)]
FM24C16 (P)
[(SA602A)]
FM24C16A (P)

FM1208@SOIC24
FM1608@SOIC28
FM1808@SOIC28
FM18L08@SOIC28
FM24164@SOIC8
FM24C04 (S) @SOP8
FM24C04A (S) @SOP8
FM24C16 (S) @SOP8
FM24C16A (S) @SOP8

[(SA602A)]	
FM24C256@SOIC8 [(SA605A)]	FM24C512@SOIC8
[(SA602A)]	
FM24C64	FM24C64@SOIC8
[(SA602A)]	
FM24CL04	FM24CL04@SOIC8
[(SA602A)]	
FM24CL16	FM24CL16@SOIC8
[(SA602A)]	
FM24CL64@SOIC8 [(SA602A)]	
FM25040	
FM25040@SOIC8 [(SA602A)]	
FM25160	
FM25160@SOIC8 [(SA602A)]	
FM25640	
FM25640@SOIC8 [(SA602A)]	
FM25C160	
FM25C160@SOIC8 [(SA602A)]	FM25CL04@SOIC8
[(SA602A)]	
FM25CL64	FM25CL64@SOIC8
[(SA602A)]	
FM25L16	FM25L16@SOIC8
[(SA602A)]	
FM25L256	FM25L256@SOIC8
[(SA602A)]	
FM25L256@TDFN8 [(BBBB)]	
FM25L512	
FM25L512@SOIC8 [(SA602A)]	FM25W256@SOIC8
[(SA602A)]	
FM30C256@SOIC20 [(SA404)]	FM3104@SOIC14
[(SA602)]	
FM3116@SOIC14 [(SA602)]	FM31256@SOIC14
[(SA602)]	
FM3164@SOIC14 [(SA602)]	FM32256G@SOIC14
[(SA602)]	
FM32256S@SOIC14 [(SA602)]	FM3264G@SOIC14
[(SA602)]	
FM3264S@SOIC14 [(SA602)]	
FM3808	
FM3808@TSOP32 [(SA620)]	

MICROCONTROLLER

VMX51C900	VMX51C900@PLCC44
[(SA244)]	
VMX51C900@TQFP44 [(SA245A)]	
VRS1000	
VRS1000@PLCC44 [(SA244)]	VRS1000@TQFP44
[(SA245A)]	
VRS1100	VRS1100@PLCC44
[(SA244)]	
VRS1100@TQFP44 [(SA245A)]	
VRS51C1000	
VRS51C1000@PLCC44 [(SA244)]	VRS51C1000@TQFP44
[(SA245A)]	
VRS51C1100	VRS51C1100@PLCC44
[(SA244)]	
VRS51C1100@TQFP44 [(SA245A)]	
VRS51C540	
VRS51C540@PLCC44 [(SA244)]	VRS51C540@TQFP44
[(SA245A)]	
VRS51C550	VRS51C550@PLCC44
[(SA244)]	
VRS51C550@TQFP44 [(SA245A)]	
VRS51C560	
VRS51C560@PLCC44 [(SA244)]	VRS51C560@TQFP44
[(SA245A)]	
VRS51C570	VRS51C570@PLCC44
[(SA244)]	
VRS51C570@TQFP44 [(SA245A)]	
VRS51C580	
VRS51C580@PLCC44 [(SA244)]	VRS51C580@TQFP44
[(SA245A)]	
VRS51C700	VRS51C700@PLCC44
[(SA244)]	
VRS51C700@TQFP44 [(SA245A)]	
VRS51L1050	
VRS51L1050@PLCC44 [(SA244)]	VRS51L1050@TQFP44
[(SA245A)]	
VRS51L540	VRS51L540@PLCC44
[(SA244)]	
VRS51L540@TQFP44 [(SA245A)]	
VRS51L550	
VRS51L550@PLCC44 [(SA244)]	VRS51L550@TQFP44
[(SA245A)]	

VRS51L560	VRS51L560@PLCC44
[(SA244)]	
VRS51L560@TQFP44 [(SA245A)]	
VRS51L570	
VRS51L570@PLCC44 [(SA244)]	VRS51L570@TQFP44
[(SA245A)]	
VRS51L580	VRS51L580@PLCC44
[(SA244)]	
VRS51L580@TQFP44 [(SA245A)]	
VRS51X540	
VRS51X540@PLCC44 [(SA244)]	VRS51X540@TQFP44
[(SA245A)]	
VRS51X550	VRS51X550@PLCC44
[(SA244)]	
VRS51X550@TQFP44 [(SA245A)]	
VRS51X560	
VRS51X560@PLCC44 [(SA244)]	VRS51X560@TQFP44
[(SA245A)]	
VRS51X570	VRS51X570@PLCC44
[(SA244)]	
VRS51X570@TQFP44 [(SA245A)]	
VRS51X580	
VRS51X580@PLCC44 [(SA244)]	VRS51X580@TQFP44
[(SA245A)]	
VRS540	VRS540@PLCC44
[(SA244)]	
VRS540@TQFP44 [(SA245A)]	
VRS550	
VRS550@PLCC44 [(SA244)]	VRS550@TQFP44
[(SA245A)]	
VRS560	VRS560@PLCC44
[(SA244)]	
VRS560@TQFP44 [(SA245A)]	
VRS570	
VRS570@PLCC44 [(SA244)]	VRS570@TQFP44
[(SA245A)]	
VRS580	VRS580@PLCC44
[(SA244)]	
VRS580@TQFP44 [(SA245A)]	
VRS700	
VRS700@PLCC44 [(SA244)]	VRS700@TQFP44
[(SA245A)]	
VRS900	VRS900@PLCC44

[(SA244)]
VRS900@TQFP44 [(SA245A)]

RATO

E (E) PROM / FRAM / NVRAM

RT24A02 [(SA602A)]	RT24A02@SOIC8
RT24A02@TSSOP8 [(SA026)]	
RT24A04 RT24A04@SOIC8 [(SA602A)]	RT24A04@TSSOP8
[(SA026)]	
RT24A08 [(SA602A)]	RT24A08@SOIC8
RT24A08@TSSOP8 [(SA026)]	
RT24A16 RT24A16@SOIC8 [(SA602A)]	RT24A16@TSSOP8
[(SA026)]	
RT93C46B(16bit) [(SA602A)]	RT93C46B(16bit)@SOIC8
RT93C46B(16bit)@TSSOP8 [(SA026)]	RT93LC46
(08bit)	
RT93LC46(08bit)@SOIC8 [(SA602A)]	RT93LC46(08bit)@TSSOP8
[(SA026)]	
RT93LC46(16bit) [(SA602A)]	RT93LC46(16bit)@SOIC8
RT93LC46(16bit)@TSSOP8 [(SA026)]	

RAYDIUM

E (E) PROM / FRAM / NVRAM

RM24C02@SOP8 [(SA602A)]	RM24C04@SOP8
[(SA602A)]	
RM24C08@SOP8 [(SA602A)]	RM24C128@SOP8
[(SA602A)]	
RM24C16@SOP8 [(SA602A)]	RM24C32@SOP8
[(SA602A)]	
RM24C64@SOP8 [(SA602A)]	

RENESAS**E (E) PROM / FRAM / NVRAM**

HN58C256A (FP)@SOP28 [(SA630)] (P)	HN58C256A
HN58C256A (T)@TSOP28 [(SA643)] [(SA620)]	HN58C257A (T)@TSOP32
HN58V24256 [(SA602A)]	HN58V24256@SOIC8
HN58V24256@TSSOP14 [(SA026)] HN58V24512	
HN58V24512@SOIC8 [(SA602A)] HN58W241000	
HN58W241000@SOIC8 [(SA602A)] HN58X2402	
HN58X2402@SOIC8 [(SA602A)] [(SA026)]	HN58X2402@TSSOP8
HN58X2404 [(SA602A)]	HN58X2404@SOIC8
HN58X2404@TSSOP8 [(SA026)] HN58X2408	
HN58X2408@SOIC8 [(SA602A)] [(SA026)]	HN58X2408@TSSOP8
HN58X24128 [(SA602A)]	HN58X24128@SOIC8
HN58X2416 [(SA602A)]	HN58X2416@SOIC8
HN58X2416@TSSOP8 [(SA026)] HN58X24256	
HN58X24256@SOIC8 [(SA602A)] HN58X2432	
HN58X2432@SOIC8 [(SA602A)] [(SA026)]	HN58X2432@TSSOP8
HN58X24512 [(SA602A)]	HN58X24512@SOIC8
HN58X2464 [(SA602A)]	HN58X2464@SOIC8
HN58X2464@TSSOP8 [(SA026)] [(SA602A)]	HN58X2502@SOIC8
HN58X2502@TSSOP8 [(SA026)]	HN58X2504@SOIC8

[(SA602A)]
HN58X2504@TSSOP8 [(SA026)] HN58X25128@SOIC8
[(SA602A)]
HN58X25128@TSSOP14 [(SA026)] HN58X25256@SOIC8
[(SA602A)]
HN58X25256@TSSOP14 [(SA026)] HN58X2532@SOIC8
[(SA602A)]
HN58X2532@TSSOP8 [(SA026)] HN58X2564@SOIC8
[(SA602A)]
HN58X2564@TSSOP8 [(SA026)]
M5L2732
M5L2732A
M5M29KB331(AVP)@TSOP48 [(SA247-B005)]
M5M29KB641(AVP)@TSOP48 [(SA247-B005)]
M5M29KE131BTP@TSOP52 [(SA657-B117)]
M5M29KE131BV@TSOP48 [(SA247-B005)]
M5M29KT331(AVP)@TSOP48 [(SA247-B005)]
M5M29KT641(AVP)@TSOP48 [(SA247-B005)]
M6MG3B641S16TP@TSOP52 [(SA657-B036)]
M6MG3T641S16TP@TSOP52 [(SA657-B036)]
M6MGB321S4TP@TSOP52 [(SA657-B036)]
M6MGB321S8TP@TSOP52 [(SA657-B036)]
M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGB331S8KT@TSOP52 [(SA657-B036)]
M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]
M6MGB641S16TP@TSOP52 [(SA657-B036)]
M6MGB641S4TP@TSOP52 [(SA657-B036)]
M6MGB641S8TP@TSOP52 [(SA657-B036)]
M6MGB647M34CKT@TSOP52 [(SA657-B036)]
M6MGB64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]
M6MGB64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]
M6MGB64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]
M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]
M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]
M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]
M6MGD13TW34DWG@CSP72 [(SA642F-B064A-T064F001)]
M6MGE157S4KT@TSOP52 [(SA657-B055)]
M6MGT321S4TP@TSOP52 [(SA657-B036)]
M6MGT321S8TP@TSOP52 [(SA657-B036)]
M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]
M6MGT331S8KT@TSOP52 [(SA657-B036)]

M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]
M6MGT641S16TP@TSOP52 [(SA657-B036)]
M6MGT641S4TP@TSOP52 [(SA657-B036)]
M6MGT641S8TP@TSOP52 [(SA657-B036)]
M6MGT647M34CKT@TSOP52 [(SA657-B036)]
M6MGT64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]
M6MGT64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]
M6MGT64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]
M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]
M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]

DRAM & SRAM

R1LV0408C@SOP32 [(SA438T)] R1LV0408C@STSOP32
[(SA620)]
R1LV0408C@TSOP32 [(SA410T)]

MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)] HD4074344@SOIC28
[(SA404)]
HD4074394@SDIP28 [(SA022A)] HD4074394@SOIC28
[(SA404)]
HD64F3694FX@TQFP48 [(SA671)] HD64F3694FY@TQFP48
[(SA248)]
HD64F3694GFX@TQFP48 [(SA671)] HD64F3694GFY@TQFP48
[(SA248)]
M34282E2GP [(SA026)] M34283G2GP
[(SA026)]
M34283G2GP(ISP) [ISP-HEADER01] M37544G2A(GP)@LQFP32
[(SA663)]
M37544G2A(GP)@LQFP32(ISP) [ISP-HEADER01]
M37544G2A(SP)@SDIP32 [(SA653)]
M37544G2A(SP)@SDIP32(ISP) [ISP-HEADER01]
M37545G4(GP)@LQFP32 [(SA663)] M37545G6(GP)@LQFP32
[(SA663)]
M37545G8(GP)@LQFP32 [(SA663)] M37546G2(FP)@SSOP36
[(SA645)]
M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]
M37546G2(GP)@LQFP32 [(SA663)]
M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]

M37546G2(SP)@SDIP32 [(SA653)]
M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]
M37546G4(FP)@SSOP36 [(SA645)]
M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]
M37546G4(GP)@LQFP32 [(SA663)]
M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]
M37546G4(SP)@SDIP32 [(SA653)]
M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]
M37547G2(FP)@SSOP36 [(SA645)]
M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]
M37547G4(FP)@SSOP36 [(SA645)]
M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20
[(SA026)]
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SDIP24
[(SA653)]
M37549G2FP@SDIP24 [(SA653)] M37549G3FP@SDIP24
[(SA653)]
R5F21102DFP@TQFP32 [(SA663+B005)]
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21102FP@TQFP32 [(SA663+B005)]
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]
R5F21103DFP@TQFP32 [(SA663+B005)]
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21103FP@TQFP32 [(SA663+B005)]
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]
R5F21104DFP@TQFP32 [(SA663+B005)]
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21104FP@TQFP32 [(SA663+B005)]
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]
R5F21112DFP@TQFP32 [(SA663+B005)]
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21112FP@TQFP32 [(SA663+B005)]
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]
R5F21113DFP@TQFP32 [(SA663+B005)]
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21113FP@TQFP32 [(SA663+B005)]
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]
R5F21114DFP@TQFP32 [(SA663+B005)]
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21114FP@TQFP32 [(SA663+B005)]
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]
R5F21122DFP@TQFP32 [(SA663+B005)]

R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21122FP@TQFP32 [(SA663+B005)]
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]
R5F21123DFP@TQFP32 [(SA663+B005)]
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21123FP@TQFP32 [(SA663+B005)]
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]
R5F21124DFP@TQFP32 [(SA663+B005)]
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21124FP@TQFP32 [(SA663+B005)]
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]
R5F21132DFP@TQFP32 [(SA663+B005)]
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21132FP@TQFP32 [(SA663+B005)]
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]
R5F21133DFP@TQFP32 [(SA663+B005)]
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21133FP@TQFP32 [(SA663+B005)]
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]
R5F21134DFP@TQFP32 [(SA663+B005)]
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]
R5F21134FP@TQFP32 [(SA663+B005)]
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]
R5F21181DD@SDIP20 [(SA725-B005)]
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(single wire) [(SA725-B005)]
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]
R5F21181DSP@TSSOP20 [(SA026-B001)]
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21181SP@TSSOP20 [(SA026-B001)]
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182DD@SDIP20 [(SA725-B005)]
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(single wire) [(SA725-B005)]
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]

R5F21182DSP@TSSOP20 [(SA026-B001)]
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21182NP@QFN28 [(SA697-B006)]
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]
R5F21182NP@QFN28(single wire) [(SA697-B006)]
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21182NP@QFN28(UART mode) [(SA697+B006)]
R5F21182SP@TSSOP20 [(SA026-B001)]
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183DD@SDIP20 [(SA725-B005)]
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(single wire) [(SA725-B005)]
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]
R5F21183DSP@TSSOP20 [(SA026-B001)]
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21183NP@QFN28 [(SA697-B006)]
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]
R5F21183NP@QFN28(single wire) [(SA697-B006)]
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21183NP@QFN28(UART mode) [(SA697+B006)]
R5F21183SP@TSSOP20 [(SA026-B001)]
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184DD@SDIP20 [(SA725-B005)]
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(single wire) [(SA725-B005)]
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]
R5F21184DSP@TSSOP20 [(SA026-B001)]
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]

R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21184NP@QFN28 [(SA697-B006)]
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]
R5F21184NP@QFN28(single wire) [(SA697-B006)]
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21184NP@QFN28(UART mode) [(SA697+B006)]
R5F21184SP@TSSOP20 [(SA026-B001)]
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191DD@SDIP20 [(SA725-B005)]
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(single wire) [(SA725+B005)]
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]
R5F21191DSP@TSSOP20 [(SA026-B001)]
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21191SP@TSSOP20 [(SA026-B001)]
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192DD@SDIP20 [(SA725-B005)]
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(single wire) [(SA725+B005)]
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]
R5F21192DSP@TSSOP20 [(SA026-B001)]
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21192NP@QFN28 [(SA697-B006)]
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]
R5F21192NP@QFN28(single wire) [(SA697+B006)]
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21192NP@QFN28(UART mode) [(SA697+B006)]
R5F21192SP@TSSOP20 [(SA026-B001)]

R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193DD@SDIP20 [(SA725-B005)]
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(single wire) [(SA725+B005)]
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]
R5F21193DSP@TSSOP20 [(SA026-B001)]
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21193NP@QFN28 [(SA697-B006)]
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]
R5F21193NP@QFN28(single wire) [(SA697+B006)]
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21193NP@QFN28(UART mode) [(SA697+B006)]
R5F21193SP@TSSOP20 [(SA026-B001)]
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194DD@SDIP20 [(SA725-B005)]
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(single wire) [(SA725+B005)]
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]
R5F21194DSP@TSSOP20 [(SA026-B001)]
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F21194NP@QFN28 [(SA697-B006)]
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]
R5F21194NP@QFN28(single wire) [(SA697+B006)]
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]
R5F21194NP@QFN28(UART mode) [(SA697+B006)]
R5F21194SP@TSSOP20 [(SA026-B001)]
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1DD@SDIP20 [(SA725-B005)]
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A1DSP@TSSOP20 [(SA026-B001)]
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A1SP@TSSOP20 [(SA026-B001)]
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2DD@SDIP20 [(SA725-B005)]
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A2DSP@TSSOP20 [(SA026-B001)]
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A2NP@QFN28 [(SA697-B006)]
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(single wire) [(SA697-B006)]
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]
R5F211A2SP@TSSOP20 [(SA026-B001)]
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3DD@SDIP20 [(SA725-B005)]
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A3DSP@TSSOP20 [(SA026-B001)]
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]

R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A3NP@QFN28 [(SA697-B006)]
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(single wire) [(SA697-B006)]
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]
R5F211A3SP@TSSOP20 [(SA026-B001)]
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4DD@SDIP20 [(SA725-B005)]
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211A4DSP@TSSOP20 [(SA026-B001)]
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211A4NP@QFN28 [(SA697-B006)]
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(single wire) [(SA697-B006)]
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]
R5F211A4SP@TSSOP20 [(SA026-B001)]
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B1DD@SDIP20 [(SA725-B005)]
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B1DSP@TSSOP20 [(SA026-B001)]
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]

R5F211B1SP@TSSOP20 [(SA026-B001)]
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2DD@SDIP20 [(SA725-B005)]
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B2DSP@TSSOP20 [(SA026-B001)]
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B2NP@QFN28 [(SA697-B006)]
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(single wire) [(SA697+B006)]
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]
R5F211B2SP@TSSOP20 [(SA026-B001)]
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3DD@SDIP20 [(SA725-B005)]
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B3DSP@TSSOP20 [(SA026-B001)]
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B3NP@QFN28 [(SA697-B006)]
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(single wire) [(SA697+B006)]
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]
R5F211B3SP@TSSOP20 [(SA026-B001)]
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]

R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4DD@SDIP20 [(SA725-B005)]
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]
R5F211B4DSP@TSSOP20 [(SA026-B001)]
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]
R5F211B4NP@QFN28 [(SA697-B006)]
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(single wire) [(SA697+B006)]
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]
R5F211B4SP@TSSOP20 [(SA026-B001)]
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]
R5F21206JFP@TQFP48 [(SA248-B005)]
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]
R5F21206KFP@TQFP48 [(SA248-B005)]
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]
R5F21207JFP@TQFP48 [(SA248-B005)]
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]
R5F21207KFP@TQFP48 [(SA248-B005)]
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]
R5F21208JFP@TQFP48 [(SA248-B005)]
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]
R5F21208KFP@TQFP48 [(SA248-B005)]
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]
R5F2120AJFP@TQFP48 [(SA248-B005)]
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]

R5F2120AKFP@TQFP48 [(SA248-B005)]
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CJFP@TQFP48 [(SA248-B005)]
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2120CKFP@TQFP48 [(SA248-B005)]
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21216JFP@TQFP48 [(SA248-B005)]
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]
R5F21216KFP@TQFP48 [(SA248-B005)]
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21216KFP@TQFP48(single wire) [(SA248-B005)]
R5F21217JFP@TQFP48 [(SA248-B005)]
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]
R5F21217KFP@TQFP48 [(SA248-B005)]
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]
R5F21218JFP@TQFP48 [(SA248-B005)]
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218JFP@TQFP48(single wire) [(SA248-B005)]
R5F21218KFP@TQFP48 [(SA248-B005)]
R5F21218KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21218KFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AJFP@TQFP48 [(SA248-B005)]
R5F2121AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121AKFP@TQFP48 [(SA248-B005)]
R5F2121AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CJFP@TQFP48 [(SA248-B005)]
R5F2121CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2121CKFP@TQFP48 [(SA248-B005)]
R5F2121CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2121CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21226JFP@TQFP48 [(SA248-B005)]
R5F21226JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226JFP@TQFP48(single wire) [(SA248-B005)]
R5F21226KFP@TQFP48 [(SA248-B005)]

R5F21226KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21226KFP@TQFP48(single wire) [(SA248-B005)]
R5F21227JFP@TQFP48 [(SA248-B005)]
R5F21227JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227JFP@TQFP48(single wire) [(SA248-B005)]
R5F21227KFP@TQFP48 [(SA248-B005)]
R5F21227KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21227KFP@TQFP48(single wire) [(SA248-B005)]
R5F21228JFP@TQFP48 [(SA248-B005)]
R5F21228JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228JFP@TQFP48(single wire) [(SA248-B005)]
R5F21228KFP@TQFP48 [(SA248-B005)]
R5F21228KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21228KFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AJFP@TQFP48 [(SA248-B005)]
R5F2122AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122AKFP@TQFP48 [(SA248-B005)]
R5F2122AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CJFP@TQFP48 [(SA248-B005)]
R5F2122CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2122CKFP@TQFP48 [(SA248-B005)]
R5F2122CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2122CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21236JFP@TQFP48 [(SA248-B005)]
R5F21236JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236JFP@TQFP48(single wire) [(SA248-B005)]
R5F21236KFP@TQFP48 [(SA248-B005)]
R5F21236KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21236KFP@TQFP48(single wire) [(SA248-B005)]
R5F21237JFP@TQFP48 [(SA248-B005)]
R5F21237JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237JFP@TQFP48(single wire) [(SA248-B005)]
R5F21237KFP@TQFP48 [(SA248-B005)]
R5F21237KFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21237KFP@TQFP48(single wire) [(SA248-B005)]
R5F21238JFP@TQFP48 [(SA248-B005)]
R5F21238JFP@TQFP48(single ISP) [ISP-HEADER01]
R5F21238JFP@TQFP48(single wire) [(SA248-B005)]
R5F21238KFP@TQFP48 [(SA248-B005)]
R5F21238KFP@TQFP48(single ISP) [ISP-HEADER01]

R5F21238KFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AJFP@TQFP48 [(SA248-B005)]
R5F2123AJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123AKFP@TQFP48 [(SA248-B005)]
R5F2123AKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123AKFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CJFP@TQFP48 [(SA248-B005)]
R5F2123CJFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CJFP@TQFP48(single wire) [(SA248-B005)]
R5F2123CKFP@TQFP48 [(SA248-B005)]
R5F2123CKFP@TQFP48(single ISP) [ISP-HEADER01]
R5F2123CKFP@TQFP48(single wire) [(SA248-B005)]
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]

R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]
R5F21262DFP@QFP32 [(SA663)]
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(single wire) [(SA663)]
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262DFP@QFP32(UART mode) [(SA663)]
R5F21262JFP@QFP32 [(SA663)]
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(single wire) [(SA663)]
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262JFP@QFP32(UART mode) [(SA663)]
R5F21262KFP@QFP32 [(SA663)]
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(single wire) [(SA663)]
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262KFP@QFP32(UART mode) [(SA663)]
R5F21262NFP@QFP32 [(SA663)]
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(single wire) [(SA663)]
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262NFP@QFP32(UART mode) [(SA663)]
R5F21262SDFP@QFP32 [(SA663)]
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(single wire) [(SA663)]
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SDFP@QFP32(UART mode) [(SA663)]
R5F21262SJFP@QFP32 [(SA663)]
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(single wire) [(SA663)]
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SJFP@QFP32(UART mode) [(SA663)]
R5F21262SKFP@QFP32 [(SA663)]
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(single wire) [(SA663)]
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SKFP@QFP32(UART mode) [(SA663)]
R5F21262SNFP@QFP32 [(SA663)]
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(single wire) [(SA663)]
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21262SNFP@QFP32(UART mode) [(SA663)]
R5F21264DFP@QFP32 [(SA663)]

R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(single wire) [(SA663)]
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264DFP@QFP32(UART mode) [(SA663)]
R5F21264JFP@QFP32 [(SA663)]
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(single wire) [(SA663)]
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264JFP@QFP32(UART mode) [(SA663)]
R5F21264KFP@QFP32 [(SA663)]
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(single wire) [(SA663)]
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264KFP@QFP32(UART mode) [(SA663)]
R5F21264NFP@QFP32 [(SA663)]
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(single wire) [(SA663)]
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264NFP@QFP32(UART mode) [(SA663)]
R5F21264SDFP@QFP32 [(SA663)]
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(single wire) [(SA663)]
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SDFP@QFP32(UART mode) [(SA663)]
R5F21264SJFP@QFP32 [(SA663)]
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(single wire) [(SA663)]
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SJFP@QFP32(UART mode) [(SA663)]
R5F21264SKFP@QFP32 [(SA663)]
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(single wire) [(SA663)]
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SKFP@QFP32(UART mode) [(SA663)]
R5F21264SNFP@QFP32 [(SA663)]
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(single wire) [(SA663)]
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21264SNFP@QFP32(UART mode) [(SA663)]
R5F21265DFP@QFP32 [(SA663)]
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265DFP@QFP32(single wire) [(SA663)]
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21265DFP@QFP32(UART mode) [(SA663)]
R5F21265JFP@QFP32 [(SA663)]
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(single wire) [(SA663)]
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265JFP@QFP32(UART mode) [(SA663)]
R5F21265KFP@QFP32 [(SA663)]
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(single wire) [(SA663)]
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265KFP@QFP32(UART mode) [(SA663)]
R5F21265NFP@QFP32 [(SA663)]
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(single wire) [(SA663)]
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265NFP@QFP32(UART mode) [(SA663)]
R5F21265SDFP@QFP32 [(SA663)]
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(single wire) [(SA663)]
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SDFP@QFP32(UART mode) [(SA663)]
R5F21265SJFP@QFP32 [(SA663)]
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(single wire) [(SA663)]
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SJFP@QFP32(UART mode) [(SA663)]
R5F21265SKFP@QFP32 [(SA663)]
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(single wire) [(SA663)]
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SKFP@QFP32(UART mode) [(SA663)]
R5F21265SNFP@QFP32 [(SA663)]
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(single wire) [(SA663)]
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21265SNFP@QFP32(UART mode) [(SA663)]
R5F21266DFP@QFP32 [(SA663)]
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(single wire) [(SA663)]
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266DFP@QFP32(UART mode) [(SA663)]
R5F21266JFP@QFP32 [(SA663)]
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]

R5F21266JFP@QFP32(single wire) [(SA663)]
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266JFP@QFP32(UART mode) [(SA663)]
R5F21266KFP@QFP32 [(SA663)]
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(single wire) [(SA663)]
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266KFP@QFP32(UART mode) [(SA663)]
R5F21266NFP@QFP32 [(SA663)]
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(single wire) [(SA663)]
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266NFP@QFP32(UART mode) [(SA663)]
R5F21266SDFP@QFP32 [(SA663)]
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(single wire) [(SA663)]
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SDFP@QFP32(UART mode) [(SA663)]
R5F21266SJFP@QFP32 [(SA663)]
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(single wire) [(SA663)]
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SJFP@QFP32(UART mode) [(SA663)]
R5F21266SKFP@QFP32 [(SA663)]
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(single wire) [(SA663)]
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SKFP@QFP32(UART mode) [(SA663)]
R5F21266SNFP@QFP32 [(SA663)]
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(single wire) [(SA663)]
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21266SNFP@QFP32(UART mode) [(SA663)]
R5F21272DFP@QFP32 [(SA663)]
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(single wire) [(SA663)]
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272DFP@QFP32(UART mode) [(SA663)]
R5F21272JFP@QFP32 [(SA663)]
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(single wire) [(SA663)]
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272JFP@QFP32(UART mode) [(SA663)]

R5F21272KFP@QFP32 [(SA663)]
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(single wire) [(SA663)]
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272KFP@QFP32(UART mode) [(SA663)]
R5F21272NFP@QFP32 [(SA663)]
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(single wire) [(SA663)]
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272NFP@QFP32(UART mode) [(SA663)]
R5F21272SDFP@QFP32 [(SA663)]
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(single wire) [(SA663)]
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SDFP@QFP32(UART mode) [(SA663)]
R5F21272SJFP@QFP32 [(SA663)]
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(single wire) [(SA663)]
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SJFP@QFP32(UART mode) [(SA663)]
R5F21272SKFP@QFP32 [(SA663)]
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(single wire) [(SA663)]
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SKFP@QFP32(UART mode) [(SA663)]
R5F21272SNFP@QFP32 [(SA663)]
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(single wire) [(SA663)]
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21272SNFP@QFP32(UART mode) [(SA663)]
R5F21274DFP@QFP32 [(SA663)]
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(single wire) [(SA663)]
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274DFP@QFP32(UART mode) [(SA663)]
R5F21274JFP@QFP32 [(SA663)]
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(single wire) [(SA663)]
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274JFP@QFP32(UART mode) [(SA663)]
R5F21274KFP@QFP32 [(SA663)]
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(single wire) [(SA663)]

R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274KFP@QFP32(UART mode) [(SA663)]
R5F21274NFP@QFP32 [(SA663)]
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(single wire) [(SA663)]
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274NFP@QFP32(UART mode) [(SA663)]
R5F21274SDFP@QFP32 [(SA663)]
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(single wire) [(SA663)]
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SDFP@QFP32(UART mode) [(SA663)]
R5F21274SJFP@QFP32 [(SA663)]
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(single wire) [(SA663)]
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SJFP@QFP32(UART mode) [(SA663)]
R5F21274SKFP@QFP32 [(SA663)]
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(single wire) [(SA663)]
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SKFP@QFP32(UART mode) [(SA663)]
R5F21274SNFP@QFP32 [(SA663)]
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(single wire) [(SA663)]
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21274SNFP@QFP32(UART mode) [(SA663)]
R5F21275DFP@QFP32 [(SA663)]
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(single wire) [(SA663)]
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275DFP@QFP32(UART mode) [(SA663)]
R5F21275JFP@QFP32 [(SA663)]
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(single wire) [(SA663)]
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275JFP@QFP32(UART mode) [(SA663)]
R5F21275KFP@QFP32 [(SA663)]
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(single wire) [(SA663)]
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275KFP@QFP32(UART mode) [(SA663)]
R5F21275NFP@QFP32 [(SA663)]

R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(single wire) [(SA663)]
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275NFP@QFP32(UART mode) [(SA663)]
R5F21275SDFP@QFP32 [(SA663)]
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(single wire) [(SA663)]
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SDFP@QFP32(UART mode) [(SA663)]
R5F21275SJFP@QFP32 [(SA663)]
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(single wire) [(SA663)]
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SJFP@QFP32(UART mode) [(SA663)]
R5F21275SKFP@QFP32 [(SA663)]
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(single wire) [(SA663)]
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SKFP@QFP32(UART mode) [(SA663)]
R5F21275SNFP@QFP32 [(SA663)]
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(single wire) [(SA663)]
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21275SNFP@QFP32(UART mode) [(SA663)]
R5F21276DFP@QFP32 [(SA663)]
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(single wire) [(SA663)]
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276DFP@QFP32(UART mode) [(SA663)]
R5F21276JFP@QFP32 [(SA663)]
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(single wire) [(SA663)]
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276JFP@QFP32(UART mode) [(SA663)]
R5F21276KFP@QFP32 [(SA663)]
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(single wire) [(SA663)]
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276KFP@QFP32(UART mode) [(SA663)]
R5F21276NFP@QFP32 [(SA663)]
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276NFP@QFP32(single wire) [(SA663)]
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21276NFP@QFP32(UART mode) [(SA663)]
R5F21276SDFP@QFP32 [(SA663)]
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(single wire) [(SA663)]
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SDFP@QFP32(UART mode) [(SA663)]
R5F21276SJFP@QFP32 [(SA663)]
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(single wire) [(SA663)]
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SJFP@QFP32(UART mode) [(SA663)]
R5F21276SKFP@QFP32 [(SA663)]
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(single wire) [(SA663)]
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SKFP@QFP32(UART mode) [(SA663)]
R5F21276SNFP@QFP32 [(SA663)]
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(single wire) [(SA663)]
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]
R5F21276SNFP@QFP32(UART mode) [(SA663)]
R5F21282DSP@SOIC20 [(SA026)]
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(single wire) [(SA026)]
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282DSP@SOIC20(UART mode) [(SA026)]
R5F21282JSP@SOIC20 [(SA026)]
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(single wire) [(SA026)]
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282JSP@SOIC20(UART mode) [(SA026)]
R5F21282KSP@SOIC20 [(SA026)]
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(single wire) [(SA026)]
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282KSP@SOIC20(UART mode) [(SA026)]
R5F21282NSP@SOIC20 [(SA026)]
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(single wire) [(SA026)]
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282NSP@SOIC20(UART mode) [(SA026)]
R5F21282SDSP@SOIC20 [(SA026)]
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]

R5F21282SDSP@SOIC20(single wire) [(SA026)]
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SDSP@SOIC20(UART mode) [(SA026)]
R5F21282SJSP@SOIC20 [(SA026)]
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(single wire) [(SA026)]
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SJSP@SOIC20(UART mode) [(SA026)]
R5F21282SKSP@SOIC20 [(SA026)]
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(single wire) [(SA026)]
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SKSP@SOIC20(UART mode) [(SA026)]
R5F21282SNSP@SOIC20 [(SA026)]
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(single wire) [(SA026)]
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21282SNSP@SOIC20(UART mode) [(SA026)]
R5F21284DSP@SOIC20 [(SA026)]
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(single wire) [(SA026)]
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284DSP@SOIC20(UART mode) [(SA026)]
R5F21284JSP@SOIC20 [(SA026)]
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(single wire) [(SA026)]
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284JSP@SOIC20(UART mode) [(SA026)]
R5F21284KSP@SOIC20 [(SA026)]
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(single wire) [(SA026)]
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284KSP@SOIC20(UART mode) [(SA026)]
R5F21284NSP@SOIC20 [(SA026)]
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(single wire) [(SA026)]
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284NSP@SOIC20(UART mode) [(SA026)]
R5F21284SDSP@SOIC20 [(SA026)]
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(single wire) [(SA026)]
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SDSP@SOIC20(UART mode) [(SA026)]

R5F21284SJSP@SOIC20 [(SA026)]
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(single wire) [(SA026)]
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SJSP@SOIC20(UART mode) [(SA026)]
R5F21284SKSP@SOIC20 [(SA026)]
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(single wire) [(SA026)]
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SKSP@SOIC20(UART mode) [(SA026)]
R5F21284SNSP@SOIC20 [(SA026)]
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(single wire) [(SA026)]
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21284SNSP@SOIC20(UART mode) [(SA026)]
R5F21292DSP@SOIC20 [(SA026)]
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(single wire) [(SA026)]
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292DSP@SOIC20(UART mode) [(SA026)]
R5F21292JSP@SOIC20 [(SA026)]
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(single wire) [(SA026)]
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292JSP@SOIC20(UART mode) [(SA026)]
R5F21292KSP@SOIC20 [(SA026)]
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(single wire) [(SA026)]
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292KSP@SOIC20(UART mode) [(SA026)]
R5F21292NSP@SOIC20 [(SA026)]
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(single wire) [(SA026)]
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292NSP@SOIC20(UART mode) [(SA026)]
R5F21292SDSP@SOIC20 [(SA026)]
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(single wire) [(SA026)]
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SDSP@SOIC20(UART mode) [(SA026)]
R5F21292SJSP@SOIC20 [(SA026)]
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(single wire) [(SA026)]

R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SJSP@SOIC20(UART mode) [(SA026)]
R5F21292SKSP@SOIC20 [(SA026)]
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(single wire) [(SA026)]
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SKSP@SOIC20(UART mode) [(SA026)]
R5F21292SNSP@SOIC20 [(SA026)]
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(single wire) [(SA026)]
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21292SNSP@SOIC20(UART mode) [(SA026)]
R5F21294DSP@SOIC20 [(SA026)]
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(single wire) [(SA026)]
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294DSP@SOIC20(UART mode) [(SA026)]
R5F21294JSP@SOIC20 [(SA026)]
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(single wire) [(SA026)]
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294JSP@SOIC20(UART mode) [(SA026)]
R5F21294KSP@SOIC20 [(SA026)]
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(single wire) [(SA026)]
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294KSP@SOIC20(UART mode) [(SA026)]
R5F21294NSP@SOIC20 [(SA026)]
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(single wire) [(SA026)]
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294NSP@SOIC20(UART mode) [(SA026)]
R5F21294SDSP@SOIC20 [(SA026)]
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(single wire) [(SA026)]
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SDSP@SOIC20(UART mode) [(SA026)]
R5F21294SJSP@SOIC20 [(SA026)]
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(single wire) [(SA026)]
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SJSP@SOIC20(UART mode) [(SA026)]
R5F21294SKSP@SOIC20 [(SA026)]

R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(single wire) [(SA026)]
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SKSP@SOIC20(UART mode) [(SA026)]
R5F21294SNSP@SOIC20 [(SA026)]
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(single wire) [(SA026)]
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]
R5F21294SNSP@SOIC20(UART mode) [(SA026)]
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]

R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]

R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]
R5F212G4SDFP@QFP32 [(SA663)]
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SDFP@QFP32(single wire) [(SA663)]
R5F212G4SNFP@QFP32 [(SA663)]
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G4SNFP@QFP32(single wire) [(SA663)]
R5F212G5SDFP@QFP32 [(SA663)]
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SDFP@QFP32(single wire) [(SA663)]
R5F212G5SNFP@QFP32 [(SA663)]
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G5SNFP@QFP32(single wire) [(SA663)]
R5F212G6SDFP@QFP32 [(SA663)]
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SDFP@QFP32(single wire) [(SA663)]
R5F212G6SNFP@QFP32 [(SA663)]
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212G6SNFP@QFP32(single wire) [(SA663)]
R5F212H1SDSP@TSSOP20 [(SA026-B001)]
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H1SNSP@TSSOP20 [(SA026-B001)]
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H1SNSP@TSSOP20(single wire [(SA026-B001)])

R5F212H2SDSP@TSSOP20 [(SA725-B005)]
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212H2SNSP@TSSOP20 [(SA725-B005)]
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212H2SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SDSP@TSSOP20 [(SA026-B001)]
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J0SNSP@TSSOP20 [(SA026-B001)]
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J0SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SDSP@TSSOP20 [(SA026-B001)]
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SDSP@TSSOP20(single wire [(SA026-B001)])
R5F212J1SNSP@TSSOP20 [(SA026-B001)]
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]
R5F212J1SNSP@TSSOP20(single wire [(SA026-B001)])
R5F212K2SDFP@QFP32 [(SA663-B005)]
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SDFP@QFP32(single wire [(SA663-B005)])
R5F212K2SNFP@QFP32 [(SA663-B005)]
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K2SNFP@QFP32(single wire [(SA663-B005)])
R5F212K4SDFP@QFP32 [(SA663-B005)]
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SDFP@QFP32(single wire [(SA663-B005)])
R5F212K4SNFP@QFP32 [(SA663-B005)]
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212K4SNFP@QFP32(single wire [(SA663-B005)])
R5F212L2SDFP@QFP32 [(SA663-B005)]
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SDFP@QFP32(single wire [(SA663+B005)])
R5F212L2SNFP@QFP32 [(SA663-B005)]
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L2SNFP@QFP32(single wire [(SA663+B005)])
R5F212L4SDFP@QFP32 [(SA663-B005)]
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SDFP@QFP32(single wire [(SA663+B005)])
R5F212L4SNFP@QFP32 [(SA663-B005)]
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]
R5F212L4SNFP@QFP32(single wire [(SA663+B005)])

RICOH

E (E) PROM / FRAM / NVRAM

RD27C256
RD27C32
RD27C64

ROCKWELL

E (E) PROM / FRAM / NVRAM

R2764
R2764C
R2764P
R27C64
R2816
R5213
R52B13
R52B33

ROHM

E (E) PROM / FRAM / NVRAM

BR24C01@SOP8 [(SA602A)]	BR24C01@TSSOP8
[(SA026)]	
BR24C01@TSSOP8 (3 * 3mm) [(SA666)]	
BR24C01A	
BR24C01A (F) [(SA602A)]	BR24C01A (FJ)
[(SA602A)]	
BR24C01A (FV) [(SA026)]	
BR24C02	
BR24C02 (F) [(SA602A)]	BR24C02 (FJ)
[(SA602A)]	
BR24C02 (FV) [(SA026)]	BR24C02@SOP8
[(SA602A)]	
BR24C02@TSSOP8 [(SA026)]	BR24C02@TSSOP8 (3 * 3mm)
[(SA666)]	

BR24C04 [(SA602A)]	BR24C04 (F)
BR24C04 (FJ) [(SA602A)] [(SA026)]	BR24C04 (FV)
BR24C04@SOP8 [(SA602A)] [(SA026)]	BR24C04@TSSOP8
BR24C04@TSSOP8 (3*3mm) [(SA666)]	
BR24C08 BR24C08 (F) [(SA602A)] [(SA602A)]	BR24C08 (FJ)
BR24C08 (FV) [(SA026)] [(SA602A)]	BR24C08@SOP8
BR24C08@TSSOP8 [(SA026)] [(SA666)]	BR24C08@TSSOP8 (3*3mm)
BR24C16 [(SA602A)]	BR24C16 (F)
BR24C16 (FJ) [(SA602A)] [(SA026)]	BR24C16 (FV)
BR24C21 [(SA602A)]	BR24C21 (F)
BR24C21 (FJ) [(SA602A)] [(SA026)]	BR24C21 (FV)
BR24C32 [(SA602A)]	BR24C32 (F)
BR24C64 [(SA602A)]	BR24C64 (F)
BR24E16 [(SA602A)]	BR24E16 (F)
BR24E16 (FJ) [(SA602A)] [(SA026)]	BR24E16 (FV)
BR24L01A [(SA602A)]	BR24L01A (F)
BR24L01A (FJ) [(SA602A)] [(SA026)]	BR24L01A (FV)
BR24L01A (FVM) [(SA666)]	
BR24L02 BR24L02 (F) [(SA602A)] [(SA602A)]	BR24L02 (FJ)
BR24L02 (FV) [(SA026)] [(SA666)]	BR24L02 (FVM)
BR24L04 [(SA602A)]	BR24L04 (F)
BR24L04 (FJ) [(SA602A)]	BR24L04 (FV)

[(SA026)]	
BR24L04 (FVM) [(SA666)]	
BR24L08	
BR24L08 (F) [(SA602A)]	BR24L08 (FJ)
[(SA602A)]	
BR24L08 (FV) [(SA026)]	BR24L08 (FVM)
[(SA666)]	
BR24L16	
[(SA602A)]	BR24L16 (F)
BR24L16 (FJ) [(SA602A)]	BR24L16 (FV)
[(SA026)]	
BR24L16 (FVM) [(SA666)]	
BR24L32	
BR24L32 (F) [(SA602A)]	BR24L32 (FJ)
[(SA602A)]	
BR24L32 (FV) [(SA026)]	
BR24L64	
BR24L64 (F) [(SA602A)]	BR24L64 (FJ)
[(SA602A)]	
BR24L64 (FV) [(SA026)]	BR25010@SOIC8
[(SA602A)]	
BR25010@TSSOP8 [(SA026)]	BR25020@SOIC8
[(SA602A)]	
BR25020@TSSOP8 [(SA026)]	BR25040@SOIC8
[(SA602A)]	
BR25040@TSSOP8 [(SA026)]	BR25080@SOIC8
[(SA602A)]	
BR25080@TSSOP8 [(SA026)]	BR25160@SOIC8
[(SA602A)]	
BR25160@TSSOP8 [(SA026)]	BR25320@SOIC8
[(SA602A)]	
BR25L010	BR25L010 (F)
[(SA602A)]	
BR25L010 (FJ) [(SA602A)]	BR25L010 (FV)
[(SA026)]	
BR25L010 (FVM) [(SA666)]	
BR25L020	
BR25L020 (F) [(SA602A)]	BR25L020 (FJ)
[(SA602A)]	
BR25L020 (FV) [(SA026)]	BR25L020 (FVM)
[(SA666)]	
BR25L040	BR25L040 (F)
[(SA602A)]	

BR25L040(FJ) [(SA602A)]	BR25L040(FV)
[(SA026)]	
BR25L040(FVM) [(SA666)]	
BR25L080	
BR25L080(F) [(SA602A)]	BR25L080(FJ)
[(SA602A)]	
BR25L080(FV) [(SA026)]	
BR25L160	
BR25L160(F) [(SA602A)]	BR25L160(FJ)
[(SA602A)]	
BR25L160(FV) [(SA026)]	
BR25L320	
BR25L320(F) [(SA602A)]	BR25L320(FJ)
[(SA602A)]	
BR25L320(FV) [(SA026)]	
BR25L640	
BR25L640(F) [(SA602A)]	BR25L640(FJ)
[(SA602A)]	
BR25L640(FV) [(SA026)]	
BR34L02	
BR34L02(F) [(SA602A)]	BR34L02(FJ)
[(SA602A)]	
BR34L02(FV) [(SA026)]	BR34L02(FVM)
[(SA666)]	
BR9010	BR9010(F)
[(SA602A)]	
BR9010(FV) [(SA026)]	BR9010(RFV)
[(SA026)]	
BR9010(RFVM) [(SA666)]	
BR9016	
BR9016(F) [(SA602A)]	BR9016(RFV)
[(SA026)]	
BR9016A(F) [(SA602A)]	BR9016A(RFV)
[(SA026)]	
BR9016A(RFVM) [(SA666)]	
BR9020	
BR9020(F) [(SA602A)]	BR9020(FV)
[(SA026)]	
BR9020(RFV) [(SA026)]	BR9020(RFVM)
[(SA666)]	
BR9040	BR9040(F)
[(SA602A)]	
BR9040(FV) [(SA026)]	BR9040(RFV)

[(SA026)]	
BR9040(RFVM) [(SA666)]	
BR9080	
BR9080(F) [(SA602A)]	BR9080(RFV)
[(SA026)]	
BR9080A	BR9080A(F)
[(SA602A)]	
BR9080A(FV) [(SA026)]	BR9080A(RFV)
[(SA026)]	
BR9080A(RFVM) [(SA666)]	BR93A46(F)
[(SA602A)]	
BR93A46(FJ) [(SA602A)]	BR93A46(RF)
[(SA602A)]	
BR93A46(RFJ) [(SA602A)]	BR93A56(F)
[(SA602A)]	
BR93A56(FJ) [(SA602A)]	BR93A56(RF)
[(SA602A)]	
BR93A56(RFJ) [(SA602A)]	BR93A66(F)
[(SA602A)]	
BR93A66(FJ) [(SA602A)]	BR93A66(RF)
[(SA602A)]	
BR93A66(RFJ) [(SA602A)]	BR93A86(F)
[(SA602A)]	
BR93A86(FJ) [(SA602A)]	BR93A86(RF)
[(SA602A)]	
BR93A86(RFJ) [(SA602A)]	
BR93C46	
BR93C46(F) [(SA602A)]	BR93C46(FJ)
[(SA602A)]	
BR93C46(FV) [(SA026)]	BR93C46(RF)
[(SA602A)]	
BR93C46(RFJ) [(SA602A)]	
BR93C56	
BR93C56(F) [(SA602A)]	BR93C56(FJ)
[(SA602A)]	
BR93C56(FV) [(SA026)]	BR93C56(RF)
[(SA602A)]	
BR93C56(RFJ) [(SA602A)]	
BR93C66	
BR93C66(F) [(SA602A)]	BR93C66(FJ)
[(SA602A)]	
BR93C66(FV) [(SA026)]	BR93C66(RF)
[(SA602A)]	

BR93C66 (RFJ) [(SA602A)]	BR93H46 (RF)
[(SA602A)]	
BR93H46 (RFJ) [(SA602A)]	BR93H56 (RF)
[(SA602A)]	
BR93H56 (RFJ) [(SA602A)]	BR93H66 (RF)
[(SA602A)]	
BR93H66 (RFJ) [(SA602A)]	BR93H76 (RF)
[(SA602A)]	
BR93H76 (RFJ) [(SA602A)]	BR93H86 (RF)
[(SA602A)]	
BR93H86 (RFJ) [(SA602A)]	
BR93L46	
BR93L46 (F) [(SA602A)]	BR93L46 (FJ)
[(SA602A)]	
BR93L46 (FV) [(SA026)]	BR93L46 (RF)
[(SA602A)]	
BR93L46 (RFJ) [(SA602A)]	
BR93L56	
BR93L56 (F) [(SA602A)]	BR93L56 (FJ)
[(SA602A)]	
BR93L56 (FV) [(SA026)]	BR93L56 (RF)
[(SA602A)]	
BR93L56 (RFJ) [(SA602A)]	
BR93L66	
BR93L66 (F) [(SA602A)]	BR93L66 (FJ)
[(SA602A)]	
BR93L66 (FV) [(SA026)]	BR93L66 (RF)
[(SA602A)]	
BR93L66 (RFJ) [(SA602A)]	BR93L76 (F)
[(SA602A)]	
BR93L76 (FJ) [(SA602A)]	BR93L76 (RF)
[(SA602A)]	
BR93L76 (RFJ) [(SA602A)]	BR93L76 (RFV)
[(SA026A)]	
BR93L76 (RFVJ) [(SA666A)]	BR93L76 (RFVM)
[(SA666A)]	
BR93L76 (RFVT) [(SA026A)]	BR93L86 (F)
[(SA602A)]	
BR93L86 (FJ) [(SA602A)]	BR93L86 (RF)
[(SA602A)]	
BR93L86 (RFJ) [(SA602A)]	BR93L86 (RFV)
[(SA026A)]	
BR93L86 (RFVJ) [(SA666A)]	BR93L86 (RFVM)

[(SA666A)]	
BR93L86 (RFVT) [(SA026A)]	
BR93LC46	
BR93LC46 (F) [(SA602A)]	BR93LC46 (FJ)
[(SA602A)]	
BR93LC46 (FV) [(SA026)]	BR93LC46 (RF)
[(SA602A)]	
BR93LC46 (RFJ) [(SA602A)]	
BR93LC56	
BR93LC56 (F) [(SA602A)]	BR93LC56 (FJ)
[(SA602A)]	
BR93LC56 (FV) [(SA026)]	BR93LC56 (RF)
[(SA602A)]	
BR93LC56 (RFJ) [(SA602A)]	
BR93LC66	
BR93LC66 (F) [(SA602A)]	BR93LC66 (FJ)
[(SA602A)]	
BR93LC66 (FV) [(SA026)]	BR93LC66 (RF)
[(SA602A)]	
BR93LC66 (RFJ) [(SA602A)]	BR93LL46 (F)
[(SA602A)]	
BR93LL46 (FV) [(SA026)]	BR95010 (3*3)@TSSOP8
[(SA666)]	
BR95010@SO8 [(SA602A)]	BR95010@TSSOP8
[(SA026)]	
BR95020 (3*3)@TSSOP8 [(SA666)]	BR95020@SO8
[(SA602A)]	
BR95020@TSSOP8 [(SA026)]	BR95040 (3*3)@TSSOP8
[(SA666)]	
BR95040@SO8 [(SA602A)]	BR95040@TSSOP8
[(SA026)]	
BR95080@SO8 [(SA602A)]	BR95080@TSSOP8
[(SA026)]	
BR95160@SO8 [(SA602A)]	BR95160@TSSOP8
[(SA026)]	

SAIFUN

E (E) PROM / FRAM / NVRAM

SA24C1024	SA24C1024@SOIC8
[(SA602A)]	

SA24C512 [(SA602A)]	SA24C512@SOIC8
SA24C512@TSSOP8 [(SA026)] (H)	SA25C1024
SA25C1024(H)@CSP8 [(SA683)] [(SA602A)]	SA25C1024(H)@SOIC8
SA25C1024(L) [(SA683)]	SA25C1024(L)@CSP8
SA25C1024(L)@SOIC8 [(SA602A)] (H)	SA25C512
SA25C512(H)@CSP8 [(SA683)] [(SA602A)]	SA25C512(H)@SOIC8
SA25C512(L) [(SA683)]	SA25C512(L)@CSP8
SA25C512(L)@SOIC8 [(SA602A)]	
SA25F005	
SA25F005@MLF8 [(SA683)] [(SA602A)]	SA25F005@SOIC8
SA25F010 [(SA683)]	SA25F010@MLF8
SA25F010@SOIC8 [(SA602A)]	
SA25F020	
SA25F020@MLF8 [(SA683)] [(SA602A)]	SA25F020@SOIC8
SA25F040 [(SA683)]	SA25F040@MLF8
SA25F040@SOIC8 [(SA602A)]	
SA25F080	
SA25F080@MLF8 [(SA683)] [(SA602A)]	SA25F080@SOIC8
SA25F160 HEADER01]	SA25F160(ISP) [ISP-
SA25F160@MLF8 [(SA683)]	
SA25F160@MLF8(ISP) [ISP-HEADER01]	
SA25F160@SOIC16 [(SA602)]	
SA25F160@SOIC16(ISP) [ISP-HEADER01]	

SAMSUNG

E (E) PROM / FRAM / NVRAM

K5A3240CBM@TFBGA69 [(SA642A-B032A-Y096F001Y)]

K5A3240CTM@TFBGA69 [(SA642A-B032A-Y096F001Y)]
K5A3240YBB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3240YBC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3240YTB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3240YTC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3280YBB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3280YBC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3280YTB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3280YTC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3281CBM@TFBGA69 [(SA642A-B032A-Y096F001Y)]
K5A3281CTM@TFBGA69 [(SA642A-B032A-Y096F001Y)]
K5A3340YBB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3340YBC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3340YTB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3340YTC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3380YBB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3380YBC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3380YTB@TBGA69 [(SA642A-B032A-Y096F001)]
K5A3380YTC@TBGA69 [(SA642A-B032A-Y096F001)]
K5A6317CBM@FBGA69 [(SA642A-B032A-Y096F001Y)]
K5A6317CTM@FBGA69 [(SA642A-B032A-Y096F001Y)]
K5D1257DCMD090@FBGA107 [(SA642V-B133-T096F001Y)]
K5D5613HCMD075@FBGA137 [(SA700E-B153-M137F001Y)]
K5D5613VCMD075@FBGA137 [(SA700E-B153-M137F001Y)]
K5D5629ACCD090@FBGA107 [(SA642V-B133-T096F001Y)]
K5D5657ACAD090@FBGA107 [(SA642V-B133-T096F001Y)]
K5D5657ACBD090@FBGA107 [(SA642V-B133-T096F001Y)]
K5D5657DCAD090@FBGA107 [(SA642V-B133-T096F001Y)]
K5J6316CBM@FBGA69 [(SA642A-B032A-Y096F001)]
K5J6316CTM@FBGA69 [(SA642A-B032A-Y096F001)]
K5J6332CBM@FBGA69 [(SA642A-B032A-Y096F001Y)]
K5J6332CTM@FBGA69 [(SA642A-B032A-Y096F001Y)]
K5L2864ABM@FBGA115 [(SA664A-B189A-W115F001Y)]
K5L2864ATM@FBGA115 [(SA664A-B189A-W115F001Y)]
K5L3216CAM@FBGA69 [(SA642A-B032A-Y096F001Y)]
K5L3316CAM@FBGA69 [(SA642A-B032A-Y096F001Y)]
K5L6331CAA@FBGA56 [(SA642P-B032A-W056F001Y)]
K5L6631CAA@FBGA56 [(SA642P-B032A-W056F001Y)]
K5N3217ABM@FBGA56 [(SA733A-B212A-M056F001Y)]
K5N3217ATM@FBGA56 [(SA733A-B212A-M056F001Y)]
K8D1716UBC@FBGA48 [(SA642N-B026A-W048F001N)]
K8D1716UBC@TSOP48 [(SA247-B005)]
K8D1716UTC@FBGA48 [(SA642N-B026A-W048F001N)]

K8D1716UTC@TSOP48 [(SA247-B005)]
K8D3216UBC@FBGA48 [(SA642B-B026A-Y072F001)]
K8D3216UBC@TSOP48 [(SA247-B005)]
K8D3216UTC@FBGA48 [(SA642B-B026A-Y072F001)]
K8D3216UTC@TSOP48 [(SA247-B005)]
K8D3316UBC@FBGA48 [(SA642B-B026A-Y072F001)]
K8D3316UBC@TSOP48 [(SA247-B005)]
K8D3316UTC@FBGA48 [(SA642B-B026A-Y072F001)]
K8D3316UTC@TSOP48 [(SA247-B005)]
K8D6316UBM@FBGA48 [(SA642N-B026A-W048F001Y)]
K8D6316UBM@TSOP48 [(SA247-B005)]
K8D6316UTM@FBGA48 [(SA642N-B026A-W048F001Y)]
K8D6316UTM@TSOP48 [(SA247-B005)]
K8P3215UQB@FBGA48 [(SA642G-B026A-T048F001Y)]
K8P3215UQB@FBGA64 [(SA655F-B099A-W064F001Y)]
K8P3215UQB@TSOP48 [(SA247-B005)]
K8P6415UQB@FBGA48 [(SA642G-B026A-T048F001Y)]
K8P6415UQB@FBGA64 [(SA655F-B099A-W064F001Y)]
K8P6415UQB@TSOP48 [(SA247-B005)] K8Q2815UQB@TSOP56 [(SA628
+B102)]
K9F1208R0C@FBGA63 [(SA642LL-B280-M063F001N)]
K9F1208U0A@TSOP48 [(SA247-B005)]
K9F1208U0B@FBGA63 [(SA642LL-B026-M063F001N)]
K9F1208U0B@TSOP48 [(SA247-B005)]
K9F1208U0C@FBGA63 [(SA642LL-B026-M063F001N)]
K9F1208U0C@TSOP48 [(SA247-B005)] K9F1208U0M@TSOP48 [(SA247-
B005)]
K9F1216U0A@TSOP48 [(SA247-B005)] K9F1G08Q0M@TSOP48 [(SA247-
B005)]
K9F1G08U0A@TSOP48 [(SA247-B005)] K9F1G08U0M@TSOP48 [(SA247-
B005)]
K9F1G16D0M(PCB0)@TSOP48 [(SA247-B005)]
K9F1G16D0M(PIB0)@TSOP48 [(SA247-B005)]
K9F1G16D0M(YCB0)@TSOP48 [(SA247-B005)]
K9F1G16D0M(YIB0)@TSOP48 [(SA247-B005)]
K9F1G16Q0M(PCB0)@TSOP48 [(SA247-B005)]
K9F1G16Q0M(PIB0)@TSOP48 [(SA247-B005)]
K9F1G16Q0M(YCB0)@TSOP48 [(SA247-B005)]
K9F1G16Q0M(YIB0)@TSOP48 [(SA247-B005)]
K9F1G16U0M(PCB0)@TSOP48 [(SA247-B005)]
K9F1G16U0M(PIB0)@TSOP48 [(SA247-B005)]
K9F1G16U0M(YCB0)@TSOP48 [(SA247-B005)]
K9F1G16U0M(YIB0)@TSOP48 [(SA247-B005)]

K9F2808U0C@TSOP48 [(SA247-B005)]
K9F2G08R0A@FBGA63 [(SA642V-B280A-T096F001)]
K9F2G08U0A@TSOP48 [(SA247-B005)] K9F2G08U0M@TSOP48 [(SA247-B005)]
K9F4008W0A@TSOP44 [(SA645)] K9F4G08U0A@TSOP48 [(SA247-B005)]
K9F4G08U0M@TSOP48 [(SA247-B005)]
K9F5608R0D@FBGA63 [(SA642KK-B026-W048F001Y)]
K9F5608U0B(partition)@TSOP48 [(SA247-B005)]
K9F5608U0B@TSOP48 [(SA247-B005)]
K9F5608U0C(partition)@FBGA63 [(SA642KK-B026-W048F001Y)]
K9F5608U0C(partition)@TSOP48 [(SA247-B005)]
K9F5608U0C@FBGA63 [(SA642KK-B026-W048F001Y)]
K9F5608U0C@TSOP48 [(SA247-B005)]
K9F5608U0D(partition)@FBGA63 [(SA642KK-B026-W048F001Y)]
K9F5608U0D(partition)@TSOP48 [(SA247-B005)]
K9F5608U0D@FBGA63 [(SA642KK-B026-W048F001Y)]
K9F5608U0D@TSOP48 [(SA247-B005)] K9F6408U0C@TSOP44 [(SA645-B005)]
K9F8G08U0A@TSOP48 [(SA247-B005)] K9F8G08U0M@TSOP48 [(SA247-B005)]
K9G4G08U0A@TSOP48 [(SA247-B005)] K9G8G08U0M@TSOP48 [(SA247-B005)]
K9GAG08U0M@TSOP48 [(SA247-B005)] K9HBG08U1M@TSOP48 [(SA247-B005)]
K9K1208D0C@FBGA63 [(SA642KK-B026-W048F001Y)]
K9K1208U0A@TSOP48 [(SA247-B005)] K9K1208U0M@TSOP48 [(SA247-B005)]
K9K1216Q0C@FBGA63 [(SA664A-B114-W115F001)]
K9K1G08U0M@TSOP48 [(SA247-B005)]
K9K2G08Q0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]
K9K2G08Q0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]
K9K2G08Q0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]
K9K2G08Q0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]
K9K2G08Q0M@TSOP48 [(SA247-B005)]
K9K2G08U0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]
K9K2G08U0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]
K9K2G08U0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]
K9K2G08U0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]
K9K2G08U0M@TSOP48 [(SA247-B005)] K9K4G08Q0M@TSOP48 [(SA247-B005)]
K9K4G08U0M@TSOP48 [(SA247-B005)]
K9K4G16Q0M(PCB0)@TSOP48 [(SA247-B005)]

K9K4G16Q0M(PIB0)@TSOP48 [(SA247-B005)]
K9K4G16Q0M(YCB0)@TSOP48 [(SA247-B005)]
K9K4G16Q0M(YIB0)@TSOP48 [(SA247-B005)]
K9K4G16U0M(PCB0)@TSOP48 [(SA247-B005)]
K9K4G16U0M(PIB0)@TSOP48 [(SA247-B005)]
K9K4G16U0M(YCB0)@TSOP48 [(SA247-B005)]
K9K4G16U0M(YIB0)@TSOP48 [(SA247-B005)]
K9K8G08U0A@TSOP48 [(SA247-B005)] K9L8G08U0M@TSOP48 [(SA247-B005)]
K9LAG08U0M@TSOP48 [(SA247-B005)] K9LAG08U1M@TSOP48 [(SA247-B005)]
K9T1G08U0M@TSOP48 [(SA247-B005)]
K9W8G08U1M(PCB0)@TSOP48 [(SA247-B005)]
K9W8G08U1M(PIB0)@TSOP48 [(SA247-B005)]
KAD060300B@TBGA69 [(SA642A-B039A-Y096F001)]
KAD060300C@TBGA69 [(SA642A-B039A-Y096F001)]
KAD060700D@TBGA69 [(SA642A-B039A-Y096F001Y)]
KAD070300B@TBGA69 [(SA642A-B039A-Y096F001)]
KAD070300C@TBGA69 [(SA642A-B039A-Y096F001)]
KAD070700D@TBGA69 [(SA642A-B039A-Y096F001Y)]
KAD090300B@TBGA69 [(SA642A-B039A-Y096F001)]
KAD100300B@TBGA69 [(SA642A-B039A-Y096F001)]
KBE00500AM-D437@FBGA137 [(SA700E-B153A-M137F001Y)]
KBE00F003A-D411@FBGA107 [(SA642V-B133-T096F001Y)]
KBE00G005M-D411@FBGA137 [(SA700E-B153A-M137F001Y)]
KBE00S005M-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]
KBE00S00AM-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]
KFG1216Q2B-DEB8@FBGA63 [(SA664L-B266-W063F001Y)]
KFG1216U2A-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]
KFG1216U2A-DIB6@FBGA63 [(SA664L-B266-W063F001Y)]
KFG1216U2B-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]
KFG1216U2B-DIB6@FBGA63 [(SA664L-B266-W063F001Y)]
KFG5616D1M@FBGA63 [(SA642A-B026A-Y096N001)]
KFG5616Q1M@FBGA63 [(SA642A-B026A-Y096N001)]
KFG5616U1M@FBGA63 [(SA642A-B026A-Y096N001)]
KM2816A
KM2816AI
KM2817A
KM2817AI
KM2864A
KM2864AH
KM2865A
KM2865AH

KM28C16 [(SA015A1T)]	KM28C16@PLCC32
KM28C16I [(SA015A1T)]	KM28C16I@PLCC32
KM28C17 [(SA015A1T)]	KM28C17@PLCC32
KM28C17I [(SA015A1T)]	KM28C17I@PLCC32
KM28C256 [(SA015A1T)]	KM28C256@PLCC32
KM28C256I [(SA015A1T)]	KM28C256I@PLCC32
KM28C64 [(SA015A1T)]	KM28C64@PLCC32
KM28C64A [(SA015A1T)]	KM28C64A@PLCC32
KM28C64B [(SA015A1T)]	KM28C64B@PLCC32
KM28C64I [(SA015A1T)]	KM28C64I@PLCC32
KM28C65 [(SA015A1T)]	KM28C65@PLCC32
KM28C65A [(SA015A1T)]	KM28C65A@PLCC32
KM28C65I [(SA015A1T)]	KM28C65I@PLCC32
KM29U128T@TSOP48 [(SA247-B005)] [(SA645)]	KM29W32000AIT@TSOP44
KM29W32000AT@TSOP44 (DWB) [(SA645)]	
KM29W32000AT@TSOP44 (ZMQ) [(SA645)]	
KM93C06 (08bit) (16bit)	KM93C06
KM93C06 (G) (08bit)@SOIC8 [(SA602A)]	
KM93C06 (G) (16bit)@SOIC8 [(SA602A)]	
KM93C06 (GD) (08bit)@SOIC8 [(SA602A)]	
KM93C06 (GD) (16bit)@SOIC8 [(SA602A)]	
KM93C07 (08bit) (16bit)	KM93C07
KM93C07 (G) (08bit)@SOIC8 [(SA602A)]	
KM93C07 (G) (16bit)@SOIC8 [(SA602A)]	
KM93C07 (GD) (08bit)@SOIC8 [(SA602A)]	
KM93C07 (GD) (16bit)@SOIC8 [(SA602A)]	
KM93C46V	KM93C46V (G)@SOIC8

[(SA602A)]	
KM93C46V(GD)@SOIC8 [(SA602A)]	
KM93C47V	
KM93C47V(G)@SOIC8 [(SA602A)]	KM93C47V(GD)@SOIC8
[(SA602A)]	
KM93C56V	KM93C56V(G)@SOIC8
[(SA602A)]	
KM93C56V(GD)@SOIC8 [(SA602A)]	
KM93C57V	
KM93C57V(G)@SOIC8 [(SA602A)]	KM93C57V(GD)@SOIC8
[(SA602A)]	
KM93C66V	KM93C66V(G)@SOIC8
[(SA602A)]	
KM93C66V(GD)@SOIC8 [(SA602A)]	
KM93C67V	
KM93C67V(G)@SOIC8 [(SA602A)]	KM93C67V(GD)@SOIC8
[(SA602A)]	
KS24C010	KS24C010@SOIC8
[(SA602A)]	
KS24C010@TSSOP8 [(SA026)]	
KS24C011	
KS24C011@SOIC8 [(SA602A)]	KS24C011@TSSOP8
[(SA026)]	
KS24C020	KS24C020@SOIC8
[(SA602A)]	
KS24C020@TSSOP8 [(SA026)]	
KS24C021	
KS24C021@SOIC8 [(SA602A)]	KS24C021@TSSOP8
[(SA026)]	
KS24C040	KS24C040@SOIC8
[(SA602A)]	
KS24C040@TSSOP8 [(SA026)]	
KS24C041	
KS24C041@SOIC8 [(SA602A)]	KS24C041@TSSOP8
[(SA026)]	
KS24C080	KS24C080@SOIC8
[(SA602A)]	
KS24C080@TSSOP8 [(SA026)]	
KS24C081	
KS24C081@SOIC8 [(SA602A)]	KS24C081@TSSOP8
[(SA026)]	
S524A40X10	S524A40X10@SOP8
[(SA602A)]	

S524A40X10@TSSOP8 [(SA026)]	
S524A40X11	
S524A40X11@SOP8 [(SA602A)]	S524A40X11@TSSOP8
[(SA026)]	
S524A40X20	
[(SA602A)]	S524A40X20@SOP8
S524A40X20@TSSOP8 [(SA026)]	
S524A40X21	
S524A40X21@SOP8 [(SA602A)]	S524A40X21@TSSOP8
[(SA026)]	
S524A40X40	
[(SA602A)]	S524A40X40@SOP8
S524A40X40@TSSOP8 [(SA026)]	
S524A40X41	
S524A40X41@SOP8 [(SA602A)]	S524A40X41@TSSOP8
[(SA026)]	
S524A60X51	
[(SA602A)]	S524A60X51@SOP8
S524A60X51@TSSOP8 [(SA026)]	
S524A60X81	
S524A60X81@SOP8 [(SA602A)]	S524A60X81@TSSOP8
[(SA026)]	
S524AB0X91	
[(SA602A)]	S524AB0X91@SOP8
S524AB0X91@TSSOP8 [(SA026)]	
S524AB0XB1	
S524AB0XB1@SOP8 [(SA602A)]	S524AB0XB1@TSSOP8
[(SA026)]	
S524AD0XD1	
[(SA602A)]	S524AD0XD1@SOP8
S524AD0XD1@TSSOP8 [(SA026)]	
S524AD0XF1	
S524AD0XF1@SOP8 [(SA602A)]	S524AD0XF1@TSSOP8
[(SA026)]	
S524C20D11	
[(SA602A)]	S524C20D11@SOP8
S524C20D11@TSSOP8 [(SA026)]	
S524C20D21	
S524C20D21@SOP8 [(SA602A)]	S524C20D21@TSSOP8
[(SA026)]	
S524C80D41	
[(SA602A)]	S524C80D41@SOP8
S524C80D41@TSSOP8 [(SA026)]	

S524C80D81	
S524C80D81@SOP8 [(SA602A)]	S524C80D81@TSSOP8
[(SA026)]	
S524L50X51	S524L50X51@SOP8
[(SA602A)]	
S524L50X51@TSSOP8 [(SA026)]	
S524LB0X91	
S524LB0X91@SOP8 [(SA602A)]	S524LB0X91@TSSOP8
[(SA026)]	
S524LB0XB1	S524LB0XB1@SOP8
[(SA602A)]	
S524LB0XB1@TSSOP8 [(SA026)]	

DRAM & SRAM

KM61257	KM61257@SOJ24
[(SA646)]	
KM61257L	KM61257L@SOJ24
[(SA646)]	
KM6165	KM6165@SOJ24
[(SA646)]	
KM6165L	KM6165L@SOJ24
[(SA646)]	
KM62256A	KM62256A@SOIC28
[(SA630)]	
KM62256AL	KM62256AL@SOIC28
[(SA630)]	
KM6264A	KM6264A@SOIC28
[(SA630)]	
KM6264AL	KM6264AL@SOIC28
[(SA630)]	
KM64257	KM64257@SOJ24
[(SA646)]	
KM64257L	KM64257L@SOJ24
[(SA646)]	
KM6465LP	KM6465LP@SOJ22
[(SA646)]	
KM6465P	
KM68257LP	
KM68257LP@SOIC28 [(SA630)]	
KM68257P	
KM68257P@SOIC28 [(SA630)]	

KM6865LP
KM6865LP@SOIC28 [(SA630)]
KM6865P
KM6865P@SOIC28 [(SA630)]

PLD

CPL16L8 [(SA001A)]	CPL16L8@PLCC20
CPL16L8L [(SA001A)]	CPL16L8L@PLCC20
CPL16R4 [(SA001A)]	CPL16R4@PLCC20
CPL16R4L [(SA001A)]	CPL16R4L@PLCC20
CPL16R6 [(SA001A)]	CPL16R6@PLCC20
CPL16R6L [(SA001A)]	CPL16R6L@PLCC20
CPL16R8 [(SA001A)]	CPL16R8@PLCC20
CPL16R8L [(SA001A)]	CPL16R8L@PLCC20

MICROCONTROLLER

S3F84I8@QFP44 [(SA675)] [(SA028)]	S3F84I8@SDIP42
S3F84I9@QFP44 [(SA675)] [(SA028)]	S3F84I9@SDIP42
S3F84P4 +B003)]	S3F84P4@SOP8 [(SA602A
S3F9444 +B003)]	S3F9444@SOP8 [(SA602A
S3F9454(dip16) (dip20)	S3F9454
S3F9454@SOP20 [(SA404+B005)] [(SA245A)]	S3F9488@QFP44
S3F9488@SDIP32 [(SA653)] [(SA028)]	S3F9488@SDIP42
S3F9488@SOP32 [(SA630)]	S3F9498@SDIP30

[(SA653)]
S3F9498@SDIP32 [(SA653)] S3F9498@SOP28
[(SA630)]
S3F9498@SOP32 [(SA630)]

SAMSUNG-CUSTOMER

E (E) PROM / FRAM / NVRAM

K9F1208U0B(LM)@TSOP48 [(SA247-B005)]
K9F1G08U0A(AMLOGIC)@TSOP48 [(SA247-B005)]
K9F1G08U0M(DD5)@TSOP48 [(SA247+B005)]
K9F2G08U0A(YYD)@TSOP48 [(SA247-B005)]
K9F2G08U0A(ZX)@TSOP48 [(SA247-B005)]
K9F2G08U0M(YYD)@TSOP48 [(SA247-B005)]
K9F4G08U0A(WS)@TSOP48 [(SA247-B005)]
K9F4G08U0M(DD5)@TSOP48 [(SA247+B005)]
K9F5608U0B(QJ)@TSOP48 [(SA247-B005)]
K9F5608U0D(RS)@TSOP48 [(SA247-B005)]
K9F8G08U0A(ZX)@TSOP48 [(SA247-B005)]
K9G4G08U0A(OMB)@TSOP48 [(SA247-B005)]
K9G8G08U0M(DD5)@TSOP48 [(SA247-B005)]
K9GAG08U0M(DD)@TSOP48 [(SA247-B005)]
K9GAG08U0M(DD5)@TSOP48 [(SA247-B005)]
K9HBG08U1A(CH)@TSOP48 [(SA247-B005)]
K9HBG08U1M(CH)@TSOP48 [(SA247-B005)]
K9K4G08U0M(YYD)@TSOP48 [(SA247-B005)]
K9K8G08U0A(DD5)@TSOP48 [(SA247+B005)]
K9K8G08U0A(FX)@TSOP48 [(SA247+B005)]
K9WAG08U1M(DD5)@TSOP48 [(SA247+B005)]

SANYO

E (E) PROM / FRAM / NVRAM

LE24C041 LE24C041@MFP8
[(SA654)]
LE24C042 LE24C042@MFP8
[(SA654)]
LE24C081 LE24C081@MFP8

[(SA654)]	
LE24C082	LE24C082@MFP8
[(SA654)]	
LE24C161	LE24C161@MFP8
[(SA654)]	
LE24C162	LE24C162@MFP8
[(SA654)]	
LE24C322@MFP8 [(SA654)]	LE24C322@WLP6
[(SA698)]	
LE24L322@MFP8 [(SA654)]	LE25FU106BMA@MFP8
[(SA654)]	
LE25FU106BTT@MSOP8 [(SA654)]	LE25FU406BMA@MFP8
[(SA602A)]	
LE25FU406BTT@MSOP8 [(SA654)]	LE25FV055T@MSOP8
[(SA654)]	
LE25FV101T@MSOP8 [(SA654)]	LE25FV105T@MSOP8
[(SA654)]	
LE25FV201T@MSOP8 [(SA654)]	LE25FV401T@MSOP8
[(SA654)]	
LE25FV411T@MSOP8 [(SA654)]	LE25FV451T@VSOP32
[(SA620)]	
LE25FW056FN@VSON8 [(SA683)]	LE25FW056MA@MFP8
[(SA602A)]	
LE25FW106M@SOP8 [(SA602A)]	LE25FW106T@MSOP8
[(SA654)]	
LE25FW1606FN@VSON8 [(SA683)]	LE25FW203ATT@MSOP8
[(SA654)]	
LE25FW206M@SOP8 [(SA602A)]	LE25FW206T@MSOP8
[(SA654)]	
LE25FW406BMA@MFP8 [(SA602A)]	LE25FW406BTT@MSOP8
[(SA654)]	
LE25FW406M@SOP8 [(SA602A)]	LE25FW406T@MSOP8
[(SA654)]	
LE25FW806M@SOP8 [(SA602A)]	LE25FW806T@MSOP8
[(SA654)]	
LE26CW006@WLP6 [(SA698)]	LE28BW168T@TSOP48 [(SA247-
B005)]	
LE28C1001AM@SOP32 [(SA687)]	LE28C1001AT@TSOP32
[(SA410T)]	
LE28C1001ATS@VSOP32 [(SA620)]	LE28C1001DT@TSOP32
[(SA410T)]	
LE28C1001DTS@VSOP32 [(SA620)]	LE28CV1001AT@TSOP32
[(SA410T)]	

LE28CV1001ATS@VSOP32 [(SA620)] LE28CV1001DT@TSOP32
[(SA410T)]
LE28CV1001DTS@VSOP32 [(SA620)] LE28CW1001DT@TSOP32
[(SA410T)]
LE28CW1001DTS@VSOP32 [(SA620)]
LE28DW1621T@FBGA63 [(SA642A-B026A-Y096F001)]
LE28DW1621T@TSOP48 [(SA247-B005)]
LE28DW8102T@TSOP48 [(SA637)]
LE28DW8163T@TSOP48 [(SA247-B005)]
LE28F1101T@TSOP40 [(SA623)] LE28F1601T@TSOP40
[(SA409T)]
LE28F2001ATS@TSOP32 [(SA410T)] LE28F4001ATS@TSOP32
[(SA410T)]
LE28F4001M@SSOP32 [(SA438T)] LE28F8001T@TSOP40
[(SA409T)]
LE28FU4101T@TSOP48 [(SA247-B005)]
LE28FV1101T@TSOP40 [(SA623)] LE28FV1601T@TSOP40
[(SA409T)]
LE28FV2001ATS@TSOP32 [(SA410T)] LE28FV4001ATS@TSOP32
[(SA410T)]
LE28FV4001CTS@TSOP32 [(SA410T)] LE28FV4001M@SSOP32
[(SA438T)]
LE28FV4001T@TSOP40 [(SA409T)]
LE28FV4101T@TSOP48 [(SA247-B005)]
LE28FV8001T@TSOP40 [(SA409T)]
LE28FW1633FB@FBGA48 [(SA642G-B026A-T048F001Y)]
LE28FW1633FT@FBGA48 [(SA642G-B026A-T048F001Y)]
LE28FW1633TB@TSOP48 [(SA247-B005)]
LE28FW1633TT@TSOP48 [(SA247-B005)]
LE28FW4101T@TSOP48 [(SA247-B005)]
LE28FW8201T@TSOP48 [(SA247-B005)]
LE28FW8203TB@FBGA48 [(SA642B-B026A-Y072F001)]
LE28FW8203TB@TSOP48 [(SA247-B005)]
LE28FW8203TT@FBGA48 [(SA642B-B026A-Y072F001)]
LE28FW8203TT@TSOP48 [(SA247-B005)]

SCENIX

MICROCONTROLLER

SX20AC/SS/G@SSOP20 [(SA626A)] SX20AC/SS@SSOP20
[(SA626A)]

SX28AC/DP

SX28AC/DP/

G

SX28AC/SS/G@SSOP28 [(SA626A)]
[(SA626A)]

SX28AC/SS@SSOP28

SX48BD/G@TQFP48 [(SA248)]
[(SA248)]

SX48BD@TQFP48

SEEQ

E (E) PROM / FRAM / NVRAM

27128

27256

2764

27C256

2804

2804A

2816A

2816AH

5213

52B13

52B13H

52B23

52B23H

52B33

52B33H

5516A

5516AH

5517A

5517AH

DE2817A

DE2817A@PLCC32 [(SA015A1T)]

DE2817AH

DE2817AH@PLCC32 [(SA015A1T)]

DQ2817A

DQ2817A@PLCC32 [(SA015A1T)]

DQ2817AH

DQ2817AH@PLCC32 [(SA015A1T)]

DQ2864

DQ2864@PLCC32 [(SA015A1T)]

DQ2864H

DQ2864H@PLCC32 [(SA015A1T)]

DQ28C256
DQ28C256@PLCC32 [(SA015A1T)]
DQ28C64
DQ28C64@PLCC32 [(SA015A1T)]
DQ28C64A
DQ28C64A@PLCC32 [(SA015A1T)]
DQ28C65
DQ28C65@PLCC32 [(SA015A1T)]
DQ52B13
DQ52B13H
E28C64
E28C64@PLCC32 [(SA015A1T)]
E52B13
E52B13H
E52B23
E52B23H
E52B33
E52B33H
M28C64
M28C64@PLCC32 [(SA015A1T)]
M52B13
M52B13H
M52B23
M52B23H
M52B33
M52B33H
PQ2864
PQ2864@PLCC32 [(SA015A1T)]
PQ2864H
PQ2864H@PLCC32 [(SA015A1T)]
PQ28C64
PQ28C64@PLCC32 [(SA015A1T)]
PQ28C65
PQ28C65@PLCC32 [(SA015A1T)]

SEIKO

E (E) PROM / FRAM / NVRAM

S-22H10
[(SA404)]
S-22H12

S-22H10@SOP18

S-22H12@SOP18

[(SA404)]	
S-22S10	S-22S10@SOP18
[(SA404)]	
S-22S12	S-22S12@SOP18
[(SA404)]	
S-24C01A(DP)	S-24C01A
(DPA)	
S-24C01A(FJA)@SOIC8 [(SA602A)]	S-24C01B
(DP)	
S-24C01B(FJ)@SOIC8 [(SA602A)]	S-24C02A
(DP)	
S-24C02A(DPA)	S-24C02A(FJA)@SOIC8
[(SA602A)]	
S-24C02B(DP)	S-24C02B(FJ)@SOIC8
[(SA602A)]	
S-24C04A(DP)	S-24C04A
(DPA)	
S-24C04A(FJA)@SOIC8 [(SA602A)]	S-24C04B
(DP)	
S-24C04B(FJ)@SOIC8 [(SA602A)]	S-24C08A
(DPA)	
S-24C08A(FJA)@SOIC8 [(SA602A)]	S-24C16A
(DPA)	
S-24C16A(FJA)@SOIC8 [(SA602A)]	S-24CS01A
(DP)	
S-24CS01A(FJ)@SOIC8 [(SA602A)]	S-24CS01A(FT)@TSSOP8
[(SA026)]	
S-24CS02A(DP)	S-24CS02A(FJ)@SOIC8
[(SA602A)]	
S-24CS02A(FT)@TSSOP8 [(SA026)]	S-24CS04A
(DP)	
S-24CS04A(FJ)@SOIC8 [(SA602A)]	S-24CS04A(FT)@TSSOP8
[(SA026)]	
S-24CS08A(DP)	S-24CS08A(FJ)@SOIC8
[(SA602A)]	
S-24CS08A(FT)@TSSOP8 [(SA026)]	S-24CS16A
(DP)	
S-24CS16A(FJ)@SOIC8 [(SA602A)]	S-24CS16A(FT)@TSSOP8
[(SA026)]	
S-24CS64A(FJ)@SOIC8 [(SA602A)]	S-24CS64A(FT)@TSSOP8
[(SA026)]	
S-2817A@SOP28 [(SA630)]	S-29130A(DFJA)@SOIC8
[(SA602A)]	

S-29130A(DPA) [(SA602A)]	S-29130A(FJA)@SOIC8
S-29131A(DPA) [(SA602A)]	S-29131A(FJA)@SOIC8
S-29190A(DPA) [(SA602A)]	S-29190A(FJA)@SOIC8
S-29191A(DPA) [(SA602A)]	S-29191A(FJA)@SOIC8
S-29194A(DPA) [(SA602A)]	S-29194A(FJA)@SOIC8
S-29220A(DFJA)@SOIC8 [(SA602A)] (DPA)	S-29220A
S-29220A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29221A
S-29221A(FJA)@SOIC8 [(SA602A)] [(SA602A)]	S-29230A(DFJA)@SOIC8
S-29230A(DPA) [(SA602A)]	S-29230A(FJA)@SOIC8
S-29231A(DPA) [(SA602A)]	S-29231A(FJA)@SOIC8
S-29290A(DPA) [(SA602A)]	S-29290A(FJA)@SOIC8
S-29291A(DPA) [(SA602A)]	S-29291A(FJA)@SOIC8
S-29294A(DPA) [(SA602A)]	S-29294A(FJA)@SOIC8
S-29330A(DFJA)@SOIC8 [(SA602A)] (DPA)	S-29330A
S-29330A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29331A
S-29331A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29390A
S-29390A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29391A
S-29391A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29394A
S-29394A(FJA)@SOIC8 [(SA602A)] 29430A	S-
S-29430A@SOIC8 [(SA602A)] 29530A	S-
S-29530A@SOIC8 [(SA602A)] 29630A	S-
S-29630A@SOIC8 [(SA602A)]	S-29L130A(DFE)@SOIC8

[(SA602A)]	
S-29L130A (FE) @SOIC8 [(SA602A)]	S-29L130A (FS) @SSOP8
[(SA026)]	
S-29L131A (DFE) @SOIC8 [(SA602A)]	S-29L131A (FS) @SSOP8
[(SA026)]	
S-29L194A (DFE) @SOIC8 [(SA602A)]	S-29L194A (FS) @TSSOP8
[(SA026)]	
S-29L220A (DFE) @SOIC8 [(SA602A)]	S-29L220A (FE) @SOIC8
[(SA602A)]	
S-29L220A (FS) @SSOP8 [(SA026)]	S-29L221A (DFE) @SOIC8
[(SA602A)]	
S-29L221A (FS) @SSOP8 [(SA026)]	S-29L294A (DFE) @SOIC8
[(SA602A)]	
S-29L294A (FS) @TSSOP8 [(SA026)]	S-29L330A (DFE) @SOIC8
[(SA602A)]	
S-29L330A (FE) @SOIC8 [(SA602A)]	S-29L330A (FS) @SSOP8
[(SA026)]	
S-29L331A (DFE) @SOIC8 [(SA602A)]	S-29L331A (FS) @SSOP8
[(SA026)]	
S-29L394A (DFE) @SOIC8 [(SA602A)]	S-29L394A (FS) @TSSOP8
[(SA026)]	
S-29U130A (DFE) @SOIC8 [(SA602A)]	S-29U130A (FS) @SSOP8
[(SA026)]	
S-29U131A (DFE) @SOIC8 [(SA602A)]	S-29U131A (FS) @SSOP8
[(SA026)]	
S-29U194A (DFE) @SOIC8 [(SA602A)]	S-29U194A (FS) @TSSOP8
[(SA026)]	
S-29U220A (DFE) @SOIC8 [(SA602A)]	S-29U220A (FS) @SSOP8
[(SA026)]	
S-29U221A (DFE) @SOIC8 [(SA602A)]	S-29U221A (FS) @SSOP8
[(SA026)]	
S-29U294A (DFE) @SOIC8 [(SA602A)]	S-29U294A (FS) @TSSOP8
[(SA026)]	
S-29U330A (DFE) @SOIC8 [(SA602A)]	S-29U330A (FS) @SSOP8
[(SA026)]	
S-29U331A (DFE) @SOIC8 [(SA602A)]	S-29U331A (FS) @SSOP8
[(SA026)]	
S-29U394A (DFE) @SOIC8 [(SA602A)]	S-29U394A (FS) @TSSOP8
[(SA026)]	
S-29Z330A (DFJA) @SOIC8 [(SA602A)]	S-29Z330A (FS) @SSOP8
[(SA026)]	
S-29Z430A (DFJA) @SOIC8 [(SA602A)]	S-29Z430A (FS) @SSOP8
[(SA026)]	

S-93A46A(D0A)@SOIC8 [(SA602A)] [(SA602A)]	S-93A56A(D0A)@SOIC8
S-93A66A(D0A)@SOIC8 [(SA602A)] [(SA602A)]	S-93A66A(FJ)@SOIC8
S-93A86A@SOIC8 [(SA602A)] [(SA602A)]	S-93C46A(DFJ)@SOIC8
S-93C46A(DP) [(SA602A)]	S-93C46A(FJ)@SOIC8
S-93C46A(FT)@TSSOP8 [(SA026)] (DP)	S-93C46B
S-93C46B(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C46B(FT)@TSSOP8
S-93C56A(DFJ)@SOIC8 [(SA602A)] (DP)	S-93C56A
S-93C56A(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C56A(FT)@TSSOP8
S-93C56B(DP) [(SA602A)]	S-93C56B(FJ)@SOIC8
S-93C56B(FT)@TSSOP8 [(SA026)] [(SA602A)]	S-93C66A(DFJ)@SOIC8
S-93C66A(DP) [(SA602A)]	S-93C66A(FJ)@SOIC8
S-93C66A(FT)@TSSOP8 [(SA026)] (DP)	S-93C66B
S-93C66B(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C66B(FT)@TSSOP8
S-93C76A(DP) [(SA602A)]	S-93C76A(FJ)@SOIC8
S-93C76A(FT)@TSSOP8 [(SA026)] (DP)	S-93C86A
S-93C86A(FJ)@SOIC8 [(SA602A)] [(SA026)]	S-93C86A(FT)@TSSOP8
S-93C86B@SOIC8 [(SA602A)] [(SA026)]	S-93C86B@TSSOP8
S-93L46A(D0I)@SOIC8 [(SA602A)] [(SA602A)]	S-93L56A(D0I)@SOIC8
S-93L66A(D0I)@SOIC8 [(SA602A)] [(SA602A)]	S-93L76A(D0I)@SOIC8

SGS-THOMSON

E (E) PROM / FRAM / NVRAM

ET2716
ETC2716
ETC2732
M24128
M24128@SOIC8 [(SA602A)]
M24164
M24164@SOIC8 [(SA602A)]
M24256
M24256[3.9]@SOIC8 [(SA602A)]
[(SA605A)]
M24512
[(SA605A)]
M24512@TSOP8 [(SA026)]
M24C04
M24C04@SOIC8 [(SA602A)]
M24C08
M24C08@SOIC8 [(SA602A)]
M24C08W
M24C08W@SOIC8 [(SA602A)]
[(SA026)]
M24C64(BN)
[(SA026)]
M24C64(DW)@TSSOP8 [(SA602A)]
[(SA605A)]
M24C64(MW)@SOIC8 [(SA602A)]
M27128A
M2716
M27256
M27256A
M2732A
M27512
M2764
M2764A
M27C1000
M27C1000@PLCC32 [(SA015A1T)]
[(SA410T)]
M27C1001
[(SA015A1T)]
M27C1001@TSOP32 [(SA410T)]
M27C1024
M27C1024@PLCC44 [(SA244)]
M27C160
M24256[5.5]@SOIC8
M24512@SOIC8
M24C08W@TSOP8
M24C64(DL)@TSSOP14
M24C64(MN)@SOIC8
M27C1000@TSOP32
M27C1001@PLCC32

M27C160@PLCC44 [(SA244)]	M27C160@PSOP44
[(SA638)]	
M27C2001	M27C2001@PLCC32
[(SA015A1T)]	
M27C2001@TSOP32 [(SA410T)]	
M27C202	
M27C202@PLCC44 [(SA244)]	M27C202@TSOP40
[(SA409T)]	
M27C256B	M27C256B@PLCC32
[(SA015A1T)]	
M27C400	
M27C4001	
M27C4001@PLCC32 [(SA015A1T)]	M27C4001@TSOP32
[(SA410T)]	
M27C4002	M27C4002@PLCC44
[(SA244)]	
M27C405	M27C405@PLCC32
[(SA015A1T)]	
M27C405@TSOP32 [(SA410T)]	
M27C512	
M27C512@PLCC32 [(SA015A1T)]	
M27C516	
M27C516@PLCC44 [(SA244)]	
M27C64A	
M27C64A@PLCC32 [(SA015A1T)]	
M27C800	
M27C800@PLCC44 [(SA244)]	M27C800@PSOP44
[(SA638)]	
M27C801	M27C801@PLCC32
[(SA015A1T)]	
M27C801@TSOP32 [(SA410T)]	
M27HC641	
M27HC641@PLCC28 [(SA008A)]	
M27HC642	
M27HC642@PLCC28 [(SA008A)]	
M27V101	
M27V101@PLCC32 [(SA015A1T)]	M27V101@TSOP32
[(SA410T)]	
M27V201	M27V201@PLCC32
[(SA015A1T)]	
M27V201@TSOP32 [(SA410T)]	
M27V401	
M27V401@PLCC32 [(SA015A1T)]	M27V401@TSOP32

[(SA410T)]	
M27V402	M27V402@PLCC44
[(SA244)]	
M27V402@TSOP40 [(SA409T)]	
M27V512	
M27V512@PLCC32 [(SA015A1T)]	M27V512@TSOP28
[(SA430T)]	
M27V800	M27V800@PLCC44
[(SA244)]	
M27V801	M27V801@PLCC32
[(SA015A1T)]	
M27V801@TSOP32 [(SA410T)]	
M27W201	
M27W201@PLCC32 [(SA015A1T)]	M27W201@TSOP32
[(SA410T)]	
M28010	M28010@PLCC32
[(SA015A1T)]	
M28010@TSOP32 [(SA410T)]	M28C16@PLCC32
[(SA015A1T)]	
M28C64C	M28C64C@PLCC32
[(SA015A1T)]	
M28C64C@SOIC28 [(SA404)]	M28C64C@TSOP28
[(SA430T)]	
M28F101	M28F101@PLCC32
[(SA015A1T)]	
M28F101@TSOP32 [(SA410T)]	
M28F102	
M28F102@PLCC44 [(SA244)]	M28F102@TSOP40
[(SA409T)]	
M28F201	M28F201@PLCC32
[(SA015A1T)]	
M28F201@TSOP32 [(SA410T)]	M28F211@TSOP40
[(SA409T)]	
M28F220@PSOP44 [(SA638)]	M28F220@TSOP48 [(SA247-
B005)]	
M28F256	M28F256@PLCC32
[(SA015A1T)]	
M28F256@TSOP32 [(SA410T)]	M28F411@TSOP40
[(SA409T)]	
M28F512	M28F512@PLCC32
[(SA015A1T)]	
M28F512@TSOP32 [(SA410T)]	
M29F002B	

M29F002B@PLCC32 [(SA015A1T)]	M29F002B@TSOP32
[(SA410T)]	
M29F002T	M29F002T@PLCC32
[(SA015A1T)]	
M29F002T@TSOP32 [(SA410T)]	
M29F040	
M29F040@PLCC32 [(SA015A1T)]	M29F040@TSOP32
[(SA410T)]	
M29F040B	M29F040B@PLCC32
[(SA015A1T)]	
M29F040B@TSOP32 [(SA410T)]	M29F100B@PSOP44 [(SA638-
B006)]	
M29F100B@TSOP48 [(SA247-B005)]	M29F100T@PSOP44 [(SA638-
B006)]	
M29F100T@TSOP48 [(SA247-B005)]	M29F102B@PLCC44
[(SA244)]	
M29F102B@TSOP40 [(SA623)]	M29F102BB@PLCC44
[(SA244)]	
M29F102BB@TSOP40 [(SA623)]	M29F200B@PSOP44 [(SA638-
B006)]	
M29F200B@TSOP48 [(SA247-B005)]	M29F200T@PSOP44 [(SA638-
B006)]	
M29F200T@TSOP48 [(SA247-B005)]	M29F400B@PSOP44 [(SA638-
B006)]	
M29F400B@TSOP48 [(SA247-B005)]	M29F400T@PSOP44 [(SA638-
B006)]	
M29F400T@TSOP48 [(SA247-B005)]	M29V040@PLCC32
[(SA015A1T)]	
M29V040@TSOP32 [(SA410T)]	M29W008B@TSOP40
[(SA409T)]	
M29W008T@TSOP40 [(SA409T)]	M29W040@PLCC32
[(SA015A1T)]	
M29W040@TSOP32 [(SA410T)]	M29W400B@PSOP44
[(SA638)]	
M29W400B@TSOP48 [(SA247-B005)]	M29W400T@PLCC44
[(SA638)]	
M29W400T@TSOP48 [(SA247-B005)]	M29W512B@PLCC32
[(SA015A1T)]	
M29W512B@TSOP32 [(SA620)]	M29W800B@PSOP44
[(SA638)]	
M29W800B@TSOP48 [(SA247-B005)]	M29W800T@PSOP44
[(SA638)]	
M29W800T@TSOP48 [(SA247-B005)]	

M48T35
M48T35@SOIC28 [(SA404)]
M48T35Y
M48T35Y@SOIC28 [(SA404)]
M48T59
M48T59@SOIC28 [(SA404)]
M48T59Y
M48T59Y@SOIC28 [(SA404)]
M48Z128
M48Z128Y
M48Z30
M48Z30Y
M48Z32
M48Z32Y M50FW080@PLCC32
[(SA015A1T)]
M50FW080@TSOP40 [(SA409T)] M50FW080@VSOP32
[(SA620)]
M87C257 M87C257@PLCC32
[(SA015A1T)]
M93C06(08bit) M93C06(08bit)@SOIC8
[(SA602A)]
M93C06(16bit) M93C06(16bit)@SOIC8
[(SA602A)]
M93S46 M93S46@SOIC8
[(SA602A)]
M93S46@TSSOP8 [(SA026)]
M95P02
M95P02@SOIC8 [(SA602A)]
M95P04
M95P04@SOIC8 [(SA602A)]
M95P08
M95P08@SOIC8 [(SA602A)]
MK48C02
MK48C02B
MK48C12
MK48C12B
MK48T02
MK48T02B
MK48T08
MK48T12
MK48T12B
MK48T18
MK48Z02

MK48Z02B
MK48Z08
MK48Z12
MK48Z12B
MK48Z18
MKI48Z02
MKI48Z02B
MKI48Z12
MKI48Z12B
MKI48Z18
ST24C01 ST24C01@SOIC8
[(SA602A)]
ST24C02A ST24C02A@SOIC8
[(SA602A)]
ST24C16 ST24C16@SOIC8
[(SA602A)]
ST24W01 ST24W01@SOIC8
[(SA602A)]
ST24W02 ST24W02@SOIC8
[(SA602A)]
ST24W04C ST24W04C@SOIC8
[(SA602A)]
ST27128A
ST27256
ST2764A
ST27C256
ST93C06(08bit) ST93C06(08bit)@SOIC8
[(SA602A)]
ST93C06(16bit) ST93C06(16bit)@SOIC8
[(SA602A)]
ST93CS46 ST93CS46@SOIC8
[(SA602A)]
TS27C256
TS27C64
TS27C64@PLCC32 [(SA015A1T)]
TS27C64A
TS27C64A@PLCC32 [(SA015A1T)]
TS28C16A
TS28C17A

PLD

GAL16V8
 GAL16V8A
 GAL20V8
 GAL20V8A

SHARP

E (E) PROM / FRAM / NVRAM

LH28F002SCHN@PSOP44 [(SA638)]	LH28F002SCHT@TSOP40
[(SA409T)]	
LH28F002SCN@PSOP44 [(SA638)]	LH28F002SCT@TSOP40
[(SA409T)]	
LH28F004BVE (BT) @TSOP40 [(SA409T)]	
LH28F004BVE (TT) @TSOP40 [(SA409T)]	
LH28F004BVHS (BT) @VSOP40 [(SA623)]	
LH28F004BVHS (TT) @VSOP40 [(SA623)]	
LH28F004BVT (BT) @TSOP40 [(SA409T)]	
LH28F004BVT (TT) @TSOP40 [(SA409T)]	
LH28F004SCHN@PSOP44 [(SA638)]	LH28F004SCHS@VSOP40
[(SA623)]	
LH28F004SCHT@TSOP40 [(SA409T)]	LH28F004SCN@PSOP44
[(SA638)]	
LH28F004SCS@VSOP40 [(SA623)]	LH28F004SCT@TSOP40
[(SA409T)]	
LH28F008BJT (BTLZ1) @TSOP40 [(SA409T)]	
LH28F008BJT (TB) @TSOP40 [(SA409T)]	
LH28F008BJT (TT) @TSOP40 [(SA409T)]	
LH28F008BJT (TTLZ2) @TSOP40 [(SA409T)]	
LH28F008BVT (BT) @TSOP40 [(SA409T)]	
LH28F008BVT (TT) @TSOP40 [(SA409T)]	
LH28F008SAN@PSOP44 [(SA638)]	LH28F008SAR@RTSOP40
[(SA409T)]	
LH28F008SAT@TSOP40 [(SA409T)]	
LH28F008SCH (L85) @RTSOP40 [(SA409T)]	
LH28F008SCH-L@TSOP40 [(SA409T)]	LH28F008SCHN@PSOP44
[(SA638)]	
LH28F008SCH-V@TSOP40 [(SA409T)]	
LH28F008SCH-ZU-120@TSOP40 [(SA409T)]	
LH28F008SCN@PSOP44 [(SA638)]	LH28F008SCN-L@PSOP44
[(SA638)]	
LH28F008SCT@TSOP40 [(SA409T)]	LH28F008SCT-L@TSOP40

[(SA409T)]
LH28F008SCT-V@TSOP40 [(SA409T)] LH28F008SCV@TSOP40
[(SA409T)]
LH28F016SA@TSOP56 [(SA628-B011)] LH28F016SC@PSOP44
[(SA638)]
LH28F016SCR(L95)@RTSOP40 [(SA409T)]
LH28F016SCT-L95@TSOP40 [(SA409T)]
LH28F016SUT@TSOP56 [(SA628-B011)]
LH28F128BFHBD@CSP72 [(SA642E-B052A-T072F001)]
LH28F128BFHE@TSOP48 [(SA247-B005)]
LH28F128BFHT(PBTL70_75A)@TSOP56 [(SA628-B045)]
LH28F128BFHT(PTTL70_75A)@TSOP56 [(SA628-B045)]
LH28F128BFHT(PWTL80)@TSOP56 [(SA628-B045)]
LH28F128BFND@PSOP44 [(SA638)]
LH28F128SPHTD@TSOP56 [(SA628-B018)]
LH28F160BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F160BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F160BGE(B)@TSOP48 [(SA247-B005)]
LH28F160BGE(T)@TSOP48 [(SA247-B005)]
LH28F160BJBB@FBGA48 [(SA642B-B029A-Y072F001)]
LH28F160BJBT@FBGA48 [(SA642B-B029A-Y072F001)]
LH28F160BJD
LH28F160BJEB@TSOP48 [(SA247-B005)]
LH28F160BJET@TSOP48 [(SA247-B005)]
LH28F160BJHBB@FBGA48 [(SA642B-B029A-Y072F001)]
LH28F160BJHBT@FBGA48 [(SA642B-B029A-Y072F001)]
LH28F160BJHEB@TSOP48 [(SA247-B005)]
LH28F160BJHET@TSOP48 [(SA247-B005)]
LH28F160BVE(BTL)@TSOP48 [(SA247-B005)]
LH28F160BVE(TTL)@TSOP48 [(SA247-B005)]
LH28F160BVEB(B)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F160BVEB(T)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F160BVHE(BTL)@TSOP48 [(SA247-B005)]
LH28F160BVHE(TTL)@TSOP48 [(SA247-B005)]
LH28F160S3HNS@SSOP56 [(SA629A-B013)]
LH28F160S3HT@TSOP56 [(SA628-B011)]
LH28F160S3NS@SSOP56 [(SA629A-B013)]
LH28F160S3T@TSOP56 [(SA628-B011)]
LH28F160S5HNS@SSOP56 [(SA629A-B013)]
LH28F160S5HT@TSOP56 [(SA628-B011)]
LH28F160S5NS@SSOP56 [(SA629A-B013)]
LH28F160S5T@TSOP56 [(SA628-B011)]
LH28F160SKT@TSOP56 [(SA628-B011)]

LH28F320BFE(PB)@TSOP48 [(SA247-B005)]
LH28F320BFE(PT)@TSOP48 [(SA247-B005)]
LH28F320BFHB(PB)@FBGA48 [(SA642B-B029A-Y072F001)]
LH28F320BFHB(PT)@FBGA48 [(SA642B-B029A-Y072F001)]
LH28F320BFHE(PB)@TSOP48 [(SA247-B005)]
LH28F320BFHE(PBTLZ2)@TSOP48 [(SA247-B005)]
LH28F320BFHE(PT)@TSOP48 [(SA247-B005)]
LH28F320BFHE(PTTLZ1)@TSOP48 [(SA247-B005)]
LH28F320BFHG(PBTLZL)@FBGA48 [(SA634A-B005A-Y048F001)]
LH28F320BFHG(PBTLZN)@FBGA48 [(SA634A-B005A-Y048F001)]
LH28F320BFHG(PTTLZ3)@FBGA48 [(SA634A-B005A-Y048F001)]
LH28F320BFHG(PTTLZK)@FBGA48 [(SA634A-B005A-Y048F001)]
LH28F320BFHG(PTTLZM)@FBGA48 [(SA634A-B005A-Y048F001)]
LH28F320BJD
LH28F320BJE(PB)(OTP)@TSOP48 [(SA247-B005)]
LH28F320BJE(PB)@TSOP48 [(SA247-B005)]
LH28F320BJE(PT)(OTP)@TSOP48 [(SA247-B005)]
LH28F320BJE(PT)@TSOP48 [(SA247-B005)]
LH28F320BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]
LH28F320BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]
LH28F320BJN@PSOP44 [(SA638)]
LH28F320S3HNS@SSOP56 [(SA629A-B013)]
LH28F320S3HT@TSOP56 [(SA628-B011)]
LH28F320S3NS@SSOP56 [(SA629A-B013)]
LH28F320S3T@TSOP56 [(SA628-B011)]
LH28F320S3TD@TSOP56 [(SA628-B011)]
LH28F320S5HNS@SSOP56 [(SA629A-B013)]
LH28F320S5HT@TSOP56 [(SA628-B011)]
LH28F320S5NS@SSOP56 [(SA629A-B013)]
LH28F320S5T@TSOP56 [(SA628-B011)]
LH28F320SKTD@TSOP56 [(SA628-B011)]
LH28F400BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F400BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F400BGE(B)@TSOP48 [(SA247-B005)]
LH28F400BGE(T)@TSOP48 [(SA247-B005)]
LH28F400BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F400BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F400BGHE(B)@TSOP48 [(SA247-B005)]
LH28F400BGHE(T)@TSOP48 [(SA247-B005)]
LH28F400BGN(B)@PSOP44 [(SA638)] LH28F400BGN(T)@PSOP44
[(SA638)]
LH28F400BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F400BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]

LH28F400BVE(B)@TSOP48 [(SA247-B005)]
LH28F400BVE(T)@TSOP48 [(SA247-B005)]
LH28F400BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F400BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F400BVHE(B)@TSOP48 [(SA247-B005)]
LH28F400BVHE(T)@TSOP48 [(SA247-B005)]
LH28F400BVN(B)@PSOP44 [(SA638)] LH28F400BVN(T)@PSOP44
[(SA638)]
LH28F640BFE(PB)@TSOP48 [(SA247-B005)]
LH28F640BFE(PT)@TSOP48 [(SA247-B005)]
LH28F640BFHB(PB)@FBGA60 [(SA642B-B029A-Y072F001)]
LH28F640BFHB(PT)@FBGA60 [(SA642B-B029A-Y072F001)]
LH28F640BFHE(PB)@TSOP48 [(SA247-B005)]
LH28F640BFHE(PT)@TSOP48 [(SA247-B005)]
LH28F640BFHE(PTTLHIA)@TSOP48 [(SA247-B005)]
LH28F640BFHG@FBGA48 [(SA634A-B005A-Y048F001)]
LH28F640BNHG@CSP56 [(SA644A-B025A-Y056F001)]
LH28F640SPHT@TSOP56 [(SA628-B018)]
LH28F800BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F800BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F800BGE(B)@TSOP48 [(SA247-B005)]
LH28F800BGE(T)@TSOP48 [(SA247-B005)]
LH28F800BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F800BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F800BGHE(B)@TSOP48 [(SA247-B005)]
LH28F800BGHE(T)@TSOP48 [(SA247-B005)]
LH28F800BGN(B)@PSOP44 [(SA638)] LH28F800BGN(T)@PSOP44
[(SA638)]
LH28F800BH-B@TSOP48 [(SA247-B005)]
LH28F800BJE(PB)(OTP)@TSOP48 [(SA247-B005)]
LH28F800BJE(PB)@TSOP48 [(SA247-B005)]
LH28F800BJE(PT)(OTP)@TSOP48 [(SA247-B005)]
LH28F800BJE(PT)@TSOP48 [(SA247-B005)]
LH28F800BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]
LH28F800BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]
LH28F800BJHG(PB)(OTP)@CSP48 [(SA634A-B005A-Y048F001)]
LH28F800BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F800BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F800BV-B@TSOP48 [(SA247-B005)]
LH28F800BVE(B)@TSOP48 [(SA247-B005)]
LH28F800BVE(T)@TSOP48 [(SA247-B005)]
LH28F800BVE(TV85)@TSOP48 [(SA247-B005)]
LH28F800BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]

LH28F800BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]
LH28F800BVHB@TSOP48 [(SA247-B005)]
LH28F800BVHE(B)@TSOP48 [(SA247-B005)]
LH28F800BVHE(T)@TSOP48 [(SA247-B005)]
LH28F800BVHT@TSOP48 [(SA247-B005)]
LH28F800BVN(B)@PSOP44 [(SA638)] LH28F800BVN(T)@PSOP44
[(SA638)]
LH28F800BVN(TV85)@PSOP44 [(SA638)]
LH28F800BV-T@TSOP48 [(SA247-B005)]
LH28F800SG(L100)@TSOP48 [(SA247)]
LH28F800SG(L120)@TSOP48 [(SA247)]
LH28F800SG(L70)@TSOP48 [(SA247)] LH28F800SG(L80)@TSOP48
[(SA247)]
LH28F800SG(L85)@TSOP48 [(SA247)]
LH28F800SGH(L100)@TSOP48 [(SA247)]
LH28F800SGH(L120)@TSOP48 [(SA247)]
LH28F800SGH(L70)@TSOP48 [(SA247)]
LH28F800SGH(L80)@TSOP48 [(SA247)]
LH28F800SGH(L85)@TSOP48 [(SA247)]
LH28F800SUT@TSOP56 [(SA628-B011)]
LHF00L03@PLCC32 [(SA015A1T)] LHF00L04@TSOP40
[(SA409T)]
LHF00L06@TSOP40 [(SA409T)] LHF00L07@PLCC32
[(SA015A1T)]
LHF00L08(LH28F320T)@FBGA48 [(SA642Z-B026A-W048F001Y)]
LHF00L09(LH28F320B)@FBGA48 [(SA642Z-B026A-W048F001Y)]
LHF00L10(LH28F320T)@FBGA48 [(SA634A-B005A-Y048F001Y)]
LHF00L11(LH28F320B)@FBGA48 [(SA634A-B005A-Y048F001Y)]
LHF00L12(LH28F320T)@TSOP48 [(SA247-B005)]
LHF00L13(LH28F320B)@TSOP48 [(SA247-B005)]
LHF00L14(LH28F320T)@TSOP48 [(SA247-B005)]
LHF00L15(LH28F320B)@TSOP48 [(SA247-B005)]
LHF00L24(LH28F160T)@FBGA48 [(SA642Z-B026A-W048F001Y)]
LHF00L25(LH28F160B)@FBGA48 [(SA642Z-B026A-W048F001Y)]
LHF00L28(LH28F160T)@TSOP48 [(SA247-B005)]
LHF00L29(LH28F160B)@TSOP48 [(SA247-B005)]
LHF00L30(LH28F160T)@TSOP48 [(SA247-B005)]
LHF00L31(LH28F160B)@TSOP48 [(SA247-B005)]
LRS1311@FBGA72 [(SA642E-B069A-T072F001)]
LRS1311A@FBGA72 [(SA642E-B069A-T072F001)]
LRS1315@FBGA72 [(SA642E-B069A-T072F001)]
LRS1316@FBGA72 [(SA642E-B069A-T072F001)]
LRS1317@FBGA72 [(SA642E-B069A-T072F001)]

LRs1320@FBGA72 [(SA642E-B069A-T072F001)]
LRs1320A@FBGA72 [(SA642E-B069A-T072F001)]
LRs1329@FBGA72 [(SA642E-B069A-T072F001)]
LRs1329A@FBGA72 [(SA642E-B069A-T072F001)]
LRs1330A@FBGA72 [(SA642E-B023A-T072F001)]
LRs1331@FBGA72 [(SA642E-B023A-T072F001)]
LRs1331B@FBGA72 [(SA642E-B023A-T072F001)]
LRs1331C@FBGA72 [(SA642E-B023A-T072F001)]
LRs1336@FBGA72 [(SA642E-B069A-T072F001)]
LRs1339@FBGA72 [(SA642E-B023A-T072F001)]
LRs1341@FBGA72 [(SA642E-B069A-T072F001)]
LRs1342@FBGA72 [(SA642E-B069A-T072F001)]
LRs1348B@FBGA72 [(SA642E-B023A-T072F001)]
LRs1350@FBGA72 [(SA642E-B069A-T072F001)]
LRs1356@FBGA72 [(SA642E-B069A-T072F001)]
LRs1360@FBGA72 [(SA642B-B023A-Y072F001)]
LRs1360C@FBGA72 [(SA642B-B023A-Y072F001)]
LRs1370@FBGA72 [(SA642B-B023A-Y072F001)]
LRs1370B@FBGA72 [(SA642B-B023A-Y072F001)]
LRs1380@FBGA72 [(SA642E-B023A-T072F001)]
LRs1381@FBGA72 [(SA642E-B023A-T072F001)]
LRs1382@FBGA72 [(SA642E-B023A-T072F001)]
LRs1383@FBGA72 [(SA642E-B023A-T072F001)]
LRs1383C@FBGA72 [(SA642E-B023A-T072F001)]
LRs1383F@FBGA72 [(SA642E-B023A-T072F001)]
LRs1384@FBGA72 [(SA642E-B023A-T072F001)]
LRs1385@FBGA72 [(SA642E-B023A-T072F001)]
LRs1386@FBGA72 [(SA642E-B023A-T072F001)]
LRs1387@FBGA72 [(SA642E-B023A-T072F001)]
LRs1391@FBGA72 [(SA642E-B023A-T072F001)]
LRs1392A@FBGA72 [(SA642E-B023A-T072F001)]
LRs1393A@FBGA72 [(SA642E-B023A-T072F001)]
LRs1393C@FBGA72 [(SA642E-B023A-T072F001N)]
LRs1395@FBGA72 [(SA642E-B052A-T072F001)]
LRs1396@TSOP56 [(SA628-B178)]
LRs13A0@FBGA72 [(SA642E-B052A-T072F001)]
LRs13A1@FBGA72 [(SA642E-B023A-T072F001)]
LRs13A2@FBGA72 [(SA642E-B023A-T072F001)]
LRs13A3@FBGA72 [(SA642E-B023A-T072F001)]
LRs13A4@FBGA72 [(SA642E-B023A-T072F001)]
LRs13A5@FBGA72 [(SA642E-B023A-T072F001)]
LRs13A6@FBGA72 [(SA642E-B023A-T072F001)]
LRs13A8@TSOP56 [(SA628-B216)]

LRS1805A@FBGA72 [(SA642E-B023A-T072F001)]
LRS1806A@FBGA72 [(SA642E-B023A-T072F001)]
LRS1806F@FBGA72 [(SA642B-B023A-Y072F001)]
LRS1807A@FBGA72 [(SA642E-B023A-T072F001)]
LRS1808A@FBGA72 [(SA642E-B023A-T072F001)]
LRS1811@FBGA72 [(SA642E-B023A-T072F001)]
LRS1812@FBGA72 [(SA642E-B023A-T072F001)]
LRS1816@FBGA72 [(SA642E-B052A-T072F001)]
LRS1816A@FBGA72 [(SA642E-B052A-T072F001)]
LRS1822@FBGA72 [(SA642E-B023A-T072F001)]
LRS1825@FBGA72 [(SA642E-B023A-T072F001)]
LRS1826@FBGA72 [(SA642E-B052A-T072F001)]
LRS1826A@FBGA72 [(SA642E-B052A-T072F001)]
LRS1827@FBGA72 [(SA642E-B052A-T072F001)]
LRS1828@FBGA72 [(SA642E-B052A-T072F001)]
LRS1829@FBGA72 [(SA642E-B052A-T072F001)]
LRS1832@FBGA72 [(SA642E-B052A-T072F001)]
LRS1844@FBGA72 [(SA642E-B023A-T072F001)]
LRS1845@FBGA72 [(SA642E-B023A-T072F001)]
LRS1850@FBGA72 [(SA642E-B023A-T072F001)]
LRS1851@FBGA72 [(SA642E-B023A-T072F001)]
LRS1852@FBGA72 [(SA642E-B023A-T072F001)]
LRS1853@FBGA72 [(SA642E-B023A-T072F001)]
LRS1871@FBGA72 [(SA642B-B023A-Y072F001)]
LRS1872@FBGA72 [(SA642B-B023A-Y072F001)]
LRS1875@FBGA72 [(SA642B-B023A-Y072F001)]
LRS1876@FBGA72 [(SA642B-B023A-Y072F001Y)]
LRS18B0@FBGA72 [(SA642E-B141A-T072F001Y)]
LRS18BK@FBGA88 [(SA642A-B091A-Y096F001)]
LRS18BL@FBGA88 [(SA642A-B091A-Y096F001)]
LRS18BS@FBGA72 [(SA642B-B023A-Y072F001)]

SHARP-CUSTOMER

E (E) PROM / FRAM / NVRAM

LH28F640BFHE (PT) @TSOP48 [(SA247-B005)]

SIEMENS

E (E) PROM / FRAM / NVRAM

SDA2526	SDA2526@SOIC8
[(SA602A)]	
SDA2546	SDA2546@SOIC8
[(SA602A)]	
SDA25X26	SDA25X26@SOIC8
[(SA602A)]	
SDA25X46	SDA25X46@SOIC8
[(SA602A)]	
SDE2526	SDE2526@SOIC8
[(SA602A)]	
SDE2546	SDE2546@SOIC8
[(SA602A)]	
SDE25X26	SDE25X26@SOIC8
[(SA602A)]	
SDE25X46	SDE25X46@SOIC8
[(SA602A)]	
SLA24C01	SLA24C01@SOIC8
[(SA602A)]	
SLA24C02	SLA24C02@SOIC8
[(SA602A)]	
SLA24C04	SLA24C04@SOIC8
[(SA602A)]	
SLA24C08	SLA24C08@SOIC8
[(SA602A)]	
SLA24C16	SLA24C16@SOIC8
[(SA602A)]	
SLA24C164	SLA24C164@SOIC8
[(SA602A)]	
SLA24C32	SLA24C32@SOIC8
[(SA602A)]	
SLA24C64	SLA24C64@SOIC8
[(SA602A)]	
SLA25010	SLA25010@SOIC8
[(SA602A)]	
SLA25020	SLA25020@SOIC8
[(SA602A)]	
SLA25040	SLA25040@SOIC8
[(SA602A)]	
SLA25080	SLA25080@SOIC8
[(SA602A)]	
SLA25160	SLA25160@SOIC8

[(SA602A)]	
SLE24C01	SLE24C01@SOIC8
[(SA602A)]	
SLE24C02	SLE24C02@SOIC8
[(SA602A)]	
SLE24C04	SLE24C04@SOIC8
[(SA602A)]	
SLE24C08	SLE24C08@SOIC8
[(SA602A)]	
SLE24C16	SLE24C16@SOIC8
[(SA602A)]	
SLE24C164	SLE24C164@SOIC8
[(SA602A)]	
SLE24C32	SLE24C32@SOIC8
[(SA602A)]	
SLE24C64	SLE24C64@SOIC8
[(SA602A)]	
SLE25010	SLE25010@SOIC8
[(SA602A)]	
SLE25020	SLE25020@SOIC8
[(SA602A)]	
SLE25040	SLE25040@SOIC8
[(SA602A)]	
SLE25080	SLE25080@SOIC8
[(SA602A)]	
SLE25160	SLE25160@SOIC8
[(SA602A)]	

SIGNETICS

E (E) PROM / FRAM / NVRAM

27C010	27C010@PLCC32
[(SA015A1T)]	
27C010@TSOP32 [(SA410T)]	
27C040	
27C040@PLCC32 [(SA015A1T)]	27C040@TSOP32
[(SA410T)]	
27C210	27C210@PLCC44
[(SA244)]	
27C240	27C240@PLCC44
[(SA244)]	

27C256	27C256@PLCC32
[(SA015A1T)]	
27C512	27C512@PLCC32
[(SA015A1T)]	
27C64A	27C64A@PLCC32
[(SA015A1T)]	
27HC641	27HC641@PLCC28
[(SA008A)]	
27HC642	27HC642@PLCC28
[(SA008A)]	
PCA8582A	PCA8582A@SOIC8
[(SA602A)]	
PCA8582B	PCA8582B@SOIC8
[(SA602A)]	
PCA8582C	PCA8582C@SOIC8
[(SA602A)]	
PCA8582D	PCA8582D@SOIC8
[(SA602A)]	
PCA8582E	PCA8582E@SOIC8
[(SA602A)]	
PCD8582A	PCD8582A@SOIC8
[(SA602A)]	
PCD8582B	PCD8582B@SOIC8
[(SA602A)]	
PCD8582C	PCD8582C@SOIC8
[(SA602A)]	
PCD8582D	PCD8582D@SOIC8
[(SA602A)]	
PCD8582E	PCD8582E@SOIC8
[(SA602A)]	
PCF8582A	PCF8582A@SOIC8
[(SA602A)]	
PCF8582B	PCF8582B@SOIC8
[(SA602A)]	
PCF8582C	PCF8582C@SOIC8
[(SA602A)]	
PCF8582D	PCF8582D@SOIC8
[(SA602A)]	
PCF8582E	PCF8582E@SOIC8
[(SA602A)]	
PCF8594	PCF8594@SOIC8
[(SA626A)]	
PCF8594C	PCF8594C@SOIC8

[(SA626A)]	
PCF8594D	PCF8594D@SOIC8
[(SA626A)]	
PCF8594E	PCF8594E@SOIC8
[(SA626A)]	
PCF8598	PCF8598@SOIC8
[(SA626A)]	
PCF8598C	PCF8598C@SOIC8
[(SA626A)]	
PCF8598D	PCF8598D@SOIC8
[(SA626A)]	
PCF8598E	PCF8598E@SOIC8
[(SA626A)]	

MICROCONTROLLER

S87C51	S87C51@PLCC44
[(SA244)]	
S87C51@TQFP44 [(SA245A)]	
S87C51FA	
S87C51FA@PLCC44 [(SA244)]	S87C51FA@TQFP44
[(SA245A)]	
S87C51FB	S87C51FB@PLCC44
[(SA244)]	
S87C51FB@TQFP44 [(SA245A)]	
S87C51FC	
S87C51FC@PLCC44 [(SA244)]	S87C51FC@TQFP44
[(SA245A)]	
S87C52	S87C52@PLCC44
[(SA244)]	
S87C52@TQFP44 [(SA245A)]	
S87C524	
S87C524@PLCC44 [(SA244)]	S87C524@TQFP44
[(SA245A)]	
S87C528	S87C528@PLCC44
[(SA244)]	
S87C528@TQFP44 [(SA245A)]	
S87C54	
S87C54@PLCC44 [(SA244)]	S87C54@TQFP44
[(SA245A)]	
S87C550	S87C550@PLCC44
[(SA244)]	

S87C552@PLCC68 (*) [(SA648-B6806)]
S87C554@PLCC68 (*) [(SA648-B6806)]
S87C575 S87C575@PLCC44
[(SA244)]
S87C575@TQFP44 [(SA245A)]
S87C576
S87C576@PLCC44 [(SA244)] S87C576@TQFP44
[(SA245A)]
S87C58 S87C58@PLCC44
[(SA244)]
S87C58@TQFP44 [(SA245A)] S87C591@PLCC44
[(SA244)]
S87C591@TQFP44 [(SA245A)]
S87C652
S87C652@PLCC44 [(SA244)] S87C652@TQFP44
[(SA245A)]
S87C654 S87C654@PLCC44
[(SA244)]
S87C654@TQFP44 [(SA245A)]
S87C748
S87C748@PLCC28 [(SA008A)]
S87C749
S87C749@PLCC28 [(SA008A)]
S87C750
S87C750@PLCC28 [(SA008A)] S87C750@SSOP24
[(SA626A)]
S87C751 S87C751@PLCC28
[(SA008A)]
S87C751@SSOP24 [(SA626A)]
S87C752
S87C752@PLCC28 [(SA008A)] S87C752@SSOP28
[(SA626A)]
S87C754 S87C754@PLCC28
[(SA008A)]
S87C754@SSOP28 [(SA626A)]
S87L51FA
S87L51FA@PLCC44 [(SA244)] S87L51FA@TQFP44
[(SA245A)]
S87L51FB S87L51FB@PLCC44
[(SA244)]
S87L51FB@TQFP44 [(SA245A)]

Silicon Laboratories

MICROCONTROLLER

C8051F000@TQFP64 (ISP) [(PEP+S616)]
 C8051F001@TQFP48 [(SA248)] C8051F001@TQFP48 (ISP)
 [(SA248)]
 C8051F002@TQFP32 [(SA663)] C8051F002@TQFP32 (ISP)
 [(SA663)]
 C8051F005@TQFP64 (ISP) [(PEP+S616)]
 C8051F006@TQFP48 [(SA248)] C8051F006@TQFP48 (ISP)
 [(SA248)]
 C8051F007@TQFP32 [(SA663)] C8051F007@TQFP32 (ISP)
 [(SA663)]
 C8051F010@TQFP64 (ISP) [(PEP+S616)]
 C8051F011@TQFP48 [(SA248)] C8051F011@TQFP48 (ISP)
 [(SA248)]
 C8051F012@TQFP32 [(SA663)] C8051F012@TQFP32 (ISP)
 [(SA663)]
 C8051F015@TQFP64 (ISP) [(PEP+S616)]
 C8051F016@TQFP48 [(SA248)] C8051F016@TQFP48 (ISP)
 [(SA248)]
 C8051F017@TQFP32 [(SA663)] C8051F017@TQFP32 (ISP)
 [(SA663)]
 C8051F018@TQFP64 (ISP) [(PEP+S616)]
 C8051F019@TQFP48 [(SA248)] C8051F019@TQFP48 (ISP)
 [(SA248)]
 C8051F020@TQFP100 (ISP) [ISP-HEADER01]
 C8051F021@TQFP64 (ISP) [ISP-HEADER01]
 C8051F022@TQFP100 (ISP) [ISP-HEADER01]
 C8051F023@TQFP64 (ISP) [ISP-HEADER01]
 C8051F040@TQFP100 (ISP) [ISP-HEADER01]
 C8051F041@TQFP64 (ISP) [ISP-HEADER01]
 C8051F042@TQFP100 (ISP) [ISP-HEADER01]
 C8051F043@TQFP64 (ISP) [ISP-HEADER01]
 C8051F044@TQFP100 (ISP) [ISP-HEADER01]
 C8051F045@TQFP64 (ISP) [ISP-HEADER01]
 C8051F046@TQFP100 (ISP) [ISP-HEADER01]
 C8051F047@TQFP64 (ISP) [ISP-HEADER01]
 C8051F206@TQFP48 [(SA248)] C8051F220@TQFP48
 [(SA248)]
 C8051F221@TQFP32 [(SA663)] C8051F226@TQFP48
 [(SA248)]

C8051F230@TQFP48 [(SA248)]	C8051F231@TQFP32
[(SA663)]	
C8051F236@TQFP48 [(SA248)]	C8051F300
[(SA695A)]	
C8051F301 [(SA695A)]	C8051F302
[(SA695A)]	
C8051F303 [(SA695A)]	C8051F304
[(SA695A)]	
C8051F305 [(SA695A)]	C8051F310@TQFP32
[(SA663)]	
C8051F310-GQ@TQFP32 [(SA663)]	C8051F311@QFN28 [(SA697-
B006)]	
C8051F311-GM@QFN28 [(SA697-B006)]	
C8051F312@TQFP32 [(SA663)]	C8051F312-GQ@TQFP32
[(SA663)]	
C8051F313@QFN28 [(SA697-B006)]	
C8051F313-GM@QFN28 [(SA697-B006)]	
C8051F314@TQFP32 [(SA663)]	C8051F314-GQ@TQFP32
[(SA663)]	
C8051F315@QFN28 [(SA697-B006)]	
C8051F315-GM@QFN28 [(SA697-B006)]	
C8051F316-GM@QFN24 [(SA710-B006)]	
C8051F317-GM@QFN24 [(SA710-B006)]	
C8051F320@TQFP32 [(SA663)]	C8051F321@QFN28 [(SA697-
B006)]	
C8051F326@QFN28 [(SA697-B006)]	
C8051F326-GQ@QFN28 [(SA697-B006)]	
C8051F327@QFN28 [(SA697-B006)]	
C8051F327-GQ@QFN28 [(SA697-B006)]	
C8051F330@MLP20 [(SA692)]	
C8051F330D	
C8051F331@MLP20 [(SA692)]	C8051F332-GM@MLP20
[(SA692)]	
C8051F333-GM@MLP20 [(SA692)]	C8051F334-GM@MLP20
[(SA692)]	
C8051F335-GM@MLP20 [(SA692)]	C8051F336-GM@QFN20
[(SA692)]	
C8051F337-GM@QFN20 [(SA692)]	C8051F338-GM@QFN24
[(SA710)]	
C8051F339-GM@QFN24 [(SA710)]	C8051F340-GQ@TQFP48
[(SA248)]	
C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32
[(SA663)]	

C8051F343-GQ@LQFP32 [(SA663)] [(SA248)]	C8051F344-GQ@TQFP48
C8051F345-GQ@TQFP48 [(SA248)] [(SA663)]	C8051F346-GQ@LQFP32
C8051F347-GQ@LQFP32 [(SA663)] [(SA663)]	C8051F350-GQ@LQFP32
C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F360@QFP48 [(SA248)] [(SA663)]	C8051F361@QFP32
C8051F362@QFN28 [(SA697)] [(SA248)]	C8051F363@QFP48
C8051F364@QFP32 [(SA663)] [(SA697)]	C8051F365@QFN28
C8051F366@QFP32 [(SA663)] [(SA697)]	C8051F367@QFN28
C8051F368@QFP32 [(SA663)] [(SA697)]	C8051F369@QFN28
C8051F410-GQ@LQFP32 [ordering number is marked above]	
C8051F411-GM@QFN28 [ordering number is marked above]	
C8051F412-GQ@LQFP32 [ordering number is marked above]	
C8051F413-GM@QFN28 [ordering number is marked above]	
C8051F520-IM@QFN10 [(SA695A)] [(SA695A)]	C8051F521-IM@QFN10
C8051F523-IM@QFN10 [(SA695A)] [(SA695A)]	C8051F524-IM@QFN10
C8051F526-IM@QFN10 [(SA695A)] [(SA695A)]	C8051F527-IM@QFN10
C8051F530-IM@QFN20 [(SA692)] [(SA026)]	C8051F530-IT@TSSOP20
C8051F531-IM@QFN20 [(SA692)] [(SA026)]	C8051F531-IT@TSSOP20
C8051F533-IM@QFN20 [(SA692)] [(SA026)]	C8051F533-IT@TSSOP20
C8051F534-IM@QFN20 [(SA692)] [(SA026)]	C8051F534-IT@TSSOP20
C8051F536-IM@QFN20 [(SA692)] [(SA026)]	C8051F536-IT@TSSOP20
C8051F537-IM@QFN20 [(SA692)] [(SA026)]	C8051F537-IT@TSSOP20
C8051F610-GQ@QFP32 [(SA663)]	
C8051F611-GM@QFN28 [(SA697-B006)]	

C8051F612-GQ@QFP32 [(SA663)]	
C8051F613-GM@QFN28 [(SA697-B006)]	
C8051F614-GQ@QFP32 [(SA663)]	
C8051F615-GM@QFN28 [(SA697-B006)]	
C8051F616-GM@QFN24 [(SA710-B006)]	
C8051F617-GM@QFN24 [(SA710-B006)]	
C8051T600@QFN11 [(SA695A)]	C8051T600@SOIC14
[(SA602)]	
C8051T601@QFN11 [(SA695A)]	C8051T601@SOIC14
[(SA602)]	
C8051T602@SOIC14 [(SA602)]	C8051T603@SOIC14
[(SA602)]	
C8051T604@QFN11 [(SA695A)]	C8051T604@SOIC14
[(SA602)]	
C8051T605@QFN11 [(SA695A)]	C8051T605@SOIC14
[(SA602)]	
SI8250@LQFP32 [(SA663)]	SI8250@QFN28
[(SA697)]	
SI8251@LQFP32 [(SA663)]	SI8251@QFN28
[(SA697)]	
SI8252@LQFP32 [(SA663)]	SI8252@QFN28
[(SA697)]	

SILICON7

E (E) PROM / FRAM / NVRAM

SV4E1602UBA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E1602UTA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E1604UBA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E1604UTA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E1608UBA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E1608UTA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E3204UBA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E3204UTA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E3208UBA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E3208UTA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E3216UBA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4E3216UTA@FBGA56 [(SA642P-B079A-W056F001Y)]	
SV4F1602UBA@FBGA66 [(SA642R-B041A-T096F001Y)]	
SV4F1602UTA@FBGA66 [(SA642R-B041A-T096F001Y)]	
SV4F1604UBA@FBGA66 [(SA642R-B041A-T096F001Y)]	

SV4F1604UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1608UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1608UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3204UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3204UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3208UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3208UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3216UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F3216UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV5C2832UCR@FBGA72 [(SA642E-B052A-T072F001)]
SV5C3238UBA(NO EFP)@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV5C3238UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV5C3238UTA(NO EFP)@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV5C3238UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV5C6416UBB(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UBB@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UBR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UBR@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UTB(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UTB@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UTR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6416UTR@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6432UBR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5C6432UTR(NO EFP)@FBGA72 [(SA642E-B065A-T072F001)]
SV5D2832UCA@FBGA88 [(SA642A-B081A-Y096F001)]
SV6C2832UBA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C2832UTA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C6416UBA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C6416UTA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C6432UBA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6C6432UTA@FBGA72 [(SA642E-B023A-T072F001Y)]
SV6D2832UBA@FBGA88 [(SA642A-B124A-Y096F001Y)]
SV6D2832UTA@FBGA88 [(SA642A-B124A-Y096F001Y)]
SV7C1602UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1602UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1604UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1604UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1608UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C1608UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3204UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3204UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3208UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3208UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]

SV7C3216UBA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7C3216UTA@FBGA72 [(SA642A-B023A-Y096F001Y)]
SV7E1602UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1602UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1604UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1604UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1608UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E1608UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3204UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3204UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3208UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3208UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3216UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]
SV7E3216UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]

SIMTEK

E (E) PROM / FRAM / NVRAM

STK10C48
STK10C48@SOIC28(300 mil) [(SA404)]
STK10C48@SOIC28(350 mil) [(SA630)]
STK10C68 STK10C68@PLCC28
[(SA008A)]
STK10C68@SOIC28(350 mil) [(SA630)]
STK11C48
STK11C48@SOIC28(300 mil) [(SA404)]
STK11C48@SOIC28(350 mil) [(SA630)]
STK11C68 STK11C68@PLCC28
[(SA008A)]
STK11C68@SOIC28(350 mil) [(SA630)]
STK11C88 STK11C88
(3V)
STK11C88(3V)@SOIC28(300 mil) [(SA404)]
STK11C88(3V)@SOIC28(350 mil) [(SA630)]
STK11C88@SOIC28(300 mil) [(SA404)]
STK11C88@SOIC28(350 mil) [(SA630)]
STK12C68 STK12C68@PLCC28
[(SA008A)]
STK12C68@SOIC28(350 mil) [(SA630)]
STK14C88 STK14C88
(3V)

STK14C88(3V)@PLCC32 [(SA015A1T)]
STK14C88(3V)@SOIC32(300 mil) [(SA715)]
STK14C88(3V)@SOIC32(350 mil) [(SA630)]
STK14C88@PLCC32 [(SA015A1T)]
STK14C88@SOIC32(300 mil) [(SA715)]
STK14C88@SOIC32(350 mil) [(SA630)]
STK14CA8
[(SA715)]
STK14CA8@SSOP48 [(SA669)]
[(SA715)]
STK14D88@SSOP48 [(SA669)]
STK15C68
STK15C68@SOIC28(350 mil) [(SA630)]
STK15C88
STK15C88@SOIC28(300 mil) [(SA404)]
STK15C88@SOIC28(350 mil) [(SA630)]
STK16C68
STK16C88
STK16C88(3V)
STK16CA8
STK20C04
STK22C48
STK22C48@SOIC28(300 mil) [(SA404)]
STK22C48@SOIC28(350 mil) [(SA630)]
STK25C48

STK14CA8@SOIC32

STK14D88@SOIC32

SMOS

E (E) PROM / FRAM / NVRAM

SPM27128
SPM27128C
SPM27C256
SPM27C64
SPM27C64H

SONIX

MICROCONTROLLER

SN8P1504	SN8P1504@SOP18
[(SA404)]	
SN8P1504@SOP28 [(SA404)]	
SN8P1506	
SN8P1507@TQFP44 [(SA245A)]	
SN8P1602	
SN8P1602@SOP18 [(SA404)]	SN8P1602@SSOP20 [(SA674-B005)]
B005)]	
SN8P1603	SN8P1603@SOP18
[(SA404)]	
SN8P1603@SSOP20 [(SA674-B005)]	
SN8P1604	
SN8P1604@SOP28 [(SA404)]	
SN8P1702	
SN8P1702@SOP18 [(SA404)]	SN8P1702@SSOP20 [(SA674-B005)]
B005)]	
SN8P1704A	SN8P1704A@SOP28
[(SA404)]	
SN8P1704B	SN8P1704B@SOP28
[(SA404)]	
SN8P1706A	
SN8P1706B	
SN8P1707A	SN8P1707A@TQFP44
[(SA245A)]	
SN8P1707B@TQFP44 [(SA245A)]	
SN8P1708A	
SN8P1708A@SSOP48 [(SA669)]	
SN8P1708B	
SN8P1708B@SSOP48 [(SA669)]	
SN8P1714	
SN8P1714@SOP18 [(SA404)]	SN8P1714@SOP28
[(SA404)]	
SN8P1716	SN8P1717@TQFP44
[(SA245A)]	
SN8P2501AP	SN8P2501AS@SOP14
[(SA602)]	
SN8P2501AX@TSSOP16 [(SA026)]	
SN8P2501BP	
SN8P2501BS@SOP14 [(SA602)]	SN8P2501BX@TSSOP16
[(SA026)]	
SN8P2602AP	SN8P2602AS@SOP18
[(SA023A)]	
SN8P2602AX@SSOP20 [(SA674)]	

SN8P2602BP	
SN8P2602BS@SOP18 [(SA023A)]	SN8P2602BX@SSOP20
[(SA674)]	
SN8P2603AP	SN8P2603AS@SOP18
[(SA023A)]	
SN8P2603AX@SSOP20 [(SA674)]	
SN8P2603BP	
SN8P2603BS@SOP18 [(SA023A)]	SN8P2603BX@SSOP20
[(SA674)]	
SN8P26042AP	SN8P26042AS@SOP20
[(SA023A)]	
SN8P26042AX@SSOP20 [(SA674)]	
SN8P26042BP	
SN8P26042BS@SOP20 [(SA023A)]	SN8P26042BX@SSOP20
[(SA674)]	
SN8P26042P	SN8P26042S@SOP20
[(SA023A)]	
SN8P26042X@SSOP20 [(SA674)]	
SN8P2604AK	
SN8P2604AS@SOP28 [(SA404)]	SN8P2604AX@SSOP28
[(SA626A)]	
SN8P2604BK	SN8P2604BS@SOP28
[(SA404)]	
SN8P2604BX@SSOP28 [(SA626A)]	
SN8P2604K	
SN8P2604S@SOP28 [(SA404)]	SN8P2604X@SSOP28
[(SA626A)]	
SN8P2606P	
SN8P2608P	
SN8P2608X@SSOP48 [(SA669)]	
SN8P2622P	
SN8P2622S@SOP18 [(SA023A)]	SN8P2622X@SSOP20
[(SA674)]	
SN8P2624K	SN8P2624S@SOP28
[(SA404)]	
SN8P2624X@SSOP28 [(SA626A)]	SN8P2704AK@SDIP28
[(SA653)]	
SN8P2704AP	SN8P2704AS@SOP28
[(SA723)]	
SN8P2705AP	SN8P2705AS@SOP32
[(SA687)]	
SN8P2706AP	SN8P2707AQ@QFP44
[(SA245A)]	

SN8P2708AP	SN8P2708AQ@LQFP48
[(SA248)]	
SN8P2708AX@TSOP48 [(SA669)]	
SN8P2722P	
SN8P2722S@SOP20 [(SA023A)]	SN8P2722X@SSOP20
[(SA674)]	

SONY

E (E) PROM / FRAM / NVRAM

CXK1011M@SOIC8 [(SA602A)]
CXK1011P
CXK1012P
CXK1013P
CXK1023P
CXK27C4001

DRAM & SRAM

CXK581000	CXK581000@SOIC32
[(SA630)]	

SPACE ELECTRONICS[SEi]

E (E) PROM / FRAM / NVRAM

28C010	28C010@PLCC32
[(SA015A1T)]	
28C010@TSOP32 [(SA410T)]	
28C010T	
28C010T@PLCC32 [(SA015A1T)]	28C010T@TSOP32
[(SA410T)]	
28C011	28C011@PLCC32
[(SA015A1T)]	
28C011@TSOP32 [(SA410T)]	
28C011T	
28C011T@PLCC32 [(SA015A1T)]	28C011T@TSOP32
[(SA410T)]	

SPANSION

E (E) PROM / FRAM / NVRAM

AM29BL162CB@SSOP56 [(SA629A-B022)]
AM29BL802CB@SSOP56 [(SA629A-B022)]
AM29DL161DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL161DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL161DB@TSOP48 [(SA247-B005)]
AM29DL161DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL161DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL161DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL161DT@TSOP48 [(SA247-B005)]
AM29DL161DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CB@TSOP48 [(SA247-B005)]
AM29DL162CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162CT@TSOP48 [(SA247-B005)]
AM29DL162DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL162DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL162DB@TSOP48 [(SA247-B005)]
AM29DL162DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL162DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL162DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL162DT@TSOP48 [(SA247-B005)]
AM29DL162DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CB@TSOP48 [(SA247-B005)]
AM29DL163CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163CT@TSOP48 [(SA247-B005)]
AM29DL163DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL163DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL163DB@TSOP48 [(SA247-B005)]
AM29DL163DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL163DT@FBGA63 [(SA642C-B026A-Y056F001)]

AM29DL163DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL163DT@TSOP48 [(SA247-B005)]
AM29DL163DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164CB@TSOP48 [(SA247-B005)]
AM29DL164CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164CT@TSOP48 [(SA247-B005)]
AM29DL164DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164DB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL164DB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL164DB@TSOP48 [(SA247-B005)]
AM29DL164DB@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL164DT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL164DT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL164DT@TSOP48 [(SA247-B005)]
AM29DL164DT@VFBGA48 [(SA642B-B026A-Y072F001)]
AM29DL320GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL320GB@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL320GB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL320GB@TSOP48 [(SA247-B005)]
AM29DL320GT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL320GT@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL320GT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL320GT@TSOP48 [(SA247-B005)]
AM29DL321CB@TSOP48 [(SA247-B005)]
AM29DL321CT@TSOP48 [(SA247-B005)]
AM29DL322CB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322CB@TSOP48 [(SA247-B005)]
AM29DL322CT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322CT@TSOP48 [(SA247-B005)]
AM29DL322DB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322DB@TSOP48 [(SA247-B005)]
AM29DL322DT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL322DT@TSOP48 [(SA247-B005)]
AM29DL322GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL322GB@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL322GB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL322GB@TSOP48 [(SA247-B005)]
AM29DL322GT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL322GT@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL322GT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL322GT@TSOP48 [(SA247-B005)]

AM29DL323CB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL323CB@TSOP48 [(SA247-B005)]
AM29DL323CT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL323CT@TSOP48 [(SA247-B005)]
AM29DL323DB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL323DB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL323DB@TSOP48 [(SA247-B005)]
AM29DL323DT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL323DT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL323DT@TSOP48 [(SA247-B005)]
AM29DL323GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL323GB@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL323GB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL323GB@TSOP48 [(SA247-B005)]
AM29DL323GT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL323GT@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL323GT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL323GT@TSOP48 [(SA247-B005)]
AM29DL324CB@TSOP48 [(SA247-B005)]
AM29DL324CT@TSOP48 [(SA247-B005)]
AM29DL324DB@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL324DB@TSOP48 [(SA247-B005)]
AM29DL324DT@FBGA63 [(SA642E-B026A-T056N001)]
AM29DL324DT@TSOP48 [(SA247-B005)]
AM29DL324GB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL324GB@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL324GB@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL324GB@TSOP48 [(SA247-B005)]
AM29DL324GT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29DL324GT@FBGA63 [(SA642A-B026A-Y096F001)]
AM29DL324GT@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL324GT@TSOP48 [(SA247-B005)]
AM29DL400BB@PSOP44 [(SA638-B006)]
AM29DL400BB@TSOP48 [(SA247-B005)]
AM29DL400BT@PLCC44 [(SA638-B006)]
AM29DL400BT@TSOP48 [(SA247-B005)]
AM29DL640D@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL640D@TSOP48 [(SA247-B005)]
AM29DL640G@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL640G@FBGA64 [(SA655A-B044A-T064N001)]
AM29DL640G@TSOP48 [(SA247-B005)]
AM29DL642G@FBGA63 [(SA642C-B026A-Y056F001)]
AM29DL800B@PSOP44 [(SA638-B006)] AM29DL800B@TSOP48 [(SA247-

B005)]
 AM29DL800BB@FBGA48 [(SA642N-B026A-W048F001Y)]
 AM29DL800BB@PSOP44 [(SA638)]
 AM29DL800BB@TSOP48 [(SA247-B005)]
 AM29DL800BT@FBGA48 [(SA642N-B026A-W048F001Y)]
 AM29DL800BT@PSOP44 [(SA638)]
 AM29DL800BT@TSOP48 [(SA247-B005)]
 AM29DL800T@PSOP44 [(SA638-B006)] AM29DL800T@TSOP48 [(SA247-B005)]
 AM29DS163CB@TSOP48 [(SA247-B005)]
 AM29DS163CT@TSOP48 [(SA247-B005)]
 AM29DS163DB@FBGA48 [(SA642B-B026A-Y072F001)]
 AM29DS163DB@TSOP48 [(SA247-B005)]
 AM29DS163DT@FBGA48 [(SA642B-B026A-Y072F001)]
 AM29DS163DT@TSOP48 [(SA247-B005)]
 AM29DS323DB@FBGA48 [(SA642B-B026A-Y072F001)]
 AM29DS323DB@TSOP48 [(SA247-B005)]
 AM29DS323DT@FBGA48 [(SA642B-B026A-Y072F001)]
 AM29DS323DT@TSOP48 [(SA247-B005)]
 AM29F002B AM29F002B@PLCC32
 [(SA015A1T)]
 AM29F002B@TSOP32 [(SA410T)]
 AM29F002BB
 AM29F002BB@PLCC32 [(SA015A1T)] AM29F002BB@TSOP32
 [(SA410T)]
 AM29F002BT AM29F002BT@PLCC32
 [(SA015A1T)]
 AM29F002BT@TSOP32 [(SA410T)]
 AM29F002NB
 AM29F002NB@PLCC32 [(SA015A1T)] AM29F002NB@TSOP32
 [(SA410T)]
 AM29F002NBB AM29F002NBB@PLCC32
 [(SA015A1T)]
 AM29F002NBB@TSOP32 [(SA410T)]
 AM29F002NBT
 AM29F002NBT@PLCC32 [(SA015A1T)] AM29F002NBT@TSOP32
 [(SA410T)]
 AM29F002NT AM29F002NT@PLCC32
 [(SA015A1T)]
 AM29F002NT@TSOP32 [(SA410T)]
 AM29F002T
 AM29F002T@PLCC32 [(SA015A1T)] AM29F002T@TSOP32
 [(SA410T)]

AM29F004BB@PLCC32 [(SA015A1T)]	AM29F004BB@TSOP32
[(SA410T)]	
AM29F004BT@PLCC32 [(SA015A1T)]	AM29F004BT@TSOP32
[(SA410T)]	
AM29F010	AM29F010@PLCC32
[(SA015A1T)]	
AM29F010@TSOP32 [(SA410T)]	
AM29F010A	
AM29F010A@PLCC32 [(SA015A1T)]	AM29F010A@TSOP32
[(SA410T)]	
AM29F010B	AM29F010B@PLCC32
[(SA015A1T)]	
AM29F010B@TSOP32 [(SA410T)]	AM29F016@PSOP44
[(SA638)]	
AM29F016@TSOP40 [(SA409T)]	AM29F016@TSOP48 [(SA247-
B005)]	
AM29F016B@PSOP44 [(SA638)]	AM29F016B@TSOP40
[(SA409T)]	
AM29F016B@TSOP48 [(SA247-B005)]	
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016D@PSOP44 [(SA638)]	AM29F016D@TSOP40
[(SA409T)]	
AM29F016D@TSOP48 [(SA247-B005)]	AM29F017B@TSOP48 [(SA247-
B005)]	
AM29F017D@TSOP40 [(SA409T)]	AM29F017D@TSOP48 [(SA247-
B005)]	
AM29F032B@PSOP44 [(SA638)]	AM29F032B@TSOP40
[(SA409T)]	
AM29F040	AM29F040@PLCC32
[(SA015A1T)]	
AM29F040@TSOP32 [(SA410T)]	
AM29F040A	
AM29F040A@PLCC32 [(SA015A1T)]	AM29F040A@TSOP32
[(SA410T)]	
AM29F040B	
AM29F040B(Reverse)@TSOP32 [(SA410T)]	
AM29F040B@PLCC32 [(SA015A1T)]	AM29F040B@TSOP32
[(SA410T)]	
AM29F080@PSOP44 [(SA638)]	AM29F080@TSOP40
[(SA409T)]	
AM29F080B@PSOP44 [(SA638)]	AM29F080B@TSOP40
[(SA409T)]	
AM29F100BE@PSOP44 [(SA638-B006)]	AM29F100BE@TSOP48 [(SA247-

B005)]
AM29F100BS@PSOP44 [(SA638-B006)] AM29F100BS@TSOP48 [(SA247-B005)]
AM29F100TE@PSOP44 [(SA638-B006)] AM29F100TE@TSOP48 [(SA247-B005)]
AM29F100TS@PSOP44 [(SA638-B006)] AM29F100TS@TSOP48 [(SA247-B005)]
AM29F160DB@TSOP48 [(SA247-B005)] AM29F160DT@TSOP48 [(SA247-B005)]
AM29F200AB@PSOP44 [(SA638-B006)] AM29F200AB@TSOP48 [(SA247-B005)]
AM29F200AT@PSOP44 [(SA638-B006)] AM29F200AT@TSOP48 [(SA247-B005)]
AM29F200BB@PSOP44 [(SA638-B006)] AM29F200BB@TSOP48 [(SA247-B005)]
AM29F200BE@PSOP44 [(SA638-B006)] AM29F200BE@TSOP48 [(SA247-B005)]
AM29F200BS@PSOP44 [(SA638-B006)] AM29F200BS@TSOP48 [(SA247-B005)]
AM29F200BT@PSOP44 [(SA638-B006)] AM29F200BT@TSOP48 [(SA247-B005)]
AM29F200TE@PSOP44 [(SA638-B006)] AM29F200TE@TSOP48 [(SA247-B005)]
AM29F200TS@PSOP44 [(SA638-B006)] AM29F200TS@TSOP48 [(SA247-B005)]
AM29F400AB@PSOP44 [(SA638-B006)] AM29F400AB@TSOP48 [(SA247-B005)]
AM29F400AT@PSOP44 [(SA638-B006)] AM29F400AT@TSOP48 [(SA247-B005)]
AM29F400BB@PSOP44 [(SA638-B006)] AM29F400BB@TSOP48 [(SA247-B005)]
AM29F400BBE@PSOP44 [(SA638-B006)]
AM29F400BBE@TSOP48 [(SA247-B005)]
AM29F400BBF@PSOP44 [(SA638-B006)]
AM29F400BBF@TSOP48 [(SA247-B005)]
AM29F400BBS@PSOP44 [(SA638-B006)]
AM29F400BBS@TSOP48 [(SA247-B005)]
AM29F400BE@PSOP44 [(SA638-B006)] AM29F400BE@TSOP48 [(SA247-B005)]
AM29F400BF@PSOP44 [(SA638-B006)] AM29F400BF@TSOP48 [(SA247-B005)]
AM29F400BS@PSOP44 [(SA638-B006)] AM29F400BS@TSOP48 [(SA247-B005)]

AM29F400BT@PSOP44 [(SA638-B006)]	AM29F400BT@TSOP48 [(SA247-B005)]
AM29F400BTE@PSOP44 [(SA638-B006)]	
AM29F400BTE@TSOP48 [(SA247-B005)]	
AM29F400BTF@PSOP44 [(SA638-B006)]	
AM29F400BTF@TSOP48 [(SA247-B005)]	
AM29F400BTS@PSOP44 [(SA638-B006)]	
AM29F400BTS@TSOP48 [(SA247-B005)]	
AM29F800B@PSOP44 [(SA638-B006)]	AM29F800B@TSOP48 [(SA247-B005)]
AM29F800BB@PSOP44 [(SA638-B006)]	AM29F800BB@TSOP48 [(SA247-B005)]
AM29F800BBF@PSOP44 [(SA638-B006)]	
AM29F800BBF@TSOP48 [(SA247-B005)]	
AM29F800BF@PSOP44 [(SA638-B006)]	AM29F800BF@TSOP48 [(SA247-B005)]
AM29F800BT@PSOP44 [(SA638-B006)]	AM29F800BT@TSOP48 [(SA247-B005)]
AM29F800BTF@PSOP44 [(SA638-B006)]	
AM29F800BTF@TSOP48 [(SA247-B005)]	
AM29F800T@PSOP44 [(SA638-B006)]	AM29F800T@TSOP48 [(SA247-B005)]
AM29F800TB@PSOP44 [(SA638-B006)]	AM29F800TB@TSOP48 [(SA247-B005)]
AM29F800TF@PSOP44 [(SA638-B006)]	AM29F800TF@TSOP48 [(SA247-B005)]
AM29LL800B@TSOP48 [(SA247-B005)]	
AM29LL800BB@TSOP48 [(SA247-B005)]	
AM29LL800BT@TSOP48 [(SA247-B005)]	
AM29LL800T@TSOP48 [(SA247-B005)]	AM29LV001BB@PLCC32
[(SA015A1T)]	
AM29LV001BB@TSOP32 [(SA410T)]	AM29LV001BT@PLCC32
[(SA015A1T)]	
AM29LV001BT@TSOP32 [(SA410T)]	AM29LV002@TSOP40
[(SA409T)]	
AM29LV002B@TSOP40 [(SA409T)]	AM29LV002BB@TSOP40
[(SA409T)]	
AM29LV002BT@TSOP40 [(SA409T)]	AM29LV004B@PSOP44
[(SA638)]	
AM29LV004B@TSOP40 [(SA409T)]	AM29LV004BB@TSOP40
[(SA409T)]	
AM29LV004BT@TSOP40 [(SA409T)]	AM29LV004T@PSOP44
[(SA638)]	

AM29LV004T@TSOP40 [(SA409T)] AM29LV008B@PSOP44
[(SA638)]
AM29LV008B@TSOP40 [(SA409T)] AM29LV008BB@TSOP40
[(SA409T)]
AM29LV008BT@TSOP40 [(SA409T)] AM29LV008T@PSOP44
[(SA638)]
AM29LV008T@TSOP40 [(SA409T)] AM29LV010B@PLCC32
[(SA015A1T)]
AM29LV010B@TSOP32 [(SA410T)] AM29LV017B@TSOP40
[(SA409T)]
AM29LV017D@FBGA48 [(SA642B-B026A-Y072F001)]
AM29LV017D@TSOP40 [(SA409T)] AM29LV020B@PLCC32
[(SA015A1T)]
AM29LV020B@TSOP32 [(SA410T)]
AM29LV033C@FBGA63 [(SA642A-B026A-Y096N001)]
AM29LV033C@TSOP40 [(SA409T)]
AM29LV033MU@FBGA48 [(SA642B-B026A-Y072F001)]
AM29LV033MU@TSOP40 [(SA409T)] AM29LV040B@PLCC32
[(SA015A1T)]
AM29LV040B@TSOP32 [(SA410T)] AM29LV040E@PLCC32
[(SA015A1T)]
AM29LV040E@TSOP32 [(SA410T)] AM29LV040J@PLCC32
[(SA015A1T)]
AM29LV040J@TSOP32 [(SA410T)]
AM29LV065D@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV065D@TSOP48 [(SA247-B005)]
AM29LV065MU@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV065MU@TSOP48 [(SA247-B005)]
AM29LV080@TSOP40 [(SA409T)] AM29LV081@TSOP40
[(SA409T)]
AM29LV081B@TSOP40 [(SA409T)] AM29LV116BB@TSOP40
[(SA409T)]
AM29LV116BT@TSOP40 [(SA409T)] AM29LV116DB@TSOP40
[(SA409T)]
AM29LV116DT@TSOP40 [(SA409T)]
AM29LV128MH@FBGA64 [(SA655F-B099A-W064F001Y)]
AM29LV128MH@TSOP56 [(SA628-B067)]
AM29LV128ML@FBGA64 [(SA655F-B099A-W064F001Y)]
AM29LV128ML@TSOP56 [(SA628-B067)]
AM29LV160BB@FBGA48 [(SA642B-B026A-Y072F001N)]
AM29LV160BB@PSOP44 [(SA638)]
AM29LV160BB@TSOP48 [(SA247-B005)]
AM29LV160BT@FBGA48 [(SA642B-B026A-Y072F001N)]

AM29LV160BT@PSOP44 [(SA638)]
AM29LV160BT@TSOP48 [(SA247-B005)]
AM29LV160DB(REVERSE)@TSOP48 [(SA247-B005)]
AM29LV160DB@FBGA48 [(SA642B-B026A-Y072F001N)]
AM29LV160DB@PSOP44 [(SA638)]
AM29LV160DB@TSOP48 [(SA247-B005)]
AM29LV160DT(REVERSE)@TSOP48 [(SA247-B005)]
AM29LV160DT@FBGA48 [(SA642B-B026A-Y072F001N)]
AM29LV160DT@PSOP44 [(SA638)]
AM29LV160DT@TSOP48 [(SA247-B005)]
AM29LV160MB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29LV160MB@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV160MB@PSOP44 [(SA638)]
AM29LV160MB@TSOP48 [(SA247-B005)]
AM29LV160MT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29LV160MT@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV160MT@PSOP44 [(SA638)]
AM29LV160MT@TSOP48 [(SA247-B005)]
AM29LV200B@PSOP44 [(SA638-B006)] AM29LV200B@TSOP48 [(SA247-B005)]
AM29LV200BB@PSOP44 [(SA638-B006)]
AM29LV200BB@TSOP48 [(SA247-B005)]
AM29LV200BE@PSOP44 [(SA638-B006)]
AM29LV200BE@TSOP48 [(SA247-B005)]
AM29LV200BF@PSOP44 [(SA638-B006)]
AM29LV200BF@TSOP48 [(SA247-B005)]
AM29LV200BS@PSOP44 [(SA638-B006)]
AM29LV200BS@TSOP48 [(SA247-B005)]
AM29LV200BT@PSOP44 [(SA638-B006)]
AM29LV200BT@TSOP48 [(SA247-B005)]
AM29LV200T@PSOP44 [(SA638-B006)] AM29LV200T@TSOP48 [(SA247-B005)]
AM29LV200TE@PSOP44 [(SA638-B006)]
AM29LV200TE@TSOP48 [(SA247-B005)]
AM29LV200TF@PSOP44 [(SA638-B006)]
AM29LV200TF@TSOP48 [(SA247-B005)]
AM29LV200TS@PSOP44 [(SA638-B006)]
AM29LV200TS@TSOP48 [(SA247-B005)]
AM29LV256MH@FBGA64 [(SA655F-B099A-W064F001Y)]
AM29LV256MH@TSOP56 [(SA628-B067)]
AM29LV256ML@FBGA64 [(SA655F-B099A-W064F001Y)]
AM29LV256ML@TSOP56 [(SA628-B067)]
AM29LV320DB@FBGA48 [(SA642E-B026A-T072F001)]

AM29LV320DB@TSOP48 [(SA247-B005)]
AM29LV320DT@FBGA48 [(SA642E-B026A-T072F001)]
AM29LV320DT@TSOP48 [(SA247-B005)]
AM29LV320FB@TSOP48 [(SA247-B005)]
AM29LV320FT@TSOP48 [(SA247-B005)]
AM29LV320MB@FBGA48 [(SA642F-B026A-T064F001)]
AM29LV320MB@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV320MB@TSOP48 [(SA247-B005)]
AM29LV320MH@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV320MH@TSOP56 [(SA628-B067)]
AM29LV320ML@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV320ML@TSOP56 [(SA628-B067)]
AM29LV320MT@FBGA48 [(SA642F-B026A-T064F001)]
AM29LV320MT@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV320MT@TSOP48 [(SA247-B005)]
AM29LV400B@PSOP44 [(SA638-B006)] AM29LV400B@TSOP48 [(SA247-B005)]
AM29LV400BB@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BB@PSOP44 [(SA638-B006)]
AM29LV400BB@TSOP48 [(SA247-B005)]
AM29LV400BT@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29LV400BT@PSOP44 [(SA638-B006)]
AM29LV400BT@TSOP48 [(SA247-B005)]
AM29LV400T@PSOP44 [(SA638-B006)] AM29LV400T@TSOP48 [(SA247-B005)]
AM29LV640DH@SSOP56 [(SA629A-B020)]
AM29LV640DL@SSOP56 [(SA629A-B020)]
AM29LV640DU@FBGA63 [(SA642M-B026A-W048F001Y)]
AM29LV640DU@FBGA64 [(SA655D-B044A-W064F001)]
AM29LV640GU@FBGA63 [(SA642M-B026A-W048F001Y)]
AM29LV640GU@FBGA64 [(SA655D-B044A-W064F001)]
AM29LV640MB@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV640MB@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV640MB@TSOP48 [(SA247-B005)]
AM29LV640MH@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV640MH@TSOP56 [(SA628-B067)]
AM29LV640ML@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV640ML@TSOP56 [(SA628-B067)]
AM29LV640MT@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV640MT@FBGA64 [(SA655A-B044A-T064N001)]
AM29LV640MT@TSOP48 [(SA247-B005)]
AM29LV640MU@FBGA63 [(SA642C-B026A-Y056F001)]
AM29LV640MU@FBGA64 [(SA655A-B044A-T064N001)]

AM29LV641DH@TSOP48 [(SA247-B005)]
AM29LV641DHR@TSOP48 [(SA247-B005)]
AM29LV641DL@TSOP48 [(SA247-B005)]
AM29LV641DLR@TSOP48 [(SA247-B005)]
AM29LV641GH@TSOP48 [(SA247-B005)]
AM29LV641GHR@TSOP48 [(SA247-B005)]
AM29LV641GL@TSOP48 [(SA247-B005)]
AM29LV641GLR@TSOP48 [(SA247-B005)]
AM29LV641MH@TSOP48 [(SA247-B005)]
AM29LV641ML@TSOP48 [(SA247-B005)]
AM29LV642G@FBGA64 [(SA655A-B038A-T064N001)]
AM29LV652D@FBGA63 [(SA642M-B026A-W048F001Y)]
AM29LV800B@PSOP44 [(SA638-B006)] AM29LV800B@TSOP48 [(SA247-B005)]
AM29LV800BB@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800BB@PSOP44 [(SA638-B006)]
AM29LV800BB@TSOP48 [(SA247-B005)]
AM29LV800BT@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800BT@PSOP44 [(SA638-B006)]
AM29LV800BT@TSOP48 [(SA247-B005)]
AM29LV800DB(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800DB(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29LV800DB@PSOP44 [(SA638)]
AM29LV800DB@TSOP48 [(SA247-B005)]
AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]
AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29LV800DT@PSOP44 [(SA638)]
AM29LV800DT@TSOP48 [(SA247-B005)]
AM29LV800T@PSOP44 [(SA638-B006)] AM29LV800T@TSOP48 [(SA247-B005)]
AM29PDS322DB@FBGA48 [(SA642E-B026A-T072F001)]
AM29PDS322DT@FBGA48 [(SA642E-B026A-T072F001)]
AM29PL160CB@PSOP44 [(SA638-B006)]
AM29PL160CB@TSOP48 [(SA247-B005)]
AM29PL160CT@PSOP44 [(SA638-B006)]
AM29PL160CT@TSOP48 [(SA247-B005)]
AM29SL160CB@FBGA48 [(SA642B-B026A-Y072F001)]
AM29SL160CB@TSOP48 [(SA247-B005)]
AM29SL160CT@FBGA48 [(SA642B-B026A-Y072F001)]
AM29SL160CT@TSOP48 [(SA247-B005)]
AM29SL400CB@TSOP48 [(SA247-B005)]
AM29SL400CT@TSOP48 [(SA247-B005)]
AM29SL800BB@TSOP48 [(SA247-B005)]

AM29SL800BT@TSOP48 [(SA247-B005)]
AM29SL800CB@TSOP48 [(SA247-B005)]
AM29SL800CT@TSOP48 [(SA247-B005)]
AM29SL800DB@TSOP48 [(SA247-B005)]
AM29SL800DBUF@FBGA48 [(SA716A-B119B-M048F001Y)]
AM29SL800DBVG@FBGA48 [(SA716A-B119B-M048F001Y)]
AM29SL800DBVU@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29SL800DBWA@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29SL800DBWC@FBGA48 [(SA642R-B026A-W080F001N)]
AM29SL800DT@TSOP48 [(SA247-B005)]
AM29SL800DTUF@FBGA48 [(SA716A-B119B-M048F001Y)]
AM29SL800DTVG@FBGA48 [(SA716A-B119B-M048F001Y)]
AM29SL800DTVU@FBGA48 [(SA642Z-B026A-W048F001Y)]
AM29SL800DTWA@FBGA48 [(SA642G-B026A-T048F001Y)]
AM29SL800DTWC@FBGA48 [(SA642R-B026A-W080F001N)]
DS42514 (AM29DL163DB)@FBGA69 [(SA642B-B032A-Y072F001)]
DS42515 (AM29DL164)@FBGA69 [(SA642B-B032A-Y072F001)]
DS42516 (AM29DL324)@FBGA73 [(SA642A-B032A-Y096F001)]
DS42546 (AM29DL163)@FBGA69 [(SA642B-B032A-Y072F001)]
DS42553 (AM29DL323)@FBGA73 [(SA642A-B032A-Y096F001)]
DS42585 (AM29DL323D)@FBGA73 [(SA642A-B032A-Y096F001)]
DS42587 (AM29DL324D)@FBGA73 [(SA642A-B032A-Y096F001)]
DS42629 (AM29DL640G)@VFBGA48 [(SA634A-B005A-Y048F001)]
DS42677 (AM29LV128MH/L)@FBGA88 [(SA642A-B058A-Y096N001)]
DS42678 (AM29LV320MT)@FBGA67 [(SA642E-B041A-T072F001)]
DS42689 (AM29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
DS42690 (AM29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]
DS42695 (AM29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
DS42696 (AM29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]
DS42701 (AM29LV640MU)@FBGA88 [(SA642W-B116A-W088F001Y)]
DS42725 (AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]
DS42772A (AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]
M420000070 (AM42BDS6408HE8)@BGA89 [(SA642A-B072A-Y096F001)]
M420000071 (AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]
M420000072 (AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]
M420000073 (AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]
M420000074 (AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]
M420000075 (AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]
M420000076 (AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]
M420000077 (AM42BDS6408HD4)@BGA89 [(SA642A-B072A-Y096F001)]
M490000030 (AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M490000031 (AM49PDL129BH)@FBGA73 [(SA642A-B039A-Y096F001)]
M4900000K (AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]

M4900000L(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]
MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21082@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21082EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21083@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21083EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21084@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21084EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21091@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21091EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21092@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21092EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21093@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21093EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21094@FBGA61 [(SA642C-B032A-Y056F001)]
MB84VD21094EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21181DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21181EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21181EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21182DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21182EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21182EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21183DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21183EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21183EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21184DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21184EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21184EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21191DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21191EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21191EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21192DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21192EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21192EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21193DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21193EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21193EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21194DA@FBGA69 [(SA642C-B032A-Y056F001)]
MB84VD21194EG@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD21194EM@FBGA56 [(SA642C-B032A-Y056F001)]
MB84VD22180FA@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22180FM@FBGA59 [(SA642F-B032A-T064F001)]

MB84VD22181A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22181EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22181EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22181FM@FBGA56 [(SA642F-B032A-T064F001)]
MB84VD22182A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22182EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22182EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22183A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22183EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22183EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22184A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22184EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22184EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22184FM@FBGA56 [(SA642E-B032A-T072F001)]
MB84VD22190FA@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22190FM@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22191A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22191EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22191EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22191FM@FBGA56 [(SA642F-B032A-T064F001)]
MB84VD22192A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22192EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22192EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22193A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22193EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22193EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22194A@FBGA77 [(SA642A-B032A-Y096N001)]
MB84VD22194EC@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22194EE@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD22194FM@FBGA56 [(SA642E-B032A-T072F001)]
MB84VD22280FE@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22282EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22283EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22284EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22290FM@FBGA59 [(SA642F-B032A-T064F001)]
MB84VD22292EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22293EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22294EE@FBGA71 [(SA642E-B032A-T072F001)]
MB84VD22386EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22387EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22388EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22396EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD22397EJ@FBGA71 [(SA642F-B032A-T064F001)]

MB84VD22398EJ@FBGA71 [(SA642F-B032A-T064F001)]
MB84VD23180FM@FBGA73 [(SA642A-B032A-Y096F001)]
MB84VD23280EA@FBGA101 [(SA642A-B032A-Y096N001)]
MB84VD23280EE@FBGA101 [(SA642A-B032A-Y096N001)]
MB84VD23280FA@FBGA65 [(SA642A-B032A-Y096N001)]
MB84VD23381EJ@FBGA101 [(SA642A-B032A-Y096N001)]
MB84VD23381FJ@FBGA65 [(SA642A-B032A-Y096N001)]
MB84VD23381HJ@FBGA56 [(SA642F-B032A-T064F001)]
MB84VD23481FJ@FBGA65 [(SA642A-B032A-Y096N001)]
MB84VF5F5FF4J2@BGA107 [(SA642D-B062A-Y088F001)]
MB84VP23481FK@FBGA65 [(SA642JJ-B032A-W064F001Y)]
MB84VP24481HK@FBGA73 [(SA642A-B039A-Y096F001)]
MB84VP24491HK@FBGA73 [(SA642A-B039A-Y096F001)]
MBM29DL161BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL161BD@TSOP48 [(SA247-B005)]
MBM29DL161BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL161TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL161TD@TSOP48 [(SA247-B005)]
MBM29DL161TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162BD@TSOP48 [(SA247-B005)]
MBM29DL162BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162BE@TSOP48 [(SA247-B005)]
MBM29DL162TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162TD@TSOP48 [(SA247-B005)]
MBM29DL162TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL162TE@TSOP48 [(SA247-B005)]
MBM29DL163BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163BD@TSOP48 [(SA247-B005)]
MBM29DL163BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163BE@TSOP48 [(SA247-B005)]
MBM29DL163TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163TD@TSOP48 [(SA247-B005)]
MBM29DL163TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL163TE@TSOP48 [(SA247-B005)]
MBM29DL164BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164BD@TSOP48 [(SA247-B005)]
MBM29DL164BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164BE@TSOP48 [(SA247-B005)]
MBM29DL164TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164TD@TSOP48 [(SA247-B005)]
MBM29DL164TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL164TE@TSOP48 [(SA247-B005)]

MBM29DL320BF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL320BF@TSOP48 [(SA247-B005)]
MBM29DL320TF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL320TF@TSOP48 [(SA247-B005)]
MBM29DL321BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL321BD@TSOP48 [(SA247-B005)]
MBM29DL321BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL321TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL321TD@TSOP48 [(SA247-B005)]
MBM29DL321TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL322BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL322BD@TSOP48 [(SA247-B005)]
MBM29DL322BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL322BE@TSOP48 [(SA247-B005)]
MBM29DL322TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL322TD@TSOP48 [(SA247-B005)]
MBM29DL322TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL322TE@TSOP48 [(SA247-B005)]
MBM29DL323BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL323BD@TSOP48 [(SA247-B005)]
MBM29DL323BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL323BE@TSOP48 [(SA247-B005)]
MBM29DL323BF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL323BF@TSOP48 [(SA247-B005)]
MBM29DL323TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL323TD@TSOP48 [(SA247-B005)]
MBM29DL323TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL323TE@TSOP48 [(SA247-B005)]
MBM29DL323TF@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29DL323TF@TSOP48 [(SA247-B005)]
MBM29DL324BD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL324BD@TSOP48 [(SA247-B005)]
MBM29DL324BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL324BE@TSOP48 [(SA247-B005)]
MBM29DL324TD@FBGA63 [(SA642E-B026A-T072N001)]
MBM29DL324TD@TSOP48 [(SA247-B005)]
MBM29DL324TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29DL324TE@TSOP48 [(SA247-B005)]
MBM29DL32BF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL32BF@TSOP48 [(SA247-B005)]
MBM29DL32TF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL32TF@TSOP48 [(SA247-B005)]
MBM29DL34BF@FBGA48 [(SA642N-B026A-W048F001)]

MBM29DL34BF@TSOP48 [(SA247-B005)]
MBM29DL34TF@FBGA48 [(SA642N-B026A-W048F001)]
MBM29DL34TF@TSOP48 [(SA247-B005)]
MBM29DL400BB@PSOP44 [(SA638-B006)]
MBM29DL400BB@TSOP48 [(SA247-B005)]
MBM29DL400BC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL400BC@PSOP44 [(SA638)]
MBM29DL400BC@TSOP48 [(SA247-B005)]
MBM29DL400BT@PSOP44 [(SA638-B006)]
MBM29DL400BT@TSOP48 [(SA247-B005)]
MBM29DL400TC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL400TC@PSOP44 [(SA638)]
MBM29DL400TC@TSOP48 [(SA247-B005)]
MBM29DL640E@FBGA63 [(SA642C-B026A-Y056F001)]
MBM29DL640E@TSOP48 [(SA247-B005)]
MBM29DL64DF@FBGA48 [(SA642F-B026A-T064F001)]
MBM29DL64DF@TSOP48 [(SA247-B005)]
MBM29DL800B@PSOP44 [(SA638-B006)]
MBM29DL800B@TSOP48 [(SA247-B005)]
MBM29DL800BA@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL800BA@TSOP48 [(SA247-B005)]
MBM29DL800BB@PSOP44 [(SA638-B006)]
MBM29DL800BB@TSOP48 [(SA247-B005)]
MBM29DL800BT@PSOP44 [(SA638-B006)]
MBM29DL800BT@TSOP48 [(SA247-B005)]
MBM29DL800T@PSOP44 [(SA638-B006)]
MBM29DL800T@TSOP48 [(SA247-B005)]
MBM29DL800TA@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29DL800TA@TSOP48 [(SA247-B005)]
MBM29DS163BE@FBGA48 [(SA642Z-B026A-W048F001Y)]
MBM29DS163BE@TSOP48 [(SA247-B005)]
MBM29DS163TE@FBGA48 [(SA642Z-B026A-W048F001Y)]
MBM29DS163TE@TSOP48 [(SA247-B005)]
MBM29F001B MBM29F001B@PLCC32
[(SA015A1T)]
MBM29F001B@TSOP32 [(SA410T)]
MBM29F001T MBM29F001T@TSOP32
MBM29F001T@PLCC32 [(SA015A1T)]
[(SA410T)]
MBM29F002B MBM29F002B@PLCC32
[(SA015A1T)]
MBM29F002B@TSOP32 [(SA410T)]
MBM29F002NB

MBM29F002NB@PLCC32 [(SA015A1T)]	MBM29F002NB@TSOP32
[(SA410T)]	
MBM29F002NT	MBM29F002NT@PLCC32
[(SA015A1T)]	
MBM29F002NT@TSOP32 [(SA410T)]	
MBM29F002T	
MBM29F002T@PLCC32 [(SA015A1T)]	MBM29F002T@TSOP32
[(SA410T)]	
MBM29F010	MBM29F010@PLCC32
[(SA015A1T)]	
MBM29F010@TSOP32 [(SA410T)]	
MBM29F010A	
MBM29F010A@PLCC32 [(SA015A1T)]	MBM29F010A@TSOP32
[(SA410T)]	
MBM29F016@PSOP44 [(SA638)]	MBM29F016@TSOP40
[(SA409T)]	
MBM29F016@TSOP48 [(SA247-B005)]	MBM29F016A@PSOP44
[(SA638)]	
MBM29F016A@TSOP40 [(SA409T)]	MBM29F016A@TSOP48 [(SA247-
B005)]	
MBM29F016B@PSOP44 [(SA638)]	MBM29F016B@TSOP40
[(SA409T)]	
MBM29F016B@TSOP48 [(SA247-B005)]	MBM29F017B@TSOP48 [(SA247-
B005)]	
MBM29F017D@TSOP40 [(SA409T)]	MBM29F017D@TSOP48 [(SA247-
B005)]	
MBM29F032B@PSOP44 [(SA638)]	MBM29F032B@TSOP40
[(SA409T)]	
MBM29F033C@TSOP40 [(SA409T)]	
MBM29F040	
MBM29F040@PLCC32 [(SA015A1T)]	MBM29F040@TSOP32
[(SA410T)]	
MBM29F040B	MBM29F040B@PLCC32
[(SA015A1T)]	
MBM29F040B@TSOP32 [(SA410T)]	MBM29F040C@PLCC32
[(SA015A1T)]	
MBM29F040C@TSOP32 [(SA410T)]	MBM29F080@PSOP44
[(SA638)]	
MBM29F080@TSOP40 [(SA409T)]	MBM29F080A@TSOP48 [(SA247-
B005)]	
MBM29F080B@PSOP44 [(SA638)]	MBM29F080B@TSOP40
[(SA409T)]	
MBM29F100B@PSOP44 [(SA638-B006)]	MBM29F100B@TSOP48 [(SA247-

B005)]
 MBM29F100T@PSOP44 [(SA638-B006)] MBM29F100T@TSOP48 [(SA247-B005)]
 MBM29F160BE@TSOP48 [(SA247-B005)]
 MBM29F160TE@TSOP48 [(SA247-B005)]
 MBM29F200AB@PSOP44 [(SA638-B006)]
 MBM29F200AB@TSOP48 [(SA247-B005)]
 MBM29F200AT@PSOP44 [(SA638-B006)]
 MBM29F200AT@TSOP48 [(SA247-B005)]
 MBM29F200B@PSOP44 [(SA638-B006)] MBM29F200B@TSOP48 [(SA247-B005)]
 MBM29F200T@PSOP44 [(SA638-B006)] MBM29F200T@TSOP48 [(SA247-B005)]
 MBM29F400AB@PSOP44 [(SA638-B006)]
 MBM29F400AB@TSOP48 [(SA247-B005)]
 MBM29F400AT@PSOP44 [(SA638-B006)]
 MBM29F400AT@TSOP48 [(SA247-B005)]
 MBM29F400B@PSOP44 [(SA638-B006)] MBM29F400B@TSOP48 [(SA247-B005)]
 MBM29F400BB@PSOP44 [(SA638-B006)]
 MBM29F400BB@TSOP48 [(SA247-B005)]
 MBM29F400BT@PSOP44 [(SA638-B006)]
 MBM29F400BT@TSOP48 [(SA247-B005)]
 MBM29F400T@PSOP44 [(SA638-B006)] MBM29F400T@TSOP48 [(SA247-B005)]
 MBM29F800B@PSOP44 [(SA638-B006)] MBM29F800B@TSOP48 [(SA247-B005)]
 MBM29F800BB@PSOP44 [(SA638-B006)]
 MBM29F800BB@TSOP48 [(SA247-B005)]
 MBM29F800BT@PSOP44 [(SA638-B006)]
 MBM29F800BT@TSOP48 [(SA247-B005)]
 MBM29F800T@PSOP44 [(SA638-B006)] MBM29F800T@TSOP48 [(SA247-B005)]
 MBM29LL800B@TSOP48 [(SA247-B005)]
 MBM29LL800BB@TSOP48 [(SA247-B005)]
 MBM29LL800BT@TSOP48 [(SA247-B005)]
 MBM29LL800T@TSOP48 [(SA247-B005)]
 MBM29LV001B@PLCC32 [(SA015A1T)] MBM29LV001BB@PLCC32 [(SA015A1T)]
 MBM29LV001BB@TSOP32 [(SA410T)] MBM29LV001BC@PLCC32 [(SA015A1T)]
 MBM29LV001BC@TSOP32 [(SA410T)] MBM29LV001BT@PLCC32 [(SA015A1T)]

MBM29LV001BT@TSOP32 [(SA410T)]	MBM29LV001T@TSOP32
[(SA410T)]	
MBM29LV001TC@PLCC32 [(SA015A1T)]	MBM29LV001TC@TSOP32
[(SA410T)]	
MBM29LV002B@TSOP40 [(SA409T)]	MBM29LV002T@TSOP40
[(SA409T)]	
MBM29LV004B@PSOP44 [(SA638)]	MBM29LV004B@TSOP40
[(SA409T)]	
MBM29LV004BB@TSOP40 [(SA409T)]	MBM29LV004BT@TSOP40
[(SA409T)]	
MBM29LV004T@PSOP44 [(SA638)]	MBM29LV004T@TSOP40
[(SA409T)]	
MBM29LV008B@PSOP44 [(SA638)]	MBM29LV008B@TSOP40
[(SA409T)]	
MBM29LV008BB@TSOP40 [(SA409T)]	MBM29LV008BT@TSOP40
[(SA409T)]	
MBM29LV008T@PSOP44 [(SA638)]	MBM29LV008T@TSOP40
[(SA409T)]	
MBM29LV016/B@TSOP40 [(SA409T)]	MBM29LV016/T@TSOP40
[(SA409T)]	
MBM29LV016B@TSOP40 [(SA409T)]	
MBM29LV017@FBGA48 [(SA642O-B026A-T064F001)]	
MBM29LV017@TSOP40 [(SA409T)]	MBM29LV017B@TSOP40
[(SA409T)]	
MBM29LV017E@TSOP40 [(SA409T)]	MBM29LV033C@TSOP40
[(SA409T)]	
MBM29LV080@TSOP40 [(SA409T)]	MBM29LV081@TSOP40
[(SA409T)]	
MBM29LV081B@TSOP40 [(SA409T)]	MBM29LV116B@TSOP40
[(SA409T)]	
MBM29LV160B@SON46 [(SA631)]	MBM29LV160B@SON46
(*)	
MBM29LV160BB@PSOP44 [(SA638-B006)]	
MBM29LV160BB@TSOP48 [(SA247-B005)]	
MBM29LV160BE@FBGA48 [(SA642B-B026A-Y072F001)]	
MBM29LV160BE@TSOP48 [(SA247-B005)]	
MBM29LV160BM@FBGA48 [(SA642B-B026A-Y072F001)]	
MBM29LV160BM@TSOP48 [(SA247-B005)]	
MBM29LV160BT@PSOP44 [(SA638-B006)]	
MBM29LV160BT@TSOP48 [(SA247-B005)]	
MBM29LV160T@SON46 [(SA631)]	MBM29LV160T@SON46
(*)	
MBM29LV160TE@FBGA48 [(SA642B-B026A-Y072F001)]	

MBM29LV160TE@TSOP48 [(SA247-B005)]
MBM29LV160TM@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV160TM@TSOP48 [(SA247-B005)]
MBM29LV200B@PSOP44 [(SA638-B006)]
MBM29LV200B@TSOP48 [(SA247-B005)]
MBM29LV200BB@PSOP44 [(SA638-B006)]
MBM29LV200BB@TSOP48 [(SA247-B005)]
MBM29LV200BC@PSOP44 [(SA638)]
MBM29LV200BC@TSOP48 [(SA247-B005)]
MBM29LV200BT@PSOP44 [(SA638-B006)]
MBM29LV200BT@TSOP48 [(SA247-B005)]
MBM29LV200T@PSOP44 [(SA638-B006)]
MBM29LV200T@TSOP48 [(SA247-B005)]
MBM29LV200TC@PSOP44 [(SA638)]
MBM29LV200TC@TSOP48 [(SA247-B005)]
MBM29LV320BE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29LV320BE@TSOP48 [(SA247-B005)]
MBM29LV320TE@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29LV320TE@TSOP48 [(SA247-B005)]
MBM29LV400B@PSOP44 [(SA638-B006)]
MBM29LV400B@TSOP48 [(SA247-B005)]
MBM29LV400BB@PSOP44 [(SA638-B006)]
MBM29LV400BB@TSOP48 [(SA247-B005)]
MBM29LV400BC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29LV400BC@PSOP44 [(SA638)]
MBM29LV400BC@TSOP48 [(SA247-B005)]
MBM29LV400BT@PSOP44 [(SA638-B006)]
MBM29LV400BT@TSOP48 [(SA247-B005)]
MBM29LV400T@PSOP44 [(SA638-B006)]
MBM29LV400T@TSOP48 [(SA247-B005)]
MBM29LV400TC@FBGA48 [(SA642N-B026A-W048F001Y)]
MBM29LV400TC@PSOP44 [(SA638)]
MBM29LV400TC@TSOP48 [(SA247-B005)]
MBM29LV650UE@TSOP48 [(SA247-B005)]
MBM29LV651UE@TSOP48 [(SA247-B005)]
MBM29LV652UE@FGBA63 [(SA642C-B026A-Y056F001)]
MBM29LV800B@PSOP44 [(SA638-B006)]
MBM29LV800B@SON46 [(SA631)] MBM29LV800B@SON46
(*)
MBM29LV800B@TSOP48 [(SA247-B005)]
MBM29LV800BA@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV800BA@PSOP44 [(SA638)]
MBM29LV800BA@TSOP48 [(SA247-B005)]

MBM29LV800BB@PSOP44 [(SA638-B006)]
MBM29LV800BB@TSOP48 [(SA247-B005)]
MBM29LV800BE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV800BE@PSOP44 [(SA638)]
MBM29LV800BE@TSOP48 [(SA247-B005)]
MBM29LV800BT@PSOP44 [(SA638-B006)]
MBM29LV800BT@TSOP48 [(SA247-B005)]
MBM29LV800T@PSOP44 [(SA638-B006)]
MBM29LV800T@SON46 [(SA631)] MBM29LV800T@SON46
(*)
MBM29LV800T@TSOP48 [(SA247-B005)]
MBM29LV800TA@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV800TA@PSOP44 [(SA638)]
MBM29LV800TA@TSOP48 [(SA247-B005)]
MBM29LV800TE@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29LV800TE@PSOP44 [(SA638)]
MBM29LV800TE@TSOP48 [(SA247-B005)]
MBM29PDS323B@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29PDS323T@FBGA63 [(SA642B-B026A-Y072F001)]
MBM29PL160BD@PSOP44 [(SA638)]
MBM29PL160BD@TSOP48 [(SA247-B005)]
MBM29PL160TD@PSOP44 [(SA638)]
MBM29PL160TD@TSOP48 [(SA247-B005)]
MBM29PL32BM@FBGA48 [(SA642G-B026A-T048F001)]
MBM29PL32BM@TSOP48 [(SA247-B005)]
MBM29PL32TM@FBGA48 [(SA642G-B026A-T048F001)]
MBM29PL32TM@TSOP48 [(SA247-B005)]
MBM29PL64LM@TSOP48 [(SA247-B005)]
MBM29PL64LM@TSOP56 [(SA628-B067)]
MBM29QM12DH@FBGA88 [(SA642J-B101A-W080F001)]
MBM29QM12DH@TSOP56 [(SA628-B097)]
MBM29SL160BD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29SL160BD@TSOP48 [(SA247-B005)]
MBM29SL160TD@FBGA48 [(SA642B-B026A-Y072F001)]
MBM29SL160TD@TSOP48 [(SA247-B005)]
MBM29SL800BB@TSOP48 [(SA247-B005)]
MBM29SL800BT@TSOP48 [(SA247-B005)]
PDL127H53V(AM29PDL127H53)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL127H63V(AM29PDL127H63)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL127H68V(AM29PDL127H68)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL127H88V(AM29PDL127H88)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H53V(AM29PDL129H53)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H63V(AM29PDL129H63)@FBGA80 [(SA642A-B070A-Y096N001)]

PDL129H68V(AM29PDL129H68)@FBGA80 [(SA642A-B070A-Y096N001)]
PDL129H88V(AM29PDL129H88)@FBGA80 [(SA642A-B070A-Y096N001)]
PL032J55BAI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J55BAI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J55BAW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J55BAW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J55BFI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J55BFI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J55BFW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J55BFW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J60BAI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J60BAI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J60BAW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J60BAW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J60BFI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J60BFI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J60BFW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J60BFW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J70BAI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J70BAI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J70BAW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J70BAW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J70BFI12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J70BFI15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL032J70BFW12(S29PL032J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL032J70BFW15(S29PL032J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J55BAI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J55BAI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J55BAW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J55BAW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J55BFI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J55BFI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J55BFW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J55BFW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J60BAI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J60BAI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J60BAW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J60BAW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J60BFI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J60BFI15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J60BFW12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J60BFW15(S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J70BAI12(S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]

PL064J70BAI15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J70BAW12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J70BAW15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J70BFI12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J70BFI15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL064J70BFW12 (S29PL064J)@FBGA48 [(SA642Z-B026A-W048F001Y)]
PL064J70BFW15 (S29PL064J)@FBGA56 [(SA642P-B079A-W056F001Y)]
PL127J55BAI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J55BAI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J55BAW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J55BAW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J55BFI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J55BFI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J55BFW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J55BFW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J60BAI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J60BAI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J60BAW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J60BAW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J60BFI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J60BFI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J60BFW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J60BFW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J65BAI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BAI01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BAI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J65BAW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BAW01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BAW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J65BFI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BFI01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BFI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J65BFW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BFW01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J65BFW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J70BAI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BAI01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BAI02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J70BAW00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BAW01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BAW02 (S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J70BFI00 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BFI01 (S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]

PL127J70BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
PL127J70BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BFW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]
PL127J70BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]
S19MN02GP30TFP00@TSOP48 [(SA247-B005)]
S19MN256P30TFP00@TSOP48 [(SA247-B005)]
S19MN512P30TFP00@TSOP48 [(SA247-B005)]
S25FL001D@SOIC8 [(SA602A)] S25FL001D@USON8
[(SA683)]
S25FL002A@SOIC8 [(SA605A)] S25FL002A@USON8
[(SA683)]
S25FL002D@SOIC8 [(SA602A)] S25FL002D@USON8
[(SA683)]
S25FL004A@SOIC8 [(SA605A)] S25FL004A@USON8
[(SA683)]
S25FL004D@SOIC8 [(SA602A)] S25FL004D@USON8
[(SA683)]
S25FL008A@SOIC8 [(SA605A)] S25FL008A@USON8
[(SA683)]
S25FL008D@SOIC8 [(SA602A)] S25FL008D@USON8
[(SA683)]
S25FL016A@SOIC16 [(SA404)]
S25FL016A@SOIC16(ISP) [ISP-HEADER01]
S25FL016A@SOIC8 [(SA605A)]
S25FL016A@SOIC8(ISP) [ISP-HEADER01]
S25FL016A@WSON8 [(SA684)]
S25FL016A@WSON8(ISP) [ISP-HEADER01]
S25FL020A@SOIC8(4.0) [(SA602A)] S25FL020A@SOIC8(5.4)
[(SA605A)]
S25FL020A@USON8 [(SA683)] S25FL032A@SOIC16
[(SA404)]
S25FL032A@SOIC16(ISP) [ISP-HEADER01]
S25FL032A@WSON8 [(SA684)]
S25FL032A@WSON8(ISP) [ISP-HEADER01]
S25FL040A(Bottom Boot)@SOP8(4.0) [(SA602A)]
S25FL040A(Bottom Boot)@SOP8(5.4) [(SA605A)]
S25FL040A(Bottom Boot)@USON8 [(SA683)]
S25FL040A(Top Boot)@SOP8(4.0) [(SA602A)]
S25FL040A(Top Boot)@SOP8(5.4) [(SA605A)]
S25FL040A(Top Boot)@USON8 [(SA683)]
S25FL040A@SOP8(4.0) [(SA602A)] S25FL040A@SOP8(5.4)
[(SA605A)]
S25FL040A@USON8 [(SA683)] S25FL064A@SOIC16

[(SA404)]
S25FL064A@SOIC16(ISP) [ISP-HEADER01]
S25FL064A@WSON8 [(SA684)]
S25FL064A@WSON8(ISP) [ISP-HEADER01]
S25FL080A@SOIC8(4.0) [(SA602A)] S25FL080A@SOIC8(5.4)
[(SA605A)]
S25FL080A@USON8 [(SA683)]
S25FL128P(256 KB)@SOIC16 [(SA404)]
S25FL128P(256 KB)@SOIC16(ISP) [ISP-HEADER01]
S25FL128P(256 KB)@WSON8 [(SA684)]
S25FL128P(256 KB)@WSON8(ISP) [ISP-HEADER01]
S25FL128P(64 KB)@SOIC16 [(SA404)]
S25FL128P(64 KB)@SOIC16(ISP) [ISP-HEADER01]
S25FL128P(64 KB)@WSON8 [(SA684)]
S25FL128P(64 KB)@WSON8(ISP) [ISP-HEADER01]
S25FLK05D@SOIC8 [(SA602A)] S25FLK05D@USON8
[(SA683)]
S29AD016DBFA01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AD016DBFA02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AD016DBFB01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AD016DBFB02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AD016DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AD016DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AD016DBFV01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AD016DBFV02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AD016DMFA01@PSOP44 [(SA638)] S29AD016DMFA02@PSOP44
[(SA638)]
S29AD016DMFB01@PSOP44 [(SA638)] S29AD016DMFB02@PSOP44
[(SA638)]
S29AD016DMFI01@PSOP44 [(SA638)] S29AD016DMFI02@PSOP44
[(SA638)]
S29AD016DMFV01@PSOP44 [(SA638)] S29AD016DMFV02@PSOP44
[(SA638)]
S29AD016DTFA01@TSOP48 [(SA247-B005)]
S29AD016DTFA02@TSOP48 [(SA247-B005)]
S29AD016DTFB01@TSOP48 [(SA247-B005)]
S29AD016DTFB02@TSOP48 [(SA247-B005)]
S29AD016DTFI01@TSOP48 [(SA247-B005)]
S29AD016DTFI02@TSOP48 [(SA247-B005)]
S29AD016DTFV01@TSOP48 [(SA247-B005)]
S29AD016DTFV02@TSOP48 [(SA247-B005)]
S29AL002BBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL002BBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]

S29AL002BBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL002BBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL002BMAI01@PSOP44 [(SA638)] S29AL002BMAI02@PSOP44
[(SA638)]
S29AL002BMFI01@PSOP44 [(SA638)] S29AL002BMFI02@PSOP44
[(SA638)]
S29AL002BTAI01@TSOP48 [(SA247-B005)]
S29AL002BTAI02@TSOP48 [(SA247-B005)]
S29AL002BTFI01@TSOP48 [(SA247-B005)]
S29AL002BTFI02@TSOP48 [(SA247-B005)]
S29AL004BBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004BBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004BBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004BBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004BMAI01@PSOP44 [(SA638)] S29AL004BMAI02@PSOP44
[(SA638)]
S29AL004BMFI01@PSOP44 [(SA638)] S29AL004BMFI02@PSOP44
[(SA638)]
S29AL004BTAI01@TSOP48 [(SA247-B005)]
S29AL004BTAI02@TSOP48 [(SA247-B005)]
S29AL004BTFI01@TSOP48 [(SA247-B005)]
S29AL004BTFI02@TSOP48 [(SA247-B005)]
S29AL004DBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBAN01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBAN02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBANR1@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBANR2@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBFN1@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DBFN2@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL004DMAI01@PSOP44 [(SA638)] S29AL004DMAI02@PSOP44
[(SA638)]
S29AL004DMAN01@PSOP44 [(SA638)] S29AL004DMAN02@PSOP44
[(SA638)]
S29AL004DMANR1@PSOP44 [(SA638)] S29AL004DMANR2@PSOP44
[(SA638)]
S29AL004DMFI01@PSOP44 [(SA638)] S29AL004DMFI02@PSOP44
[(SA638)]
S29AL004DMFN01@PSOP44 [(SA638)] S29AL004DMFN02@PSOP44

[(SA638)]
S29AL004DMFNR1@PSOP44 [(SA638)] S29AL004DMFNR2@PSOP44
[(SA638)]
S29AL004DTAI01@TSOP48 [(SA247-B005)]
S29AL004DTAI02@TSOP48 [(SA247-B005)]
S29AL004DTAN01@TSOP48 [(SA247-B005)]
S29AL004DTAN02@TSOP48 [(SA247-B005)]
S29AL004DTANR1@TSOP48 [(SA247-B005)]
S29AL004DTANR2@TSOP48 [(SA247-B005)]
S29AL004DTFI01@TSOP48 [(SA247-B005)]
S29AL004DTFI02@TSOP48 [(SA247-B005)]
S29AL004DTFN01@TSOP48 [(SA247-B005)]
S29AL004DTFN02@TSOP48 [(SA247-B005)]
S29AL004DTFNR1@TSOP48 [(SA247-B005)]
S29AL004DTFNR2@TSOP48 [(SA247-B005)]
S29AL008DBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBAN01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBAN02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBANR1@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBANR2@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBFNR1@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DBFNR2@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL008DMAI01@PSOP44 [(SA638)] S29AL008DMAI02@PSOP44
[(SA638)]
S29AL008DMAN01@PSOP44 [(SA638)] S29AL008DMAN02@PSOP44
[(SA638)]
S29AL008DMANR1@PSOP44 [(SA638)] S29AL008DMANR2@PSOP44
[(SA638)]
S29AL008DMFI01@PSOP44 [(SA638)] S29AL008DMFI02@PSOP44
[(SA638)]
S29AL008DMFN01@PSOP44 [(SA638)] S29AL008DMFN02@PSOP44
[(SA638)]
S29AL008DMFNR1@PSOP44 [(SA638)] S29AL008DMFNR2@PSOP44
[(SA638)]
S29AL008DTAI01@TSOP48 [(SA247-B005)]
S29AL008DTAI02@TSOP48 [(SA247-B005)]
S29AL008DTAN01@TSOP48 [(SA247-B005)]
S29AL008DTAN02@TSOP48 [(SA247-B005)]

S29AL008DTANR1@TSOP48 [(SA247-B005)]
S29AL008DTANR2@TSOP48 [(SA247-B005)]
S29AL008DTFI01@TSOP48 [(SA247-B005)]
S29AL008DTFI02@TSOP48 [(SA247-B005)]
S29AL008DTFN01@TSOP48 [(SA247-B005)]
S29AL008DTFN02@TSOP48 [(SA247-B005)]
S29AL008DTFNR1@TSOP48 [(SA247-B005)]
S29AL008DTFNR2@TSOP48 [(SA247-B005)]
S29AL016DBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL016DBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL016DBAN01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL016DBAN02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL016DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL016DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL016DBFN01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL016DBFN02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29AL016DMAI01@PSOP44 [(SA638)] S29AL016DMAI02@PSOP44
[(SA638)]
S29AL016DMAN01@PSOP44 [(SA638)] S29AL016DMAN02@PSOP44
[(SA638)]
S29AL016DMFI01@PSOP44 [(SA638)] S29AL016DMFI02@PSOP44
[(SA638)]
S29AL016DMFN01@PSOP44 [(SA638)] S29AL016DMFN02@PSOP44
[(SA638)]
S29AL016DTAI01@TSOP48 [(SA247-B005)]
S29AL016DTAI02@TSOP48 [(SA247-B005)]
S29AL016DTAN01@TSOP48 [(SA247-B005)]
S29AL016DTAN02@TSOP48 [(SA247-B005)]
S29AL016DTFI01@TSOP48 [(SA247-B005)]
S29AL016DTFI02@TSOP48 [(SA247-B005)]
S29AL016DTFN01@TSOP48 [(SA247-B005)]
S29AL016DTFN02@TSOP48 [(SA247-B005)]
S29AL016MBAI01@FBGA48 [(SA642G-B026A-T048F001Y)]
S29AL016MBAI02@FBGA48 [(SA642G-B026A-T048F001Y)]
S29AL016MBAIR1@FBGA48 [(SA642G-B026A-T048F001Y)]
S29AL016MBAIR2@FBGA48 [(SA642G-B026A-T048F001Y)]
S29AL016MBFI01@FBGA48 [(SA642G-B026A-T048F001Y)]
S29AL016MBFI02@FBGA48 [(SA642G-B026A-T048F001Y)]
S29AL016MBFIR1@FBGA48 [(SA642G-B026A-T048F001Y)]
S29AL016MBFIR2@FBGA48 [(SA642G-B026A-T048F001Y)]
S29AL016MFAI01@FBGA64 [(SA655D-B044A-W064F001Y)]
S29AL016MFAI02@FBGA64 [(SA655D-B044A-W064F001Y)]
S29AL016MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]

S29AL016MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29AL016MFFI01@FBGA64 [(SA655D-B044A-W064F001Y)]
S29AL016MFFI02@FBGA64 [(SA655D-B044A-W064F001Y)]
S29AL016MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]
S29AL016MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29AL016MTAI01@TSOP48 [(SA247-B005)]
S29AL016MTAI02@TSOP48 [(SA247-B005)]
S29AL016MTAIR1@TSOP48 [(SA247-B005)]
S29AL016MTAIR2@TSOP48 [(SA247-B005)]
S29AL016MTFI01@TSOP48 [(SA247-B005)]
S29AL016MTFI02@TSOP48 [(SA247-B005)]
S29AL016MTFIR1@TSOP48 [(SA247-B005)]
S29AL016MTFIR2@TSOP48 [(SA247-B005)]
S29AL032DBAI00@FBGA48 [(SA642Y-B026A-W048F001N)]
S29AL032DBAI03@FBGA48 [(SA642Y-B026A-W048F001N)]
S29AL032DBAI04@FBGA48 [(SA642Y-B026A-W048F001N)]
S29AL032DBFI00@FBGA48 [(SA642Y-B026A-W048F001N)]
S29AL032DBFI03@FBGA48 [(SA642Y-B026A-W048F001N)]
S29AL032DBFI04@FBGA48 [(SA642Y-B026A-W048F001N)]
S29AL032DTAI00@TSOP40 [(SA409T)]
S29AL032DTAI03@TSOP48 [(SA247-B005)]
S29AL032DTAI04@TSOP48 [(SA247-B005)]
S29AL032DTFI00@TSOP40 [(SA409T)]
S29AL032DTFI03@TSOP48 [(SA247-B005)]
S29AL032DTFI04@TSOP48 [(SA247-B005)]
S29GL016ABAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABAIR1@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABAIR2@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABAIW1@FBGA56 [(SA642P-B032A-W056F001Y)]
S29GL016ABAIW2@FBGA56 [(SA642P-B032A-W056F001Y)]
S29GL016ABFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABFI03@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABFI04@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABFIR1@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABFIR2@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL016ABFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]

S29GL016ABFIW1@FBGA56 [(SA642P-B032A-W056F001Y)]
S29GL016ABFIW2@FBGA56 [(SA642P-B032A-W056F001Y)]
S29GL016AFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016AFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL016ATAI01@TSOP48 [(SA247-B005)]
S29GL016ATAI02@TSOP48 [(SA247-B005)]
S29GL016ATAI03@TSOP48 [(SA247-B005)]
S29GL016ATAI04@TSOP48 [(SA247-B005)]
S29GL016ATAIR1@TSOP48 [(SA247-B005)]
S29GL016ATAIR2@TSOP48 [(SA247-B005)]
S29GL016ATAIR3@TSOP48 [(SA247-B005)]
S29GL016ATAIR4@TSOP48 [(SA247-B005)]
S29GL016ATFI01@TSOP48 [(SA247-B005)]
S29GL016ATFI02@TSOP48 [(SA247-B005)]
S29GL016ATFI03@TSOP48 [(SA247-B005)]
S29GL016ATFI04@TSOP48 [(SA247-B005)]
S29GL016ATFIR1@TSOP48 [(SA247-B005)]
S29GL016ATFIR2@TSOP48 [(SA247-B005)]
S29GL016ATFIR3@TSOP48 [(SA247-B005)]
S29GL016ATFIR4@TSOP48 [(SA247-B005)]
S29GL032ABAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032ABAIR4 (Normal)@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032ABAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032ABAIW3@FBGA56 [(SA642P-B032A-W056F001Y)]
S29GL032ABAIW4@FBGA56 [(SA642P-B032A-W056F001Y)]
S29GL032ABFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032ABFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032ABFIW3@FBGA56 [(SA642P-B032A-W056F001Y)]
S29GL032ABFIW4@FBGA56 [(SA642P-B032A-W056F001Y)]
S29GL032AFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL032AFAIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFAIS2(29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFAIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032AFAIS4(29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032AFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFFIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFFIS2(29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032AFFIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032AFFIS4(29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032ATAIR1@TSOP56 [(SA628-B102)]
S29GL032ATAIR2@TSOP56 [(SA628-B102)]
S29GL032ATAIR3@TSOP48 [(SA247-B005)]
S29GL032ATAIR4@TSOP48 [(SA247-B005)]
S29GL032ATFIR1@TSOP56 [(SA628-B102)]
S29GL032ATFIR2@TSOP56 [(SA628-B102)]
S29GL032ATFIR3@TSOP48 [(SA247-B005)]
S29GL032ATFIR4(Normal)@TSOP48 [(SA247-B005)]
S29GL032ATFIR4@TSOP48 [(SA247-B005)]
S29GL032MBACR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]
S29GL032MBACR0@FBGA48 [(SA642AA-B026A-W064F001N)]
S29GL032MBACR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBACR3@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBACR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBACR4@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBAIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]
S29GL032MBAIR0@FBGA48 [(SA642AA-B026A-W064F001N)]
S29GL032MBAIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBAIR3@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBAIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBAIR4@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBAIR5@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBAIR6@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFCR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]
S29GL032MBFCR0@FBGA48 [(SA642AA-B026A-W064F001N)]
S29GL032MBFCR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFCR3@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFCR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFCR4@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]
S29GL032MBFIR0@FBGA48 [(SA642AA-B026A-W064F001N)]

S29GL032MBFIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFIR3@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFIR4@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFIR5@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MBFIR6@FBGA48 [(SA642G-B026A-T048F001Y)]
S29GL032MFACR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFACR1@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFACR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFACR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFACR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFACR3@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFACR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFACR4@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFACS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032MFACS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032MFACS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032MFACS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFAIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032MFAIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032MFAIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032MFAIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032MFFCR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFCR1@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFCR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFCR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFCR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFCR3@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFCR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFCR4@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFCS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032MFFCS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032MFFCS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032MFFCS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]

S29GL032MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL032MFFIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032MFFIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032MFFIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032MFFIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL032MTACR0(Mirror)@TSOP40 [(SA409T)]
S29GL032MTACR0@TSOP40 [(SA409T)]
S29GL032MTACR1(Mirror)@TSOP56 [(SA628-B067)]
S29GL032MTACR1@TSOP56 [(SA628-B067)]
S29GL032MTACR2(Mirror)@TSOP56 [(SA628-B067)]
S29GL032MTACR2@TSOP56 [(SA628-B067)]
S29GL032MTACR3(Mirror)@TSOP48 [(SA247-B005)]
S29GL032MTACR3@TSOP48 [(SA247-B005)]
S29GL032MTACR4(Mirror)@TSOP48 [(SA247-B005)]
S29GL032MTACR4@TSOP48 [(SA247-B005)]
S29GL032MTAIR0(Mirror)@TSOP40 [(SA409T)]
S29GL032MTAIR0@TSOP40 [(SA409T)]
S29GL032MTAIR1(Mirror)@TSOP56 [(SA628-B067)]
S29GL032MTAIR1@TSOP56 [(SA628-B067)]
S29GL032MTAIR2(Mirror)@TSOP56 [(SA628-B067)]
S29GL032MTAIR2@TSOP56 [(SA628-B067)]
S29GL032MTAIR3(Mirror)@TSOP48 [(SA247-B005)]
S29GL032MTAIR3@TSOP48 [(SA247-B005)]
S29GL032MTAIR4(Mirror)@TSOP48 [(SA247-B005)]
S29GL032MTAIR4@TSOP48 [(SA247-B005)]
S29GL032MTFCR0(Mirror)@TSOP40 [(SA409T)]
S29GL032MTFCR0@TSOP40 [(SA409T)]
S29GL032MTFCR1(Mirror)@TSOP56 [(SA628-B067)]
S29GL032MTFCR1@TSOP56 [(SA628-B067)]
S29GL032MTFCR2(Mirror)@TSOP56 [(SA628-B067)]
S29GL032MTFCR2@TSOP56 [(SA628-B067)]
S29GL032MTFCR3(Mirror)@TSOP48 [(SA247-B005)]
S29GL032MTFCR3@TSOP48 [(SA247-B005)]
S29GL032MTFCR4(Mirror)@TSOP48 [(SA247-B005)]
S29GL032MTFCR4@TSOP48 [(SA247-B005)]
S29GL032MTFIR0(Mirror)@TSOP40 [(SA409T)]
S29GL032MTFIR0@TSOP40 [(SA409T)]

S29GL032MTFIR1(Mirror)@TSOP56 [(SA628-B067)]
S29GL032MTFIR1@TSOP56 [(SA628-B067)]
S29GL032MTFIR2(Mirror)@TSOP56 [(SA628-B067)]
S29GL032MTFIR2@TSOP56 [(SA628-B067)]
S29GL032MTFIR3(Mirror)@TSOP48 [(SA247-B005)]
S29GL032MTFIR3@TSOP48 [(SA247-B005)]
S29GL032MTFIR4(Mirror)@TSOP48 [(SA247-B005)]
S29GL032MTFIR4@TSOP48 [(SA247-B005)]
S29GL032NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032NBFIO3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032NBFIO4@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL032NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL032NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL032NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIO1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIO2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIO3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIO4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL032NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL032NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL032NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL032NTAI01@TSOP56 [(SA628-B102)]
S29GL032NTAI02@TSOP56 [(SA628-B102)]
S29GL032NTAI03@TSOP48 [(SA247-B005)]
S29GL032NTAI04@TSOP48 [(SA247-B005)]
S29GL032NTAIR1@TSOP56 [(SA628-B102)]
S29GL032NTAIR2@TSOP56 [(SA628-B102)]
S29GL032NTAIR3@TSOP48 [(SA247-B005)]
S29GL032NTAIR4@TSOP48 [(SA247-B005)]
S29GL032NTAIV1@TSOP56 [(SA628-B102)]
S29GL032NTAIV2@TSOP56 [(SA628-B102)]
S29GL032NTFI01@TSOP56 [(SA628-B102)]
S29GL032NTFI02@TSOP56 [(SA628-B102)]
S29GL032NTFI03@TSOP48 [(SA247-B005)]
S29GL032NTFI04@TSOP48 [(SA247-B005)]
S29GL032NTFIR1@TSOP56 [(SA628-B102)]
S29GL032NTFIR2@TSOP56 [(SA628-B102)]
S29GL032NTFIR3@TSOP48 [(SA247-B005)]
S29GL032NTFIR4@TSOP48 [(SA247-B005)]
S29GL032NTFIV1@TSOP56 [(SA628-B102)]
S29GL032NTFIV2@TSOP56 [(SA628-B102)]
S29GL064ABAIR3@FBGA48 [(SA642B-B026A-Y072F001N)]
S29GL064ABAIR4@FBGA48 [(SA642B-B026A-Y072F001N)]
S29GL064ABAIR5@FBGA48 [(SA642B-B026A-Y072F001N)]
S29GL064ABFIR3@FBGA48 [(SA642B-B026A-Y072F001N)]
S29GL064ABFIR4@FBGA48 [(SA642B-B026A-Y072F001N)]
S29GL064ABFIR5@FBGA48 [(SA642B-B026A-Y072F001N)]
S29GL064AFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFAIR5@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFAIS1 (29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFAIS2 (29LV640MB)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFAIS3 (29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL064AFAIS4 (29LV640MB)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL064AFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFFIR5@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFFIS1 (29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064AFFIS2 (29LV640MB)@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL064AFFIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL064AFFIS4(29LV640MB)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL064ATAIR1@TSOP56 [(SA628-B102)]
S29GL064ATAIR2@TSOP56 [(SA628-B102)]
S29GL064ATAIR3@TSOP48 [(SA247-B005)]
S29GL064ATAIR4@TSOP48 [(SA247-B005)]
S29GL064ATAIR6@TSOP48 [(SA247-B005)]
S29GL064ATAIR7@TSOP48 [(SA247-B005)]
S29GL064ATAIR8@TSOP48 [(SA247-B005)]
S29GL064ATAIR9@TSOP48 [(SA247-B005)]
S29GL064ATFIR1@TSOP56 [(SA628-B102)]
S29GL064ATFIR2@TSOP56 [(SA628-B102)]
S29GL064ATFIR3@TSOP48 [(SA247-B005)]
S29GL064ATFIR4@TSOP48 [(SA247-B005)]
S29GL064ATFIR6@TSOP48 [(SA247-B005)]
S29GL064ATFIR7@TSOP48 [(SA247-B005)]
S29GL064ATFIR8@TSOP48 [(SA247-B005)]
S29GL064ATFIR9@TSOP48 [(SA247-B005)]
S29GL064MBAIR0(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBAIR0@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBAIR3(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBAIR3@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBAIR4(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBAIR4@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBAIR5(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBAIR5@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBFIR0(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBFIR0@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBFIR3(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBFIR3@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBFIR4(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBFIR4@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBFIR5(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MBFIR5@FBGA63 [(SA642M-B026A-W048F001Y)]
S29GL064MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFAIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]

S29GL064MFAIR5@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFAIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064MFAIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064MFAIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL064MFAIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL064MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIR5@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL064MFFIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064MFFIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064MFFIS2(Normal)@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064MFFIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL064MFFIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]
S29GL064MTAIR0(Mirror)@TSOP48 [(SA247-B005)]
S29GL064MTAIR0@TSOP48 [(SA247-B005)]
S29GL064MTAIR1(Mirror)@TSOP56 [(SA628-B067)]
S29GL064MTAIR1@TSOP56 [(SA628-B067)]
S29GL064MTAIR2(Mirror)@TSOP56 [(SA628-B067)]
S29GL064MTAIR2@TSOP56 [(SA628-B067)]
S29GL064MTAIR3(Mirror)@TSOP48 [(SA247-B005)]
S29GL064MTAIR3@TSOP48 [(SA247-B005)]
S29GL064MTAIR4(Mirror)@TSOP48 [(SA247-B005)]
S29GL064MTAIR4@TSOP48 [(SA247-B005)]
S29GL064MTAIR6(Mirror)@TSOP48 [(SA247-B005)]
S29GL064MTAIR6@TSOP48 [(SA247-B005)]
S29GL064MTAIR7(Mirror)@TSOP48 [(SA247-B005)]
S29GL064MTAIR7@TSOP48 [(SA247-B005)]
S29GL064MTFIR0(Mirror)@TSOP48 [(SA247-B005)]
S29GL064MTFIR0@TSOP48 [(SA247-B005)]
S29GL064MTFIR1(Mirror)@TSOP56 [(SA628-B067)]
S29GL064MTFIR1@TSOP56 [(SA628-B067)]
S29GL064MTFIR2(Mirror)@TSOP56 [(SA628-B067)]
S29GL064MTFIR2@TSOP56 [(SA628-B067)]
S29GL064MTFIR3(Mirror)@TSOP48 [(SA247-B005)]
S29GL064MTFIR3@TSOP48 [(SA247-B005)]
S29GL064MTFIR4(Mirror)@TSOP48 [(SA247-B005)]

S29GL064MTFIR4@TSOP48 [(SA247-B005)]
S29GL064MTFIR6(Mirror)@TSOP48 [(SA247-B005)]
S29GL064MTFIR6@TSOP48 [(SA247-B005)]
S29GL064MTFIR7(Mirror)@TSOP48 [(SA247-B005)]
S29GL064MTFIR7@TSOP48 [(SA247-B005)]
S29GL064NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL064NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL064NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL064NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL064NBFIO3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL064NBFIO4@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL064NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL064NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29GL064NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL064NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL064NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFI03@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFI04@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFIR4@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL064NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL064NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL064NTAI01@TSOP56 [(SA628-B102)]
S29GL064NTAI02@TSOP56 [(SA628-B102)]

S29GL064NTAI03@TSOP48 [(SA247-B005)]
S29GL064NTAI04@TSOP48 [(SA247-B005)]
S29GL064NTAI06@TSOP48 [(SA247-B005)]
S29GL064NTAI07@TSOP48 [(SA247-B005)]
S29GL064NTAIR1@TSOP56 [(SA628-B102)]
S29GL064NTAIR2@TSOP56 [(SA628-B102)]
S29GL064NTAIR3@TSOP48 [(SA247-B005)]
S29GL064NTAIR4@TSOP48 [(SA247-B005)]
S29GL064NTAIR6@TSOP48 [(SA247-B005)]
S29GL064NTAIR7@TSOP48 [(SA247-B005)]
S29GL064NTAIV1@TSOP56 [(SA628-B102)]
S29GL064NTAIV2@TSOP56 [(SA628-B102)]
S29GL064NTAIV6@TSOP48 [(SA247-B005)]
S29GL064NTAIV7@TSOP48 [(SA247-B005)]
S29GL064NTFI01@TSOP56 [(SA628-B102)]
S29GL064NTFI02@TSOP56 [(SA628-B102)]
S29GL064NTFI03@TSOP48 [(SA247-B005)]
S29GL064NTFI04 (Low)@TSOP48 [(SA247-B005)]
S29GL064NTFI04@TSOP48 [(SA247-B005)]
S29GL064NTFI06@TSOP48 [(SA247-B005)]
S29GL064NTFI07@TSOP48 [(SA247-B005)]
S29GL064NTFIR1@TSOP56 [(SA628-B102)]
S29GL064NTFIR2@TSOP56 [(SA628-B102)]
S29GL064NTFIR3@TSOP48 [(SA247-B005)]
S29GL064NTFIR4@TSOP48 [(SA247-B005)]
S29GL064NTFIR6@TSOP48 [(SA247-B005)]
S29GL064NTFIR7@TSOP48 [(SA247-B005)]
S29GL064NTFIV1@TSOP56 [(SA628-B102)]
S29GL064NTFIV2@TSOP56 [(SA628-B102)]
S29GL064NTFIV6@TSOP48 [(SA247-B005)]
S29GL064NTFIV7@TSOP48 [(SA247-B005)]
S29GL128MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL128MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL128MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL128MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]
S29GL128MTAIR1@TSOP56 [(SA628-B067)]
S29GL128MTAIR2@TSOP56 [(SA628-B067)]
S29GL128MTFIR1@TSOP56 [(SA628-B067)]
S29GL128MTFIR2@TSOP56 [(SA628-B067)]
S29GL128NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFAIIH@FBGA64 [(SA655E-B129A-T056F001Y)]
S29GL128NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL128NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL128NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL128NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFAW01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFAW02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFAWIH@FBGA64 [(SA655E-B129A-T056F001Y)]
S29GL128NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFFIIH@FBGA64 [(SA655E-B129A-T056F001Y)]
S29GL128NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL128NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]
S29GL128NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFFW01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NFFW02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128NTAI01@TSOP56 [(SA628-B102)]
S29GL128NTAI02@TSOP56 [(SA628-B102)]
S29GL128NTAIR1@TSOP56 [(SA628-B102)]
S29GL128NTAIR2@TSOP56 [(SA628-B102)]
S29GL128NTAIV1@TSOP56 [(SA628-B102)]
S29GL128NTAIV2@TSOP56 [(SA628-B102)]
S29GL128NTAW01@TSOP56 [(SA628-B102)]
S29GL128NTAW02@TSOP56 [(SA628-B102)]
S29GL128NTFI01@TSOP56 [(SA628-B102)]
S29GL128NTFI02@TSOP56 [(SA628-B102)]
S29GL128NTFIR1@TSOP56 [(SA628-B102)]
S29GL128NTFIR2@TSOP56 [(SA628-B102)]
S29GL128NTFIV1@TSOP56 [(SA628-B102)]
S29GL128NTFIV2@TSOP56 [(SA628-B102)]
S29GL128NTFW01@TSOP56 [(SA628-B102)]
S29GL128NTFW02@TSOP56 [(SA628-B102)]
S29GL128PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL128PFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL128PTAI01@TSOP56 [(SA628-B102)]
S29GL128PTAI02@TSOP56 [(SA628-B102)]
S29GL128PTAIR1@TSOP56 [(SA628-B102)]
S29GL128PTAIR2@TSOP56 [(SA628-B102)]
S29GL128PTAIV1@TSOP56 [(SA628-B102)]
S29GL128PTAIV2@TSOP56 [(SA628-B102)]
S29GL128PTFI01@TSOP56 [(SA628-B102)]
S29GL128PTFI02@TSOP56 [(SA628-B102)]
S29GL128PTFIR1@TSOP56 [(SA628-B102)]
S29GL128PTFIR2@TSOP56 [(SA628-B102)]
S29GL128PTFIV1@TSOP56 [(SA628-B102)]
S29GL128PTFIV2@TSOP56 [(SA628-B102)]
S29GL256MR1@TSOP56 [(SA628-B067)]
S29GL256MR2@TSOP56 [(SA628-B067)]
S29GL256NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFAIIH@FBGA64 [(SA655E-B129A-T056F001Y)]
S29GL256NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFFIIH@FBGA64 [(SA655E-B129A-T056F001Y)]
S29GL256NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256NTAI01@TSOP56 [(SA628-B102)]
S29GL256NTAI02@TSOP56 [(SA628-B102)]
S29GL256NTAIR1@TSOP56 [(SA628-B102)]
S29GL256NTAIR2@TSOP56 [(SA628-B102)]
S29GL256NTAIV1@TSOP56 [(SA628-B102)]
S29GL256NTAIV2@TSOP56 [(SA628-B102)]
S29GL256NTFI01@TSOP56 [(SA628-B102)]

S29GL256NTFI02@TSOP56 [(SA628-B102)]
S29GL256NTFIR1@TSOP56 [(SA628-B102)]
S29GL256NTFIR2@TSOP56 [(SA628-B102)]
S29GL256NTFIV1@TSOP56 [(SA628-B102)]
S29GL256NTFIV2@TSOP56 [(SA628-B102)]
S29GL256PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL256PTAI01@TSOP56 [(SA628-B102)]
S29GL256PTAI02@TSOP56 [(SA628-B102)]
S29GL256PTAIR1@TSOP56 [(SA628-B102)]
S29GL256PTAIR2@TSOP56 [(SA628-B102)]
S29GL256PTAIV1@TSOP56 [(SA628-B102)]
S29GL256PTAIV2@TSOP56 [(SA628-B102)]
S29GL256PTFI01@TSOP56 [(SA628-B102)]
S29GL256PTFI02@TSOP56 [(SA628-B102)]
S29GL256PTFIR1@TSOP56 [(SA628-B102)]
S29GL256PTFIR2@TSOP56 [(SA628-B102)]
S29GL256PTFIV1@TSOP56 [(SA628-B102)]
S29GL256PTFIV2@TSOP56 [(SA628-B102)]
S29GL512NFA01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFA02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFAV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFAV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFF01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFF02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFFV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NFFV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512NTA01@TSOP56 [(SA628-B102)]
S29GL512NTA02@TSOP56 [(SA628-B102)]

S29GL512NTAV1@TSOP56 [(SA628-B102)]
S29GL512NTAV2@TSOP56 [(SA628-B102)]
S29GL512NTF01@TSOP56 [(SA628-B102)]
S29GL512NTF02@TSOP56 [(SA628-B102)]
S29GL512NTFV1@TSOP56 [(SA628-B102)]
S29GL512NTFV2@TSOP56 [(SA628-B102)]
S29GL512PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512PFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512PFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512PFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512PFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512PFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512PFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]
S29GL512PTAI01@TSOP56 [(SA628-B102)]
S29GL512PTAI02@TSOP56 [(SA628-B102)]
S29GL512PTAIV1@TSOP56 [(SA628-B102)]
S29GL512PTAIV2@TSOP56 [(SA628-B102)]
S29GL512PTFI01@TSOP56 [(SA628-B102)]
S29GL512PTFI02@TSOP56 [(SA628-B102)]
S29GL512PTFIV1@TSOP56 [(SA628-B102)]
S29GL512PTFIV2@TSOP56 [(SA628-B102)]
S29JL032HBAI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBAI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBAI21@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBAI22@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBAI31@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBAI32@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBAI41@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBAI42@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBFI21@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBFI22@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBFI31@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBFI32@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBFI41@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HBFI42@FBGA48 [(SA642Z-B026A-W048F001Y)]
S29JL032HTAI01@TSOP48 [(SA247-B005)]
S29JL032HTAI02@TSOP48 [(SA247-B005)]
S29JL032HTAI21@TSOP48 [(SA247-B005)]
S29JL032HTAI22@TSOP48 [(SA247-B005)]
S29JL032HTAI31@TSOP48 [(SA247-B005)]

S29JL032HTAI32@TSOP48 [(SA247-B005)]
S29JL032HTAI41@TSOP48 [(SA247-B005)]
S29JL032HTAI42@TSOP48 [(SA247-B005)]
S29JL032HTFI01@TSOP48 [(SA247-B005)]
S29JL032HTFI02@TSOP48 [(SA247-B005)]
S29JL032HTFI21@TSOP48 [(SA247-B005)]
S29JL032HTFI22@TSOP48 [(SA247-B005)]
S29JL032HTFI31@TSOP48 [(SA247-B005)]
S29JL032HTFI32@TSOP48 [(SA247-B005)]
S29JL032HTFI41@TSOP48 [(SA247-B005)]
S29JL032HTFI42@TSOP48 [(SA247-B005)]
S29JL064HBAI00@FBGA63 [(SA642M-B026A-W048F001Y)]
S29JL064HBFI00@FBGA63 [(SA642M-B026A-W048F001Y)]
S29JL064HTAI00@TSOP48 [(SA247-B005)]
S29JL064HTAN00@TSOP48 [(SA247-B005)]
S29JL064HTFI00@TSOP48 [(SA247-B005)]
S29JL064HTFN00@TSOP48 [(SA247-B005)]
S29PL127J55TAI13@TSOP56 [(SA628-B097)]
S29PL127J55TAW13@TSOP56 [(SA628-B097)]
S29PL127J55TFI13@TSOP56 [(SA628-B097)]
S29PL127J55TFW13@TSOP56 [(SA628-B097)]
S29PL127J60TAI13@TSOP56 [(SA628-B097)]
S29PL127J60TAW13@TSOP56 [(SA628-B097)]
S29PL127J60TFI13@TSOP56 [(SA628-B097)]
S29PL127J60TFW13@TSOP56 [(SA628-B097)]
S29PL127J70TAI13@TSOP56 [(SA628-B097)]
S29PL127J70TAW13@TSOP56 [(SA628-B097)]
S29PL127J70TFI13@TSOP56 [(SA628-B097)]
S29PL127J70TFW13@TSOP56 [(SA628-B097)]
S29VS016K0PBJW00@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS016K0PBJW01@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS016KAABJW00@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS016KAABJW01@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS032K0PBJW00@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS032K0PBJW01@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS032KAABJW00@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS032KAABJW01@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS064K0PBJW00@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS064K0PBJW01@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS064KAABJW00@BGA44 [(SA733B-B206A-M044F001Y)]
S29VS064KAABJW01@BGA44 [(SA733B-B206A-M044F001Y)]
S29WS064J0PBAI00@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBAI01@FBGA80 [(SA642T-B093A-W080F001Y)]

S29WS064J0PBAI02@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBAI03@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBAW00@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBAW01@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBAW02@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBAW03@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBF100@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBF101@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBFW00@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0PBFW01@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBAI00@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBAI01@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBAI02@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBAI03@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBAW00@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBAW01@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBAW02@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBAW03@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBFI00@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBFI01@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBFW00@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J0SBFW01@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J1ABAI00@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J1ABAI01@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J1ABAW00@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS064J1ABAW01@FBGA80 [(SA642T-B093A-W080F001Y)]
S29WS128J0PBAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAI02@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAI03@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAI10@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAI11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAW02@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAW03@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAW10@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBF100@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBF101@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBF110@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBF111@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBFW00@FBGA84 [(SA642A-B093A-Y096F001Y)]

S29WS128J0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBFW10@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBAI02@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBAI03@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBAW02@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBAW03@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBFI00@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBFI01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBFW00@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J0SBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128J1ABAI00@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J1ABAI01@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J1ABAW00@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128J1ABAW01@FBGA80 [(SA642A-B093A-Y096F001Y)]
S29WS128N0LBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128N0LBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128N0LBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128N0LBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128N0PBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128N0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128N0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS128N0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0LBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0LBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0LBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0LBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0PBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0PBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0PBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0PBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0SBAW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0SBAW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0SBFW01@FBGA84 [(SA642A-B093A-Y096F001Y)]
S29WS256N0SBFW11@FBGA84 [(SA642A-B093A-Y096F001Y)]
S30ML01GP30TFE00@TSOP48 [(SA247-B005)]
S30ML01GP30TFE50@TSOP48 [(SA247-B005)]
S30ML01GP50TFE01@TSOP48 [(SA247-B005)]
S30ML01GP50TFE51@TSOP48 [(SA247-B005)]

S30ML02GP30TFE00@TSOP48 [(SA247-B005)]
S30ML02GP30TFE50@TSOP48 [(SA247-B005)]
S30ML02GP50TFE01@TSOP48 [(SA247-B005)]
S30ML02GP50TFE51@TSOP48 [(SA247-B005)]
S30ML128P30TFE00@TSOP48 [(SA247-B005)]
S30ML128P30TFE50@TSOP48 [(SA247-B005)]
S30ML128P50TFE01@TSOP48 [(SA247+B005)]
S30ML128P50TFE51@TSOP48 [(SA247+B005)]
S30ML256P30TFE00@TSOP48 [(SA247-B005)]
S30ML256P30TFE50@TSOP48 [(SA247-B005)]
S30ML256P50TFE01@TSOP48 [(SA247+B005)]
S30ML256P50TFE51@TSOP48 [(SA247+B005)]
S30ML512P50TFE01@TSOP48 [(SA247+B005)]
S30ML512P50TFE51@TSOP48 [(SA247+B005)]
S30MS01GP25TFW00@TSOP48 [(SA247-B005)]
S30MS01GP25TFW010@TSOP48 [(SA247-B005)]
S30MS01GP25TFW50@TSOP48 [(SA247-B005)]
S30MS01GP25TFW510@TSOP48 [(SA247-B005)]
S70PL254J00BAW91@FBGA64 [(SA642A-B079A-Y096F001)]
S70PL254J00BAW93@FBGA64 [(SA642A-B079A-Y096F001)]
S70PL254J00BAWA1@FBGA84 [(SA642A-B079A-Y096F001)]
S70PL254J00BAWA3@FBGA84 [(SA642A-B079A-Y096F001)]
S70PL254J00BFW91@FBGA64 [(SA642A-B079A-Y096F001)]
S70PL254J00BFW93@FBGA64 [(SA642A-B079A-Y096F001)]
S70PL254J00BFWA1@FBGA84 [(SA642A-B079A-Y096F001)]
S70PL254J00BFWA3@FBGA84 [(SA642A-B079A-Y096F001)]
S71AL016D02BAWB@FBGA56 [(SA642P-B032A-W056F001Y)]
S71AL016D02BAWT@FBGA56 [(SA642P-B032A-W056F001Y)]
S71AL016D02BFWB@FBGA56 [(SA642P-B032A-W056F001Y)]
S71AL016D02BFWT@FBGA56 [(SA642P-B032A-W056F001Y)]
S71AL016D04BAWB@FBGA56 [(SA642P-B032A-W056F001Y)]
S71AL016D04BAWT@FBGA56 [(SA642P-B032A-W056F001Y)]
S71AL016D04BFWB@FBGA56 [(SA642P-B032A-W056F001Y)]
S71AL016D04BFWT@FBGA56 [(SA642P-B032A-W056F001Y)]
S71GL016A40BAW1J@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL016A40BAW3J@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL016A40BFW1J@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL016A40BFW3J@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A08BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A08BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A40BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]

S71GL032A40BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A40BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A40BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032A80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032AA0BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032AA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032AA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032AA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032M40BAIBQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BAIFQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BAIKQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BAIPQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BAWBQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BAWFQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BAWKQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BAWPQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BFIBQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BFIFQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BFIKQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BFIPQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BFWBQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BFWFQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BFWKQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032M40BFWPQ@FBGA56 [(SA642B-B032A-Y072F001)]
S71GL032N40BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032N40BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032N80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032N80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032NA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL032NA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A08BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]

S71GL064A0ABAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A0ABAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A0ABFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A0ABFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A0ABFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A0ABFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A80BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A80BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A80BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A80BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064A80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BAI0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BAI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BFI0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BFI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064AA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064NA0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064NA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064NB0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL064NB0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71GL128NB0BAEAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAEAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAEAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAEAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAW9J@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BAW9K@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BAW9N@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BAW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BAW9T@FBGA64 [(SA642A-B079A-Y096F001Y)]

S71GL128NB0BAW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BAW9Y@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BAWAJ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAWAK@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAWAN@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAWAP@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAWAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAWAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAWAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BAWEJ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BAWEK@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BAWEN@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BAWEP@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BAWET@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BAWEU@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BAWEY@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BAWEZ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BFEAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFEAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFEAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFEAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFW9J@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BFW9K@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BFW9N@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BFW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BFW9T@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BFW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BFW9Y@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71GL128NB0BFWAJ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFWAK@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFWAN@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFWAP@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFWAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFWAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFWAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NB0BFWEJ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BFWEK@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BFWEN@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BFWEP@FBGA84 [(SA642A-B108A-Y096N001)]

S71GL128NB0BFWET@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BFWEU@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BFWFY@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NB0BFWFZ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL128NC0BAEAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BAEAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BAEAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BAWAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BAWAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BAWAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BAZAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BFEAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BFEAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BFEAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BFEAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BFWAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BFWAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BFWAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL128NC0BFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BAWAJ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BAWAK@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BAWAN@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BAWAP@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BAWAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BAWAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BAWAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BAWEJ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BAWEK@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BAWEN@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BAWEP@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BAWET@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BAWEU@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BAWEY@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BAWEZ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BFWAJ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BFWAK@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BFWAN@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BFWAP@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BFWAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BFWAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BFWAY@FBGA84 [(SA642A-B108A-Y096F001)]

S71GL256NB0BFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NB0BFW EJ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BFW EK@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BFW EN@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BFW EP@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BFW ET@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BFW EU@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BFW EY@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NB0BFW EZ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL256NC0BAEAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BAEAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BAEAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BAE AZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BAWAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BAWAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BAWAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BAWAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BF EAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BF EAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BF EAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BF EAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BFWAT@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BFWAU@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BFWAY@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL256NC0BFWAZ@FBGA84 [(SA642A-B108A-Y096F001)]
S71GL512NB0BAWEJ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BAWEK@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BAWEN@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BAWEP@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BAWET@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BAWEU@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BAWEY@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BAWEZ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BFW EJ@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BFW EK@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BFW EN@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BFW EP@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BFW ET@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BFW EU@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BFW EY@FBGA84 [(SA642A-B108A-Y096N001)]
S71GL512NB0BFW EZ@FBGA84 [(SA642A-B108A-Y096N001)]
S71JL064H80BAW01 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064H80BAW02 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]

S71JL064H80BAW03 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064H80BAW04 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064H80BAW10 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064H80BAW11 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064H80BAW12 (DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064HA0BAW01 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064HA0BAW02 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064HA0BAW10 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064HA0BAW11 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064HA0BAW12 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064HB0BAW00 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064HB0BAW01 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL064HB0BAW02 (DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]
S71JL128HB0BAW00 (DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
S71JL128HB0BAW01 (DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
S71JL128HB0BAW02 (DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
S71JL128HB0BAW03 (DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]
S71JL128HC0BAW00 (DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]
S71JL128HC0BAW01 (DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]
S71JL128HC0BAW02 (DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]
S71JL128HC0BAW03 (DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]
S71PL032J04BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J04BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J04BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J04BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J04BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J04BFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J04BFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J04BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J04BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J04BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J08BAE0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J08BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J08BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J08BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J08BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J40BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J40BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J40BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J40BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J40BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]

S71PL032J40BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BAWQ7@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BAWQF@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BFWQ7@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032J80BFWQF@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BAE07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BAE0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BAWQF@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL032JA0BFWQF@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BAI0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BFI0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]

S71PL064J08BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J08BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J0ABAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J0ABAW0S@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J0ABFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J0ABFW0S@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BAI0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BFI0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064J80BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BAI0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BAI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BAW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BAW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BFI05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BFI0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BFI0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BFW05@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BFW0P@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JA0BFW0Z@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JB0BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JB0BAI0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JB0BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JB0BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JB0BAW0U@FBGA56 [(SA642P-B079A-W056F001Y)]

S71PL064JB0BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JB0BFI0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JB0BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JB0BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL064JB0BFW0U@FBGA56 [(SA642P-B079A-W056F001Y)]
S71PL127JA0BAI9P@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JA0BAI9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JA0BAW9P@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JA0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JA0BFI9P@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JA0BFI9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JA0BFW9P@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JA0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JB0BAI97@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JB0BAI9U@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JB0BAI9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JB0BAW97@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JB0BAW9B@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JB0BAW9U@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JB0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JB0BFI97@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JB0BFI9U@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JB0BFI9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JB0BFW97@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JB0BFW9B@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JB0BFW9U@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JB0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JC0BAI97@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JC0BAI9U@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JC0BAI9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JC0BAW97@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JC0BAW9B@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JC0BAW9U@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JC0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JC0BFI97@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JC0BFI9U@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JC0BFI9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JC0BFW97@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JC0BFW9B@FBGA64 [(SA642P-B079A-W056F001Y)]
S71PL127JC0BFW9U@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127JC0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001)]
S71PL127NB0HAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL127NB0HAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]

S71PL127NB0HFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL127NB0HFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL127NC0HAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL127NC0HAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL127NC0HFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL127NC0HFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JA0BAW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JA0BFW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JB0BAW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JB0BAW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JB0BAW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JB0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JB0BFW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JB0BFW9P@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JB0BFW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JB0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JC0BAW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JC0BAW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JC0BAW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JC0BFW9B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JC0BFW9U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129JC0BFW9Z@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129NB0HAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129NB0HAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129NB0HFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129NB0HFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129NC0HAW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129NC0HAW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129NC0HFW4B@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL129NC0HFW4U@FBGA64 [(SA642A-B079A-Y096F001Y)]
S71PL191HB0BAI10@FBGA73 [(SA642A-B079A-Y096N001)]
S71PL191HB0BAW10@FBGA73 [(SA642A-B079A-Y096N001)]
S71PL191HB0BFI10@FBGA73 [(SA642A-B079A-Y096N001)]
S71PL191HB0BFW10@FBGA73 [(SA642A-B079A-Y096N001)]
S71PL191HC0BAI10@FBGA73 [(SA642A-B079A-Y096N001)]
S71PL191HC0BAW10@FBGA73 [(SA642A-B079A-Y096N001)]
S71PL191HC0BFI10@FBGA73 [(SA642A-B079A-Y096N001)]
S71PL191HC0BFW10@FBGA73 [(SA642A-B079A-Y096N001)]
S71PL193HB0BAI10@FBGA73 [(SA664J-B236A-M116F001Y)]
S71PL193HB0BAW10@FBGA73 [(SA664J-B236A-M116F001Y)]
S71PL193HB0BFI10@FBGA73 [(SA664J-B236A-M116F001Y)]
S71PL193HB0BFW10@FBGA73 [(SA664J-B236A-M116F001Y)]
S71PL193HC0BAI10@FBGA73 [(SA664J-B236A-M116F001Y)]

S71PL193HC0BAW10@FBGA73 [(SA664J-B236A-M116F001Y)]
S71PL193HC0BFI10@FBGA73 [(SA664J-B236A-M116F001Y)]
S71PL193HC0BFW10@FBGA73 [(SA664J-B236A-M116F001Y)]
S71PL254HC0BAW00@FBGA84 [(SA642A-B079A-Y096N001)]
S71PL254JB0BAIT7@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JB0BAITU@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JB0BAWT7@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JB0BAWTU@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JB0BFIT7@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JB0BFITU@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JB0BFWT7@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JB0BFWTU@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JC0BAITU@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JC0BAITZ@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JC0BAWTU@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JC0BAWTZ@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JC0BFITU@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JC0BFITZ@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JC0BFWTU@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JC0BFWTZ@FBGA84 [(SA642A-B079A-Y096F001)]
S71PL254JD0BAWTB@FBGA84 [(SA642A-B079A-Y096F001Y)]
S71PL254JD0BFWTB@FBGA84 [(SA642A-B079A-Y096F001Y)]
S71PL256NC0HAW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]
S71PL256NC0HAW5U@FBGA84 [(SA642A-B108A-Y096F001Y)]
S71PL256NC0HFW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]
S71PL256NC0HFW5U@FBGA84 [(SA642A-B108A-Y096F001Y)]
S71PL256ND0GAW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]
S71PL256ND0GFW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]
S71PL256ND0HAW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]
S71PL256ND0HFW5B@FBGA84 [(SA642A-B108A-Y096F001Y)]
S71PL258HC0BAW00@FBGA84 [(SA642A-B088A-Y096N001)]
S71PL512ND0JAW5B@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71PL512ND0JFW5B@FBGA84 [(SA642A-B158A-Y096F001Y)]
S71VS032K80ZJK01@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS032K80ZJK03@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS032KA0ZJK09@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS032KA0ZJK0B@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS032KA0ZJK11@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS032KA0ZJK13@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS032KA0ZJK19@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS032KA0ZJK1B@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS064KA0ZJK01@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS064KA0ZJK03@BGA44 [(SA733D-B212A-M044F001Y)]

S71VS064KA0ZJK09@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS064KA0ZJK0B@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS064KA0ZJK11@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS064KA0ZJK13@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS064KA0ZJK19@BGA44 [(SA733D-B212A-M044F001Y)]
S71VS064KA0ZJK1B@BGA44 [(SA733D-B212A-M044F001Y)]
S71WS064JA0BAI2A@FBGA80 [(SA642T-B134A-W080F001Y)]
S71WS064JA0BAI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]
S71WS064JA0BAW2A@FBGA80 [(SA642T-B134A-W080F001Y)]
S71WS064JA0BAW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]
S71WS064JA0BFI2A@FBGA80 [(SA642T-B134A-W080F001Y)]
S71WS064JA0BFI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]
S71WS064JA0BFW2A@FBGA80 [(SA642T-B134A-W080F001Y)]
S71WS064JA0BFW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]
S71WS064JB0BAI2A@FBGA80 [(SA642T-B134A-W080F001Y)]
S71WS064JB0BAI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]
S71WS064JB0BAW2A@FBGA80 [(SA642T-B134A-W080F001Y)]
S71WS064JB0BAW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]
S71WS064JB0BFI2A@FBGA80 [(SA642T-B134A-W080F001Y)]
S71WS064JB0BFI2Y@FBGA80 [(SA642T-B086A-W080F001Y)]
S71WS064JB0BFW2A@FBGA80 [(SA642T-B134A-W080F001Y)]
S71WS064JB0BFW2Y@FBGA80 [(SA642T-B086A-W080F001Y)]
S71WS128JA0BAIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JA0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JA0BAWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JA0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JA0BFIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JA0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JA0BFWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JA0BFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JB0BAIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JB0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JB0BAIAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS128JB0BAWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JB0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JB0BAWAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS128JB0BFIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JB0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JB0BFIAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS128JB0BFWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JB0BFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JB0BFWAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS128JC0BAE9A@FBGA84 [(SA642A-B134A-Y096F001Y)]

S71WS128JC0BAIA6@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JC0BAIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JC0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JC0BAIAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS128JC0BAWA6@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JC0BAWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JC0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JC0BAWAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS128JC0BFE9A@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JC0BFIA6@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JC0BFIAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JC0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JC0BFIAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS128JC0BFWA6@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JC0BFWAA@FBGA84 [(SA642A-B134A-Y096F001Y)]
S71WS128JC0BFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS128JC0BFWAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS128NB0BAWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BAWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BAWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BAWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BAWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BAWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BFWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BFWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BFWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BFWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BFWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NB0BFWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BAWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BAWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BAWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BAWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BAWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BAWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BFWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BFWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BFWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BFWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BFWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS128NC0BFWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256JC0BAIA6@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BAIAJ@FBGA84 [(SA642A-B109A-Y096F001)]

S71WS256JC0BAIAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS256JC0BAIT6@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BAITJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BAITY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS256JC0BAWA6@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BAWAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BAWAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS256JC0BAWT6@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BAWTJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BAWTY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS256JC0BFIA6@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BFIAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BFIAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS256JC0BFIT6@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BFITJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BFITY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS256JC0BFWA6@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BFWAJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BFWAY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS256JC0BFWT6@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BFWTJ@FBGA84 [(SA642A-B109A-Y096F001)]
S71WS256JC0BFWTY@FBGA84 [(SA642A-B086A-Y096F001)]
S71WS256NC0BAIAB@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAIAF@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAIAK@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAIAP@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAIAU@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAIAZ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAA@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAB@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAE@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAF@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAU@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BAWAZ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFIAB@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFIAF@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFIAK@FBGA84 [(SA642A-B139A-Y096F001Y)]

S71WS256NC0BFIAP@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFIAU@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFIAZ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAA@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAB@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAE@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAF@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAH@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAJ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAK@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAM@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAN@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAP@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAU@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256NC0BFWAZ@FBGA84 [(SA642A-B139A-Y096F001Y)]
S71WS256ND0BAIE3@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAIE7@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAIEK@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAIEP@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAIEU@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAIEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWE3@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWE7@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWEK@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWEP@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWEU@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWYH@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWYJ@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWYK@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWYM@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWYN@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BAWYP@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFIE3@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFIE7@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFIEK@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFIEP@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFIEU@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFIEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWE3@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWE7@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWEK@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWEP@FBGA84 [(SA642CC-B139A-W080F001Y)]

S71WS256ND0BFWEU@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWEZ@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWYH@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWYJ@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWYK@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWYM@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWYN@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS256ND0BFWYP@FBGA84 [(SA642CC-B139A-W080F001Y)]
S71WS512NC0BAIAB@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAIAF@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAIAK@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAIAP@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAIAU@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAIAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWAB@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWAF@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWAK@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWAP@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWAU@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWTA@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWTE@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWTH@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWTJ@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWTM@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BAWTN@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFIAB@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFIAF@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFIAK@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFIAP@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFIAU@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFIAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWAB@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWAF@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWAK@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWAP@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWAU@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWTA@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWTE@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWTH@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWTJ@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512NC0BFWTM@FBGA88 [(SA642A-B139A-Y096F001Y)]

S71WS512NC0BFWTN@FBGA88 [(SA642A-B139A-Y096F001Y)]
S71WS512ND0BAIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BAWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]
S71WS512ND0BFWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]
S75PL127JBDBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JBDBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JBDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JBDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JBEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JBEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JBEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JBEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JCDBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JCDBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JCDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JCDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JCEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JCEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]

S75PL127JCEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]
S75PL127JCEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]
S99-50001(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]
S99-50003(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]
S99-50005(2*S29WS128H)@FBGA88 [(SA642A-B123A-Y096F001Y)]
S99-50011(2*S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]
S99-50031(AM29BDS320)@FBGA56 [(SA644B-B025B-Y056F001Y)]
S99-50034-9N(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]
S99-50034-9P(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]
S99-50034-9Y(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]
S99-50034-9Z(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]
S99-50048(S29GL064N)@FBGA64 [(SA655E-B129A-T056F001Y)]
S99-50052(S29GL128N)@FBGA64 [(SA655E-B129A-T056F001Y)]
S99-50057(S29GL032A)@FBGA88 [(SA642W-B116A-W088F001Y)]
S99-50059(S29GL064A)@FBGA88 [(SA642A-B116A-Y096N001N)]
S99-50066(S29GL032M)@FBGA88 [(SA642A-B116A-Y096N001N)]
S99-50073(S29WS256N)@FBGA88 [(SA642A-B124A-Y096F001Y)]
S99-50074(2*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]
S99-50076(S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]
S99-50080(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]
S99-50080-LF(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]
S99-50085(S29WS256N)@FBGA88 [(SA642A-B112A-Y096F001Y)]
S99-50089(2*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]
S99-50109(2*S29WS256N)@FBGA88 [(SA642A-B138A-Y096F001Y)]
S99-50111(S29AL016DFFI02)@FBGA64 [(SA655F-B099A-W064F001Y)]
S99-50121-9Y@FBGA64 [(SA642A-B039A-Y096F001Y)]
S99-50121-9Y-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]
S99-50121-9Z@FBGA64 [(SA642A-B039A-Y096F001Y)]
S99-50121-9Z-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]
S99-50134(S29GL128N)@FBGA88 [(SA642R-B199A-T096F001Y)]
S99-50158(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]
S99-50158-LF(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]
S99-50183(S29GL256N)@FBGA64 [(SA655E-B129A-T056F001Y)]
S99PL128JC0BAWFC0@FBGA84 [(SA642A-B062A-Y096F001Y)]
S99PL128JC0BAWNB0@FBGA84 [(SA642A-B062A-Y096F001Y)]
S99PL128JC0BAWT10@FBGA84 [(SA642A-B062A-Y096F001Y)]
S99PL128JC0BAWUB0@FBGA84 [(SA642A-B062A-Y096F001Y)]
S99PL193JB0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)]
S99PL193JB0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)]
S99PL193JB0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)]
S99PL193JB0BAWUC@FBGA73 [(SA664J-B236A-M116F001Y)]
S99PL193JC0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)]
S99PL193JC0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)]

S99PL193JC0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)]

S99PL193JC0BAWUC@FBGA73 [(SA664J-B236A-M116F001Y)]

SPANSION-CUSTOMER

E (E) PROM / FRAM / NVRAM

S71PL129JB0BFW9U (ZX) @ FBGA64 [(SA642A-B079A-Y096F001Y)]

S75PL127JBEBAWKB (DX) @ FBGA84 [(SA642CC-B135A-W080F001Y)]

S75PL127JBEBAWKU (DX) @ FBGA84 [(SA642CC-B135A-W080F001Y)]

S75PL127JBEBFWKB (DX) @ FBGA84 [(SA642CC-B135A-W080F001Y)]

S75PL127JBEBFWKU (DX) @ FBGA84 [(SA642CC-B135A-W080F001Y)]

SSSC

MICROCONTROLLER

SSU7301

SSU7301@PLCC44

[(SA244)]

SSU7301@TQFP44 [(SA245A)]

SST

E (E) PROM / FRAM / NVRAM

SST25LF010@SOIC8 (4.0) [(SA602A)]

SST25LF010@SOIC8 (5.4)

[(SA605B)]

SST25LF010@WSON8 [(SA683)]

SST25LF010A@SOIC8 (4.0) [(SA602A)]

SST25LF010A@SOIC8 (5.4) [(SA605B)]

SST25LF010A@WSON8 [(SA683)]

SST25LF016A@SOIC8 (4.0) [(SA602A)]

SST25LF016A@SOIC8 (5.4) [(SA605A)]

SST25LF016A@WSON8 [(SA683)]

SST25LF016B@SOIC8 (4.0) [(SA602A)]

SST25LF016B@SOIC8 (5.4) [(SA605A)]

SST25LF016B@WSON8 [(SA683)]

SST25LF020@SOIC8 (4.0)

[(SA602A)]

SST25LF020@SOIC8 (5.4) [(SA605B)]

SST25LF020@WSON8

[(SA683)]
SST25LF020A@SOIC8(4.0) [(SA602A)]
SST25LF020A@SOIC8(5.4) [(SA605B)]
SST25LF020A@WSON8 [(SA683)] SST25LF040@SOIC8(4.0)
[(SA602A)]
SST25LF040@SOIC8(5.4) [(SA605B)] SST25LF040@WSON8
[(SA683)]
SST25LF040A@SOIC8(4.0) [(SA602A)]
SST25LF040A@SOIC8(5.4) [(SA605B)]
SST25LF040A@WSON8 [(SA683)] SST25LF080@SOIC8(4.0)
[(SA602A)]
SST25LF080@SOIC8(5.4) [(SA605B)] SST25LF080@WSON8
[(SA683)]
SST25LF080A@SOIC8(4.0) [(SA602A)]
SST25LF080A@SOIC8(5.4) [(SA605B)]
SST25LF080A@WSON8 [(SA683)] SST25VF010@SOIC8(4.0)
[(SA602A)]
SST25VF010@SOIC8(5.4) [(SA605B)] SST25VF010@WSON8
[(SA683)]
SST25VF010A@SOIC8(4.0) [(SA602A)]
SST25VF010A@SOIC8(5.4) [(SA605B)]
SST25VF010A@WSON8 [(SA683)]
SST25VF016B@SOIC8(4.0) [(SA602A)]
SST25VF016B@SOIC8(5.4) [(SA605A)]
SST25VF016B@WSON8 [(SA683)] SST25VF020@SOIC8(4.0)
[(SA602A)]
SST25VF020@SOIC8(5.4) [(SA605B)] SST25VF020@WSON8
[(SA683)]
SST25VF032B@SOIC8(4.0) [(SA602A)]
SST25VF032B@SOIC8(5.4) [(SA605A)]
SST25VF032B@WSON8 [(SA683)] SST25VF040@SOIC8(4.0)
[(SA602A)]
SST25VF040@SOIC8(5.4) [(SA605B)] SST25VF040@WSON8
[(SA683)]
SST25VF040B@SOIC8(4.0) [(SA602A)]
SST25VF040B@SOIC8(5.4) [(SA605A)]
SST25VF040B@WSON8 [(SA683)] SST25VF080@SOIC8(4.0)
[(SA602A)]
SST25VF080@SOIC8(5.4) [(SA605B)] SST25VF080@WSON8
[(SA683)]
SST25VF080B@SOIC8(4.0) [(SA602A)]
SST25VF080B@SOIC8(5.4) [(SA605A)]
SST25VF080B@WSON8 [(SA683)] SST25VF512@SOIC8(4.0)

[(SA602A)]	
SST25VF512@SOIC8(5.4) [(SA605B)]	SST25VF512@WSON8
[(SA683)]	
SST25VF512A@SOIC8(4.0) [(SA602A)]	
SST25VF512A@SOIC8(5.4) [(SA605B)]	
SST25VF512A@WSON8 [(SA683)]	SST25WF010@SOIC8
[(SA602A)]	
SST25WF020@SOIC8 [(SA602A)]	SST25WF040@SOIC8
[(SA602A)]	
SST25WF080@SOIC8 [(SA602A)]	SST25WF512@SOIC8
[(SA602A)]	
SST27SF010	SST27SF010@PLCC32
[(SA015A1T)]	
SST27SF010@TSOP32 [(SA410T)]	
SST27SF020	
SST27SF020@PLCC32 [(SA015A1T)]	SST27SF020@TSOP32
[(SA410T)]	
SST27SF256	SST27SF256@PLCC32
[(SA015A1T)]	
SST27SF256@VSOP32 [(SA620)]	
SST27SF512	
SST27SF512@PLCC32 [(SA015A1T)]	SST27SF512@VSOP32
[(SA620)]	
SST27VF010	SST27VF010@PLCC32
[(SA015A1T)]	
SST27VF010@TSOP32 [(SA410T)]	
SST27VF020	
SST27VF020@PLCC32 [(SA015A1T)]	SST27VF020@TSOP32
[(SA410T)]	
SST27VF040	SST27VF040@PLCC32
[(SA015A1T)]	
SST27VF040@TSOP32 [(SA410T)]	
SST27VF256	
SST27VF256@PLCC32 [(SA015A1T)]	SST27VF256@VSOP32
[(SA620)]	
SST27VF512	SST27VF512@PLCC32
[(SA015A1T)]	
SST27VF512@VSOP32 [(SA620)]	
SST28EE011	
SST28EE011@PLCC32 [(SA015A1T)]	SST28EE011@TSOP32
[(SA410T)]	
SST28LE011	SST28LE011@PLCC32
[(SA015A1T)]	

SST28LE011@TSOP32 [(SA410T)]	
SST28LF040	
SST28LF040@PLCC32 [(SA015A1T)]	SST28LF040@TSOP32
[(SA410T)]	
SST28SF040	SST28SF040@PLCC32
[(SA015A1T)]	
SST28SF040@TSOP32 [(SA410T)]	
SST28SF040A	
SST28SF040A@PLCC32 [(SA015A1T)]	SST28SF040A@TSOP32
[(SA410T)]	
SST28VE011	SST28VE011@PLCC32
[(SA015A1T)]	
SST28VE011@TSOP32 [(SA410T)]	
SST28VF040	
SST28VF040@PLCC32 [(SA015A1T)]	SST28VF040@TSOP32
[(SA410T)]	
SST28VF040A	SST28VF040A@PLCC32
[(SA015A1T)]	
SST28VF040A@TSOP32 [(SA410T)]	
SST29EE010	
SST29EE010@PLCC32 [(SA015A1T)]	SST29EE010@TSOP32
[(SA410T)]	
SST29EE020	SST29EE020@PLCC32
[(SA015A1T)]	
SST29EE020@TSOP32 [(SA410T)]	
SST29EE512	
SST29EE512@PLCC32 [(SA015A1T)]	SST29EE512@TSOP32
[(SA410T)]	
SST29LE010	SST29LE010@PLCC32
[(SA015A1T)]	
SST29LE010@TSOP32 [(SA410T)]	
SST29LE020	
SST29LE020@PLCC32 [(SA015A1T)]	SST29LE020@TSOP32
[(SA410T)]	
SST29LE512	SST29LE512@PLCC32
[(SA015A1T)]	
SST29LE512@TSOP32 [(SA410T)]	
SST29SF010	
SST29SF010@PLCC32 [(SA015A1T)]	SST29SF010@VSOP32
[(SA620)]	
SST29SF020	SST29SF020@PLCC32
[(SA015A1T)]	
SST29SF020@VSOP32 [(SA620)]	

SST29SF040

SST29SF040@PLCC32 [(SA015A1T)]
[(SA620)]

SST29SF040@VSOP32

SST29SF512

[(SA015A1T)]

SST29SF512@PLCC32

SST29SF512@VSOP32 [(SA620)]

SST29VE010

SST29VE010@PLCC32 [(SA015A1T)]
[(SA410T)]

SST29VE010@TSOP32

SST29VE020

[(SA015A1T)]

SST29VE020@PLCC32

SST29VE020@TSOP32 [(SA410T)]

SST29VE512

SST29VE512@PLCC32 [(SA015A1T)]
[(SA410T)]

SST29VE512@TSOP32

SST29VF010

[(SA015A1T)]

SST29VF010@PLCC32

SST29VF010@VSOP32 [(SA620)]

SST29VF020

SST29VF020@PLCC32 [(SA015A1T)]
[(SA620)]

SST29VF020@VSOP32

SST29VF040

[(SA015A1T)]

SST29VF040@PLCC32

SST29VF040@VSOP32 [(SA620)]

SST29VF512

SST29VF512@PLCC32 [(SA015A1T)]
[(SA620)]

SST29VF512@VSOP32

SST31LF021@VSOP32 [(SA620)]

[(SA623)]

SST31LF041@VSOP40

SST31LF041A@VSOP32 [(SA620)]

[(SA623)]

SST31LF043@VSOP40

SST31LF043A@VSOP32 [(SA620)]

SST32HF162@LFBGA48 [(SA655E-B026A-T064F001)]

SST32HF162@LFBGA48(SST adapter)

SST32HF162@TSOP48 [(SA247-

B005)]

SST32HF1621C@LFBGA62 [(SA642R-B083A-T096F001Y)]

SST32HF1621C@LFBGA63 [(SA642R-B032A-T096F001Y)]

SST32HF1622C@LFBGA62 [(SA642R-B083A-T096F001Y)]

SST32HF1622C@LFBGA63 [(SA642R-B032A-T096F001Y)]

SST32HF164@LFBGA48 [(SA655E-B026A-T064F001)]

SST32HF164@LFBGA48(SST adapter)

SST32HF164@TSOP48 [(SA247-

B005)]

SST32HF1641@LFBGA62 [(SA642R-B023A-T096F001Y)]

SST32HF1641@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1641C@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF1641C@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1642@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF1642@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1642C@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF1642C@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1681@LFBGA62 [(SA642R-B083A-T096F001Y)]
SST32HF1681@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF1682@LFBGA62 [(SA642R-B083A-T096F001Y)]
SST32HF1682@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF200@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF201@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF202@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF324@LFBGA62 [(SA642E-B023A-T072F001)]
SST32HF324@LFBGA63 [(SA642E-B032A-T072F001)]
SST32HF324@TFBGA63 [(SA642E-B032A-T072F001)]
SST32HF3241@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3241@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3241C@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3241C@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3242@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3242@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3242C@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3242C@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3244C@FBGA56 [(SA642R-B032A-T096F001Y)]
SST32HF324C@LFBGA62 [(SA642E-B023A-T072F001)]
SST32HF324C@LFBGA63 [(SA642E-B032A-T072F001)]
SST32HF324C@TFBGA63 [(SA642E-B032A-T072F001)]
SST32HF328@LFBGA62 [(SA642E-B023A-T072F001)]
SST32HF328@LFBGA63 [(SA642E-B032A-T072F001)]
SST32HF328@TFBGA63 [(SA642E-B032A-T072F001)]
SST32HF3281@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3281@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3281C@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3281C@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3282@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3282@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3282C@FBGA62 [(SA642R-B023A-T096F001Y)]
SST32HF3282C@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF3284@FBGA56 [(SA642R-B032A-T096F001Y)]
SST32HF328C@LFBGA62 [(SA642E-B023A-T072F001)]
SST32HF328C@LFBGA63 [(SA642E-B032A-T072F001)]

SST32HF328C@TFBGA63 [(SA642E-B032A-T072F001)]
SST32HF32A1@LFBGA62 [(SA642R-B083A-T096F001Y)]
SST32HF32A1@LFBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF32A4@FBGA56 [(SA642R-B032A-T096F001Y)]
SST32HF400@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF401@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF402@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF64161@LFBGA64 [(SA642R-B083A-T096F001Y)]
SST32HF64161C@LFBGA64 [(SA642R-B083A-T096F001Y)]
SST32HF6481@LFBGA64 [(SA642R-B083A-T096F001Y)]
SST32HF6481C@LFBGA64 [(SA642R-B083A-T096F001Y)]
SST32HF6482@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF6482@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF6482C@FBGA63 [(SA642R-B032A-T096F001Y)]
SST32HF6482C@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF64A1@FBGA63 [(SA642I-B032A-W080F001Y)]
SST32HF64A1@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF64A2@FBGA56 [(SA642R-B032A-T096F001Y)]
SST32HF64A2@FBGA63 [(SA642I-B032A-W080F001Y)]
SST32HF64A2@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF64B1@FBGA63 [(SA642I-B032A-W080F001Y)]
SST32HF64B1@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF64B2@FBGA63 [(SA642I-B032A-W080F001Y)]
SST32HF64B2@FBGA64 [(SA642R-B023A-T096F001Y)]
SST32HF800@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF802@LBGA48 [(SA655E-B026A-T064F001)]
SST32HF802@LFBGA48 [(SA642B-B026A-Y072F001)]
SST32HF802@LFBGA48(SST adapter)
SST34HF1601B@LFBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1601B@TSOP48 [(SA247-B005)]
SST34HF1601C@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1601C@FBGA62 [(SA642E-B023A-T072F001)]
SST34HF1602C@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1602C@FBGA62 [(SA642E-B023A-T072F001)]
SST34HF1621@LFBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1621A@LFBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1621A@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF1621C@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1621C@FBGA62 [(SA642E-B023A-T072F001)]
SST34HF1621S@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1622@LFBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1622C@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1622C@FBGA62 [(SA642E-B023A-T072F001)]

SST34HF1622S@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF162C@LBGA48 [(SA655E-B026A-T064F001)]
SST34HF162G@LBGA48 [(SA655E-B026A-T064F001)]
SST34HF162G@LFBGA48 [(SA642G-B026A-T048F001)]
SST34HF1641@LFBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1641A@LFBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1641A@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF1641C@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1641C@FBGA62 [(SA642E-B023A-T072F001)]
SST34HF1641D@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1641D@FBGA62 [(SA642E-B023A-T072F001)]
SST34HF1641J@FBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1641J@FBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF1641S@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1642@LFBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1642C@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1642C@FBGA62 [(SA642E-B023A-T072F001)]
SST34HF1642D@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1642D@FBGA62 [(SA642E-B023A-T072F001)]
SST34HF1642S@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF164C@LBGA48 [(SA655E-B026A-T064F001)]
SST34HF164G@LBGA48 [(SA655E-B026A-T064F001)]
SST34HF164G@LFBGA48 [(SA642G-B026A-T048F001)]
SST34HF1681@LFBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1681@LFBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF1681D@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1681D@FBGA62 [(SA642E-B023A-T072F001)]
SST34HF1681J@FBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF1681J@FBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF1682D@FBGA56 [(SA642E-B032A-T072F001)]
SST34HF1682D@FBGA62 [(SA642E-B023A-T072F001)]
SST34HF3243C@FBGA56 [(SA642I-B032A-W080F001Y)]
SST34HF3243C@FBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF3244@FBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF3244@FBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF3244C@FBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF3244C@FBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF3282@FBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF3282@FBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF3283@FBGA56 [(SA642I-B032A-W080F001Y)]
SST34HF3283@FBGA62 [(SA642R-B023A-T096F001Y)]
SST34HF3284@FBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF3284@FBGA62 [(SA642R-B023A-T096F001Y)]

SST34HF32A4@FBGA56 [(SA642R-B032A-T096F001Y)]
SST34HF32A4@FBGA62 [(SA642R-B023A-T096F001Y)]
SST36VF1601(B3K)@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST36VF1601(BK)@TFBGA48 [(SA642R-B026A-T096F001Y)]
SST36VF1601@TSOP48 [(SA247-B005)]
SST36VF1601C@FBGA48 [(SA642G-B026A-T048F001)]
SST36VF1601C@TSOP48 [(SA247-B005)]
SST36VF1601E@FBGA48 [(SA642G-B026A-T048F001)]
SST36VF1601E@TSOP48 [(SA247-B005)]
SST36VF1601G@LFBGA56 [(SA642A-B032A)]
SST36VF1601G@TFBGA48 [(SA642G-B026A-T048F001)]
SST36VF1601G@TSOP48 [(SA247-B005)]
SST36VF1602(B3K)@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST36VF1602(BK)@TFBGA48 [(SA642R-B026A-T096F001Y)]
SST36VF1602@TSOP48 [(SA247-B005)]
SST36VF1602C@FBGA48 [(SA642G-B026A-T048F001)]
SST36VF1602C@TSOP48 [(SA247-B005)]
SST36VF1602E@FBGA48 [(SA642G-B026A-T048F001)]
SST36VF1602E@TSOP48 [(SA247-B005)]
SST36VF1602G@LFBGA56 [(SA642A-B032A)]
SST36VF1602G@TFBGA48 [(SA642G-B026A-T048F001)]
SST36VF1602G@TSOP48 [(SA247-B005)]
SST36VF3203@FBGA48 [(SA642G-B026A-T048F001Y)]
SST36VF3203@TSOP48 [(SA247-B005)]
SST36VF3204@FBGA48 [(SA642G-B026A-T048F001Y)]
SST36VF3204@TSOP48 [(SA247-B005)]
SST37VF010 [(SA015A1T)] SST37VF010@PLCC32
SST37VF010@VSOP32 [(SA620)]
SST37VF020 [(SA015A1T)] SST37VF020@VSOP32
SST37VF020@PLCC32 [(SA620)]
SST37VF040 [(SA015A1T)] SST37VF040@PLCC32
SST37VF040@VSOP32 [(SA620)]
SST37VF512 [(SA015A1T)] SST37VF512@VSOP32
SST37VF512@PLCC32 [(SA620)]
SST39LF010@PLCC32 [(SA015A1T)]
SST39LF010@TFBGA48 [(SA642G-B026A-T048F001)]
SST39LF010@VSOP32 [(SA620)]
SST39LF010@WFBGA48 [(SA716A-B120A-M048F001Y)]
SST39LF016@FBGA48 [(SA642G-B026A-T048F001Y)]

SST39LF016@TSOP40 [(SA409T)] SST39LF020@PLCC32
[(SA015A1T)]
SST39LF020@TFBGA48 [(SA642G-B026A-T048F001)]
SST39LF020@VSOP32 [(SA620)]
SST39LF020@WFBGA48 [(SA716A-B120A-M048F001Y)]
SST39LF040@PLCC32 [(SA015A1T)] SST39LF040@VSOP32
[(SA620)]
SST39LF080@FBGA48 [(SA642G-B026A-T048F001Y)]
SST39LF080@TSOP40 [(SA409T)] SST39LF080Q@TSOP40
[(SA409T)]
SST39LF100@FBGA48 [(SA642B-B026A-Y072F001)]
SST39LF100@VSOP40 [(SA623)]
SST39LF160@TFBGA48 [(SA642B-B026A-Y072F001)]
SST39LF160@TSOP48 [(SA247-B005)]
SST39LF200A@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39LF200A@TSOP48 [(SA247-B005)]
SST39LF200A@WFBGA48 [(SA716B-B119B-T048F001Y)]
SST39LF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39LF400A@TSOP48 [(SA247-B005)]
SST39LF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]
SST39LF512@PLCC32 [(SA015A1T)] SST39LF512@VSOP32
[(SA620)]
SST39LF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39LF800A@TSOP48 [(SA247-B005)]
SST39LF800A@WFBGA48 [(SA716B-B119B-T048F001Y)]
SST39LH010 SST39LH010@PLCC32
[(SA015A1T)]
SST39LH010@TSOP32 [(SA410T)]
SST39LH040
SST39LH040@PLCC32 [(SA015A1T)] SST39LH040@TSOP32
[(SA410T)]
SST39LH512 SST39LH512@PLCC32
[(SA015A1T)]
SST39LH512@TSOP32 [(SA410T)]
SST39SF010
SST39SF010@PLCC32 [(SA015A1T)] SST39SF010@VSOP32
[(SA620)]
SST39SF010A SST39SF010A@PLCC32
[(SA015A1T)]
SST39SF010A@VSOP32 [(SA620)]
SST39SF020
SST39SF020@PLCC32 [(SA015A1T)] SST39SF020@VSOP32
[(SA620)]

SST39SF020A SST39SF020A@PLCC32
 [(SA015A1T)]
 SST39SF020A@VSOP32 [(SA620)]
 SST39SF020P
 SST39SF020P@PLCC32 [(SA015A1T)] SST39SF020P@VSOP32
 [(SA620)]
 SST39SF040 SST39SF040@PLCC32
 [(SA015A1T)]
 SST39SF040@VSOP32 [(SA620)]
 SST39SF040P
 SST39SF040P@PLCC32 [(SA015A1T)] SST39SF040P@VSOP32
 [(SA620)]
 SST39SF512 SST39SF512@PLCC32
 [(SA015A1T)]
 SST39SF512@VSOP32 [(SA620)]
 SST39SF512A
 SST39SF512A@PLCC32 [(SA015A1T)] SST39SF512A@VSOP32
 [(SA620)]
 SST39VF010 SST39VF010@PLCC32
 [(SA015A1T)]
 SST39VF010@TFBGA48 [(SA642G-B026A-T048F001)]
 SST39VF010@VSOP32 [(SA620)]
 SST39VF016@FBGA48 [(SA642G-B026A-T048F001Y)]
 SST39VF016@TSOP40 [(SA409T)] SST39VF016Q@TSOP40
 [(SA409T)]
 SST39VF020 SST39VF020@PLCC32
 [(SA015A1T)]
 SST39VF020@TFBGA48 [(SA642G-B026A-T048F001)]
 SST39VF020@VSOP32 [(SA620)]
 SST39VF020P
 SST39VF020P@PLCC32 [(SA015A1T)] SST39VF020P@VSOP32
 [(SA620)]
 SST39VF040 SST39VF040@PLCC32
 [(SA015A1T)]
 SST39VF040@VSOP32 [(SA620)]
 SST39VF040P
 SST39VF040P@PLCC32 [(SA015A1T)] SST39VF040P@VSOP32
 [(SA620)]
 SST39VF080@FBGA48 [(SA642G-B026A-T048F001Y)]
 SST39VF080@TSOP40 [(SA409T)] SST39VF080Q@TSOP40
 [(SA409T)]
 SST39VF088@TSOP48 [(SA247-B005)]
 SST39VF100@FBGA48 [(SA642B-B026A-Y072F001)]

SST39VF100@VSOP40 [(SA623)]
SST39VF160@TFBGA48 [(SA642B-B026A-Y072F001)]
SST39VF160@TSOP48 [(SA247-B005)]
SST39VF1601@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39VF1601@TSOP48 [(SA247-B005)]
SST39VF1602@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39VF1602@TSOP48 [(SA247-B005)]
SST39VF160Q@TSOP48 [(SA247-B005)]
SST39VF1681@TFBGA48 [(SA642B-B026A-Y072F001)]
SST39VF1681@TSOP48 [(SA247-B005)]
SST39VF1682@TFBGA48 [(SA642B-B026A-Y072F001)]
SST39VF1682@TSOP48 [(SA247-B005)]
SST39VF200A@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39VF200A@TSOP48 [(SA247-B005)]
SST39VF200A@WFBGA48 [(SA716B-B119B-T048F001Y)]
SST39VF320@TFBGA48 [(SA642G-B026A-T048F001)]
SST39VF320@TSOP48 [(SA247-B005)]
SST39VF3201@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39VF3201@TSOP48 [(SA247-B005)]
SST39VF3202@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39VF3202@TSOP48 [(SA247-B005)]
SST39VF400@TSOP48 [(SA247-B005)]
SST39VF400A(Low)@TSOP48 [(SA247)]
SST39VF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39VF400A@TSOP48 [(SA247-B005)]
SST39VF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]
SST39VF400Q@TSOP48 [(SA247-B005)]
SST39VF512 SST39VF512@PLCC32
[(SA015A1T)]
SST39VF512@VSOP32 [(SA620)]
SST39VF6401@TFBGA48 [(SA642R-B026A-T096F001Y)]
SST39VF6401@TSOP48 [(SA247-B005)]
SST39VF6401B@FBGA48 [(SA642R-B026A-T096F001Y)]
SST39VF6401B@TSOP48 [(SA247-B005)]
SST39VF6402@TFBGA48 [(SA642R-B026A-T096F001Y)]
SST39VF6402@TSOP48 [(SA247-B005)]
SST39VF6402B@FBGA48 [(SA642R-B026A-T096F001Y)]
SST39VF6402B@TSOP48 [(SA247-B005)]
SST39VF800@TSOP48 [(SA247-B005)]
SST39VF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39VF800A@TSOP48 [(SA247-B005)]
SST39VF800A@WFBGA48 [(SA716B-B119B-T048F001Y)]
SST39VF800Q@TSOP48 [(SA247-B005)]

SST39WF1601@FBGA48 [(SA642G-B026A-T048F001Y)]
SST39WF1601@WFBGA48 [(SA716C-B119A-T048F001Y)]
SST39WF1602@FBGA48 [(SA642G-B026A-T048F001Y)]
SST39WF1602@WFBGA48 [(SA716C-B119A-T048F001Y)]
SST39WF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39WF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]
SST39WF800A(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]
SST39WF800A(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]
SST39WF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST39WF800B(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]
SST39WF800B(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]
SST39WF800B@TFBGA48 [(SA642G-B026A-T048F001Y)]
SST45LF010@SOIC8 [(SA602A)] SST45LF010@WSON8
[(SA683)]
SST45VF010@SOIC8 [(SA602A)] SST45VF020@SOIC8
[(SA602A)]
SST45VF512@SOIC8 [(SA602A)] SST49LF002@PLCC32
[(SA015A1T)]
SST49LF002@VSOP32 [(SA620)] SST49LF002A@PLCC32
[(SA015A1T)]
SST49LF002A@VSOP32 [(SA620)] SST49LF002B@PLCC32
[(SA015A1T)]
SST49LF003A@PLCC32 [(SA015A1T)] SST49LF003A@VSOP32
[(SA620)]
SST49LF003B@PLCC32 [(SA015A1T)] SST49LF004@PLCC32
[(SA015A1T)]
SST49LF004@VSOP32 [(SA620)] SST49LF004A@PLCC32
[(SA015A1T)]
SST49LF004A@VSOP32 [(SA620)] SST49LF004B@PLCC32
[(SA015A1T)]
SST49LF004B@VSOP32 [(SA620)] SST49LF004B@VSOP40
[(SA409T)]
SST49LF004C@PLCC32 [(SA015A1T)] SST49LF004C@VSOP32
[(SA620)]
SST49LF008@PLCC32 [(SA015A1T)] SST49LF008@VSOP32
[(SA620)]
SST49LF008A@PLCC32 [(SA015A1T)] SST49LF008A@TSOP40
[(SA409T)]
SST49LF008A@VSOP32 [(SA620)] SST49LF008C@PLCC32
[(SA015A1T)]
SST49LF008C@VSOP32 [(SA620)] SST49LF016C@PLCC32
[(SA015A1T)]
SST49LF016C@TSOP40 [(SA409T)] SST49LF016C@VSOP32

[(SA620)]	
SST49LF020@PLCC32 [(SA015A1T)]	SST49LF020@VSOP32
[(SA620)]	
SST49LF020A@PLCC32 [(SA015A1T)]	SST49LF020A@VSOP32
[(SA620)]	
SST49LF030A@PLCC32 [(SA015A1T)]	SST49LF030A@VSOP32
[(SA620)]	
SST49LF040@PLCC32 [(SA015A1T)]	SST49LF040@VSOP32
[(SA620)]	
SST49LF040A@PLCC32 [(SA015A1T)]	SST49LF040A@VSOP32
[(SA620)]	
SST49LF040B@PLCC32 [(SA015A1T)]	SST49LF040B@TSOP40
[(SA409T)]	
SST49LF040B@VSOP32 [(SA620)]	SST49LF080A@PLCC32
[(SA015A1T)]	
SST49LF080A@VSOP32 [(SA620)]	SST49LF160C@PLCC32
[(SA015A1T)]	
SST49LF160C@TSOP32 [(SA620)]	

MICROCONTROLLER

SST65P542R@SOIC28 [(SA404)]	
SST89C54	
SST89C54@PLCC44 [(SA244)]	SST89C54@TQFP44
[(SA245A)]	
SST89C58	SST89C58@PLCC44
[(SA244)]	
SST89C58@TQFP44 [(SA245A)]	SST89C58RC@PLCC44
[(SA244)]	
SST89C58RC@TQFP44 [(SA245A)]	SST89C58RC@WQFN40
[(SA750)]	
SST89E516RD	SST89E516RD@PLCC44
[(SA244)]	
SST89E516RD@TQFP44 [(SA245A)]	
SST89E516RD2	
SST89E516RD2@PLCC44 [(SA244)]	SST89E516RD2@TQFP44
[(SA245A)]	
SST89E52RC	SST89E52RC@PLCC44
[(SA244)]	
SST89E52RC@TQFP44 [(SA245A)]	
SST89E52RD	
SST89E52RD@PLCC44 [(SA244)]	SST89E52RD@TQFP44

[(SA245A)]
SST89E52RD2 SST89E52RD2@PLCC44
[(SA244)]
SST89E52RD2@TQFP44 [(SA245A)]
SST89E54RC
SST89E54RC@PLCC44 [(SA244)] SST89E54RC@TQFP44
[(SA245A)]
SST89E54RD SST89E54RD@PLCC44
[(SA244)]
SST89E54RD@TQFP44 [(SA245A)]
SST89E54RD2
SST89E54RD2@PLCC44 [(SA244)] SST89E54RD2@TQFP44
[(SA245A)]
SST89E554RC SST89E554RC@PLCC44
[(SA244)]
SST89E554RC@TQFP44 [(SA245A)]
SST89E564RD
SST89E564RD@PLCC44 [(SA244)] SST89E564RD@TQFP44
[(SA245A)]
SST89E58RD SST89E58RD@PLCC44
[(SA244)]
SST89E58RD@TQFP44 [(SA245A)]
SST89E58RD2
SST89E58RD2@PLCC44 [(SA244)] SST89E58RD2@TQFP44
[(SA245A)]
SST89V516RD SST89V516RD@PLCC44
[(SA244)]
SST89V516RD@TQFP44 [(SA245A)]
SST89V516RD2
SST89V516RD2@PLCC44 [(SA244)] SST89V516RD2@TQFP44
[(SA245A)]
SST89V52RD SST89V52RD@PLCC44
[(SA244)]
SST89V52RD@TQFP44 [(SA245A)]
SST89V52RD2
SST89V52RD2@PLCC44 [(SA244)] SST89V52RD2@TQFP44
[(SA245A)]
SST89V54RD2 SST89V54RD2@PLCC44
[(SA244)]
SST89V54RD2@TQFP44 [(SA245A)]
SST89V554RC
SST89V554RC@PLCC44 [(SA244)] SST89V554RC@TQFP44
[(SA245A)]

SST89V564RD	SST89V564RD@PLCC44
[(SA244)]	
SST89V564RD@TQFP44 [(SA245A)]	
SST89V58RD2	
SST89V58RD2@PLCC44 [(SA244)]	SST89V58RD2@TQFP44
[(SA245A)]	

ST

E (E) PROM / FRAM / NVRAM

ET2716	
ETC2716	
ETC2732	
M24128	
M24128@MLP8 [(SA724)]	M24128@SOIC8
[(SA602A)]	
M24128@TSOP8 [(SA026)]	
M24164	
M24164@SOIC8 [(SA602A)]	
M24256	
M24256@MLP8 [(SA724)]	M24256@TSOP8
[(SA026)]	
M24256[3.9]@SOIC8 [(SA602A)]	M24256[5.5]@SOIC8
[(SA605A)]	
M24512	M24512@SOIC8
[(SA605A)]	
M24512@TSOP8 [(SA026)]	
M24C01	
M24C01@MLP8 [(SA724)]	M24C01@SOIC8
[(SA602A)]	
M24C01R	M24C01R@MLP8
[(SA724)]	
M24C01R@SOIC8 [(SA602A)]	M24C01R@TSOP8
[(SA026)]	
M24C01W	M24C01W@MLP8
[(SA724)]	
M24C01W@SOIC8 [(SA602A)]	M24C01W@TSOP8
[(SA026)]	
M24C02	M24C02@MLP8
[(SA724)]	
M24C02@SOIC8 [(SA602A)]	

M24C02R	
M24C02R@MLP8 [(SA724)]	M24C02R@SOIC8
[(SA602A)]	
M24C02R@TSOP8 [(SA026)]	
M24C02W	
M24C02W@MLP8 [(SA724)]	M24C02W@SOIC8
[(SA602A)]	
M24C02W@TSOP8 [(SA026)]	
M24C04	
M24C04@MLP8 [(SA724)]	M24C04@SOIC8
[(SA602A)]	
M24C04R	M24C04R@MLP8
[(SA724)]	
M24C04R@SOIC8 [(SA602A)]	M24C04R@TSOP8
[(SA026)]	
M24C04W	M24C04W@MLP8
[(SA724)]	
M24C04W@SOIC8 [(SA602A)]	M24C04W@TSOP8
[(SA026)]	
M24C08	M24C08@MLP8
[(SA724)]	
M24C08@MSOP8 [(SA695A)]	M24C08@SOIC8
[(SA602A)]	
M24C08@TSOP8 [(SA026)]	
M24C08R	
M24C08R@MLP8 [(SA724)]	M24C08R@MSOP8
[(SA695A)]	
M24C08R@SOIC8 [(SA602A)]	M24C08R@TSOP8
[(SA026)]	
M24C08W	M24C08W@MLP8
[(SA724)]	
M24C08W@MSOP8 [(SA695A)]	M24C08W@SOIC8
[(SA602A)]	
M24C08W@TSOP8 [(SA026)]	M24C128
(BN)	
M24C128(MN)@SOIC8 [(SA605A)]	M24C128(MW)@SOIC8
[(SA602A)]	
M24C128@MLP8 [(SA724)]	M24C128B
(BN)	
M24C128B(MN)@SOIC8 [(SA605A)]	M24C128B(MW)@SOIC8
[(SA602A)]	
M24C128B@MLP8 [(SA724)]	
M24C16	

M24C16@MLP8 [(SA724)]	M24C16@SOIC8
[(SA602A)]	
M24C16R	M24C16R@MLP8
[(SA724)]	
M24C16R@SOIC8 [(SA602A)]	M24C16R@TSOP8
[(SA026)]	
M24C16W	M24C16W@MLP8
[(SA724)]	
M24C16W@SOIC8 [(SA602A)]	M24C16W@TSOP8
[(SA026)]	
M24C256(BN)	M24C256(MN)@SOIC8
[(SA605A)]	
M24C256(MW)@SOIC8 [(SA602A)]	M24C256@MLP8
[(SA724)]	
M24C256A(BN)	M24C256A(MN)@SOIC8
[(SA605A)]	
M24C256A(MW)@SOIC8 [(SA602A)]	M24C256A@MLP8
[(SA724)]	
M24C256B(BN)	M24C256B(MN)@SOIC8
[(SA605A)]	
M24C256B(MW)@SOIC8 [(SA602A)]	M24C256B@MLP8
[(SA724)]	
M24C256W(BN)	M24C256W(MN)@SOIC8
[(SA605A)]	
M24C256W(MW)@SOIC8 [(SA602A)]	M24C256W@MLP8
[(SA724)]	
M24C32(BN)	M24C32(DL)@TSSOP14
[(SA026)]	
M24C32(DW)@TSSOP8 [(SA602A)]	M24C32(MN)@SOIC8
[(SA605A)]	
M24C32(MW)@SOIC8 [(SA602A)]	M24C32@MLP8
[(SA724)]	
M24C32W(BN)	M24C32W(DL)@TSSOP14
[(SA026)]	
M24C32W(DW)@TSSOP8 [(SA602A)]	M24C32W(MN)@SOIC8
[(SA605A)]	
M24C32W(MW)@SOIC8 [(SA602A)]	M24C32W@MLP8
[(SA724)]	
M24C64(BN)	M24C64(DL)@TSSOP14
[(SA026)]	
M24C64(DW)@TSSOP8 [(SA602A)]	M24C64(MN)@SOIC8
[(SA605A)]	
M24C64(MW)@SOIC8 [(SA602A)]	M24C64@MLP8

[(SA724)]	
M24C64W(BN)	M24C64W(DL)@TSSOP14
[(SA026)]	
M24C64W(DW)@TSSOP8 [(SA602A)]	M24C64W(MN)@SOIC8
[(SA605A)]	
M24C64W(MW)@SOIC8 [(SA602A)]	M24C64W@MLP8
[(SA724)]	
M24CL04B	M24CL04B@MLP8
[(SA724)]	
M24CL04B@SOIC8 [(SA602A)]	M24CL04B@TSOP8
[(SA026)]	
M24E16	M24E32
(BN)	
M24E32(DW)@TSSOP8 [(SA602A)]	M24E32(MN)@SOIC8
[(SA605A)]	
M24E32(MW)@SOIC8 [(SA602A)]	
M24W01	
M24W01@SOIC8 [(SA602A)]	
M24W02	
M24W02@SOIC8 [(SA602A)]	
M24W04	
M24W04@SOIC8 [(SA602A)]	
M24W08	
M24W08@SOIC8 [(SA602A)]	
M24W16	
M24W16@SOIC8 [(SA602A)]	
M25C01	
M25C02	
M25C04	
M25C08	
M25C16	
M25E16	M25P05@SOIC8
[(SA602A)]	
M25P05@VQFPN8 [(SA684)]	M25P05-A@SOIC8
[(SA602A)]	
M25P05-A@TSSOP8 [(SA605A)]	M25P05-A@VDFPN8
[(SA684)]	
M25P10@SOIC8 [(SA602A)]	M25P10@VQFPN8
[(SA684)]	
M25P10-A@SOIC8 [(SA602A)]	M25P10-A@VFQFPN8
[(SA684)]	
M25P128@SOIC16 [(SA404)]	
M25P128@SOIC16(ISP) [ISP-HEADER01]	

M25P128@VDFPN8 [(SA684)]
M25P128@VDFPN8(ISP) [ISP-HEADER01]
M25P16@SOIC16 [(SA404)]
M25P16@SOIC16(ISP) [ISP-HEADER01]
M25P16@SOIC8(150mil) [(SA602A)]
M25P16@SOIC8(150mil)(ISP) [ISP-HEADER01]
M25P16@SOIC8(200mil) [(SA605A)]
M25P16@SOIC8(200mil)(ISP) [ISP-HEADER01]
M25P16@VDFPN8 [(SA684)]
M25P16@VDFPN8(ISP) [ISP-HEADER01]
M25P16@VFQFPN8 [(SA683)]
M25P16@VFQFPN8(ISP) [ISP-HEADER01]
M25P20@SOIC8 [(SA602A)] M25P20@VFQFPN8
[(SA684)]
M25P32(Fast Mode)@SOIC16 [(SA404)]
M25P32(Fast Mode)@VQFPN8 [(SA684)]
M25P32@SOIC16 [(SA404)]
M25P32@SOIC16(ISP) [ISP-HEADER01]
M25P32@SOIC8 [(SA605A)] M25P32@SOIC8(ISP) [ISP-
HEADER01]
M25P32@VDFPN8 [(SA684)]
M25P32@VDFPN8(ISP) [ISP-HEADER01]
M25P32@VFQFPN8 [(SA683)]
M25P32@VFQFPN8(ISP) [ISP-HEADER01]
M25P40@SOIC8 [(SA602A)] M25P40@VFQFPN8
[(SA684)]
M25P64(Fast Mode)@SOIC16 [(SA404)]
M25P64(Fast Mode)@VDFPN8 [(SA684)]
M25P64@SOIC16 [(SA404)]
M25P64@SOIC16(ISP) [ISP-HEADER01]
M25P64@VDFPN8 [(SA684)]
M25P64@VDFPN8(ISP) [ISP-HEADER01]
M25P80@SOIC16 [(SA404)] M25P80@SOIC8
[(SA605A)]
M25P80@VFQFPN8 [(SA684)] M25PE10@SOIC8
[(SA602A)]
M25PE10@SOIC8(ISP) [ISP-HEADER01]
M25PE10@VQFPN8 [(SA683)]
M25PE10@VQFPN8(ISP) [ISP-HEADER01]
M25PE16@SOIC8 [(SA023A)] M25PE16@VQFPN8
[(SA683)]
M25PE20@SOIC8 [(SA602A)]
M25PE20@SOIC8(ISP) [ISP-HEADER01]

M25PE20@VQFPN8 [(SA683)]
M25PE20@VQFPN8(ISP) [ISP-HEADER01]
M25PE40@SOIC8 [(SA023A)]
M25PE40@SOIC8(ISP) [ISP-HEADER01]
M25PE40@VQFPN8 [(SA683)]
M25PE40@VQFPN8(ISP) [ISP-HEADER01]
M25PE80@SOIC8 [(SA023A)]
M25PE80@SOIC8(ISP) [ISP-HEADER01]
M25PE80@VQFPN8 [(SA683)]
M25PE80@VQFPN8(ISP) [ISP-HEADER01]
M25PX32@SOIC16 [(SA404)] M25PX32@SOIC8
[(SA023A)]
M25PX32@VFQFPN8 [(SA683)] M25PX64@SOIC16
[(SA404)]
M25PX64@VDFPN8 [(SA684)]
M25W01
M25W02
M25W04
M25W08
M25W16
M25W166
M27128A
M2716
M2716F1
M27256
M27256A
M2732A
M27512
M2764
M2764A
M27C1000 M27C1000@PLCC32
[(SA015A1T)]
M27C1000@TSOP32 [(SA410T)]
M27C1001
M27C1001@PLCC32 [(SA015A1T)] M27C1001@TSOP32
[(SA410T)]
M27C1024 M27C1024@PLCC44
[(SA244)]
M27C128B
M27C16
M27C160 M27C160@PLCC44
[(SA244)]
M27C160@PSOP44 [(SA638)]

M27C160K	
M27C160K@PLCC44 [(SA244)]	M27C160K@PSOP44
[(SA638)]	
M27C2001	M27C2001@PLCC32
[(SA015A1T)]	
M27C2001@TSOP32 [(SA410T)]	
M27C202	
M27C202@PLCC44 [(SA244)]	M27C202@TSOP40
[(SA409T)]	
M27C256B	M27C256B@PLCC32
[(SA015A1T)]	
M27C32	
M27C322	
M27C322@SDIP42 [(SA028)]	
M27C400	
M27C4001	M27C4001@PLCC32
[(SA015A1T)]	
M27C4001@TSOP32 [(SA410T)]	
M27C4002	
M27C4002@PLCC44 [(SA244)]	
M27C405	
M27C405@PLCC32 [(SA015A1T)]	M27C405@TSOP32
[(SA410T)]	
M27C512	M27C512@PLCC32
[(SA015A1T)]	
M27C513	
M27C516	
M27C516@PLCC44 [(SA244)]	
M27C64A	
M27C64A@PLCC32 [(SA015A1T)]	
M27C800	
M27C800@PLCC44 [(SA244)]	M27C800@PSOP44
[(SA638)]	
M27C801	M27C801@PLCC32
[(SA015A1T)]	
M27C801@TSOP32 [(SA410T)]	
M27HC641	
M27HC641@PLCC28 [(SA008A)]	
M27HC642	
M27HC642@PLCC28 [(SA008A)]	
M27V101	
M27V101@PLCC32 [(SA015A1T)]	M27V101@TSOP32
[(SA410T)]	

M27V102 [(SA244)]	M27V102@PLCC44
M27V160 [(SA244)]	M27V160@PLCC44
M27V160@PSOP44 [(SA638)]	
M27V160K M27V160K@PLCC44 [(SA244)] [(SA638)]	M27V160K@PSOP44
M27V201 [(SA015A1T)]	M27V201@PLCC32
M27V201@TSOP32 [(SA410T)]	
M27V256 M27V322 [(SA028)]	M27V322@SDIP42
M27V401 [(SA015A1T)]	M27V401@PLCC32
M27V401@TSOP32 [(SA410T)]	
M27V402 M27V402@PLCC44 [(SA244)] [(SA409T)]	M27V402@TSOP40
M27V405 [(SA015A1T)]	M27V405@PLCC32
M27V405@TSOP32 [(SA410T)]	
M27V512 M27V512@PLCC32 [(SA015A1T)] [(SA430T)]	M27V512@TSOP28
M27V800 [(SA244)]	M27V800@PLCC44
M27V801 [(SA015A1T)]	M27V801@PLCC32
M27V801@TSOP32 [(SA410T)] [(SA638)]	M27W016@PSOP44
M27W016@TSOP48 [(SA247-B005)] [(SA638)]	M27W032@PSOP44
M27W032@TSOP48 [(SA247-B005)] [(SA638)]	M27W064@PSOP44
M27W064@TSOP48 [(SA247-B005)]	
M27W101 M27W101@PLCC32 [(SA015A1T)] [(SA410T)]	M27W101@TSOP32
M27W102 [(SA244)]	M27W102@PLCC44
M27W160	M27W160@PLCC44

[(SA244)]
M27W160@PSOP44 [(SA638)]
M27W201
M27W201@PLCC32 [(SA015A1T)] M27W201@TSOP32
[(SA410T)]
M27W202 M27W202@PLCC44
[(SA244)]
M27W202@TSOP40 [(SA409T)]
M27W400
M27W400@PLCC44 [(SA244)]
M27W401
M27W401@PLCC32 [(SA015A1T)] M27W401@TSOP32
[(SA410T)]
M27W402 M27W402@PLCC44
[(SA244)]
M27W402@TSOP40 [(SA409T)]
M27W512
M27W512@PLCC32 [(SA015A1T)] M27W512@TSOP28
[(SA430T)]
M27W800 M27W800@PLCC44
[(SA244)]
M27W801 M27W801@PLCC32
[(SA015A1T)]
M27W801@TSOP32 [(SA410T)]
M28010
M28010@PLCC32 [(SA015A1T)] M28010@TSOP32
[(SA410T)]
M28010R M28010R@PLCC32
[(SA015A1T)]
M28010R@TSOP32 [(SA410T)]
M28010W
M28010W@PLCC32 [(SA015A1T)] M28010W@TSOP32
[(SA410T)]
M28256 M28256@PLCC32
[(SA015A1T)]
M28256@TSOP28 [(SA430T)]
M28C010
M28C010@PLCC32 [(SA015A1T)] M28C010@TSOP32
[(SA410T)]
M28C010R M28C010R@PLCC32
[(SA015A1T)]
M28C010R@TSOP32 [(SA410T)]
M28C010W

M28C010W@PLCC32 [(SA015A1T)] [(SA410T)]	M28C010W@TSOP32
M28C16@PLCC32 [(SA015A1T)] [(SA404)]	M28C17@SOIC28
M28C64 [(SA015A1T)]	M28C64@PLCC32
M28C64@TSOP28 [(SA430T)] M28C64C	
M28C64C@PLCC32 [(SA015A1T)] [(SA404)]	M28C64C@SOIC28
M28C64C@TSOP28 [(SA430T)] M28C64X	
M28C64X@PLCC32 [(SA015A1T)] [(SA430T)]	M28C64X@TSOP28
M28F101 [(SA015A1T)]	M28F101@PLCC32
M28F101@TSOP32 [(SA410T)] M28F102	
M28F102@PLCC44 [(SA244)] [(SA409T)]	M28F102@TSOP40
M28F151 [(SA015A1T)]	M28F151@PLCC32
M28F151@TSOP32 [(SA410T)] M28F201	
M28F201@PLCC32 [(SA015A1T)] [(SA410T)]	M28F201@TSOP32
M28F211@TSOP40 [(SA409T)] [(SA638)]	M28F220@PSOP44
M28F220@TSOP48 [(SA247-B005)] [(SA409T)]	M28F221@TSOP40
M28F256 [(SA015A1T)]	M28F256@PLCC32
M28F256@TSOP32 [(SA410T)] [(SA409T)]	M28F411@TSOP40
M28F421@TSOP40 [(SA409T)] M28F512	
M28F512@PLCC32 [(SA015A1T)] [(SA410T)]	M28F512@TSOP32
M28LV64 [(SA015A1T)]	M28LV64@PLCC32
M28LV64@TSOP28 [(SA430T)] M28R400CB@FBGA48 [(SA634A-B005A-Y048F001)]	
M28R400CT@FBGA48 [(SA634A-B005A-Y048F001)]	

M28V411@TSOP40 [(SA409T)] M28V421@TSOP40
[(SA409T)]
M28W160B@FBGA48 [(SA634A-B005A-Y048F001)]
M28W160B@TSOP48 [(SA247-B005)]
M28W160BB@FBGA48 [(SA634A-B005A-Y048F001)]
M28W160BB@TSOP48 [(SA247-B005)]
M28W160BT@FBGA48 [(SA634A-B005A-Y048F001)]
M28W160BT@TSOP48 [(SA247-B005)]
M28W160CB@FBGA48 [(SA634A-B005A-Y048F001)]
M28W160CB@TSOP48 [(SA247-B005)]
M28W160CT@FBGA48 [(SA634A-B005A-Y048F001)]
M28W160CT@TSOP48 [(SA247-B005)]
M28W160ECB@FBGA48 [(SA634A-B005A-Y048F001Y)]
M28W160ECB@TSOP48 [(SA247-B005)]
M28W160ECT@FBGA48 [(SA634A-B005A-Y048F001Y)]
M28W160ECT@TSOP48 [(SA247-B005)]
M28W160T@FBGA48 [(SA634A-B005A-Y048F001)]
M28W160T@TSOP48 [(SA247-B005)]
M28W320CB@FBGA48 [(SA634A-B005A-Y048F001)]
M28W320CB@TSOP48 [(SA247-B005)]
M28W320CT@FBGA48 [(SA634A-B005A-Y048F001)]
M28W320CT@TSOP48 [(SA247-B005)]
M28W320ECB@FBGA48 [(SA634A-B005A-Y048F001)]
M28W320ECB@TSOP48 [(SA247-B005)]
M28W320ECT@FBGA48 [(SA634A-B005A-Y048F001)]
M28W320ECT@TSOP48 [(SA247-B005)]
M28W320FCB@FBGA48 [(SA634A-B005A-Y048F001Y)]
M28W320FCB@TSOP48 [(SA247-B005)]
M28W320FCT@FBGA48 [(SA634A-B005A-Y048F001Y)]
M28W320FCT@TSOP48 [(SA247-B005)]
M28W320FSB@FBGA47 [(SA714B-B026A-T048F001Y)]
M28W320FSB@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W320FST@FBGA47 [(SA714B-B026A-T048F001Y)]
M28W320FST@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W320FSU(Double)@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W320FSU@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W320HSB@FBGA47 [(SA714B-B026A-T048F001Y)]
M28W320HSB@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W320HST@FBGA47 [(SA714B-B026A-T048F001Y)]
M28W320HST@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W320HSU(Double)@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W320HSU@FBGA47 [(SA714B-B026A-T048F001Y)]
M28W320HSU@FBGA64 [(SA655E-B090A-T064F001Y)]

M28W640ECB@FBGA48 [(SA634A-B005A-Y048F001)]
M28W640ECB@TSOP48 [(SA247-B005)]
M28W640ECT@FBGA48 [(SA634A-B005A-Y048F001)]
M28W640ECT@TSOP48 [(SA247-B005)]
M28W640FCB@FBGA48 [(SA634A-B005A-Y048F001Y)]
M28W640FCB@TSOP48 [(SA247-B005)]
M28W640FCT@FBGA48 [(SA634A-B005A-Y048F001Y)]
M28W640FCT@TSOP48 [(SA247-B005)]
M28W640FSB@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W640FST@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W640FSU@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W640HSB@FBGA48 [(SA714B-B026A-T048F001Y)]
M28W640HSB@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W640HST@FBGA48 [(SA714B-B026A-T048F001Y)]
M28W640HST@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W640HSU@FBGA48 [(SA714B-B026A-T048F001Y)]
M28W640HSU@FBGA64 [(SA655E-B090A-T064F001Y)]
M28W800B@FBGA48 [(SA634A-B005A-Y048F001)]
M28W800B@TSOP48 [(SA247-B005)]
M28W800BB@FBGA48 [(SA634A-B005A-Y048F001)]
M28W800BB@TSOP48 [(SA247-B005)]
M28W800BT@FBGA48 [(SA634A-B005A-Y048F001)]
M28W800BT@TSOP48 [(SA247-B005)]
M28W800CB@FBGA48 [(SA634A-B005A-Y048F001)]
M28W800CB@TSOP48 [(SA247-B005)]
M28W800CT@FBGA48 [(SA634A-B005A-Y048F001)]
M28W800CT@TSOP48 [(SA247-B005)]
M28W800T@FBGA48 [(SA634A-B005A-Y048F001)]
M28W800T@TSOP48 [(SA247-B005)]
M29DW128F@FBGA64 [(SA655E-B099A-T064F001Y)]
M29DW128F@TSOP56 [(SA628-B102)]
M29DW323DB@TFBGA48 [(SA642E-B026A-T072F001)]
M29DW323DB@TFBGA63 [(SA642E-B026A-T072F001)]
M29DW323DB@TSOP48 [(SA247-B005)]
M29DW323DT@TFBGA48 [(SA642E-B026A-T072F001)]
M29DW323DT@TFBGA63 [(SA642E-B026A-T072F001)]
M29DW323DT@TSOP48 [(SA247-B005)]
M29DW324DB@TFBGA48 [(SA642E-B026A-T072F001)]
M29DW324DB@TFBGA63 [(SA642E-B026A-T072F001)]
M29DW324DB@TSOP48 [(SA247-B005)]
M29DW324DT@TFBGA48 [(SA642E-B026A-T072F001)]
M29DW324DT@TFBGA63 [(SA642E-B026A-T072F001)]
M29DW324DT@TSOP48 [(SA247-B005)]

M29DW640D@FBGA63 [(SA642E-B026A-T072F001N)]
M29DW640D@TSOP48 [(SA247-B005)]
M29DW640F@FBGA48 [(SA642G-B026A-T048F001Y)]
M29DW640F@TSOP48 [(SA247-B005)]
M29DW641F@FBGA48 [(SA642G-B026A-T048F001Y)]
M29DW641F@TSOP48 [(SA247-B005)]
M29F002B
M29F002B@PLCC32 [(SA015A1T)] M29F002B@TSOP32
[(SA410T)]
M29F002BB M29F002BB@PLCC32
[(SA015A1T)]
M29F002BB@TSOP32 [(SA410T)]
M29F002BNT
M29F002BNT@PLCC32 [(SA015A1T)] M29F002BNT@TSOP32
[(SA410T)]
M29F002BT M29F002BT@PLCC32
[(SA015A1T)]
M29F002BT@TSOP32 [(SA410T)]
M29F002T
M29F002T@PLCC32 [(SA015A1T)] M29F002T@TSOP32
[(SA410T)]
M29F010B M29F010B@PLCC32
[(SA015A1T)]
M29F010B@TSOP32 [(SA410T)] M29F016B@PSOP44
[(SA638)]
M29F016B@TSOP40 [(SA409T)] M29F016D@PSOP44
[(SA638)]
M29F016D@TSOP40 [(SA409T)] M29F032D@TSOP40
[(SA409T)]
M29F040 M29F040@PLCC32
[(SA015A1T)]
M29F040@TSOP32 [(SA410T)]
M29F040B
M29F040B@PLCC32 [(SA015A1T)] M29F040B@TSOP32
[(SA410T)]
M29F080A@PSOP44 [(SA638)] M29F080A@TSOP40
[(SA409T)]
M29F080D@PSOP44 [(SA638)] M29F080D@TSOP40
[(SA409T)]
M29F100B@PSOP44 [(SA638-B006)] M29F100B@TSOP48 [(SA247-
B005)]
M29F100T@PSOP44 [(SA638-B006)] M29F100T@TSOP48 [(SA247-
B005)]

M29F102B@PLCC44 [(SA244)]	M29F102B@TSOP40
[(SA623)]	
M29F102BB@PLCC44 [(SA244)]	M29F102BB@TSOP40
[(SA623)]	
M29F160BB@TSOP48 [(SA247-B005)]	M29F160BT@TSOP48 [(SA247-
B005)]	
M29F200B@PSOP44 [(SA638-B006)]	M29F200B@TSOP48 [(SA247-
B005)]	
M29F200BB@PSOP44 [(SA638-B006)]	M29F200BB@TSOP48 [(SA247-
B005)]	
M29F200BT@PSOP44 [(SA638-B006)]	M29F200BT@TSOP48 [(SA247-
B005)]	
M29F200T@PSOP44 [(SA638-B006)]	M29F200T@TSOP48 [(SA247-
B005)]	
M29F400B@PSOP44 [(SA638-B006)]	M29F400B@TSOP48 [(SA247-
B005)]	
M29F400BB@PSOP44 [(SA638-B006)]	M29F400BB@TSOP48 [(SA247-
B005)]	
M29F400BT@PSOP44 [(SA638-B006)]	M29F400BT@TSOP48 [(SA247-
B005)]	
M29F400T@PSOP44 [(SA638-B006)]	M29F400T@TSOP48 [(SA247-
B005)]	
M29F512B@PLCC32 [(SA015A1T)]	M29F512B@TSOP32
[(SA620)]	
M29F800AB@PSOP44 [(SA638-B006)]	M29F800AB@TSOP48 [(SA247-
B005)]	
M29F800AT@PSOP44 [(SA638-B006)]	M29F800AT@TSOP48 [(SA247-
B005)]	
M29F800DB@PSOP44 [(SA638)]	M29F800DB@TSOP48 [(SA247-
B005)]	
M29F800DT@PSOP44 [(SA638)]	M29F800DT@TSOP48 [(SA247-
B005)]	
M29KW016E@PSOP44 [(SA638)]	
M29KW016E@TFBGA48 [(SA642E-B026A-T072F001)]	
M29KW016E@TSOP48 [(SA247-B005)]	
M29KW032E@TFBGA48 [(SA642E-B026A-T072F001)]	
M29KW032E@TSOP48 [(SA247-B005)]	
M29KW064E@TFBGA48 [(SA642E-B026A-T072F001)]	
M29KW064E@TSOP48 [(SA247-B005)]	M29V040@PLCC32
[(SA015A1T)]	
M29V040@TSOP32 [(SA410T)]	M29W004B@TSOP40
[(SA409T)]	
M29W004BB@TSOP40 [(SA409T)]	M29W004BT@TSOP40

[(SA409T)]
 M29W004T@TSOP40 [(SA409T)] M29W008AB@TSOP40
 [(SA409T)]
 M29W008AT@TSOP40 [(SA409T)] M29W008B@TSOP40
 [(SA409T)]
 M29W008T@TSOP40 [(SA409T)] M29W010B@PLCC32
 [(SA015A1T)]
 M29W010B@TSOP32 [(SA410T)]
 M29W017D@TFBGA48 [(SA642B-B026A-Y072F001)]
 M29W017D@TSOP40 [(SA409T)]
 M29W022BB
 M29W022BB@PLCC32 [(SA015A1T)] M29W022BB@TSOP32
 [(SA410T)]
 M29W022BT M29W022BT@PLCC32
 [(SA015A1T)]
 M29W022BT@TSOP32 [(SA410T)] M29W040@PLCC32
 [(SA015A1T)]
 M29W040@TSOP32 [(SA410T)] M29W040B@PLCC32
 [(SA015A1T)]
 M29W040B@TSOP32 [(SA410T)] M29W102BB@TSOP40
 [(SA623)]
 M29W102BT@TSOP40 [(SA623)] M29W116BB@TSOP40
 [(SA409T)]
 M29W116BT@TSOP40 [(SA409T)]
 M29W128FH@FBGA64 [(SA655E-B099A-T064F001Y)]
 M29W128FH@TSOP56 [(SA628-B102)]
 M29W128FL@FBGA64 [(SA655E-B099A-T064F001Y)]
 M29W128FL@TSOP56 [(SA628-B102)]
 M29W128GH@FBGA64 [(SA655E-B099A-T064F001Y)]
 M29W128GH@TSOP56 [(SA628-B102)]
 M29W128GL@FBGA64 [(SA655E-B099A-T064F001Y)]
 M29W128GL@TSOP56 [(SA628-B102)]
 M29W160BB@LBGA48 [(SA642G-B026A-T048F001Y)]
 M29W160BB@PSOP44 [(SA638)] M29W160BB@TSOP48 [(SA247-
 B005)]
 M29W160BT@LBGA48 [(SA642G-B026A-T048F001Y)]
 M29W160BT@PSOP44 [(SA638)] M29W160BT@TSOP48 [(SA247-
 B005)]
 M29W160DB@LBGA48 [(SA642G-B026A-T048F001Y)]
 M29W160DB@PSOP44 [(SA638)] M29W160DB@TSOP48 [(SA247-
 B005)]
 M29W160DT@LBGA48 [(SA642G-B026A-T048F001Y)]
 M29W160DT@PSOP44 [(SA638)] M29W160DT@TSOP48 [(SA247-

B005)]
M29W160EB@LBGA48 [(SA642G-B026A-T048F001Y)]
M29W160EB@PSOP44 [(SA638)] M29W160EB@TSOP48 [(SA247-
B005)]
M29W160ET@LBGA48 [(SA642G-B026A-T048F001Y)]
M29W160ET@PSOP44 [(SA638)] M29W160ET@TSOP48 [(SA247-
B005)]
M29W160FB@TSOP48 [(SA247-B005)] M29W160FT@TSOP48 [(SA247-
B005)]
M29W200BB@PSOP44 [(SA638)] M29W200BB@TSOP48 [(SA247-
B005)]
M29W200BT@PSOP44 [(SA638)] M29W200BT@TSOP48 [(SA247-
B005)]
M29W320DB@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W320DB@FBGA63 [(SA642DD-B026A-W063F001Y)]
M29W320DB@TSOP48 [(SA247-B005)]
M29W320DT@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W320DT@FBGA63 [(SA642DD-B026A-W063F001Y)]
M29W320DT@TSOP48 [(SA247-B005)]
M29W320EB@FBGA48 [(SA642G-B026A-T048F001)]
M29W320EB@TSOP48 [(SA247-B005)]
M29W320ET@FBGA48 [(SA642G-B026A-T048F001)]
M29W320ET@TSOP48 [(SA247-B005)] M29W400B@PSOP44
[(SA638)]
M29W400B@TSOP48 [(SA247-B005)]
M29W400BB@LBGA48 [(SA642G-B026A-T048F001Y)]
M29W400BB@PSOP44 [(SA638)] M29W400BB@TSOP48 [(SA247-
B005)]
M29W400BT@LBGA48 [(SA642G-B026A-T048F001Y)]
M29W400BT@PSOP44 [(SA638)] M29W400BT@TSOP48 [(SA247-
B005)]
M29W400DB(ZA)@LBGA48 [(SA642N-B026A-W048F001Y)]
M29W400DB(ZE)@LBGA48 [(SA642G-B026A-T048F001Y)]
M29W400DB@PSOP44 [(SA638)] M29W400DB@TSOP48 [(SA247-
B005)]
M29W400DT(ZA)@LBGA48 [(SA642N-B026A-W048F001Y)]
M29W400DT(ZE)@LBGA48 [(SA642G-B026A-T048F001Y)]
M29W400DT@PSOP44 [(SA638)] M29W400DT@TSOP48 [(SA247-
B005)]
M29W400T@PSOP44 [(SA638)] M29W400T@TSOP48 [(SA247-
B005)]
M29W512B@PLCC32 [(SA015A1T)] M29W512B@TSOP32
[(SA620)]

M29W640DB@FBGA63 [(SA642E-B026A-T072F001)]
M29W640DB@TSOP48 [(SA247-B005)]
M29W640DT@FBGA63 [(SA642E-B026A-T072F001)]
M29W640DT@TSOP48 [(SA247-B005)]
M29W640FB@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640FB@TSOP48 [(SA247-B005)]
M29W640FT@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640FT@TSOP48 [(SA247-B005)]
M29W640GB@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640GB@FBGA64 [(SA655E-B099A-T064F001Y)]
M29W640GB@TSOP48 [(SA247-B005)] M29W640GB@TSOP56 [(SA628-B102)]
M29W640GH@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640GH@FBGA64 [(SA655E-B099A-T064F001Y)]
M29W640GH@TSOP48 [(SA247-B005)] M29W640GH@TSOP56 [(SA628-B102)]
M29W640GL@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640GL@FBGA64 [(SA655E-B099A-T064F001Y)]
M29W640GL@TSOP48 [(SA247-B005)] M29W640GL@TSOP56 [(SA628-B102)]
M29W640GSB@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640GSB@FBGA64 [(SA655E-B099A-T064F001Y)]
M29W640GSB@TSOP48 [(SA247-B005)] M29W640GSB@TSOP56 [(SA628-B102)]
M29W640GSH@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640GSH@FBGA64 [(SA655E-B099A-T064F001Y)]
M29W640GSH@TSOP48 [(SA247-B005)] M29W640GSH@TSOP56 [(SA628-B102)]
M29W640GSL@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640GSL@FBGA64 [(SA655E-B099A-T064F001Y)]
M29W640GSL@TSOP48 [(SA247-B005)] M29W640GSL@TSOP56 [(SA628-B102)]
M29W640GST@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640GST@FBGA64 [(SA655E-B099A-T064F001Y)]
M29W640GST@TSOP48 [(SA247-B005)] M29W640GST@TSOP56 [(SA628-B102)]
M29W640GT@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W640GT@FBGA64 [(SA655E-B099A-T064F001Y)]
M29W640GT@TSOP48 [(SA247-B005)] M29W640GT@TSOP56 [(SA628-B102)]
M29W641DH@TSOP48 [(SA247-B005)] M29W641DL@TSOP48 [(SA247-B005)]
M29W641DU@FBGA63 [(SA642E-B026A-T072F001)]

M29W800AB@LBGA48 [(SA642G-B026A-T048F001Y)]
M29W800AB@PSOP44 [(SA638)] M29W800AB@TSOP48 [(SA247-B005)]
M29W800AT@LBGA48 [(SA642G-B026A-T048F001Y)]
M29W800AT@PSOP44 [(SA638)] M29W800AT@TSOP48 [(SA247-B005)]
M29W800B@PSOP44 [(SA638)] M29W800B@TSOP48 [(SA247-B005)]
M29W800DB@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W800DB@PSOP44 [(SA638)] M29W800DB@TSOP48 [(SA247-B005)]
M29W800DT@FBGA48 [(SA642G-B026A-T048F001Y)]
M29W800DT@PSOP44 [(SA638)] M29W800DT@TSOP48 [(SA247-B005)]
M29W800T@PSOP44 [(SA638)] M29W800T@TSOP48 [(SA247-B005)]
M30L0R7000B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M30L0R7000T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M30L0R8000B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M30L0R8000T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M30W0R6600T0@LFBGA88 [(SA642A-B061A-Y096F001)]
M30WR128B@LFBGA88 [(SA642A-B061A-Y096F001)]
M34C02 M34C02@MSOP8
[(SA666)]
M34C02@SOIC8 [(SA602A)] M34C02@TSOP8
[(SA026)]
M34D32 M34D32@SOIC8
[(SA602A)]
M34D32@TSSOP8 [(SA026)]
M34D64 M34D64@TSSOP8
M34D64@SOIC8 [(SA602A)]
[(SA026)]
M34E02 M34E02@MSOP8
[(SA666)]
M34E02@SOIC8 [(SA602A)] M34E02@TSOP8
[(SA026)]
M35080 M35080@SOIC8
[(SA602A)]
M36A0W5020B0@FBGA66 [(SA642E-B023A-T072F001Y)]
M36A0W5020T0@FBGA66 [(SA642E-B023A-T072F001Y)]
M36A0W5030B0@FBGA66 [(SA642E-B023A-T072F001Y)]
M36A0W5030T0@FBGA66 [(SA642E-B023A-T072F001Y)]
M36A0W5040B0@FBGA66 [(SA642E-B023A-T072F001Y)]

M36A0W5040B1@FBGA66 [(SA642E-B023A-T072F001Y)]
M36A0W5040T0@FBGA66 [(SA642E-B023A-T072F001Y)]
M36A0W5040T1@FBGA66 [(SA642E-B023A-T072F001Y)]
M36D0R5030B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]
M36D0R5030B0(Q_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]
M36D0R5030T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]
M36D0R5030T0(Q_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]
M36D0R5040B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]
M36D0R5040B0(Q_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]
M36D0R5040T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]
M36D0R5040T0(Q_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]
M36D0R6040B0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]
M36D0R6040B0(Q_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]
M36D0R6040T0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]
M36D0R6040T0(Q_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]
M36DR232A@FBGA66 [(SA642E-B023A-T072F001Y)]
M36DR232B@FBGA66 [(SA642E-B023A-T072F001Y)]
M36DR432AD@FBGA66 [(SA642E-B023A-T072F001Y)]
M36DR432BD@FBGA66 [(SA642E-B023A-T072F001Y)]
M36L0R7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0R8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7060B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7060T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T8050B1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T8050T1@FBGA88 [(SA642R-B124A-T096F001Y)]

M36L0T8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36L0T8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]
M36LLR8760B1@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8760D1@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8760M1@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8760T1@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8860B1@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8860D1@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8860M1@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8860T1@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8870B0@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8870B1@FBGA88 [(SA642A-B113A-Y096F001Y)]
M36LLR8870D0@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8870D1@FBGA88 [(SA642A-B113A-Y096F001Y)]
M36LLR8870M0@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8870M1@FBGA88 [(SA642A-B113A-Y096F001Y)]
M36LLR8870T0@FBGA88 [(SA642R-B113A-T096F001Y)]
M36LLR8870T1@FBGA88 [(SA642A-B113A-Y096F001Y)]
M36W0R5020B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5020B0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5020T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5020T0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5030B0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5030T0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5040B0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5040L3@FBGA88 [(SA642R-B180-T096F001Y)]
M36W0R5040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5040T0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R5040U3@FBGA88 [(SA642R-B180-T096F001Y)]
M36W0R6030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6030B0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6030T0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6040B0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0R6040L3@FBGA88 [(SA642R-B180-T096F001Y)]
M36W0R6040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]

M36W0R6040T0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0R6040U3@FBGA88 [(SA642R-B180-T096F001Y)]
M36W0R6050B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6050B0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6050B1@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6050L0@FBGA88 [(SA642R-B180-T096F001Y)]
M36W0R6050T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6050T0(Q_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6050T1@FBGA88 [(SA642R-B107A-T096F001Y)]
M36W0R6050U0@FBGA88 [(SA642R-B180-T096F001Y)]
M36W0T5040B1@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T5040T1@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T6040B0@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T6040T0@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]
M36W0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36W0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]
M36W216BI@LFBGA66 [(SA642E-B041A-T072F001)]
M36W216TI@LFBGA66 [(SA642E-B041A-T072F001)]
M36W432BG@LFBGA66 [(SA642E-B041A-T072F001)]
M36W432TG@LFBGA66 [(SA642E-B041A-T072F001)]
M36W864BE@LFBGA67 [(SA642E-B041A-T072F001)]
M36W864TE@LFBGA67 [(SA642E-B041A-T072F001)]
M36WWR6650B0@LFBGA88 [(SA642A-B076A-Y096F001)]
M36WWR6650D0@LFBGA88 [(SA642A-B076A-Y096F001)]
M36WWR6650T0@LFBGA88 [(SA642A-B076A-Y096F001)]
M45PE10@SOIC8 [(SA602A)] M45PE10@VQFPN8
[(SA683)]
M45PE16@SOIC8 [(SA023A)] M45PE16@VQFPN8
[(SA683)]
M45PE20@SOIC8 [(SA602A)]
M45PE20@SOIC8(ISP) [ISP-HEADER01]
M45PE20@VQFPN8 [(SA683)]
M45PE20@VQFPN8(ISP) [ISP-HEADER01]
M45PE40@SOIC8 [(SA023A)]
M45PE40@SOIC8(ISP) [ISP-HEADER01]
M45PE40@VQFPN8 [(SA683)]
M45PE40@VQFPN8(ISP) [ISP-HEADER01]
M45PE80@SOIC16 [(SA023A)]
M45PE80@SOIC16(ISP) [ISP-HEADER01]
M45PE80@SOIC8 [(SA023A)]

M45PE80@SOIC8(ISP) [ISP-HEADER01]
M45PE80@VQFPN8 [(SA683)]
M45PE80@VQFPN8(ISP) [ISP-HEADER01]
M48C02
M48C02B
M48C12
M48C12B
M48T02
M48T02B
M48T08
M48T12
M48T128V
M48T128Y
M48T129V
M48T129Y
M48T12B
M48T18
M48T30
M48T30Y
M48T32
M48T32Y
M48T35
[(SA404)]
M48T35AV
[(SA630)]
M48T35AY
[(SA630)]
M48T35Y
[(SA404)]
M48T512AV
M48T512AY
M48T512V
M48T512Y
M48T513V
M48T513Y
M48T559
[(SA630)]
M48T559Y
[(SA630)]
M48T58
[(SA404)]
M48T58Y
[(SA404)]

M48T35@SOIC28
M48T35AV@SOIC28
M48T35AY@SOIC28
M48T35Y@SOIC28
M48T559@SOIC28
M48T559Y@SOIC28
M48T58@SOIC28
M48T58Y@SOIC28

M48T59	M48T59@SOIC28
[(SA404)]	
M48T59V	M48T59V@SOIC28
[(SA404)]	
M48T59Y	M48T59Y@SOIC28
[(SA404)]	
M48Z02	
M48Z02B	
M48Z08	
M48Z12	
M48Z128	
M48Z128V	
M48Z128Y	
M48Z129V	
M48Z129Y	
M48Z12B	
M48Z18	
M48Z30	
M48Z30Y	
M48Z32	
M48Z32Y	
M48Z35	
M48Z35@SOIC28 [(SA630)]	
M48Z35Y	
M48Z35Y@SOIC28 [(SA630)]	
M48Z512AV	
M48Z512AY	
M48Z512V	
M48Z512Y	
M48Z513V	
M48Z513Y	
M48Z58	
M48Z58@SOIC28 [(SA404)]	
M48Z58Y	
M48Z58Y@SOIC28 [(SA404)]	
M48Z59	
M48Z59@SOIC28 [(SA404)]	
M48Z59W	
M48Z59W@SOIC28 [(SA404)]	
M48Z59Y	
M48Z59Y@SOIC28 [(SA404)]	M50FLW040A@PLCC32
[(SA015A1T)]	
M50FLW040A@TSOP40 [(SA409T)]	M50FLW040A@VSOP32

[(SA620)]
M50FLW040B@PLCC32 [(SA015A1T)] M50FLW040B@TSOP40
[(SA409T)]
M50FLW040B@VSOP32 [(SA620)] M50FLW080A@PLCC32
[(SA015A1T)]
M50FLW080A@TSOP40 [(SA409T)] M50FLW080A@VSOP32
[(SA620)]
M50FLW080B@PLCC32 [(SA015A1T)] M50FLW080B@TSOP40
[(SA409T)]
M50FLW080B@VSOP32 [(SA620)] M50FW002@PLCC32
[(SA015A1T)]
M50FW016@TSOP40 [(SA409T)] M50FW020@PLCC32
[(SA015A1T)]
M50FW040@PLCC32 [(SA015A1T)] M50FW040@TSOP40
[(SA409T)]
M50FW080@PLCC32 [(SA015A1T)] M50FW080@TSOP40
[(SA409T)]
M50FW080@VSOP32 [(SA620)] M50LPW002@PLCC32
[(SA015A1T)]
M50LPW012@PLCC32 [(SA015A1T)] M50LPW020@PLCC32
[(SA015A1T)]
M50LPW040@PLCC32 [(SA015A1T)] M50LPW040@TSOP40
[(SA409T)]
M50LPW041@PLCC32 [(SA015A1T)] M50LPW041@TSOP40
[(SA409T)]
M50LPW080@PLCC32 [(SA015A1T)] M50LPW080@TSOP40
[(SA409T)]
M50LPW116@TSOP40 [(SA409T)]
M58LR128FB@VFBGA56 [(SA644A-B025B-Y072F001)]
M58LR128FT@VFBGA56 [(SA644A-B025B-Y072F001)]
M58LR128GB@VFBGA56 [(SA644A-B025B-Y072F001)]
M58LR128GT@VFBGA56 [(SA644A-B025B-Y072F001)]
M58LT128GB@FBGA56 [(SA644A-B025B-Y072F001Y)]
M58LT128GSB@FBGA64 [(SA655E-B130A-T056F001Y)]
M58LT128GST@FBGA64 [(SA655E-B130A-T056F001Y)]
M58LT128GT@FBGA56 [(SA644A-B025B-Y072F001Y)]
M58LT256GB@FBGA64 [(SA655E-B130A-T056F001Y)]
M58LT256GT@FBGA64 [(SA655E-B130A-T056F001Y)]
M58LW032A@TSOP56 [(SA628-B031)]
M58LW032C@FBGA64 [(SA655A-B054A-T064F001)]
M58LW032C@TSOP56 [(SA628-B031)]
M58LW032D@FBGA64 [(SA655A-B054A-T064F001)]
M58LW032D@TSOP56 [(SA628-B018)]

M58LW064C@FBGA64 [(SA655A-B054A-T064F001)]
M58LW064C@TSOP56 [(SA628-B063)]
M58LW064D@FBGA64 [(SA655A-B054A-T064F001)]
M58LW064D@TSOP56 [(SA628-B018)] M58LW128A@TSOP56 [(SA628-B018)]
M58WR016QB(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR016QB(Q_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR016QL@FBGA44 [(SA733A-B206A-M056F001N)]
M58WR016QT(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR016QT(Q_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR016QU@FBGA44 [(SA733A-B206A-M056F001N)]
M58WR032EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR032EB(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR032ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR032ET(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR032FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR032FB(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR032FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR032FT(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR032HB@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR032HT@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR032QB(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR032QB(Q_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR032QL@FBGA44 [(SA733A-B206A-M056F001N)]
M58WR032QT(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR032QT(Q_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR032QU@FBGA44 [(SA733A-B206A-M056F001N)]
M58WR064EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR064EB(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR064ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR064ET(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR064FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR064FB(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR064FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR064FT(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR064HB@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR064HT@FBGA56 [(SA656C-B104A-T056F001Y)]
M58WR128FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR128FB(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR128FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]
M58WR128FT(Q_Word)@FBGA56 [(SA644A-B025B-Y072F001)]
M59DR008E@FBGA48 [(SA634A-B005-Y048F001Y)]
M59DR008E@TSOP48 [(SA247-B005)]

M59DR008F@FBGA48 [(SA634A-B005-Y048F001Y)]
M59DR008F@TSOP48 [(SA247-B005)]
M59DR016C@FBGA48 [(SA634A-B005A-Y048N001N)]
M59DR016D@FBGA48 [(SA634A-B005A-Y048N001N)]
M59PW016@PSOP44 [(SA638)] M59PW016@SDIP42
[(SA028)]
M59PW016@TSOP48 [(SA247-B005)] M59PW032@PSOP44
[(SA638)]
M59PW032@PSOP44(Fast) [(SA638+B006)]
M59PW032@TSOP48 [(SA247-B005)] M59PW064@PSOP44
[(SA638)]
M59PW1282@PSOP44 [(SA638)]
M72DW64000B@FBGA73 [(SA642A-B032A-Y096F001Y)]
M72DW75000C@FBGA73 [(SA642A-B039A-Y096F001Y)]
M72DW75001C@FBGA73 [(SA642A-B032A-Y096F001Y)]
M72DW76001D@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW52003BA@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW52003TA@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW52004BA@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW52004TA@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW62000A@FBGA73 [(SA642A-B032A-Y096F001Y)]
M76DW63000A@FBGA73 [(SA642A-B032A-Y096F001Y)]
M87C257 M87C257@PLCC32
[(SA015A1T)]
M93C06(08bit) M93C06(08bit)@SOIC8
[(SA602A)]
M93C06(16bit) M93C06(16bit)@SOIC8
[(SA602A)]
M93C46(08bit) M93C46(08bit)@MLP8
[(SA694)]
M93C46(08bit)@MSOP8 [(SA666)] M93C46(08bit)@SOIC8
[(SA602A)]
M93C46(08bit)@TSSOP8 [(SA026)] M93C46
(16bit)
M93C46(16bit)@MLP8 [(SA694)] M93C46(16bit)@MSOP8
[(SA666)]
M93C46(16bit)@SOIC8 [(SA602A)] M93C46(16bit)@TSSOP8
[(SA026)]
M93C46R(08bit) M93C46R(08bit)@MLP8
[(SA694)]
M93C46R(08bit)@MSOP8 [(SA666)] M93C46R(08bit)@SOIC8
[(SA602A)]
M93C46R(08bit)@TSSOP8 [(SA026)] M93C46R

(16bit)	
M93C46R(16bit)@MLP8 [(SA694)]	M93C46R(16bit)@MSOP8
[(SA666)]	
M93C46R(16bit)@SOIC8 [(SA602A)]	M93C46R(16bit)@TSSOP8
[(SA026)]	
M93C46W(08bit)	M93C46W(08bit)@MLP8
[(SA694)]	
M93C46W(08bit)@MSOP8 [(SA666)]	M93C46W(08bit)@SOIC8
[(SA602A)]	
M93C46W(08bit)@TSSOP8 [(SA026)]	M93C46W
(16bit)	
M93C46W(16bit)@MLP8 [(SA694)]	M93C46W(16bit)@MSOP8
[(SA666)]	
M93C46W(16bit)@SOIC8 [(SA602A)]	M93C46W(16bit)@TSSOP8
[(SA026)]	
M93C56(08bit)	M93C56(08bit)@MLP8
[(SA694)]	
M93C56(08bit)@MSOP8 [(SA666)]	M93C56(08bit)@SOIC8
[(SA602A)]	
M93C56(08bit)@TSSOP8 [(SA026)]	M93C56
(16bit)	
M93C56(16bit)@MLP8 [(SA694)]	M93C56(16bit)@MSOP8
[(SA666)]	
M93C56(16bit)@SOIC8 [(SA602A)]	M93C56(16bit)@TSSOP8
[(SA026)]	
M93C56R(08bit)	M93C56R(08bit)@MLP8
[(SA694)]	
M93C56R(08bit)@MSOP8 [(SA666)]	M93C56R(08bit)@SOIC8
[(SA602A)]	
M93C56R(08bit)@TSSOP8 [(SA026)]	M93C56R
(16bit)	
M93C56R(16bit)@MLP8 [(SA694)]	M93C56R(16bit)@MSOP8
[(SA666)]	
M93C56R(16bit)@SOIC8 [(SA602A)]	M93C56R(16bit)@TSSOP8
[(SA026)]	
M93C56W(08bit)	M93C56W(08bit)@MLP8
[(SA694)]	
M93C56W(08bit)@MSOP8 [(SA666)]	M93C56W(08bit)@SOIC8
[(SA602A)]	
M93C56W(08bit)@TSSOP8 [(SA026)]	M93C56W
(16bit)	
M93C56W(16bit)@MLP8 [(SA694)]	M93C56W(16bit)@MSOP8
[(SA666)]	

M93C56W(16bit)@SOIC8 [(SA602A)]	M93C56W(16bit)@TSSOP8
[(SA026)]	
M93C66(08bit)	M93C66(08bit)@MLP8
[(SA694)]	
M93C66(08bit)@MSOP8 [(SA666)]	M93C66(08bit)@SOIC8
[(SA602A)]	
M93C66(08bit)@TSSOP8 [(SA026)]	M93C66
(16bit)	
M93C66(16bit)@MLP8 [(SA694)]	M93C66(16bit)@MSOP8
[(SA666)]	
M93C66(16bit)@SOIC8 [(SA602A)]	M93C66(16bit)@TSSOP8
[(SA026)]	
M93C66R(08bit)	M93C66R(08bit)@MLP8
[(SA694)]	
M93C66R(08bit)@MSOP8 [(SA666)]	M93C66R(08bit)@SOIC8
[(SA602A)]	
M93C66R(08bit)@TSSOP8 [(SA026)]	M93C66R
(16bit)	
M93C66R(16bit)@MLP8 [(SA694)]	M93C66R(16bit)@MSOP8
[(SA666)]	
M93C66R(16bit)@SOIC8 [(SA602A)]	M93C66R(16bit)@TSSOP8
[(SA026)]	
M93C66W(08bit)	M93C66W(08bit)@MLP8
[(SA694)]	
M93C66W(08bit)@MSOP8 [(SA666)]	M93C66W(08bit)@SOIC8
[(SA602A)]	
M93C66W(08bit)@TSSOP8 [(SA026)]	M93C66W
(16bit)	
M93C66W(16bit)@MLP8 [(SA694)]	M93C66W(16bit)@MSOP8
[(SA666)]	
M93C66W(16bit)@SOIC8 [(SA602A)]	M93C66W(16bit)@TSSOP8
[(SA026)]	
M93C76(08bit)	M93C76(08bit)@MLP8
[(SA694)]	
M93C76(08bit)@MSOP8 [(SA666)]	M93C76(08bit)@SOIC8
[(SA602A)]	
M93C76(08bit)@TSSOP8 [(SA026)]	M93C76
(16bit)	
M93C76(16bit)@MLP8 [(SA694)]	M93C76(16bit)@MSOP8
[(SA666)]	
M93C76(16bit)@SOIC8 [(SA602A)]	M93C76(16bit)@TSSOP8
[(SA026)]	
M93C76R(08bit)	M93C76R(08bit)@MLP8

[(SA694)]	
M93C76R(08bit)@MSOP8 [(SA666)]	M93C76R(08bit)@SOIC8
[(SA602A)]	
M93C76R(08bit)@TSSOP8 [(SA026)]	M93C76R
(16bit)	
M93C76R(16bit)@MLP8 [(SA694)]	M93C76R(16bit)@MSOP8
[(SA666)]	
M93C76R(16bit)@SOIC8 [(SA602A)]	M93C76R(16bit)@TSSOP8
[(SA026)]	
M93C76W(08bit)	M93C76W(08bit)@MLP8
[(SA694)]	
M93C76W(08bit)@MSOP8 [(SA666)]	M93C76W(08bit)@SOIC8
[(SA602A)]	
M93C76W(08bit)@TSSOP8 [(SA026)]	M93C76W
(16bit)	
M93C76W(16bit)@MLP8 [(SA694)]	M93C76W(16bit)@MSOP8
[(SA666)]	
M93C76W(16bit)@SOIC8 [(SA602A)]	M93C76W(16bit)@TSSOP8
[(SA026)]	
M93C86(08bit)	M93C86(08bit)@MLP8
[(SA694)]	
M93C86(08bit)@MSOP8 [(SA666)]	M93C86(08bit)@SOIC8
[(SA602A)]	
M93C86(08bit)@TSSOP8 [(SA026)]	M93C86
(16bit)	
M93C86(16bit)@MLP8 [(SA694)]	M93C86(16bit)@MSOP8
[(SA666)]	
M93C86(16bit)@SOIC8 [(SA602A)]	M93C86(16bit)@TSSOP8
[(SA026)]	
M93C86R(08bit)	M93C86R(08bit)@MLP8
[(SA694)]	
M93C86R(08bit)@MSOP8 [(SA666)]	M93C86R(08bit)@SOIC8
[(SA602A)]	
M93C86R(08bit)@TSSOP8 [(SA026)]	M93C86R
(16bit)	
M93C86R(16bit)@MLP8 [(SA694)]	M93C86R(16bit)@MSOP8
[(SA666)]	
M93C86R(16bit)@SOIC8 [(SA602A)]	M93C86R(16bit)@TSSOP8
[(SA026)]	
M93C86W(08bit)	M93C86W(08bit)@MLP8
[(SA694)]	
M93C86W(08bit)@MSOP8 [(SA666)]	M93C86W(08bit)@SOIC8
[(SA602A)]	

M93C86W(08bit)@TSSOP8 [(SA026)] (16bit)	M93C86W
M93C86W(16bit)@MLP8 [(SA694)] [(SA666)]	M93C86W(16bit)@MSOP8
M93C86W(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C86W(16bit)@TSSOP8
M93CS566 [(SA602A)]	M93CS566@SOIC8
M93S46 [(SA602A)]	M93S46@SOIC8
M93S46@TSSOP8 [(SA026)]	
M93S46R	
M93S46R@SOIC8 [(SA602A)] [(SA026)]	M93S46R@TSSOP8
M93S46W [(SA602A)]	M93S46W@SOIC8
M93S46W@TSSOP8 [(SA026)]	
M93S56	
M93S56@SOIC8 [(SA602A)] [(SA026)]	M93S56@TSSOP8
M93S56R [(SA602A)]	M93S56R@SOIC8
M93S56R@TSSOP8 [(SA026)]	
M93S56W	
M93S56W@SOIC8 [(SA602A)] [(SA026)]	M93S56W@TSSOP8
M93S66 [(SA602A)]	M93S66@SOIC8
M93S66@TSSOP8 [(SA026)]	
M93S66R	
M93S66R@SOIC8 [(SA602A)] [(SA026)]	M93S66R@TSSOP8
M93S66W [(SA602A)]	M93S66W@SOIC8
M93S66W@TSSOP8 [(SA026)]	
M95010	
M95010(ISP) [ISP-HEADER01] [(SA602A)]	M95010@SOIC8
M95010@SOIC8(ISP) [ISP-HEADER01] [(SA026)]	M95010@TSSOP8
M95010@TSSOP8(ISP) [ISP-HEADER01]	
M95020 HEADER01]	M95020(ISP) [ISP-

M95020@SOIC8 [(SA602A)] M95020@SOIC8(ISP) [ISP-
HEADER01]
M95020@TSSOP8 [(SA026)]
M95020@TSSOP8(ISP) [ISP-HEADER01]
M95040 M95040(ISP) [ISP-
HEADER01]
M95040@SOIC8 [(SA602A)] M95040@SOIC8(ISP) [ISP-
HEADER01]
M95040@TSSOP8 [(SA026)]
M95040@TSSOP8(ISP) [ISP-HEADER01]
M95080 M95080(ISP) [ISP-
HEADER01]
M95080@SOIC8 [(SA602A)] M95080@SOIC8(ISP) [ISP-
HEADER01]
M95080@TSSOP14 [(SA026)]
M95080@TSSOP14(ISP) [ISP-HEADER01]
M95080@TSSOP8 [(SA026)]
M95080@TSSOP8(ISP) [ISP-HEADER01]
M95128 M95128(ISP) [ISP-
HEADER01]
M95128@TSSOP14 [(SA026)]
M95128@TSSOP14(ISP) [ISP-HEADER01]
M95128@TSSOP8 [(SA026)]
M95128@TSSOP8(ISP) [ISP-HEADER01]
M95128[150mil]@SOIC8 [(SA602A)]
M95128[150mil]@SOIC8(ISP) [ISP-HEADER01]
M95128[200mil]@SOIC8 [(SA023A)]
M95128[200mil]@SOIC8(ISP) [ISP-HEADER01]
M95160 M95160(ISP) [ISP-
HEADER01]
M95160@SOIC8 [(SA602A)] M95160@SOIC8(ISP) [ISP-
HEADER01]
M95160@TSSOP14 [(SA026)]
M95160@TSSOP14(ISP) [ISP-HEADER01]
M95160@TSSOP8 [(SA026)]
M95160@TSSOP8(ISP) [ISP-HEADER01]
M95256 M95256(ISP) [ISP-
HEADER01]
M95256@TSSOP14 [(SA026)]
M95256@TSSOP14(ISP) [ISP-HEADER01]
M95256@TSSOP8 [(SA026)]
M95256@TSSOP8(ISP) [ISP-HEADER01]
M95256[150mil]@SOIC8 [(SA602A)]

M95256[150mil]@SOIC8(ISP) [ISP-HEADER01]
M95256[200mil]@SOIC8 [(SA023A)]
M95256[200mil]@SOIC8(ISP) [ISP-HEADER01]
M95320 M95320(ISP) [ISP-
HEADER01]
M95320@SOIC8 [(SA602A)] M95320@SOIC8(ISP) [ISP-
HEADER01]
M95320@TSSOP14 [(SA026)]
M95320@TSSOP14(ISP) [ISP-HEADER01]
M95320@TSSOP8 [(SA026)]
M95320@TSSOP8(ISP) [ISP-HEADER01]
M95512@SOIC8 [(SA602A)] M95512@SOIC8(ISP) [ISP-
HEADER01]
M95512@TSSOP8 [(SA026)]
M95512@TSSOP8(ISP) [ISP-HEADER01]
M95640 M95640(ISP) [ISP-
HEADER01]
M95640@SOIC8 [(SA602A)] M95640@SOIC8(ISP) [ISP-
HEADER01]
M95640@TSSOP14 [(SA026)]
M95640@TSSOP14(ISP) [ISP-HEADER01]
M95640@TSSOP8 [(SA026)]
M95640@TSSOP8(ISP) [ISP-HEADER01]
M95M01[150mil]@SOIC8 [(SA602A)]
M95P02
M95P02@SOIC8 [(SA602A)]
M95P04
M95P04@SOIC8 [(SA602A)]
M95P08
M95P08@SOIC8 [(SA602A)]
MK48C02
MK48C02B
MK48C12
MK48C12B
MK48T02
MK48T02B
MK48T08
MK48T12
MK48T12B
MK48T18
MK48T32
MK48T32Y
MK48T35

MK48T35@SOIC28 [(SA630)]
MK48T35Y
MK48T35Y@SOIC28 [(SA630)]
MK48T512V
MK48T512Y
MK48Z02
MK48Z02B
MK48Z08
MK48Z12
MK48Z12B
MK48Z18
MK48Z32
MK48Z32Y
MK48Z35
MK48Z35@SOIC28 [(SA630)]
MK48Z35Y
MK48Z35Y@SOIC28 [(SA630)]
MK48Z512V
MK48Z512Y
MKI48Z02
MKI48Z02B
MKI48Z12
MKI48Z12B
MKI48Z18
NAND01GR3B2BZA6@FBGA63 [(SA642KK-B280-W048F001Y)]
NAND01GW3A0AN6@TSOP48 [(SA247-B005)]
NAND01GW3B2AN6E@TSOP48 [(SA247-B005)]
NAND01GW3B2BN6E@TSOP48 [(SA247-B005)]
NAND01GW3B2BZA6@FBGA63 [(SA642KK-B026-W048F001Y)]
NAND02GR3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]
NAND02GW3B2AN6@TSOP48 [(SA247-B005)]
NAND02GW3B2CN6@TSOP48 [(SA247-B005)]
NAND02GW3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]
NAND04GW3B2BN6@TSOP48 [(SA247-B005)]
NAND04GW3C2AN1@TSOP48 [(SA247-B005)]
NAND08GW3B2AN6@TSOP48 [(SA247-B005)]
NAND128W3A0AN6@TSOP48 [(SA247-B005)]
NAND128W3A2BN6@TSOP48 [(SA247-B005)]
NAND256R3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]
NAND256R3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]
NAND256W3A0AN6@TSOP48 [(SA247-B005)]
NAND256W3A0AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]
NAND256W3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]

NAND256W3A2BN6@TSOP48 [(SA247-B005)]
 NAND256W3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]
 NAND512R3A2AZB6@TFBGA63 [(SA642KK-B026-W048F001Y)]
 NAND512R3A2AZB6E@TFBGA55 [(SA642R-B026-T096F001Y)]
 NAND512R3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]
 NAND512W3A0AN6@TSOP48 [(SA247-B005)]
 NAND512W3A2BN6@TSOP48 [(SA247-B005)]
 NAND512W3A2CN6@TSOP48 [(SA247-B005)]
 NAND512W3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]
 NAND99R4M2AZBA5@BGA149 [(SA664G-B279-Y149F001Y)]
 ST24C01 ST24C01@SOIC8
 [(SA602A)]
 ST24C02A ST24C02A@SOIC8
 [(SA602A)]
 ST24C16 ST24C16@SOIC8
 [(SA602A)]
 ST24FC21 ST24FC21@SOIC8
 [(SA602A)]
 ST24FW21 ST24FW21@SOIC8
 [(SA602A)]
 ST24LC21B ST24LC21B@SOIC8
 [(SA602A)]
 ST24LW21 ST24LW21@SOIC8
 [(SA602A)]
 ST24W01 ST24W01@SOIC8
 [(SA602A)]
 ST24W02 ST24W02@SOIC8
 [(SA602A)]
 ST24W04C ST24W04C@SOIC8
 [(SA602A)]
 ST26C201 ST26C201@PLCC32
 [(SA015A1T)]
 ST26C201@TSOP32 [(SA410T)]
 ST27128A
 ST27256
 ST2764A
 ST27C256 ST93C06
 (08bit)
 ST93C06(08bit)@SOIC8 [(SA602A)] ST93C06
 (16bit)
 ST93C06(16bit)@SOIC8 [(SA602A)] ST93C46
 (08bit)
 ST93C46(08bit)@SOIC8 [(SA602A)] ST93C46

(16bit)		
ST93C46(16bit)@SOIC8 [(SA602A)]		ST93C46A
(08bit)		
ST93C46A(08bit)@SOIC8 [(SA602A)]		ST93C46A
(16bit)		
ST93C46A(16bit)@SOIC8 [(SA602A)]		ST93C46C
(08bit)		
ST93C46C(08bit)@SOIC8 [(SA602A)]		ST93C46C
(16bit)		
ST93C46C(16bit)@SOIC8 [(SA602A)]		ST93C46T
(08bit)		
ST93C46T(08bit)@SOIC8 [(SA602A)]		ST93C46T
(16bit)		
ST93C46T(16bit)@SOIC8 [(SA602A)]		ST93C47C
(08bit)		
ST93C47C(08bit)@SOIC8 [(SA602A)]		ST93C47C
(16bit)		
ST93C47C(16bit)@SOIC8 [(SA602A)]		ST93C47T
(08bit)		
ST93C47T(08bit)@SOIC8 [(SA602A)]		ST93C47T
(16bit)		
ST93C47T(16bit)@SOIC8 [(SA602A)]		ST93C56
(08bit)		
ST93C56(08bit)@SOIC8 [(SA602A)]		ST93C56
(16bit)		
ST93C56(16bit)@SOIC8 [(SA602A)]		ST93C56B
(08bit)		
ST93C56B(08bit)@SOIC8 [(SA602A)]		ST93C56B
(16bit)		
ST93C56B(16bit)@SOIC8 [(SA602A)]		ST93C56C
(08bit)		
ST93C56C(08bit)@SOIC8 [(SA602A)]		ST93C56C
(16bit)		
ST93C56C(16bit)@SOIC8 [(SA602A)]		ST93C57C
(08bit)		
ST93C57C(08bit)@SOIC8 [(SA602A)]		ST93C57C
(16bit)		
ST93C57C(16bit)@SOIC8 [(SA602A)]		ST93C66
(08bit)		
ST93C66(08bit)@SOIC8 [(SA602A)]		ST93C66
(16bit)		
ST93C66(16bit)@SOIC8 [(SA602A)]		ST93C67
(08bit)		

ST93C67(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C67
ST93C67(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C76
ST93C76(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C76
ST93C76(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C86
ST93C86(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C86
ST93C86(16bit)@SOIC8 [(SA602A)]	
ST93CS46	
ST93CS46@SOIC8 [(SA602A)]	
ST93CS47	
ST93CS47@SOIC8 [(SA602A)]	
ST93CS56	
ST93CS56@SOIC8 [(SA602A)]	
ST93CS566	
ST93CS566@SOIC8 [(SA602A)]	
ST93CS57	
ST93CS57@SOIC8 [(SA602A)]	
ST93CS66	
ST93CS66@SOIC14 [(SA602)]	
ST93CS67	
ST93CS67@SOIC14 [(SA602)]	
TS27C256	
TS27C64	TS27C64@PLCC32
[(SA015A1T)]	
TS27C64A	TS27C64A@PLCC32
[(SA015A1T)]	
TS28C16A	
TS28C17A	

MICROCONTROLLER

ST62E01	ST62E01@SOIC16
[(SA404)]	
ST62E01CF1	
ST62E18CF1	
ST62E20	ST62E20@SOIC20
[(SA404)]	
ST62E20CF1	

ST62E25	
ST62E25@SOIC28 [(SA404)]	
ST62E25CF1	
ST62E28CF1	
ST62E30BF1	
ST62E32BF1@SDIP42 [(SA028)]	
ST62E60B	
ST62E60B@SOIC20 [(SA404)]	
ST62E62CF1	
ST62E65B	ST62E65B@SOIC28
[(SA404)]	
ST62E65CF1	
ST62T00	
ST62T00@SOIC16 [(SA404)]	ST62T00C
(B6)	
ST62T00C(M6)@SOIC16 [(SA404)]	ST62T00C(N6)@SSOP16
[(SA626A)]	
ST62T01	ST62T01@SOIC16
[(SA404)]	
ST62T01C(B3)	ST62T01C
(B6)	
ST62T01C(M3)@SOIC16 [(SA404)]	ST62T01C(M6)@SOIC16
[(SA404)]	
ST62T01C(N3)@SSOP16 [(SA626A)]	ST62T01C(N6)@SSOP16
[(SA626A)]	
ST62T03	ST62T03@SOIC16
[(SA404)]	
ST62T03C(B6)	ST62T03C(M3)@SOIC16
[(SA404)]	
ST62T03C(M6)@SOIC16 [(SA404)]	ST62T03C(N6)@SSOP16
[(SA626A)]	
ST62T08	ST62T08@SOIC20
[(SA404)]	
ST62T08C(B6)	ST62T08C(M6)@SOIC20
[(SA404)]	
ST62T09	ST62T09@SOIC20
[(SA404)]	
ST62T09C(B3)	ST62T09C
(B6)	
ST62T09C(M3)@SOIC20 [(SA404)]	ST62T09C(M6)@SOIC20
[(SA404)]	
ST62T10	ST62T10@SOIC20
[(SA404)]	

ST62T10C(B6)	ST62T10C(M6)@SOIC20
[(SA404)]	
ST62T15	ST62T15@SOIC28
[(SA404)]	
ST62T15C(B6)	ST62T15C(M6)@SOIC28
[(SA404)]	
ST62T18C(B6)	ST62T18C(M3)@SOIC20
[(SA404)]	
ST62T18C(M6)@SOIC20 [(SA404)]	
ST62T20	
ST62T20@SOIC20 [(SA404)]	ST62T20C
(B3)	
ST62T20C(B6)	ST62T20C(M3)@SOIC20
[(SA404)]	
ST62T20C(M6)@SOIC20 [(SA404)]	
ST62T25	
ST62T25@SOIC28 [(SA404)]	ST62T25C
(B3)	
ST62T25C(B6)	ST62T25C(M3)@SOIC28
[(SA404)]	
ST62T25C(M6)@SOIC28 [(SA404)]	ST62T25C(N6)@SSOP28
[(SA626A)]	
ST62T28C(B6)	ST62T28C(M3)@SOIC28
[(SA404)]	
ST62T28C(M6)@SOIC28 [(SA404)]	ST62T28C(N6)@SSOP28
[(SA626A)]	
ST62T30B(B3)	ST62T30B
(B6)	
ST62T30B(M6)@SOIC28 [(SA404)]	ST62T32B(B6)@SDIP42
[(SA028)]	
ST62T52C(B6)	ST62T52C(M3)@SOIC16
[(SA404)]	
ST62T52C(M6)@SOIC16 [(SA404)]	ST62T52C(N3)@SSOP16
[(SA626A)]	
ST62T52C(N6)@SSOP16 [(SA626A)]	
ST62T53B	
ST62T53B@SOIC20 [(SA404)]	ST62T53C
(B6)	
ST62T53C(M6)@SOIC20 [(SA404)]	ST62T55C
(B6)	
ST62T55C(M6)@SOIC28 [(SA404)]	ST62T55C(N6)@SSOP28
[(SA626A)]	
ST62T60B	ST62T60B@SOIC20

[(SA404)]	
ST62T60C6	ST62T62C
(B6)	
ST62T62C(M3)@SOIC16 [(SA404)]	ST62T62C(M6)@SOIC16
[(SA404)]	
ST62T62C(N3)@SSOP16 [(SA626A)]	ST62T62C(N6)@SSOP16
[(SA626A)]	
ST62T63B	ST62T63B@SOIC20
[(SA404)]	
ST62T63C(B6)	ST62T63C(M6)@SOIC20
[(SA404)]	
ST62T65B	ST62T65B@SOIC28
[(SA404)]	
ST62T65C(B3)	ST62T65C
(B6)	
ST62T65C(M3)@SOIC28 [(SA404)]	ST62T65C(M6)@SOIC28
[(SA404)]	
ST62T65C(N6)@SSOP28 [(SA626A)]	ST63E73@SDIP42
[(SA028)]	
ST63T73@SDIP42 [(SA028)]	ST72C104G1B@SDIP32
[(SA653)]	
ST72C104G1M@SOIC28 [(SA404)]	ST72C104G2B@SDIP32
[(SA653)]	
ST72C104G2M@SOIC28 [(SA404)]	ST72C124J2B@SDIP42
[(SA028)]	
ST72C124J2T@TQFP44 [(SA245A)]	ST72C124J4B@SDIP42
[(SA028)]	
ST72C124J4T@TQFP44 [(SA245A)]	ST72C215G1B@SDIP32
[(SA653)]	
ST72C215G1M@SOIC28 [(SA404)]	ST72C215G2B@SDIP32
[(SA653)]	
ST72C215G2M@SOIC28 [(SA404)]	ST72C216G1B@SDIP32
[(SA653)]	
ST72C216G1M@SOIC28 [(SA404)]	ST72C216G2B@SDIP32
[(SA653)]	
ST72C216G2M@SOIC28 [(SA404)]	ST72C254G1B@SDIP32
[(SA653)]	
ST72C254G1M@SOIC28 [(SA404)]	ST72C254G2B@SDIP32
[(SA653)]	
ST72C254G2M@SOIC28 [(SA404)]	ST72C314J2B@SDIP42
[(SA028)]	
ST72C314J2T@TQFP44 [(SA245A)]	ST72C314J4B@SDIP42
[(SA028)]	

ST72C314J4T@TQFP44 [(SA245A)]	ST72C334J2B@SDIP42
[(SA028)]	
ST72C334J2T@TQFP44 [(SA245A)]	ST72C334J4B@SDIP42
[(SA028)]	
ST72C334J4T@TQFP44 [(SA245A)]	ST72F260G1B6@SDIP32
[(SA653)]	
ST72F260G1M6@SOIC28 [(SA404)]	ST72F262G1B6@SDIP32
[(SA653)]	
ST72F262G1M6@SOIC28 [(SA404)]	ST72F262G2B6@SDIP32
[(SA653)]	
ST72F262G2M6@SOIC28 [(SA404)]	ST72F264G1B6@SDIP32
[(SA653)]	
ST72F264G1M6@SOIC28 [(SA404)]	ST72F264G2B6@SDIP32
[(SA653)]	
ST72F264G2H1@LFBGA36 [(SA642G-B026A-T048F001N)]	
ST72F264G2H6@LFBGA36 [(SA642G-B026A-T048F001N)]	
ST72F264G2M6@SOIC28 [(SA404)]	ST72F324BJ2B5@SDIP42
[(SA028)]	
ST72F324BJ2B6@SDIP42 [(SA028)]	ST72F324BJ2T3@TQFP44
[(SA245A)]	
ST72F324BJ2T5@TQFP44 [(SA245A)]	ST72F324BJ2T6@TQFP44
[(SA245A)]	
ST72F324BJ4B5@SDIP42 [(SA028)]	ST72F324BJ4B6@SDIP42
[(SA028)]	
ST72F324BJ4T3@TQFP44 [(SA245A)]	ST72F324BJ4T6@TQFP44
[(SA245A)]	
ST72F324BJ6B5@SDIP42 [(SA028)]	ST72F324BJ6B6@SDIP42
[(SA028)]	
ST72F324BJ6T3@TQFP44 [(SA245A)]	ST72F324BJ6T6@TQFP44
[(SA245A)]	
ST72F324BK2B5@SDIP32 [(SA653)]	ST72F324BK2B6@SDIP32
[(SA653)]	
ST72F324BK2T3@TQFP32 [(SA663)]	ST72F324BK2T5@TQFP32
[(SA663)]	
ST72F324BK2T6@TQFP32 [(SA663)]	ST72F324BK4B5@SDIP32
[(SA653)]	
ST72F324BK4B6@SDIP32 [(SA653)]	ST72F324BK4T3@TQFP32
[(SA663)]	
ST72F324BK4T6@TQFP32 [(SA663)]	ST72F324BK6B5@SDIP32
[(SA653)]	
ST72F324BK6B6@SDIP32 [(SA653)]	ST72F324BK6T3@TQFP32
[(SA663)]	
ST72F324BK6T6@TQFP32 [(SA663)]	ST72F324J2B5@SDIP42

[(SA028)]
ST72F324J2B5@SDIP42 (ISP) [ISP-HEADER01]
ST72F324J2T6@TQFP44 [(SA245A)]
ST72F324J2T6@TQFP44 (ISP) [ISP-HEADER01]
ST72F324J2TA@TQFP44 [(SA245A)]
ST72F324J2TA@TQFP44 (ISP) [ISP-HEADER01]
ST72F324J4B5@SDIP42 [(SA028)]
ST72F324J4B5@SDIP42 (ISP) [ISP-HEADER01]
ST72F324J4T6@TQFP44 [(SA245A)]
ST72F324J4T6@TQFP44 (ISP) [ISP-HEADER01]
ST72F324J4TA@TQFP44 [(SA245A)]
ST72F324J4TA@TQFP44 (ISP) [ISP-HEADER01]
ST72F324J6B5@SDIP42 [(SA028)]
ST72F324J6B5@SDIP42 (ISP) [ISP-HEADER01]
ST72F324J6T3@TQFP44 [(SA245A)]
ST72F324J6T3@TQFP44 (ISP) [ISP-HEADER01]
ST72F324J6T5@TQFP44 [(SA245A)]
ST72F324J6T5@TQFP44 (ISP) [ISP-HEADER01]
ST72F324J6T6@TQFP44 [(SA245A)]
ST72F324J6T6@TQFP44 (ISP) [ISP-HEADER01]
ST72F324J6TA@TQFP44 [(SA245A)]
ST72F324J6TA@TQFP44 (ISP) [ISP-HEADER01]
ST72F324J6TC@TQFP44 [(SA245A)]
ST72F324J6TC@TQFP44 (ISP) [ISP-HEADER01]
ST72F324K2B5@SDIP32 [(SA653)]
ST72F324K2B5@SDIP32 (ISP) [ISP-HEADER01]
ST72F324K2B6@SDIP32 [(SA653)]
ST72F324K2B6@SDIP32 (ISP) [ISP-HEADER01]
ST72F324K2T6@TQFP32 [(SA663)]
ST72F324K2T6@TQFP32 (ISP) [ISP-HEADER01]
ST72F324K2TA@TQFP32 [(SA663)]
ST72F324K2TA@TQFP32 (ISP) [ISP-HEADER01]
ST72F324K4B5@SDIP32 [(SA653)]
ST72F324K4B5@SDIP32 (ISP) [ISP-HEADER01]
ST72F324K4B6@SDIP32 [(SA653)]
ST72F324K4B6@SDIP32 (ISP) [ISP-HEADER01]
ST72F324K4T6@TQFP32 [(SA663)]
ST72F324K4T6@TQFP32 (ISP) [ISP-HEADER01]
ST72F324K4TA@TQFP32 [(SA663)]
ST72F324K4TA@TQFP32 (ISP) [ISP-HEADER01]
ST72F324K6B5@SDIP32 [(SA653)]
ST72F324K6B5@SDIP32 (ISP) [ISP-HEADER01]
ST72F324K6B6@SDIP32 [(SA653)]

ST72F324K6B6@SDIP32 (ISP) [ISP-HEADER01]
ST72F324K6T5@TQFP32 [(SA663)]
ST72F324K6T5@TQFP32 (ISP) [ISP-HEADER01]
ST72F324K6T6@TQFP32 [(SA663)]
ST72F324K6T6@TQFP32 (ISP) [ISP-HEADER01]
ST72F324K6TA@TQFP32 [(SA663)]
ST72F324K6TA@TQFP32 (ISP) [ISP-HEADER01]
ST72F324K6TC@TQFP32 [(SA663)]
ST72F324K6TC@TQFP32 (ISP) [ISP-HEADER01]
ST72F324LJ2T5@TQFP44 [(SA245A)]
ST72F324LJ2T5@TQFP44 (ISP) [ISP-HEADER01]
ST72F324LJ2T6@TQFP44 [(SA245A)]
ST72F324LJ2T6@TQFP44 (ISP) [ISP-HEADER01]
ST72F324LJ4T5@TQFP44 [(SA245A)]
ST72F324LJ4T5@TQFP44 (ISP) [ISP-HEADER01]
ST72F324LJ4T6@TQFP44 [(SA245A)]
ST72F324LJ4T6@TQFP44 (ISP) [ISP-HEADER01]
ST72F324LJ6T5@TQFP44 [(SA245A)]
ST72F324LJ6T5@TQFP44 (ISP) [ISP-HEADER01]
ST72F324LJ6T6@TQFP44 [(SA245A)]
ST72F324LJ6T6@TQFP44 (ISP) [ISP-HEADER01]
ST72F324LJ6TA@TQFP44 [(SA245A)]
ST72F324LJ6TA@TQFP44 (ISP) [ISP-HEADER01]
ST72F324LK2T5@TQFP32 [(SA663)]
ST72F324LK2T5@TQFP32 (ISP) [ISP-HEADER01]
ST72F324LK2T6@TQFP32 [(SA663)]
ST72F324LK2T6@TQFP32 (ISP) [ISP-HEADER01]
ST72F324LK4T5@TQFP32 [(SA663)]
ST72F324LK4T5@TQFP32 (ISP) [ISP-HEADER01]
ST72F324LK4T6@TQFP32 [(SA663)]
ST72F324LK4T6@TQFP32 (ISP) [ISP-HEADER01]
ST72F324LK6B5@SDIP32 [(SA653)]
ST72F324LK6B5@SDIP32 (ISP) [ISP-HEADER01]
ST72F324LK6T5@TQFP32 [(SA663)]
ST72F324LK6T5@TQFP32 (ISP) [ISP-HEADER01]
ST72F324LK6T6@TQFP32 [(SA663)]
ST72F324LK6T6@TQFP32 (ISP) [ISP-HEADER01]
ST72F324LK6TA@TQFP32 [(SA663)]
ST72F324LK6TA@TQFP32 (ISP) [ISP-HEADER01]
ST72F325C4T6@TQFP48 [(SA248)] ST72F325C6T6@TQFP48
[(SA248)]
ST72F325C7T6@TQFP48 [(SA248)] ST72F325C9T6@TQFP48
[(SA248)]

ST72F325J4T6@TQFP44 [(SA245A)] ST72F325J6B5@SDIP42
[(SA028)]
ST72F325J6B6@SDIP42 [(SA028)]
ST72F325J6B6@SDIP42(ISP) [ISP-HEADER01]
ST72F325J6T6@TQFP44 [(SA245A)] ST72F325J7T6@TQFP44
[(SA245A)]
ST72F325J9T6@TQFP44 [(SA245A)] ST72F325K4B5@SDIP32
[(SA653)]
ST72F325K4T6@TQFP32 [(SA663)] ST72F325K6B5@SDIP32
[(SA653)]
ST72F325K6B6@SDIP32 [(SA653)]
ST72F325K6B6@SDIP32(ISP) [ISP-HEADER01]
ST72F325K6T6@TQFP32 [(SA663)] ST72F32AJ1B5@SDIP42
[(SA028)]
ST72F32AJ1B6@SDIP42 [(SA028)] ST72F32AJ1T5@TQFP44
[(SA245A)]
ST72F32AJ1T6@TQFP44 [(SA245A)] ST72F32AJ2B5@SDIP42
[(SA028)]
ST72F32AJ2B6@SDIP42 [(SA028)] ST72F32AJ2T5@TQFP44
[(SA245A)]
ST72F32AJ2T6@TQFP44 [(SA245A)] ST72F32AJ2TA@TQFP44
[(SA245A)]
ST72F32AJ2TB@TQFP44 [(SA245A)] ST72F32AJ2TC@TQFP44
[(SA245A)]
ST72F32AK1B5@SDIP32 [(SA653)] ST72F32AK1B6@SDIP32
[(SA653)]
ST72F32AK1T5@TQFP32 [(SA663)] ST72F32AK1T6@TQFP32
[(SA663)]
ST72F32AK2B5@SDIP32 [(SA653)] ST72F32AK2B6@SDIP32
[(SA653)]
ST72F32AK2T5@TQFP32 [(SA663)] ST72F32AK2T6@TQFP32
[(SA663)]
ST72F32AK2TA@TQFP32 [(SA663)] ST72F32AK2TB@TQFP32
[(SA663)]
ST72F32AK2TC@TQFP32 [(SA663)] ST72F60D4U1@QFN40
[(SA750)]
ST72F60D4U1@QFN40(ISP) [ISP-HEADER01]
ST72F60D6U1@QFN40 [(SA750)]
ST72F60D6U1@QFN40(ISP) [ISP-HEADER01]
ST72F60E1M1@SOIC24 [(SA404)]
ST72F60E1M1@SOIC24(ISP) [ISP-HEADER01]
ST72F60E2M1@SOIC24 [(SA404)]
ST72F60E2M1@SOIC24(ISP) [ISP-HEADER01]

ST72F60E4M1@SOIC24 [(SA404)]
ST72F60E4M1@SOIC24(ISP) [ISP-HEADER01]
ST72F60E6M1@SOIC24 [(SA404)]
ST72F60E6M1@SOIC24(ISP) [ISP-HEADER01]
ST72F60K1U1@QFN40 [(SA750)]
ST72F60K1U1@QFN40(ISP) [ISP-HEADER01]
ST72F60K2U1@QFN40 [(SA750)]
ST72F60K2U1@QFN40(ISP) [ISP-HEADER01]
ST72F621J4B1@SDIP42 [(SA028)] ST72F621J4T1@TQFP44
[(SA245A)]
ST72F621K4B1@SDIP32 [(SA653)] ST72F621L4M1@SOIC34
[(SA658)]
ST72F622L2M1@SOIC34 [(SA658)]
ST72F623F2B1
ST72F623F2M1@SOIC20 [(SA404)] ST72F63BD4U1@QFN40
[(SA750)]
ST72F63BD4U1@QFN40(ISP) [ISP-HEADER01]
ST72F63BD6U1@QFN40 [(SA750)]
ST72F63BD6U1@QFN40(ISP) [ISP-HEADER01]
ST72F63BE1M1@SOP24 [(SA404)]
ST72F63BE1M1@SOP24(ISP) [ISP-HEADER01]
ST72F63BE2M1@SOP24 [(SA404)]
ST72F63BE2M1@SOP24(ISP) [ISP-HEADER01]
ST72F63BE4M1@SOP24 [(SA404)]
ST72F63BE4M1@SOP24(ISP) [ISP-HEADER01]
ST72F63BE6M1@SOP24 [(SA404)]
ST72F63BE6M1@SOP24(ISP) [ISP-HEADER01]
ST72F63BH1T1@QFP48 [(SA248)]
ST72F63BH1T1@QFP48(ISP) [ISP-HEADER01]
ST72F63BH2T1@QFP48 [(SA248)]
ST72F63BH2T1@QFP48(ISP) [ISP-HEADER01]
ST72F63BH4T1@QFP48 [(SA248)]
ST72F63BH4T1@QFP48(ISP) [ISP-HEADER01]
ST72F63BH6T1@QFP48 [(SA248)]
ST72F63BH6T1@QFP48(ISP) [ISP-HEADER01]
ST72F63BK1B1@SOIC34 [(SA653)]
ST72F63BK1B1@SOIC34(ISP) [ISP-HEADER01]
ST72F63BK1M1@SOIC34 [(SA658)]
ST72F63BK1M1@SOIC34(ISP) [ISP-HEADER01]
ST72F63BK1U1@QFN40 [(SA750)]
ST72F63BK1U1@QFN40(ISP) [ISP-HEADER01]
ST72F63BK2B1@SOIC34 [(SA653)]
ST72F63BK2B1@SOIC34(ISP) [ISP-HEADER01]

ST72F63BK2M1@SOIC34 [(SA658)]
ST72F63BK2M1@SOIC34(ISP) [ISP-HEADER01]
ST72F63BK2U1@QFN40 [(SA750)]
ST72F63BK2U1@QFN40(ISP) [ISP-HEADER01]
ST72F63BK4B1@SOIC34 [(SA653)]
ST72F63BK4B1@SOIC34(ISP) [ISP-HEADER01]
ST72F63BK4M1@SOIC34 [(SA658)]
ST72F63BK4M1@SOIC34(ISP) [ISP-HEADER01]
ST72F63BK6B1@SOIC34 [(SA653)]
ST72F63BK6B1@SOIC34(ISP) [ISP-HEADER01]
ST72F63BK6M1@SOIC34 [(SA658)]
ST72F63BK6M1@SOIC34(ISP) [ISP-HEADER01]
ST72T101G1B@SDIP32 [(SA653)] ST72T101G1M@SOIC28
[(SA404)]
ST72T101G2B@SDIP32 [(SA653)] ST72T101G2M@SOIC28
[(SA404)]
ST72T121J2B@SDIP42 [(SA028)] ST72T121J2T@TQFP44
[(SA245A)]
ST72T121J4B@SDIP42 [(SA028)] ST72T121J4T@TQFP44
[(SA245A)]
ST72T141K2B@SDIP32 [(SA653)] ST72T141K2M@SSOP34
[(SA658)]
ST72T212G2B@SDIP32 [(SA653)] ST72T212G2M@SOIC28
[(SA404)]
ST72T213G1B@SDIP32 [(SA653)] ST72T213G1M@SOIC28
[(SA404)]
ST72T251G1B@SDIP32 [(SA653)] ST72T251G1M@SOIC28
[(SA404)]
ST72T251G2B@SDIP32 [(SA653)] ST72T251G2M@SOIC28
[(SA404)]
ST72T272K4B@SDIP32 [(SA653)] ST72T272K4M@SSOP34
[(SA658)]
ST72T311J2B@SDIP42 [(SA028)] ST72T311J2T@TQFP44
[(SA245A)]
ST72T311J4B@SDIP42 [(SA028)] ST72T311J4T@TQFP44
[(SA245A)]
ST72T331J2B@SDIP42 [(SA028)] ST72T331J2T@TQFP44
[(SA245A)]
ST72T331J4B@SDIP42 [(SA028)] ST72T331J4T@TQFP44
[(SA245A)]
ST72T371N4B@SDIP56(*) [(SA627-B5601)]
ST72T372J4B@SDIP42 [(SA028)] ST72T631K4B1@SDIP32
[(SA653)]

ST72T631K4M1@SSOP34 [(SA658)] ST72T632K2B1@SDIP32
[(SA653)]
ST72T632K2M1@SSOP34 [(SA658)] ST72T633K1B1@SDIP32
[(SA653)]
ST72T633K1M1@SSOP34 [(SA658)]
ST72T671N6B@SDIP56(*) [(SA627-B5601)]
ST72T751N9B@SDIP56(*) [(SA627-B5601)]
ST72T752J6B@SDIP42 [(SA028)] ST72T753L6M@SSOP34
[(SA658)]
ST72T771N9B@SDIP56(*) [(SA627-B5601)]
ST7FDALIF2M6@SOIC20 [(SA404)]
ST7FDALIF2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLIT10BF0B3
ST7FLIT10BF0B6
ST7FLIT10BF0M3@SOIC20 [(SA404)] ST7FLIT10BF0M6@SOIC20
[(SA404)]
ST7FLIT10BF1B3
ST7FLIT10BF1B6
ST7FLIT10BF1M3@SOIC20 [(SA404)] ST7FLIT10BF1M6@SOIC20
[(SA404)]
ST7FLIT10BY0B3
ST7FLIT10BY0B6
ST7FLIT10BY0M3@SOIC16 [(SA602)] ST7FLIT10BY0M6@SOIC16
[(SA602)]
ST7FLIT10BY1B3
ST7FLIT10BY1B6
ST7FLIT10BY1M3@SOIC16 [(SA602)] ST7FLIT10BY1M6@SOIC16
[(SA602)]
ST7FLIT15BF0B3
ST7FLIT15BF0B6
ST7FLIT15BF0M3@SOIC20 [(SA404)] ST7FLIT15BF0M6@SOIC20
[(SA404)]
ST7FLIT15BF1B3
ST7FLIT15BF1B6
ST7FLIT15BF1M3@SOIC20 [(SA404)] ST7FLIT15BF1M6@SOIC20
[(SA404)]
ST7FLIT15BF1U6TR@QFN20 [(BBBB)]
ST7FLIT15BY0B3
ST7FLIT15BY0B6 ST7FLIT15BY0M3@SOIC16
[(SA602)]
ST7FLIT15BY0M6@SOIC16 [(SA602)]
ST7FLIT15BY1B3
ST7FLIT15BY1B6 ST7FLIT15BY1M3@SOIC16

[(SA602)]
ST7FLIT15BY1M6@SOIC16 [(SA602)]
ST7FLIT19BF0B3
ST7FLIT19BF0B6 ST7FLIT19BF0M3@SOIC20
[(SA404)]
ST7FLIT19BF0M6@SOIC20 [(SA404)]
ST7FLIT19BF1B3
ST7FLIT19BF1B6 ST7FLIT19BF1M3@SOIC20
[(SA404)]
ST7FLIT19BF1M6@SOIC20 [(SA404)] ST7FLIT19BF1U6TR@QFN20
[(BBBB)]
ST7FLIT19BY0B3
ST7FLIT19BY0B6
ST7FLIT19BY0M3@SOIC16 [(SA602)] ST7FLIT19BY0M6@SOIC16
[(SA602)]
ST7FLIT19BY1B3
ST7FLIT19BY1B6
ST7FLIT19BY1M3@SOIC16 [(SA602)] ST7FLIT19BY1M6@SOIC16
[(SA602)]
ST7FLITE02B6 ST7FLITE02B6(ISP) [ISP-
HEADER01]
ST7FLITE02M6@SOIC16 [(SA602)]
ST7FLITE02M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE02Y0B6
ST7FLITE02Y0B6(ISP) [ISP-HEADER01]
ST7FLITE02Y0M6@SOIC16 [(SA602)]
ST7FLITE02Y0M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE05B6 ST7FLITE05B6(ISP) [ISP-
HEADER01]
ST7FLITE05M6@SOIC16 [(SA602)]
ST7FLITE05M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE05Y0B6
ST7FLITE05Y0B6(ISP) [ISP-HEADER01]
ST7FLITE05Y0M6@SOIC16 [(SA602)]
ST7FLITE05Y0M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE09B6 ST7FLITE09B6(ISP) [ISP-
HEADER01]
ST7FLITE09M6@SOIC16 [(SA602)]
ST7FLITE09M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITE09Y0B6
ST7FLITE09Y0B6(ISP) [ISP-HEADER01]
ST7FLITE09Y0M6@SOIC16 [(SA602)]
ST7FLITE09Y0M6@SOIC16(ISP) [ISP-HEADER01]

ST7FLITE10F1B6
ST7FLITE10F1B6(ISP) [ISP-HEADER01]
ST7FLITE10F1M6@SOIC20 [(SA404)]
ST7FLITE10F1M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE15F1B6
ST7FLITE15F1B6(ISP) [ISP-HEADER01]
ST7FLITE15F1M6@SOIC20 [(SA404)]
ST7FLITE15F1M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE19F1B6
ST7FLITE19F1B6(ISP) [ISP-HEADER01]
ST7FLITE19F1M6@SOIC20 [(SA404)]
ST7FLITE19F1M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE20F2B6
ST7FLITE20F2B6(ISP) [ISP-HEADER01]
ST7FLITE20F2M6@SOIC20 [(SA404)]
ST7FLITE20F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE25F2B6
ST7FLITE25F2B6(ISP) [ISP-HEADER01]
ST7FLITE25F2M6@SOIC20 [(SA404)]
ST7FLITE25F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE29F2B6
ST7FLITE29F2B6(ISP) [ISP-HEADER01]
ST7FLITE29F2M6@SOIC20 [(SA404)]
ST7FLITE29F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE30F2B6
ST7FLITE30F2B6(ISP) [ISP-HEADER01]
ST7FLITE30F2M6@SOIC20 [(SA404)]
ST7FLITE30F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE35F2B6
ST7FLITE35F2B6(ISP) [ISP-HEADER01]
ST7FLITE35F2M6@SOIC20 [(SA404)]
ST7FLITE35F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITE39F2B6
ST7FLITE39F2B6(ISP) [ISP-HEADER01]
ST7FLITE39F2M6@SOIC20 [(SA404)]
ST7FLITE39F2M6@SOIC20(ISP) [ISP-HEADER01]
ST7FLITEBC ST7FLITEBCM6@SOIC16
[(SA602)]
ST7FLITES0 ST7FLITES0@SOIC16
[(SA602)]
ST7FLITES2B6 ST7FLITES2B6(ISP) [ISP-
HEADER01]
ST7FLITES2M6@SOIC16 [(SA602)]

ST7FLITES2M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITES2Y0B6
ST7FLITES2Y0B6(ISP) [ISP-HEADER01]
ST7FLITES2Y0M6@SOIC16 [(SA602)]
ST7FLITES2Y0M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITES5B6 ST7FLITES5B6(ISP) [ISP-
HEADER01]
ST7FLITES5M6@SOIC16 [(SA602)]
ST7FLITES5M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITES5Y0B6
ST7FLITES5Y0B6(ISP) [ISP-HEADER01]
ST7FLITES5Y0M6@SOIC16 [(SA602)]
ST7FLITES5Y0M6@SOIC16(ISP) [ISP-HEADER01]
ST7FLITEUS2B6 ST7FLITEUS2M6@SOIC8
[(SA602A)]
ST7FLITEUS2M6TR@SOIC8 [(SA602A)] ST7FLITEUS2U6TR@DFN8
[(BBBB)]
ST7FLITEUS5B6 ST7FLITEUS5M6@SOIC8
[(SA602A)]
ST7FLITEUS5M6TR@SOIC8 [(SA602A)] ST7FLITEUS5U6TR@DFN8
[(BBBB)]
ST7FLU05B6
ST7FLU05BAE
ST7FLU05BATRE
ST7FLU05BCE
ST7FLU05BCTRE ST7FLU05M6@SOIC8
[(SA602A)]
ST7FLU05MAE@SOIC8 [(SA602A)] ST7FLU05MATRE@SOIC8
[(SA602A)]
ST7FLU05MCE@SOIC8 [(SA602A)] ST7FLU05MCTRE@SOIC8
[(SA602A)]
ST7FLU09B6
ST7FLU09BAE
ST7FLU09BATRE
ST7FLU09BCE
ST7FLU09BCTRE ST7FLU09M6@SOIC8
[(SA602A)]
ST7FLU09MAE@SOIC8 [(SA602A)] ST7FLU09MATRE@SOIC8
[(SA602A)]
ST7FLU09MCE@SOIC8 [(SA602A)] ST7FLU09MCTRE@SOIC8
[(SA602A)]
ST7FLUS5B6
ST7FLUS5BAE

ST7FLUS5BATRE

ST7FLUS5BCE

ST7FLUS5BCTRE

[(SA602A)]

ST7FLUS5MAE@SOIC8 [(SA602A)]

[(SA602A)]

ST7FLUS5MCE@SOIC8 [(SA602A)]

[(SA602A)]

ST7FSCR1E4M1@SOIC24(*) [(SA404-B140)]

ST7FLUS5M6@SOIC8

ST7FLUS5MATRE@SOIC8

ST7FLUS5MCTRE@SOIC8

STC

MICROCONTROLLER

STC89C516RD

[(SA244)]

STC89C516RD@TQFP44 [(SA245A)]

STC89C58RD

STC89C58RD@PLCC44 [(SA244)]

[(SA245A)]

STC89LE516AD

[(SA244)]

STC89LE516AD@TQFP44 [(SA245A)]

STC89LE516X2

STC89LE516X2@PLCC44 [(SA244)]

[(SA245A)]

STC89LE52AD

[(SA244)]

STC89LE52AD@TQFP44 [(SA675)]

STC89LE54AD

STC89LE54AD@PLCC44 [(SA244)]

[(SA675)]

STC89LE556AD

[(SA244)]

STC89LE556AD@TQFP44 [(SA245A)]

STC89LE556X2

STC89LE556X2@PLCC44 [(SA244)]

[(SA245A)]

STC89LE58AD

[(SA244)]

STC89LE58AD@TQFP44 [(SA675)]

STC89LV516RD

STC89C516RD@PLCC44

STC89C58RD@TQFP44

STC89LE516AD@PLCC44

STC89LE516X2@TQFP44

STC89LE52AD@PLCC44

STC89LE54AD@TQFP44

STC89LE556AD@PLCC44

STC89LE556X2@TQFP44

STC89LE58AD@PLCC44

STC89LV516RD@PLCC44 [(SA244)]	STC89LV516RD@TQFP44
[(SA245A)]	
STC89LV58RD	STC89LV58RD@PLCC44
[(SA244)]	
STC89LV58RD@TQFP44 [(SA245A)]	

ST-CUSTOMER

E(E) PROM/FRAM/NVRAM

M36L0R7050B0_B1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]	
M36L0R7050T0_T1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]	
M36L0R8060B3(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]	
M36L0R8060B5ZAQ(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]	
M58LR128FB_GB(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]	
M58LR128FT_GT(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]	
NAND01GW3B2BZA6(ASUS)@FBGA63 [(SA642KK-B026-W048F001Y)]	
NAND04GW3B2BN6(WS)@TSOP48 [(SA247-B005)]	
NAND512R3A2(MLT)@FBGA63 [(SA642KK-B026-W0638F001Y)]	

SUMMIT

E(E) PROM/FRAM/NVRAM

S24022	S24022@SOIC8
[(SA602A)]	
S24023	S24023@SOIC8
[(SA602A)]	
S24042	S24042@SOIC8
[(SA602A)]	
S24043	S24043@SOIC8
[(SA602A)]	
S24162	S24162@SOIC8
[(SA602A)]	
S24VP02	S24VP02@SOIC8
[(SA602A)]	
S24VP04	S24VP04@SOIC8
[(SA602A)]	
S24VP08	S24VP08@SOIC8
[(SA602A)]	

S24VP16 [(SA602A)]	S24VP16@SOIC8
S93462(08bit) [(SA602A)]	S93462(08bit)@SOIC8
S93462(16bit) [(SA602A)]	S93462(16bit)@SOIC8
S93463(08bit) [(SA602A)]	S93463(08bit)@SOIC8
S93463(16bit) [(SA602A)]	S93463(16bit)@SOIC8
S93662(08bit) [(SA602A)]	S93662(08bit)@SOIC8
S93662(16bit) [(SA602A)]	S93662(16bit)@SOIC8
S93663(08bit) [(SA602A)]	S93663(08bit)@SOIC8
S93663(16bit) [(SA602A)]	S93663(16bit)@SOIC8
S93WD462(08bit) [(SA602A)]	S93WD462(08bit)@SOIC8
S93WD462(16bit) [(SA602A)]	S93WD462(16bit)@SOIC8
S93WD463(08bit) [(SA602A)]	S93WD463(08bit)@SOIC8
S93WD463(16bit) [(SA602A)]	S93WD463(16bit)@SOIC8
S93WD662(08bit) [(SA602A)]	S93WD662(08bit)@SOIC8
S93WD662(16bit) [(SA602A)]	S93WD662(16bit)@SOIC8
S93WD663(08bit) [(SA602A)]	S93WD663(08bit)@SOIC8
S93WD663(16bit) [(SA602A)]	S93WD663(16bit)@SOIC8

MICROCONTROLLER

I-SMM465F-249@TQFP48 (ISP) [ISP-HEADER01]	
SMM465F-249@TQFP48 [(SA248)]	SMM665BFC-266@TQFP48
[(SA248)]	
SMM665BFC-266@TQFP48 (ISP) [ISP-HEADER01]	

SUNPLUS

E (E) PROM / FRAM / NVRAM

SPHE6400A
[(SA602A)]

SPHE6400A@SOIC8

MICROCONTROLLER

SPMC65P2102A(dip18)
SPMC65P2102A(dip18)(ISP) [ISP-HEADER01]
SPMC65P2102A@SOP18 [(SA404)]
SPMC65P2102A@SOP18(ISP) [ISP-HEADER01]
SPMC65P2104A(dip18)
SPMC65P2104A(dip18)(ISP) [ISP-HEADER01]
SPMC65P2104A@SOP18 [(SA404)]
SPMC65P2104A@SOP18(ISP) [ISP-HEADER01]
SPMC65P2202A(dip16)
SPMC65P2202A(dip16)(ISP) [ISP-HEADER01]
SPMC65P2202A(dip20)
SPMC65P2202A(dip20)(ISP) [ISP-HEADER01]
SPMC65P2202A@SOP16 [(SA404)]
SPMC65P2202A@SOP16(ISP) [ISP-HEADER01]
SPMC65P2202A@SOP20 [(SA404)]
SPMC65P2202A@SOP20(ISP) [ISP-HEADER01]
SPMC65P2204A(dip16)
SPMC65P2204A(dip16)(ISP) [ISP-HEADER01]
SPMC65P2204A(dip20)
SPMC65P2204A(dip20)(ISP) [ISP-HEADER01]
SPMC65P2204A@SOP16 [(SA404)]
SPMC65P2204A@SOP16(ISP) [ISP-HEADER01]
SPMC65P2204A@SOP20 [(SA404)]
SPMC65P2204A@SOP20(ISP) [ISP-HEADER01]
SPMC65P2404A(dip20)
SPMC65P2404A(dip20)(ISP) [ISP-HEADER01]
SPMC65P2404A(dip28)
SPMC65P2404A(dip28)(ISP) [ISP-HEADER01]
SPMC65P2404A@SOP20 [(SA404)]
SPMC65P2404A@SOP20(ISP) [ISP-HEADER01]
SPMC65P2404A@SOP28 [(SA404)]
SPMC65P2404A@SOP28(ISP) [ISP-HEADER01]

SPMC65P2408A(dip28)
 SPMC65P2408A(dip28)(ISP) [ISP-HEADER01]
 SPMC65P2408A(dip32)
 SPMC65P2408A(dip32)(ISP) [ISP-HEADER01]
 SPMC65P2408A@SOP28 [(SA404)]
 SPMC65P2408A@SOP28(ISP) [ISP-HEADER01]
 SPMC65P2408A@SOP32 [(SA603)]
 SPMC65P2408A@SOP32(ISP) [ISP-HEADER01]

SYNCMOS

E (E) PROM/FRAM/NVRAM

F29C31004B [(SA015A1T)]	F29C31004B@PLCC32
F29C31004B@TSOP32 [(SA410T)]	
F29C31004T F29C31004T@PLCC32 [(SA015A1T)]	F29C31004T@TSOP32
[(SA410T)]	
F29C51000B [(SA015A1T)]	F29C51000B@PLCC32
F29C51000T [(SA015A1T)]	F29C51000T@PLCC32
F29C51001B [(SA015A1T)]	F29C51001B@PLCC32
F29C51001B@TSOP32 [(SA410T)]	
F29C51001T F29C51001T@PLCC32 [(SA015A1T)]	F29C51001T@TSOP32
[(SA410T)]	
F29C51002B [(SA015A1T)]	F29C51002B@PLCC32
F29C51002B@TSOP32 [(SA410T)]	
F29C51002T F29C51002T@PLCC32 [(SA015A1T)]	F29C51002T@TSOP32
[(SA410T)]	
F29C51004B [(SA015A1T)]	F29C51004B@PLCC32
F29C51004B@TSOP32 [(SA410T)]	
F29C51004T F29C51004T@PLCC32 [(SA015A1T)]	F29C51004T@TSOP32
[(SA410T)]	
F29LC51000	F29LC51000@PLCC32

[(SA015A1T)]
F29LC51001 F29LC51001@PLCC32
[(SA015A1T)]
F29LC51002 F29LC51002@PLCC32
[(SA015A1T)]
S29C31001B S29C31001B@PLCC32
[(SA015A1T)]
S29C31001B@TSOP32 [(SA410T)]
S29C31001T
S29C31001T@PLCC32 [(SA015A1T)] S29C31001T@TSOP32
[(SA410T)]
S29C31002B S29C31002B@PLCC32
[(SA015A1T)]
S29C31002B@TSOP32 [(SA410T)]
S29C31002T
S29C31002T@PLCC32 [(SA015A1T)] S29C31002T@TSOP32
[(SA410T)]
S29C31004B S29C31004B@PLCC32
[(SA015A1T)]
S29C31004B@TSOP32 [(SA410T)]
S29C31004T
S29C31004T@PLCC32 [(SA015A1T)] S29C31004T@TSOP32
[(SA410T)]
S29C51001B S29C51001B@PLCC32
[(SA015A1T)]
S29C51001B@TSOP32 [(SA410T)]
S29C51001T
S29C51001T@PLCC32 [(SA015A1T)] S29C51001T@TSOP32
[(SA410T)]
S29C51002B S29C51002B@PLCC32
[(SA015A1T)]
S29C51002B@TSOP32 [(SA410T)]
S29C51002T
S29C51002T@PLCC32 [(SA015A1T)] S29C51002T@TSOP32
[(SA410T)]
S29C51004B S29C51004B@PLCC32
[(SA015A1T)]
S29C51004B@TSOP32 [(SA410T)]
S29C51004T
S29C51004T@PLCC32 [(SA015A1T)] S29C51004T@TSOP32
[(SA410T)]

MICROCONTROLLER

MSU1958 [(SA244)]	MSU1958@PLCC44
MSU1958@TQFP44 [(SA245A)]	
MSU2952 MSU2952@PLCC44 [(SA244)] [(SA245A)]	MSU2952@TQFP44
MSU2964 [(SA244)]	MSU2964@PLCC44
MSU2964@TQFP44 [(SA245A)]	
SM2958 SM2958@PLCC44 [(SA244)] [(SA245A)]	SM2958@TQFP44
SM2965 [(SA244)]	SM2965@PLCC44
SM2965@TQFP44 [(SA245A)]	
SM59064 SM59064@PLCC44 [(SA244)] [(SA245A)]	SM59064@TQFP44
SM59128C [(SA244)]	SM59128C@PLCC44
SM59128C@TQFP44 [(SA245A)]	
SM59128L SM59128L@PLCC44 [(SA244)] [(SA245A)]	SM59128L@TQFP44
SM59164 [(SA244)]	SM59164@PLCC44
SM59164@TQFP44 [(SA245A)]	
SM59264 SM59264@PLCC44 [(SA244)] [(SA245A)]	SM59264@TQFP44
SM5964 [(SA244)]	SM5964@PLCC44
SM5964@TQFP44 [(SA245A)]	
SM5964A SM5964A@PLCC44 [(SA244)] [(SA245A)]	SM5964A@TQFP44
SM5964AC [(SA244)]	SM5964AC@PLCC44
SM5964AC@TQFP44 [(SA245A)]	
SM5964AL SM5964AL@PLCC44 [(SA244)]	SM5964AL@TQFP44

[(SA245A)]
SM5964C SM5964C@PLCC44
[(SA244)]
SM5964C@TQFP44 [(SA245A)]
SM5964D0
SM5964D0@PLCC44 [(SA244)] SM5964D0@TQFP44
[(SA245A)]
SM5964D0A SM5964D0A@PLCC44
[(SA244)]
SM5964D0A@TQFP44 [(SA245A)]
SM5964D1A
SM5964D1A@PLCC44 [(SA244)] SM5964D1A@TQFP44
[(SA245A)]
SM59D02G2C SM59D02G2C (ISP) [ISP-
HEADER01]
SM59D02G2C@LQFP44 [(SA675-B005)]
SM59D02G2C@LQFP44 (ISP) [ISP-HEADER01]
SM59D02G2C@PLCC44 [(SA244-B002)]
SM59D02G2C@PLCC44 (ISP) [ISP-HEADER01]
SM59D02G2L SM59D02G2L (ISP) [ISP-
HEADER01]
SM59D02G2L@LQFP44 [(SA675-B005)]
SM59D02G2L@LQFP44 (ISP) [ISP-HEADER01]
SM59D02G2L@PLCC44 [(SA244-B002)]
SM59D02G2L@PLCC44 (ISP) [ISP-HEADER01]
SM59D03G2C SM59D03G2C (ISP) [ISP-
HEADER01]
SM59D03G2C@LQFP44 [(SA675-B005)]
SM59D03G2C@LQFP44 (ISP) [ISP-HEADER01]
SM59D03G2C@PLCC44 [(SA244-B002)]
SM59D03G2C@PLCC44 (ISP) [ISP-HEADER01]
SM59D03G2L SM59D03G2L (ISP) [ISP-
HEADER01]
SM59D03G2L@LQFP44 [(SA675-B005)]
SM59D03G2L@LQFP44 (ISP) [ISP-HEADER01]
SM59D03G2L@PLCC44 [(SA244-B002)]
SM59D03G2L@PLCC44 (ISP) [ISP-HEADER01]
SM59D04G2C SM59D04G2C (ISP) [ISP-
HEADER01]
SM59D04G2C@LQFP44 [(SA675-B005)]
SM59D04G2C@LQFP44 (ISP) [ISP-HEADER01]
SM59D04G2C@PLCC44 [(SA244-B002)]
SM59D04G2C@PLCC44 (ISP) [ISP-HEADER01]

SM59D04G2L SM59D04G2L(ISP) [ISP-
HEADER01]
SM59D04G2L@LQFP44 [(SA675-B005)]
SM59D04G2L@LQFP44(ISP) [ISP-HEADER01]
SM59D04G2L@PLCC44 [(SA244-B002)]
SM59D04G2L@PLCC44(ISP) [ISP-HEADER01]
SM59R08A2@TQFP64(*) [(SA732-B292)]
SM59R16A2@TQFP64(*) [(SA732-B292)]
SM7908 SM7908@PLCC44
[(SA244)]
SM7908@TQFP44 [(SA245A)]
SM79108
SM79108@PLCC44 [(SA244)] SM79108@TQFP44
[(SA245A)]
SM79164 SM79164@PLCC44
[(SA244)]
SM79164@TQFP44 [(SA245A)]
SM79164L
SM79164L@PLCC44 [(SA244)] SM79164L@TQFP44
[(SA245A)]
SM79164V SM79164V@PLCC44
[(SA244)]
SM79164V@TQFP44 [(SA245A)]
SM7932
SM7932@PLCC44 [(SA244)] SM7932@TQFP44
[(SA245A)]
SM7964 SM7964@PLCC44
[(SA244)]
SM7964@TQFP44 [(SA245A)]
SM894051
SM894051@SOIC20 [ordering number is marked above]
SM8951 SM8951@PLCC44
[(SA244)]
SM8951@TQFP44 [(SA245A)]
SM89516
SM89516@PLCC44 [(SA244)] SM89516@TQFP44
[(SA245A)]
SM89516A SM89516A@PLCC44
[(SA244)]
SM89516A@TQFP44 [(SA245A)]
SM89516AL
SM89516AL@PLCC44 [(SA244)] SM89516AL@TQFP44
[(SA245A)]

SM89516B [(SA244)]	SM89516B@PLCC44
SM89516B@TQFP44 [(SA245A)]	
SM89516BL SM89516BL@PLCC44 [(SA244)] [(SA245A)]	SM89516BL@TQFP44
SM89516L [(SA244)]	SM89516L@PLCC44
SM89516L@TQFP44 [(SA245A)]	
SM8951A SM8951A@PLCC44 [(SA244)] [(SA245A)]	SM8951A@TQFP44
SM8951AL [(SA244)]	SM8951AL@PLCC44
SM8951AL@TQFP44 [(SA245A)]	
SM8951B SM8951B@PLCC44 [(SA244)] [(SA245A)]	SM8951B@TQFP44
SM8951BL [(SA244)]	SM8951BL@PLCC44
SM8951BL@TQFP44 [(SA245A)]	
SM8951L SM8951L@PLCC44 [(SA244)] [(SA245A)]	SM8951L@TQFP44
SM8952 [(SA244)]	SM8952@PLCC44
SM8952@TQFP44 [(SA245A)]	
SM8952A SM8952A@PLCC44 [(SA244)] [(SA245A)]	SM8952A@TQFP44
SM8952AL [(SA244)]	SM8952AL@PLCC44
SM8952AL@TQFP44 [(SA245A)]	
SM8952B SM8952B@PLCC44 [(SA244)] [(SA245A)]	SM8952B@TQFP44
SM8952BL [(SA244)]	SM8952BL@PLCC44
SM8952BL@TQFP44 [(SA245A)]	
SM8952L SM8952L@PLCC44 [(SA244)] [(SA245A)]	SM8952L@TQFP44
SM8954	SM8954@PLCC44

[(SA244)]	
SM8954@TQFP44 [(SA245A)]	
SM8954A	
SM8954A@PLCC44 [(SA244)]	SM8954A@TQFP44
[(SA245A)]	
SM8954AL	SM8954AL@PLCC44
[(SA244)]	
SM8954AL@TQFP44 [(SA245A)]	
SM8954B	
SM8954B@PLCC44 [(SA244)]	SM8954B@TQFP44
[(SA245A)]	
SM8954BL	SM8954BL@PLCC44
[(SA244)]	
SM8954BL@TQFP44 [(SA245A)]	
SM8954L	
SM8954L@PLCC44 [(SA244)]	SM8954L@TQFP44
[(SA245A)]	
SM8958	SM8958@PLCC44
[(SA244)]	
SM8958@TQFP44 [(SA245A)]	
SM8958A	
SM8958A@PLCC44 [(SA244)]	SM8958A@TQFP44
[(SA245A)]	
SM8958AL	SM8958AL@PLCC44
[(SA244)]	
SM8958AL@TQFP44 [(SA245A)]	
SM8958B	
SM8958B@PLCC44 [(SA244)]	SM8958B@TQFP44
[(SA245A)]	
SM8958BL	SM8958BL@PLCC44
[(SA244)]	
SM8958BL@TQFP44 [(SA245A)]	
SM8958L	
SM8958L@PLCC44 [(SA244)]	SM8958L@TQFP44
[(SA245A)]	
SM89S16R1C	SM89S16R1C@PLCC44
[(SA244)]	
SM89S16R1C@TQFP44 [(SA245A)]	
SM89T04R1C	
SM89T04R1C@PLCC44 [(SA244)]	SM89T04R1C@TQFP44
[(SA245A)]	
SM89T04R1L	SM89T04R1L@PLCC44
[(SA244)]	

SM89T04R1L@TQFP44 [(SA245A)]	
SM89T08R1C	
SM89T08R1C@PLCC44 [(SA244)]	SM89T08R1C@TQFP44
[(SA245A)]	
SM89T08R1L	
[(SA244)]	SM89T08R1L@PLCC44
SM89T08R1L@TQFP44 [(SA245A)]	
SM89T16R1C	
SM89T16R1C@PLCC44 [(SA244)]	SM89T16R1C@TQFP44
[(SA245A)]	
SM89T16R1L	
[(SA244)]	SM89T16R1L@PLCC44
SM89T16R1L@TQFP44 [(SA245A)]	

SYNERTEK

E (E) PROM / FRAM / NVRAM

SY2716

SYNTEK

MICROCONTROLLER

STK6011BP1-3V@PLCC44 [(SA244)]	STK6011BP21-5V@PLCC44
[(SA244)]	
STK6011BP5-3V@TQFP44 [(SA245A)]	STK6011P10-5V@LQFP48
[(SA248)]	
STK6011P1-3V@PLCC44 [(SA244)]	STK6011P2-5V@PLCC44
[(SA244)]	
STK6011P3-3V@SDIP42 [(SA028)]	STK6011P4-5V@SDIP42
[(SA028)]	
STK6011P5-3V@PQFP44 [(SA245A)]	STK6011P6-5V@PQFP44
[(SA245A)]	
STK6011P7-3V	STK6011P8-
5V	
STK6011P9-3V@LQFP48 [(SA248)]	STK6012BP1-3V@PLCC44
[(SA244)]	
STK6012BP22-5V@PLCC44 [(SA244)]	STK6012BP5-3V@TQFP44
[(SA245A)]	

STK6012P10-5V@LQFP48 [(SA248)]
[(SA244)]
STK6012P2-5V@PLCC44 [(SA244)]
[(SA028)]
STK6012P4-5V@SDIP42 [(SA028)]
[(SA245A)]
STK6012P6-5V@PQFP44 [(SA245A)]
3V
STK6012P8-5V
[(SA248)]

STK6012P1-3V@PLCC44
STK6012P3-3V@SDIP42
STK6012P5-3V@PQFP44
STK6012P7-
STK6012P9-3V@LQFP48

TECHCODE

MICROCONTROLLER

T89C516
[(SA244)]
T89C516@TQFP44 [(SA245A)]
T89C52
T89C52@PLCC44 [(SA244)]
[(SA245A)]
T89C58
[(SA244)]
T89C58@TQFP44 [(SA245A)]

T89C516@PLCC44
T89C52@TQFP44
T89C58@PLCC44

TEKMOS

E(E) PROM/FRAM/NVRAM

TK17LV040@PLCC20 [(SA001A)]

TEMIC

MICROCONTROLLER

T89C51RD2
[(SA244)]
T89C51RD2@TQFP44 [(SA245A)]
T89F64

T89C51RD2@PLCC44

T89F64@PLCC44 [(SA244)]	T89F64@TQFP44
[(SA245A)]	
TS87C51RB2	TS87C51RB2@PLCC44
[(SA244)]	
TS87C51RB2@TQFP44 [(SA245A)]	
TS87C51RC2	
TS87C51RC2@PLCC44 [(SA244)]	TS87C51RC2@TQFP44
[(SA245A)]	
TS87C51RD2	TS87C51RD2@PLCC44
[(SA244)]	
TS87C51RD2@TQFP44 [(SA245A)]	
TS87C51U2	
TS87C51U2@PLCC44 [(SA244)]	TS87C51U2@TQFP44
[(SA245A)]	
TS87C52X2	TS87C52X2@PLCC44
[(SA244)]	
TS87C52X2@TQFP44 [(SA245A)]	
TS87C54X2	
TS87C54X2@PLCC44 [(SA244)]	TS87C54X2@TQFP44
[(SA245A)]	
TS87C58X2	TS87C58X2@PLCC44
[(SA244)]	
TS87C58X2@TQFP44 [(SA245A)]	
TSC71RBX2	
TSC71RBX2@PLCC44 [(SA244)]	TSC71RBX2@TQFP44
[(SA245A)]	
TSC71RCX2	TSC71RCX2@PLCC44
[(SA244)]	
TSC71RCX2@TQFP44 [(SA245A)]	
TSC71RDX2	
TSC71RDX2@PLCC44 [(SA244)]	TSC71RDX2@TQFP44
[(SA245A)]	
TSC87251A1@PLCC44 [(SA244)]	
TSC87251G1	
TSC87251G1@PLCC44 [(SA244)]	
TSC87251G1A	
TSC87251G1A@PLCC44 [(SA244)]	
TSC87251G2D	
TSC87251G2D@PLCC44 [(SA244)]	TSC87251G2D@TQFP44
[(SA245A)]	
TSC87C51	TSC87C51@PLCC44
[(SA244)]	
TSC87C51@TQFP44 [(SA245A)]	

TSC87C52

TSC87C52@PLCC44 [(SA244)]
[(SA245A)]

TSC87C52@TQFP44

TSC87C54
[(SA244)]

TSC87C54@PLCC44

TSC87C54@TQFP44 [(SA245A)]

TSC87C58

TSC87C58@PLCC44 [(SA244)]
[(SA245A)]

TSC87C58@TQFP44

TI

E (E) PROM / FRAM / NVRAM

BQ4010

BQ4010Y

BQ4011

BQ4011Y

BQ4013

BQ4013Y

BQ4014

BQ4014Y

BQ4015

BQ4015Y

SMJ2516

SMJ2532

SMJ2532A

SMJ2564

SMJ2564@PLCC32 [(SA015A1T)]

SMJ2716

SMJ27C256

SMJ27C256@PLCC32

[(SA015A1T)]

SMJ27C512

SMJ27C512@PLCC32

[(SA015A1T)]

TMS2516

TMS2516JLW

TMS2532

TMS2532A

TMS2564

TMS2564@PLCC32

[(SA015A1T)]

TMS25L32

TMS27128

TMS27128A
TMS2716
TMS2732
TMS2732A
TMS2764
TMS27C010
TMS27C010@PLCC32 [(SA015A1T)] TMS27C010@TSOP32
[(SA410T)]
TMS27C010A TMS27C010A@PLCC32
[(SA015A1T)]
TMS27C010A@TSOP32 [(SA410T)]
TMS27C020
TMS27C020@PLCC32 [(SA015A1T)] TMS27C020@TSOP32
[(SA410T)]
TMS27C040 TMS27C040@PLCC32
[(SA015A1T)]
TMS27C040@TSOP32 [(SA410T)]
TMS27C128
TMS27C128@PLCC32 [(SA015A1T)]
TMS27C2001
TMS27C2001@PLCC32 [(SA015A1T)] TMS27C2001@TSOP32
[(SA410T)]
TMS27C210 TMS27C210@PLCC44
[(SA244)]
TMS27C210A TMS27C210A@PLCC44
[(SA244)]
TMS27C240 TMS27C240@PLCC44
[(SA244)]
TMS27C256 TMS27C256@PLCC32
[(SA015A1T)]
TMS27C291 TMS27C291@PLCC28
[(SA008A)]
TMS27C292 TMS27C292@PLCC28
[(SA008A)]
TMS27C32
TMS27C512
TMS27C512@PLCC32 [(SA015A1T)]
TMS27C64
TMS27LV010A TMS27LV010A@PLCC32
[(SA015A1T)]
TMS27LV010A@TSOP32 [(SA410T)]
TMS27P32A
TMS27P64

TMS27PC010	
TMS27PC010@PLCC32 [(SA015A1T)]	TMS27PC010@TSOP32
[(SA410T)]	
TMS27PC010A	TMS27PC010A@PLCC32
[(SA015A1T)]	
TMS27PC010A@TSOP32 [(SA410T)]	
TMS27PC020	
TMS27PC020@PLCC32 [(SA015A1T)]	TMS27PC020@TSOP32
[(SA410T)]	
TMS27PC040	TMS27PC040@PLCC32
[(SA015A1T)]	
TMS27PC040@TSOP32 [(SA410T)]	
TMS27PC128	
TMS27PC128@PLCC32 [(SA015A1T)]	
TMS27PC210	
TMS27PC210@PLCC44 [(SA244)]	
TMS27PC210A	
TMS27PC210A@PLCC44 [(SA244)]	
TMS27PC240	
TMS27PC240@PLCC44 [(SA244)]	
TMS27PC256	
TMS27PC256@PLCC32 [(SA015A1T)]	
TMS27PC291	
TMS27PC291@PLCC28 [(SA008A)]	
TMS27PC32	
TMS27PC32A	
TMS27PC512	
TMS27PC512@PLCC32 [(SA015A1T)]	
TMS27PC64	
TMS28F010	TMS28F010@PLCC32
[(SA015A1T)]	
TMS28F010@TSOP32 [(SA410T)]	
TMS28F020	
TMS28F020@PLCC32 [(SA015A1T)]	TMS28F020@TSOP32
[(SA410T)]	
TMS28F200BZ-B@PSOP44 [(SA638)]	TMS28F200BZ-T@PSOP44
[(SA638)]	
TMS28F210	TMS28F210@PLCC44
[(SA244)]	
TMS28F210@TSOP40 [(SA409T)]	TMS28F400AF-B@PSOP44
[(SA638)]	
TMS28F400AF-T@PSOP44 [(SA638)]	TMS28F400AS-B@PSOP44
[(SA638)]	

TMS28F400AS-T@PSOP44 [(SA638)]	TMS28F400BZ-B@PSOP44
[(SA638)]	
TMS28F400BZ-T@PSOP44 [(SA638)]	
TMS28F512	
TMS28F512@PLCC32 [(SA015A1T)]	TMS28F512@TSOP32
[(SA410T)]	
TMS29F040	TMS29F040@PLCC32
[(SA015A1T)]	
TMS29F040@TSOP32 [(SA410T)]	
TMS29F259	
TMS29F259@PLCC32 [(SA015A1T)]	TMS29F259@TSOP32
[(SA410T)]	
TMS29F512	TMS29F512@PLCC32
[(SA015A1T)]	
TMS29F512@TSOP32 [(SA410T)]	
TMS87C257	
TMS87C257@PLCC32 [(SA015A1T)]	

PLD

EP330	EP330@PLCC20
[(SA001A)]	
EP910	EP910-P44
[(SA244)]	

MICROCONTROLLER

MSP430F1122@SOIC20(ISP) [ISP-HEADER01]
MSP430F1122@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1132@SOIC20(ISP) [ISP-HEADER01]
MSP430F1132@TSSOP20(ISP) [ISP-HEADER01]
MSP430F1222@SOIC28(ISP) [ISP-HEADER01]
MSP430F1222@TSSOP28(ISP) [ISP-HEADER01]
MSP430F1232@SOIC28(ISP) [ISP-HEADER01]
MSP430F1232@TSSOP28(ISP) [ISP-HEADER01]
MSP430F133@QFN64(ISP) [ISP-HEADER01]
MSP430F133@TQFP64(ISP) [ISP-HEADER01]
MSP430F135@QFN64(ISP) [ISP-HEADER01]
MSP430F135@TQFP64(ISP) [ISP-HEADER01]
MSP430F147@QFN64(ISP) [ISP-HEADER01]
MSP430F147@TQFP64(ISP) [ISP-HEADER01]

MSP430F1471@QFN64(ISP) [ISP-HEADER01]
MSP430F1471@TQFP64(ISP) [ISP-HEADER01]
MSP430F148@QFN64(ISP) [ISP-HEADER01]
MSP430F148@TQFP64(ISP) [ISP-HEADER01]
MSP430F1481@QFN64(ISP) [ISP-HEADER01]
MSP430F1481@TQFP64(ISP) [ISP-HEADER01]
MSP430F149@QFN64(ISP) [ISP-HEADER01]
MSP430F149@TQFP64(ISP) [ISP-HEADER01]
MSP430F1491@QFN64(ISP) [ISP-HEADER01]
MSP430F1491@TQFP64(ISP) [ISP-HEADER01]
MSP430F155@QFN64(ISP) [ISP-HEADER01]
MSP430F155@TQFP64(ISP) [ISP-HEADER01]
MSP430F156@QFN64(ISP) [ISP-HEADER01]
MSP430F156@TQFP64(ISP) [ISP-HEADER01]
MSP430F157@QFN64(ISP) [ISP-HEADER01]
MSP430F157@TQFP64(ISP) [ISP-HEADER01]
MSP430F1610@QFN64(ISP) [ISP-HEADER01]
MSP430F1610@TQFP64(ISP) [ISP-HEADER01]
MSP430F1611@QFN64(ISP) [ISP-HEADER01]
MSP430F1611@TQFP64(ISP) [ISP-HEADER01]
MSP430F1612@QFN64(ISP) [ISP-HEADER01]
MSP430F1612@TQFP64(ISP) [ISP-HEADER01]
MSP430F167@QFN64(ISP) [ISP-HEADER01]
MSP430F167@TQFP64(ISP) [ISP-HEADER01]
MSP430F168@QFN64(ISP) [ISP-HEADER01]
MSP430F168@TQFP64(ISP) [ISP-HEADER01]
MSP430F169@QFN64(ISP) [ISP-HEADER01]
MSP430F169@TQFP64(ISP) [ISP-HEADER01]
MSP430F412@QFN64(ISP) [ISP-HEADER01]
MSP430F412@TQFP64(ISP) [ISP-HEADER01]
MSP430F413@QFN64(ISP) [ISP-HEADER01]
MSP430F413@TQFP64(ISP) [ISP-HEADER01]
MSP430F435@TQFP100(ISP) [ISP-HEADER01]
MSP430F435@TQFP80(ISP) [ISP-HEADER01]
MSP430F4351@TQFP100(ISP) [ISP-HEADER01]
MSP430F4351@TQFP80(ISP) [ISP-HEADER01]
MSP430F436@TQFP100(ISP) [ISP-HEADER01]
MSP430F436@TQFP80(ISP) [ISP-HEADER01]
MSP430F4361@TQFP100(ISP) [ISP-HEADER01]
MSP430F4361@TQFP80(ISP) [ISP-HEADER01]
MSP430F437@TQFP100(ISP) [ISP-HEADER01]
MSP430F437@TQFP80(ISP) [ISP-HEADER01]
MSP430F4371@TQFP100(ISP) [ISP-HEADER01]

MSP430F4371@TQFP80(ISP) [ISP-HEADER01]
 MSP430F447@TQFP100(ISP) [ISP-HEADER01]
 MSP430F448@TQFP100(ISP) [ISP-HEADER01]
 MSP430F449@TQFP100(ISP) [ISP-HEADER01]
 MSP430FG4250@QFN48(ISP) [ISP-HEADER01]
 MSP430FG4260@QFN48(ISP) [ISP-HEADER01]
 MSP430FG4270@QFN48(ISP) [ISP-HEADER01]
 MSP430FG437@TQFP100(ISP) [ISP-HEADER01]
 MSP430FG437@TQFP80(ISP) [ISP-HEADER01]
 MSP430FG438@TQFP100(ISP) [ISP-HEADER01]
 MSP430FG438@TQFP80(ISP) [ISP-HEADER01]
 MSP430FG439@TQFP100(ISP) [ISP-HEADER01]
 MSP430FG439@TQFP80(ISP) [ISP-HEADER01]

TMC

E (E) PROM/FRAM/NVRAM

24A01 [(SA602A)] 24A01@TSSOP8 [(SA026)] 24A02 24A02@SOIC8 [(SA602A)] [(SA026)] 24A04 [(SA602A)] 24A04@TSSOP8 [(SA026)] 24A08 24A08@SOIC8 [(SA602A)] [(SA026)] 24A16 [(SA602A)] 24A16@TSSOP8 [(SA026)] (08bit) 93LC46(08bit)@SOIC8 [(SA602A)] [(SA026)] 93LC46(16bit) [(SA602A)] 93LC46(16bit)@TSSOP8 [(SA026)] (08bit) 93LC56(08bit)@SOIC8 [(SA602A)] [(SA026)]	 24A01@SOIC8 24A02@TSSOP8 24A04@SOIC8 24A08@TSSOP8 24A16@SOIC8 93LC46 93LC46(08bit)@TSSOP8 93LC46(16bit)@SOIC8 93LC56 93LC56(08bit)@TSSOP8
--	--

93LC56(16bit) [(SA602A)]	93LC56(16bit)@SOIC8
93LC56(16bit)@TSSOP8 [(SA026)]	
93LC57	
93LC57@SOIC8 [(SA602A)] [(SA026)]	93LC57@TSSOP8
93LC66(08bit) [(SA602A)]	93LC66(08bit)@SOIC8
93LC66(08bit)@TSSOP8 [(SA026)] (16bit)	93LC66
93LC66(16bit)@SOIC8 [(SA602A)] [(SA026)]	93LC66(16bit)@TSSOP8
93LC86(08bit) [(SA602A)]	93LC86(08bit)@SOIC8
93LC86(08bit)@TSSOP8 [(SA026)] (16bit)	93LC86
93LC86(16bit)@SOIC8 [(SA602A)] [(SA026)]	93LC86(16bit)@TSSOP8

TOPRO

MICROCONTROLLER

TP2804H [(SA244)]	TP2804H@PLCC44
TP2804H@TQFP44 [(SA245A)]	
TP2804L	
TP2804L@PLCC44 [(SA244)] [(SA245A)]	TP2804L@TQFP44
TP2808H [(SA244)]	TP2808H@PLCC44
TP2808H@TQFP44 [(SA245A)]	
TP2808L	
TP2808L@PLCC44 [(SA244)] [(SA245A)]	TP2808L@TQFP44

TOSHIBA

E(E) PROM/FRAM/NVRAM

TC541000AF@PLCC32 [(SA015A1T)]
TC541000AP
TC541001AF@PLCC32 [(SA015A1T)]
TC541001AP
TC54256AF TC54256AF@SOIC28
[(SA404)]
TC54256AP TC54256AP@SOIC28
[(SA404)]
TC544000P
TC54512AF
TC54512AP
TC571000
TC571000AD
TC571000D
TC571001AD
TC571001D
TC571024D
TC57256
TC57256A
TC57256AD
TC57256ADI
TC57256D
TC574000D
TC574096D
TC574200D
TC57512
TC57512AD
TC578200D
TC57H1000AD
TC57H1001AD
TC57H256D TC58128AFT@TSOP48 [(SA247-
B005)]
TC58512FT@TSOP48 [(SA247-B005)]
TC58DVG02A1FT00@TSOP48 [(SA247-B005)]
TC58DVG02A2FT00@TSOP48 [(SA247-B005)]
TC58DVM72A1FT00@TSOP48 [(SA247-B005)]
TC58DVM72A1TG00@TSOP48 [(SA247-B005)]
TC58DVM82A1FT00@TSOP48 [(SA247-B005)]
TC58DVM82A1XBJ1@TFBGA56 [(SA642U-B197-T064F001Y)]
TC58DVM92A1FT00@TSOP48 [(SA247-B005)]
TC58F400@PSOP44 [(SA638-B006)] TC58F400@TSOP48 [(SA247-
B005)]
TC58F401@PSOP44 [(SA638-B006)] TC58F401@TSOP48 [(SA247-

B005)]
TC58FVB004FT@TSOP40 [(SA409T)] TC58FVB008FT@TSOP40
[(SA409T)]
TC58FVB016FT@TSOP40 [(SA409T)]
TC58FVB160AFT@TSOP48 [(SA247-B005)]
TC58FVB160AXB@TFBGA48 [(SA642B_B026A-Y072F001)]
TC58FVB160FT@TSOP48 [(SA247-B005)]
TC58FVB321FT@TSOP48 [(SA247-B005)]
TC58FVB321XB@TFBGA56 [(SA642A-B026A-Y096F001)]
TC58FVB400F@PSOP44 [(SA638)]
TC58FVB400FT@TSOP48 [(SA247-B005)]
TC58FVB641FT@TSOP48 [(SA247-B005)]
TC58FVB641XB@TFBGA63 [(SA642A-B026A-Y096N001)]
TC58FVB800F@PSOP44 [(SA638)]
TC58FVB800FT@TSOP48 [(SA247-B005)]
TC58FVM5B2AFT@TSOP48 [(SA247-B005)]
TC58FVM5B2ATG@TSOP48 [(SA247-B005)]
TC58FVM5B2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]
TC58FVM5B2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]
TC58FVM5B3AFT@TSOP48 [(SA247-B005)]
TC58FVM5B3ATG@TSOP48 [(SA247-B005)]
TC58FVM5B3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]
TC58FVM5B3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]
TC58FVM5T2AFT@TSOP48 [(SA247-B005)]
TC58FVM5T2ATG@TSOP48 [(SA247-B005)]
TC58FVM5T2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]
TC58FVM5T2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]
TC58FVM5T3AFT@TSOP48 [(SA247-B005)]
TC58FVM5T3ATG@TSOP48 [(SA247-B005)]
TC58FVM5T3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]
TC58FVM5T3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]
TC58FVM6B2AFT@TSOP48 [(SA247-B005)]
TC58FVM6B2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]
TC58FVM6B5BTG@TSOP48 [(SA247-B005)]
TC58FVM6B5BXG@TFBGA56 [(SA642U-B026A-T064F001Y)]
TC58FVM6T2AFT@TSOP48 [(SA247-B005)]
TC58FVM6T2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]
TC58FVM6T5BTG@TSOP48 [(SA247-B005)]
TC58FVM6T5BXG@TFBGA56 [(SA642U-B026A-T064F001Y)]
TC58FVM7B2AFT@TSOP56 [(SA628-B045)]
TC58FVM7B5BTG@TSOP56 [(SA628-B102)]
TC58FVM7B5BXG@FBGA80 [(SA642R-B099A-T096F001Y)]
TC58FVM7T2AFT@TSOP56 [(SA628-B045)]

TC58FVM7T5BTG@TSOP56 [(SA628-B102)]
 TC58FVM7T5BXG@FBGA80 [(SA642R-B099A-T096F001Y)]
 TC58FVT004FT@TSOP40 [(SA409T)] TC58FVT008FT@TSOP40
 [(SA409T)]
 TC58FVT016FT@TSOP40 [(SA409T)]
 TC58FVT160AFT@TSOP48 [(SA247-B005)]
 TC58FVT160AXB@TFBGA48 [(SA642B_B026A-Y072F001)]
 TC58FVT160FT@TSOP48 [(SA247-B005)]
 TC58FVT321FT@TSOP48 [(SA247-B005)]
 TC58FVT321XB@TFBGA56 [(SA642A-B026A-Y096F001)]
 TC58FVT400F@PSOP44 [(SA638)]
 TC58FVT400FT@TSOP48 [(SA247-B005)]
 TC58FVT641FT@TSOP48 [(SA247-B005)]
 TC58FVT641XB@TFBGA63 [(SA642A-B026A-Y096N001)]
 TC58FVT800F@PSOP44 [(SA638)]
 TC58FVT800FT@TSOP48 [(SA247-B005)]
 TC58FYB160FT@TSOP48 [(SA247-B005)]
 TC58FYT160FT@TSOP48 [(SA247-B005)]
 TC58NVG0S3AFT05@TSOP48 [(SA247-B005)]
 TC58V64BFT@TSOP44 [(SA645-B005)] TC89101
 (08bit)
 TC89101(16bit) TC89102
 (08bit)
 TC89102(16bit)
 TC89121
 TC89121@SOIC8 [(SA602A)]
 TC89122
 TC89122@SOIC8 [(SA602A)]
 TC97101
 TC9WMA1FK@US8 [(BBBB)] TC9WMA2FK@US8
 [(BBBB)]
 TC9WMB1AFK@US8 [(BBBB)] TC9WMB1AFU@SM8
 [(SA666)]
 TC9WMB1FK@US8 [(BBBB)] TC9WMB2AFK@US8
 [(BBBB)]
 TC9WMB2AFU@SM8 [(SA666)] TC9WMB2FK@US8
 [(BBBB)]
 TC9WMB4FU@SM8 [(SA666)] TC9WMB8FU@SM8
 [(SA666)]
 TC9WMC1FK@US8 [(BBBB)] TC9WMC1FU@SM8
 [(SA666)]
 TC9WMC2FK@US8 [(BBBB)] TC9WMC2FU@SM8
 [(SA666)]

TC9WMC4FK@US8 [(BBBB)] TC9WMC4FU@SM8
[(SA602A)]
TH50VPF5582ADSB@FBGA73 [(SA642E-B032A-T072F001)]
TH50VPF5583ADSB@FBGA73 [(SA642E-B032A-T072F001)]
TH50VPF5682CDSB@FBGA73 [(SA642E-B032A-T072F001)]
TH50VPF5683CDSB@FBGA73 [(SA642E-B032A-T072F001)]
TH50VPF5782AASB@FBGA73 [(SA664A-B096A-W115F001Y)]
TH50VPF5783AASB@FBGA73 [(SA664A-B096A-W115F001Y)]
TH50VPF6782AASB@FBGA73 [(SA664A-B096A-W115F001Y)]
TH50VPF6783AASB@FBGA73 [(SA664A-B096A-W115F001Y)]
TH50VSF1480AASB@FBGA65 [(SA642A-B032A-Y096N001)]
TH50VSF1481AASB@FBGA65 [(SA642A-B032A-Y096N001)]
TH50VSF2480AASB@FBGA65 [(SA642A-B032A-Y096N001)]
TH50VSF2481AASB@FBGA65 [(SA642A-B032A-Y096N001)]
TH50VSF2580AASB@FBGA69 [(SA642A-B032A-Y096F001)]
TH50VSF2581AASB@FBGA69 [(SA642A-B032A-Y096F001)]
TH50VSF2582AASB@FBGA69 [(SA642A-B032A-Y096F001)]
TH50VSF2582ADSB@FBGA73 [(SA642A-B032A-Y096F001)]
TH50VSF2582BDSB@FBGA73 [(SA642A-B032A-Y096F001)]
TH50VSF2583AASB@FBGA69 [(SA642A-B032A-Y096F001)]
TH50VSF2583ADSB@FBGA73 [(SA642A-B032A-Y096F001)]
TH50VSF2583BDSB@FBGA73 [(SA642A-B032A-Y096F001)]
TH50VSF2590AASB@FBGA69 [(SA642A-B032A-Y096F001)]
TH50VSF2682BDSB@FBGA73 [(SA642A-B032A-Y096F001)]
TH50VSF2683BDSB@FBGA73 [(SA642A-B032A-Y096F001)]
TH50VSF3580AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TH50VSF3581AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TH50VSF3582AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TH50VSF3582BDSB@FBGA73 [(SA642A-B032A-Y096F001)]
TH50VSF3583AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TH50VSF3583BDSB@FBGA73 [(SA642A-B032A-Y096F001)]
TH50VSF3680AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TH50VSF3681AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TH50VSF3682AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TH50VSF3682BDSB@FBGA73 [(SA642E-B032A-T072F001)]
TH50VSF3683AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TH50VSF3683BDSB@FBGA73 [(SA642E-B032A-T072F001)]
TH50VSF4682AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TH50VSF4683AASB@FBGA69 [(SA642A-B032A-Y096N001)]
TMM24128
TMM24128A
TMM24128AP
TMM24256

TMM24256A
TMM24256AP
TMM24256B
TMM24512
TMM24512A
TMM24512P
TMM2464AP
TMM27128
TMM27128A
TMM27128ADI
TMM27128AP
TMM27256
TMM27256A
TMM27256AD
TMM27256ADI
TMM27256BD
TMM27256BDI
TMM27256D
TMM27256DI
TMM2732
TMM2732A
TMM2732D
TMM27512
TMM27512AD
TMM27512ADI
TMM27512D
TMM27512DI
TMM2764
TMM2764AD
TMM2764ADI
TMM2764AP
TMM2764D
TMM2764DI
TV00560002ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]
TV00560002DDGB@FBGA81 [(SA642R-B079A-T096F001N)]
TV00560002EDGB@FBGA81 [(SA642R-B079A-T096F001N)]
TV00560003ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]
TV00569002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00569002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00569002BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00569002BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00569003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00569003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]

TV00569003BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00569003BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00570002AABB@FBGA73 [(SA664A-B096A-W115F001Y)]
TV00570002ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]
TV00570003AABB@FBGA73 [(SA664A-B096A-W115F001Y)]
TV00570003ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]
TV00578002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00578002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00578002CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00578002CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00578003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00578003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00578003CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00578003CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00579002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00579002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00579002AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00579002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00579003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00579003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00579003AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV00579003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV0057A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV0057A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV0057A002CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV0057A002CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV0057A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV0057A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV0057A003CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV0057A003CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV00670002ADGB@FBGA81 [(SA642R-B079A-T096F001N)]
TV00670002CABB@FBGA73 [(SA664A-B096A-W115F001Y)]
TV00670002CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]
TV00670003ADGB@FBGA81 [(SA642R-B079A-T096F001N)]
TV00670003CABB@FBGA73 [(SA664A-B096A-W115F001Y)]
TV00670003CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]
TV0067A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV0067A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TV0067A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]
TV0067A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TY00679002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TY00679003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]
TY8000A010AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]

TY9000A000CMHF@BGA149 [(SA664G-B279-Y149F001Y)]
TY9000A000GMGF@BGA149 [(SA664G-B143A-Y144F001Y)]
TY9000A400AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]
TYA000AC00EOGG@TFBGA225 [(SA678L-B294-Y225F001Y)]

DRAM & SRAM

TC518128 [(SA630)]	TC518128@SOIC32
TC518129 [(SA630)]	TC518129@SOIC32
TC51832 [(SA630)]	TC51832@SOIC28
TC518512 [(SA630)]	TC518512@SOIC32
TC551001FL [(SA630)]	TC551001FL@SOIC32
TC551001PL [(SA630)]	TC551001PL@SOIC32
TC55257 [(SA630)]	TC55257@SOIC28
TC55257L [(SA630)]	TC55257L@SOIC28
TC55258 [(SA630)]	TC55258@SOIC28
TC55258L [(SA630)]	TC55258L@SOIC28
TC55328 [(SA630)]	TC55328@SOIC28
TC5561P [(SA646)]	TC5561P@SOJ24
TC5562P [(SA646)]	TC5562P@SOJ24
TC5563APL [(SA630)]	TC5563APL@SOIC28
TC5564APL [(SA630)]	TC5564APL@SOIC28
TC5565AFL [(SA630)]	TC5565AFL@SOIC28
TC5565APL [(SA630)]	TC5565APL@SOIC28
TC5588	TC5588@SOIC28

[(SA630)]
TC55B88 TC55B88@SOIC28
[(SA630)]
TMM2018 TMM2018@PLCC32
[(SA015A1T)]
TMM2063 TMM2063@SOIC28
[(SA630)]

MICROCONTROLLER

TMP87P808LM@SOP28 (Toshiba) [(BM11116)]
TMP87P808LN@SDIP28 (Toshiba) [(BM11122)]
TMP87P808M@SOP28 (Toshiba) [(BM11116)]
TMP87P808N@SDIP28 (Toshiba) [(BM11122)]
TMP87P844N@SDIP42 (Toshiba) [(BM11108)]
TMP87P844NG@SDIP42 (Toshiba) [(BM11108)]
TMP87PH00DF@QFP64 (Toshiba) [(BM1173)]
TMP87PH00F@QFP64 (Toshiba) [(BM1137)]
TMP87PH00LF@QFP64 (Toshiba) [(BM1173)]
TMP87PH00N@SDIP64 (Toshiba) [(BM1136)]
TMP87PH20F@QFP80 (Toshiba) [(BM1138)]
TMP87PH40AF@PQFP64 (Toshiba) [(BM1137)]
TMP87PH40AN@SDIP64 (Toshiba) [(BM1136)]
TMP87PH46N@SDIP42 (Toshiba) [(BM1193)]
TMP87PH47LU@QFP44 (Toshiba) [(BM1194C)]
TMP87PH47U@QFP44 (Toshiba) [(BM1194C)]
TMP87PM14F@QFP64 (Toshiba) [(BM1199)]
TMP87PM14N@SDIP64 (Toshiba) [(BM1198)]
TMP87PM20F@QFP80 (Toshiba) [(BM1138)]
TMP87PM29U@LQFP64 (Toshiba) [(BM11117)]
TMP87PM34AN@SDIP42 (Toshiba) [(BM1183A)]
TMP87PM36N@SDIP42 (Toshiba) [(BM1183A)]
TMP87PM40AF@PQFP64 (Toshiba) [(BM1137)]
TMP87PM40AN@SDIP64 (Toshiba) [(BM1136)]
TMP87PM41F@QFP64 (Toshiba) [(BM1137)]
TMP87PM41N@SDIP64 (Toshiba) [(BM1136)]
TMP87PM41U@LQFP64 (Toshiba) [(BM1121)]
TMP87PM43N@SDIP42 (Toshiba) [(BM1163)]
TMP87PM70F@QFP80 (Toshiba) [(BM1150B)]
TMP87PM74F@QFP80 (Toshiba) [(BM11120)]
TMP87PM75F@QFP100 (Toshiba) [(BM11124)]
TMP87PM78F@QFP100 (Toshiba) [(BM1188)]

TMP87PP21DF@LQFP80(Toshiba) [(BM11105)]
TMP87PP21F@QFP80(Toshiba) [(BM11104)]
TMP87PP23F@QFP100(Toshiba) [(BM1185A)]
TMP87PP24F@LQFP100(Toshiba) [(BM11127)]
TMP87PP71F@QFP80(Toshiba) [(BM11107)]
TMP87PS38F@QFP44(Toshiba) [(BM11136)]
TMP87PS38N@SDIP42(Toshiba) [(BM11112)]
TMP87PS39F@QFP64(Toshiba) [(BM11138)]
TMP87PS39N@SDIP64(Toshiba) [(BM11118)]
TMP87PS64F@QFP100(Toshiba) [(BM1185A)]
TMP87PS71F@QFP80(Toshiba) [(BM11107)]

TOSHIBA-CUSTOMER

E (E) PROM / FRAM / NVRAM

TC58DAM72A1F@TSOP48 [(SA247-B005)]
TC58DVM72A1F@TSOP48 [(SA247-B005)]
TC58DVM82A1@FBGA63 [(SA642B-B026A-Y072F001)]
TC58DVM82A1@TSOP48 [(SA247-B005)]

TURBO IC

E (E) PROM / FRAM / NVRAM

TU24C01 [(SA602A)]	TU24C01@SOIC8
TU24C02 [(SA602A)]	TU24C02@SOIC8
TU24C04 [(SA602A)]	TU24C04@SOIC8
TU24C08 [(SA602A)]	TU24C08@SOIC8
TU24C128 [(SA602A)]	TU24C128@SOIC8
TU24C16 [(SA602A)]	TU24C16@SOIC8
TU24C16@TSSOP8 [(SA026)]	
TU24C256 TU24C256@SOIC8 [(SA602A)]	

TU24C32
TU24C32@SOIC8 [(SA602A)]
TU24C64
TU24C64@SOIC8 [(SA602A)]

UBICOM

MICROCONTROLLER

SX20AC/SS/G@SSOP20 [(SA626A)] [(SA626A)]	SX20AC/SS@SSOP20
SX28AC/DP G	SX28AC/DP/
SX28AC/SS/G@SSOP28 [(SA626A)] [(SA626A)]	SX28AC/SS@SSOP28
SX48BD/G@TQFP48 [(SA248)] [(SA248)]	SX48BD@TQFP48

UMC

E (E) PROM / FRAM / NVRAM

2732
2764

DRAM & SRAM

UM6116 [(SA015A1T)]	UM6116@PLCC32
UM6116A [(SA015A1T)]	UM6116A@PLCC32
UM61256 [(SA630)]	UM61256@SOIC28
UM61257	
UM61512	
UM61512@SOIC32 [(SA630)]	
UM6164	
UM6164@SOIC28 [(SA630)]	
UM6167	

UM621024	UM621024@SOIC32
[(SA630)]	
UM62256	UM62256@SOIC28
[(SA630)]	
UM62256A	UM62256A@SOIC28
[(SA630)]	
UM6264	UM6264@SOIC28
[(SA630)]	
UM6264A	UM6264A@SOIC28
[(SA630)]	

UTRON

E (E) PROM / FRAM / NVRAM

UT61256C	UT61256C@SOIC28
[(SA630)]	
UT61256C@TSOP28 [(SA430T)]	UT6164C@SOIC28
[(SA630)]	
UT6164C@TSOP28 [(SA430T)]	
UT61L256C	
UT61L256C@SOIC28 [(SA630)]	UT61L256C@TSOP28
[(SA430T)]	
UT62256C	UT62256C@SOIC28
[(SA630)]	
UT62256C@TSOP28 [(SA430T)]	
UT62256CE	
UT62256CE@SOIC28 [(SA630)]	UT62256CE@TSOP28
[(SA430T)]	
UT62257C	UT62257C@SOIC28
[(SA630)]	
UT62257C@TSOP28 [(SA430T)]	
UT6264C	
UT6264C@SOIC28 [(SA630)]	
UT62L256C	
UT62L256C@SOIC28 [(SA630)]	UT62L256C@TSOP28
[(SA430T)]	
UT62L64C	UT62L64C@SOIC28
[(SA630)]	
UT62W256C	UT62W256C@SOIC28
[(SA630)]	
UT62W256C@TSOP28 [(SA430T)]	

UT62W64C

UT62W64C@SOIC28 [(SA630)]

VANTIS

PLD

PALCE20RA10

[(SA008A)]

PALCE20RA10@SOIC24 [(SA404)]

PALCE20RA10H

PALCE20RA10H@PLCC28 [(SA008A)]

[(SA404)]

PALCE20RA10Q

[(SA008A)]

PALCE20RA10Q@SOIC24 [(SA404)]

PALCE20RA10@PLCC28

PALCE20RA10H@SOIC24

PALCE20RA10Q@PLCC28

VERSACHIPS

MICROCONTROLLER

V87C54

[(SA244)]

V87C54@TQFP44 [(SA245A)]

V87C58

V87C58@PLCC44 [(SA244)]

[(SA245A)]

V87C54@PLCC44

V87C58@TQFP44

VLSI

E (E) PROM / FRAM / NVRAM

VT27C128

VT27C256

VT27C512

VT27C64

VT28H64

VT28HC64

PLD

GAL16V8

WELTREND

MICROCONTROLLER

WT61P4K420@SDIP42 [(SA028)]	WT61P4K421@SDIP42
[(SA028)]	
WT61P4K422@SDIP42 [(SA028)]	WT61P4L440@PLCC44
[(SA244)]	
WT61P4N400	
WT61P4N401	
WT61P6K420@SDIP42 [(SA028)]	WT61P6L440@PLCC44
[(SA244)]	
WT61P6L441@PLCC44 [(SA244)]	WT62P1-K42@SDIP42
[(SA028)]	
WT62P1-N28(dip28)	WT62P1-N40
(dip40)	
WT62P1-N42(dip42)	WT62P1-S44@PSOP44
[(SA638)]	
WT62P2-K42@SDIP42 [(SA028)]	WT62P2-L44@PLCC44
[(SA244)]	
WT62P2-N40(dip40)	WT62P2-N42
(dip42)	
WT62P2-S44@PSOP44 [(SA638)]	WT65F1@SOIC28
[(SA404)]	
WT65F1@TQFP48 [(SA248)]	WT6702F@SOP16
[(SA602)]	
WT6702F@SOP20 [(SA404)]	WT6702F@SOP24
[(SA404)]	
WT6702F@SSOP20 [(SA674)]	

WHITE ELECTRONIC DESIGNS

E(E) PROM/FRAM/NVRAM

WE128K8

WE256K8	
WE512K8	
WF256K8	
WF256K8@CLCC32 [(SA015A1T)]	WF256K8@CSOJ32
[(SA661)]	
WF512K8	WF512K8@CLCC32
[(SA015A1T)]	
WF512K8@CSOJ32 [(SA661)]	
WME128K8	
WME128K8@CLCC32 [(SA015A1T)]	WME128K8@CSOJ32
[(SA661)]	
WMF128K8	WMF128K8@CLCC32
[(SA015A1T)]	
WMF128K8@CSOJ32 [(SA661)]	
WMF256K8	
WMF256K8@CLCC32 [(SA015A1T)]	WMF256K8@CSOJ32
[(SA661)]	
WMF512K8	WMF512K8@CLCC32
[(SA015A1T)]	
WMF512K8@CSOJ32 [(SA661)]	
WMS128K8	
WMS128K8@CLCC32 [(SA015A1T)]	WMS128K8@CSOJ32
[(SA661)]	
WMS256K8	WMS256K8@CLCC32
[(SA015A1T)]	
WMS256K8@CSOJ32 [(SA661)]	
WMS512K8	
WMS512K8@CLCC32 [(SA015A1T)]	WMS512K8@CSOJ32
[(SA661)]	

WINBOND

E (E) PROM / FRAM / NVRAM

W15B020L	W15B020L@SOIC8
[(SA602A)]	
W15B020M	W15B020M@SOIC8
[(SA602A)]	
W15B040L	W15B040L@SOIC8
[(SA602A)]	
W15B040M	W15B040M@SOIC8
[(SA602A)]	

W19B160BB@FBGA48 [(SA642G-B026A-T048F001Y)]
W19B160BB@TSOP48 [(SA247-B005)]
W19B160BT@FBGA48 [(SA642G-B026A-T048F001Y)]
W19B160BT@TSOP48 [(SA247-B005)]
W19B320AB@FBGA48 [(SA642A-B026A-Y096F001Y)]
W19B320AB@TSOP48 [(SA247-B005)]
W19B320AT@FBGA48 [(SA642A-B026A-Y096F001Y)]
W19B320AT@TSOP48 [(SA247-B005)]
W19B320BB@FBGA48 [(SA642G-B026A-T048F001Y)]
W19B320BB@TSOP48 [(SA247-B005)]
W19B320BT@FBGA48 [(SA642G-B026A-T048F001Y)]
W19B320BT@TSOP48 [(SA247-B005)]
W19B320SB@FBGA48 [(SA642F-B026A-T064F001)]
W19B320SB@TSOP48 [(SA247-B005)]
W19B320ST@FBGA48 [(SA642F-B026A-T064F001)]
W19B320ST@TSOP48 [(SA247-B005)]
W19B322MB@FBGA48 [(SA642F-B026A-T064F001)]
W19B322MB@TSOP48 [(SA247-B005)]
W19B322MT@FBGA48 [(SA642F-B026A-T064F001)]
W19B322MT@TSOP48 [(SA247-B005)]
W19B323MB@FBGA48 [(SA642F-B026A-T064F001)]
W19B323MB@TSOP48 [(SA247-B005)]
W19B323MT@FBGA48 [(SA642F-B026A-T064F001)]
W19B323MT@TSOP48 [(SA247-B005)]
W19B324MB@FBGA48 [(SA642F-B026A-T064F001)]
W19B324MB@TSOP48 [(SA247-B005)]
W19B324MT@FBGA48 [(SA642F-B026A-T064F001)]
W19B324MT@TSOP48 [(SA247-B005)]
W19L320SB@FBGA48 [(SA642F-B026A-T064F001)]
W19L320SB@TSOP48 [(SA247-B005)]
W19L320ST@FBGA48 [(SA642F-B026A-T064F001)]
W19L320ST@TSOP48 [(SA247-B005)]
W25B40(Bottom Boot)@SOIC8 [(SA602A)]
W25B40(Bottom Boot)@WSON8 [(SA683)]
W25B40(Top Boot)@SOIC8 [(SA602A)]
W25B40(Top Boot)@WSON8 [(SA683)]
W25B40A(Bottom Boot)@SOIC8 [(SA602A)]
W25B40A(Bottom Boot)@WSON8 [(SA683)]
W25B40A(Top Boot)@SOIC8 [(SA602A)]
W25B40A(Top Boot)@WSON8 [(SA683)]
W25D10 [(SA602A)] W25D10 (SN)@SOIC8
W25D10 (SS)@SOIC8 [(SA023A)] W25D10 (ZP)@WSON8

[(SA683)]	
W25D20	W25D20 (SN)@SOIC8
[(SA602A)]	
W25D20 (SS)@SOIC8 [(SA023A)]	W25D20 (ZP)@WSON8
[(SA683)]	
W25D40	W25D40 (SN)@SOIC8
[(SA602A)]	
W25D40 (SS)@SOIC8 [(SA023A)]	W25D40 (ZP)@WSON8
[(SA683)]	
W25D80	W25D80 (SN)@SOIC8
[(SA602A)]	
W25D80 (SS)@SOIC8 [(SA023A)]	W25D80 (ZP)@WSON8
[(SA683)]	
W25P10@SOIC8 [(SA602A)]	W25P10@WSON8
[(SA683)]	
W25P16@SOIC16 [(SA404)]	
W25P16@SOIC16 (ISP) [ISP-HEADER01]	
W25P16@SOIC8 [(SA023A)]	W25P16@SOIC8 (ISP) [ISP-
HEADER01]	
W25P16@WSON8 [(SA683)]	W25P16@WSON8 (ISP) [ISP-
HEADER01]	
W25P20@SOIC8 [(SA602A)]	W25P20@WSON8
[(SA683)]	
W25P32@SOIC16 [(SA404)]	
W25P32@SOIC16 (ISP) [ISP-HEADER01]	
W25P32@WSON8 [(SA683)]	W25P32@WSON8 (ISP) [ISP-
HEADER01]	
W25P40@SOIC8 [(SA602A)]	W25P40@WSON8
[(SA683)]	
W25P64@SOIC16 [(SA404)]	
W25P64@SOIC16 (ISP) [ISP-HEADER01]	
W25P64@WSON8 [(SA683)]	W25P64@WSON8 (ISP) [ISP-
HEADER01]	
W25P80@SOIC8 [(SA602A)]	W25P80@WSON8
[(SA683)]	
W25Q16@SOIC16 [(SA404)]	
W25Q16@SOIC16 (ISP) [ISP-HEADER01]	
W25Q16@SOIC8 [(SA023A)]	W25Q16@SOIC8 (ISP) [ISP-
HEADER01]	
W25Q16@WSON8 [(SA683)]	W25Q16@WSON8 (ISP) [ISP-
HEADER01]	
W25Q32@SOIC16 [(SA404)]	
W25Q32@SOIC16 (ISP) [ISP-HEADER01]	

W25Q32@WSON8 [(SA683)]	W25Q32@WSON8 (ISP) [ISP-
HEADER01]	
W25Q80@SOIC8 [(SA602A)]	W25Q80@WSON8
[(SA683)]	
W25X10	W25X10 (SN)@SOIC8
[(SA602A)]	
W25X10 (SS)@SOIC8 [(SA023A)]	W25X10 (ZP)@WSON8
[(SA683)]	
W25X10L	W25X10L (SN)@SOIC8
[(SA602A)]	
W25X10L (ZP)@WSON8 [(SA683)]	
W25X10V	W25X10V (SS)@SOIC8
W25X10V (SN)@SOIC8 [(SA602A)]	
[(SA023A)]	
W25X10V (ZP)@WSON8 [(SA683)]	W25X16@SOIC16
[(SA404)]	
W25X16@SOIC16 (ISP) [ISP-HEADER01]	
W25X16@SOIC8 [(SA023A)]	W25X16@SOIC8 (ISP) [ISP-
HEADER01]	
W25X20	W25X20 (SN)@SOIC8
[(SA602A)]	
W25X20 (SS)@SOIC8 [(SA023A)]	W25X20 (ZP)@WSON8
[(SA683)]	
W25X20L	W25X20L (SN)@SOIC8
[(SA602A)]	
W25X20L (ZP)@WSON8 [(SA683)]	
W25X20V	W25X20V (SS)@SOIC8
W25X20V (SN)@SOIC8 [(SA602A)]	
[(SA023A)]	
W25X20V (ZP)@WSON8 [(SA683)]	W25X32@SOIC16
[(SA404)]	
W25X32@SOIC16 (ISP) [ISP-HEADER01]	
W25X32@SOIC8 [(SA023A)]	W25X32@SOIC8 (ISP) [ISP-
HEADER01]	
W25X40	W25X40 (SN)@SOIC8
[(SA602A)]	
W25X40 (SS)@SOIC8 [(SA023A)]	W25X40 (ZP)@WSON8
[(SA683)]	
W25X40L	W25X40L (SN)@SOIC8
[(SA602A)]	
W25X40L (SS)@SOIC8 [(SA023A)]	W25X40L (ZP)@WSON8
[(SA683)]	
W25X40V	W25X40V (SN)@SOIC8

[(SA602A)]	
W25X40V(SS)@SOIC8 [(SA023A)]	W25X40V(ZP)@WSON8
[(SA683)]	
W25X64@SOIC16 [(SA404)]	
W25X64@SOIC16(ISP) [ISP-HEADER01]	
W25X64@SOIC8 [(SA023A)]	W25X64@SOIC8(ISP) [ISP-
HEADER01]	
W25X80	W25X80(SN)@SOIC8
[(SA602A)]	
W25X80(SS)@SOIC8 [(SA023A)]	W25X80(ZP)@WSON8
[(SA683)]	
W25X80L	W25X80L(SS)@SOIC8
[(SA023A)]	
W25X80L(ZP)@WSON8 [(SA683)]	
W25X80V	
W25X80V(SN)@SOIC8 [(SA602A)]	W25X80V(SS)@SOIC8
[(SA023A)]	
W25X80V(ZP)@WSON8 [(SA683)]	
W27C01	
W27C01@PLCC32 [(SA015A1T)]	W27C01@VSOP32
[(SA620)]	
W27C010	W27C010@PLCC32
[(SA015A1T)]	
W27C010@SOIC32 [(SA438T)]	
W27C02	
W27C02@PLCC32 [(SA015A1T)]	W27C02@VSOP32
[(SA620)]	
W27C020	W27C020@PLCC32
[(SA015A1T)]	
W27C020M	W27C020M@PLCC32
[(SA015A1T)]	
W27C257	W27C257@PLCC32
[(SA015A1T)]	
W27C4096	W27C4096@PLCC44
[(SA244)]	
W27C4096@TSOP40 [(SA409T)]	
W27C512	
W27C512@PLCC32 [(SA015A1T)]	W27C512@TSOP28
[(SA430T)]	
W27C520@SOIC20 [(SA404)]	W27C520@TSSOP20
[(SA026)]	
W27E01	W27E01@PLCC32
[(SA015A1T)]	

W27E01@VSOP32 [(SA620)]
W27E010
W27E010@PLCC32 [(SA015A1T)] W27E010@SOIC32
[(SA438T)]
W27E02 W27E02@PLCC32
[(SA015A1T)]
W27E02@VSOP32 [(SA620)]
W27E020
W27E020@PLCC32 [(SA015A1T)]
W27E040
W27E040@PLCC32 [(SA015A1T)] W27E040@SOIC32
[(SA438T)]
W27E257 W27E257@PLCC32
[(SA015A1T)]
W27E4096 W27E4096@PLCC44
[(SA244)]
W27E4096@TSOP40 [(SA409T)]
W27E512
W27E512@PLCC32 [(SA015A1T)] W27E512@TSOP28
[(SA430T)]
W27E520@SOIC20 [(SA404)] W27E520@TSSOP20
[(SA026)]
W27L01 W27L01@PLCC32
[(SA015A1T)]
W27L01@VSOP32 [(SA620)]
W27L010
W27L010@PLCC32 [(SA015A1T)]
W27L02
W27L02@PLCC32 [(SA015A1T)] W27L02@VSOP32
[(SA620)]
W27L520@SOIC20 [(SA404)] W27L520@TSSOP20
[(SA026)]
W28F321BB@FBGA48 [(SA634A-B005A-Y048F001)]
W28F321BT@TSOP48 [(SA247-B005)]
W28F321TB@FBGA48 [(SA634A-B005A-Y048F001)]
W28F321TT@TSOP48 [(SA247-B005)]
W28F641BB@FBGA48 [(SA634A-B005A-Y048F001)]
W28F641BT@TSOP48 [(SA247-B005)]
W28F641TB@FBGA48 [(SA634A-B005A-Y048F001)]
W28F641TT@TSOP48 [(SA247-B005)] W28J160BT@TSOP48 [(SA247-
B005)]
W28J160TT@TSOP48 [(SA247-B005)]
W28J161BB@TFBGA48 [(SA634A-B005A-Y048F001)]

W28J161TB@TFBGA48 [(SA634A-B005A-Y048F001)]
W28J320BT@TSOP48 [(SA247-B005)] W28J320TT@TSOP48 [(SA247-B005)]
W28J321BB@TFBGA48 [(SA634A-B005A-Y048F001)]
W28J321TB@TFBGA48 [(SA634A-B005A-Y048F001)]
W28J800BT@TSOP48 [(SA247-B005)] W28J800TT@TSOP48 [(SA247-B005)]
W28V400BT@TSOP48 [(SA247-B005)] W28V400TT@TSOP48 [(SA247-B005)]
W29C010 W29C010@PLCC32
[(SA015A1T)]
W29C011A W29C011A@PLCC32
[(SA015A1T)]
W29C020 W29C020@PLCC32
[(SA015A1T)]
W29C020@SOIC32 [(SA438T)] W29C020@TSOP32
[(SA410T)]
W29C020C W29C020C@VSOP32 [(SA620-B005)]
W29C020C@PLCC32 [(SA015A1T-B001)]
W29C020C@TSOP32 [(SA410T-B003)]
W29C040 W29C040@PLCC32 [(SA015A1T-B001)]
B001)]
W29C040@TSOP32 [(SA410T-B003)] W29C040@VSOP32 [(SA620-B005)]
B005)]
W29C101 W29C101@PLCC44
[(SA244)]
W29C101@TSOP40 [(SA409T)]
W29C102 W29C102@TSOP40
W29C102@PLCC44 [(SA244)]
[(SA409T)]
W29EE010 W29EE010@PLCC32
[(SA015A1T)]
W29EE010@SOIC32 [(SA438T)] W29EE010@TSOP32
[(SA410T)]
W29EE011 W29EE011@PLCC32
[(SA015A1T)]
W29EE011@SOIC32 [(SA438T)]
W29EE012 W29EE012@SOIC32
W29EE012@PLCC32 [(SA015A1T)]
[(SA438T)]
W29EE512 W29EE512@PLCC32
[(SA015A1T)]

W29EE512@SOIC32 [(SA438T)]	W29EE512@TSOP32
[(SA410T)]	
W29F040	W29F040@PLCC32
[(SA015A1T)]	
W29F040@TSOP32 [(SA410T)]	W29F102@PLCC44
[(SA244)]	
W29F102@TSOP40 [(SA623)]	W29L102@PLCC44
[(SA244)]	
W29L102@TSOP40 [(SA623)]	
W39F010	
W39F010@PLCC32 [(SA015A1T-B001)]	
W39F010@TSOP32[12.4mm] [(SA620-B005)]	
W39F010@TSOP32[18.4mm] [(SA410T-B003)]	
W39L010@PLCC32 [(SA015A1T-B001)]	W39L010@TSOP32 [(SA620-
B005)]	
W39L020@PLCC32 [(SA015A1T-B001)]	
W39L020@TSOP32[12.4mm] [(SA620-B005)]	
W39L020@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040@PLCC32 [(SA015A1T-B001)]	
W39L040@TSOP32[12.4mm] [(SA620-B005)]	
W39L040@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040A	W39L040A@PLCC32
[(SA015A1T)]	
W39L040A@TSOP32 [(SA410T)]	W39L040A@VSOP32
[(SA620)]	
W39L512@PLCC32 [(SA015A1T-B001)]	W39L512@TSOP32 [(SA620-
B005)]	
W39V040AP@PLCC32 [(SA015A1T)]	W39V040AQ@VSOP32
[(SA620)]	
W39V040B(P)@PLCC32 [(SA015A1T)]	W39V040B(Q)@VSOP32
[(SA620)]	
W39V040CP@PLCC32 [(SA015A1T)]	W39V040CPZ@PLCC32
[(SA015A1T)]	
W39V040CQ@VSOP32 [(SA620)]	W39V040CQZ@VSOP32
[(SA620)]	
W39V040FAP@PLCC32 [(SA015A1T)]	W39V040FAQ@VSOP32
[(SA620)]	
W39V040FAT@TSOP40 [(SA409T)]	W39V040FB(P)@PLCC32
[(SA015A1T)]	
W39V040FB(Q)@VSOP32 [(SA620)]	W39V040FCP@PLCC32
[(SA015A1T)]	
W39V040FCPZ@PLCC32 [(SA015A1T)]	W39V040FCQ@VSOP32
[(SA620)]	

W39V040FCQZ@VSOP32 [(SA620)]	W39V080A(P)@PLCC32
[(SA015A1T)]	
W39V080A(Q)@VSOP32 [(SA620)]	W39V080A(T)@TSOP40
[(SA409T)]	
W39V080FA(P)@PLCC32 [(SA015A1T)]	W39V080FA(Q)@VSOP32
[(SA620)]	
W39V080FA(T)@TSOP40 [(SA409T)]	W45B012@PLCC32
[(SA015A1T)]	
W45B012@SON8 [(SA683)]	W45B512@PLCC32
[(SA015A1T)]	
W45B512@SON8 [(SA683)]	
W49F002	
W49F002@PLCC32 [(SA015A1T-B001)]	W49F002@TSOP32 [(SA410T-
B003)]	
W49F002B	
W49F002B@PLCC32 [(SA015A1T-B001)]	
W49F002B@TSOP32 [(SA410T-B003)]	
W49F002N	
W49F002N@PLCC32 [(SA015A1T-B001)]	
W49F002N@TSOP32 [(SA410T-B003)]	
W49F002U	
W49F002U@PLCC32 [(SA015A1T-B001)]	
W49F002U@TSOP32 [(SA410T-B003)]	
W49F020	
W49F020@PLCC32 [(SA015A1T)]	W49F020@TSOP32
[(SA410T)]	
W49F102@PLCC44 [(SA244)]	W49F102@TSOP40
[(SA623)]	
W49F201@PSOP44 [(SA638)]	W49F201@TSOP48 [(SA247-
B005)]	
W49L102@PLCC44 [(SA244)]	W49L102@TSOP40
[(SA623)]	
W49L201@PSOP44 [(SA638)]	W49L201@TSOP48 [(SA247-
B005)]	
W49L401@PSOP44 [(SA638)]	W49L401@TSOP48 [(SA247-
B005)]	
W49L401T@PSOP44 [(SA638)]	W49L401T@TSOP48 [(SA247-
B005)]	
W49V002A@PLCC32 [(SA015A1T)]	W49V002A@VSOP32
[(SA620)]	
W49V002FA@PLCC32 [(SA015A1T)]	W49V002FA@VSOP32
[(SA620)]	
W49V002FP@PLCC32 [(SA015A1T)]	W49V002FP@VSOP32

[(SA620)]
W49V002P@PLCC32 [(SA015A1T)] W49V002P@VSOP32
[(SA620)]
W55F05
W55F10A
W55F20

MICROCONTROLLER

W77E058 W77E058@PLCC44
[(SA244)]
W77E058@TQFP44 [(SA245A)]
W77E516
W77E516@PLCC44 [(SA244)] W77E516@TQFP44
[(SA245A)]
W77E532 W77E532@PLCC44
[(SA244)]
W77E532@TQFP44 [(SA245A)]
W77E532A
W77E532A@PLCC44 [(SA244)] W77E532A@TQFP44
[(SA245A)]
W77E58 W77E58@PLCC44
[(SA244)]
W77E58@TQFP44 [(SA245A)]
W77E58A
W77E58A@PLCC44 [(SA244)] W77E58A@TQFP44
[(SA245A)]
W77IE58 W77IE58@PLCC44
[(SA244)]
W77IE58@TQFP44 [(SA245A)]
W77L058
W77L058@PLCC44 [(SA244)] W77L058@TQFP44
[(SA245A)]
W77L516A W77L516A@PLCC44
[(SA244)]
W77L516A@TQFP44 [(SA245A)]
W77L532A
W77L532A@PLCC44 [(SA244)] W77L532A@TQFP44
[(SA245A)]
W77LE516 W77LE516@PLCC44
[(SA244)]
W77LE516@TQFP44 [(SA245A)]

W77LE532
W77LE532@PLCC44 [(SA244)] W77LE532@TQFP44
[(SA245A)]
W77LE58 W77LE58@PLCC44
[(SA244)]
W77LE58@TQFP44 [(SA245A)]
W78E051B
W78E051B@PLCC44 [(SA244)] W78E051B@TQFP44
[(SA245A)]
W78E051C W78E051C@PLCC44
[(SA244)]
W78E051C@TQFP44 [(SA245A)]
W78E052B
W78E052B@PLCC44 [(SA244)] W78E052B@TQFP44
[(SA245A)]
W78E052C W78E052C@PLCC44
[(SA244)]
W78E052C@TQFP44 [(SA245A)]
W78E054B
W78E054B@PLCC44 [(SA244)] W78E054B@TQFP44
[(SA245A)]
W78E054C W78E054C@PLCC44
[(SA244)]
W78E054C@TQFP44 [(SA245A)]
W78E058B
W78E058B@PLCC44 [(SA244)] W78E058B@TQFP44
[(SA245A)]
W78E065 W78E065@PLCC44
[(SA244)]
W78E065@TQFP44 [(SA245A)]
(dip40)
W78E354(dip48)
W78E365 W78E365@PLCC44 [(SA244)] W78E365@TQFP44
[(SA245A)]
W78E374B
W78E378 W78E378P@PLCC44
W78E378E
[(SA244)]
W78E51 W78E51@PLCC44
[(SA244)]
W78E51@TQFP44 [(SA245A)]
W78E516

W78E516@PLCC44 [(SA244)]	W78E516@TQFP44
[(SA245A)]	
W78E516B	W78E516B@PLCC44
[(SA244)]	
W78E516B@TQFP44 [(SA245A)]	
W78E51B	
W78E51B@PLCC44 [(SA244)]	W78E51B@TQFP44
[(SA245A)]	
W78E51C	W78E51C@PLCC44
[(SA244)]	
W78E51C@TQFP44 [(SA245A)]	
W78E52	
W78E52@PLCC44 [(SA244)]	W78E52@TQFP44
[(SA245A)]	
W78E52B	W78E52B@PLCC44
[(SA244)]	
W78E52B@TQFP44 [(SA245A)]	
W78E52C	
W78E52C@PLCC44 [(SA244)]	W78E52C@TQFP44
[(SA245A)]	
W78E54	W78E54@PLCC44
[(SA244)]	
W78E54@TQFP44 [(SA245A)]	
W78E54B	
W78E54B@PLCC44 [(SA244)]	W78E54B@TQFP44
[(SA245A)]	
W78E54C	W78E54C@PLCC44
[(SA244)]	
W78E54C@TQFP44 [(SA245A)]	
W78E58	
W78E58@PLCC44 [(SA244)]	W78E58@TQFP44
[(SA245A)]	
W78E58B	W78E58B@PLCC44
[(SA244)]	
W78E58B@TQFP44 [(SA245A)]	
W78E62B	
W78E62B@PLCC44 [(SA244)]	W78E62B@TQFP44
[(SA245A)]	
W78E65	W78E65@PLCC44
[(SA244)]	
W78E65@TQFP44 [(SA245A)]	
W78E858	
W78E858@PLCC44 [(SA244)]	W78E858@TQFP44

[(SA245A)]
W78ERD2 W78ERD2@PLCC44
[(SA244)]
W78ERD2@TQFP44 [(SA245A)]
W78I052
W78I052@PLCC44 [(SA244)]
W78I054
W78I054@PLCC44 [(SA244)]
W78IE52
W78IE52@PLCC44 [(SA244)]
W78IE54
W78IE54@PLCC44 [(SA244)]
W78IRD2
W78IRD2@PLCC44 [(SA244)] W78IRD2@TQFP44
[(SA245A)]
W78L051 W78L051@PLCC44
[(SA244)]
W78L051@TQFP44 [(SA245A)]
W78L051C
W78L051C@PLCC44 [(SA244)] W78L051C@TQFP44
[(SA245A)]
W78L052 W78L052@PLCC44
[(SA244)]
W78L052@TQFP44 [(SA245A)]
W78L052C
W78L052C@PLCC44 [(SA244)] W78L052C@TQFP44
[(SA245A)]
W78L054 W78L054@PLCC44
[(SA244)]
W78L054@TQFP44 [(SA245A)]
W78L054C
W78L054C@PLCC44 [(SA244)] W78L054C@TQFP44
[(SA245A)]
W78L058 W78L058@PLCC44
[(SA244)]
W78L058@TQFP44 [(SA245A)]
W78L365
W78L365@PLCC44 [(SA244)] W78L365@TQFP44
[(SA245A)]
W78L365@TQFP48 [(SA248A-B005)]
W78L516
W78L516@PLCC44 [(SA244)] W78L516@TQFP44
[(SA245A)]

W78L812 [(SA244)]	W78L812@PLCC44
W78L812@TQFP44 [(SA245A)]	
W78LE365	
W78LE365@PLCC44 [(SA244)] [(SA245A)]	W78LE365@TQFP44
W78LE365@TQFP48 [(SA248A-B005)]	
W78LE51	
W78LE51@PLCC44 [(SA244)] [(SA245A)]	W78LE51@TQFP44
W78LE516	W78LE516@PLCC44
[(SA244)]	
W78LE516@TQFP44 [(SA675)]	
W78LE51C	
W78LE51C@PLCC44 [(SA244)] [(SA245A)]	W78LE51C@TQFP44
W78LE52	W78LE52@PLCC44
[(SA244)]	
W78LE52@TQFP44 [(SA245A)]	
W78LE52C	
W78LE52C@PLCC44 [(SA244)] [(SA245A)]	W78LE52C@TQFP44
W78LE54	W78LE54@PLCC44
[(SA244)]	
W78LE54@TQFP44 [(SA245A)]	
W78LE54C	
W78LE54C@PLCC44 [(SA244)] [(SA245A)]	W78LE54C@TQFP44
W78LE58	W78LE58@PLCC44
[(SA244)]	
W78LE58@TQFP44 [(SA245A)]	
W78LE812	
W78LE812@PLCC44 [(SA244)] [(SA245A)]	W78LE812@TQFP44
W79E201	W79E201@PLCC44
[(SA244)]	
W79E201@TQFP44 [(SA245A)] (dip14)	W79E2051
W79E2051(dip16) (dip20)	W79E2051
W79E2051@SOP20 [(SA404A)] [(SA626A)]	W79E2051@SSOP14
W79E2051@SSOP16 [(SA626A)]	W79E2051@SSOP20

[(SA626A)]
W79E216AFG@PQFP100(*) [(SA741-B226)]
W79E217AFG@PQFP100(*) [(SA741-B226)]
W79E227A@LQFP48 [(SA248)] W79E227A@PLCC44
[(SA244)]
W79E4051(dip14) W79E4051
(dip16)
W79E4051(dip20) W79E4051@SOP20
[(SA404A)]
W79E4051@SSOP14 [(SA626A)] W79E4051@SSOP16
[(SA626A)]
W79E4051@SSOP20 [(SA626A)]
W79E532
W79E532@PLCC44 [(SA244)] W79E532@TQFP44
[(SA245A)]
W79E532A W79E532A@PLCC44
[(SA244)]
W79E532A@TQFP44 [(SA245A)]
W79E632
W79E632@PLCC44 [(SA244)] W79E632@TQFP44
[(SA245A)]
W79E633@PLCC44 [(SA244)]
W79E648A@PLCC68(*) [(SA648-B6809)]
W79E649A@PLCC68(*) [(SA648-B6809)]
W79E659A@PQFP100(*) [(SA741-B233)]
W79E801A W79E801A@SOIC20
[(SA404)]
W79E802A W79E802A@SOIC20
[(SA404)]
W79E803A W79E803A@SOIC20
[(SA404)]
W79E804A W79E804A@SOIC20
[(SA404)]
W79E821A W79E821A@SOIC20
[(SA404)]
W79E822A W79E822A@SOIC20
[(SA404)]
W79E822B W79E822B@SOIC20
[(SA404)]
W79E823A W79E823A@SOIC20
[(SA404)]
W79E823B W79E823B@SOIC20
[(SA404)]

W79E824A [(SA404)]	W79E824A@SOIC20
W79E825A [(SA404)]	W79E825A@SOIC20
W79E831A [(SA404)]	W79E831A@SOIC28
W79E832A [(SA404)]	W79E832A@SOIC28
W79E833A [(SA404)]	W79E833A@SOIC28
W79E834A [(SA404)]	W79E834A@SOIC28
W79L532 [(SA244)]	W79L532@PLCC44
W79L532@TQFP44 [(SA245A)]	
W79L632 W79L632@PLCC44 [(SA244)] [(SA245A)]	W79L632@TQFP44
W79L633@PLCC44 [(SA244)]	
W79L648A@PLCC68(*) [(SA648-B6809)]	
W79L649A@PLCC68(*) [(SA648-B6809)]	
W79L659A@PQFP100(*) [(SA741-B233)]	
W925EP01@PQFP100(*) [(TA041-B006)]	
W99100DG@TQFP48 [(SA248A-B005)]	

WSI

E (E) PROM / FRAM / NVRAM

WS27C010L [(SA015A1T)]	WS27C010L@PLCC32
WS27C010L@TSOP32 [(SA410T)]	
WS27C010R WS27C010R@PLCC32 [(SA015A1T)] [(SA410T)]	WS27C010R@TSOP32
WS27C040L [(SA015A1T)]	WS27C040L@PLCC32
WS27C040L@TSOP32 [(SA410T)]	
WS27C128F WS27C128F@PLCC32 [(SA015A1T)]	
WS27C128L WS27C128L@PLCC32 [(SA015A1T)]	

WS27C210L
WS27C210L@PLCC44 [(SA244)]
WS27C256F
WS27C256F@PLCC32 [(SA015A1T)]
WS27C256L
WS27C256L@PLCC32 [(SA015A1T)]
WS27C512F
WS27C512F@PLCC32 [(SA015A1T)]
WS27C512L
WS27C512L@PLCC32 [(SA015A1T)]
WS27C64
WS27C64@PLCC32 [(SA015A1T)]
WS27C64F
WS27C64F@PLCC32 [(SA015A1T)]
WS27C64L
WS27C64L@PLCC32 [(SA015A1T)]
WS57C128
WS57C128@PLCC32 [(SA015A1T)]
WS57C128F
WS57C128F@PLCC32 [(SA015A1T)]
WS57C128FB
WS57C128FB@PLCC32 [(SA015A1T)]
WS57C191
WS57C191@PLCC28 [(SA008A)]
WS57C191B
WS57C191B@PLCC28 [(SA008A)]
WS57C191C
WS57C191C@PLCC28 [(SA008A)]
WS57C256F
WS57C256F@PLCC32 [(SA015A1T)]
WS57C256FB
WS57C256FB@PLCC32 [(SA015A1T)]
WS57C257
WS57C257@PLCC44 [(SA244)]
WS57C291
WS57C291@PLCC28 [(SA008A)]
WS57C291B
WS57C291B@PLCC28 [(SA008A)]
WS57C291C
WS57C291C@PLCC28 [(SA008A)]
WS57C43
WS57C43@PLCC28 [(SA008A)]
WS57C43B

WS57C43B@PLCC28 [(SA008A)]
WS57C43C
WS57C43C@PLCC28 [(SA008A)]
WS57C45
WS57C45@PLCC28 [(SA008A)]
WS57C49
WS57C49@PLCC28 [(SA008A)]
WS57C49B
WS57C49B@PLCC28 [(SA008A)]
WS57C49C
WS57C49C@PLCC28 [(SA008A)]
WS57C51
WS57C51@PLCC32 [(SA015A1T)]
WS57C51B
WS57C51B@PLCC32 [(SA015A1T)]
WS57C51C
WS57C51C@PLCC32 [(SA015A1T)]
WS57C64F
WS57C64F@PLCC32 [(SA015A1T)]
WS57C71C
WS57C71C@PLCC32 [(SA015A1T)]
WS57LV191C
WS57LV191C@PLCC28 [(SA008A)]
WS57LV291C
WS57LV291C@PLCC28 [(SA008A)]

XELTEK

E (E) PROM / FRAM / NVRAM

S29GL128N10TAI01@TSOP56 [(SA628-B334)]
S29GL128N10TAI02@TSOP56 [(SA628-B334)]
S29GL128N10TFI01@TSOP56 [(SA628-B334)]
S29GL128N10TFI02@TSOP56 [(SA628-B334)]
S29GL128N11TAI01@TSOP56 [(SA628-B334)]
S29GL128N11TAI02@TSOP56 [(SA628-B334)]
S29GL128N11TAIV1@TSOP56 [(SA628-B334)]
S29GL128N11TAIV2@TSOP56 [(SA628-B334)]
S29GL128N11TFI01@TSOP56 [(SA628-B334)]
S29GL128N11TFI02@TSOP56 [(SA628-B334)]
S29GL128N11TFIV1@TSOP56 [(SA628-B334)]
S29GL128N11TFIV2@TSOP56 [(SA628-B334)]

S29GL128N90TAIR1@TSOP56 [(SA628-B334)]
S29GL128N90TAIR2@TSOP56 [(SA628-B334)]
S29GL128N90TFIR1@TSOP56 [(SA628-B334)]
S29GL128N90TFIR2@TSOP56 [(SA628-B334)]

MICROCONTROLLER

#####1111111111111111
#####2222222222222222
#####3333333333333333
#####4444444444444444
#####9999999999999999 ATMEGA168@TQFP32
[(SA636)]
ATMEGA48@TQFP32 [(SA636)] ATMEGA88@TQFP32
[(SA636)]
ATMEGA8L(fast)@TQFP32 [(SA636)] ATMEGA8L@TQFP32
[(SA636)]
MK68F15P MK68F15S@SOP18
[(SA023A)]
MK68F15X@SSOP20 [(SA674)]
MK68F30K
MK68F30S@SOP28 [(SA404)] MK68F30X@SSOP28
[(SA626A)]

XICOR

E (E) PROM / FRAM / NVRAM

X2004 X2004@PLCC32
[(SA015A1T)]
X2004D X2004D@PLCC32
[(SA015A1T)]
X2004I X2004I@PLCC32
[(SA015A1T)]
X2210 X2210@SOIC16
[(SA404)]
X2210A X2210A@SOIC16
[(SA404)]
X2210I X2210I@SOIC16
[(SA404)]
X2212 X2212@SOIC20

[(SA404)]	
X2212A	X2212A@SOIC20
[(SA404)]	
X2212I	X2212I@SOIC20
[(SA404)]	
X22C10	X22C10@SOIC16
[(SA404)]	
X22C10I	X22C10I@SOIC16
[(SA404)]	
X22C12	X22C12@SOIC20
[(SA404)]	
X22C12I	X22C12I@SOIC20
[(SA404)]	
X24012	X24012@SOIC8
[(SA602A)]	
X24022	X24022@SOIC8
[(SA602A)]	
X24026	X24026@SOIC8
[(SA602A)]	
X24042	X24042@SOIC8
[(SA602A)]	
X24164	X24164@SOIC8
[(SA602A)]	
X24165	X24165@SOIC8
[(SA602A)]	
X24325	X24325@SOIC8
[(SA602A)]	
X24645	X24645@SOIC8
[(SA602A)]	
X24C01	X24C01@MSOP8
[(SA666)]	
X24C01@SOIC8 [(SA602A)]	
X24C01A	
X24C01A@SOIC8 [(SA602A)]	
X24C01I	
X24C01I@SOIC8 [(SA602A)]	
X24C02	
X24C02@SOIC8 [(SA602A)]	
X24C02I	
X24C02I@SOIC8 [(SA602A)]	
X24C04	
X24C04@SOIC14 [(SA602)]	X24C04@SOIC8
[(SA602A)]	

X24C04I [(SA602)]	X24C04I@SOIC14
X24C04I@SOIC8 [(SA602A)]	
X24C08 X24C08@SOIC14 [(SA602)] [(SA602A)]	X24C08@SOIC8
X24C08I [(SA602)]	X24C08I@SOIC14
X24C08I@SOIC8 [(SA602A)]	
X24C16 X24C16@SOIC14 [(SA602)] [(SA602A)]	X24C16@SOIC8
X24C16I [(SA602)]	X24C16I@SOIC14
X24C16I@SOIC8 [(SA602A)]	
X24C44 X24C44@SOIC8 [(SA602A)]	
X24C44I X24C44I@SOIC8 [(SA602A)]	
X24C45 X24C45@SOIC8 [(SA602A)]	
X24C45I X24C45I@SOIC8 [(SA602A)]	X24F008
(3V)	
X24F008(3V)@SOIC8 [(SA602A)] [(SA602)]	X24F008(3V)@TSSOP14
X24F008(5V) [(SA602A)]	X24F008(5V)@SOIC8
X24F008(5V)@TSSOP14 [(SA602)] (3V)	X24F016
X24F016(3V)@SOIC8 [(SA602A)] [(SA602)]	X24F016(3V)@TSSOP14
X24F016(5V) [(SA602A)]	X24F016(5V)@SOIC8
X24F016(5V)@TSSOP14 [(SA602)] (3V)	X24F032
X24F032(3V)@SOIC8 [(SA602A)] [(SA602)]	X24F032(3V)@TSSOP14
X24F032(5V) [(SA602A)]	X24F032(5V)@SOIC8
X24F032(5V)@TSSOP14 [(SA602)] (3V)	X24F064
X24F064(3V)@SOIC8 [(SA602A)]	X24F064(3V)@TSSOP20

[(SA404)]	
X24F064 (5V)	X24F064 (5V)@SOIC8
[(SA602A)]	
X24F064 (5V)@TSSOP20 [(SA404)]	
X25020	
X25020@SOIC8 [(SA602A)]	
X25021	
X25021@SOIC8 [(SA602A)]	
X25040	
X25040@SOIC8 [(SA602A)]	
X25041	
X25041@SOIC8 [(SA602A)]	
X25043	
X25043@MSOP8 [(SA666)]	X25043@SOIC8
[(SA602A)]	
X25043@TSSOP14 [(SA026)]	
X25045	
X25045@MSOP8 [(SA666)]	X25045@SOIC8
[(SA602A)]	
X25045@TSSOP14 [(SA026)]	X25057@MSOP8
[(SA666)]	
X25057@TSSOP8 [(SA026)]	
X25080	
X25080@SOIC8 [(SA602A)]	X25080@TSSOP14
[(SA026)]	
X25097@MSOP8 [(SA666)]	X25097@SOIC8
[(SA602A)]	
X25097@TSSOP8 [(SA026)]	
X25128	
X25128@SOIC16 [(SA602)]	
X25138	
X25138@SOIC14 [(SA602)]	X25138@SOIC16
[(SA602)]	
X25138@SOIC8 [(SA602A)]	X25138@TSSOP8
[(SA026)]	
X25160	X25160@SOIC8
[(SA602A)]	
X25160@TSSOP14 [(SA026)]	
X25163	
X25163@SOIC8 [(SA602A)]	X25163@TSSOP14
[(SA026)]	
X25164	X25164@SOIC8
[(SA602A)]	

X25164@TSSOP14 [(SA026)]	
X25165	
X25165@SOIC8 [(SA602A)]	X25165@TSSOP14
[(SA026)]	
X25166	
[(SA602A)]	X25166@SOIC8
X25166@TSSOP14 [(SA026)]	
X25168	
X25168@SOIC8 [(SA602A)]	X25168@TSSOP14
[(SA026)]	
X25169	
[(SA602A)]	X25169@SOIC8
X25169@TSSOP14 [(SA026)]	
X25256	
X25256@SOIC8 [(SA602A)]	X25256@TSSOP20
[(SA026)]	
X25320	
[(SA602A)]	X25320@SOIC8
X25323@SOIC8 [(SA602A)]	X25323@TSSOP14
[(SA026)]	
X25324@SOIC8 [(SA602A)]	X25324@TSSOP14
[(SA026)]	
X25325@SOIC8 [(SA602A)]	X25325@TSSOP14
[(SA026)]	
X25326@SOIC8 [(SA602A)]	X25328@SOIC8
[(SA602A)]	
X25328@TSSOP14 [(SA026)]	X25329@SOIC8
[(SA602A)]	
X25329@TSSOP14 [(SA026)]	X25330@SOIC8
[(SA602A)]	
X25330@TSSOP14 [(SA026)]	
X25401	
X25401@SOIC8 [(SA602A)]	
X25640	
X25640@SOIC14 [(SA602)]	
X25642	
X25642@SOIC14 [(SA602)]	X25642@SOIC8
[(SA602A)]	
X25642@TSSOP20 [(SA026)]	X25643@SOIC14
[(SA602)]	
X25644@SOIC14 [(SA602)]	
X25645	
X25645@SOIC14 [(SA602)]	X25645@SOIC8

[(SA602A)]	
X25645@TSSOP20 [(SA026)]	X25648@SOIC14
[(SA602)]	
X25649@SOIC14 [(SA602)]	
X25650	
X25650@SOIC14 [(SA602)]	X25650@SOIC8
[(SA602A)]	
X25650@TSSOP20 [(SA026)]	
X25C02	
X25C02@SOIC8 [(SA602A)]	X25C02@TSSOP8
[(SA026)]	
X25F008 (3V)	X25F008 (3V)@SOIC8
[(SA602A)]	
X25F008 (3V)@TSSOP14 [(SA602)]	X25F008 (3V)@TSSOP20
[(SA404)]	
X25F008 (5V)	X25F008 (5V)@SOIC8
[(SA602A)]	
X25F008 (5V)@TSSOP14 [(SA602)]	X25F008 (5V)@TSSOP20
[(SA404)]	
X25F016 (3V)	X25F016 (3V)@SOIC8
[(SA602A)]	
X25F016 (3V)@TSSOP14 [(SA602)]	X25F016 (3V)@TSSOP20
[(SA404)]	
X25F016 (5V)	X25F016 (5V)@SOIC8
[(SA602A)]	
X25F016 (5V)@TSSOP14 [(SA602)]	X25F016 (5V)@TSSOP20
[(SA404)]	
X25F032 (3V)	X25F032 (3V)@SOIC8
[(SA602A)]	
X25F032 (3V)@TSSOP14 [(SA602)]	X25F032 (3V)@TSSOP20
[(SA404)]	
X25F032 (5V)	X25F032 (5V)@SOIC8
[(SA602A)]	
X25F032 (5V)@TSSOP14 [(SA602)]	X25F032 (5V)@TSSOP20
[(SA404)]	
X25F047 (3V)	X25F047 (3V)@MSOP8
[(SA666)]	
X25F047 (3V)@SOIC8 [(SA602A)]	X25F047 (3V)@TSSOP8
[(SA026)]	
X25F047 (5V)	X25F047 (5V)@MSOP8
[(SA666)]	
X25F047 (5V)@SOIC8 [(SA602A)]	X25F047 (5V)@TSSOP8
[(SA026)]	

X25F064(3V) [(SA602A)]	X25F064(3V)@SOIC8
X25F064(3V)@TSSOP14 [(SA602)] [(SA404)]	X25F064(3V)@TSSOP20
X25F064(5V) [(SA602A)]	X25F064(5V)@SOIC8
X25F064(5V)@TSSOP14 [(SA602)] [(SA404)]	X25F064(5V)@TSSOP20
X25F087(3V) [(SA666)]	X25F087(3V)@MSOP8
X25F087(3V)@SOIC8 [(SA602A)] [(SA026)]	X25F087(3V)@TSSOP8
X25F087(5V) [(SA666)]	X25F087(5V)@MSOP8
X25F087(5V)@SOIC8 [(SA602A)] [(SA026)]	X25F087(5V)@TSSOP8
X25F128(3V) [(SA602)]	X25F128(3V)@SOIC16
X25F128(5V) [(SA602)]	X25F128(5V)@SOIC16
X28010 [(SA015A1T)]	X28010@PLCC32
X28010@TSOP32 [(SA410T)]	
X2804A X2804A(I) (MB)	X2804A
X2816A [(SA015A1T)]	X2816A@PLCC32
X2816B [(SA015A1T)]	X2816B@PLCC32
X2816BI [(SA015A1T)]	X2816BI@PLCC32
X2816BMB X2816C X2816C@PLCC32 [(SA015A1T)]	
X28256 X28256@PLCC32 [(SA015A1T)]	
X28256I X28256I@PLCC32 [(SA015A1T)]	
X2864A X2864A(I) [(SA015A1T)]	X2864A(I)@PLCC32
X2864A(M)	X2864A(M)@PLCC32

[(SA015A1T)]	
X2864A(MB)	X2864A(MB)@PLCC32
[(SA015A1T)]	
X2864A(T)	X2864A(T)@PLCC32
[(SA015A1T)]	
X2864A@PLCC32 [(SA015A1T)]	
X2864B	
X2864B(I)	X2864B(I)@PLCC32
[(SA015A1T)]	
X2864B(M)	X2864B(M)@PLCC32
[(SA015A1T)]	
X2864B@PLCC32 [(SA015A1T)]	
X2864H	
X2864H(I)	X2864H(I)@PLCC32
[(SA015A1T)]	
X2864H@PLCC32 [(SA015A1T)]	
X28C010	
X28C010@PLCC32 [(SA015A1T)]	
X28C16A	
X28C16A@PLCC32 [(SA015A1T)]	
X28C16B	
X28C16B@PLCC32 [(SA015A1T)]	
X28C16C	
X28C16C@PLCC32 [(SA015A1T)]	
X28C256	
X28C256@PLCC32 [(SA015A1T)]	X28C256@TSOP28
[(SA430T)]	
X28C512	X28C512@PLCC32
[(SA015A1T)]	
X28C513	X28C513@PLCC32
[(SA015A1T)]	
X28C64	X28C64@PLCC32
[(SA015A1T)]	
X28C64@SOIC28 [(SA404)]	X28C64@TSOP28
[(SA430T)]	
X28HC16	X28HC16@PLCC32
[(SA015A1T)]	
X28HC16@SOIC24 [(SA404)]	
X28HC256	
X28HC256@PLCC32 [(SA015A1T)]	X28HC256@TSOP28
[(SA430T)]	
X28HC64	X28HC64@PLCC32
[(SA015A1T)]	

X28HC64@SOIC28 [(SA404)]	X28HC64@TSOP28
[(SA430T)]	
X28LC512	X28LC512@PLCC32
[(SA015A1T)]	
X28LC513	X28LC513@PLCC32
[(SA015A1T)]	
X28VC256	X28VC256@PLCC32
[(SA015A1T)]	
X28VC256@TSOP28 [(SA430T)]	X40231@SOIC16
[(SA404)]	
X40233@SOIC16 [(SA404)]	X40235@SOIC16
[(SA404)]	
X40237@SOIC16 [(SA404)]	X40239@SOIC16
[(SA404)]	
X40430@SOIC14 [(SA404)]	X40430@TSSOP14
[(SA026)]	
X40431@SOIC14 [(SA404)]	X40431@TSSOP14
[(SA026)]	
X40434@SOIC14 [(SA404)]	X40434@TSSOP14
[(SA026)]	
X40435@SOIC14 [(SA404)]	X40435@TSSOP14
[(SA026)]	
X4C105@TSSOP20 [(SA026)]	
X5043	
X5043@MSOP8 [(SA666)]	X5043@SOIC8
[(SA602A)]	
X5043@TSSOP14 [(SA026)]	
X5045	
X5045@MSOP8 [(SA666)]	X5045@SOIC8
[(SA602A)]	
X5045@TSSOP14 [(SA026)]	
X5083	
X5083@SOIC8 [(SA602A)]	X5083@TSSOP8
[(SA026)]	
X5163	X5163@SOIC8
[(SA602A)]	
X5163@TSSOP14 [(SA026)]	
X51638	
X51638@SOIC8 [(SA602A)]	X51638@TSSOP14
[(SA026)]	
X5165	X5165@SOIC8
[(SA602A)]	
X5165@TSSOP14 [(SA026)]	

X5168	
X5168@SOIC8 [(SA602A)]	X5168@TSSOP14
[(SA026)]	
X5169	X5169@SOIC8
[(SA602A)]	
X5169@TSSOP14 [(SA026)]	
X5323	
X5323@SOIC8 [(SA602A)]	X5323@TSSOP14
[(SA026)]	
X5325	X5325@SOIC8
[(SA602A)]	
X5325@TSSOP14 [(SA026)]	
X5328	
X5328@SOIC8 [(SA602A)]	X5328@TSSOP14
[(SA026)]	
X5329	X5329@SOIC8
[(SA602A)]	
X5329@TSSOP14 [(SA026)]	
X5643	
X5643@SOIC14 [(SA602)]	X5643@SOIC8
[(SA602A)]	
X5643@TSSOP20 [(SA026)]	
X5645	
X5645@SOIC14 [(SA602)]	X5645@SOIC8
[(SA602A)]	
X5645@TSSOP20 [(SA026)]	
X5648	
X5648@SOIC14 [(SA602)]	
X5649	
X5649@SOIC14 [(SA602)]	
X76F041	
X76F041(3)	X76F041(3)@SOIC8
[(SA605)]	
X76F041@SOIC8 [(SA605)]	
X76F101	
X76F101@SOIC8 [(SA602A)]	X76F400@SOIC8
[(SA602A)]	
X76F400@TSSOP8 [(SA026)]	
X84041	
X84041@SOIC14 [(SA602)]	X84041@SOIC8
[(SA602A)]	
X84047	X84047@TSSOP8
[(SA026)]	

X84087 [(SA026)]	X84087@TSSOP8
X84128 [(SA602)]	X84128@SOIC14
X84128@TSSOP28 [(SA643)] [(SA683)]	X84128@XBGA8
X84129 [(SA602)]	X84129@SOIC16
X84160 [(SA602A)]	X84160@SOIC8
X84160@TSSOP8 [(SA026)]	
X84161 X84161@SOIC8 [(SA602A)] [(SA026)]	X84161@TSSOP8
X84256 [(SA602A)]	X84256@SOIC8
X84256@TSSOP14 [(SA026)] [(SA683)]	X84256@XBGA8
X84640 [(SA602A)]	X84640@SOIC8
X84640@TSSOP20 [(SA026)] [(SA683)]	X84640@XBGA8
X84641 [(SA602A)]	X84641@SOIC8
X84641@TSSOP20 [(SA026)] [(SA683)]	X84641@XBGA8
XD2210 [(SA404)]	XD2210@SOIC16
XM28C010	
XM28C020	
XM28C040	

XILINX

E (E) PROM/FRAM/NVRAM

XC1701 [(SA001A)]	XC1701@PLCC20
XC1701@PLCC44 [(SA244)] [(SA404)]	XC1701@SOIC20
XC1701L [(SA001A)]	XC1701L@PLCC20

XC1701L@PLCC44 [(SA244)]	XC1701L@SOIC20
[(SA404)]	
XC1702L@PLCC44 [(SA244)]	XC1702L@TQFP44
[(SA245A)]	
XC1704L@PLCC44 [(SA244)]	XC1704L@TQFP44
[(SA245A)]	
XC17128	XC17128@SOIC8
[(SA602A)]	
XC17128D	XC17128D@PLCC20
[(SA001A)]	
XC17128D@SOIC8 [(SA602A)]	XC17128D@VOIC8
[(SA602A)]	
XC17128E	XC17128E@PLCC20
[(SA001A)]	
XC17128E@VOIC8 [(SA602A)]	
XC17128EL	
XC17128EL@PLCC20 [(SA001A)]	XC17128EL@VOIC8
[(SA602A)]	
XC17128L	XC17128L@PLCC20
[(SA001A)]	
XC17128L@SOIC8 [(SA602A)]	XC17128L@VOIC8
[(SA602A)]	
XC17128X	XC17128X@PLCC20
[(SA001A)]	
XC17128X@SOIC8 [(SA602A)]	XC17128X@VOIC8
[(SA602A)]	
XC1718D	XC1718D@PLCC20
[(SA001A)]	
XC1718D@SOIC8 [(SA602A)]	XC1718D@VOIC8
[(SA602A)]	
XC1718L	XC1718L@PLCC20
[(SA001A)]	
XC1718L@SOIC8 [(SA602A)]	XC1718L@VOIC8
[(SA602A)]	
XC17256D	XC17256D@PLCC20
[(SA001A)]	
XC17256D@SOIC8 [(SA602A)]	XC17256D@VOIC8
[(SA602A)]	
XC17256E	XC17256E@PLCC20
[(SA001A)]	
XC17256E@VOIC8 [(SA602A)]	
XC17256EL	
XC17256EL@PLCC20 [(SA001A)]	XC17256EL@VOIC8

[(SA602A)]	
XC17256L	XC17256L@PLCC20
[(SA001A)]	
XC17256L@SOIC8 [(SA602A)]	XC17256L@VOIC8
[(SA602A)]	
XC17256X	XC17256X@PLCC20
[(SA001A)]	
XC17256X@SOIC8 [(SA602A)]	XC17256X@VOIC8
[(SA602A)]	
XC1736	XC1736@SOIC8
[(SA602A)]	
XC1736A	XC1736A@SOIC8
[(SA602A)]	
XC1736D	XC1736D@PLCC20
[(SA001A)]	
XC1736D@SOIC8 [(SA602A)]	XC1736D@VOIC8
[(SA602A)]	
XC1736E	XC1736E@PLCC20
[(SA001A)]	
XC1736E@SOIC8 [(SA602A)]	XC1736E@VOIC8
[(SA602A)]	
XC17512L	XC17512L@PLCC20
[(SA001A)]	
XC17512L@PLCC44 [(SA244)]	XC17512L@SOIC20
[(SA404)]	
XC1765	XC1765@SOIC8
[(SA602A)]	
XC1765D	XC1765D@PLCC20
[(SA001A)]	
XC1765D@SOIC8 [(SA602A)]	XC1765D@VOIC8
[(SA602A)]	
XC1765E	XC1765E@PLCC20
[(SA001A)]	
XC1765E@SOIC8 [(SA602A)]	XC1765E@VOIC8
[(SA602A)]	
XC1765EL	XC1765EL@PLCC20
[(SA001A)]	
XC1765EL@SOIC8 [(SA602A)]	XC1765EL@VOIC8
[(SA602A)]	
XC1765L	XC1765L@PLCC20
[(SA001A)]	
XC1765L@SOIC8 [(SA602A)]	XC1765L@VOIC8
[(SA602A)]	

XC1765X [(SA001A)]	XC1765X@PLCC20
XC1765X@SOIC8 [(SA602A)] [(SA602A)]	XC1765X@VOIC8
XC17S05 [(SA602A)]	XC17S05@SOIC8
XC17S05XL(L) [(SA602A)]	XC17S05XL(L)@SOIC8
XC17S10 [(SA602A)]	XC17S10@SOIC8
XC17S100A [(SA404)]	XC17S100A@SOIC20
XC17S100A@SOIC8 [(SA602A)] (L)	XC17S100XL
XC17S100XL(L)@SOIC20 [(SA404)] (L)	XC17S10XL
XC17S10XL(L)@SOIC8 [(SA602A)]	
XC17S150A XC17S150A@SOIC20 [(SA404)] [(SA602A)]	XC17S150A@SOIC8
XC17S150XL(L) [(SA404)]	XC17S150XL(L)@SOIC20
XC17S15A [(SA404)]	XC17S15A@SOIC20
XC17S15A@SOIC8 [(SA602A)]	
XC17S20 XC17S20@SOIC8 [(SA602A)]	
XC17S200A XC17S200A@SOIC8 [(SA602A)] [(SA245A)]	XC17S200A@TQFP44
XC17S20XL(L) [(SA602A)]	XC17S20XL(L)@SOIC8
XC17S30 [(SA602A)]	XC17S30@SOIC8
XC17S300A@TQFP44 [(SA245A)]	
XC17S30A XC17S30A@SOIC20 [(SA404)] [(SA602A)]	XC17S30A@SOIC8
XC17S30XL(L) [(SA602A)]	XC17S30XL(L)@SOIC8
XC17S40 [(SA404)]	XC17S40@SOIC20
XC17S40XL(L)	XC17S40XL(L)@SOIC20

[(SA404)]	
XC17S50A	XC17S50A@SOIC20
[(SA404)]	
XC17S50A@SOIC8 [(SA602A)]	XC17S50XL
(L)	
XC17S50XL(L)@SOIC20 [(SA404)]	XC17V01@PLCC20
[(SA001A)]	
XC17V01@SOIC20 [(SA404)]	XC17V01@SOIC8
[(SA602A)]	
XC17V02@PLCC20 [(SA001A)]	XC17V02@PLCC44
[(SA244)]	
XC17V02@TQFP44 [(SA245A)]	XC17V04@PLCC20
[(SA001A)]	
XC17V04@PLCC44 [(SA244)]	XC17V04@TQFP44
[(SA245A)]	
XC17V08@PLCC44 [(SA244)]	XC17V08@TQFP44
[(SA245A)]	
XC17V16@PLCC44 [(SA244)]	XC17V16@TQFP44
[(SA245A)]	
XCF01S(VO)@TSSOP20 [(SA026)]	XCF01S(VOG)@TSSOP20
[(SA026)]	
XCF02S(VO)@TSSOP20 [(SA026)]	XCF02S(VOG)@TSSOP20
[(SA026)]	
XCF04S(VO)@TSSOP20 [(SA026)]	XCF04S(VOG)@TSSOP20
[(SA026)]	
XCF08P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]	
XCF08P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]	
XCF08P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]	
XCF08P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]	
XCF08P(VO)@TSOP48 [(SA247-B005)]	
XCF08P(VO)@TSOP48(ISP) [ISP-HEADER01]	
XCF08P(VOG)@TSOP48 [(SA247-B005)]	
XCF08P(VOG)@TSOP48(ISP) [ISP-HEADER01]	
XCF16P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]	
XCF16P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]	
XCF16P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]	
XCF16P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]	
XCF16P(VO)@TSOP48 [(SA247-B005)]	
XCF16P(VO)@TSOP48(ISP) [ISP-HEADER01]	
XCF16P(VOG)@TSOP48 [(SA247-B005)]	
XCF16P(VOG)@TSOP48(ISP) [ISP-HEADER01]	
XCF32P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]	
XCF32P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]	

XCF32P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]
XCF32P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]
XCF32P(VO)@TSOP48 [(SA247-B005)]
XCF32P(VO)@TSOP48(ISP) [ISP-HEADER01]
XCF32P(VOG)@TSOP48 [(SA247-B005)]
XCF32P(VOG)@TSOP48(ISP) [ISP-HEADER01]

PLD

XC2C32@PLCC44 [(SA244)] [(SA686)]	XC2C32@QFG32
XC2C32@VQFP44 [(SA245A)] [(SA244)]	XC2C32A@PLCC44
XC2C32A@QFG32 [(SA686)] [(SA245A)]	XC2C32A@VQFP44
XC2C64@CSP56(*) [(SA699A-B136B-W056F001Y)]	
XC2C64@PLCC44 [(SA244)] [(SA245A)]	XC2C64@VQFP44
XC2C64A@5QFG48C [(SA696)] [(SA696)]	XC2C64A@5QFG48I
XC2C64A@7QFG48C [(SA696)] [(SA696)]	XC2C64A@7QFG48I
XC2C64A@CSP56(*) [(SA699A-B136B-W056F001Y)]	
XC2C64A@PLCC44 [(SA244)] [(SA245A)]	XC2C64A@VQFP44
XC9536@PLCC44 [(SA244)] [(SA245A)]	XC9536@TQFP44
XC9536XL@BCSP48 [(SA244)]	XC9536XL@PLCC44
XC9536XL@VQFP44 [(SA245A)]	
XC9536XV@BCSP48 XC9536XV@PLCC44 [(SA244)] [(SA245A)]	XC9536XV@TQFP44
XC9572@PLCC44 [(SA244)] [(SA245A)]	XC9572@TQFP44
XC9572XL@BCSP48 [(SA244)]	XC9572XL@PLCC44
XC9572XL@TQFP44 [(SA245A)]	
XC9572XV@BCSP48 XC9572XV@PLCC44 [(SA244)] [(SA245A)]	XC9572XV@TQFP44

XILINX-CUSTOMER**E (E) PROM / FRAM / NVRAM**

XC17S100A [(SA404)]	XC17S100A@SOIC20
XC17S100A@SOIC8 [(SA602A)]	
XC17S150A XC17S150A@SOIC20 [(SA404)] [(SA602A)]	XC17S150A@SOIC8
XC17S15A [(SA404)]	XC17S15A@SOIC20
XC17S15A@SOIC8 [(SA602A)]	
XC17S200A XC17S200A@SOIC8 [(SA602A)] [(SA245A)]	XC17S200A@TQFP44
XC17S300A@TQFP44 [(SA245A)]	
XC17S30A XC17S30A@SOIC20 [(SA404)] [(SA602A)]	XC17S30A@SOIC8
XC17S50A [(SA404)]	XC17S50A@SOIC20
XC17S50A@SOIC8 [(SA602A)] [(SA001A)]	XC17V01@PLCC20
XC17V01@SOIC20 [(SA404)] [(SA602A)]	XC17V01@SOIC8
XC17V02@PLCC20 [(SA001A)] [(SA244)]	XC17V02@PLCC44
XC17V02@TQFP44 [(SA245A)] [(SA001A)]	XC17V04@PLCC20
XC17V04@PLCC44 [(SA244)] [(SA245A)]	XC17V04@TQFP44
XC17V08@PLCC44 [(SA244)] [(SA245A)]	XC17V08@TQFP44
XC17V16@PLCC44 [(SA244)] [(SA245A)]	XC17V16@TQFP44

YMC**E (E) PROM / FRAM / NVRAM**

Y24LC01 [(SA602A)]	Y24LC01@SOIC8
Y24LC01@TSSOP8 [(SA026)]	
Y24LC02	
Y24LC02@SOIC8 [(SA602A)]	Y24LC02@TSSOP8
[(SA026)]	
Y24LC02A	
[(SA602A)]	Y24LC02A@SOIC8
Y24LC02A@TSSOP8 [(SA026)]	
Y24LC04	
Y24LC04@SOIC8 [(SA602A)]	Y24LC04@TSSOP8
[(SA026)]	
Y24LC08	
[(SA602A)]	Y24LC08@SOIC8
Y24LC08@TSSOP8 [(SA026)]	
Y24LC16	
Y24LC16@SOIC8 [(SA602A)]	Y24LC16@TSSOP8
[(SA026)]	
Y24LC32	
[(SA602A)]	Y24LC32@SOIC8
Y24LC32@TSSOP8 [(SA026)]	
Y24LC64	
Y24LC64@SOIC8 [(SA602A)]	Y24LC64@TSSOP8
[(SA026)]	
Y93LC46(08bit)	
[(SA602A)]	Y93LC46(08bit)@SOIC8
Y93LC46(08bit)@TSSOP8 [(SA026)]	Y93LC46
(16bit)	
Y93LC46(16bit)@SOIC8 [(SA602A)]	Y93LC46(16bit)@TSSOP8
[(SA026)]	
Y93LC66(08bit)	
[(SA602A)]	Y93LC66(08bit)@SOIC8
Y93LC66(08bit)@TSSOP8 [(SA026)]	Y93LC66
(16bit)	
Y93LC66(16bit)@SOIC8 [(SA602A)]	Y93LC66(16bit)@TSSOP8
[(SA026)]	
Y93LC86(08bit)	
[(SA602A)]	Y93LC86(08bit)@SOIC8
Y93LC86(08bit)@TSSOP8 [(SA026)]	Y93LC86
(16bit)	
Y93LC86(16bit)@SOIC8 [(SA602A)]	Y93LC86(16bit)@TSSOP8
[(SA026)]	

YSS

E (E) PROM / FRAM / NVRAM

Y25F05@SOP8 [(SA602A)]	Y25F05@VQFN8
[(SA683)]	
Y25F10@SOP8 [(SA602A)]	Y25F10@VQFN8
[(SA683)]	

ZHIXIN

E (E) PROM / FRAM / NVRAM

PC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]	
PC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]	

ZILOG

MICROCONTROLLER

Z86733	Z86733@PLCC28
[(SA008A)]	
Z86733@SOIC28 [(SA404)]	
Z86743	
Z86743@PLCC44 [(SA244)]	
Z86C0208PEC	
Z86C0208PSC	Z86C0208SEC@SOIC18
[(SA404)]	
Z86C0208SSC@SOIC18 [(SA404)]	
Z86E02	
Z86E02@SOIC18 [(SA404)]	
Z86E03	
Z86E03@SOIC18 [(SA404)]	
Z86E04	
Z86E04@SOIC18 [(SA404)]	
Z86E0412PEC	
Z86E0412PEC1903	
Z86E0412PSC1866	
Z86E0412PSC1903	Z86E0412SEC

[(SA404)]
Z86E0412SEC1903 [(SA404)] Z86E0412SSC1866
[(SA404)]
Z86E0412SSC1903 [(SA404)]
Z86E06
Z86E06@SOIC18 [(SA404)]
Z86E07
Z86E07@SOIC18 [(SA404)]
Z86E08
Z86E08@SOIC18 [(SA404)]
Z86E0812PEC
Z86E0812PEC1903
Z86E0812PSC1866
Z86E0812PSC1903 Z86E0812SEC
[(SA404)]
Z86E0812SEC1903 [(SA404)] Z86E0812SSC1866
[(SA404)]
Z86E0812SSC1903 [(SA404)]
Z86E122
Z86E122@SOIC20 [(SA404)]
Z86E123
Z86E123@SOIC20 [(SA404)]
Z86E124
Z86E124@SOIC20 [(SA404)]
Z86E125
Z86E125@SOIC20 [(SA404)]
Z86E126
Z86E126@SOIC20 [(SA404)]
Z86E132
Z86E132@SOIC28 [(SA404)]
Z86E133
Z86E133@SOIC28 [(SA404)]
Z86E134
Z86E134@SOIC28 [(SA404)]
Z86E135
Z86E135@SOIC28 [(SA404)]
Z86E136
Z86E136@SOIC28 [(SA404)]
Z86E142
Z86E142@TQFP44 [(SA245A)]
Z86E143
Z86E143@TQFP44 [(SA245A)]
Z86E144

Z86E144@TQFP44 [(SA245A)]	
Z86E145	
Z86E145@TQFP44 [(SA245A)]	
Z86E146	
Z86E146@TQFP44 [(SA245A)]	
Z86E15	
Z86E21	Z86E21@PLCC44
[(SA244)]	
Z86E21@TQFP44	
Z86E23	
Z86E23@PLCC44 [(SA244)]	Z86E23@TQFP44
[(SA245A)]	
Z86E3016PEC	
Z86E3016PSC	
Z86E3016SEC@SOIC28 [(SA404)]	Z86E3016SSC@SOIC28
[(SA404)]	
Z86E3016VEC@PLCC28 [(SA008A)]	Z86E3016VSC@PLCC28
[(SA008A)]	
Z86E3016VSG@PLCC28 [(SA008A)]	
Z86E3116PEC	
Z86E3116PSC	Z86E3116SEC@SOIC28
[(SA404)]	
Z86E3116SSC@SOIC28 [(SA404)]	Z86E3116VEC@PLCC28
[(SA008A)]	
Z86E3116VSC@PLCC28 [(SA008A)]	Z86E3116VSG@PLCC28
[(SA008A)]	
Z86E33	Z86E33@PLCC28
[(SA008A)]	
Z86E33@SOIC28 [(SA404)]	
Z86E34	
Z86E34@PLCC28 [(SA008A)]	Z86E34@SOIC28
[(SA404)]	
Z86E4016FEC@TQFP44 [(SA245A)]	Z86E4016FSC@TQFP44
[(SA245A)]	
Z86E4016PEC	
Z86E4016PSC	
Z86E4016VEC@PLCC44 [(SA244)]	Z86E4016VSC@PLCC44
[(SA244)]	
Z86E4016VSG@PLCC44 [(SA244)]	
Z86E43	
Z86E43@PLCC44 [(SA244)]	Z86E43@TQFP44
[(SA245A)]	
Z86E44	Z86E44@PLCC44

[(SA244)]	
Z86E44@TQFP44 [(SA245A)]	Z86E61FSC@TQFP44
[(SA245A)]	
Z86E61PSC	Z86E61VSC@PLCC44
[(SA244)]	
Z86E63FSC@TQFP44 [(SA245A)]	
Z86E63PSC	
Z86E63VSC@PLCC44 [(SA244)]	
Z86E72	
Z86E72@PLCC44 [(SA244)]	Z86E72@TQFP44
[(SA245A)]	
Z86E73	Z86E73@PLCC44
[(SA244)]	
Z86E73@TQFP44 [(SA245A)]	
Z86E83	
Z86E83@PLCC28 [(SA008A)]	Z86E83@SOIC28
[(SA404)]	
Z86L0208PEC	
Z86L0208PSC	
Z86L0208SEC@SOIC18 [(SA404)]	Z86L0208SSC@SOIC18
[(SA404)]	
Z89371	Z89371@PLCC44
[(SA244)]	
Z89371@TQFP44 [(SA245A)]	
Z89371B	
Z89371B@PLCC44 [(SA244)]	Z89371B@TQFP44
[(SA245A)]	
Z8F0113HH005EC@SSOP20 [(SA626A)]	Z8F0113HH005EG@SSOP20
[(SA626A)]	
Z8F0113HH005SC@SSOP20 [(SA626A)]	Z8F0113HH005SG@SSOP20
[(SA626A)]	
Z8F0113HJ005EC@SSOP28 [(SA626A)]	Z8F0113HJ005EG@SSOP28
[(SA626A)]	
Z8F0113HJ005SC@SSOP28 [(SA626A)]	Z8F0113HJ005SG@SSOP28
[(SA626A)]	
Z8F0113PB005EC	
Z8F0113PB005EG	
Z8F0113PB005SC	
Z8F0113PB005SG	
Z8F0113PH005EC	
Z8F0113PH005EG	
Z8F0113PH005SC	
Z8F0113PH005SG	

Z8F0113PJ005EC

Z8F0113PJ005EG

Z8F0113PJ005SC

Z8F0113PJ005SG

Z8F0113QB005EC@QFN8 [(SA683)]
[(SA683)]

Z8F0113QB005EG@QFN8

Z8F0113QB005SC@QFN8 [(SA683)]
[(SA683)]

Z8F0113QB005SG@QFN8

Z8F0113SB005EC@SOIC8 [(SA602A)]
[(SA602A)]

Z8F0113SB005EG@SOIC8

Z8F0113SB005SC@SOIC8 [(SA602A)]
[(SA602A)]

Z8F0113SB005SG@SOIC8

Z8F0113SH005EC@SOIC20 [(SA404)]
[(SA404)]

Z8F0113SH005EG@SOIC20

Z8F0113SH005SC@SOIC20 [(SA404)]
[(SA404)]

Z8F0113SH005SG@SOIC20

Z8F0113SJ005EC@SOIC28 [(SA404)]
[(SA404)]

Z8F0113SJ005EG@SOIC28

Z8F0113SJ005SC@SOIC28 [(SA404)]
[(SA404)]

Z8F0113SJ005SG@SOIC28

Z8F011AHH020EC@SSOP20 [(SA626A)]
[(SA626A)]

Z8F011AHH020EG@SSOP20

Z8F011AHH020SC@SSOP20 [(SA626A)]
[(SA626A)]

Z8F011AHH020SG@SSOP20

Z8F011AHJ020EC@SSOP28 [(SA626A)]
[(SA626A)]

Z8F011AHJ020EG@SSOP28

Z8F011AHJ020SC@SSOP28 [(SA626A)]
[(SA626A)]

Z8F011AHJ020SG@SSOP28

Z8F011APB020EC

Z8F011APB020EG

Z8F011APB020SC

Z8F011APB020SG

Z8F011APH020EC

Z8F011APH020EG

Z8F011APH020SC

Z8F011APH020SG

Z8F011APJ020EC

Z8F011APJ020EG

Z8F011APJ020SC

Z8F011APJ020SG

Z8F011AQB020EC@QFN8 [(SA683)]
[(SA683)]

Z8F011AQB020EG@QFN8

Z8F011AQB020SC@QFN8 [(SA683)]

Z8F011AQB020SG@QFN8

[(SA683)]		
Z8F011ASB020EC@SOIC8 [(SA602A)]		Z8F011ASB020EG@SOIC8
[(SA602A)]		
Z8F011ASB020SC@SOIC8 [(SA602A)]		Z8F011ASB020SG@SOIC8
[(SA602A)]		
Z8F011ASH020EC@SOIC20 [(SA404)]		Z8F011ASH020EG@SOIC20
[(SA404)]		
Z8F011ASH020SC@SOIC20 [(SA404)]		Z8F011ASH020SG@SOIC20
[(SA404)]		
Z8F011ASJ020EC@SOIC28 [(SA404)]		Z8F011ASJ020EG@SOIC28
[(SA404)]		
Z8F011ASJ020SC@SOIC28 [(SA404)]		Z8F011ASJ020SG@SOIC28
[(SA404)]		
Z8F0123HH005EC@SSOP20 [(SA626A)]		Z8F0123HH005EG@SSOP20
[(SA626A)]		
Z8F0123HH005SC@SSOP20 [(SA626A)]		Z8F0123HH005SG@SSOP20
[(SA626A)]		
Z8F0123HJ005EC@SSOP28 [(SA626A)]		Z8F0123HJ005EG@SSOP28
[(SA626A)]		
Z8F0123HJ005SC@SSOP28 [(SA626A)]		Z8F0123HJ005SG@SSOP28
[(SA626A)]		
Z8F0123PB005EC		
Z8F0123PB005EG		
Z8F0123PB005SC		
Z8F0123PB005SG		
Z8F0123PH005EC		
Z8F0123PH005EG		
Z8F0123PH005SC		
Z8F0123PH005SG		
Z8F0123PJ005EC		
Z8F0123PJ005EG		
Z8F0123PJ005SC		
Z8F0123PJ005SG		
Z8F0123QB005EC@QFN8 [(SA683)]		Z8F0123QB005EG@QFN8
[(SA683)]		
Z8F0123QB005SC@QFN8 [(SA683)]		Z8F0123QB005SG@QFN8
[(SA683)]		
Z8F0123SB005EC@SOIC8 [(SA602A)]		Z8F0123SB005EG@SOIC8
[(SA602A)]		
Z8F0123SB005SC@SOIC8 [(SA602A)]		Z8F0123SB005SG@SOIC8
[(SA602A)]		
Z8F0123SH005EC@SOIC20 [(SA404)]		Z8F0123SH005EG@SOIC20
[(SA404)]		

Z8F0123SH005SC@SOIC20 [(SA404)]	Z8F0123SH005SG@SOIC20
[(SA404)]	
Z8F0123SJ005EC@SOIC28 [(SA404)]	Z8F0123SJ005EG@SOIC28
[(SA404)]	
Z8F0123SJ005SC@SOIC28 [(SA404)]	Z8F0123SJ005SG@SOIC28
[(SA404)]	
Z8F012AHH020EC@SSOP20 [(SA626A)]	Z8F012AHH020EG@SSOP20
[(SA626A)]	
Z8F012AHH020SC@SSOP20 [(SA626A)]	Z8F012AHH020SG@SSOP20
[(SA626A)]	
Z8F012AHJ020EC@SSOP28 [(SA626A)]	Z8F012AHJ020EG@SSOP28
[(SA626A)]	
Z8F012AHJ020SC@SSOP28 [(SA626A)]	Z8F012AHJ020SG@SSOP28
[(SA626A)]	
Z8F012APB020EC	
Z8F012APB020EG	
Z8F012APB020SC	
Z8F012APB020SG	
Z8F012APH020EC	
Z8F012APH020EG	
Z8F012APH020SC	
Z8F012APH020SG	
Z8F012APJ020EC	
Z8F012APJ020EG	
Z8F012APJ020SC	
Z8F012APJ020SG	
Z8F012AQB020EC@QFN8 [(SA683)]	Z8F012AQB020EG@QFN8
[(SA683)]	
Z8F012AQB020SC@QFN8 [(SA683)]	Z8F012AQB020SG@QFN8
[(SA683)]	
Z8F012ASB020EC@SOIC8 [(SA602A)]	Z8F012ASB020EG@SOIC8
[(SA602A)]	
Z8F012ASB020SC@SOIC8 [(SA602A)]	Z8F012ASB020SG@SOIC8
[(SA602A)]	
Z8F012ASH020EC@SOIC20 [(SA404)]	Z8F012ASH020EG@SOIC20
[(SA404)]	
Z8F012ASH020SC@SOIC20 [(SA404)]	Z8F012ASH020SG@SOIC20
[(SA404)]	
Z8F012ASJ020EC@SOIC28 [(SA404)]	Z8F012ASJ020EG@SOIC28
[(SA404)]	
Z8F012ASJ020SC@SOIC28 [(SA404)]	Z8F012ASJ020SG@SOIC28
[(SA404)]	
Z8F0130HH020EG@SSOP20 [(SA626A)]	Z8F0130HH020SG@SSOP20

[(SA626A)]
Z8F0130HJ020EG@SSOP28 [(SA626A)] Z8F0130HJ020SG@SSOP28
[(SA626A)]
Z8F0130PH020EG
Z8F0130PH020SG
Z8F0130PJ020EG
Z8F0130PJ020SG
Z8F0130QH020EG@QFN20 [(SA759)] Z8F0130QH020SG@QFN20
[(SA759)]
Z8F0130QJ020EG@QFN28 [(SA697)] Z8F0130QJ020SG@QFN28
[(SA697)]
Z8F0130SH020EG@SOIC20 [(SA404)] Z8F0130SH020SG@SOIC20
[(SA404)]
Z8F0130SJ020EG@SOIC28 [(SA404)] Z8F0130SJ020SG@SOIC28
[(SA404)]
Z8F0131HH020EG@SSOP20 [(SA626A)] Z8F0131HH020SG@SSOP20
[(SA626A)]
Z8F0131HJ020EG@SSOP28 [(SA626A)] Z8F0131HJ020SG@SSOP28
[(SA626A)]
Z8F0131PH020EG
Z8F0131PH020SG
Z8F0131PJ020EG
Z8F0131PJ020SG
Z8F0131QH020EG@QFN20 [(SA759)] Z8F0131QH020SG@QFN20
[(SA759)]
Z8F0131QJ020EG@QFN28 [(SA697)] Z8F0131QJ020SG@QFN28
[(SA697)]
Z8F0131SH020EG@SOIC20 [(SA404)] Z8F0131SH020SG@SOIC20
[(SA404)]
Z8F0131SJ020EG@SOIC28 [(SA404)] Z8F0131SJ020SG@SOIC28
[(SA404)]
Z8F0213HH005EC@SSOP20 [(SA626A)] Z8F0213HH005EG@SSOP20
[(SA626A)]
Z8F0213HH005SC@SSOP20 [(SA626A)] Z8F0213HH005SG@SSOP20
[(SA626A)]
Z8F0213HJ005EC@SSOP28 [(SA626A)] Z8F0213HJ005EG@SSOP28
[(SA626A)]
Z8F0213HJ005SC@SSOP28 [(SA626A)] Z8F0213HJ005SG@SSOP28
[(SA626A)]
Z8F0213PB005EC
Z8F0213PB005EG
Z8F0213PB005SC
Z8F0213PB005SG

Z8F0213PH005EC

Z8F0213PH005EG

Z8F0213PH005SC

Z8F0213PH005SG

Z8F0213PJ005EC

Z8F0213PJ005EG

Z8F0213PJ005SC

Z8F0213PJ005SG

Z8F0213QB005EC@QFN8 [(SA683)]

[(SA683)]

Z8F0213QB005SC@QFN8 [(SA683)]

[(SA683)]

Z8F0213SB005EC@SOIC8 [(SA602A)]

[(SA602A)]

Z8F0213SB005SC@SOIC8 [(SA602A)]

[(SA602A)]

Z8F0213SH005EC@SOIC20 [(SA404)]

[(SA404)]

Z8F0213SH005SC@SOIC20 [(SA404)]

[(SA404)]

Z8F0213SJ005EC@SOIC28 [(SA404)]

[(SA404)]

Z8F0213SJ005SC@SOIC28 [(SA404)]

[(SA404)]

Z8F021AHH020EC@SSOP20 [(SA626A)]

[(SA626A)]

Z8F021AHH020SC@SSOP20 [(SA626A)]

[(SA626A)]

Z8F021AHJ020EC@SSOP28 [(SA626A)]

[(SA626A)]

Z8F021AHJ020SC@SSOP28 [(SA626A)]

[(SA626A)]

Z8F021APB020EC

Z8F021APB020EG

Z8F021APB020SC

Z8F021APB020SG

Z8F021APH020EC

Z8F021APH020EG

Z8F021APH020SC

Z8F021APH020SG

Z8F021APJ020EC

Z8F021APJ020EG

Z8F021APJ020SC

Z8F0213QB005EG@QFN8

Z8F0213QB005SG@QFN8

Z8F0213SB005EG@SOIC8

Z8F0213SB005SG@SOIC8

Z8F0213SH005EG@SOIC20

Z8F0213SH005SG@SOIC20

Z8F0213SJ005EG@SOIC28

Z8F0213SJ005SG@SOIC28

Z8F021AHH020EG@SSOP20

Z8F021AHH020SG@SSOP20

Z8F021AHJ020EG@SSOP28

Z8F021AHJ020SG@SSOP28

Z8F021APJ020SG

Z8F021AQB020EC@QFN8 [(SA683)]
[(SA683)]

Z8F021AQB020SC@QFN8 [(SA683)]
[(SA683)]

Z8F021ASB020EC@SOIC8 [(SA602A)]
[(SA602A)]

Z8F021ASB020SC@SOIC8 [(SA602A)]
[(SA602A)]

Z8F021ASH020EC@SOIC20 [(SA404)]
[(SA404)]

Z8F021ASH020SC@SOIC20 [(SA404)]
[(SA404)]

Z8F021ASJ020EC@SOIC28 [(SA404)]
[(SA404)]

Z8F021ASJ020SC@SOIC28 [(SA404)]
[(SA404)]

Z8F0223HH005EC@SSOP20 [(SA626A)]
[(SA626A)]

Z8F0223HH005SC@SSOP20 [(SA626A)]
[(SA626A)]

Z8F0223HJ005EC@SSOP28 [(SA626A)]
[(SA626A)]

Z8F0223HJ005SC@SSOP28 [(SA626A)]
[(SA626A)]

Z8F0223PB005EC

Z8F0223PB005EG

Z8F0223PB005SC

Z8F0223PB005SG

Z8F0223PH005EC

Z8F0223PH005EG

Z8F0223PH005SC

Z8F0223PH005SG

Z8F0223PJ005EC

Z8F0223PJ005EG

Z8F0223PJ005SC

Z8F0223PJ005SG

Z8F0223QB005EC@QFN8 [(SA683)]
[(SA683)]

Z8F0223QB005SC@QFN8 [(SA683)]
[(SA683)]

Z8F0223SB005EC@SOIC8 [(SA602A)]
[(SA602A)]

Z8F021AQB020EG@QFN8

Z8F021AQB020SG@QFN8

Z8F021ASB020EG@SOIC8

Z8F021ASB020SG@SOIC8

Z8F021ASH020EG@SOIC20

Z8F021ASH020SG@SOIC20

Z8F021ASJ020EG@SOIC28

Z8F021ASJ020SG@SOIC28

Z8F0223HH005EG@SSOP20

Z8F0223HH005SG@SSOP20

Z8F0223HJ005EG@SSOP28

Z8F0223HJ005SG@SSOP28

Z8F0223QB005EG@QFN8

Z8F0223QB005SG@QFN8

Z8F0223SB005EG@SOIC8

Z8F0223SB005SC@SOIC8 [(SA602A)]	Z8F0223SB005SG@SOIC8
[(SA602A)]	
Z8F0223SH005EC@SOIC20 [(SA404)]	Z8F0223SH005EG@SOIC20
[(SA404)]	
Z8F0223SH005SC@SOIC20 [(SA404)]	Z8F0223SH005SG@SOIC20
[(SA404)]	
Z8F0223SJ005EC@SOIC28 [(SA404)]	Z8F0223SJ005EG@SOIC28
[(SA404)]	
Z8F0223SJ005SC@SOIC28 [(SA404)]	Z8F0223SJ005SG@SOIC28
[(SA404)]	
Z8F022AHH020EC@SSOP20 [(SA626A)]	Z8F022AHH020EG@SSOP20
[(SA626A)]	
Z8F022AHH020SC@SSOP20 [(SA626A)]	Z8F022AHH020SG@SSOP20
[(SA626A)]	
Z8F022AHJ020EC@SSOP28 [(SA626A)]	Z8F022AHJ020EG@SSOP28
[(SA626A)]	
Z8F022AHJ020SC@SSOP28 [(SA626A)]	Z8F022AHJ020SG@SSOP28
[(SA626A)]	
Z8F022APB020EC	
Z8F022APB020EG	
Z8F022APB020SC	
Z8F022APB020SG	
Z8F022APH020EC	
Z8F022APH020EG	
Z8F022APH020SC	
Z8F022APH020SG	
Z8F022APJ020EC	
Z8F022APJ020EG	
Z8F022APJ020SC	
Z8F022APJ020SG	
Z8F022AQB020EC@QFN8 [(SA683)]	Z8F022AQB020EG@QFN8
[(SA683)]	
Z8F022AQB020SC@QFN8 [(SA683)]	Z8F022AQB020SG@QFN8
[(SA683)]	
Z8F022ASB020EC@SOIC8 [(SA602A)]	Z8F022ASB020EG@SOIC8
[(SA602A)]	
Z8F022ASB020SC@SOIC8 [(SA602A)]	Z8F022ASB020SG@SOIC8
[(SA602A)]	
Z8F022ASH020EC@SOIC20 [(SA404)]	Z8F022ASH020EG@SOIC20
[(SA404)]	
Z8F022ASH020SC@SOIC20 [(SA404)]	Z8F022ASH020SG@SOIC20
[(SA404)]	
Z8F022ASJ020EC@SOIC28 [(SA404)]	Z8F022ASJ020EG@SOIC28

[(SA404)]
Z8F022ASJ020SC@SOIC28 [(SA404)] Z8F022ASJ020SG@SOIC28
[(SA404)]
Z8F0230HH020EG@SSOP20 [(SA626A)] Z8F0230HH020SG@SSOP20
[(SA626A)]
Z8F0230HJ020EG@SSOP28 [(SA626A)] Z8F0230HJ020SG@SSOP28
[(SA626A)]
Z8F0230PH020EG
Z8F0230PH020SG
Z8F0230PJ020EG
Z8F0230PJ020SG
Z8F0230QH020EG@QFN20 [(SA759)] Z8F0230QH020SG@QFN20
[(SA759)]
Z8F0230QJ020EG@QFN28 [(SA697)] Z8F0230QJ020SG@QFN28
[(SA697)]
Z8F0230SH020EG@SOIC20 [(SA404)] Z8F0230SH020SG@SOIC20
[(SA404)]
Z8F0230SJ020EG@SOIC28 [(SA404)] Z8F0230SJ020SG@SOIC28
[(SA404)]
Z8F0231HH020EG@SSOP20 [(SA626A)] Z8F0231HH020SG@SSOP20
[(SA626A)]
Z8F0231HJ020EG@SSOP28 [(SA626A)] Z8F0231HJ020SG@SSOP28
[(SA626A)]
Z8F0231PH020EG
Z8F0231PH020SG
Z8F0231PJ020EG
Z8F0231PJ020SG
Z8F0231QH020EG@QFN20 [(SA759)] Z8F0231QH020SG@QFN20
[(SA759)]
Z8F0231QJ020EG@QFN28 [(SA697)] Z8F0231QJ020SG@QFN28
[(SA697)]
Z8F0231SH020EG@SOIC20 [(SA404)] Z8F0231SH020SG@SOIC20
[(SA404)]
Z8F0231SJ020EG@SOIC28 [(SA404)] Z8F0231SJ020SG@SOIC28
[(SA404)]
Z8F0411HH020EC@SSOP20 [(SA626A)] Z8F0411HH020EG@SSOP20
[(SA626A)]
Z8F0411HH020SC@SSOP20 [(SA626A)] Z8F0411HH020SG@SSOP20
[(SA626A)]
Z8F0411PH020EC
Z8F0411PH020EG
Z8F0411PH020SC
Z8F0411PH020SG

Z8F0412PJ020EC
Z8F0412PJ020EG
Z8F0412PJ020SC
Z8F0412PJ020SG
Z8F0412SJ020EC@SOIC28 [(SA404)] Z8F0412SJ020EG@SOIC28
[(SA404)]
Z8F0412SJ020SC@SOIC28 [(SA404)] Z8F0412SJ020SG@SOIC28
[(SA404)]
Z8F0413HH005EC@SSOP20 [(SA626A)] Z8F0413HH005EG@SSOP20
[(SA626A)]
Z8F0413HH005SC@SSOP20 [(SA626A)] Z8F0413HH005SG@SSOP20
[(SA626A)]
Z8F0413HJ005EC@SSOP28 [(SA626A)] Z8F0413HJ005EG@SSOP28
[(SA626A)]
Z8F0413HJ005SC@SSOP28 [(SA626A)] Z8F0413HJ005SG@SSOP28
[(SA626A)]
Z8F0413PB005EC
Z8F0413PB005EG
Z8F0413PB005SC
Z8F0413PB005SG
Z8F0413PH005EC
Z8F0413PH005EG
Z8F0413PH005SC
Z8F0413PH005SG
Z8F0413PJ005EC
Z8F0413PJ005EG
Z8F0413PJ005SC
Z8F0413PJ005SG
Z8F0413QB005EC@QFN8 [(SA683)] Z8F0413QB005EG@QFN8
[(SA683)]
Z8F0413QB005SC@QFN8 [(SA683)] Z8F0413QB005SG@QFN8
[(SA683)]
Z8F0413SB005EC@SOIC8 [(SA602A)] Z8F0413SB005EG@SOIC8
[(SA602A)]
Z8F0413SB005SC@SOIC8 [(SA602A)] Z8F0413SB005SG@SOIC8
[(SA602A)]
Z8F0413SH005EC@SOIC20 [(SA404)] Z8F0413SH005EG@SOIC20
[(SA404)]
Z8F0413SH005SC@SOIC20 [(SA404)] Z8F0413SH005SG@SOIC20
[(SA404)]
Z8F0413SJ005EC@SOIC28 [(SA404)] Z8F0413SJ005EG@SOIC28
[(SA404)]
Z8F0413SJ005SC@SOIC28 [(SA404)] Z8F0413SJ005SG@SOIC28

[(SA404)]
Z8F041AHH020EC@SSOP20 [(SA626A)] Z8F041AHH020EG@SSOP20
[(SA626A)]
Z8F041AHH020SC@SSOP20 [(SA626A)] Z8F041AHH020SG@SSOP20
[(SA626A)]
Z8F041AHJ020EC@SSOP28 [(SA626A)] Z8F041AHJ020EG@SSOP28
[(SA626A)]
Z8F041AHJ020SC@SSOP28 [(SA626A)] Z8F041AHJ020SG@SSOP28
[(SA626A)]
Z8F041APB020EC
Z8F041APB020EG
Z8F041APB020SC
Z8F041APB020SG
Z8F041APH020EC
Z8F041APH020EG
Z8F041APH020SC
Z8F041APH020SG
Z8F041APJ020EC
Z8F041APJ020EG
Z8F041APJ020SC
Z8F041APJ020SG
Z8F041AQB020EC@QFN8 [(SA683)] Z8F041AQB020EG@QFN8
[(SA683)]
Z8F041AQB020SC@QFN8 [(SA683)] Z8F041AQB020SG@QFN8
[(SA683)]
Z8F041ASB020EC@SOIC8 [(SA602A)] Z8F041ASB020EG@SOIC8
[(SA602A)]
Z8F041ASB020SC@SOIC8 [(SA602A)] Z8F041ASB020SG@SOIC8
[(SA602A)]
Z8F041ASH020EC@SOIC20 [(SA404)] Z8F041ASH020EG@SOIC20
[(SA404)]
Z8F041ASH020SC@SOIC20 [(SA404)] Z8F041ASH020SG@SOIC20
[(SA404)]
Z8F041ASJ020EC@SOIC28 [(SA404)] Z8F041ASJ020EG@SOIC28
[(SA404)]
Z8F041ASJ020SC@SOIC28 [(SA404)] Z8F041ASJ020SG@SOIC28
[(SA404)]
Z8F0421HH020EC@SSOP20 [(SA626A)] Z8F0421HH020EG@SSOP20
[(SA626A)]
Z8F0421HH020SC@SSOP20 [(SA626A)] Z8F0421HH020SG@SSOP20
[(SA626A)]
Z8F0421PH020EC
Z8F0421PH020EG

Z8F0421PH020SC
Z8F0421PH020SG
Z8F0422PJ020EC
Z8F0422PJ020EG
Z8F0422PJ020SC
Z8F0422PJ020SG
Z8F0422SJ020EC@SOIC28 [(SA404)] Z8F0422SJ020EG@SOIC28
[(SA404)]
Z8F0422SJ020SC@SOIC28 [(SA404)] Z8F0422SJ020SG@SOIC28
[(SA404)]
Z8F0423HH005EC@SSOP20 [(SA626A)] Z8F0423HH005EG@SSOP20
[(SA626A)]
Z8F0423HH005SC@SSOP20 [(SA626A)] Z8F0423HH005SG@SSOP20
[(SA626A)]
Z8F0423HJ005EC@SSOP28 [(SA626A)] Z8F0423HJ005EG@SSOP28
[(SA626A)]
Z8F0423HJ005SC@SSOP28 [(SA626A)] Z8F0423HJ005SG@SSOP28
[(SA626A)]
Z8F0423PB005EC
Z8F0423PB005EG
Z8F0423PB005SC
Z8F0423PB005SG
Z8F0423PH005EC
Z8F0423PH005EG
Z8F0423PH005SC
Z8F0423PH005SG
Z8F0423PJ005EC
Z8F0423PJ005EG
Z8F0423PJ005SC
Z8F0423PJ005SG
Z8F0423QB005EC@QFN8 [(SA683)] Z8F0423QB005EG@QFN8
[(SA683)]
Z8F0423QB005SC@QFN8 [(SA683)] Z8F0423QB005SG@QFN8
[(SA683)]
Z8F0423SB005EC@SOIC8 [(SA602A)] Z8F0423SB005EG@SOIC8
[(SA602A)]
Z8F0423SB005SC@SOIC8 [(SA602A)] Z8F0423SB005SG@SOIC8
[(SA602A)]
Z8F0423SH005EC@SOIC20 [(SA404)] Z8F0423SH005EG@SOIC20
[(SA404)]
Z8F0423SH005SC@SOIC20 [(SA404)] Z8F0423SH005SG@SOIC20
[(SA404)]
Z8F0423SJ005EC@SOIC28 [(SA404)] Z8F0423SJ005EG@SOIC28

[(SA404)]		
Z8F0423SJ005SC@SOIC28 [(SA404)]		Z8F0423SJ005SG@SOIC28
[(SA404)]		
Z8F042AHH020EC@SSOP20 [(SA626A)]		Z8F042AHH020EG@SSOP20
[(SA626A)]		
Z8F042AHH020SC@SSOP20 [(SA626A)]		Z8F042AHH020SG@SSOP20
[(SA626A)]		
Z8F042AHJ020EC@SSOP28 [(SA626A)]		Z8F042AHJ020EG@SSOP28
[(SA626A)]		
Z8F042AHJ020SC@SSOP28 [(SA626A)]		Z8F042AHJ020SG@SSOP28
[(SA626A)]		
Z8F042APB020EC		
Z8F042APB020EG		
Z8F042APB020SC		
Z8F042APB020SG		
Z8F042APH020EC		
Z8F042APH020EG		
Z8F042APH020SC		
Z8F042APH020SG		
Z8F042APJ020EC		
Z8F042APJ020EG		
Z8F042APJ020SC		
Z8F042APJ020SG		
Z8F042AQB020EC@QFN8 [(SA683)]		Z8F042AQB020EG@QFN8
[(SA683)]		
Z8F042AQB020SC@QFN8 [(SA683)]		Z8F042AQB020SG@QFN8
[(SA683)]		
Z8F042ASB020EC@SOIC8 [(SA602A)]		Z8F042ASB020EG@SOIC8
[(SA602A)]		
Z8F042ASB020SC@SOIC8 [(SA602A)]		Z8F042ASB020SG@SOIC8
[(SA602A)]		
Z8F042ASH020EC@SOIC20 [(SA404)]		Z8F042ASH020EG@SOIC20
[(SA404)]		
Z8F042ASH020SC@SOIC20 [(SA404)]		Z8F042ASH020SG@SOIC20
[(SA404)]		
Z8F042ASJ020EC@SOIC28 [(SA404)]		Z8F042ASJ020EG@SOIC28
[(SA404)]		
Z8F042ASJ020SC@SOIC28 [(SA404)]		Z8F042ASJ020SG@SOIC28
[(SA404)]		
Z8F0430HH020EG@SSOP20 [(SA626A)]		Z8F0430HH020SG@SSOP20
[(SA626A)]		
Z8F0430HJ020EG@SSOP28 [(SA626A)]		Z8F0430HJ020SG@SSOP28
[(SA626A)]		

Z8F0430PH020EG
Z8F0430PH020SG
Z8F0430PJ020EG
Z8F0430PJ020SG
Z8F0430QH020EG@QFN20 [(SA759)] Z8F0430QH020SG@QFN20
[(SA759)]
Z8F0430QJ020EG@QFN28 [(SA697)] Z8F0430QJ020SG@QFN28
[(SA697)]
Z8F0430SH020EG@SOIC20 [(SA404)] Z8F0430SH020SG@SOIC20
[(SA404)]
Z8F0430SJ020EG@SOIC28 [(SA404)] Z8F0430SJ020SG@SOIC28
[(SA404)]
Z8F0431HH020EG@SSOP20 [(SA626A)] Z8F0431HH020SG@SSOP20
[(SA626A)]
Z8F0431HJ020EG@SSOP28 [(SA626A)] Z8F0431HJ020SG@SSOP28
[(SA626A)]
Z8F0431PH020EG
Z8F0431PH020SG
Z8F0431PJ020EG
Z8F0431PJ020SG
Z8F0431QH020EG@QFN20 [(SA759)] Z8F0431QH020SG@QFN20
[(SA759)]
Z8F0431QJ020EG@QFN28 [(SA697)] Z8F0431QJ020SG@QFN28
[(SA697)]
Z8F0431SH020EG@SOIC20 [(SA404)] Z8F0431SH020SG@SOIC20
[(SA404)]
Z8F0431SJ020EG@SOIC28 [(SA404)] Z8F0431SJ020SG@SOIC28
[(SA404)]
Z8F0811HH020EC@SSOP20 [(SA626A)] Z8F0811HH020EG@SSOP20
[(SA626A)]
Z8F0811HH020SC@SSOP20 [(SA626A)] Z8F0811HH020SG@SSOP20
[(SA626A)]
Z8F0811PH020EC
Z8F0811PH020EG
Z8F0811PH020SC
Z8F0811PH020SG
Z8F0812PJ020EC
Z8F0812PJ020EG
Z8F0812PJ020SC
Z8F0812PJ020SG
Z8F0812SJ020EC@SOIC28 [(SA404)] Z8F0812SJ020EG@SOIC28
[(SA404)]
Z8F0812SJ020SC@SOIC28 [(SA404)] Z8F0812SJ020SG@SOIC28

[(SA404)]
Z8F0813HH005EC@SSOP20 [(SA626A)] Z8F0813HH005EG@SSOP20
[(SA626A)]
Z8F0813HH005SC@SSOP20 [(SA626A)] Z8F0813HH005SG@SSOP20
[(SA626A)]
Z8F0813HJ020EC@SSOP28 [(SA626A)] Z8F0813HJ020EG@SSOP28
[(SA626A)]
Z8F0813HJ020SC@SSOP28 [(SA626A)] Z8F0813HJ020SG@SSOP28
[(SA626A)]
Z8F0813PB005EC
Z8F0813PB005EG
Z8F0813PB005SC
Z8F0813PB005SG
Z8F0813PH005EC
Z8F0813PH005EG
Z8F0813PH005SC
Z8F0813PH005SG
Z8F0813PJ020EC
Z8F0813PJ020EG
Z8F0813PJ020SC
Z8F0813PJ020SG
Z8F0813QB005EC@QFN8 [(SA683)] Z8F0813QB005EG@QFN8
[(SA683)]
Z8F0813QB005SC@QFN8 [(SA683)] Z8F0813QB005SG@QFN8
[(SA683)]
Z8F0813SB005EC@SOIC8 [(SA602A)] Z8F0813SB005EG@SOIC8
[(SA602A)]
Z8F0813SB005SC@SOIC8 [(SA602A)] Z8F0813SB005SG@SOIC8
[(SA602A)]
Z8F0813SH005EC@SOIC20 [(SA404)] Z8F0813SH005EG@SOIC20
[(SA404)]
Z8F0813SH005SC@SOIC20 [(SA404)] Z8F0813SH005SG@SOIC20
[(SA404)]
Z8F0813SJ020EC@SOIC28 [(SA404)] Z8F0813SJ020EG@SOIC28
[(SA404)]
Z8F0813SJ020SC@SOIC28 [(SA404)] Z8F0813SJ020SG@SOIC28
[(SA404)]
Z8F081AHH005EC@SSOP20 [(SA626A)] Z8F081AHH005EG@SSOP20
[(SA626A)]
Z8F081AHH005SC@SSOP20 [(SA626A)] Z8F081AHH005SG@SSOP20
[(SA626A)]
Z8F081AHJ020EC@SSOP28 [(SA626A)] Z8F081AHJ020EG@SSOP28
[(SA626A)]

Z8F081AHJ020SC@SSOP28 [(SA626A)]	Z8F081AHJ020SG@SSOP28
[(SA626A)]	
Z8F081APB020EC	
Z8F081APB020EG	
Z8F081APB020SC	
Z8F081APB020SG	
Z8F081APH005EC	
Z8F081APH005EG	
Z8F081APH005SC	
Z8F081APH005SG	
Z8F081APJ020EC	
Z8F081APJ020EG	
Z8F081APJ020SC	
Z8F081APJ020SG	
Z8F081AQB020EC@QFN8 [(SA683)]	Z8F081AQB020EG@QFN8
[(SA683)]	
Z8F081AQB020SC@QFN8 [(SA683)]	Z8F081AQB020SG@QFN8
[(SA683)]	
Z8F081ASB020EC@SOIC8 [(SA602A)]	Z8F081ASB020EG@SOIC8
[(SA602A)]	
Z8F081ASB020SC@SOIC8 [(SA602A)]	Z8F081ASB020SG@SOIC8
[(SA602A)]	
Z8F081ASH005EC@SOIC20 [(SA404)]	Z8F081ASH005EG@SOIC20
[(SA404)]	
Z8F081ASH005SC@SOIC20 [(SA404)]	Z8F081ASH005SG@SOIC20
[(SA404)]	
Z8F081ASJ020EC@SOIC28 [(SA404)]	Z8F081ASJ020EG@SOIC28
[(SA404)]	
Z8F081ASJ020SC@SOIC28 [(SA404)]	Z8F081ASJ020SG@SOIC28
[(SA404)]	
Z8F0821HH020EC@SSOP20 [(SA626A)]	Z8F0821HH020EG@SSOP20
[(SA626A)]	
Z8F0821HH020SC@SSOP20 [(SA626A)]	Z8F0821HH020SG@SSOP20
[(SA626A)]	
Z8F0821PH020EC	
Z8F0821PH020EG	
Z8F0821PH020SC	
Z8F0821PH020SG	
Z8F0822PJ020EC	
Z8F0822PJ020EG	
Z8F0822PJ020SC	
Z8F0822PJ020SG	
Z8F0822SJ020EC@SOIC28 [(SA404)]	Z8F0822SJ020EG@SOIC28

[(SA404)]		
Z8F0822SJ020SC@SOIC28 [(SA404)]		Z8F0822SJ020SG@SOIC28
[(SA404)]		
Z8F0823HH005EC@SSOP20 [(SA626A)]		Z8F0823HH005EG@SSOP20
[(SA626A)]		
Z8F0823HH005SC@SSOP20 [(SA626A)]		Z8F0823HH005SG@SSOP20
[(SA626A)]		
Z8F0823HJ020EC@SSOP28 [(SA626A)]		Z8F0823HJ020EG@SSOP28
[(SA626A)]		
Z8F0823HJ020SC@SSOP28 [(SA626A)]		Z8F0823HJ020SG@SSOP28
[(SA626A)]		
Z8F0823PB005EC		
Z8F0823PB005EG		
Z8F0823PB005SC		
Z8F0823PB005SG		
Z8F0823PH005EC		
Z8F0823PH005EG		
Z8F0823PH005SC		
Z8F0823PH005SG		
Z8F0823PJ020EC		
Z8F0823PJ020EG		
Z8F0823PJ020SC		
Z8F0823PJ020SG		
Z8F0823QB005EC@QFN8 [(SA683)]		Z8F0823QB005EG@QFN8
[(SA683)]		
Z8F0823QB005SC@QFN8 [(SA683)]		Z8F0823QB005SG@QFN8
[(SA683)]		
Z8F0823SB005EC@SOIC8 [(SA602A)]		Z8F0823SB005EG@SOIC8
[(SA602A)]		
Z8F0823SB005SC@SOIC8 [(SA602A)]		Z8F0823SB005SG@SOIC8
[(SA602A)]		
Z8F0823SH005EC@SOIC20 [(SA404)]		Z8F0823SH005EG@SOIC20
[(SA404)]		
Z8F0823SH005SC@SOIC20 [(SA404)]		Z8F0823SH005SG@SOIC20
[(SA404)]		
Z8F0823SJ020EC@SOIC28 [(SA404)]		Z8F0823SJ020EG@SOIC28
[(SA404)]		
Z8F0823SJ020SC@SOIC28 [(SA404)]		Z8F0823SJ020SG@SOIC28
[(SA404)]		
Z8F082AHH005EC@SSOP20 [(SA626A)]		Z8F082AHH005EG@SSOP20
[(SA626A)]		
Z8F082AHH005SC@SSOP20 [(SA626A)]		Z8F082AHH005SG@SSOP20
[(SA626A)]		

Z8F082AHJ020EC@SSOP28 [(SA626A)]	Z8F082AHJ020EG@SSOP28
[(SA626A)]	
Z8F082AHJ020SC@SSOP28 [(SA626A)]	Z8F082AHJ020SG@SSOP28
[(SA626A)]	
Z8F082APB020EC	
Z8F082APB020EG	
Z8F082APB020SC	
Z8F082APB020SG	
Z8F082APH005EC	
Z8F082APH005EG	
Z8F082APH005SC	
Z8F082APH005SG	
Z8F082APJ020EC	
Z8F082APJ020EG	
Z8F082APJ020SC	
Z8F082APJ020SG	
Z8F082AQB020EC@QFN8 [(SA683)]	Z8F082AQB020EG@QFN8
[(SA683)]	
Z8F082AQB020SC@QFN8 [(SA683)]	Z8F082AQB020SG@QFN8
[(SA683)]	
Z8F082ASB020EC@SOIC8 [(SA602A)]	Z8F082ASB020EG@SOIC8
[(SA602A)]	
Z8F082ASB020SC@SOIC8 [(SA602A)]	Z8F082ASB020SG@SOIC8
[(SA602A)]	
Z8F082ASH005EC@SOIC20 [(SA404)]	Z8F082ASH005EG@SOIC20
[(SA404)]	
Z8F082ASH005SC@SOIC20 [(SA404)]	Z8F082ASH005SG@SOIC20
[(SA404)]	
Z8F082ASJ020EC@SOIC28 [(SA404)]	Z8F082ASJ020EG@SOIC28
[(SA404)]	
Z8F082ASJ020SC@SOIC28 [(SA404)]	Z8F082ASJ020SG@SOIC28
[(SA404)]	
Z8F0830HH020EG@SSOP20 [(SA626A)]	Z8F0830HH020SG@SSOP20
[(SA626A)]	
Z8F0830HJ020EG@SSOP28 [(SA626A)]	Z8F0830HJ020SG@SSOP28
[(SA626A)]	
Z8F0830PH020EG	
Z8F0830PH020SG	
Z8F0830PJ020EG	
Z8F0830PJ020SG	
Z8F0830QH020EG@QFN20 [(SA759)]	Z8F0830QH020SG@QFN20
[(SA759)]	
Z8F0830QJ020EG@QFN28 [(SA697)]	Z8F0830QJ020SG@QFN28

[(SA697)]
Z8F0830SH020EG@SOIC20 [(SA404)] Z8F0830SH020SG@SOIC20
[(SA404)]
Z8F0830SJ020EG@SOIC28 [(SA404)] Z8F0830SJ020SG@SOIC28
[(SA404)]
Z8F0831HH020EG@SSOP20 [(SA626A)] Z8F0831HH020SG@SSOP20
[(SA626A)]
Z8F0831HJ020EG@SSOP28 [(SA626A)] Z8F0831HJ020SG@SSOP28
[(SA626A)]
Z8F0831PH020EG
Z8F0831PH020SG
Z8F0831PJ020EG
Z8F0831PJ020SG
Z8F0831QH020EG@QFN20 [(SA759)] Z8F0831QH020SG@QFN20
[(SA759)]
Z8F0831QJ020EG@QFN28 [(SA697)] Z8F0831QJ020SG@QFN28
[(SA697)]
Z8F0831SH020EG@SOIC20 [(SA404)] Z8F0831SH020SG@SOIC20
[(SA404)]
Z8F0831SJ020EG@SOIC28 [(SA404)] Z8F0831SJ020SG@SOIC28
[(SA404)]
Z8F1232HH020EG@SSOP20 [(SA626A)] Z8F1232HH020SG@SSOP20
[(SA626A)]
Z8F1232HJ020EG@SSOP28 [(SA626A)] Z8F1232HJ020SG@SSOP28
[(SA626A)]
Z8F1232PH020EG
Z8F1232PH020SG
Z8F1232PJ020EG
Z8F1232PJ020SG
Z8F1232QH020EG@QFN20 [(SA759)] Z8F1232QH020SG@QFN20
[(SA759)]
Z8F1232QJ020EG@QFN28 [(SA697)] Z8F1232QJ020SG@QFN28
[(SA697)]
Z8F1232SH020EG@SOIC20 [(SA404)] Z8F1232SH020SG@SOIC20
[(SA404)]
Z8F1232SJ020EG@SOIC28 [(SA404)] Z8F1232SJ020SG@SOIC28
[(SA404)]
Z8F1233HH020EG@SSOP20 [(SA626A)] Z8F1233HH020SG@SSOP20
[(SA626A)]
Z8F1233HJ020EG@SSOP28 [(SA626A)] Z8F1233HJ020SG@SSOP28
[(SA626A)]
Z8F1233PH020EG
Z8F1233PH020SG

Z8F1233PJ020EG	
Z8F1233PJ020SG	
Z8F1233QH020EG@QFN20 [(SA759)]	Z8F1233QH020SG@QFN20
[(SA759)]	
Z8F1233QJ020EG@QFN28 [(SA697)]	Z8F1233QJ020SG@QFN28
[(SA697)]	
Z8F1233SH020EG@SOIC20 [(SA404)]	Z8F1233SH020SG@SOIC20
[(SA404)]	
Z8F1233SJ020EG@SOIC28 [(SA404)]	Z8F1233SJ020SG@SOIC28
[(SA404)]	
Z8F4801AN@TQFP44 [(SA245A)]	
Z8F4801PM	
Z8F4801VN@PLCC44 [(SA244)]	Z8F6401AN@TQFP44
[(SA245A)]	
Z8F6401PM	Z8F6401VN@PLCC44
[(SA244)]	
Z8F6421AN020EC@LQFP44 [(SA245A)]	Z8F6421AN020SC@LQFP44
[(SA245A)]	
Z8F6421PM020EC	
Z8F6421PM020SC	
Z8F6421VN020EC@PLCC44 [(SA244)]	Z8F6421VN020SC@PLCC44
[(SA244)]	
ZGP323HAH2004C@SSOP20 [(SA626A)]	ZGP323HAH2004G@SSOP20
[(SA626A)]	
ZGP323HAH2008C@SSOP20 [(SA626A)]	ZGP323HAH2008G@SSOP20
[(SA626A)]	
ZGP323HAH2016C@SSOP20 [(SA626A)]	ZGP323HAH2016G@SSOP20
[(SA626A)]	
ZGP323HAH2032C@SSOP20 [(SA626A)]	ZGP323HAH2032G@SSOP20
[(SA626A)]	
ZGP323HAH2804C@SSOP28 [(SA626A)]	ZGP323HAH2804G@SSOP28
[(SA626A)]	
ZGP323HAH2808C@SSOP28 [(SA626A)]	ZGP323HAH2808G@SSOP28
[(SA626A)]	
ZGP323HAH2816C@SSOP28 [(SA626A)]	ZGP323HAH2816G@SSOP28
[(SA626A)]	
ZGP323HAH2832C@SSOP28 [(SA626A)]	ZGP323HAH2832G@SSOP28
[(SA626A)]	
ZGP323HAH4804C@SSOP48 [(SA669)]	ZGP323HAH4804G@SSOP48
[(SA669)]	
ZGP323HAH4808C@SSOP48 [(SA669)]	ZGP323HAH4808G@SSOP48
[(SA669)]	
ZGP323HAH4816C@SSOP48 [(SA669)]	ZGP323HAH4816G@SSOP48

[(SA669)]

ZGP323HAH4832C@SSOP48 [(SA669)]

ZGP323HAH4832G@SSOP48

[(SA669)]

ZGP323HAP2004C

ZGP323HAP2004G

ZGP323HAP2008C

ZGP323HAP2008G

ZGP323HAP2016C

ZGP323HAP2016G

ZGP323HAP2032C

ZGP323HAP2032G

ZGP323HAP2804C

ZGP323HAP2804G

ZGP323HAP2808C

ZGP323HAP2808G

ZGP323HAP2816C

ZGP323HAP2816G

ZGP323HAP2832C

ZGP323HAP2832G

ZGP323HAP4004C

ZGP323HAP4004G

ZGP323HAP4008C

ZGP323HAP4008G

ZGP323HAP4016C

ZGP323HAP4016G

ZGP323HAP4032C

ZGP323HAP4032G

ZGP323HAS2004C@SOIC20 [(SA404)]

ZGP323HAS2004G@SOIC20

[(SA404)]

ZGP323HAS2008C@SOIC20 [(SA404)]

ZGP323HAS2008G@SOIC20

[(SA404)]

ZGP323HAS2016C@SOIC20 [(SA404)]

ZGP323HAS2016G@SOIC20

[(SA404)]

ZGP323HAS2032C@SOIC20 [(SA404)]

ZGP323HAS2032G@SOIC20

[(SA404)]

ZGP323HAS2804C@SOIC28 [(SA404)]

ZGP323HAS2804G@SOIC28

[(SA404)]

ZGP323HAS2808C@SOIC28 [(SA404)]

ZGP323HAS2808G@SOIC28

[(SA404)]

ZGP323HAS2816C@SOIC28 [(SA404)]

ZGP323HAS2816G@SOIC28

[(SA404)]

ZGP323HAS2832C@SOIC28 [(SA404)]

ZGP323HAS2832G@SOIC28

[(SA404)]

ZGP323HEH2004C@SSOP20 [(SA626A)]	ZGP323HEH2004G@SSOP20
[(SA626A)]	
ZGP323HEH2008C@SSOP20 [(SA626A)]	ZGP323HEH2008G@SSOP20
[(SA626A)]	
ZGP323HEH2016C@SSOP20 [(SA626A)]	ZGP323HEH2016G@SSOP20
[(SA626A)]	
ZGP323HEH2032C@SSOP20 [(SA626A)]	ZGP323HEH2032G@SSOP20
[(SA626A)]	
ZGP323HEH2804C@SSOP28 [(SA626A)]	ZGP323HEH2804G@SSOP28
[(SA626A)]	
ZGP323HEH2808C@SSOP28 [(SA626A)]	ZGP323HEH2808G@SSOP28
[(SA626A)]	
ZGP323HEH2816C@SSOP28 [(SA626A)]	ZGP323HEH2816G@SSOP28
[(SA626A)]	
ZGP323HEH2832C@SSOP28 [(SA626A)]	ZGP323HEH2832G@SSOP28
[(SA626A)]	
ZGP323HEH4804C@SSOP48 [(SA669)]	ZGP323HEH4804G@SSOP48
[(SA669)]	
ZGP323HEH4808C@SSOP48 [(SA669)]	ZGP323HEH4808G@SSOP48
[(SA669)]	
ZGP323HEH4816C@SSOP48 [(SA669)]	ZGP323HEH4816G@SSOP48
[(SA669)]	
ZGP323HEH4832C@SSOP48 [(SA669)]	ZGP323HEH4832G@SSOP48
[(SA669)]	
ZGP323HEP2004C	
ZGP323HEP2004G	
ZGP323HEP2008C	
ZGP323HEP2008G	
ZGP323HEP2016C	
ZGP323HEP2016G	
ZGP323HEP2032C	
ZGP323HEP2032G	
ZGP323HEP2804C	
ZGP323HEP2804G	
ZGP323HEP2808C	
ZGP323HEP2808G	
ZGP323HEP2816C	
ZGP323HEP2816G	
ZGP323HEP2832C	
ZGP323HEP2832G	
ZGP323HEP4004C	
ZGP323HEP4004G	
ZGP323HEP4008C	

ZGP323HEP4008G
ZGP323HEP4016C
ZGP323HEP4016G
ZGP323HEP4032C
ZGP323HEP4032G
ZGP323HES2004C@SOIC20 [(SA404)] ZGP323HES2004G@SOIC20
[(SA404)]
ZGP323HES2008C@SOIC20 [(SA404)] ZGP323HES2008G@SOIC20
[(SA404)]
ZGP323HES2016C@SOIC20 [(SA404)] ZGP323HES2016G@SOIC20
[(SA404)]
ZGP323HES2032C@SOIC20 [(SA404)] ZGP323HES2032G@SOIC20
[(SA404)]
ZGP323HES2804C@SOIC28 [(SA404)] ZGP323HES2804G@SOIC28
[(SA404)]
ZGP323HES2808C@SOIC28 [(SA404)] ZGP323HES2808G@SOIC28
[(SA404)]
ZGP323HES2816C@SOIC28 [(SA404)] ZGP323HES2816G@SOIC28
[(SA404)]
ZGP323HES2832C@SOIC28 [(SA404)] ZGP323HES2832G@SOIC28
[(SA404)]
ZGP323HSH2004C@SSOP20 [(SA626A)] ZGP323HSH2004G@SSOP20
[(SA626A)]
ZGP323HSH2008C@SSOP20 [(SA626A)] ZGP323HSH2008G@SSOP20
[(SA626A)]
ZGP323HSH2016C@SSOP20 [(SA626A)] ZGP323HSH2016G@SSOP20
[(SA626A)]
ZGP323HSH2032C@SSOP20 [(SA626A)] ZGP323HSH2032G@SSOP20
[(SA626A)]
ZGP323HSH2804C@SSOP28 [(SA626A)] ZGP323HSH2804G@SSOP28
[(SA626A)]
ZGP323HSH2808C@SSOP28 [(SA626A)] ZGP323HSH2808G@SSOP28
[(SA626A)]
ZGP323HSH2816C@SSOP28 [(SA626A)] ZGP323HSH2816G@SSOP28
[(SA626A)]
ZGP323HSH2832C@SSOP28 [(SA626A)] ZGP323HSH2832G@SSOP28
[(SA626A)]
ZGP323HSH4804C@SSOP48 [(SA669)] ZGP323HSH4804G@SSOP48
[(SA669)]
ZGP323HSH4808C@SSOP48 [(SA669)] ZGP323HSH4808G@SSOP48
[(SA669)]
ZGP323HSH4816C@SSOP48 [(SA669)] ZGP323HSH4816G@SSOP48
[(SA669)]

ZGP323HSH4832C@SSOP48 [(SA669)]	ZGP323HSH4832G@SSOP48
[(SA669)]	
ZGP323HSP2004C	
ZGP323HSP2004G	
ZGP323HSP2008C	
ZGP323HSP2008G	
ZGP323HSP2016C	
ZGP323HSP2016G	
ZGP323HSP2032C	
ZGP323HSP2032G	
ZGP323HSP2804C	
ZGP323HSP2804G	
ZGP323HSP2808C	
ZGP323HSP2808G	
ZGP323HSP2816C	
ZGP323HSP2816G	
ZGP323HSP2832C	
ZGP323HSP2832G	
ZGP323HSP4004C	
ZGP323HSP4004G	
ZGP323HSP4008C	
ZGP323HSP4008G	
ZGP323HSP4016C	
ZGP323HSP4016G	
ZGP323HSP4032C	
ZGP323HSP4032G	
ZGP323HSS2004C@SOIC20 [(SA404)]	ZGP323HSS2004G@SOIC20
[(SA404)]	
ZGP323HSS2008C@SOIC20 [(SA404)]	ZGP323HSS2008G@SOIC20
[(SA404)]	
ZGP323HSS2016C@SOIC20 [(SA404)]	ZGP323HSS2016G@SOIC20
[(SA404)]	
ZGP323HSS2032C@SOIC20 [(SA404)]	ZGP323HSS2032G@SOIC20
[(SA404)]	
ZGP323HSS2804C@SOIC28 [(SA404)]	ZGP323HSS2804G@SOIC28
[(SA404)]	
ZGP323HSS2808C@SOIC28 [(SA404)]	ZGP323HSS2808G@SOIC28
[(SA404)]	
ZGP323HSS2816C@SOIC28 [(SA404)]	ZGP323HSS2816G@SOIC28
[(SA404)]	
ZGP323HSS2832C@SOIC28 [(SA404)]	ZGP323HSS2832G@SOIC28
[(SA404)]	
ZGP323LAH2004C@SSOP20 [(SA626A)]	ZGP323LAH2004G@SSOP20

[(SA626A)]
ZGP323LAH2008C@SSOP20 [(SA626A)] ZGP323LAH2008G@SSOP20
[(SA626A)]
ZGP323LAH2016C@SSOP20 [(SA626A)] ZGP323LAH2016G@SSOP20
[(SA626A)]
ZGP323LAH2032C@SSOP20 [(SA626A)] ZGP323LAH2032G@SSOP20
[(SA626A)]
ZGP323LAH2804C@SSOP28 [(SA626A)] ZGP323LAH2804G@SSOP28
[(SA626A)]
ZGP323LAH2808C@SSOP28 [(SA626A)] ZGP323LAH2808G@SSOP28
[(SA626A)]
ZGP323LAH2816C@SSOP28 [(SA626A)] ZGP323LAH2816G@SSOP28
[(SA626A)]
ZGP323LAH2832C@SSOP28 [(SA626A)] ZGP323LAH2832G@SSOP28
[(SA626A)]
ZGP323LAH4804C@SSOP48 [(SA669)] ZGP323LAH4804G@SSOP48
[(SA669)]
ZGP323LAH4808C@SSOP48 [(SA669)] ZGP323LAH4808G@SSOP48
[(SA669)]
ZGP323LAH4816C@SSOP48 [(SA669)] ZGP323LAH4816G@SSOP48
[(SA669)]
ZGP323LAH4832C@SSOP48 [(SA669)] ZGP323LAH4832G@SSOP48
[(SA669)]
ZGP323LAP2004C
ZGP323LAP2004G
ZGP323LAP2008C
ZGP323LAP2008G
ZGP323LAP2016C
ZGP323LAP2016G
ZGP323LAP2032C
ZGP323LAP2032G
ZGP323LAP2804C
ZGP323LAP2804G
ZGP323LAP2808C
ZGP323LAP2808G
ZGP323LAP2816C
ZGP323LAP2816G
ZGP323LAP2832C
ZGP323LAP2832G
ZGP323LAP4004C
ZGP323LAP4004G
ZGP323LAP4008C
ZGP323LAP4008G

ZGP323LAP4016C
ZGP323LAP4016G
ZGP323LAP4032C
ZGP323LAP4032G
ZGP323LAS2004C@SOIC20 [(SA404)] ZGP323LAS2004G@SOIC20
[(SA404)]
ZGP323LAS2008C@SOIC20 [(SA404)] ZGP323LAS2008G@SOIC20
[(SA404)]
ZGP323LAS2016C@SOIC20 [(SA404)] ZGP323LAS2016G@SOIC20
[(SA404)]
ZGP323LAS2032C@SOIC20 [(SA404)] ZGP323LAS2032G@SOIC20
[(SA404)]
ZGP323LAS2804C@SOIC28 [(SA404)] ZGP323LAS2804G@SOIC28
[(SA404)]
ZGP323LAS2808C@SOIC28 [(SA404)] ZGP323LAS2808G@SOIC28
[(SA404)]
ZGP323LAS2816C@SOIC28 [(SA404)] ZGP323LAS2816G@SOIC28
[(SA404)]
ZGP323LAS2832C@SOIC28 [(SA404)] ZGP323LAS2832G@SOIC28
[(SA404)]
ZGP323LEH2004C@SSOP20 [(SA626A)] ZGP323LEH2004G@SSOP20
[(SA626A)]
ZGP323LEH2008C@SSOP20 [(SA626A)] ZGP323LEH2008G@SSOP20
[(SA626A)]
ZGP323LEH2016C@SSOP20 [(SA626A)] ZGP323LEH2016G@SSOP20
[(SA626A)]
ZGP323LEH2032C@SSOP20 [(SA626A)] ZGP323LEH2032G@SSOP20
[(SA626A)]
ZGP323LEH2804C@SSOP28 [(SA626A)] ZGP323LEH2804G@SSOP28
[(SA626A)]
ZGP323LEH2808C@SSOP28 [(SA626A)] ZGP323LEH2808G@SSOP28
[(SA626A)]
ZGP323LEH2816C@SSOP28 [(SA626A)] ZGP323LEH2816G@SSOP28
[(SA626A)]
ZGP323LEH2832C@SSOP28 [(SA626A)] ZGP323LEH2832G@SSOP28
[(SA626A)]
ZGP323LEH4804C@SSOP48 [(SA669)] ZGP323LEH4804G@SSOP48
[(SA669)]
ZGP323LEH4808C@SSOP48 [(SA669)] ZGP323LEH4808G@SSOP48
[(SA669)]
ZGP323LEH4816C@SSOP48 [(SA669)] ZGP323LEH4816G@SSOP48
[(SA669)]
ZGP323LEH4832C@SSOP48 [(SA669)] ZGP323LEH4832G@SSOP48

[(SA669)]

ZGP323LEP2004C

ZGP323LEP2004G

ZGP323LEP2008C

ZGP323LEP2008G

ZGP323LEP2016C

ZGP323LEP2016G

ZGP323LEP2032C

ZGP323LEP2032G

ZGP323LEP2804C

ZGP323LEP2804G

ZGP323LEP2808C

ZGP323LEP2808G

ZGP323LEP2816C

ZGP323LEP2816G

ZGP323LEP2832C

ZGP323LEP2832G

ZGP323LEP4004C

ZGP323LEP4004G

ZGP323LEP4008C

ZGP323LEP4008G

ZGP323LEP4016C

ZGP323LEP4016G

ZGP323LEP4032C

ZGP323LEP4032G

ZGP323LES2004C@SOIC20 [(SA404)]

ZGP323LES2004G@SOIC20

[(SA404)]

ZGP323LES2008C@SOIC20 [(SA404)]

ZGP323LES2008G@SOIC20

[(SA404)]

ZGP323LES2016C@SOIC20 [(SA404)]

ZGP323LES2016G@SOIC20

[(SA404)]

ZGP323LES2032C@SOIC20 [(SA404)]

ZGP323LES2032G@SOIC20

[(SA404)]

ZGP323LES2804C@SOIC28 [(SA404)]

ZGP323LES2804G@SOIC28

[(SA404)]

ZGP323LES2808C@SOIC28 [(SA404)]

ZGP323LES2808G@SOIC28

[(SA404)]

ZGP323LES2816C@SOIC28 [(SA404)]

ZGP323LES2816G@SOIC28

[(SA404)]

ZGP323LES2832C@SOIC28 [(SA404)]

ZGP323LES2832G@SOIC28

[(SA404)]

ZGP323LSH2004C@SSOP20 [(SA626A)]

ZGP323LSH2004G@SSOP20

[(SA626A)]

ZGP323LSH2008C@SSOP20 [(SA626A)]	ZGP323LSH2008G@SSOP20
[(SA626A)]	
ZGP323LSH2016C@SSOP20 [(SA626A)]	ZGP323LSH2016G@SSOP20
[(SA626A)]	
ZGP323LSH2032C@SSOP20 [(SA626A)]	ZGP323LSH2032G@SSOP20
[(SA626A)]	
ZGP323LSH2804C@SSOP28 [(SA626A)]	ZGP323LSH2804G@SSOP28
[(SA626A)]	
ZGP323LSH2808C@SSOP28 [(SA626A)]	ZGP323LSH2808G@SSOP28
[(SA626A)]	
ZGP323LSH2816C@SSOP28 [(SA626A)]	ZGP323LSH2816G@SSOP28
[(SA626A)]	
ZGP323LSH2832C@SSOP28 [(SA626A)]	ZGP323LSH2832G@SSOP28
[(SA626A)]	
ZGP323LSH4804C@SSOP48 [(SA669)]	ZGP323LSH4804G@SSOP48
[(SA669)]	
ZGP323LSH4808C@SSOP48 [(SA669)]	ZGP323LSH4808G@SSOP48
[(SA669)]	
ZGP323LSH4816C@SSOP48 [(SA669)]	ZGP323LSH4816G@SSOP48
[(SA669)]	
ZGP323LSH4832C@SSOP48 [(SA669)]	ZGP323LSH4832G@SSOP48
[(SA669)]	
ZGP323LSK2032E	
ZGP323LSK2032G	
ZGP323LSK2832E	
ZGP323LSK2832G	
ZGP323LSK4032E	
ZGP323LSK4032G	
ZGP323LSP2004C	
ZGP323LSP2004G	
ZGP323LSP2008C	
ZGP323LSP2008G	
ZGP323LSP2016C	
ZGP323LSP2016G	
ZGP323LSP2032C	
ZGP323LSP2032G	
ZGP323LSP2804C	
ZGP323LSP2804G	
ZGP323LSP2808C	
ZGP323LSP2808G	
ZGP323LSP2816C	
ZGP323LSP2816G	
ZGP323LSP2832C	

ZGP323LSP2832G
ZGP323LSP4004C
ZGP323LSP4004G
ZGP323LSP4008C
ZGP323LSP4008G
ZGP323LSP4016C
ZGP323LSP4016G
ZGP323LSP4032C
ZGP323LSP4032G

ZGP323LSS2004C@SOIC20 [(SA404)]
[(SA404)]

ZGP323LSS2004G@SOIC20

ZGP323LSS2008C@SOIC20 [(SA404)]
[(SA404)]

ZGP323LSS2008G@SOIC20

ZGP323LSS2016C@SOIC20 [(SA404)]
[(SA404)]

ZGP323LSS2016G@SOIC20

ZGP323LSS2032C@SOIC20 [(SA404)]
[(SA404)]

ZGP323LSS2032G@SOIC20

ZGP323LSS2804C@SOIC28 [(SA404)]
[(SA404)]

ZGP323LSS2804G@SOIC28

ZGP323LSS2808C@SOIC28 [(SA404)]
[(SA404)]

ZGP323LSS2808G@SOIC28

ZGP323LSS2816C@SOIC28 [(SA404)]
[(SA404)]

ZGP323LSS2816G@SOIC28

ZGP323LSS2832C@SOIC28 [(SA404)]
[(SA404)]

ZGP323LSS2832G@SOIC28

ZLP12840H2028C@SSOP20 [(SA626A)]
[(SA626A)]

ZLP12840H2028G@SSOP20

ZLP12840H2032C@SSOP20 [(SA626A)]
[(SA626A)]

ZLP12840H2032G@SSOP20

ZLP12840H2064C@SSOP20 [(SA626A)]
[(SA626A)]

ZLP12840H2064G@SSOP20

ZLP12840H2096C@SSOP20 [(SA626A)]
[(SA626A)]

ZLP12840H2096G@SSOP20

ZLP12840H2828C@SSOP28 [(SA626A)]
[(SA626A)]

ZLP12840H2828G@SSOP28

ZLP12840H2832C@SSOP28 [(SA626A)]
[(SA626A)]

ZLP12840H2832G@SSOP28

ZLP12840H2864C@SSOP28 [(SA626A)]
[(SA626A)]

ZLP12840H2864G@SSOP28

ZLP12840H2896C@SSOP28 [(SA626A)]
[(SA626A)]

ZLP12840H2896G@SSOP28

ZLP12840P2028C

ZLP12840P2028G

ZLP12840P2032C
ZLP12840P2032G
ZLP12840P2064C
ZLP12840P2064G
ZLP12840P2096C
ZLP12840P2096G
ZLP12840P2828C
ZLP12840P2828G
ZLP12840P2832C
ZLP12840P2832G
ZLP12840P2864C
ZLP12840P2864G
ZLP12840P2896C
ZLP12840P2896G

ZLP12840S2028C@SOIC20 [(SA404)]
[(SA404)]
ZLP12840S2032C@SOIC20 [(SA404)]
[(SA404)]
ZLP12840S2064C@SOIC20 [(SA404)]
[(SA404)]
ZLP12840S2096C@SOIC20 [(SA404)]
[(SA404)]
ZLP12840S2828C@SOIC28 [(SA404)]
[(SA404)]
ZLP12840S2832C@SOIC28 [(SA404)]
[(SA404)]
ZLP12840S2864C@SOIC28 [(SA404)]
[(SA404)]
ZLP12840S2896C@SOIC28 [(SA404)]
[(SA404)]
ZLP32300H2004C@SSOP20 [(SA626A)]
[(SA626A)]
ZLP32300H2008C@SSOP20 [(SA626A)]
[(SA626A)]
ZLP32300H2016C@SSOP20 [(SA626A)]
[(SA626A)]
ZLP32300H2032C@SSOP20 [(SA626A)]
[(SA626A)]
ZLP32300H2804C@SSOP28 [(SA626A)]
[(SA626A)]
ZLP32300H2808C@SSOP28 [(SA626A)]
[(SA626A)]
ZLP32300H2816C@SSOP28 [(SA626A)]

ZLP12840S2028G@SOIC20
ZLP12840S2032G@SOIC20
ZLP12840S2064G@SOIC20
ZLP12840S2096G@SOIC20
ZLP12840S2828G@SOIC28
ZLP12840S2832G@SOIC28
ZLP12840S2864G@SOIC28
ZLP12840S2896G@SOIC28
ZLP32300H2004G@SSOP20
ZLP32300H2008G@SSOP20
ZLP32300H2016G@SSOP20
ZLP32300H2032G@SSOP20
ZLP32300H2804G@SSOP28
ZLP32300H2808G@SSOP28
ZLP32300H2816G@SSOP28

[(SA626A)]
ZLP32300H2832C@SSOP28 [(SA626A)] ZLP32300H2832G@SSOP28
[(SA626A)]
ZLP32300H4804C@SSOP48 [(SA669)] ZLP32300H4804G@SSOP48
[(SA669)]
ZLP32300H4808C@SSOP48 [(SA669)] ZLP32300H4808G@SSOP48
[(SA669)]
ZLP32300H4816C@SSOP48 [(SA669)] ZLP32300H4816G@SSOP48
[(SA669)]
ZLP32300H4832C@SSOP48 [(SA669)] ZLP32300H4832G@SSOP48
[(SA669)]
ZLP32300P2004C
ZLP32300P2004G
ZLP32300P2008C
ZLP32300P2008G
ZLP32300P2016C
ZLP32300P2016G
ZLP32300P2032C
ZLP32300P2032G
ZLP32300P2804C
ZLP32300P2804G
ZLP32300P2808C
ZLP32300P2808G
ZLP32300P2816C
ZLP32300P2816G
ZLP32300P2832C
ZLP32300P2832G
ZLP32300P4004C
ZLP32300P4004G
ZLP32300P4008C
ZLP32300P4008G
ZLP32300P4016C
ZLP32300P4016G
ZLP32300P4032C
ZLP32300P4032G
ZLP32300S2004C@SOIC20 [(SA404)] ZLP32300S2004G@SOIC20
[(SA404)]
ZLP32300S2008C@SOIC20 [(SA404)] ZLP32300S2008G@SOIC20
[(SA404)]
ZLP32300S2016C@SOIC20 [(SA404)] ZLP32300S2016G@SOIC20
[(SA404)]
ZLP32300S2032C@SOIC20 [(SA404)] ZLP32300S2032G@SOIC20
[(SA404)]

ZLP32300S2804C@SOIC28 [(SA404)]	ZLP32300S2804G@SOIC28
[(SA404)]	
ZLP32300S2808C@SOIC28 [(SA404)]	ZLP32300S2808G@SOIC28
[(SA404)]	
ZLP32300S2816C@SOIC28 [(SA404)]	ZLP32300S2816G@SOIC28
[(SA404)]	
ZLP32300S2832C@SOIC28 [(SA404)]	ZLP32300S2832G@SOIC28
[(SA404)]	

ZMD

E (E) PROM/FRAM/NVRAM

U62256	
U6264	
U6264@SOIC28 [(SA630)]	
U6264A	
U6264A@SOIC28 [(SA630)]	U62H256A@SOIC28
[(SA630)]	
U62H256S@SOIC28 [(SA630)]	U62H64SA@SOIC28
[(SA630)]	
U630H16	U630H16@SOIC28
[(SA630)]	
U630H64	U630H64@SOIC28
[(SA630)]	
U631H16	U631H16@SOIC24
[(SA404)]	
U631H16@SOIC28 [(SA630)]	
U631H256	
U631H256@SOIC28 [(SA630)]	
U631H64	
U631H64@SOIC28 [(SA630)]	
U632H16	
U632H16@SOIC28 [(SA630)]	
U632H64	
U632H64@SOIC28 [(SA630)]	
U634H256	
U634H256@SOIC32 [(SA630)]	
U635H16	
U635H16@SOIC24 [(SA404)]	
U635H256	
U635H256@SOIC28 [(SA630)]	

U635H64

U635H64@SOIC28 [(SA630)]

U63716

U637256

U63764

U637H256

UL62H256A@SOIC28

[(SA630)]

UL631H256@SOIC28 [(SA630)]

UL631H256@TSOP32

[(SA410T)]

UL634H256@SOIC32 [(SA630)]

UL634H256@TSOP32

[(SA410T)]

UL635H256@SOIC28 [(SA630)]

UL635H256@TSOP32

[(SA410T)]