

HOT AIR GUN

ZD-509

SAFETY OPERATION EXPLAIN

1. Please connect limited power as per signed voltage on the brand tool.
2. Forbid to use when any outside screwdriver is lost. If outside screwdriver is moved, please change them first, and keep the accessory integrity anytime.
3. It must hold the tool when using the tool in the high.
4. Don't put the tool down before stop to run.

Hot Air Gun safety defend:

1. Don't use hot air gun as hair drier.
2. Don't use hot air gun straightly face the people and animals.
3. Don't use hot air gun beside the tinder and gas.
4. Don't backup or cover mouth where hot gas canes out.
5. When using hot air gun or just after using it, do not touch handle of muzzle hot air gun, it must keep dry, clean and for away from oil articles and gas.
6. Don't use hot air gun in the rain or dankly place.
7. Don't put anything into hot muzzle.
8. Hot air gun can be reserved after cooling.

SPECIFICATION:

INPUT POWER: LOW :800W HIGH :1500W
TEMPERATURE: LOW :50-200°C HIGH :200-500°C
WIND MEASURE: 450L/min

OPERATION WAY:

Please know the operation way well before use.

The way to use hot air gun:

This product is very light and easy to use.

Adjust temperature switches control the temperature.

Please put the controlled switches off before the plug push out from the socket.

When you begin to operate, please wait for one minute, if the adjust temperature the heat you need.

This hot air gun attach stand.

Note:

1. Do not use the hot air gun together with the chemical (plastic) drawknife.
2. Please clean off the dry oil paint in the muzzle or drawknife after using hot air gun.
3. Please use in the fresh air, because the oil paint's draffy is poisonous.
4. Please confirm the temperature has been cooling completely when the hot air gun is stocked.
5. Do not connect the power when the hot air gun is not used.

WARMING

Check all extended insulation wire, please change wire immediately if attained.

Do not use the attained insulation wire, because it maybe harmed the health if touching them.

