3-1/2D LCD Digital Panel Meter PM-428/PM-438

1. FEATURES

200mV full scale input sensitivity

Single 9V DC operation

Decimal Point selectable

13mm LCD figure height

Automatic Polarity Indication

Guaranteed zero reading for 0 volts input

High input impedance (>100 Mohm)

2. APPLICATIONS

Voltmeter Current Meter

Thermometer Capacitance Meter

PH Meter Lux Meter

dB Meter LCR meter

Watt Meter Other Industrial &

Domestic Uses

3. SPECIFICATIONS

Maximum Input: 199.9mV DC

Maximum Display: 1999 counts (3-1/2 Digit) with

automatic polarity indication

Indication Method: LCD display

Measuring Method: Dual-Slope Integration A/D

converter system

Overrange Indication: "1" shown in the display Reading rate time: 2-3 readings per sec.

Reading rate time: 2-3 readings per sec.
Input Imepdance: >100 Mohms

Accuracy: $\pm 0.5\%$ (23° ± 5 °C, <80% RH)


Power Dissipation: 1 mA DC

Decimal Point: Selectable with wire jumper

Supply Voltage: 8-12V DC

Size: 68mm x 44mm

4. PANEL HOLE FOR FIXING PM-428/PM-438



5. OPERATION:


A) If needed, added proper voltage dividers (not included) and decimal point wire jumper:

Max. Voltage to be measured	Proper Voltage Divider	Decimal Point
200mV	are helght - acatem	Shortcircuit P3
20V	Disconnect wire jumper in RB. RB=9.9 Mohms RA=100 Kohms	Shortcircuit P2
200V	Disconnect wire jumper in RB. RB=9.99 Mohms RA=10 Kohms	Shortcircuit P3
500V	Disconnect wire jumper in RB. RB=9.999 Mohms RA=1 Kohm	PECHICAT

RA and RB are 1/2W 0.5% Metal Film Resistors.

- B) Connect an 8-12V DC power supply to panel meter.
- C) For ranges other than 200mV, input accurate 1/2 x Max Voltage generated by calibrator (e.g. 100.0V for 200.0V range) and carefully adjust semifixed resistor R2 to have the same reading in LCD.
- D) Connect the input voltage to be measured to Vin and GD. The input voltage should be DC only.

6. WIRING DIAGRAM:



8-12V DC

Input Signal to be measured